



SINOTRUCK Function List V1.12

Tips and Instructions:
* This feature is new.
✓ This feature is supported.
This feature is not supported.
※ This feature is partially supported.

Vehicle	System	System	System	System	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Actuation Test	Remarks
HOWO	Engine	Bosch common rail engine control module(EDC 17CV44/54)			✓	✓	✓	✓		
HOWO	Engine	Denso common rail engine control module			✓	✓	✓	✓	✓	1.Cut cylinder test 2.Fuel leak inspection function 3.Exhaust brake check 4.Oil pump learning 5.Total odometer and fuel usage cleared 6.QR code
HOWO	Engine	Hino P11C-type engine control module			✓	✓	✓	✓	✓	1.Target idle speed 2.Engine exhaust brake solenoid valve 3.Engine retarder 1 solenoid valve 4.Engine retarder 2 solenoid valve 5.Engine stop forced drive 6.PCV solenoid valve 1 forced to stop 7.PCV solenoid valve 2 forced to stop 8.Induction heating work 9.Fuel leakage check function 10.Turbo check 11.Throttle sensor adjustment 12.Adjust the PTO acceleration sensor 13.Cut cylinder test 14.QR Code
HOWO	Engine	EGR system			✓	✓	✓	✓	✓	1.Motor test 2.EGR test
HOWO	Aftertreatment	Tenneco DCU			✓	✓	✓	✓		
HOWO	Aftertreatment	Tenneco DCU (OBD)			✓	✓	✓	✓		