

## Ford Function List V10.31

**Notes:**

✓	Functions is fully supported and already existed in former software version.
*	Functions is fully supported and newly added in current software version.
#	Functions is partially supported , which means the functions is verified on some vehcile models or systems and it might supports other vehcle models or systems.
	Functions left with blank is not supported.

Year	Mode	Capacity	EngineType	Module	Read Codes	Erase Codes	Live Data	Active Test	Special Function
2005	(A1105)	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2005	(A1105)	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2005	(A1105)	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2005	(A1105)	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2005	(A1105)	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2005	(A1105)	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2005	(A1105)	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2005	(A1105)	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2005	(A1105)	3. 0L	4V	4X4	✓	✓	✓	✓	
2005	(A1105)	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2005	(A1105) Escape/Tribute/Maverick/Mariner	3. 0L	4V	GEM	✓	✓	✓	✓	F042, F04E, F04F, F050, F051, F056, F057, F058, F059
2005	(A1105) Escape/Tribute/Maverick/Mariner	3. 0L	4V	GEM	✓	✓	✓	✓	F042, F04E, F04F, F050, F051, F056, F057, F058, F059, F090
2005	(A1105) Escape/Tribute/Maverick/Mariner	3. 0L	4V	IC	✓	✓	✓	✓	0005, F040, F043, F04D, F052, F053, F054, F055
2005	(A1105)	3. 0L	4V	PAM	✓	✓	✓	✓	
2005	(A1105)	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 00C5
2005	(A1105)	3. 0L	4V	RCM	✓	✓	✓	✓	000C
1997	626 / 626 WAGON / TELSTAR	1. 8L	FP	PCM	✓	✓	✓	✓	0025
1997	626 / 626 WAGON / TELSTAR	2. 0L	FS	ABS	✓	✓	✓	✓	
1997	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	
1997	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	0025
1997	626 / 626 WAGON / TELSTAR	2. 0L	RF-T	PCM	✓	✓	✓	✓	
1997	626 / 626 WAGON / TELSTAR	2. 5L	KL	PCM	✓	✓	✓	✓	
1998	626 / 626 WAGON / TELSTAR	2. 0L	FS	ABS/TCS	✓	✓	✓	✓	
1998	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	0025
1998	626 / 626 WAGON / TELSTAR	2. 5L	KL	ABS/TCS	✓	✓	✓	✓	
1998	626 / 626 WAGON / TELSTAR	2. 5L	KL	PCM	✓	✓	✓	✓	0025
1999	626 / 626 WAGON / TELSTAR	1. 8L	FP	ABS	✓	✓	✓	✓	
1999	626 / 626 WAGON / TELSTAR	1. 8L	FP	PCM	✓	✓	✓	✓	
1999	626 / 626 WAGON / TELSTAR	2. 0L	FS	ABS	✓	✓	✓	✓	
1999	626 / 626 WAGON / TELSTAR	2. 0L	FS	ABS/TCS	✓	✓	✓	✓	
1999	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	
1999	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	0025
1999	626 / 626 WAGON / TELSTAR	2. 0L	RF-T	ABS	✓	✓	✓	✓	
1999	626 / 626 WAGON / TELSTAR	2. 0L	RF-T	PCM	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	1. 8L	FP	ABS/TCS	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	1. 8L	FP	PCM	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	2. 0L	FS	ABS/TCS	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	0025
2000	626 / 626 WAGON / TELSTAR	2. 0L	RF-T	ABS	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	2. 0L	RF-T	PCM	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	2. 5L	KL	ABS/TCS	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	2. 5L	KL	PCM	✓	✓	✓	✓	0025
2001	626 / 626 WAGON / TELSTAR	2. 0L	FS	ABS/TCS	✓	✓	✓	✓	
2001	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	0025
2001	626 / 626 WAGON / TELSTAR	2. 5L	KL	ABS/TCS	✓	✓	✓	✓	
2001	626 / 626 WAGON / TELSTAR	2. 5L	KL	PCM	✓	✓	✓	✓	0025
1996	AEROSTAR	3. 0L	Other	PCM	✓	✓	✓	✓	0025
1996	AEROSTAR	4. 0L	Other	PCM	✓	✓	✓	✓	0025
1997	AEROSTAR	3. 0L	Other	PCM	✓	✓	✓	✓	0025
1997	AEROSTAR	4. 0L	Other	PCM	✓	✓	✓	✓	0025
1996	Aspire	1. 3L	Other	PCM	✓	✓	✓	✓	
1997	Aspire	1. 3L	Other	PCM	✓	✓	✓	✓	
1997	Aspire	1. 5L	Other	PCM	✓	✓	✓	✓	0025
2003	Aviator	4. 6L	4V	4X4	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Aviator	4. 6L	4V	DCSM	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	DSM	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	EATC	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	IC	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	NAV	✓	✓	✓	✓	0016
2003	Aviator	4. 6L	4V	PAM	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Aviator	4. 6L	4V	PCSM	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	RCM	✓	✓	✓	✓	000C
2003	Aviator	4. 6L	4V	TPM	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	VAPS	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	VEMS	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	VSM	✓	✓	✓	✓	
2004	Aviator	4. 6L	4V	4X4	✓	✓	✓	✓	
2004	Aviator	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2004	Aviator	4. 6L	4V	DCSM	✓	✓	✓	✓	
2004	Aviator	4. 6L	4V	DSM	✓	✓	✓	✓	

2004	Aviator	4.6L	4V	EATC	✓	✓	✓	✓	
2004	Aviator	4.6L	4V	IC	✓	✓	✓	✓	
2004	Aviator	4.6L	4V	NAV	✓	✓	✓	✓	0016
2004	Aviator	4.6L	4V	PAM	✓	✓	✓	✓	
2004	Aviator	4.6L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Aviator	4.6L	4V	PCSM	✓	✓	✓	✓	
2004	Aviator	4.6L	4V	RCM	✓	✓	✓	✓	000C
2004	Aviator	4.6L	4V	TPM	✓	✓	✓	✓	
2004	Aviator	4.6L	4V	VAPS	✓	✓	✓	✓	
2004	Aviator	4.6L	4V	VSM	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	4X4	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2005	Aviator	4.6L	4V	DCSM	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	DSM	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	EATC	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	IC	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	NAV	✓	✓	✓	✓	0016
2005	Aviator	4.6L	4V	PAM	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Aviator	4.6L	4V	PCSM	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	RCM	✓	✓	✓	✓	000C
2005	Aviator	4.6L	4V	TPM	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	VAPS	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	VSM	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	ABS	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	FCDIM	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	IPC	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	PSCM	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	RFA	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	FCDIM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	IPC	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	PSCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	RFA	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	FCDIM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	

2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓		
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓		
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓		
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓		
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓		
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓		
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓		
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D7, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00FE, 0101, 0118
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00D7, 00DC
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00DC
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	APIM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	BCMii	✓	✓	✓	✓	00FE, 0101, 0118
2012.75	B-Max	1.4L	DURATEC 16V	DDM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	FCDIM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	FDSM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	GPSM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	GWM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	IPC	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	00BC
2012.75	B-Max	1.4L	DURATEC 16V	PDM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	PSCM	✓	✓	✓	✓	00D7, 00DC
2012.75	B-Max	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	00EF
2012.75	B-Max	1.4L	DURATEC 16V	RFA	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D7, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 00D9, 00DB, 00E8, 0119

2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	00FE, 0101, 0118
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	FDSM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	GPSM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	GWM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00BD
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00D7, 00DC
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00DC
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	APIM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	00FE, 0101, 0118
2012.75	B-Max	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	FCDIM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	FDSM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	GPSM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	GWM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	00BC
2012.75	B-Max	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	00D7, 00DC
2012.75	B-Max	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	00EF
2012.75	B-Max	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	TCM	✓	✓	✓	✓	0117
2012.75	B-Max	1.6L	TDCi ECO II	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D7, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.6L	TDCi ECO II	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.6L	TDCi ECO II	ACM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	APIM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	BCMii	✓	✓	✓	✓	00FE, 0101, 0118
2012.75	B-Max	1.6L	TDCi ECO II	DDM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	FCDIM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	FDSM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	GPSM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	GWM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	HVAC	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	IPC	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00BD
2012.75	B-Max	1.6L	TDCi ECO II	PDM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	PSCM	✓	✓	✓	✓	00D7, 00DC
2012.75	B-Max	1.6L	TDCi ECO II	PSCM	✓	✓	✓	✓	00DC
2012.75	B-Max	1.6L	TDCi ECO II	RCM	✓	✓	✓	✓	00EF
2012.75	B-Max	1.6L	TDCi ECO II	RFA	✓	✓	✓	✓	
1996	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.2L	F2	PCM	✓	✓	✓	✓	
1996	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	PCM	✓	✓	✓	✓	
1999	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.2L	F2	PCM	✓	✓	✓	✓	
1999	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	ABS	✓	✓	✓	✓	
1999	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	PCM	✓	✓	✓	✓	
2001	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	ABS	✓	✓	✓	✓	
2001	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	PCM	✓	✓	✓	✓	

2001	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	ABS	✓	✓	✓	✓	
2001	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	PCM	✓	✓	✓	✓	
2002	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL	ABS	✓	✓	✓	✓	
2002	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	ABS	✓	✓	✓	✓	
2002	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 9L	W9	ABS	✓	✓	✓	✓	
2005	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	ABS	✓	✓	✓	✓	
2005	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	PCM	✓	✓	✓	✓	
2005	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	TCM	✓	✓	✓	✓	
Other	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 2L	F2	PCM	✓	✓	✓	✓	
1999	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	ABS	✓	✓	✓	✓	
1999	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	PCM	✓	✓	✓	✓	
1999	BONGO / BONGO BRAWNY / SPECTRON	2. 2L	R2	ABS	✓	✓	✓	✓	
1999	BONGO / BONGO BRAWNY / SPECTRON	2. 2L	R2	PCM	✓	✓	✓	✓	
2002	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	ABS/TCS	✓	✓	✓	✓	
2002	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	PCM	✓	✓	✓	✓	
2002	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	TCM	✓	✓	✓	✓	
2003	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	ABS/TCS	✓	✓	✓	✓	
2003	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	PCM	✓	✓	✓	✓	
2003	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	TCM	✓	✓	✓	✓	
2004	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	ABS/TCS	✓	✓	✓	✓	
2004	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	PCM	✓	✓	✓	✓	
2004	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	TCM	✓	✓	✓	✓	
2007	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	ABS/TCS	✓	✓	✓	✓	
2007	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	PCM	✓	✓	✓	✓	0055, 0056, 005C
2007	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	PCM	✓	✓	✓	✓	0055, 005C
2007	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	TCM	✓	✓	✓	✓	
2010	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	ABS	✓	✓	✓	✓	
2010	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	IC	✓	✓	✓	✓	
2010	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	PCM	✓	✓	✓	✓	
2010	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	TCM	✓	✓	✓	✓	
1997	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	ABS	✓	✓	✓	✓	
1997	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	PCM	✓	✓	✓	✓	
1998	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	ABS	✓	✓	✓	✓	
1998	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	PCM	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	1. 8L	F8	ABS	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	1. 8L	F8	PCM	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	ABS	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	PCM	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 2L	R2	ABS	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 2L	R2	PCM	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 5L	WL	ABS	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 5L	WL	PCM	✓	✓	✓	✓	
2002	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	ABS/TCS	✓	✓	✓	✓	
2002	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	PCM	✓	✓	✓	✓	
2002	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	TCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 2L	F2	ABS/TCS	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 2L	F2	PCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 2L	F2	RCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL	ABS/TCS	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL	PCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL	RCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL-CD	ABS/TCS	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL-CD	PCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL-CD	PCM	✓	✓	✓	✓	0055
2007	BT-50 / Ranger	2. 5L	WL-CD	RCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL-CD	TCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL-CD	TCM	✓	✓	✓	✓	00C5, 00CE
2007	BT-50 / Ranger	2. 6L	G6	ABS/TCS	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 6L	G6	PCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 6L	G6	RCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	3. 0L	WE-CD	ABS/TCS	✓	✓	✓	✓	
2007	BT-50 / Ranger	3. 0L	WE-CD	PCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	3. 0L	WE-CD	PCM	✓	✓	✓	✓	0055, 0092
2007	BT-50 / Ranger	3. 0L	WE-CD	RCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	3. 0L	WE-CD	TCM	✓	✓	✓	✓	

2007	BT-50 / Ranger	3.0L	WE-CD	TCM	✓	✓	✓	✓	00C5, 00CE
2007	BT-50 / Ranger	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2007	BT-50 / Ranger	4.0L	V6 SOHC	ESOF	✓	✓	✓	✓	
2007	BT-50 / Ranger	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2012	BT-50 / Ranger	2.5L	L5	PCM	✓	✓	✓	✓	
2001	Bantam	1.3L	Zetec Rocam	PCM	✓	✓	✓	✓	
2001	Bantam	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	
2006	Bantam	1.3L	Zetec Rocam	PCM	✓	✓	✓	✓	
2006	Bantam	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	
2009.25	Bantam	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2009.25	Bantam	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2009.25	Bantam	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	ABS/TCS	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	DSM	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	EATC	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	GEM	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	HEC	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	LTM	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	PAM	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	PCM	✓	✓	✓	✓	0025
2002	Blackwood	5.4L	4V	RAP	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	RASM	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	RCM	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	ABS/TCS	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	DSM	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	EATC	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	GEM	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	HEC	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	LTM	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	PAM	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	PCM	✓	✓	✓	✓	0025
2003	Blackwood	5.4L	4V	RAP	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	RASM	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	RCM	✓	✓	✓	✓	
2012	Blue Bird C-Class Vision	6.8L	3V	PCM	✓	✓	✓	✓	0067
1996	Bronco	5.0L	Other	PCM	✓	✓	✓	✓	0025
1996	Bronco	5.8L	Other	PCM	✓	✓	✓	✓	0025
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	ABS	✓	✓	✓	✓	0012, 010A
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	ACM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	APIM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	BCM#1	✓	✓	✓	✓	00D5
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	BECM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	DACM-C	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	DCDC	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	DDM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	FCDIM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	FCIM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	GPSM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	GWM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	HVAC	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	IPC	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	IPM-B	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	PAM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	PCM	✓	✓	✓	✓	0025, 0095
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	PDM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	PSCM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	RCM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	RFA	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	RGTM	✓	✓	✓	✓	013D

2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	SASM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	✓	✓	✓	✓	013C
2013	C-MAX	2.0L	PHEV	ABS	✓	✓	✓	✓	0012, 010A
2013	C-MAX	2.0L	PHEV	ACCM#2	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	ACM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	APIM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	BCM#1	✓	✓	✓	✓	00D5
2013	C-MAX	2.0L	PHEV	BECM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	DACM-C	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	DCDC	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	DDM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	FCDIM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	FCIM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	GFM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	GPSM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	GWM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	HVAC	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	IPC	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	IPM-B	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	OCSM	✓	✓	✓	✓	000C
2013	C-MAX	2.0L	PHEV	PAM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	PCM	✓	✓	✓	✓	0025
2013	C-MAX	2.0L	PHEV	PDM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	PSCM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	RCM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	RFA	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	RGTM	✓	✓	✓	✓	013D
2013	C-MAX	2.0L	PHEV	SASM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	SOBDM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	SOBDM-C	✓	✓	✓	✓	013C
2013	C-MAX	2.0L	PHEV	TCU#1	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	ABS	✓	✓	✓	✓	0012, 010A
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	ACM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	APIM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	BCM#1	✓	✓	✓	✓	00D5, 0101, 020F
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	BECM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	DACM-C	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	DCDC	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	DDM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	FCDIM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	FCIM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	GPSM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	GWM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	HVAC	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	IPC	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	IPM-B	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	PAM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	PCM	✓	✓	✓	✓	0025
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	PDM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	PSCM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	RCM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	RFA	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	RGTM	✓	✓	✓	✓	013D
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	SASM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	✓	✓	✓	✓	013C
2014	C-MAX	2.0L	PHEV	ABS	✓	✓	✓	✓	0012, 010A
2014	C-MAX	2.0L	PHEV	ACCM#2	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	ACM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	APIM	✓	✓	✓	✓	

2014	C-MAX	2.0L	PHEV	BCM#1	✓	✓	✓	✓	00D5, 0101, 020F
2014	C-MAX	2.0L	PHEV	BECM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	DACM-C	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	DCDC	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	DDM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	FCDIM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	FCIM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	GFM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	GPSM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	GWM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	HVAC	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	IPC	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	IPM-B	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	OCSM	✓	✓	✓	✓	000C
2014	C-MAX	2.0L	PHEV	PAM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	PCM	✓	✓	✓	✓	0025
2014	C-MAX	2.0L	PHEV	PDM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	PSCM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	RCM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	RFA	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	RGTM	✓	✓	✓	✓	013D
2014	C-MAX	2.0L	PHEV	SASM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	SOBDM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	SOBDM-C	✓	✓	✓	✓	013C
2014	C-MAX	2.0L	PHEV	TCU#1	✓	✓	✓	✓	
1997	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	1.8L	FP	PCM	✓	✓	✓	✓	
1997	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	FS	PCM	✓	✓	✓	✓	
1997	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	RF	PCM	✓	✓	✓	✓	
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	1.8L	FP	ABS	✓	✓	✓	✓	
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	1.8L	FP	PCM	✓	✓	✓	✓	
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	FS	ABS	✓	✓	✓	✓	
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	FS	PCM	✓	✓	✓	✓	
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.5L	KL	ABS	✓	✓	✓	✓	
2006	CF/LCF	4.5L	Direct Injection -	ABS	✓	✓	✓	✓	
2006	CF/LCF	4.5L	Direct Injection -	ABS	✓	✓	✓	✓	0008
2006	CF/LCF	4.5L	Direct Injection -	TCM	✓	✓	✓	✓	
2007	CF/LCF	4.5L	Direct Injection -	ABS	✓	✓	✓	✓	0008
2007	CF/LCF	4.5L	Direct Injection -	TCM	✓	✓	✓	✓	
2008	CF/LCF	4.5L	Direct Injection -	ABS	✓	✓	✓	✓	
2008	CF/LCF	4.5L	Direct Injection -	ABS	✓	✓	✓	✓	0008
2008	CF/LCF	4.5L	Direct Injection -	TCM	✓	✓	✓	✓	
2009	CF/LCF	4.5L	Direct Injection -	ABS	✓	✓	✓	✓	0008
2009	CF/LCF	4.5L	Direct Injection -	TCM	✓	✓	✓	✓	
2004	Cargo	7.3L	ECOTORQ	PCM	✓	✓	✓	✓	
2009	Cargo	Other	ISBe	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	Cargo	Other	ISCe	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	Cargo	Other	Mechanical	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Cargo	Other	ISBe	HEC	✓	✓	✓	✓	
2012	Cargo	Other	ISBe	RKE	✓	✓	✓	✓	
2012	Cargo	Other	ISBe	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3, 012F, 0130
2012	Cargo	Other	ISCe	HEC	✓	✓	✓	✓	
2012	Cargo	Other	ISCe	RKE	✓	✓	✓	✓	
2012	Cargo	Other	ISCe	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3, 012F, 0130
2012	Cargo	Other	Mechanical	HEC	✓	✓	✓	✓	
2012	Cargo	Other	Mechanical	RKE	✓	✓	✓	✓	
2012	Cargo	Other	Mechanical	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3, 012F, 0130
1995	Continental	4.6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1995	Continental	4.6L	4V	ACM	✓	✓	✓	✓	
1995	Continental	4.6L	4V	CPM	✓	✓	✓	✓	
1995	Continental	4.6L	4V	DDM	✓	✓	✓	✓	
1995	Continental	4.6L	4V	DSM	✓	✓	✓	✓	
1995	Continental	4.6L	4V	EATC	✓	✓	✓	✓	
1995	Continental	4.6L	4V	LCM	✓	✓	✓	✓	
1995	Continental	4.6L	4V	PCM	✓	✓	✓	✓	0025
1995	Continental	4.6L	4V	VDM	✓	✓	✓	✓	
1995	Continental	4.6L	4V	VIC	✓	✓	✓	✓	
1996	Continental	4.6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1996	Continental	4.6L	4V	ACM	✓	✓	✓	✓	
1996	Continental	4.6L	4V	CPM	✓	✓	✓	✓	
1996	Continental	4.6L	4V	DDM	✓	✓	✓	✓	
1996	Continental	4.6L	4V	DSM	✓	✓	✓	✓	
1996	Continental	4.6L	4V	EATC	✓	✓	✓	✓	
1996	Continental	4.6L	4V	IAB	✓	✓	✓	✓	
1996	Continental	4.6L	4V	LCM	✓	✓	✓	✓	
1996	Continental	4.6L	4V	PCM	✓	✓	✓	✓	0025
1996	Continental	4.6L	4V	RESCU	✓	✓	✓	✓	
1996	Continental	4.6L	4V	VDM	✓	✓	✓	✓	
1996	Continental	4.6L	4V	VIC	✓	✓	✓	✓	



1997	Continental	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1997	Continental	4. 6L	4V	ACM	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	CPM	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	DDM	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	DSM	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	EATC	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	IAB	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	LCM	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	PCM	✓	✓	✓	✓	0025
1997	Continental	4. 6L	4V	RESCU	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	VDM	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	VIC	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1998	Continental	4. 6L	4V	ACM	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	CPM	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	DDM	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	DSM	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	EATC	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	ECS	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	LCM	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	NGSC	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	PCM	✓	✓	✓	✓	0025
1998	Continental	4. 6L	4V	RESCU	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	VDM	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	VIC	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1999	Continental	4. 6L	4V	ACM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	CPM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	DDM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	DSM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	EATC	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	LCM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	NGSC	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	PCM	✓	✓	✓	✓	0025
1999	Continental	4. 6L	4V	RCM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	RESCU	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	VDM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	VIC	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2000	Continental	4. 6L	4V	ACM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	CPM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	DDM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	DSM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	EATC	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	LCM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	NGSC	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	PCM	✓	✓	✓	✓	0025
2000	Continental	4. 6L	4V	RCM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	RESCU	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	VDM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	VIC	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2002	Continental	4. 6L	4V	ACM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	CPM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	DDM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	DSM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	EATC	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	LCM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	NGSC	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	PCM	✓	✓	✓	✓	0025
2002	Continental	4. 6L	4V	RCM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	VDM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	VIC	✓	✓	✓	✓	
1996	Contour	2. 0L	GFP	ABS/TCS	✓	✓	✓	✓	
1996	Contour	2. 0L	GFP	PCM	✓	✓	✓	✓	0025
1996	Contour	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1996	Contour	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
1996	Contour	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1996	Contour	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1997	Contour	2. 0L	GFP	ABS/TCS	✓	✓	✓	✓	
1997	Contour	2. 0L	GFP	PCM	✓	✓	✓	✓	0025
1997	Contour	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1997	Contour	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
1997	Contour	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1997	Contour	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1998	Contour	2. 0L	GFP	ABS/TCS	✓	✓	✓	✓	
1998	Contour	2. 0L	GFP	ABS/TCS	✓	✓	✓	✓	0008
1998	Contour	2. 0L	GFP	CSM	✓	✓	✓	✓	
1998	Contour	2. 0L	GFP	PATS	✓	✓	✓	✓	
1998	Contour	2. 0L	GFP	PCM	✓	✓	✓	✓	
1998	Contour	2. 0L	GFP	PCM	✓	✓	✓	✓	0025
1998	Contour	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1998	Contour	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
1998	Contour	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1998	Contour	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1998	Contour	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
1998	Contour	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1998	Contour	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
1998	Contour	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	

1998	Contour	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
1998	Contour	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1998	Contour	2.5L	HO	ABS/TCS	✓	✓	✓	✓	
1998	Contour	2.5L	HO	ABS/TCS	✓	✓	✓	✓	0008
1998	Contour	2.5L	HO	CSM	✓	✓	✓	✓	
1998	Contour	2.5L	HO	PATS	✓	✓	✓	✓	
1998	Contour	2.5L	HO	PCM	✓	✓	✓	✓	
1998	Contour	2.5L	HO	PCM	✓	✓	✓	✓	0025
1999	Contour	2.0L	GFP	ABS/TCS	✓	✓	✓	✓	0008
1999	Contour	2.0L	GFP	CSM	✓	✓	✓	✓	
1999	Contour	2.0L	GFP	PCM	✓	✓	✓	✓	
1999	Contour	2.0L	GFP	RCM	✓	✓	✓	✓	
1999	Contour	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
1999	Contour	2.0L	Zetec	CSM	✓	✓	✓	✓	
1999	Contour	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
1999	Contour	2.0L	Zetec	RCM	✓	✓	✓	✓	
1999	Contour	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
1999	Contour	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1999	Contour	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1999	Contour	2.5L	Duratec-VE	RCM	✓	✓	✓	✓	
1999	Contour	2.5L	HO	ABS/TCS	✓	✓	✓	✓	0008
1999	Contour	2.5L	HO	CSM	✓	✓	✓	✓	
1999	Contour	2.5L	HO	PCM	✓	✓	✓	✓	
1999	Contour	2.5L	HO	PCM	✓	✓	✓	✓	0025
1999	Contour	2.5L	HO	RCM	✓	✓	✓	✓	
2000	Contour	2.0L	GFP	ABS/TCS	✓	✓	✓	✓	0008
2000	Contour	2.0L	GFP	CSM	✓	✓	✓	✓	
2000	Contour	2.0L	GFP	PCM	✓	✓	✓	✓	
2000	Contour	2.0L	GFP	RCM	✓	✓	✓	✓	
2000	Contour	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2000	Contour	2.0L	Zetec	CSM	✓	✓	✓	✓	
2000	Contour	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2000	Contour	2.0L	Zetec	RCM	✓	✓	✓	✓	
2000	Contour	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
2000	Contour	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
2000	Contour	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2000	Contour	2.5L	Duratec-VE	RCM	✓	✓	✓	✓	
2000	Contour	2.5L	HO	ABS/TCS	✓	✓	✓	✓	0008
2000	Contour	2.5L	HO	CSM	✓	✓	✓	✓	
2000	Contour	2.5L	HO	PCM	✓	✓	✓	✓	0008
2000	Contour	2.5L	HO	PCM	✓	✓	✓	✓	0025
2000	Contour	2.5L	HO	RCM	✓	✓	✓	✓	
1994	Cougar	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1994	Cougar	4.6L	2V	HEC	✓	✓	✓	✓	
1994	Cougar	4.6L	2V	PCM	✓	✓	✓	✓	0025
1995	Cougar	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1995	Cougar	4.6L	2V	HEC	✓	✓	✓	✓	
1995	Cougar	4.6L	2V	PCM	✓	✓	✓	✓	0025
1996	Cougar	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1996	Cougar	3.8L	Other	HEC	✓	✓	✓	✓	
1996	Cougar	3.8L	Other	PCM	✓	✓	✓	✓	0025
1996	Cougar	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1996	Cougar	4.6L	2V	HEC	✓	✓	✓	✓	
1996	Cougar	4.6L	2V	PCM	✓	✓	✓	✓	0025
1997	Cougar	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1997	Cougar	3.8L	Other	HEC	✓	✓	✓	✓	
1997	Cougar	3.8L	Other	PCM	✓	✓	✓	✓	0025
1997	Cougar	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1997	Cougar	4.6L	2V	HEC	✓	✓	✓	✓	
1997	Cougar	4.6L	2V	PCM	✓	✓	✓	✓	0025
1998.75	Cougar	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1998.75	Cougar	2.0L	Zetec	CSM	✓	✓	✓	✓	
1998.75	Cougar	2.0L	Zetec	HEC	✓	✓	✓	✓	
1998.75	Cougar	2.0L	Zetec	IAB	✓	✓	✓	✓	
1998.75	Cougar	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
1998.75	Cougar	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1998.75	Cougar	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1998.75	Cougar	2.5L	Duratec-VE	HEC	✓	✓	✓	✓	
1998.75	Cougar	2.5L	Duratec-VE	IAB	✓	✓	✓	✓	
1998.75	Cougar	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1999	Cougar	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
1999	Cougar	2.0L	Zetec	CSM	✓	✓	✓	✓	
1999	Cougar	2.0L	Zetec	HEC	✓	✓	✓	✓	
1999	Cougar	2.0L	Zetec	IAB	✓	✓	✓	✓	
1999	Cougar	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
1999	Cougar	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
1999	Cougar	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1999	Cougar	2.5L	Duratec-VE	HEC	✓	✓	✓	✓	
1999	Cougar	2.5L	Duratec-VE	IAB	✓	✓	✓	✓	
1999	Cougar	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1999.75	Cougar	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
1999.75	Cougar	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1999.75	Cougar	2.5L	Duratec-VE	HEC	✓	✓	✓	✓	
1999.75	Cougar	2.5L	Duratec-VE	IAB	✓	✓	✓	✓	
1999.75	Cougar	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2000	Cougar	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2000	Cougar	2.0L	Zetec	CSM	✓	✓	✓	✓	
2000	Cougar	2.0L	Zetec	HEC	✓	✓	✓	✓	
2000	Cougar	2.0L	Zetec	IAB	✓	✓	✓	✓	

2000	Cougar	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2000	Cougar	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
2000	Cougar	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
2000	Cougar	2.5L	Duratec-VE	HEC	✓	✓	✓	✓	
2000	Cougar	2.5L	Duratec-VE	IAB	✓	✓	✓	✓	
2000	Cougar	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2000.5	Cougar	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
2000.5	Cougar	2.0L	Zetec	CSM	✓	✓	✓	✓	
2000.5	Cougar	2.0L	Zetec	HEC	✓	✓	✓	✓	
2000.5	Cougar	2.0L	Zetec	IAB	✓	✓	✓	✓	
2000.5	Cougar	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2000.5	Cougar	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
2000.5	Cougar	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
2000.5	Cougar	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
2000.5	Cougar	2.5L	Duratec-VE	HEC	✓	✓	✓	✓	
2000.5	Cougar	2.5L	Duratec-VE	IAB	✓	✓	✓	✓	
2000.5	Cougar	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2001	Cougar	2.5L	Duratec-VE	ABS	✓	✓	✓	✓	
2001	Cougar	2.5L	Duratec-VE	IC	✓	✓	✓	✓	
2001	Cougar	2.5L	Duratec-VE	MC	✓	✓	✓	✓	
2001	Cougar	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	
2001	Cougar	2.5L	Duratec-VE	REM	✓	✓	✓	✓	
2002	Cougar	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2002	Cougar	2.0L	Zetec	CSM	✓	✓	✓	✓	
2002	Cougar	2.0L	Zetec	HEC	✓	✓	✓	✓	
2002	Cougar	2.0L	Zetec	IAB	✓	✓	✓	✓	
2002	Cougar	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2002	Cougar	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
2002	Cougar	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
2002	Cougar	2.5L	Duratec-VE	HEC	✓	✓	✓	✓	
2002	Cougar	2.5L	Duratec-VE	IAB	✓	✓	✓	✓	
2002	Cougar	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1995	Crown Victoria	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1995	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	
1995	Crown Victoria	4.6L	2V	DSM	✓	✓	✓	✓	
1995	Crown Victoria	4.6L	2V	EATC	✓	✓	✓	✓	
1995	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	
1995	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025
1995	Crown Victoria	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1995	Crown Victoria	4.6L	Other	PCM	✓	✓	✓	✓	0025
1996	Crown Victoria	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1996	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	
1996	Crown Victoria	4.6L	2V	DSM	✓	✓	✓	✓	
1996	Crown Victoria	4.6L	2V	EATC	✓	✓	✓	✓	
1996	Crown Victoria	4.6L	2V	IAB	✓	✓	✓	✓	
1996	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	
1996	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025
1996	Crown Victoria	4.6L	2V NGV	ABS/TCS	✓	✓	✓	✓	0008
1996	Crown Victoria	4.6L	2V NGV	DDM	✓	✓	✓	✓	
1996	Crown Victoria	4.6L	2V NGV	DSM	✓	✓	✓	✓	
1996	Crown Victoria	4.6L	2V NGV	FIM	✓	✓	✓	✓	
1996	Crown Victoria	4.6L	2V NGV	IAB	✓	✓	✓	✓	
1996	Crown Victoria	4.6L	2V NGV	LCM	✓	✓	✓	✓	
1996	Crown Victoria	4.6L	2V NGV	PCM	✓	✓	✓	✓	
1997	Crown Victoria	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1997	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	
1997	Crown Victoria	4.6L	2V	DSM	✓	✓	✓	✓	
1997	Crown Victoria	4.6L	2V	EATC	✓	✓	✓	✓	
1997	Crown Victoria	4.6L	2V	IAB	✓	✓	✓	✓	
1997	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	
1997	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025
1997	Crown Victoria	4.6L	2V NGV	ABS/TCS	✓	✓	✓	✓	0008
1997	Crown Victoria	4.6L	2V NGV	DDM	✓	✓	✓	✓	
1997	Crown Victoria	4.6L	2V NGV	DSM	✓	✓	✓	✓	
1997	Crown Victoria	4.6L	2V NGV	FIM	✓	✓	✓	✓	
1997	Crown Victoria	4.6L	2V NGV	IAB	✓	✓	✓	✓	
1997	Crown Victoria	4.6L	2V NGV	LCM	✓	✓	✓	✓	
1997	Crown Victoria	4.6L	2V NGV	PCM	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1998	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V	EATC	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V	ECS	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V	PATS	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025
1998	Crown Victoria	4.6L	2V NGV	ABS/TCS	✓	✓	✓	✓	0008
1998	Crown Victoria	4.6L	2V NGV	DDM	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V NGV	EATC	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V NGV	ECS	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V NGV	FIM	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V NGV	LCM	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V NGV	PATS	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V NGV	PCM	✓	✓	✓	✓	
1998	Crown Victoria	4.6L	2V NGV	PCM	✓	✓	✓	✓	0028, 0031, 0033
1999	Crown Victoria	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1999	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	
1999	Crown Victoria	4.6L	2V	EATC	✓	✓	✓	✓	
1999	Crown Victoria	4.6L	2V	ECS	✓	✓	✓	✓	
1999	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	



2007	Crown Victoria	4.6L	2V	FSSM	✓	✓	✓	✓	
2007	Crown Victoria	4.6L	2V	IC	✓	✓	✓	✓	0005
2007	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	
2007	Crown Victoria	4.6L	2V	MC	✓	✓	✓	✓	
2007	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Crown Victoria	4.6L	2V	RCM	✓	✓	✓	✓	000C
2007	Crown Victoria	4.6L	2V	VDM	✓	✓	✓	✓	0005, 0013, 0014
2008	Crown Victoria	4.6L	2V	ABS	✓	✓	✓	✓	0008
2008	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	0005, 0042, F044, F04C, F06A
2008	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	0042
2008	Crown Victoria	4.6L	2V	FSSM	✓	✓	✓	✓	
2008	Crown Victoria	4.6L	2V	HVAC	✓	✓	✓	✓	
2008	Crown Victoria	4.6L	2V	IC	✓	✓	✓	✓	0005
2008	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	F042, F043
2008	Crown Victoria	4.6L	2V	MC	✓	✓	✓	✓	
2008	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Crown Victoria	4.6L	2V	RCM	✓	✓	✓	✓	000C
2008	Crown Victoria	4.6L	2V	VDM	✓	✓	✓	✓	0005, 0013, 0014
2009	Crown Victoria	4.6L	2V	ABS	✓	✓	✓	✓	0008
2009	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	0042
2009	Crown Victoria	4.6L	2V	FSSM	✓	✓	✓	✓	
2009	Crown Victoria	4.6L	2V	HVAC	✓	✓	✓	✓	
2009	Crown Victoria	4.6L	2V	IC	✓	✓	✓	✓	
2009	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	
2009	Crown Victoria	4.6L	2V	MC	✓	✓	✓	✓	
2009	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Crown Victoria	4.6L	2V	RCM	✓	✓	✓	✓	000C
2009	Crown Victoria	4.6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2010	Crown Victoria	4.6L	2V	ABS	✓	✓	✓	✓	0008
2010	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	0042
2010	Crown Victoria	4.6L	2V	FSSM	✓	✓	✓	✓	
2010	Crown Victoria	4.6L	2V	HVAC	✓	✓	✓	✓	
2010	Crown Victoria	4.6L	2V	IC	✓	✓	✓	✓	
2010	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	
2010	Crown Victoria	4.6L	2V	MC	✓	✓	✓	✓	
2010	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2010	Crown Victoria	4.6L	2V	RCM	✓	✓	✓	✓	000C
2010	Crown Victoria	4.6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2011	Crown Victoria	4.6L	2V	ABS	✓	✓	✓	✓	0008
2011	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	0042
2011	Crown Victoria	4.6L	2V	FSSM	✓	✓	✓	✓	
2011	Crown Victoria	4.6L	2V	HVAC	✓	✓	✓	✓	
2011	Crown Victoria	4.6L	2V	IC	✓	✓	✓	✓	
2011	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	
2011	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Crown Victoria	4.6L	2V	RCM	✓	✓	✓	✓	000C
2011	Crown Victoria	4.6L	2V	VDM	✓	✓	✓	✓	0013, 0014
1996	DEMIO / FESTIVA MINI WAGON	1.3L	B3	ABS	✓	✓	✓	✓	
1996	DEMIO / FESTIVA MINI WAGON	1.3L	B3	PCM	✓	✓	✓	✓	
1996	DEMIO / FESTIVA MINI WAGON	1.5L	B5	ABS	✓	✓	✓	✓	
1999	DEMIO / FESTIVA MINI WAGON	1.3L	B3	ABS	✓	✓	✓	✓	
1999	DEMIO / FESTIVA MINI WAGON	1.3L	B3	PCM	✓	✓	✓	✓	
1999	DEMIO / FESTIVA MINI WAGON	1.5L	B5	ABS	✓	✓	✓	✓	
2000	DEMIO / FESTIVA MINI WAGON	1.3L	B3	ABS/TCS	✓	✓	✓	✓	
2000	DEMIO / FESTIVA MINI WAGON	1.3L	B3	PCM	✓	✓	✓	✓	
Other	DEMIO / FESTIVA MINI WAGON	1.3L	B3	PCM	✓	✓	✓	✓	
1995	E-Series	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008
1995	E-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	
1995	E-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1996	E-Series	4.9L	GFP	ABS/TCS	✓	✓	✓	✓	0008
1996	E-Series	4.9L	GFP	PCM	✓	✓	✓	✓	
1996	E-Series	4.9L	Other	ABS/TCS	✓	✓	✓	✓	0008
1996	E-Series	4.9L	Other	PCM	✓	✓	✓	✓	0025
1996	E-Series	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1996	E-Series	5.0L	Other	PCM	✓	✓	✓	✓	0025
1996	E-Series	5.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
1996	E-Series	5.8L	Other	PCM	✓	✓	✓	✓	0025
1996	E-Series	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008
1996	E-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	
1996	E-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1996	E-Series	7.5L	Other	ABS/TCS	✓	✓	✓	✓	0008
1996	E-Series	7.5L	Other	PCM	✓	✓	✓	✓	0025
1997	E-Series	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	E-Series	4.2L	Other	ECS	✓	✓	✓	✓	
1997	E-Series	4.2L	Other	PCM	✓	✓	✓	✓	0025
1997	E-Series	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	E-Series	4.6L	Other	ECS	✓	✓	✓	✓	
1997	E-Series	4.6L	Other	PCM	✓	✓	✓	✓	0025
1997	E-Series	5.4L	NGV	ABS/TCS	✓	✓	✓	✓	0008
1997	E-Series	5.4L	NGV	ECS	✓	✓	✓	✓	



2002	E-Series	7.3L	Direct Injection -	ECS	✓	✓	✓	✓	
2002	E-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	E-Series	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
2003	E-Series	4.2L	Other	ECS	✓	✓	✓	✓	
2003	E-Series	4.2L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	E-Series	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	E-Series	4.6L	2V	ECS	✓	✓	✓	✓	
2003	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	E-Series	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2003	E-Series	5.4L	Other	AFCM	✓	✓	✓	✓	
2003	E-Series	5.4L	Other	ECS	✓	✓	✓	✓	
2003	E-Series	5.4L	Other	FIM	✓	✓	✓	✓	
2003	E-Series	5.4L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	E-Series	6.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
2003	E-Series	6.8L	Other	ECS	✓	✓	✓	✓	
2003	E-Series	6.8L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	E-Series	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008
2003	E-Series	7.3L	Direct Injection -	ECS	✓	✓	✓	✓	
2003	E-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	E-Series	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	E-Series	4.6L	2V	IC	✓	✓	✓	✓	
2004	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	E-Series	4.6L	2V	RAP	✓	✓	✓	✓	
2004	E-Series	4.6L	2V	RCM	✓	✓	✓	✓	
2004	E-Series	5.4L	2V	ABS/TCS	✓	✓	✓	✓	
2004	E-Series	5.4L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	E-Series	5.4L	2V	AFCM	✓	✓	✓	✓	
2004	E-Series	5.4L	2V	IC	✓	✓	✓	✓	
2004	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	
2004	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	E-Series	5.4L	2V	RAP	✓	✓	✓	✓	
2004	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	
2004	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	
2004	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	
2004	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2004	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2004	E-Series	6.0L	Direct Injection -	RAP	✓	✓	✓	✓	
2004	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓	✓	
2004	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2004	E-Series	6.8L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	E-Series	6.8L	2V	IC	✓	✓	✓	✓	
2004	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	E-Series	6.8L	2V	RAP	✓	✓	✓	✓	
2004	E-Series	6.8L	2V	RCM	✓	✓	✓	✓	
2005	E-Series	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2005	E-Series	4.6L	2V	IC	✓	✓	✓	✓	
2005	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	
2005	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	E-Series	4.6L	2V	RAP	✓	✓	✓	✓	
2005	E-Series	4.6L	2V	RCM	✓	✓	✓	✓	
2005	E-Series	5.4L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2005	E-Series	5.4L	2V	IC	✓	✓	✓	✓	
2005	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	
2005	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	E-Series	5.4L	2V	RAP	✓	✓	✓	✓	
2005	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008, 001B
2005	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	0005
2005	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2005	E-Series	6.0L	Direct Injection -	RAP	✓	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2005	E-Series	6.8L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2005	E-Series	6.8L	2V	IC	✓	✓	✓	✓	
2005	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	
2005	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	E-Series	6.8L	2V	RAP	✓	✓	✓	✓	
2005	E-Series	6.8L	2V	RCM	✓	✓	✓	✓	
2006	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2006	E-Series	4.6L	2V	ABS/TCS	✓	✓	✓	✓	001B
2006	E-Series	4.6L	2V	IC	✓	✓	✓	✓	0005, F027, F066, F067
2006	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025
2006	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	E-Series	4.6L	2V	RAP	✓	✓	✓	✓	
2006	E-Series	4.6L	2V	RCM	✓	✓	✓	✓	
2006	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0008, 0012
2006	E-Series	5.4L	2V	ABS/TCS	✓	✓	✓	✓	001B
2006	E-Series	5.4L	2V	IC	✓	✓	✓	✓	0005
2006	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025
2006	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	E-Series	5.4L	2V	RAP	✓	✓	✓	✓	

2006	E-Series	5.4L	2V	RCM	✓	✓	✓		
2006	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	
2006	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	0008, 0012
2006	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	
2006	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	001B
2006	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	
2006	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	0005, F027, F066, F067
2006	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2006	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	E-Series	6.0L	Direct Injection -	RAP	✓	✓	✓	✓	
2006	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓		
2006	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2006	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0008, 0012
2006	E-Series	6.8L	2V	ABS/TCS	✓	✓	✓	✓	001B
2006	E-Series	6.8L	2V	IC	✓	✓	✓	✓	
2006	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025
2006	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	E-Series	6.8L	2V	RAP	✓	✓	✓	✓	
2006	E-Series	6.8L	2V	RCM	✓	✓	✓		
2007	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2007	E-Series	4.6L	2V	ABS/TCS	✓	✓	✓	✓	001B
2007	E-Series	4.6L	2V	IC	✓	✓	✓	✓	
2007	E-Series	4.6L	2V	PAM	✓	✓	✓	✓	
2007	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025
2007	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	E-Series	4.6L	2V	RCM	✓	✓	✓		
2007	E-Series	4.6L	2V	VSM	✓	✓	✓	✓	
2007	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0008, 0012
2007	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0012
2007	E-Series	5.4L	2V	ABS/TCS	✓	✓	✓	✓	001B
2007	E-Series	5.4L	2V	IC	✓	✓	✓	✓	
2007	E-Series	5.4L	2V	IC	✓	✓	✓	✓	0005, F066, F067
2007	E-Series	5.4L	2V	PAM	✓	✓	✓	✓	
2007	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	
2007	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025
2007	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	E-Series	5.4L	2V	RCM	✓	✓	✓		
2007	E-Series	5.4L	2V	VSM	✓	✓	✓	✓	
2007	E-Series	5.4L	2V	VSM	✓	✓	✓	✓	F044
2007	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	
2007	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	0008, 0012
2007	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	
2007	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	001B
2007	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	
2007	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	0005
2007	E-Series	6.0L	Direct Injection -	PAM	✓	✓	✓	✓	
2007	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2007	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓		
2007	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2007	E-Series	6.0L	Direct Injection -	VSM	✓	✓	✓	✓	
2007	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0008, 0012
2007	E-Series	6.8L	2V	ABS/TCS	✓	✓	✓	✓	001B
2007	E-Series	6.8L	2V	IC	✓	✓	✓	✓	
2007	E-Series	6.8L	2V	PAM	✓	✓	✓	✓	
2007	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025
2007	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	E-Series	6.8L	2V	RCM	✓	✓	✓		
2007	E-Series	6.8L	2V	VSM	✓	✓	✓	✓	
2008	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2008	E-Series	4.6L	2V	IC	✓	✓	✓	✓	
2008	E-Series	4.6L	2V	PAM	✓	✓	✓	✓	
2008	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0008, 0012, 0025, 0042
2008	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	E-Series	4.6L	2V	RCM	✓	✓	✓		
2008	E-Series	4.6L	2V	VSM	✓	✓	✓	✓	0042
2008	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0008, 0012
2008	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0012
2008	E-Series	5.4L	2V	IC	✓	✓	✓	✓	
2008	E-Series	5.4L	2V	IC	✓	✓	✓	✓	0005, F027, F066
2008	E-Series	5.4L	2V	PAM	✓	✓	✓	✓	
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0005, 0008, 0008, 0012, 0025, 0042, F022, F044
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0005, 0008, 0012, 0025, 0042, F022, F044
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0005, 0012, 0042, F022, F044
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	
2008	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	0005, F022
2008	E-Series	5.4L	2V	VSM	✓	✓	✓	✓	
2008	E-Series	5.4L	2V	VSM	✓	✓	✓	✓	0042, F044



2008	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	0008, 0012
2008	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	PAM	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	0008, 0012, 0042
2008	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	VSM	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	VSM	✓	✓	✓	✓	0042
2008	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0008, 0012
2008	E-Series	6.8L	2V	IC	✓	✓	✓	✓	
2008	E-Series	6.8L	2V	PAM	✓	✓	✓	✓	
2008	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0008, 0012, 0025, 0042
2008	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	E-Series	6.8L	2V	RCM	✓	✓	✓	✓	
2008	E-Series	6.8L	2V	VSM	✓	✓	✓	✓	0042
2009	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0012
2009	E-Series	4.6L	2V	ACM	✓	✓	✓	✓	
2009	E-Series	4.6L	2V	ACM	✓	✓	✓	✓	
2009	E-Series	4.6L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	E-Series	4.6L	2V	IPC	✓	✓	✓	✓	
2009	E-Series	4.6L	2V	PAM	✓	✓	✓	✓	
2009	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0012
2009	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0067
2009	E-Series	4.6L	2V	RCM	✓	✓	✓	✓	
2009	E-Series	4.6L	2V	TBC	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0012
2009	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	E-Series	5.4L	2V	IPC	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	PAM	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012, 0025
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0028, 0031, 0033
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0067
2009	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	TBC	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	0005, 0008, 0012
2009	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	0017, 0018
2009	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	0017, 0018
2009	E-Series	6.0L	Direct Injection -	GEM / SJB	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection - Turbo	GEM / SJB	✓	✓	✓	✓	0042, F03C, F042, F049, F04B, F04C, F068, F069, F06A
2009	E-Series	6.0L	Direct Injection -	IPC	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	PAM	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0005, 0008, 0012, 0017, 0018
2009	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2009	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	TBC	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0012
2009	E-Series	6.8L	2V	ACM	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	ACM	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	E-Series	6.8L	2V	IPC	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	PAM	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0012
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0028, 0031, 0033
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2009	E-Series	6.8L	2V	RCM	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	TBC	✓	✓	✓	✓	
2010	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0012
2010	E-Series	4.6L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	4.6L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	4.6L	2V	APIM	✓	✓	✓	✓	0019

2010	E-Series	4.6L	2V	GEM / SJB	✓	✓	✓	✓	0042, F03C, F042, F049, F04B, F04C, F068, F069, F06A
2010	E-Series	4.6L	2V	GPSM	✓	✓	✓	✓	
2010	E-Series	4.6L	2V	IPC	✓	✓	✓	✓	
2010	E-Series	4.6L	2V	PAM	✓	✓	✓	✓	
2010	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0012, 0017, 0018
2010	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0067
2010	E-Series	4.6L	2V	RCM	✓	✓	✓	✓	
2010	E-Series	4.6L	2V	SDARS	✓	✓	✓	✓	
2010	E-Series	4.6L	2V	TBC	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0012
2010	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	5.4L	2V	APIM	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	APIM	✓	✓	✓	✓	0019
2010	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓	0042
2010	E-Series	5.4L	2V	GPSM	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	IPC	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	PAM	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012, 0017, 0018
2010	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012, 0017, 0018, 0025, 0028, 0031, 0033
2010	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012, 0025
2010	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025
2010	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0067
2010	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	SDARS	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	TBC	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	6.0L	Direct Injection -	APIM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	APIM	✓	✓	✓	✓	0019
2010	E-Series	6.0L	Direct Injection -	GEM / SJB	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection - Turbo	GEM / SJB	✓	✓	✓	✓	0042, F03C, F042, F049, F04B, F04C, F068, F069, F06A
2010	E-Series	6.0L	Direct Injection -	GPSM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	IPC	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	PAM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0005, 0008, 0012, 0017, 0018
2010	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2010	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	SDARS	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	TBC	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0005, 0012
2010	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0012
2010	E-Series	6.8L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	6.8L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	6.8L	2V	APIM	✓	✓	✓	✓	0019
2010	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓	0042, F03C, F042, F049, F04B, F04C, F068, F069, F06A
2010	E-Series	6.8L	2V	GPSM	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	IPC	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	PAM	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0005, 0012, 0017, 0018
2010	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0012, 0017, 0018, 0025, 0028, 0031, 0033
2010	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	E-Series	6.8L	2V	RCM	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	SDARS	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	TBC	✓	✓	✓	✓	
2011	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2011	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0012
2011	E-Series	4.6L	2V	ACM	✓	✓	✓	✓	0017, 0018
2011	E-Series	4.6L	2V	ACM	✓	✓	✓	✓	0017, 0018
2011	E-Series	4.6L	2V	APIM	✓	✓	✓	✓	0019
2011	E-Series	4.6L	2V	GEM / SJB	✓	✓	✓	✓	0042
2011	E-Series	4.6L	2V	GPSM	✓	✓	✓	✓	
2011	E-Series	4.6L	2V	IPC	✓	✓	✓	✓	
2011	E-Series	4.6L	2V	PAM	✓	✓	✓	✓	
2011	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0012, 0017, 0018



2012	E-Series	6. 8L	2V	PCM	✓	✓	✓	✓	0025
2012	E-Series	6. 8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	E-Series	6. 8L	2V	RCM	✓	✓	✓	✓	
2012	E-Series	6. 8L	2V	SDARS	✓	✓	✓	✓	
2012	E-Series	6. 8L	2V	TBC	✓	✓	✓	✓	
2012	E-Series	Other	Other	ABS	✓	✓	✓	✓	
2012	E-Series	Other	Other	ACM	✓	✓	✓	✓	
2012	E-Series	Other	Other	ACM	✓	✓	✓	✓	
2012	E-Series	Other	Other	APIM	✓	✓	✓	✓	
2012	E-Series	Other	Other	GEM / SJB	✓	✓	✓	✓	0042
2012	E-Series	Other	Other	GPSM	✓	✓	✓	✓	
2012	E-Series	Other	Other	IPC	✓	✓	✓	✓	
2012	E-Series	Other	Other	PAM	✓	✓	✓	✓	
2012	E-Series	Other	Other	PCM	✓	✓	✓	✓	
2012	E-Series	Other	Other	RCM	✓	✓	✓	✓	
2012	E-Series	Other	Other	SDARS	✓	✓	✓	✓	
2012	E-Series	Other	Other	TBC	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	ABS	✓	✓	✓	✓	0012
2013	E-Series	4. 6L	2V	ABS	✓	✓	✓	✓	0012
2013	E-Series	4. 6L	2V	ACM	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	ACM	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	APIM	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	GEM / SJB	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	GPSM	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	IPC	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	PAM	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2013	E-Series	4. 6L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0028, 0031, 0033
2013	E-Series	4. 6L	2V	RCM	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	SDARS	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	TBC	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	ABS	✓	✓	✓	✓	0012
2013	E-Series	5. 4L	2V	ABS	✓	✓	✓	✓	0012
2013	E-Series	5. 4L	2V	ACM	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	ACM	✓	✓	✓	✓	0017, 0018
2013	E-Series	5. 4L	2V	ACM	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	ACM	✓	✓	✓	✓	0017, 0018
2013	E-Series	5. 4L	2V	APIM	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	GEM / SJB	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	GPSM	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	IPC	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	IPC	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	PAM	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	E-Series	5. 4L	2V	PCM	✓	✓	✓	✓	0012, 0025
2013	E-Series	5. 4L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0028, 0028, 0031, 0031, 0033, 0033, 0067
2013	E-Series	5. 4L	2V	PCM	✓	✓	✓	✓	0025
2013	E-Series	5. 4L	2V	RCM	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	SDARS	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	TBC	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	TBC	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	ABS	✓	✓	✓	✓	0012
2013	E-Series	6. 8L	2V	ABS	✓	✓	✓	✓	0012
2013	E-Series	6. 8L	2V	ACM	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	ACM	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	APIM	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	GEM / SJB	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	GPSM	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	IPC	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	IPC	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	PAM	✓	✓	✓	✓	0025
2013	E-Series	6. 8L	2V	PCM	✓	✓	✓	✓	0012, 0025
2013	E-Series	6. 8L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0025, 0028, 0031, 0033
2013	E-Series	6. 8L	2V	PCM	✓	✓	✓	✓	0025
2013	E-Series	6. 8L	2V	RCM	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	SDARS	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	TBC	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	TBC	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	ABS	✓	✓	✓	✓	0012
2014	E-Series	4. 6L	2V	ACM	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	APIM	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	GEM / SJB	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	GPSM	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	IPC	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	PAM	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0028, 0031, 0033
2014	E-Series	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	E-Series	4. 6L	2V	RCM	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	TBC	✓	✓	✓	✓	
2014	E-Series	5. 4L	2V	ABS	✓	✓	✓	✓	0012
2014	E-Series	5. 4L	2V	ACM	✓	✓	✓	✓	

2014	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	0017, 0018
2014	E-Series	5.4L	2V	APIM	✓	✓	✓	✓	
2014	E-Series	5.4L	2V	APIM	✓	✓	✓	✓	0019
2014	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓	
2014	E-Series	5.4L	2V	GPSM	✓	✓	✓	✓	
2014	E-Series	5.4L	2V	IPC	✓	✓	✓	✓	
2014	E-Series	5.4L	2V	PAM	✓	✓	✓	✓	
2014	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0025, 0028, 0028, 0031, 0031, 0033, 0033, 0067
2014	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	
2014	E-Series	5.4L	2V	TBC	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0012
2014	E-Series	6.8L	2V	ACM	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	APIM	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	GPSM	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	IPC	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	PAM	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0025, 0028, 0031, 0033
2014	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	E-Series	6.8L	2V	RCM	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	TBC	✓	✓	✓	✓	
2006	E-Series Shuttle Bus	6.8L	H2ICE	ABS/TCS	✓	✓	✓	✓	
2006	E-Series Shuttle Bus	6.8L	H2ICE	AFCM	✓	✓	✓	✓	
2006	E-Series Shuttle Bus	6.8L	H2ICE	EMM	✓	✓	✓	✓	
2006	E-Series Shuttle Bus	6.8L	H2ICE	IC	✓	✓	✓	✓	
2006	E-Series Shuttle Bus	6.8L	H2ICE	PCM	✓	✓	✓	✓	
2006	E-Series Shuttle Bus	6.8L	H2ICE	RCM	✓	✓	✓	✓	
2003.25	EcoSport	1.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008, 000B
2003.25	EcoSport	1.0L	Zetec Rocam	GEM	✓	✓	✓	✓	
2003.25	EcoSport	1.0L	Zetec Rocam	IC	✓	✓	✓	✓	
2003.25	EcoSport	1.0L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2003.25	EcoSport	1.0L	Zetec Rocam	RCM	✓	✓	✓	✓	
2003.25	EcoSport	1.0L	Zetec Rocam	RKE	✓	✓	✓	✓	
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 000B
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2003.25	EcoSport	1.6L	FFV	GEM	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	FFV	IC	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2003.25	EcoSport	1.6L	FFV	RCM	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	FFV	RKE	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008, 000B
2003.25	EcoSport	1.6L	Zetec Rocam	GEM	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2003.25	EcoSport	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2003.25	EcoSport	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 000B
2003.25	EcoSport	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2003.25	EcoSport	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2003.25	EcoSport	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2003.25	EcoSport	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2003.25	EcoSport	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2006	EcoSport	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2006	EcoSport	1.6L	FFV	GEM	✓	✓	✓	✓	
2006	EcoSport	1.6L	FFV	IC	✓	✓	✓	✓	
2006	EcoSport	1.6L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2006	EcoSport	1.6L	FFV	RCM	✓	✓	✓	✓	
2006	EcoSport	1.6L	FFV	RKE	✓	✓	✓	✓	
2006	EcoSport	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 000B
2006	EcoSport	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	EcoSport	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	EcoSport	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	EcoSport	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006	EcoSport	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2007	EcoSport	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 000B
2007	EcoSport	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	EcoSport	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	EcoSport	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007	EcoSport	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2009	EcoSport	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2009	EcoSport	1.6L	FFV	IC	✓	✓	✓	✓	
2009	EcoSport	1.6L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2009	EcoSport	1.6L	FFV	RCM	✓	✓	✓	✓	

2009	EcoSport	1.6L	FFV	RKE	✓	✓	✓	✓	
2009	EcoSport	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2009	EcoSport	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	EcoSport	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	EcoSport	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2009	EcoSport	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2009	EcoSport	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2009	EcoSport	2.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
2009	EcoSport	2.0L	FFV	IC	✓	✓	✓	✓	
2009	EcoSport	2.0L	FFV	IC	✓	✓	✓	✓	
2009	EcoSport	2.0L	FFV	PCM	✓	✓	✓	✓	0025
2009	EcoSport	2.0L	FFV	PCM	✓	✓	✓	✓	0025, 00C5
2009	EcoSport	2.0L	FFV	RCM	✓	✓	✓	✓	
2009	EcoSport	2.0L	FFV	RKE	✓	✓	✓	✓	
2009	EcoSport	2.0L	FFV	TCM	✓	✓	✓	✓	0070, 00C5
2009	EcoSport	2.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2009	EcoSport	2.0L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	EcoSport	2.0L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	EcoSport	2.0L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2009	EcoSport	2.0L	Zetec Rocam	RCM	✓	✓	✓	✓	
2009	EcoSport	2.0L	Zetec Rocam	RKE	✓	✓	✓	✓	
2009	EcoSport	2.0L	Zetec Rocam	TCM	✓	✓	✓	✓	0070, 00C5
2011	EcoSport	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	000B
2011	EcoSport	1.6L	FFV	IC	✓	✓	✓	✓	
2011	EcoSport	1.6L	FFV	IC	✓	✓	✓	✓	
2011	EcoSport	1.6L	FFV	PCM	✓	✓	✓	✓	012E
2011	EcoSport	1.6L	FFV	RCM	✓	✓	✓	✓	
2011	EcoSport	1.6L	FFV	RKE	✓	✓	✓	✓	
2011	EcoSport	1.6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	EcoSport	2.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2011	EcoSport	2.0L	FFV	IC	✓	✓	✓	✓	
2011	EcoSport	2.0L	FFV	IC	✓	✓	✓	✓	
2011	EcoSport	2.0L	FFV	PCM	✓	✓	✓	✓	0025, 00C5
2011	EcoSport	2.0L	FFV	PCM	✓	✓	✓	✓	00C5
2011	EcoSport	2.0L	FFV	RCM	✓	✓	✓	✓	
2011	EcoSport	2.0L	FFV	RKE	✓	✓	✓	✓	
2011	EcoSport	2.0L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	EcoSport	2.0L	FFV	TCM	✓	✓	✓	✓	0070, 00C5
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	BCM#1	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0025, 0090, 0092, 0098, 0099, 009A, 00AF, 00B0, 00B2, 00B8, 00BD
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	TBM	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	ABS	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	ACM	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	APIM	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	BCM#1	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	DDM	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	FCDIM	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	HVAC	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	IPC	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	PCM	✓	✓	✓	✓	0025
2012	EcoSport	1.5L	TivCT	PSCM	✓	✓	✓	✓	00CB, 00CC
2012	EcoSport	1.5L	TivCT	RCM	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	RFA	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	TCM	✓	✓	✓	✓	0117, 0158
2012	EcoSport	1.6L	Sigma	ABS	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	ACM	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	APIM	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	BCM#1	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	DDM	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	FCDIM	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	HVAC	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	IPC	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	PCM	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	PSCM	✓	✓	✓	✓	00CB, 00CC
2012	EcoSport	1.6L	Sigma	RCM	✓	✓	✓	✓	

2012	EcoSport	1. 6L	Sigma	RFA	✓	✓	✓	✓	
2012	EcoSport	1. 6L	Sigma	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	EcoSport	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	BCM#1	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	FCDIM	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2012	EcoSport	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0067
2012	EcoSport	2. 0L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	00CB, 00CC
2012	EcoSport	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	EcoSport	2. 0L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D2, 00D3
2012	EcoSport	Other	Other	ABS	✓	✓	✓	✓	
2012	EcoSport	Other	Other	ACM	✓	✓	✓	✓	
2012	EcoSport	Other	Other	APIM	✓	✓	✓	✓	
2012	EcoSport	Other	Other	BCM#1	✓	✓	✓	✓	
2012	EcoSport	Other	Other	DDM	✓	✓	✓	✓	
2012	EcoSport	Other	Other	FCDIM	✓	✓	✓	✓	
2012	EcoSport	Other	Other	HVAC	✓	✓	✓	✓	
2012	EcoSport	Other	Other	IPC	✓	✓	✓	✓	
2012	EcoSport	Other	Other	PSCM	✓	✓	✓	✓	
2012	EcoSport	Other	Other	RCM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	ABS	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	ACM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	APIM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	BCM#1	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	DDM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	FCDIM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	GPSM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	HVAC	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	IPC	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	PCM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	PCM	✓	✓	✓	✓	0025
2013	EcoSport	2. 0L	DURATEC	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	EcoSport	2. 0L	DURATEC	PSCM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	RCM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	RFA	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	TBM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	TBM	✓	✓	✓	✓	00D2, 00D3
2013	EcoSport	2. 0L	DURATEC	TCM	✓	✓	✓	✓	0117, 0158
2014	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	

2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓		
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	0101
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	ABS	✓	✓	✓	✓	00E8
2014	EcoSport	1.5L	DURATEC VCT	ACM	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	APIM	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	BCMii	✓	✓	✓	✓	0101
2014	EcoSport	1.5L	DURATEC VCT	GPSM	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	IPC	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	PCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	PSCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	RCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	RFA	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	TCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	00E8
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	APIM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	0101
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	GPSM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2008	Econovan	2.0L	OHC	IC	✓	✓	✓	✓	
2008	Econovan	2.0L	OHC	PCM	✓	✓	✓	✓	
2007	Edge	3.5L	4V	4X4	✓	✓	✓	✓	
2007	Edge	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2007	Edge	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Edge	3.5L	4V	DSM	✓	✓	✓	✓	
2007	Edge	3.5L	4V	EATC	✓	✓	✓	✓	
2007	Edge	3.5L	4V	GEM	✓	✓	✓	✓	001A
2007	Edge	3.5L	4V	IC	✓	✓	✓	✓	
2007	Edge	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2007	Edge	3.5L	4V	PAM	✓	✓	✓	✓	
2007	Edge	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Edge	3.5L	4V	RCM	✓	✓	✓	✓	
2007	Edge	3.5L	4V	RETM	✓	✓	✓	✓	
2007	Edge	3.5L	4V	SASM	✓	✓	✓	✓	
2007	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2007	Edge	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3



2008	Edge	3.5L	4V	4X4	✓	✓	✓	✓	
2008	Edge	3.5L	4V	ABS	✓	✓	✓	✓	0005
2008	Edge	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0012
2008	Edge	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0019
2008	Edge	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Edge	3.5L	4V	DSM	✓	✓	✓	✓	0005, F041
2008	Edge	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C
2008	Edge	3.5L	4V	HVAC	✓	✓	✓	✓	
2008	Edge	3.5L	4V	IC	✓	✓	✓	✓	0005, F027, F047, F04A
2008	Edge	3.5L	4V	LTM	✓	✓	✓	✓	
2008	Edge	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Edge	3.5L	4V	PAM	✓	✓	✓	✓	0005
2008	Edge	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Edge	3.5L	4V	RCM	✓	✓	✓	✓	0005
2008	Edge	3.5L	4V	RETM	✓	✓	✓	✓	0005, F04D
2008	Edge	3.5L	4V	SASM	✓	✓	✓	✓	
2008	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0005, 0019
2008	Edge	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	Edge	3.5L	4V	4X4	✓	✓	✓	✓	
2009	Edge	3.5L	4V	ABS	✓	✓	✓	✓	
2009	Edge	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0012
2009	Edge	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0019
2009	Edge	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0019
2009	Edge	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Edge	3.5L	4V	DSM	✓	✓	✓	✓	
2009	Edge	3.5L	4V	DSM	✓	✓	✓	✓	0005
2009	Edge	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Edge	3.5L	4V	HVAC	✓	✓	✓	✓	
2009	Edge	3.5L	4V	IC	✓	✓	✓	✓	
2009	Edge	3.5L	4V	IC	✓	✓	✓	✓	0005
2009	Edge	3.5L	4V	LTM	✓	✓	✓	✓	
2009	Edge	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2009	Edge	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Edge	3.5L	4V	PAM	✓	✓	✓	✓	
2009	Edge	3.5L	4V	PAM	✓	✓	✓	✓	0005
2009	Edge	3.5L	4V	PCM	✓	✓	✓	✓	0025
2009	Edge	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Edge	3.5L	4V	RCM	✓	✓	✓	✓	
2009	Edge	3.5L	4V	RCM	✓	✓	✓	✓	0005
2009	Edge	3.5L	4V	RETM	✓	✓	✓	✓	
2009	Edge	3.5L	4V	SASM	✓	✓	✓	✓	
2009	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0005
2009	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0005, 0019
2009	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2009	Edge	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Edge	3.5L	4V	4X4	✓	✓	✓	✓	
2010	Edge	3.5L	4V	ABS	✓	✓	✓	✓	0012
2010	Edge	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0019
2010	Edge	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0019
2010	Edge	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Edge	3.5L	4V	DSM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	DSM	✓	✓	✓	✓	0005
2010	Edge	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Edge	3.5L	4V	GPSM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	HVAC	✓	✓	✓	✓	
2010	Edge	3.5L	4V	IC	✓	✓	✓	✓	
2010	Edge	3.5L	4V	LTM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	Edge	3.5L	4V	PAM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	PAM	✓	✓	✓	✓	0005
2010	Edge	3.5L	4V	PCM	✓	✓	✓	✓	0025
2010	Edge	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2010	Edge	3.5L	4V	RCM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	RETM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	SASM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0005, 0019
2010	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2010	Edge	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Edge	3.5L	TivCT	ABS	✓	✓	✓	✓	0008, 0012
2011	Edge	3.5L	TivCT	ACM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	APIM	✓	✓	✓	✓	00D6
2011	Edge	3.5L	TivCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	Edge	3.5L	TivCT	C-CM	✓	✓	✓	✓	0046
2011	Edge	3.5L	TivCT	DSCM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	DSM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	DSP	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	FCDIM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	FCIM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	FLM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	GPSM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	HUD	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	HVAC	✓	✓	✓	✓	

2011	Edge	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2011	Edge	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	PCM	✓	✓	✓	✓	0067, 0095
2011	Edge	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Edge	3.5L	TiVCT	TPM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2011	Edge	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	APIM	✓	✓	✓	✓	00D6
2011	Edge	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 0042, 00D4, 00D5, 00FE
2011	Edge	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	Edge	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2011	Edge	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2011	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2011	Edge	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	PCM	✓	✓	✓	✓	0067, 0095
2011	Edge	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Edge	3.7L	TiVCT	TPM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	

2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0095
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TBM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	0028, 0031, 0033
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TPM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	Edge	3. 5L	TiVCT	ACM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	APIM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	Edge	3. 5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2012	Edge	3. 5L	TiVCT	DCSM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	DSM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	DSP	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	FCDIM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	FCIM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	FLM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	GPSM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	HUD	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	HVAC	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	IPC	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	LTM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2012	Edge	3. 5L	TiVCT	PAM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2012	Edge	3. 5L	TiVCT	RCM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	RFA	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	SCCM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	SOD-L	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	SOD-R	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Edge	3. 5L	TiVCT	TPM	✓	✓	✓	✓	
2012	Edge	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	Edge	3. 7L	TiVCT	ACM	✓	✓	✓	✓	

2012	Edge	3.7L	TiVCT	APIM	✓	✓	✓		
2012	Edge	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	Edge	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2012	Edge	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2012	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2012	Edge	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2012	Edge	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Edge	3.7L	TiVCT	TPM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015

2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	0015
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0095, 0108
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TBM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	0028, 0031, 0033
2013	Edge	3.5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	Edge	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Edge	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Edge	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	FLM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	Edge	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	Edge	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2013	Edge	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	Edge	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Edge	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Edge	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	LTM	✓	✓	✓	✓	

2013	Edge	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	Edge	3. 7L	TiVCT	PAM	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2013	Edge	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	Edge	3. 7L	TiVCT	RCM	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	RFA	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	RLCM-A	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	RTM	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00CE
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	

2014	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2014	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2014	Edge	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112
2014	Edge	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Edge	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	FLM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	Edge	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Edge	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2014	Edge	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2014	Edge	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112
2014	Edge	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Edge	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	Edge	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Edge	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2014	Edge	Other	Other	ABS	✓	✓	✓	✓	
2014	Edge	Other	Other	ACM	✓	✓	✓	✓	
2014	Edge	Other	Other	APIM	✓	✓	✓	✓	
2014	Edge	Other	Other	BCM#1	✓	✓	✓	✓	
2014	Edge	Other	Other	C-CM	✓	✓	✓	✓	
2014	Edge	Other	Other	DCSM	✓	✓	✓	✓	
2014	Edge	Other	Other	DSM	✓	✓	✓	✓	
2014	Edge	Other	Other	DSP	✓	✓	✓	✓	
2014	Edge	Other	Other	FCDIM	✓	✓	✓	✓	
2014	Edge	Other	Other	FCIM	✓	✓	✓	✓	
2014	Edge	Other	Other	FLM	✓	✓	✓	✓	
2014	Edge	Other	Other	GPSM	✓	✓	✓	✓	
2014	Edge	Other	Other	HUD	✓	✓	✓	✓	
2014	Edge	Other	Other	HVAC	✓	✓	✓	✓	
2014	Edge	Other	Other	IPC	✓	✓	✓	✓	
2014	Edge	Other	Other	LTM	✓	✓	✓	✓	
2014	Edge	Other	Other	OCSM	✓	✓	✓	✓	
2014	Edge	Other	Other	PAM	✓	✓	✓	✓	
2014	Edge	Other	Other	RCM	✓	✓	✓	✓	
2014	Edge	Other	Other	RFA	✓	✓	✓	✓	
2014	Edge	Other	Other	RLCM-A	✓	✓	✓	✓	
2014	Edge	Other	Other	RTM	✓	✓	✓	✓	
2014	Edge	Other	Other	SCCM	✓	✓	✓	✓	
2014	Edge	Other	Other	SOD-L	✓	✓	✓	✓	











2001	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓	
2002	Escape / Tribute / Maverick	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2002	Escape / Tribute / Maverick	2.0L	Zetec	GEM	✓	✓	✓	✓	
2002	Escape / Tribute / Maverick	2.0L	Zetec	IC	✓	✓	✓	✓	
2002	Escape / Tribute / Maverick	2.0L	Zetec	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Escape / Tribute / Maverick	2.0L	Zetec	RCM	✓	✓	✓	✓	
2002	Escape / Tribute / Maverick	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2002	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓	
2002	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓	
2002	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2003	Escape / Tribute / Maverick	2.0L	Zetec	GEM	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	2.0L	Zetec	IC	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	2.0L	Zetec	PAM	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	2.0L	Zetec	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Escape / Tribute / Maverick	2.0L	Zetec	RCM	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	3.0L	4V	PAM	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2004	Escape / Tribute / Maverick	2.0L	Zetec	GEM	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	2.0L	Zetec	IC	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	2.0L	Zetec	PAM	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	2.0L	Zetec	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Escape / Tribute / Maverick	2.0L	Zetec	RCM	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2004	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	3.0L	4V	PAM	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2006	Escape / Tribute / Maverick	3.0L	4V	4X4	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	3.0L	4V	ABS	✓	✓	✓	✓	0005, 0008
2006	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓	F042, F04E, F04F, F050, F051, F056, F057, F058, F059
2006	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓	F042, F04E, F04F, F050, F051, F056, F057, F058, F059, F090
2006	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓	0005, F040, F043, F04D, F052, F053, F054, F055
2006	Escape / Tribute / Maverick	3.0L	4V	PAM	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓	000C
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2007	Escape / Tribute / Maverick	3.0L	4V	4X4	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	3.0L	4V	ABS	✓	✓	✓	✓	0008
2007	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	3.0L	4V	PAM	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓	000C
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D5, 0101

2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0108
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	013D
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D5, 0101
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	

2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓		
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0108
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓		
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓		013D
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓		
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	ABS	✓	✓	✓	✓	0012
2013	Escape/Kuga	2.5L	IVCT	ACM	✓	✓	✓	✓	0017
2013	Escape/Kuga	2.5L	IVCT	APIM	✓	✓	✓	✓	0019
2013	Escape/Kuga	2.5L	IVCT	BCM#1	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	BCM#1	✓	✓	✓	✓	00D5, 0101
2013	Escape/Kuga	2.5L	IVCT	DDM	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	DSM	✓	✓	✓	✓	00F2
2013	Escape/Kuga	2.5L	IVCT	DSP	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	FCDIM	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	FCIM	✓	✓	✓		
2013	Escape/Kuga	2.5L	IVCT	GPSM	✓	✓	✓		
2013	Escape/Kuga	2.5L	IVCT	HCM	✓	✓	✓		
2013	Escape/Kuga	2.5L	IVCT	HVAC	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	IPC	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	IPM-B	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	OCSM	✓	✓	✓	✓	000C
2013	Escape/Kuga	2.5L	IVCT	PAM	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2013	Escape/Kuga	2.5L	IVCT	PDM	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	Escape/Kuga	2.5L	IVCT	RCM	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	RFA	✓	✓	✓		
2013	Escape/Kuga	2.5L	IVCT	RGTM	✓	✓	✓		013D
2013	Escape/Kuga	2.5L	IVCT	SASM	✓	✓	✓		
2013	Escape/Kuga	2.5L	IVCT	SOD-L	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	SOD-R	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	TRM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	

2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D5, 0101
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	013D
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D5, 0101
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	

2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓		013D
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	ABS	✓	✓	✓	✓	0012
2014	Escape/Kuga	2.5L	IVCT	ACM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	APIM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	BCM#1	✓	✓	✓	✓	00D5, 0101
2014	Escape/Kuga	2.5L	IVCT	DDM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	DSM	✓	✓	✓	✓	00F2
2014	Escape/Kuga	2.5L	IVCT	DSP	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	FCDIM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	FCIM	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	GPSM	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	HCM	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	HVAC	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	IPC	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	OCSM	✓	✓	✓	✓	000C
2014	Escape/Kuga	2.5L	IVCT	PAM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Escape/Kuga	2.5L	IVCT	PDM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Escape/Kuga	2.5L	IVCT	RCM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	RFA	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	RGTM	✓	✓	✓		013D
2014	Escape/Kuga	2.5L	IVCT	SASM	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	SOD-L	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	SOD-R	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	TRM	✓	✓	✓	✓	
1992	Escort	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1992	Escort	1.8L	Zetec	CSM	✓	✓	✓	✓	
1992	Escort	1.8L	Zetec	HEC	✓	✓	✓	✓	
1992	Escort	1.8L	Zetec	PATS	✓	✓	✓	✓	
1992	Escort	1.8L	Zetec	PCM	✓	✓	✓	✓	0025
1993	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1993	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1993	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1993	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1993	Escort	1.6L	Zetec	PCM	✓	✓	✓	✓	0025
1993.5	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	



1993.5	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1993.5	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1993.5	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1993.5	Escort	1.6L	Zetec	PCM	✓	✓	✓	✓	0025
1994	Escort	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1994	Escort	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	✓	
1994	Escort	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓	
1994	Escort	1.4L	1.4 PT-E SFI	PATS			✓	✓	
1994	Escort	1.4L	1.4 PT-E SFI	PATS	✓	✓	✓	✓	
1994	Escort	1.4L	1.4 PT-E SFI	PCM	✓	✓	✓	✓	
1994	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1994	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1994	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1994	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1994	Escort	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1994	Escort	1.8L	Zetec	CSM	✓	✓	✓	✓	
1994	Escort	1.8L	Zetec	HEC	✓	✓	✓	✓	
1994	Escort	1.8L	Zetec	PATS	✓	✓	✓	✓	
1994.5	Escort	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1994.5	Escort	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	✓	
1994.5	Escort	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓	
1994.5	Escort	1.4L	1.4 PT-E SFI	PATS			✓	✓	
1994.5	Escort	1.4L	1.4 PT-E SFI	PATS	✓	✓	✓	✓	
1994.5	Escort	1.4L	1.4 PT-E SFI	PCM	✓	✓	✓	✓	
1994.5	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1994.5	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1994.5	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1994.5	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1994.75	Escort	2.0L	DOHC Cosworth	ABS/TCS	✓	✓	✓	✓	
1994.75	Escort	2.0L	DOHC Cosworth	PATS	✓	✓	✓	✓	
1994.75	Escort	2.0L	DOHC Cosworth	PCM	✓	✓	✓	✓	
1995	Escort	1.4L	1.4 PT-E SFI	ABS	✓	✓	✓	✓	
1995	Escort	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1995	Escort	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	✓	
1995	Escort	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓	
1995	Escort	1.4L	1.4 PT-E SFI	PATS			✓	✓	
1995	Escort	1.4L	1.4 PT-E SFI	PCM	✓	✓	✓	✓	
1995	Escort	1.6L	Zetec	ABS	✓	✓	✓	✓	
1995	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1995	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1995	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1995	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1995	Escort	1.8L	Zetec	ABS	✓	✓	✓	✓	
1995	Escort	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1995	Escort	1.8L	Zetec	CSM	✓	✓	✓	✓	
1995	Escort	1.8L	Zetec	HEC	✓	✓	✓	✓	
1995	Escort	1.8L	Zetec	PATS	✓	✓	✓	✓	
1995	Escort	2.0L	DOHC Cosworth	ABS	✓	✓	✓	✓	
1995	Escort	2.0L	DOHC Cosworth	ABS/TCS	✓	✓	✓	✓	
1995	Escort	2.0L	DOHC Cosworth	PATS	✓	✓	✓	✓	
1995	Escort	2.0L	DOHC Cosworth	PCM	✓	✓	✓	✓	
1995.5	Escort	1.3L	Endura-E	ABS	✓	✓	✓	✓	
1995.5	Escort	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1995.5	Escort	1.3L	Endura-E	CSM	✓	✓	✓	✓	
1995.5	Escort	1.3L	Endura-E	HEC	✓	✓	✓	✓	
1995.5	Escort	1.3L	Endura-E	PATS	✓	✓	✓	✓	
1995.5	Escort	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1995.5	Escort	1.6L	Zetec	ABS	✓	✓	✓	✓	
1995.5	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1995.5	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1995.5	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1995.5	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1995.5	Escort	1.6L	Zetec	PCM	✓	✓	✓	✓	0025
1995.5	Escort	1.8L	Zetec	ABS	✓	✓	✓	✓	
1995.5	Escort	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1995.5	Escort	1.8L	Zetec	CSM	✓	✓	✓	✓	
1995.5	Escort	1.8L	Zetec	HEC	✓	✓	✓	✓	
1995.5	Escort	1.8L	Zetec	PATS	✓	✓	✓	✓	
1996	Escort	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1996	Escort	1.3L	Endura-E	CSM	✓	✓	✓	✓	
1996	Escort	1.3L	Endura-E	HEC	✓	✓	✓	✓	
1996	Escort	1.3L	Endura-E	PATS	✓	✓	✓	✓	
1996	Escort	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1996	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1996	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1996	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1996	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1996	Escort	1.6L	Zetec	PCM	✓	✓	✓	✓	0025
1996	Escort	1.8L	Endura-DE	ABS/TCS	✓	✓	✓	✓	
1996	Escort	1.8L	Endura-DE	CSM	✓	✓	✓	✓	
1996	Escort	1.8L	Endura-DE	HEC	✓	✓	✓	✓	
1996	Escort	1.8L	Endura-DE	PATS	✓	✓	✓	✓	
1996	Escort	1.8L	Endura-DE	PCM			✓	✓	
1996	Escort	1.8L	Endura-DE	PCM	✓	✓	✓	✓	
1996	Escort	1.8L	Endura-DE	PCM	✓	✓	✓	✓	
1996	Escort	1.8L	Other	ABS/TCS	✓	✓	✓	✓	
1996	Escort	1.8L	Other	CSM	✓	✓	✓	✓	
1996	Escort	1.8L	Other	HEC	✓	✓	✓	✓	
1996	Escort	1.8L	Other	PATS	✓	✓	✓	✓	

1996	Escort	1. 8L	Other	PCM	✓	✓	✓		
1996	Escort	1. 8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1996	Escort	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1996	Escort	1. 8L	Zetec	HEC	✓	✓	✓	✓	
1996	Escort	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1996	Escort	1. 8L	Zetec	PCM	✓	✓	✓	✓	0025
1996	Escort	1. 9L	Other	ABS/TCS	✓	✓	✓	✓	
1996	Escort	1. 9L	Other	PATS	✓	✓	✓	✓	
1996	Escort	1. 9L	Other	PCM	✓	✓	✓	✓	0025
1996. 5	Escort	1. 6L	Zetec	ABS	✓	✓	✓	✓	
1996. 5	Escort	1. 6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1996. 5	Escort	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1996. 5	Escort	1. 6L	Zetec	HEC	✓	✓	✓	✓	
1996. 5	Escort	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1997	Escort	1. 3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1997	Escort	1. 3L	Endura-E	CSM	✓	✓	✓	✓	
1997	Escort	1. 3L	Endura-E	HEC	✓	✓	✓	✓	
1997	Escort	1. 3L	Endura-E	PATS	✓	✓	✓	✓	
1997	Escort	1. 3L	Endura-E	PCM	✓	✓	✓	✓	0025
1997	Escort	1. 6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1997	Escort	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1997	Escort	1. 6L	Zetec	HEC	✓	✓	✓	✓	
1997	Escort	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1997	Escort	1. 6L	Zetec	PCM	✓	✓	✓	✓	0025
1997	Escort	1. 8L	Endura-DE	ABS/TCS	✓	✓	✓	✓	
1997	Escort	1. 8L	Endura-DE	CSM	✓	✓	✓	✓	
1997	Escort	1. 8L	Endura-DE	HEC	✓	✓	✓	✓	
1997	Escort	1. 8L	Endura-DE	PATS	✓	✓	✓	✓	
1997	Escort	1. 8L	Endura-DE	PCM	✓	✓	✓	✓	
1997	Escort	1. 8L	Endura-DE	PCM	✓	✓	✓	✓	
1997	Escort	1. 8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1997	Escort	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1997	Escort	1. 8L	Zetec	HEC	✓	✓	✓	✓	
1997	Escort	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1997	Escort	1. 8L	Zetec	PCM	✓	✓	✓	✓	0025
1997	Escort	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
1997	Escort	2. 0L	SPI	PATS	✓	✓	✓	✓	
1997	Escort	2. 0L	SPI	PCM	✓	✓	✓	✓	0025
1997	Escort	2. 0L	SPI	RAP	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	ABS	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	ABS/TCS	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	CSM	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	HEC	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	PATS	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	PCM	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	PCM	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	ABS	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	CSM	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	HEC	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	PATS	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	PATS	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	PCM	✓	✓	✓	✓	
1997. 75	Escort	1. 6L	Zetec	ABS	✓	✓	✓	✓	
1997. 75	Escort	1. 6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1997. 75	Escort	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1997. 75	Escort	1. 6L	Zetec	HEC	✓	✓	✓	✓	
1997. 75	Escort	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1997. 75	Escort	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1997. 75	Escort	1. 8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1997. 75	Escort	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1997. 75	Escort	1. 8L	Zetec	HEC	✓	✓	✓	✓	
1997. 75	Escort	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1997. 75	Escort	1. 8L	Zetec	PCM	✓	✓	✓	✓	0025
1998	Escort	1. 3L	Endura-E	ABS	✓	✓	✓	✓	
1998	Escort	1. 3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1998	Escort	1. 3L	Endura-E	CSM	✓	✓	✓	✓	
1998	Escort	1. 3L	Endura-E	HEC	✓	✓	✓	✓	
1998	Escort	1. 3L	Endura-E	PATS	✓	✓	✓	✓	
1998	Escort	1. 3L	Endura-E	PCM	✓	✓	✓	✓	0025
1998	Escort	1. 4L	1. 4 PT-E SFI	ABS	✓	✓	✓	✓	
1998	Escort	1. 4L	1. 4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1998	Escort	1. 4L	1. 4 PT-E SFI	CSM	✓	✓	✓	✓	
1998	Escort	1. 4L	1. 4 PT-E SFI	HEC	✓	✓	✓	✓	
1998	Escort	1. 4L	1. 4 PT-E SFI	PATS	✓	✓	✓	✓	
1998	Escort	1. 4L	1. 4 PT-E SFI	PATS	✓	✓	✓	✓	
1998	Escort	1. 4L	1. 4 PT-E SFI	PCM	✓	✓	✓	✓	
1998	Escort	1. 6L	Zetec	ABS	✓	✓	✓	✓	
1998	Escort	1. 6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1998	Escort	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1998	Escort	1. 6L	Zetec	HEC	✓	✓	✓	✓	
1998	Escort	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1998	Escort	1. 6L	Zetec	PCM	✓	✓	✓	✓	0025
1998	Escort	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1998	Escort	1. 8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1998	Escort	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1998	Escort	1. 8L	Zetec	HEC	✓	✓	✓	✓	
1998	Escort	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1998	Escort	1. 8L	Zetec	PCM	✓	✓	✓	✓	0025

1998	Escort	2.0L	SPI	ABS	✓	✓	✓	✓	0008
1998	Escort	2.0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
1998	Escort	2.0L	SPI	ECS	✓	✓	✓	✓	
1998	Escort	2.0L	SPI	PATS	✓	✓	✓	✓	
1998	Escort	2.0L	SPI	PCM	✓	✓	✓	✓	0008, 0025
1998	Escort	2.0L	SPI	RAP	✓	✓	✓	✓	
1998	Escort	2.0L	Zetec	ABS	✓	✓	✓	✓	0008
1998	Escort	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1998	Escort	2.0L	Zetec	ECS	✓	✓	✓	✓	
1998	Escort	2.0L	Zetec	PATS	✓	✓	✓	✓	
1998	Escort	2.0L	Zetec	PCM	✓	✓	✓	✓	0008, 0025
1998	Escort	2.0L	Zetec	RAP	✓	✓	✓	✓	
1999	Escort	2.0L	SPI	ABS	✓	✓	✓	✓	0008
1999	Escort	2.0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
1999	Escort	2.0L	SPI	ECS	✓	✓	✓	✓	
1999	Escort	2.0L	SPI	PATS	✓	✓	✓	✓	
1999	Escort	2.0L	SPI	PCM	✓	✓	✓	✓	0008, 0025
1999	Escort	2.0L	SPI	PCM	✓	✓	✓	✓	0025
1999	Escort	2.0L	SPI	RAP	✓	✓	✓	✓	
1999	Escort	2.0L	Zetec	ABS	✓	✓	✓	✓	0008
1999	Escort	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1999	Escort	2.0L	Zetec	ECS	✓	✓	✓	✓	
1999	Escort	2.0L	Zetec	PATS	✓	✓	✓	✓	
1999	Escort	2.0L	Zetec	PCM	✓	✓	✓	✓	0008, 0025
1999	Escort	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
1999	Escort	2.0L	Zetec	RAP	✓	✓	✓	✓	
2000	Escort	2.0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
2000	Escort	2.0L	SPI	ECS	✓	✓	✓	✓	
2000	Escort	2.0L	SPI	PATS	✓	✓	✓	✓	
2000	Escort	2.0L	SPI	PCM	✓	✓	✓	✓	0025
2000	Escort	2.0L	SPI	RAP	✓	✓	✓	✓	
2000	Escort	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
2000	Escort	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2000	Escort	2.0L	Zetec	ECS	✓	✓	✓	✓	
2000	Escort	2.0L	Zetec	PATS	✓	✓	✓	✓	
2000	Escort	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2000	Escort	2.0L	Zetec	RAP	✓	✓	✓	✓	
2000.5	Escort	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2000.5	Escort	1.6L	Zetec Rocam	CSM	✓	✓	✓	✓	
2000.5	Escort	1.6L	Zetec Rocam	HEC	✓	✓	✓	✓	
2000.5	Escort	1.6L	Zetec Rocam	PATS	✓	✓	✓	✓	
2000.5	Escort	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2002	Escort	2.0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
2002	Escort	2.0L	SPI	ECS	✓	✓	✓	✓	
2002	Escort	2.0L	SPI	PATS	✓	✓	✓	✓	
2002	Escort	2.0L	SPI	PCM	✓	✓	✓	✓	0025
2002	Escort	2.0L	SPI	RAP	✓	✓	✓	✓	
2002	Escort	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2002	Escort	2.0L	Zetec	ECS	✓	✓	✓	✓	
2002	Escort	2.0L	Zetec	PATS	✓	✓	✓	✓	
2002	Escort	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2002	Escort	2.0L	Zetec	RAP	✓	✓	✓	✓	
2003	Escort	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2003	Escort	2.0L	Zetec	ECS	✓	✓	✓	✓	
2003	Escort	2.0L	Zetec	PATS	✓	✓	✓	✓	
2003	Escort	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2003	Escort	2.0L	Zetec	RAP	✓	✓	✓	✓	
Other	Escort	1.6L	PT-E	ABS/TCS	✓	✓	✓	✓	
Other	Escort	1.6L	PT-E	CSM	✓	✓	✓	✓	
Other	Escort	1.6L	PT-E	HEC	✓	✓	✓	✓	
Other	Escort	1.6L	PT-E	PATS	✓	✓	✓	✓	
Other	Escort	1.6L	PT-E	PCM	✓	✓	✓	✓	
Other	Escort	1.8L	Endura-DE	ABS/TCS	✓	✓	✓	✓	
Other	Escort	1.8L	Endura-DE	CSM	✓	✓	✓	✓	
Other	Escort	1.8L	Endura-DE	HEC	✓	✓	✓	✓	
Other	Escort	1.8L	Endura-DE	PATS	✓	✓	✓	✓	
Other	Escort	1.8L	Endura-DE	PCM	✓	✓	✓	✓	
Other	Escort	1.8L	Endura-DE	PCM	✓	✓	✓	✓	
2007	Everest / Endeavour	2.5L	WL-CD	ABS/TCS	✓	✓	✓	✓	
2007	Everest / Endeavour	2.5L	WL-CD	PCM	✓	✓	✓	✓	
2007	Everest / Endeavour	2.5L	WL-CD	PCM	✓	✓	✓	✓	0055
2007	Everest / Endeavour	2.5L	WL-CD	PCM	✓	✓	✓	✓	0055, 00CE
2007	Everest / Endeavour	2.5L	WL-CD	RCM	✓	✓	✓	✓	
2007	Everest / Endeavour	2.5L	WL-CD	TCM	✓	✓	✓	✓	
2007	Everest / Endeavour	2.5L	WL-CD	TCM	✓	✓	✓	✓	00C5, 00CE
2007	Everest / Endeavour	2.6L	G6	ABS/TCS	✓	✓	✓	✓	
2007	Everest / Endeavour	2.6L	G6	PCM	✓	✓	✓	✓	
2007	Everest / Endeavour	2.6L	G6	RCM	✓	✓	✓	✓	
2007	Everest / Endeavour	3.0L	WE-CD	ABS/TCS	✓	✓	✓	✓	
2007	Everest / Endeavour	3.0L	WE-CD	PCM	✓	✓	✓	✓	
2007	Everest / Endeavour	3.0L	WE-CD	PCM	✓	✓	✓	✓	0055
2007	Everest / Endeavour	3.0L	WE-CD	PCM	✓	✓	✓	✓	0055, 00CE
2007	Everest / Endeavour	3.0L	WE-CD	RCM	✓	✓	✓	✓	
2007	Everest / Endeavour	3.0L	WE-CD	TCM	✓	✓	✓	✓	
2007	Everest / Endeavour	3.0L	WE-CD	TCM	✓	✓	✓	✓	00C5
2007	Everest / Endeavour	3.0L	WE-CD	TCM	✓	✓	✓	✓	00C5, 00CE
2000	Excursion	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Excursion	5.4L	Other	ECS	✓	✓	✓	✓	
2000	Excursion	5.4L	Other	GEM	✓	✓	✓	✓	





2005	Excursion	6. 8L	2V	RCM	✓	✓	✓	✓	
2005	Excursion	6. 8L	2V	VSM	✓	✓	✓	✓	
1997	Expedition	4. 6L	Other	4WAS	✓	✓	✓	✓	
1997	Expedition	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Expedition	4. 6L	Other	GEM	✓	✓	✓	✓	
1997	Expedition	4. 6L	Other	IAB	✓	✓	✓	✓	
1997	Expedition	4. 6L	Other	PATS	✓	✓	✓	✓	
1997	Expedition	4. 6L	Other	PCM	✓	✓	✓	✓	0025
1997	Expedition	4. 6L	Other	RAP	✓	✓	✓	✓	
1997	Expedition	5. 4L	Other	4WAS	✓	✓	✓	✓	
1997	Expedition	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Expedition	5. 4L	Other	GEM	✓	✓	✓	✓	
1997	Expedition	5. 4L	Other	IAB	✓	✓	✓	✓	
1997	Expedition	5. 4L	Other	PATS	✓	✓	✓	✓	
1997	Expedition	5. 4L	Other	PCM	✓	✓	✓	✓	0025
1997	Expedition	5. 4L	Other	RAP	✓	✓	✓	✓	
1998	Expedition	4. 6L	Other	4WAS	✓	✓	✓	✓	
1998	Expedition	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Expedition	4. 6L	Other	GEM	✓	✓	✓	✓	
1998	Expedition	4. 6L	Other	IAB	✓	✓	✓	✓	
1998	Expedition	4. 6L	Other	PATS	✓	✓	✓	✓	
1998	Expedition	4. 6L	Other	PCM	✓	✓	✓	✓	0025
1998	Expedition	4. 6L	Other	RAP	✓	✓	✓	✓	
1998	Expedition	4. 6L	Other	RCC	✓	✓	✓	✓	
1998	Expedition	5. 4L	Other	4WAS	✓	✓	✓	✓	
1998	Expedition	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Expedition	5. 4L	Other	GEM	✓	✓	✓	✓	
1998	Expedition	5. 4L	Other	IAB	✓	✓	✓	✓	
1998	Expedition	5. 4L	Other	PATS	✓	✓	✓	✓	
1998	Expedition	5. 4L	Other	PCM	✓	✓	✓	✓	0025
1998	Expedition	5. 4L	Other	RAP	✓	✓	✓	✓	
1998	Expedition	5. 4L	Other	RCC	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	4WAS	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	4WAS	✓	✓	✓	✓	000E
1999	Expedition	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Expedition	4. 6L	Other	EATC	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	GEM	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	HEC	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	PCM	✓	✓	✓	✓	0025
1999	Expedition	4. 6L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1999	Expedition	4. 6L	Other	RAP	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	RCM	✓	✓	✓	✓	
1999	Expedition	5. 4L	Other	4WAS	✓	✓	✓	✓	
1999	Expedition	5. 4L	Other	4WAS	✓	✓	✓	✓	000E
1999	Expedition	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Expedition	5. 4L	Other	EATC	✓	✓	✓	✓	
1999	Expedition	5. 4L	Other	GEM	✓	✓	✓	✓	
1999	Expedition	5. 4L	Other	HEC	✓	✓	✓	✓	
1999	Expedition	5. 4L	Other	PCM	✓	✓	✓	✓	0025
1999	Expedition	5. 4L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1999	Expedition	5. 4L	Other	RAP	✓	✓	✓	✓	
1999	Expedition	5. 4L	Other	RCM	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	4WAS	✓	✓	✓	✓	000E
2000	Expedition	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Expedition	4. 6L	Other	DSM	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	EATC	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	GEM	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	HEC	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	PAM	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	PCM	✓	✓	✓	✓	0025
2000	Expedition	4. 6L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Expedition	4. 6L	Other	RAP	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	RCM	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	4WAS	✓	✓	✓	✓	000E
2000	Expedition	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Expedition	5. 4L	Other	DSM	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	EATC	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	GEM	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	HEC	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	PAM	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Expedition	5. 4L	Other	RAP	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	RCM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	4X4	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	Expedition	4. 6L	2V	DCSM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	DSM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	EATC	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	HEC	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	PAM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	PAM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Expedition	4. 6L	2V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2003	Expedition	4. 6L	2V	PCSM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2003	Expedition	4. 6L	2V	TPM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2003	Expedition	4. 6L	2V	VSM	✓	✓	✓	✓	

2003	Expedition	5. 4L	2V	4X4	✓	✓	✓	✓	
2003	Expedition	5. 4L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	Expedition	5. 4L	2V	DCSM	✓	✓	✓	✓	
2003	Expedition	5. 4L	2V	DSM	✓	✓	✓	✓	
2003	Expedition	5. 4L	2V	EATC	✓	✓	✓	✓	
2003	Expedition	5. 4L	2V	HEC	✓	✓	✓	✓	
2003	Expedition	5. 4L	2V	PAM	✓	✓	✓	✓	
2003	Expedition	5. 4L	2V	PAM	✓	✓	✓	✓	
2003	Expedition	5. 4L	2V	PCM	✓	✓	✓	✓	0025
2003	Expedition	5. 4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Expedition	5. 4L	2V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2003	Expedition	5. 4L	2V	PCSM	✓	✓	✓	✓	
2003	Expedition	5. 4L	2V	RCM	✓	✓	✓	✓	000C
2003	Expedition	5. 4L	2V	TPM	✓	✓	✓	✓	
2003	Expedition	5. 4L	2V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2003	Expedition	5. 4L	2V	VSM	✓	✓	✓	✓	
2004	Expedition	4. 6L	2V	4X4	✓	✓	✓	✓	
2004	Expedition	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2004	Expedition	4. 6L	2V	DCSM	✓	✓	✓	✓	
2004	Expedition	4. 6L	2V	DSM	✓	✓	✓	✓	
2004	Expedition	4. 6L	2V	EATC	✓	✓	✓	✓	
2004	Expedition	4. 6L	2V	HEC	✓	✓	✓	✓	
2004	Expedition	4. 6L	2V	PAM	✓	✓	✓	✓	
2004	Expedition	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Expedition	4. 6L	2V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2004	Expedition	4. 6L	2V	PCSM	✓	✓	✓	✓	
2004	Expedition	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2004	Expedition	4. 6L	2V	TPM	✓	✓	✓	✓	
2004	Expedition	4. 6L	2V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2004	Expedition	4. 6L	2V	VSM	✓	✓	✓	✓	
2004	Expedition	5. 4L	2V	4X4	✓	✓	✓	✓	
2004	Expedition	5. 4L	2V	ABS/TCS	✓	✓	✓	✓	0008
2004	Expedition	5. 4L	2V	DCSM	✓	✓	✓	✓	
2004	Expedition	5. 4L	2V	DSM	✓	✓	✓	✓	
2004	Expedition	5. 4L	2V	EATC	✓	✓	✓	✓	
2004	Expedition	5. 4L	2V	HEC	✓	✓	✓	✓	
2004	Expedition	5. 4L	2V	PAM	✓	✓	✓	✓	
2004	Expedition	5. 4L	2V	PCM	✓	✓	✓	✓	0025
2004	Expedition	5. 4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Expedition	5. 4L	2V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2004	Expedition	5. 4L	2V	PCSM	✓	✓	✓	✓	
2004	Expedition	5. 4L	2V	RCM	✓	✓	✓	✓	000C
2004	Expedition	5. 4L	2V	TPM	✓	✓	✓	✓	
2004	Expedition	5. 4L	2V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2004	Expedition	5. 4L	2V	VSM	✓	✓	✓	✓	
2005	Expedition	5. 4L	3V	4X4	✓	✓	✓	✓	
2005	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2005	Expedition	5. 4L	3V	DCSM	✓	✓	✓	✓	
2005	Expedition	5. 4L	3V	DSM	✓	✓	✓	✓	
2005	Expedition	5. 4L	3V	EATC	✓	✓	✓	✓	
2005	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	
2005	Expedition	5. 4L	3V	PAM	✓	✓	✓	✓	
2005	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2005	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2005	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2005	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013
2005	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2005	Expedition	5. 4L	3V	VSM	✓	✓	✓	✓	
2006	Expedition	5. 4L	3V	4X4	✓	✓	✓	✓	
2006	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2006	Expedition	5. 4L	3V	DCSM	✓	✓	✓	✓	
2006	Expedition	5. 4L	3V	DSM	✓	✓	✓	✓	
2006	Expedition	5. 4L	3V	EATC	✓	✓	✓	✓	
2006	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	
2006	Expedition	5. 4L	3V	PAM	✓	✓	✓	✓	
2006	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	
2006	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2006	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013
2006	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2006	Expedition	5. 4L	3V	VSM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	4X4	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2007	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Expedition	5. 4L	3V	DCSM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	DCSM	✓	✓	✓	✓	F070
2007	Expedition	5. 4L	3V	DSM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	DSM	✓	✓	✓	✓	F041, F06C, F06D, F06F
2007	Expedition	5. 4L	3V	DSP	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	EATC	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	GEM	✓	✓	✓	✓	

2007	Expedition	5. 4L	3V	GEM	✓	✓	✓	✓	F03C, F042, F049, F05C, F060, F068, F069, F06A
2007	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	F041, F044, F04A, F04D, F06B, F06E
2007	Expedition	5. 4L	3V	LTM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	PAM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0016, 0016, 0016, 0017, 0017, 0017, 0018, 0018, 0018, 0019, 00C5, F04D, F05A, F05A
2007	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0016, 0016, 0016, 0017, 0017, 0017, 0018, 0018, 0018, 0019, F04D, F05A, F05A
2007	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 00C5
2007	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	F022, F05D
2007	Expedition	5. 4L	3V	RCU	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	RCU	✓	✓	✓	✓	F05A
2007	Expedition	5. 4L	3V	RETM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	RETM	✓	✓	✓	✓	F04D, F05A
2007	Expedition	5. 4L	3V	SDARS	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	SDARS	✓	✓	✓	✓	0019
2007	Expedition	5. 4L	3V	TCM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	TCM	✓	✓	✓	✓	00CE
2007	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2008	Expedition	5. 4L	3V	4X4	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2008	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2008	Expedition	5. 4L	3V	DCSM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	DSM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	DSM	✓	✓	✓	✓	0005
2008	Expedition	5. 4L	3V	DSP	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	HVAC	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	0005
2008	Expedition	5. 4L	3V	LTM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	PAM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	PAM	✓	✓	✓	✓	0005
2008	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0019
2008	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 00C5
2008	Expedition	5. 4L	3V	PRB	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	0005
2008	Expedition	5. 4L	3V	RCU	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	RETM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	RETM	✓	✓	✓	✓	0005
2008	Expedition	5. 4L	3V	SDARS	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2008	Expedition	5. 4L	3V	TCM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	TCM	✓	✓	✓	✓	00CE
2008	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2009	Expedition	5. 4L	3V	4X4	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012, 0067
2009	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Expedition	5. 4L	3V	APIM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Expedition	5. 4L	3V	DCSM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	DSM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	DSP	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	Expedition	5. 4L	3V	HVAC	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	LTM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	PAM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0067
2009	Expedition	5. 4L	3V	PRB	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	RCU	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	RETM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	SDARS	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	TCM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	TCM	✓	✓	✓	✓	00CE
2009	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	





2012	Expedition	5. 4L	3V	PRB	✓	✓	✓	✓	
2012	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	
2012	Expedition	5. 4L	3V	RCU	✓	✓	✓	✓	
2012	Expedition	5. 4L	3V	RCU	✓	✓	✓	✓	
2012	Expedition	5. 4L	3V	RETM	✓	✓	✓	✓	
2012	Expedition	5. 4L	3V	SDARS	✓	✓	✓	✓	
2012	Expedition	5. 4L	3V	TCCM	✓	✓	✓	✓	
2012	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	
2012	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2013	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	0012
2013	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2013	Expedition	5. 4L	3V	APIM	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	APIM	✓	✓	✓	✓	0019
2013	Expedition	5. 4L	3V	DCSM	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	DSM	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	DSP	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2013	Expedition	5. 4L	3V	GPSM	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	HVAC	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	LTM	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	PAM	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0018, 0025, 0028, 0028, 0031, 0031, 0033, 0067, 0108
2013	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033
2013	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	Expedition	5. 4L	3V	PRB	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	RCU	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	SDARS	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	TBC	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	TCCM	✓	✓	✓	✓	
2013	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2013	Expedition	Other	Other	ABS	✓	✓	✓	✓	
2013	Expedition	Other	Other	ACM	✓	✓	✓	✓	
2013	Expedition	Other	Other	APIM	✓	✓	✓	✓	
2013	Expedition	Other	Other	DCSM	✓	✓	✓	✓	
2013	Expedition	Other	Other	DSM	✓	✓	✓	✓	
2013	Expedition	Other	Other	DSP	✓	✓	✓	✓	
2013	Expedition	Other	Other	GEM / SJB	✓	✓	✓	✓	
2013	Expedition	Other	Other	GPSM	✓	✓	✓	✓	
2013	Expedition	Other	Other	HVAC	✓	✓	✓	✓	
2013	Expedition	Other	Other	IC	✓	✓	✓	✓	
2013	Expedition	Other	Other	LTM	✓	✓	✓	✓	
2013	Expedition	Other	Other	PAM	✓	✓	✓	✓	
2013	Expedition	Other	Other	PCM	✓	✓	✓	✓	
2013	Expedition	Other	Other	PCM	✓	✓	✓	✓	
2013	Expedition	Other	Other	PRB	✓	✓	✓	✓	
2013	Expedition	Other	Other	RCM	✓	✓	✓	✓	
2013	Expedition	Other	Other	RCU	✓	✓	✓	✓	
2013	Expedition	Other	Other	SDARS	✓	✓	✓	✓	
2013	Expedition	Other	Other	TBC	✓	✓	✓	✓	
2013	Expedition	Other	Other	TCCM	✓	✓	✓	✓	
2013	Expedition	Other	Other	VDM	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	0012
2014	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2014	Expedition	5. 4L	3V	APIM	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	APIM	✓	✓	✓	✓	0019
2014	Expedition	5. 4L	3V	DCSM	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	DSM	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	DSP	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2014	Expedition	5. 4L	3V	GPSM	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	HVAC	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	LTM	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	PAM	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0018, 0025, 0028, 0028, 0031, 0031, 0033, 0067, 0108
2014	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033
2014	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Expedition	5. 4L	3V	PRB	✓	✓	✓	✓	
2014	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	

2014	Expedition	5.4L	3V	RCU	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	SDARS	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	TBC	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	TCCM	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2007	Expedition EL	5.4L	3V	4X4	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2007	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Expedition EL	5.4L	3V	DCSM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	DSM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	DSP	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	EATC	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	GEM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	IC	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	LTM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	PAM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Expedition EL	5.4L	3V	RCM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	RCU	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	RET	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	SDARS	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	SDARS	✓	✓	✓	✓	0019
2007	Expedition EL	5.4L	3V	TCM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	TCM	✓	✓	✓	✓	00CE
2007	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2008	Expedition EL	5.4L	3V	4X4	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2008	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Expedition EL	5.4L	3V	DCSM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	DSM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	DSP	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	HVAC	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	IC	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	LTM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	PAM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Expedition EL	5.4L	3V	PRB	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	RCM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	RCU	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	RET	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	SDARS	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	SDARS	✓	✓	✓	✓	0019
2008	Expedition EL	5.4L	3V	TCM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	TCM	✓	✓	✓	✓	00CE
2008	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2009	Expedition EL	5.4L	3V	4X4	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012, 0067
2009	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	0016
2009	Expedition EL	5.4L	3V	APIM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Expedition EL	5.4L	3V	DCSM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	DSM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	DSP	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	Expedition EL	5.4L	3V	HVAC	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	IC	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	LTM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	PAM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓	0067
2009	Expedition EL	5.4L	3V	PRB	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	RCM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	RCU	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	RET	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	SDARS	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	TCM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2010	Expedition EL	5.4L	3V	4X4	✓	✓	✓	✓	
2010	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	
2010	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2010	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	
2010	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2010	Expedition EL	5.4L	3V	APIM	✓	✓	✓	✓	
2010	Expedition EL	5.4L	3V	APIM	✓	✓	✓	✓	0019, 001C



2013	Expedition EL	5. 4L	3V	LTM	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	PAM	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	Expedition EL	5. 4L	3V	PRB	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	RCM	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	RCU	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	SDARS	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	TBC	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	TCCM	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2013	Expedition EL	Other	Other	ABS	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	ACM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	APIM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	DCSM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	DSM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	DSP	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	GEM / SJB	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	GPSM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	HVAC	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	IC	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	LTM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	PAM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	PCM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	PRB	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	RCM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	RCU	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	SDARS	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	TBC	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	TCCM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	VDM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	ABS	✓	✓	✓	✓	0012
2014	Expedition EL	5. 4L	3V	ACM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2014	Expedition EL	5. 4L	3V	APIM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	APIM	✓	✓	✓	✓	0019
2014	Expedition EL	5. 4L	3V	DCSM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	DSM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	DSP	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2014	Expedition EL	5. 4L	3V	GPSM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	HVAC	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	IC	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	LTM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	PAM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Expedition EL	5. 4L	3V	PRB	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	RCM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	RCU	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	SDARS	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	TBC	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	TCCM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
1996	Explorer	4. 0L	Other	ABS/TCS	✓	✓	✓	✓	
1996	Explorer	4. 0L	Other	ARC	✓	✓	✓	✓	
1996	Explorer	4. 0L	Other	EATC	✓	✓	✓	✓	
1996	Explorer	4. 0L	Other	GEM	✓	✓	✓	✓	0203
1996	Explorer	4. 0L	Other	IAB	✓	✓	✓	✓	
1996	Explorer	4. 0L	Other	PCM	✓	✓	✓	✓	0025
1996	Explorer	4. 0L	Other	RAP	✓	✓	✓	✓	
1996	Explorer	4. 0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1996	Explorer	4. 0L	V6 OHV	ARC	✓	✓	✓	✓	
1996	Explorer	4. 0L	V6 OHV	EATC	✓	✓	✓	✓	
1996	Explorer	4. 0L	V6 OHV	GEM	✓	✓	✓	✓	0203
1996	Explorer	4. 0L	V6 OHV	IAB	✓	✓	✓	✓	
1996	Explorer	4. 0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1996	Explorer	4. 0L	V6 OHV	RAP	✓	✓	✓	✓	
1996	Explorer	5. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1996	Explorer	5. 0L	Other	EATC	✓	✓	✓	✓	
1996	Explorer	5. 0L	Other	GEM	✓	✓	✓	✓	0203
1996	Explorer	5. 0L	Other	IAB	✓	✓	✓	✓	
1996	Explorer	5. 0L	Other	PCM	✓	✓	✓	✓	0025
1996	Explorer	5. 0L	Other	RAP	✓	✓	✓	✓	
1997	Explorer	4. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Explorer	4. 0L	Other	ARC	✓	✓	✓	✓	
1997	Explorer	4. 0L	Other	EATC	✓	✓	✓	✓	
1997	Explorer	4. 0L	Other	GEM	✓	✓	✓	✓	0203
1997	Explorer	4. 0L	Other	IAB	✓	✓	✓	✓	
1997	Explorer	4. 0L	Other	PCM	✓	✓	✓	✓	0025
1997	Explorer	4. 0L	Other	RAP	✓	✓	✓	✓	
1997	Explorer	4. 0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	0008
1997	Explorer	4. 0L	V6 OHV	ARC	✓	✓	✓	✓	
1997	Explorer	4. 0L	V6 OHV	EATC	✓	✓	✓	✓	
1997	Explorer	4. 0L	V6 OHV	GEM	✓	✓	✓	✓	0203
1997	Explorer	4. 0L	V6 OHV	IAB	✓	✓	✓	✓	
1997	Explorer	4. 0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1997	Explorer	4. 0L	V6 OHV	RAP	✓	✓	✓	✓	

1997	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
1997	Explorer	4.0L	V6 SOHC	ARC	✓	✓	✓		
1997	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓		
1997	Explorer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
1997	Explorer	4.0L	V6 SOHC	IAB	✓	✓	✓		
1997	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
1997	Explorer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
1997	Explorer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Explorer	5.0L	Other	ARC	✓	✓	✓		
1997	Explorer	5.0L	Other	ARC	✓	✓	✓		000E
1997	Explorer	5.0L	Other	EATC	✓	✓	✓		
1997	Explorer	5.0L	Other	GEM	✓	✓	✓	✓	0203
1997	Explorer	5.0L	Other	IAB	✓	✓	✓		
1997	Explorer	5.0L	Other	PCM	✓	✓	✓	✓	0025
1997	Explorer	5.0L	Other	RAP	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Explorer	4.0L	Other	ARC	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	DSM	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	EATC	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	GEM	✓	✓	✓	✓	0203
1998	Explorer	4.0L	Other	IAB	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	PAM	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	PATS	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	PCM	✓	✓	✓	✓	0025
1998	Explorer	4.0L	Other	RAP	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	0008
1998	Explorer	4.0L	V6 OHV	ARC	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	DSM	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	EATC	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	GEM	✓	✓	✓	✓	0203
1998	Explorer	4.0L	V6 OHV	IAB	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	PAM	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	PATS	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1998	Explorer	4.0L	V6 OHV	RAP	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
1998	Explorer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
1998	Explorer	4.0L	V6 SOHC	IAB	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
1998	Explorer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Explorer	5.0L	Other	ARC	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	DSM	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	EATC	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	GEM	✓	✓	✓	✓	0203
1998	Explorer	5.0L	Other	IAB	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	PAM	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	PATS	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	PCM	✓	✓	✓	✓	0025
1998	Explorer	5.0L	Other	RAP	✓	✓	✓	✓	
1999	Explorer	4.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Explorer	4.0L	Other	ARC	✓	✓	✓	✓	000E
1999	Explorer	4.0L	Other	DSM	✓	✓	✓	✓	
1999	Explorer	4.0L	Other	EATC	✓	✓	✓	✓	
1999	Explorer	4.0L	Other	GEM	✓	✓	✓	✓	0203
1999	Explorer	4.0L	Other	PAM	✓	✓	✓	✓	
1999	Explorer	4.0L	Other	PATS	✓	✓	✓	✓	
1999	Explorer	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025
1999	Explorer	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
1999	Explorer	4.0L	Other	RAP	✓	✓	✓	✓	
1999	Explorer	4.0L	Other	RCM	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	0008
1999	Explorer	4.0L	V6 OHV	ARC	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	DSM	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	EATC	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	GEM	✓	✓	✓	✓	0203
1999	Explorer	4.0L	V6 OHV	PAM	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	PATS	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1999	Explorer	4.0L	V6 OHV	RAP	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	RCM	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
1999	Explorer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓	000E
1999	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
1999	Explorer	4.0L	V6 SOHC	MC	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
1999	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
1999	Explorer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	

1999	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
1999	Explorer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Explorer	5.0L	Other	ARC	✓	✓	✓	✓	000E
1999	Explorer	5.0L	Other	DSM	✓	✓	✓	✓	
1999	Explorer	5.0L	Other	EATC	✓	✓	✓	✓	
1999	Explorer	5.0L	Other	GEM	✓	✓	✓	✓	0005, 0203
1999	Explorer	5.0L	Other	GEM	✓	✓	✓	✓	0203
1999	Explorer	5.0L	Other	PAM	✓	✓	✓	✓	
1999	Explorer	5.0L	Other	PATS	✓	✓	✓	✓	
1999	Explorer	5.0L	Other	PCM	✓	✓	✓	✓	0005, 0008, 0025, 0028, 0031, 0033
1999	Explorer	5.0L	Other	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
1999	Explorer	5.0L	Other	RAP	✓	✓	✓	✓	
1999	Explorer	5.0L	Other	RAP	✓	✓	✓	✓	0005, F044
1999	Explorer	5.0L	Other	RCM	✓	✓	✓	✓	
2000	Explorer	4.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Explorer	4.0L	Other	ARC	✓	✓	✓	✓	000E
2000	Explorer	4.0L	Other	DSM	✓	✓	✓	✓	
2000	Explorer	4.0L	Other	EATC	✓	✓	✓	✓	
2000	Explorer	4.0L	Other	GEM	✓	✓	✓	✓	0203
2000	Explorer	4.0L	Other	PAM	✓	✓	✓	✓	
2000	Explorer	4.0L	Other	PATS	✓	✓	✓	✓	
2000	Explorer	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025
2000	Explorer	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2000	Explorer	4.0L	Other	RAP	✓	✓	✓	✓	
2000	Explorer	4.0L	Other	RCM	✓	✓	✓	✓	
2000	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2000	Explorer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓	000E
2000	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2000	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2000	Explorer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
2000	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2000	Explorer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓	
2000	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2000	Explorer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
2000	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2000	Explorer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0005, 0008
2000	Explorer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Explorer	5.0L	Other	ARC	✓	✓	✓	✓	000E
2000	Explorer	5.0L	Other	DSM	✓	✓	✓	✓	
2000	Explorer	5.0L	Other	EATC	✓	✓	✓	✓	
2000	Explorer	5.0L	Other	GEM	✓	✓	✓	✓	0005, 0203
2000	Explorer	5.0L	Other	GEM	✓	✓	✓	✓	0203
2000	Explorer	5.0L	Other	PAM	✓	✓	✓	✓	
2000	Explorer	5.0L	Other	PATS	✓	✓	✓	✓	
2000	Explorer	5.0L	Other	PCM	✓	✓	✓	✓	0005, 0008, 0025, 0028, 0031, 0033
2000	Explorer	5.0L	Other	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2000	Explorer	5.0L	Other	RAP	✓	✓	✓	✓	
2000	Explorer	5.0L	Other	RAP	✓	✓	✓	✓	0005, F044
2000	Explorer	5.0L	Other	RCM	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2002	Explorer	4.0L	V6 SOHC	CSM	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
2002	Explorer	4.0L	V6 SOHC	IC	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	4X4	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2002	Explorer	4.6L	2V	CSM	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	DSM	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	EATC	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	GEM	✓	✓	✓	✓	0203
2002	Explorer	4.6L	2V	IC	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	PAM	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Explorer	4.6L	2V	RCM	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2002.5	Explorer	4.0L	V6 SOHC	CSM	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	HEC	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002.5	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2002.5	Explorer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓	
2002.5	Explorer	4.6L	2V	4X4	✓	✓	✓	✓	
2002.5	Explorer	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2002.5	Explorer	4.6L	2V	CSM	✓	✓	✓	✓	
2002.5	Explorer	4.6L	2V	DSM	✓	✓	✓	✓	

2002.5	Explorer	4.6L	2V	EATC	✓	✓	✓	✓	
2002.5	Explorer	4.6L	2V	HEC	✓	✓	✓	✓	
2002.5	Explorer	4.6L	2V	PAM	✓	✓	✓	✓	
2002.5	Explorer	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002.5	Explorer	4.6L	2V	RCM	✓	✓	✓	✓	000C
2002.5	Explorer	4.6L	2V	TPM	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2003	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	HEC	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2003	Explorer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	VSM	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	4X4	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	Explorer	4.6L	2V	DSM	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	EATC	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	HEC	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	PAM	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Explorer	4.6L	2V	RCM	✓	✓	✓	✓	000C
2003	Explorer	4.6L	2V	TPM	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	VSM	✓	✓	✓	✓	
2004	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2004	Explorer	4.0L	V6 SOHC	ABS	✓	✓	✓	✓	0008, 0012
2004	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2004	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	0005
2004	Explorer	4.0L	V6 SOHC	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054, F071, F072
2004	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2004	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2004	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2004	Explorer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓	0005
2004	Explorer	4.0L	V6 SOHC	VSM	✓	✓	✓	✓	
2004	Explorer	4.6L	2V	4X4	✓	✓	✓	✓	
2004	Explorer	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2004	Explorer	4.6L	2V	DSM	✓	✓	✓	✓	
2004	Explorer	4.6L	2V	EATC	✓	✓	✓	✓	0005
2004	Explorer	4.6L	2V	IC	✓	✓	✓	✓	0005
2004	Explorer	4.6L	2V	PAM	✓	✓	✓	✓	
2004	Explorer	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Explorer	4.6L	2V	RCM	✓	✓	✓	✓	000C
2004	Explorer	4.6L	2V	TPM	✓	✓	✓	✓	0005
2004	Explorer	4.6L	2V	VSM	✓	✓	✓	✓	
2005	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2005	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	0111
2005	Explorer	4.0L	V6 SOHC	ABS	✓	✓	✓	✓	0005, 0008, 0012
2005	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2005	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2005	Explorer	4.0L	V6 SOHC	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054, F071, F072
2005	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2005	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2005	Explorer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓	0005
2005	Explorer	4.0L	V6 SOHC	VSM	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	4X4	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2005	Explorer	4.6L	2V	DSM	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	EATC	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	IC	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	PAM	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Explorer	4.6L	2V	RCM	✓	✓	✓	✓	000C
2005	Explorer	4.6L	2V	TPM	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	VSM	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	4X4	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2006	Explorer	4.0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2006	Explorer	4.0L	2V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F05A, F073
2006	Explorer	4.0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2006	Explorer	4.0L	2V	DSM	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	EATC	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	GEM	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2006	Explorer	4.0L	2V	IC	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	IC	✓	✓	✓	✓	F027, F040, F044, F04D, F054, F06B
2006	Explorer	4.0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2006	Explorer	4.0L	2V	PAM	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Explorer	4.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5



2006	Explorer	4. 0L	2V	PRB	✓	✓	✓	✓	
2006	Explorer	4. 0L	2V	RCM	✓	✓	✓	✓	
2006	Explorer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2006	Explorer	4. 0L	2V	RETM	✓	✓	✓	✓	
2006	Explorer	4. 0L	2V	RETM	✓	✓	✓	✓	F04D, F05A
2006	Explorer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005, 0019
2006	Explorer	4. 0L	2V	SDARS	✓	✓	✓	✓	0019
2006	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	0111
2006	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2006	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2006	Explorer	4. 6L	3V	DSM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	EATC	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	EATC	✓	✓	✓	✓	0005
2006	Explorer	4. 6L	3V	GEM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	GEM	✓	✓	✓	✓	0005
2006	Explorer	4. 6L	3V	IC	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2006	Explorer	4. 6L	3V	PAM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2006	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 00C5
2006	Explorer	4. 6L	3V	PRB	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	RCM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	RCM	✓	✓	✓	✓	0005
2006	Explorer	4. 6L	3V	RETM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	RETM	✓	✓	✓	✓	0005
2006	Explorer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2006	Explorer	4. 6L	3V	TCM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2007	Explorer	4. 0L	2V	4X4	✓	✓	✓	✓	
2007	Explorer	4. 0L	2V	ABS	✓	✓	✓	✓	
2007	Explorer	4. 0L	2V	ACM	✓	✓	✓	✓	0005, 0008, 0012
2007	Explorer	4. 0L	2V	DSM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F05A, F073
2007	Explorer	4. 0L	2V	EATC	✓	✓	✓	✓	F041, F074, F075
2007	Explorer	4. 0L	2V	GEM	✓	✓	✓	✓	
2007	Explorer	4. 0L	2V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2007	Explorer	4. 0L	2V	IC	✓	✓	✓	✓	F027, F040, F044, F04D, F054, F06B
2007	Explorer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Explorer	4. 0L	2V	PAM	✓	✓	✓	✓	
2007	Explorer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Explorer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Explorer	4. 0L	2V	PRB	✓	✓	✓	✓	
2007	Explorer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Explorer	4. 0L	2V	RETM	✓	✓	✓	✓	F04D, F05A
2007	Explorer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	0111
2007	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2007	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F04D, F05A, F073
2007	Explorer	4. 6L	3V	DSM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	EATC	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	EATC	✓	✓	✓	✓	0005
2007	Explorer	4. 6L	3V	GEM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2007	Explorer	4. 6L	3V	IC	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	IC	✓	✓	✓	✓	F044
2007	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Explorer	4. 6L	3V	PAM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2007	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2007	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Explorer	4. 6L	3V	PRB	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	RCM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Explorer	4. 6L	3V	RETM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	RETM	✓	✓	✓	✓	0005, F04D, F05A
2007	Explorer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Explorer	4. 6L	3V	TCM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2008	Explorer	4. 0L	2V	4X4	✓	✓	✓	✓	
2008	Explorer	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2008	Explorer	4. 0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012

2008	Explorer	4. 0L	2V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F05A, F073
2008	Explorer	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2008	Explorer	4. 0L	2V	DSM	✓	✓	✓	✓	F041, F074, F075
2008	Explorer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2008	Explorer	4. 0L	2V	HVAC	✓	✓	✓	✓	
2008	Explorer	4. 0L	2V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2008	Explorer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Explorer	4. 0L	2V	PAM	✓	✓	✓	✓	
2008	Explorer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Explorer	4. 0L	2V	PRB	✓	✓	✓	✓	
2008	Explorer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2008	Explorer	4. 0L	2V	RETM	✓	✓	✓	✓	F04D, F05A
2008	Explorer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005
2008	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	0111
2008	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2008	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Explorer	4. 6L	3V	APIM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2008	Explorer	4. 6L	3V	DSM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	DSM	✓	✓	✓	✓	F041, F074, F075
2008	Explorer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2008	Explorer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042, F042, F044, F04C
2008	Explorer	4. 6L	3V	HVAC	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	IC	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2008	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Explorer	4. 6L	3V	PAM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0028, 0031, 0031, 0031, 0033, 0033, 0033, 00C5
2008	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2008	Explorer	4. 6L	3V	PRB	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	RCM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	RCM	✓	✓	✓	✓	F022, F05D
2008	Explorer	4. 6L	3V	RETM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	RETM	✓	✓	✓	✓	F05A
2008	Explorer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	TCM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2009	Explorer	4. 0L	2V	4X4	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2009	Explorer	4. 0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2009	Explorer	4. 0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	Explorer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Explorer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0018
2009	Explorer	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2009	Explorer	4. 0L	2V	DSM	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	DSM	✓	✓	✓	✓	0005, F041, F074, F075
2009	Explorer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2009	Explorer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	Explorer	4. 0L	2V	HVAC	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	HVAC	✓	✓	✓	✓	0005
2009	Explorer	4. 0L	2V	IC	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	IC	✓	✓	✓	✓	0005, F044
2009	Explorer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Explorer	4. 0L	2V	PAM	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Explorer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Explorer	4. 0L	2V	PRB	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	RCM	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Explorer	4. 0L	2V	RETM	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	RETM	✓	✓	✓	✓	F04D, F05A, F076
2009	Explorer	4. 0L	2V	SDARS	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005
2009	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	
2009	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	
2009	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2009	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2009	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0018
2009	Explorer	4. 6L	3V	APIM	✓	✓	✓	✓	
2009	Explorer	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Explorer	4. 6L	3V	DSM	✓	✓	✓	✓	
2009	Explorer	4. 6L	3V	DSM	✓	✓	✓	✓	0005, F041, F074, F075

2009	Explorer	4.6L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2009	Explorer	4.6L	3V	HVAC	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	HVAC	✓	✓	✓	✓	0005
2009	Explorer	4.6L	3V	IC	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2009	Explorer	4.6L	3V	OCSM	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Explorer	4.6L	3V	PAM	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	PCM	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2009	Explorer	4.6L	3V	PRB	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	RCM	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Explorer	4.6L	3V	RETM	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	RETM	✓	✓	✓	✓	F04D, F05A, F076
2009	Explorer	4.6L	3V	SDARS	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	TCM	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	TCM	✓	✓	✓	✓	00CE
2010	Explorer	4.0L	2V	4X4	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	4X4	✓	✓	✓	✓	0111
2010	Explorer	4.0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	Explorer	4.0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2010	Explorer	4.0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0018
2010	Explorer	4.0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2010	Explorer	4.0L	2V	DSM	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	GEM / SJB	✓	✓	✓	✓	0042
2010	Explorer	4.0L	2V	GPSM	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	HVAC	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	IC	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Explorer	4.0L	2V	PAM	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	PCM	✓	✓	✓	✓	0025
2010	Explorer	4.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Explorer	4.0L	2V	PRB	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	RCM	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	RETM	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	SDARS	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	4X4	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	ABS	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Explorer	4.6L	3V	ACM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2010	Explorer	4.6L	3V	ACM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0018
2010	Explorer	4.6L	3V	APIM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2010	Explorer	4.6L	3V	DSM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	DSM	✓	✓	✓	✓	0005, F041, F074, F075
2010	Explorer	4.6L	3V	GEM / SJB	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2010	Explorer	4.6L	3V	GPSM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	HVAC	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	HVAC	✓	✓	✓	✓	0005
2010	Explorer	4.6L	3V	IC	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2010	Explorer	4.6L	3V	OCSM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Explorer	4.6L	3V	PAM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	PCM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2010	Explorer	4.6L	3V	PRB	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	RCM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	RETM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	RETM	✓	✓	✓	✓	F04D, F05A, F076
2010	Explorer	4.6L	3V	SDARS	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	TCM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	TCM	✓	✓	✓	✓	00CE
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM	✓	✓	✓	✓	

2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D5, 00FE
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	CLM#1	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TPM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2011	Explorer	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	ATCM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	Explorer	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2011	Explorer	3.5L	TiVCT	CLM#1	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	DSM	✓	✓	✓	✓	

2011	Explorer	3.5L	TiVCT	DSP	✓	✓	✓		
2011	Explorer	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	FLM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	HSWM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C
2011	Explorer	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	PCM	✓	✓	✓	✓	0067, 0095
2011	Explorer	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	TPM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM#1	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C

2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0095
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TPM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	Explorer	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	ATCM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	Explorer	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2012	Explorer	3.5L	TiVCT	CLM#1	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	FLM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	GPMS	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C
2012	Explorer	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	PCM	✓	✓	✓	✓	0067, 0095
2012	Explorer	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	TPM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ATCM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE

2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	CLM#1	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0095
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	

2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	0028, 0031, 0033
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ATCM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	CLM#1	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108



2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	ABS	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	Explorer	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	ATCM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Explorer	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Explorer	3.5L	TiVCT	CLM#1	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	FLM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	GFM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	HSWM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2013	Explorer	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	Explorer	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2013	Explorer	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	Explorer	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	ATCM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Explorer	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Explorer	3.7L	TiVCT	CLM#1	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	GFM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2013	Explorer	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	Explorer	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095
2013	Explorer	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	RTM	✓	✓	✓	✓	

2013	Explorer	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM#1	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00CE, 0108
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	

2014	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ATCM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	CLM#1	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	

2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2014	Explorer	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	ATCM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Explorer	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Explorer	3.5L	TiVCT	CLM#1	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	FLM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	GFM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	HSWM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	Explorer	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Explorer	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Explorer	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2014	Explorer	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	ATCM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Explorer	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Explorer	3.7L	TiVCT	CLM#1	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	GFM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	Explorer	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Explorer	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Explorer	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Explorer	Other	Other	ABS	✓	✓	✓	✓	
2014	Explorer	Other	Other	ACM	✓	✓	✓	✓	
2014	Explorer	Other	Other	APIM	✓	✓	✓	✓	
2014	Explorer	Other	Other	ATCM	✓	✓	✓	✓	
2014	Explorer	Other	Other	BCM#1	✓	✓	✓	✓	



2004	Explorer SportTrac	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2005	Explorer SportTrac	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2005	Explorer SportTrac	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2005	Explorer SportTrac	4.0L	V6 SOHC	HEC	✓	✓	✓	✓	
2005	Explorer SportTrac	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Explorer SportTrac	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
2005	Explorer SportTrac	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2007	Explorer SportTrac	4.0L	2V	4X4	✓	✓	✓	✓	
2007	Explorer SportTrac	4.0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2007	Explorer SportTrac	4.0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Explorer SportTrac	4.0L	2V	EATC	✓	✓	✓	✓	
2007	Explorer SportTrac	4.0L	2V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2007	Explorer SportTrac	4.0L	2V	IC	✓	✓	✓	✓	F027, F040, F044, F04D, F054, F06B
2007	Explorer SportTrac	4.0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Explorer SportTrac	4.0L	2V	PAM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Explorer SportTrac	4.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Explorer SportTrac	4.0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Explorer SportTrac	4.0L	2V	RETM	✓	✓	✓	✓	F04D, F05A
2007	Explorer SportTrac	4.0L	2V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Explorer SportTrac	4.6L	3V	4X4	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	4X4	✓	✓	✓	✓	0111
2007	Explorer SportTrac	4.6L	3V	ABS	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2007	Explorer SportTrac	4.6L	3V	ACM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Explorer SportTrac	4.6L	3V	EATC	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	EATC	✓	✓	✓	✓	0005
2007	Explorer SportTrac	4.6L	3V	GEM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	GEM	✓	✓	✓	✓	0005
2007	Explorer SportTrac	4.6L	3V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2007	Explorer SportTrac	4.6L	3V	IC	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	IC	✓	✓	✓	✓	F044
2007	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Explorer SportTrac	4.6L	3V	PAM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	PAM	✓	✓	✓	✓	0005
2007	Explorer SportTrac	4.6L	3V	PCM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2007	Explorer SportTrac	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Explorer SportTrac	4.6L	3V	RCM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	RCM	✓	✓	✓	✓	0005
2007	Explorer SportTrac	4.6L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Explorer SportTrac	4.6L	3V	RETM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	RETM	✓	✓	✓	✓	0005
2007	Explorer SportTrac	4.6L	3V	RETM	✓	✓	✓	✓	0005, F04D, F05A
2007	Explorer SportTrac	4.6L	3V	SDARS	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Explorer SportTrac	4.6L	3V	TCM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	TCM	✓	✓	✓	✓	00CE
2008	Explorer SportTrac	4.0L	2V	4X4	✓	✓	✓	✓	
2008	Explorer SportTrac	4.0L	2V	4X4	✓	✓	✓	✓	0111
2008	Explorer SportTrac	4.0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2008	Explorer SportTrac	4.0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Explorer SportTrac	4.0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2008	Explorer SportTrac	4.0L	2V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2008	Explorer SportTrac	4.0L	2V	HVAC	✓	✓	✓	✓	
2008	Explorer SportTrac	4.0L	2V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2008	Explorer SportTrac	4.0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Explorer SportTrac	4.0L	2V	PAM	✓	✓	✓	✓	
2008	Explorer SportTrac	4.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Explorer SportTrac	4.0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2008	Explorer SportTrac	4.0L	2V	RETM	✓	✓	✓	✓	F04D, F05A
2008	Explorer SportTrac	4.0L	2V	SDARS	✓	✓	✓	✓	0005
2008	Explorer SportTrac	4.6L	3V	4X4	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	4X4	✓	✓	✓	✓	0111
2008	Explorer SportTrac	4.6L	3V	ABS	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2008	Explorer SportTrac	4.6L	3V	ACM	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Explorer SportTrac	4.6L	3V	APIM	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2008	Explorer SportTrac	4.6L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2008	Explorer SportTrac	4.6L	3V	GEM / SJB	✓	✓	✓	✓	0042, F042, F044, F04C
2008	Explorer SportTrac	4.6L	3V	HVAC	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	IC	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2008	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Explorer SportTrac	4.6L	3V	PAM	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	PCM	✓	✓	✓	✓	

2008	Explorer SportTrac	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0028, 0031, 0031, 0031, 0033, 0033, 0033, 00C5
2008	Explorer SportTrac	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2008	Explorer SportTrac	4. 6L	3V	RCM	✓	✓	✓	✓	
2008	Explorer SportTrac	4. 6L	3V	RCM	✓	✓	✓	✓	F022, F05D
2008	Explorer SportTrac	4. 6L	3V	RETM	✓	✓	✓	✓	
2008	Explorer SportTrac	4. 6L	3V	RETM	✓	✓	✓	✓	F05A
2008	Explorer SportTrac	4. 6L	3V	SDARS	✓	✓	✓	✓	
2008	Explorer SportTrac	4. 6L	3V	TCM	✓	✓	✓	✓	
2008	Explorer SportTrac	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2009	Explorer SportTrac	4. 0L	2V	4X4	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2009	Explorer SportTrac	4. 0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	Explorer SportTrac	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Explorer SportTrac	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0018
2009	Explorer SportTrac	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2009	Explorer SportTrac	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2009	Explorer SportTrac	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	Explorer SportTrac	4. 0L	2V	HVAC	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	HVAC	✓	✓	✓	✓	0005
2009	Explorer SportTrac	4. 0L	2V	IC	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	IC	✓	✓	✓	✓	0005, F044
2009	Explorer SportTrac	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Explorer SportTrac	4. 0L	2V	PAM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Explorer SportTrac	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Explorer SportTrac	4. 0L	2V	RCM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Explorer SportTrac	4. 0L	2V	RETM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	SDARS	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	SDARS	✓	✓	✓	✓	0005
2009	Explorer SportTrac	4. 6L	3V	4X4	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	ABS	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2009	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2009	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0018
2009	Explorer SportTrac	4. 6L	3V	APIM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Explorer SportTrac	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2009	Explorer SportTrac	4. 6L	3V	HVAC	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	HVAC	✓	✓	✓	✓	0005
2009	Explorer SportTrac	4. 6L	3V	IC	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2009	Explorer SportTrac	4. 6L	3V	OCSM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Explorer SportTrac	4. 6L	3V	PAM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2009	Explorer SportTrac	4. 6L	3V	PCM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2009	Explorer SportTrac	4. 6L	3V	RCM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Explorer SportTrac	4. 6L	3V	RETM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	SDARS	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	TCM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2010	Explorer SportTrac	4. 0L	2V	4X4	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2010	Explorer SportTrac	4. 0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	Explorer SportTrac	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2010	Explorer SportTrac	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0018
2010	Explorer SportTrac	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2010	Explorer SportTrac	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0042
2010	Explorer SportTrac	4. 0L	2V	GPSM	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	HVAC	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	IC	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Explorer SportTrac	4. 0L	2V	PAM	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	PCM	✓	✓	✓	✓	0025
2010	Explorer SportTrac	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Explorer SportTrac	4. 0L	2V	RCM	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	RETM	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	SDARS	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 6L	3V	4X4	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 6L	3V	ABS	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2010	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2010	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	

2010	Explorer SportTrac	4.6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0018
2010	Explorer SportTrac	4.6L	3V	APIM	✓	✓	✓		
2010	Explorer SportTrac	4.6L	3V	APIM	✓	✓	✓		0019, 001C
2010	Explorer SportTrac	4.6L	3V	GEM / SJB	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2010	Explorer SportTrac	4.6L	3V	GPSM	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	HVAC	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	HVAC	✓	✓	✓	✓	0005
2010	Explorer SportTrac	4.6L	3V	IC	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2010	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Explorer SportTrac	4.6L	3V	PAM	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	PAM	✓	✓	✓	✓	0005
2010	Explorer SportTrac	4.6L	3V	PCM	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2010	Explorer SportTrac	4.6L	3V	RCM	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	RETN	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	SDARS	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	TCM	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	TCM	✓	✓	✓	✓	00CE
1997	F-150	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	F-150	4.2L	Other	GEM	✓	✓	✓	✓	
1997	F-150	4.2L	Other	IAB	✓	✓	✓	✓	
1997	F-150	4.2L	Other	PCM	✓	✓	✓	✓	0025
1997	F-150	4.2L	Other	RAP	✓	✓	✓	✓	
1997	F-150	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	F-150	4.6L	Other	GEM	✓	✓	✓	✓	
1997	F-150	4.6L	Other	IAB	✓	✓	✓	✓	
1997	F-150	4.6L	Other	PCM	✓	✓	✓	✓	0025
1997	F-150	4.6L	Other	RAP	✓	✓	✓	✓	
1997	F-150	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	F-150	5.4L	Other	GEM	✓	✓	✓	✓	
1997	F-150	5.4L	Other	IAB	✓	✓	✓	✓	
1997	F-150	5.4L	Other	PCM	✓	✓	✓	✓	0025
1997	F-150	5.4L	Other	RAP	✓	✓	✓	✓	
1998	F-150	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	F-150	4.2L	Other	GEM	✓	✓	✓	✓	
1998	F-150	4.2L	Other	IAB	✓	✓	✓	✓	
1998	F-150	4.2L	Other	PCM	✓	✓	✓	✓	0025
1998	F-150	4.2L	Other	RAP	✓	✓	✓	✓	
1998	F-150	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	F-150	4.6L	Other	GEM	✓	✓	✓	✓	
1998	F-150	4.6L	Other	IAB	✓	✓	✓	✓	
1998	F-150	4.6L	Other	PCM	✓	✓	✓	✓	0025
1998	F-150	4.6L	Other	RAP	✓	✓	✓	✓	
1998	F-150	5.4L	BIF	ABS/TCS	✓	✓	✓	✓	0008
1998	F-150	5.4L	BIF	AFCM	✓	✓	✓	✓	
1998	F-150	5.4L	BIF	GEM	✓	✓	✓	✓	
1998	F-150	5.4L	BIF	IAB	✓	✓	✓	✓	
1998	F-150	5.4L	BIF	PCM	✓	✓	✓	✓	
1998	F-150	5.4L	BIF	RAP	✓	✓	✓	✓	
1998	F-150	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	F-150	5.4L	Other	GEM	✓	✓	✓	✓	
1998	F-150	5.4L	Other	IAB	✓	✓	✓	✓	
1998	F-150	5.4L	Other	PCM	✓	✓	✓	✓	0025
1998	F-150	5.4L	Other	RAP	✓	✓	✓	✓	
1999	F-150	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-150	4.2L	Other	GEM	✓	✓	✓	✓	
1999	F-150	4.2L	Other	IAB	✓	✓	✓	✓	
1999	F-150	4.2L	Other	IC	✓	✓	✓	✓	
1999	F-150	4.2L	Other	PCM	✓	✓	✓	✓	0025
1999	F-150	4.2L	Other	RAP	✓	✓	✓	✓	
1999	F-150	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-150	4.6L	Other	GEM	✓	✓	✓	✓	
1999	F-150	4.6L	Other	IAB	✓	✓	✓	✓	
1999	F-150	4.6L	Other	IC	✓	✓	✓	✓	
1999	F-150	4.6L	Other	PCM	✓	✓	✓	✓	0025
1999	F-150	4.6L	Other	RAP	✓	✓	✓	✓	
1999	F-150	5.4L	BIF	ABS/TCS	✓	✓	✓	✓	0008
1999	F-150	5.4L	BIF	AFCM	✓	✓	✓	✓	
1999	F-150	5.4L	BIF	GEM	✓	✓	✓	✓	
1999	F-150	5.4L	BIF	IAB	✓	✓	✓	✓	
1999	F-150	5.4L	BIF	IC	✓	✓	✓	✓	
1999	F-150	5.4L	BIF	PCM	✓	✓	✓	✓	
1999	F-150	5.4L	BIF	RAP	✓	✓	✓	✓	
1999	F-150	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-150	5.4L	Other	GEM	✓	✓	✓	✓	
1999	F-150	5.4L	Other	IAB	✓	✓	✓	✓	
1999	F-150	5.4L	Other	IC	✓	✓	✓	✓	
1999	F-150	5.4L	Other	PCM	✓	✓	✓	✓	0025
1999	F-150	5.4L	Other	RAP	✓	✓	✓	✓	
2000	F-150	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	F-150	4.2L	Other	GEM	✓	✓	✓	✓	
2000	F-150	4.2L	Other	IAB	✓	✓	✓	✓	



2000	F-150	4. 2L	Other	IC	✓	✓	✓	✓	
2000	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025
2000	F-150	4. 2L	Other	RAP	✓	✓	✓	✓	
2000	F-150	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	
2000	F-150	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	F-150	4. 6L	Other	GEM	✓	✓	✓	✓	
2000	F-150	4. 6L	Other	IAB	✓	✓	✓	✓	
2000	F-150	4. 6L	Other	IC	✓	✓	✓	✓	
2000	F-150	4. 6L	Other	PCM	✓	✓	✓	✓	0025
2000	F-150	4. 6L	Other	RAP	✓	✓	✓	✓	
2000	F-150	5. 4L	BIF	ABS/TCS	✓	✓	✓	✓	0008
2000	F-150	5. 4L	BIF	AFCM	✓	✓	✓	✓	
2000	F-150	5. 4L	BIF	GEM	✓	✓	✓	✓	
2000	F-150	5. 4L	BIF	IAB	✓	✓	✓	✓	
2000	F-150	5. 4L	BIF	IC	✓	✓	✓	✓	
2000	F-150	5. 4L	BIF	PCM	✓	✓	✓	✓	
2000	F-150	5. 4L	BIF	PCM	✓	✓	✓	✓	0025
2000	F-150	5. 4L	BIF	RAP	✓	✓	✓	✓	
2000	F-150	5. 4L	NGV	ABS/TCS	✓	✓	✓	✓	0008
2000	F-150	5. 4L	NGV	ABS/TCS	✓	✓	✓	✓	0008, 001B
2000	F-150	5. 4L	NGV	FIM	✓	✓	✓	✓	
2000	F-150	5. 4L	NGV	GEM	✓	✓	✓	✓	
2000	F-150	5. 4L	NGV	IAB	✓	✓	✓	✓	
2000	F-150	5. 4L	NGV	IC	✓	✓	✓	✓	
2000	F-150	5. 4L	NGV	PCM	✓	✓	✓	✓	
2000	F-150	5. 4L	NGV	PCM	✓	✓	✓	✓	0025
2000	F-150	5. 4L	NGV	RAP	✓	✓	✓	✓	
2000	F-150	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	F-150	5. 4L	Other	GEM	✓	✓	✓	✓	
2000	F-150	5. 4L	Other	IAB	✓	✓	✓	✓	
2000	F-150	5. 4L	Other	IC	✓	✓	✓	✓	
2000	F-150	5. 4L	Other	PCM	✓	✓	✓	✓	0025
2000	F-150	5. 4L	Other	RAP	✓	✓	✓	✓	
2002	F-150	4. 2L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	F-150	4. 2L	Other	GEM	✓	✓	✓	✓	
2002	F-150	4. 2L	Other	IC	✓	✓	✓	✓	
2002	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025
2002	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	F-150	4. 2L	Other	RAP	✓	✓	✓	✓	
2002	F-150	4. 2L	Other	RCM	✓	✓	✓	✓	
2002	F-150	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	F-150	4. 6L	Other	GEM	✓	✓	✓	✓	
2002	F-150	4. 6L	Other	IC	✓	✓	✓	✓	
2002	F-150	4. 6L	Other	PCM	✓	✓	✓	✓	0025
2002	F-150	4. 6L	Other	RAP	✓	✓	✓	✓	
2002	F-150	4. 6L	Other	RCM	✓	✓	✓	✓	
2002	F-150	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	F-150	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008, 001B
2002	F-150	5. 4L	Other	AFCM	✓	✓	✓	✓	
2002	F-150	5. 4L	Other	FIM	✓	✓	✓	✓	
2002	F-150	5. 4L	Other	GEM	✓	✓	✓	✓	
2002	F-150	5. 4L	Other	IC	✓	✓	✓	✓	
2002	F-150	5. 4L	Other	PCM	✓	✓	✓	✓	0025
2002	F-150	5. 4L	Other	RAP	✓	✓	✓	✓	
2002	F-150	5. 4L	Other	RCM	✓	✓	✓	✓	
2003	F-150	4. 2L	Other	ABS/TCS	✓	✓	✓	✓	0008
2003	F-150	4. 2L	Other	GEM	✓	✓	✓	✓	
2003	F-150	4. 2L	Other	IC	✓	✓	✓	✓	
2003	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025
2003	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	F-150	4. 2L	Other	RAP	✓	✓	✓	✓	
2003	F-150	4. 2L	Other	RCM	✓	✓	✓	✓	
2003	F-150	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	F-150	4. 6L	2V	GEM	✓	✓	✓	✓	
2003	F-150	4. 6L	2V	IC	✓	✓	✓	✓	
2003	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025
2003	F-150	4. 6L	2V	RAP	✓	✓	✓	✓	
2003	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	
2003	F-150	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2003	F-150	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008, 001B
2003	F-150	5. 4L	Other	AFCM	✓	✓	✓	✓	
2003	F-150	5. 4L	Other	FIM	✓	✓	✓	✓	
2003	F-150	5. 4L	Other	GEM	✓	✓	✓	✓	
2003	F-150	5. 4L	Other	IC	✓	✓	✓	✓	
2003	F-150	5. 4L	Other	PCM	✓	✓	✓	✓	0008, 001B, 0025
2003	F-150	5. 4L	Other	PCM	✓	✓	✓	✓	0025
2003	F-150	5. 4L	Other	RAP	✓	✓	✓	✓	
2003	F-150	5. 4L	Other	RCM	✓	✓	✓	✓	
2004	F-150	4. 2L	Other	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	F-150	4. 2L	Other	GEM	✓	✓	✓	✓	
2004	F-150	4. 2L	Other	IC	✓	✓	✓	✓	
2004	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025
2004	F-150	4. 2L	Other	RAP	✓	✓	✓	✓	
2004	F-150	4. 2L	Other	RCM	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	4X4	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0008, 000B
2004	F-150	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	EATC	✓	✓	✓	✓	

2004	F-150	4. 6L	2V	GEM	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	IC	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025
2004	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	F-150	4. 6L	2V	RAP	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2004	F-150	4. 6L	2V	VSM	✓	✓	✓	✓	
2004	F-150	5. 4L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	F-150	5. 4L	2V	AFCM	✓	✓	✓	✓	
2004	F-150	5. 4L	2V	FIM	✓	✓	✓	✓	
2004	F-150	5. 4L	2V	GEM	✓	✓	✓	✓	
2004	F-150	5. 4L	2V	IC	✓	✓	✓	✓	
2004	F-150	5. 4L	2V	PCM	✓	✓	✓	✓	0025
2004	F-150	5. 4L	2V	RAP	✓	✓	✓	✓	
2004	F-150	5. 4L	2V	RCM	✓	✓	✓	✓	
2004	F-150	5. 4L	3V	4X4	✓	✓	✓	✓	
2004	F-150	5. 4L	3V	4X4	✓	✓	✓	✓	0143
2004	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008, 000B
2004	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 000B
2004	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	
2004	F-150	5. 4L	3V	EATC	✓	✓	✓	✓	
2004	F-150	5. 4L	3V	IC	✓	✓	✓	✓	
2004	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2004	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	0025
2004	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2004	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2004	F-150	5. 4L	3V	VSM	✓	✓	✓	✓	
2004	F-150	Other	Other	4X4	✓	✓	✓	✓	
2004	F-150	Other	Other	ABS	✓	✓	✓	✓	
2004	F-150	Other	Other	DSM	✓	✓	✓	✓	
2004	F-150	Other	Other	EATC	✓	✓	✓	✓	
2004	F-150	Other	Other	IC	✓	✓	✓	✓	
2004	F-150	Other	Other	PAM	✓	✓	✓	✓	
2004	F-150	Other	Other	PCM	✓	✓	✓	✓	
2004	F-150	Other	Other	RCM	✓	✓	✓	✓	
2004	F-150	Other	Other	VSM	✓	✓	✓	✓	
2005	F-150	4. 2L	2V	4X4	✓	✓	✓	✓	
2005	F-150	4. 2L	2V	ABS	✓	✓	✓	✓	0005, 0008, 000B
2005	F-150	4. 2L	2V	DSM	✓	✓	✓	✓	
2005	F-150	4. 2L	2V	EATC	✓	✓	✓	✓	
2005	F-150	4. 2L	2V	IC	✓	✓	✓	✓	F071
2005	F-150	4. 2L	2V	PAM	✓	✓	✓	✓	
2005	F-150	4. 2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	F-150	4. 2L	2V	RCM	✓	✓	✓	✓	000C
2005	F-150	4. 2L	2V	VSM	✓	✓	✓	✓	
2005	F-150	4. 2L	Other	ABS/TCS	✓	✓	✓	✓	0008, 001B
2005	F-150	4. 2L	Other	GEM	✓	✓	✓	✓	
2005	F-150	4. 2L	Other	IC	✓	✓	✓	✓	
2005	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025
2005	F-150	4. 2L	Other	RAP	✓	✓	✓	✓	
2005	F-150	4. 2L	Other	RCM	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	4X4	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0008, 000B
2005	F-150	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2005	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	EATC	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	GEM	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	IC	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025
2005	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	F-150	4. 6L	2V	RAP	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2005	F-150	4. 6L	2V	VSM	✓	✓	✓	✓	
2005	F-150	5. 4L	3V	4X4	✓	✓	✓	✓	
2005	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008, 000B
2005	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 000B
2005	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	
2005	F-150	5. 4L	3V	EATC	✓	✓	✓	✓	
2005	F-150	5. 4L	3V	IC	✓	✓	✓	✓	F071
2005	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2005	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	0025
2005	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2005	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2005	F-150	5. 4L	3V	VSM	✓	✓	✓	✓	
2006	F-150	4. 2L	2V	4X4	✓	✓	✓	✓	
2006	F-150	4. 2L	2V	ABS	✓	✓	✓	✓	0005, 0008, 000B
2006	F-150	4. 2L	2V	DSM	✓	✓	✓	✓	
2006	F-150	4. 2L	2V	EATC	✓	✓	✓	✓	
2006	F-150	4. 2L	2V	IC	✓	✓	✓	✓	
2006	F-150	4. 2L	2V	PAM	✓	✓	✓	✓	
2006	F-150	4. 2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	F-150	4. 2L	2V	RCM	✓	✓	✓	✓	000C
2006	F-150	4. 2L	2V	VSM	✓	✓	✓	✓	

2006	F-150	4. 2L	Other	ABS/TCS	✓	✓	✓	✓	
2006	F-150	4. 2L	Other	GEM	✓	✓	✓	✓	
2006	F-150	4. 2L	Other	IC	✓	✓	✓	✓	
2006	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025
2006	F-150	4. 2L	Other	RAP	✓	✓	✓	✓	
2006	F-150	4. 2L	Other	RCM	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	4X4	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0008, 000B
2006	F-150	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	EATC	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	GEM	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	IC	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025
2006	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	F-150	4. 6L	2V	RAP	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2006	F-150	4. 6L	2V	VSM	✓	✓	✓	✓	
2006	F-150	5. 4L	3V	4X4	✓	✓	✓	✓	
2006	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 000B
2006	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	000B
2006	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	
2006	F-150	5. 4L	3V	EATC	✓	✓	✓	✓	
2006	F-150	5. 4L	3V	IC	✓	✓	✓	✓	
2006	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2006	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	0025
2006	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2006	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2006	F-150	5. 4L	3V	VSM	✓	✓	✓	✓	
2007	F-150	4. 2L	2V	4X4	✓	✓	✓	✓	
2007	F-150	4. 2L	2V	ABS	✓	✓	✓	✓	0008
2007	F-150	4. 2L	2V	DSM	✓	✓	✓	✓	
2007	F-150	4. 2L	2V	EATC	✓	✓	✓	✓	
2007	F-150	4. 2L	2V	IC	✓	✓	✓	✓	
2007	F-150	4. 2L	2V	PAM	✓	✓	✓	✓	
2007	F-150	4. 2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	F-150	4. 2L	2V	RCM	✓	✓	✓	✓	000C
2007	F-150	4. 2L	2V	VSM	✓	✓	✓	✓	
2007	F-150	4. 6L	2V	4X4	✓	✓	✓	✓	
2007	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0008
2007	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2007	F-150	4. 6L	2V	EATC	✓	✓	✓	✓	
2007	F-150	4. 6L	2V	IC	✓	✓	✓	✓	0005, F071, F077
2007	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2007	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2007	F-150	4. 6L	2V	VSM	✓	✓	✓	✓	
2007	F-150	5. 4L	3V	4X4	✓	✓	✓	✓	
2007	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005
2007	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2007	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	
2007	F-150	5. 4L	3V	EATC	✓	✓	✓	✓	
2007	F-150	5. 4L	3V	IC	✓	✓	✓	✓	0005
2007	F-150	5. 4L	3V	IC	✓	✓	✓	✓	0005, F044, F071
2007	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2007	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	0025
2007	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2007	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2007	F-150	5. 4L	3V	VSM	✓	✓	✓	✓	
2008	F-150	4. 2L	2V	4X4	✓	✓	✓	✓	
2008	F-150	4. 2L	2V	ABS	✓	✓	✓	✓	0008
2008	F-150	4. 2L	2V	DSM	✓	✓	✓	✓	
2008	F-150	4. 2L	2V	HVAC	✓	✓	✓	✓	
2008	F-150	4. 2L	2V	IC	✓	✓	✓	✓	
2008	F-150	4. 2L	2V	PAM	✓	✓	✓	✓	
2008	F-150	4. 2L	2V	PCM	✓	✓	✓	✓	0025
2008	F-150	4. 2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	F-150	4. 2L	2V	RCM	✓	✓	✓	✓	000C
2008	F-150	4. 2L	2V	RET M	✓	✓	✓	✓	0018
2008	F-150	4. 2L	2V	VSM	✓	✓	✓	✓	
2008	F-150	4. 6L	2V	4X4	✓	✓	✓	✓	
2008	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0008
2008	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2008	F-150	4. 6L	2V	HVAC	✓	✓	✓	✓	
2008	F-150	4. 6L	2V	IC	✓	✓	✓	✓	0005, F071, F077
2008	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2008	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2008	F-150	4. 6L	2V	RET M	✓	✓	✓	✓	0018
2008	F-150	4. 6L	2V	VSM	✓	✓	✓	✓	
2008	F-150	5. 4L	3V	4X4	✓	✓	✓	✓	
2008	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2008	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	

2008	F-150	5. 4L	3V	HVAC	✓	✓	✓	✓	
2008	F-150	5. 4L	3V	IC	✓	✓	✓	✓	0005, F044, F071
2008	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2008	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	0025
2008	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2008	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2008	F-150	5. 4L	3V	RETm	✓	✓	✓	✓	
2008	F-150	5. 4L	3V	RETm	✓	✓	✓	✓	0018
2008	F-150	5. 4L	3V	VSM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	F-150	4. 6L	2V	ACM	✓	✓	✓	✓	0017, 0018
2009	F-150	4. 6L	2V	APIM	✓	✓	✓	✓	0019, 001C
2009	F-150	4. 6L	2V	DCSM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	DSP	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	FCIM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	FDIM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	F-150	4. 6L	2V	HVAC	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	IC	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2009	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0067
2009	F-150	4. 6L	2V	PRB	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	TBC	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	TCCM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	ABS	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2009	F-150	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	ACM	✓	✓	✓	✓	0017, 0018
2009	F-150	4. 6L	3V	APIM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	F-150	4. 6L	3V	DCSM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	DSM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	DSP	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	FCIM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	FDIM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	F-150	4. 6L	3V	HVAC	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	IC	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	OCSM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2009	F-150	4. 6L	3V	PAM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	PCM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	PCM	✓	✓	✓	✓	0067
2009	F-150	4. 6L	3V	PRB	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	RCM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	TBC	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	TCCM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	TCM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2009	F-150	5. 4L	3V	ACM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2009	F-150	5. 4L	3V	APIM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	F-150	5. 4L	3V	DCSM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	DSP	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	FCIM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	FDIM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	F-150	5. 4L	3V	HVAC	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	IC	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	OCSM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2009	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 00C5
2009	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0067
2009	F-150	5. 4L	3V	PRB	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	TBC	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	TCCM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	TCM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	TCM	✓	✓	✓	✓	00CE
2010	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	F-150	4. 6L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	F-150	4. 6L	2V	APIM	✓	✓	✓	✓	0019, 001C
2010	F-150	4. 6L	2V	DCSM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	DSP	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	FCIM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	FDIM	✓	✓	✓	✓	

2010	F-150	4. 6L	2V	GEM / SJB	✓	✓	✓	✓	0042
2010	F-150	4. 6L	2V	GPSM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	HVAC	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	IC	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	ILCM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2010	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	F-150	4. 6L	2V	PRB	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	TBC	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	TCCM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	ABS	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2010	F-150	4. 6L	3V	ACM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	ACM	✓	✓	✓	✓	0017, 0018
2010	F-150	4. 6L	3V	APIM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2010	F-150	4. 6L	3V	DCSM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	DSM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	DSP	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	FCIM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	FDIM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2010	F-150	4. 6L	3V	GPSM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	HVAC	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	IC	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	ILCM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	OCSM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2010	F-150	4. 6L	3V	PAM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	PCM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	PCM	✓	✓	✓	✓	0067
2010	F-150	4. 6L	3V	PRB	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	RCM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	TBC	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	TCCM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	TCM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2010	F-150	5. 4L	3V	ACM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2010	F-150	5. 4L	3V	APIM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2010	F-150	5. 4L	3V	DCSM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	DSP	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	FCIM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	FDIM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2010	F-150	5. 4L	3V	GPSM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	HVAC	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	IC	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	ILCM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	OCSM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2010	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 00C5
2010	F-150	5. 4L	3V	PRB	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	TBC	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	TCCM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	TCM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	F-150	6. 2L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	F-150	6. 2L	2V	APIM	✓	✓	✓	✓	0019, 001C
2010	F-150	6. 2L	2V	DCSM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	DSM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	DSP	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	FCIM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	FDIM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	GEM / SJB	✓	✓	✓	✓	0042
2010	F-150	6. 2L	2V	GPSM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	HVAC	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	IC	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	ILCM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2010	F-150	6. 2L	2V	PAM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	F-150	6. 2L	2V	PRB	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	RCM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	TBC	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	TCCM	✓	✓	✓	✓	

2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019, 001C
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	0005
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	0005
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	0005
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	0005
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0095
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PRB	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	0005, 00CB
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	0005
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	TBC	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	TCCM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	TPM	✓	✓	✓	✓	

2011	F-150	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2011	F-150	3.7L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2011	F-150	3.7L	TiVCT	APIM	✓	✓	✓	✓	0019, 001C
2011	F-150	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	F-150	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	DSM	✓	✓	✓	✓	0005
2011	F-150	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	FDIM	✓	✓	✓	✓	0005
2011	F-150	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	HVAC	✓	✓	✓	✓	0005
2011	F-150	3.7L	TiVCT	ILCM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	IPC	✓	✓	✓	✓	0005
2011	F-150	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2011	F-150	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2011	F-150	3.7L	TiVCT	PRB	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	PSCM	✓	✓	✓	✓	0005, 00CB
2011	F-150	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	SCCM	✓	✓	✓	✓	0005
2011	F-150	3.7L	TiVCT	TBC	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	TCCM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	TPM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2011	F-150	5.0L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2011	F-150	5.0L	TiVCT	APIM	✓	✓	✓	✓	0019, 001C
2011	F-150	5.0L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	F-150	5.0L	TiVCT	DCSM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	DSM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	DSP	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	FCIM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	FDIM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	GPSM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	HVAC	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	ILCM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	IPC	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2011	F-150	5.0L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2011	F-150	5.0L	TiVCT	PAM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	PCM	✓	✓	✓	✓	0067, 0095
2011	F-150	5.0L	TiVCT	PRB	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2011	F-150	5.0L	TiVCT	RCM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	SCCM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	TBC	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	TCCM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	TPM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	ABS	✓	✓	✓	✓	0008, 0012
2011	F-150	6.2L	2V	ACM	✓	✓	✓	✓	0017, 0018
2011	F-150	6.2L	2V	APIM	✓	✓	✓	✓	0019, 001C
2011	F-150	6.2L	2V	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	F-150	6.2L	2V	DCSM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	DSM	✓	✓	✓	✓	0005
2011	F-150	6.2L	2V	DSP	✓	✓	✓	✓	
2011	F-150	6.2L	2V	FCIM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	FDIM	✓	✓	✓	✓	0005
2011	F-150	6.2L	2V	GPSM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	HVAC	✓	✓	✓	✓	0005
2011	F-150	6.2L	2V	ILCM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	IPC	✓	✓	✓	✓	0005
2011	F-150	6.2L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2011	F-150	6.2L	2V	PAM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2011	F-150	6.2L	2V	PRB	✓	✓	✓	✓	
2011	F-150	6.2L	2V	PSCM	✓	✓	✓	✓	0005, 00CB
2011	F-150	6.2L	2V	RCM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	SCCM	✓	✓	✓	✓	0005
2011	F-150	6.2L	2V	TBC	✓	✓	✓	✓	
2011	F-150	6.2L	2V	TCCM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	TPM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019, 001C
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	

2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IILCM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TPM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	F-150	3.7L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2012	F-150	3.7L	TiVCT	APIM	✓	✓	✓	✓	0019, 001C
2012	F-150	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112
2012	F-150	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	FDIM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	IILCM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2012	F-150	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095
2012	F-150	3.7L	TiVCT	PRB	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2012	F-150	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	TBC	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	TCCM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	TPM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	F-150	5.0L	TiVCT	ABS	✓	✓	✓	✓	0012
2012	F-150	5.0L	TiVCT	ACM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2012	F-150	5.0L	TiVCT	APIM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	APIM	✓	✓	✓	✓	0019, 001C
2012	F-150	5.0L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	F-150	5.0L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5
2012	F-150	5.0L	TiVCT	DCSM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	DSM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	DSP	✓	✓	✓	✓	



2012	F-150	5.0L	TiVCT	FCIM	✓	✓	✓		
2012	F-150	5.0L	TiVCT	FDIM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	GPSM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	HVAC	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	ILCM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	IPC	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2012	F-150	5.0L	TiVCT	PAM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2012	F-150	5.0L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095
2012	F-150	5.0L	TiVCT	PRB	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2012	F-150	5.0L	TiVCT	RCM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	SCCM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	TBC	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	TCCM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	TPM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	ABS	✓	✓	✓	✓	0008, 0012
2012	F-150	6.2L	2V	ACM	✓	✓	✓	✓	0017, 0018
2012	F-150	6.2L	2V	APIM	✓	✓	✓	✓	0019, 001C
2012	F-150	6.2L	2V	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	F-150	6.2L	2V	DCSM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	DSM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	DSP	✓	✓	✓	✓	
2012	F-150	6.2L	2V	FCIM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	FDIM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	GPSM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	HVAC	✓	✓	✓	✓	
2012	F-150	6.2L	2V	ILCM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	IPC	✓	✓	✓	✓	
2012	F-150	6.2L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2012	F-150	6.2L	2V	PAM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2012	F-150	6.2L	2V	PRB	✓	✓	✓	✓	
2012	F-150	6.2L	2V	PSCM	✓	✓	✓	✓	00CB
2012	F-150	6.2L	2V	RCM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	SCCM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	TBC	✓	✓	✓	✓	
2012	F-150	6.2L	2V	TCCM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	TPM	✓	✓	✓	✓	
2012	F-150	Other	Other	ABS	✓	✓	✓	✓	
2012	F-150	Other	Other	ACM	✓	✓	✓	✓	
2012	F-150	Other	Other	BCM#1	✓	✓	✓	✓	0112
2012	F-150	Other	Other	DCSM	✓	✓	✓	✓	
2012	F-150	Other	Other	DSM	✓	✓	✓	✓	
2012	F-150	Other	Other	DSP	✓	✓	✓	✓	
2012	F-150	Other	Other	FCIM	✓	✓	✓	✓	
2012	F-150	Other	Other	FDIM	✓	✓	✓	✓	
2012	F-150	Other	Other	HVAC	✓	✓	✓	✓	
2012	F-150	Other	Other	ILCM	✓	✓	✓	✓	
2012	F-150	Other	Other	IPC	✓	✓	✓	✓	
2012	F-150	Other	Other	OCSM	✓	✓	✓	✓	
2012	F-150	Other	Other	PAM	✓	✓	✓	✓	
2012	F-150	Other	Other	PRB	✓	✓	✓	✓	
2012	F-150	Other	Other	PSCM	✓	✓	✓	✓	
2012	F-150	Other	Other	RCM	✓	✓	✓	✓	
2012	F-150	Other	Other	SCCM	✓	✓	✓	✓	
2012	F-150	Other	Other	TBC	✓	✓	✓	✓	
2012	F-150	Other	Other	TCCM	✓	✓	✓	✓	
2012	F-150	Other	Other	TPM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	

2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PRB	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	TBC	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	TCCM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	ABS	✓	✓	✓	✓	0012
2013	F-150	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	APIM	✓	✓	✓	✓	0019, 001C
2013	F-150	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112
2013	F-150	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	FDIM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	F-150	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	F-150	3.7L	TiVCT	PRB	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2013	F-150	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	TBC	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	TCCM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	ABS	✓	✓	✓	✓	0012
2013	F-150	5.0L	TiVCT	ACM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	APIM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE
2013	F-150	5.0L	TiVCT	DCSM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	DSM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	DSP	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	FCIM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	FDIM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	GPSM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	IPC	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	F-150	5.0L	TiVCT	PAM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	PCM	✓	✓	✓	✓	0025
2013	F-150	5.0L	TiVCT	PRB	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2013	F-150	5.0L	TiVCT	RCM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	RTM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	SCCM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	TBC	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	TCCM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	ABS	✓	✓	✓	✓	0012
2013	F-150	6.2L	2V	ACM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	APIM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	F-150	6.2L	2V	DCSM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	DSM	✓	✓	✓	✓	

2013	F-150	6.2L	2V	DSP	✓	✓	✓	✓	
2013	F-150	6.2L	2V	FCDIM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	FCIM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	FDIM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	GPSM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	IPC	✓	✓	✓	✓	
2013	F-150	6.2L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2013	F-150	6.2L	2V	PAM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2013	F-150	6.2L	2V	PRB	✓	✓	✓	✓	
2013	F-150	6.2L	2V	PSCM	✓	✓	✓	✓	00CB
2013	F-150	6.2L	2V	RCM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	RTM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	SCCM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	TBC	✓	✓	✓	✓	
2013	F-150	6.2L	2V	TCCM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC	✓	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	ABS	✓	✓	✓	✓	0012
2014	F-150	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0112
2014	F-150	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	DSP	✓	✓	✓	✓	

2014	F-150	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	FDIM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	F-150	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	F-150	3.7L	TiVCT	PRB	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	TBC	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	TCCM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	ABS	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	ABS	✓	✓	✓	✓	0012
2014	F-150	5.0L	TiVCT	ACM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	APIM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	F-150	5.0L	TiVCT	DCSM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	DSM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	DSP	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	FCIM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	FDIM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	GPSM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	IPC	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	F-150	5.0L	TiVCT	PAM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	PCM	✓	✓	✓	✓	0025
2014	F-150	5.0L	TiVCT	PRB	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	PSCM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	RCM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	RTM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	SCCM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	TBC	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	TCCM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	ABS	✓	✓	✓	✓	0012
2014	F-150	6.2L	2V	ACM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	APIM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	F-150	6.2L	2V	DCSM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	DSM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	DSP	✓	✓	✓	✓	
2014	F-150	6.2L	2V	FCDIM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	FCIM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	FDIM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	GPSM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	IPC	✓	✓	✓	✓	
2014	F-150	6.2L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2014	F-150	6.2L	2V	PAM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2014	F-150	6.2L	2V	PRB	✓	✓	✓	✓	
2014	F-150	6.2L	2V	PSCM	✓	✓	✓	✓	00CB
2014	F-150	6.2L	2V	RCM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	RTM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	SCCM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	TBC	✓	✓	✓	✓	
2014	F-150	6.2L	2V	TCCM	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	GEM	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	HEC	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	PCM	✓	✓	✓	✓	0025
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	RAP	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	RCM	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	GEM	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	HEC	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	PCM	✓	✓	✓	✓	0025
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	RAP	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	RCM	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	EATC	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	GEM	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	HEC	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	PCM	✓	✓	✓	✓	0025
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	RAP	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	RCM	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	EATC	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	GEM	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	HEC	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	PCM	✓	✓	✓	✓	0025
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	RAP	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	RCM	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	EATC	✓	✓	✓	✓	

2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	GEM	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	HEC	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	PCM	✓	✓	✓	✓	0025
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	RAP	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	RCM	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	EATC	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	GEM	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	HEC	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	PCM	✓	✓	✓	✓	0025
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	RAP	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	RCM	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	4X4	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	ABS/TCS	✓	✓	✓	✓	0008
2006	F-250	3.9L	Cummins Diesel	GEM	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	HEC	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	OTC	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	PAM	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	RCM	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
1997	F-250 Light Duty	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	F-250 Light Duty	4.6L	Other	GEM	✓	✓	✓	✓	
1997	F-250 Light Duty	4.6L	Other	IAB	✓	✓	✓	✓	
1997	F-250 Light Duty	4.6L	Other	PCM	✓	✓	✓	✓	0025
1997	F-250 Light Duty	4.6L	Other	RAP	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	NGV	ABS/TCS	✓	✓	✓	✓	0008
1997	F-250 Light Duty	5.4L	NGV	FIM	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	NGV	GEM	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	NGV	IAB	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	NGV	PCM	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	NGV	RAP	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	F-250 Light Duty	5.4L	Other	GEM	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	Other	IAB	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	Other	PCM	✓	✓	✓	✓	0025
1997	F-250 Light Duty	5.4L	Other	RAP	✓	✓	✓	✓	
1998	F-250 Light Duty	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	F-250 Light Duty	4.6L	Other	GEM	✓	✓	✓	✓	
1998	F-250 Light Duty	4.6L	Other	IAB	✓	✓	✓	✓	
1998	F-250 Light Duty	4.6L	Other	PCM	✓	✓	✓	✓	0025
1998	F-250 Light Duty	5.4L	BIF	ABS/TCS	✓	✓	✓	✓	0008
1998	F-250 Light Duty	5.4L	BIF	AFCM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	BIF	GEM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	BIF	IAB	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	BIF	PCM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	BIF	PCM	✓	✓	✓	✓	0025
1998	F-250 Light Duty	5.4L	BIF	RAP	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	NGV	ABS/TCS	✓	✓	✓	✓	0008
1998	F-250 Light Duty	5.4L	NGV	FIM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	NGV	GEM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	NGV	IAB	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	NGV	PCM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	NGV	RAP	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	F-250 Light Duty	5.4L	Other	GEM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	Other	IAB	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	Other	PCM	✓	✓	✓	✓	0025
1998	F-250 Light Duty	5.4L	Other	RAP	✓	✓	✓	✓	
1999	F-250 Light Duty	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-250 Light Duty	4.2L	Other	GEM	✓	✓	✓	✓	
1999	F-250 Light Duty	4.2L	Other	IC	✓	✓	✓	✓	
1999	F-250 Light Duty	4.2L	Other	PCM	✓	✓	✓	✓	0025
1999	F-250 Light Duty	4.2L	Other	RAP	✓	✓	✓	✓	
1999	F-250 Light Duty	4.2L	Other	RCM	✓	✓	✓	✓	
1999	F-250 Light Duty	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-250 Light Duty	4.6L	Other	GEM	✓	✓	✓	✓	
1999	F-250 Light Duty	4.6L	Other	IC	✓	✓	✓	✓	
1999	F-250 Light Duty	4.6L	Other	PCM	✓	✓	✓	✓	0025
1999	F-250 Light Duty	4.6L	Other	RAP	✓	✓	✓	✓	
1999	F-250 Light Duty	4.6L	Other	RCM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	BIF	ABS/TCS	✓	✓	✓	✓	0008
1999	F-250 Light Duty	5.4L	BIF	AFCM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	BIF	GEM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	BIF	IC	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	BIF	PCM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	BIF	RAP	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	BIF	RCM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	NGV	ABS/TCS	✓	✓	✓	✓	0008
1999	F-250 Light Duty	5.4L	NGV	FIM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	NGV	GEM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	NGV	IC	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	NGV	PCM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	NGV	RAP	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	NGV	RCM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-250 Light Duty	5.4L	Other	GEM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	Other	IC	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	Other	PCM	✓	✓	✓	✓	0025



2013	F-650 / F-750	6.7L	Cummins Diesel	APIM	✓	✓	✓	✓	
2013	F-650 / F-750	6.7L	Cummins Diesel	GEM / SJB	✓	✓	✓	✓	
2013	F-650 / F-750	6.7L	Cummins Diesel	HVAC	✓	✓	✓	✓	
2013	F-650 / F-750	6.7L	Cummins Diesel	IPC	✓	✓	✓	✓	
2013	F-650 / F-750	6.8L	3V	ACM	✓	✓	✓	✓	0005
2013	F-650 / F-750	6.8L	3V	APIM	✓	✓	✓	✓	
2013	F-650 / F-750	6.8L	3V	GEM / SJB	✓	✓	✓	✓	
2013	F-650 / F-750	6.8L	3V	HVAC	✓	✓	✓	✓	
2013	F-650 / F-750	6.8L	3V	IPC	✓	✓	✓	✓	
2013	F-650 / F-750	6.8L	3V	PCM	✓	✓	✓	✓	0025
2013	F-650 / F-750	Other	Other	ACM	✓	✓	✓	✓	
2013	F-650 / F-750	Other	Other	APIM	✓	✓	✓	✓	
2013	F-650 / F-750	Other	Other	HVAC	✓	✓	✓	✓	
2013	F-650 / F-750	Other	Other	IPC	✓	✓	✓	✓	
2014	F-650 / F-750	6.8L	3V	ACM	✓	✓	✓	✓	
2014	F-650 / F-750	6.8L	3V	APIM	✓	✓	✓	✓	
2014	F-650 / F-750	6.8L	3V	HVAC	✓	✓	✓	✓	
2014	F-650 / F-750	6.8L	3V	IPC	✓	✓	✓	✓	
1994	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	
1994	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1995	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	
1995	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1996	F-Series	4.9L	GFP	PCM	✓	✓	✓	✓	
1996	F-Series	4.9L	Other	PCM	✓	✓	✓	✓	0025
1996	F-Series	5.0L	Other	PCM	✓	✓	✓	✓	0025
1996	F-Series	5.8L	Other	PCM	✓	✓	✓	✓	0025
1996	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	
1996	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1996	F-Series	7.5L	Other	PCM	✓	✓	✓	✓	0025
1997	F-Series	5.8L	Other	PCM	✓	✓	✓	✓	0025
1997	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	
1997	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1997	F-Series	7.5L	Other	PCM	✓	✓	✓	✓	0025
1999	F-Series Super Duty	5.4L	BIF	ABS/TCS	✓	✓	✓	✓	0008
1999	F-Series Super Duty	5.4L	BIF	AFCM	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	BIF	ECS	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	BIF	GEM	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	BIF	OTC	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	BIF	PCM	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-Series Super Duty	5.4L	Other	ECS	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	Other	GEM	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	Other	OTC	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	Other	PCM	✓	✓	✓	✓	0025
1999	F-Series Super Duty	6.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-Series Super Duty	6.8L	Other	ECS	✓	✓	✓	✓	
1999	F-Series Super Duty	6.8L	Other	GEM	✓	✓	✓	✓	
1999	F-Series Super Duty	6.8L	Other	OTC	✓	✓	✓	✓	
1999	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓	0025
1999	F-Series Super Duty	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008
1999	F-Series Super Duty	7.3L	Direct Injection -	ECS	✓	✓	✓	✓	
1999	F-Series Super Duty	7.3L	Direct Injection -	GEM	✓	✓	✓	✓	
1999	F-Series Super Duty	7.3L	Direct Injection -	OTC	✓	✓	✓	✓	
1999	F-Series Super Duty	7.3L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
1999	F-Series Super Duty	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1999	F-Series Super Duty	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	F-Series Super Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	F-Series Super Duty	5.4L	Other	ECS	✓	✓	✓	✓	
2000	F-Series Super Duty	5.4L	Other	GEM	✓	✓	✓	✓	
2000	F-Series Super Duty	5.4L	Other	OTC	✓	✓	✓	✓	
2000	F-Series Super Duty	5.4L	Other	PATS	✓	✓	✓	✓	
2000	F-Series Super Duty	5.4L	Other	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2000	F-Series Super Duty	6.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	F-Series Super Duty	6.8L	Other	AFCM	✓	✓	✓	✓	
2000	F-Series Super Duty	6.8L	Other	ECS	✓	✓	✓	✓	
2000	F-Series Super Duty	6.8L	Other	GEM	✓	✓	✓	✓	
2000	F-Series Super Duty	6.8L	Other	OTC	✓	✓	✓	✓	
2000	F-Series Super Duty	6.8L	Other	PATS	✓	✓	✓	✓	
2000	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2000	F-Series Super Duty	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008
2000	F-Series Super Duty	7.3L	Direct Injection -	ECS	✓	✓	✓	✓	
2000	F-Series Super Duty	7.3L	Direct Injection -	GEM	✓	✓	✓	✓	
2000	F-Series Super Duty	7.3L	Direct Injection -	OTC	✓	✓	✓	✓	
2000	F-Series Super Duty	7.3L	Direct Injection -	PATS	✓	✓	✓	✓	
2000	F-Series Super Duty	7.3L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2001	F-Series Super Duty	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
2001	F-Series Super Duty	4.2L	Other	ECS	✓	✓	✓	✓	
2001	F-Series Super Duty	4.2L	Other	GEM	✓	✓	✓	✓	
2001	F-Series Super Duty	4.2L	Other	OTC	✓	✓	✓	✓	
2001	F-Series Super Duty	4.2L	Other	PAM	✓	✓	✓	✓	
2001	F-Series Super Duty	4.2L	Other	PCM	✓	✓	✓	✓	0025
2001	F-Series Super Duty	4.2L	Other	RCM	✓	✓	✓	✓	
2001	F-Series Super Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2001	F-Series Super Duty	5.4L	Other	ECS	✓	✓	✓	✓	
2001	F-Series Super Duty	5.4L	Other	GEM	✓	✓	✓	✓	











2008	F-Series Super Duty	5.4L	3V	PAM	✓	✓	✓	✓	
2008	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓	0025
2008	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	F-Series Super Duty	5.4L	3V	RCM	✓	✓	✓	✓	
2008	F-Series Super Duty	5.4L	3V	RETM	✓	✓	✓	✓	
2008	F-Series Super Duty	5.4L	3V	SDARS	✓	✓	✓	✓	0019
2008	F-Series Super Duty	5.4L	3V	TBC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0005, F046, F084
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F05A, F07A, F07F
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	0005
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	0042
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F05C, F06A, F080, F081
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC	✓	✓	✓	✓	F027, F04D, F07E, F082, F083
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0047, 0048, 0058, 00A2, 00A3
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0025, 0047, 0048, 0058, 00A2, 00A3
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0047, 0048, 0058, 00A2, 00A3
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	0005, F022
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓	✓	0005, F04D, F05A
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0005, 0019, F07F
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0019
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	00CE
2008	F-Series Super Duty	6.8L	2V	4X4	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	ABS	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	F-Series Super Duty	6.8L	2V	DSM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	GEM / SJB	✓	✓	✓	✓	0042
2008	F-Series Super Duty	6.8L	2V	HVAC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	IC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	PAM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	PCM	✓	✓	✓	✓	0025
2008	F-Series Super Duty	6.8L	2V	RCM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	RETM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	SDARS	✓	✓	✓	✓	0019
2008	F-Series Super Duty	6.8L	2V	TBC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	3V	4X4	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	F-Series Super Duty	6.8L	3V	DSM	✓	✓	✓	✓	

2008	F-Series Super Duty	6. 8L	3V	GEM / SJB	✓	✓	✓	✓	0042
2008	F-Series Super Duty	6. 8L	3V	HVAC	✓	✓	✓	✓	
2008	F-Series Super Duty	6. 8L	3V	IC	✓	✓	✓	✓	
2008	F-Series Super Duty	6. 8L	3V	PAM	✓	✓	✓	✓	
2008	F-Series Super Duty	6. 8L	3V	PCM	✓	✓	✓	✓	0025
2008	F-Series Super Duty	6. 8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	F-Series Super Duty	6. 8L	3V	RCM	✓	✓	✓	✓	
2008	F-Series Super Duty	6. 8L	3V	RETM	✓	✓	✓	✓	
2008	F-Series Super Duty	6. 8L	3V	SDARS	✓	✓	✓	✓	0019
2008	F-Series Super Duty	6. 8L	3V	TBC	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	4X4	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	ABS	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	ACM	✓	✓	✓	✓	0016
2009	F-Series Super Duty	5. 4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	F-Series Super Duty	5. 4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	F-Series Super Duty	5. 4L	3V	APIM	✓	✓	✓	✓	001C
2009	F-Series Super Duty	5. 4L	3V	DSM	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	DSM	✓	✓	✓	✓	0005, F041
2009	F-Series Super Duty	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	F-Series Super Duty	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C, F05C, F065, F06A, F080, F081, F0B0
2009	F-Series Super Duty	5. 4L	3V	HVAC	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	IC	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	PAM	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2009	F-Series Super Duty	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	F-Series Super Duty	5. 4L	3V	RCM	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	RCM	✓	✓	✓	✓	0005, F022
2009	F-Series Super Duty	5. 4L	3V	RETM	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	RETM	✓	✓	✓	✓	0005, F04D, F05A
2009	F-Series Super Duty	5. 4L	3V	SDARS	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	SDARS	✓	✓	✓	✓	0005, F07F
2009	F-Series Super Duty	5. 4L	3V	TBC	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	4X4	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0005
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0005, F046, F084
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0005, 0016
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0016
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	AHCM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	APIM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	APIM	✓	✓	✓	✓	0019, 001C
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	CDIM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	0005
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	0042
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	HVAC	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	IC	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PAM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0047, 0048, 0058, 00A2, 00A3
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0025, 0047, 0048, 0058, 00A2, 00A3
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0047, 0048, 0058, 00A2, 00A3
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	0005

2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	0005, F022
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓		
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓		0005
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓		0005, F04D, F05A
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0005
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0005, 0019
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0005, 0019, F07F
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC	✓	✓	✓	✓	
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	00CE
2009	F-Series Super Duty	6.8L	3V	4X4	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	0016
2009	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	F-Series Super Duty	6.8L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	F-Series Super Duty	6.8L	3V	DSM	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	F-Series Super Duty	6.8L	3V	HVAC	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	IC	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	PAM	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓	0025
2009	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	RETM	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	SDARS	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓	
2010	F-Series Super Duty	5.4L	3V	4X4	✓	✓	✓	✓	
2010	F-Series Super Duty	5.4L	3V	ABS	✓	✓	✓	✓	0005
2010	F-Series Super Duty	5.4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2010	F-Series Super Duty	5.4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2010	F-Series Super Duty	5.4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2010	F-Series Super Duty	5.4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2010	F-Series Super Duty	5.4L	3V	DSM	✓	✓	✓	✓	0005, F041
2010	F-Series Super Duty	5.4L	3V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C, F05C, F065, F06A, F080, F081, F080
2010	F-Series Super Duty	5.4L	3V	GPSM	✓	✓	✓	✓	
2010	F-Series Super Duty	5.4L	3V	HVAC	✓	✓	✓	✓	
2010	F-Series Super Duty	5.4L	3V	IC	✓	✓	✓	✓	0005, F027, F04D, F07E
2010	F-Series Super Duty	5.4L	3V	PAM	✓	✓	✓	✓	0005
2010	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓	0025
2010	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	F-Series Super Duty	5.4L	3V	RCM	✓	✓	✓	✓	0005, F022
2010	F-Series Super Duty	5.4L	3V	RETM	✓	✓	✓	✓	0005, F04D, F05A
2010	F-Series Super Duty	5.4L	3V	SDARS	✓	✓	✓	✓	0005, F07F
2010	F-Series Super Duty	5.4L	3V	TBC	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0005
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0016, 0017, 0018
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0017, 0018
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM	✓	✓	✓	✓	0019, 001C
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	0005
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	

2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	0042
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GPSM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0047, 0048, 0058, 00A2, 00A3
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0025, 0047, 0048, 0058, 00A2, 00A3
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0047, 0048, 0058, 00A2, 00A3
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	0005
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	0005, F022
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓		
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓		0005
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓		0005, F04D, F05A
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0005
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0005, 0019, F07F
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	00CE
2010	F-Series Super Duty	6.8L	3V	4X4	✓	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓	0008
2010	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2010	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	0017, 0018
2010	F-Series Super Duty	6.8L	3V	APIM	✓	✓	✓	✓	0019, 001C
2010	F-Series Super Duty	6.8L	3V	DSM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	GEM / SJB	✓	✓	✓	✓	0042
2010	F-Series Super Duty	6.8L	3V	GPSM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	HVAC	✓	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	IC	✓	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	PAM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓	0025
2010	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	RETM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	SDARS	✓	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	TCCM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	TPM	✓	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	ABS	✓	✓	✓	✓	0008
2011	F-Series Super Duty	6.2L	2V	ACM	✓	✓	✓	✓	0017, 0018
2011	F-Series Super Duty	6.2L	2V	APIM	✓	✓	✓	✓	0019
2011	F-Series Super Duty	6.2L	2V	BCM#1	✓	✓	✓	✓	0042, 00D4
2011	F-Series Super Duty	6.2L	2V	DCSM	✓	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	DSM	✓	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	GPSM	✓	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	HVAC	✓	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	IPC	✓	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	PAM	✓	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2011	F-Series Super Duty	6.2L	2V	RCM	✓	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	SCCM	✓	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	SDARS	✓	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	TBC	✓	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	TCCM	✓	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	TPM	✓	✓	✓	✓	
2011	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0008
2011	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0005, 0008
2011	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0008
2011	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0008, 0012
2011	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0005, 0017, 0018







2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓		0005
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TBC	✓	✓	✓		
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TBC	✓	✓	✓	✓	
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TCCM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	00CE
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TPM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓	0008
2012	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	0017, 0018
2012	F-Series Super Duty	6.8L	3V	APIM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	APIM	✓	✓	✓	✓	0019
2012	F-Series Super Duty	6.8L	3V	BCM#1	✓	✓	✓	✓	0042, 00D4
2012	F-Series Super Duty	6.8L	3V	BCM#1	✓	✓	✓	✓	00D4
2012	F-Series Super Duty	6.8L	3V	DCSM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	DSM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	GPSM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	HVAC	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	IPC	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	PAM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓	0025
2012	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095
2012	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	SCCM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	TCCM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	TPM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	ABS	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	ACM	✓	✓	✓	✓	0017, 0018
2013	F-Series Super Duty	6.2L	2V	APIM	✓	✓	✓	✓	0019
2013	F-Series Super Duty	6.2L	2V	BCM#1	✓	✓	✓	✓	00D4, 00FE
2013	F-Series Super Duty	6.2L	2V	BCM#1	✓	✓	✓	✓	00D4, 00FE, 0112
2013	F-Series Super Duty	6.2L	2V	DCSM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	DSM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	DSP	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	FCDIM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	FCIM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	GPSM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	HSWM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	IPC	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	PAM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	PCM	✓	✓	✓	✓	0025
2013	F-Series Super Duty	6.2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	F-Series Super Duty	6.2L	2V	RCM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	RTM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	SCCM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	TBC	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	TCCM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0017, 0018
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	AHCM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	APIM	✓	✓	✓	✓	0019
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	BCM#1	✓	✓	✓	✓	00D4, 00FE
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	CDIM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	DCSM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	DSP	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	FCDIM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	FCIM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	GPCM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	GPSM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	HSWM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	IPC	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	PAM	✓	✓	✓	✓	



2014	F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0058, 0059, 0091, 009C, 009D, 009E, 009F, 00A0, 00CE
2014	F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	RTM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	SCCM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	TBC	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	TCCM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	ABS	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	ACM	✓	✓	✓	✓	0017, 0018
2014	F-Series Super Duty	6. 8L	3V	APIM	✓	✓	✓	✓	0019
2014	F-Series Super Duty	6. 8L	3V	BCM#1	✓	✓	✓	✓	00D4, 00FE, 0112
2014	F-Series Super Duty	6. 8L	3V	DCSM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	DSM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	DSP	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	FCDIM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	FCIM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	GPSM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	HSWM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	IPC	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	PAM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	F-Series Super Duty	6. 8L	3V	RCM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	RTM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	SCCM	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	TBC	✓	✓	✓	✓	
2014	F-Series Super Duty	6. 8L	3V	TCCM	✓	✓	✓	✓	
2009	F350/4000	3. 9L	Cummins Diesel	4X4	✓	✓	✓	✓	
2009	F350/4000	3. 9L	Cummins Diesel	GEM	✓	✓	✓	✓	
2009	F350/4000	3. 9L	Cummins Diesel	TBM	✓	✓	✓	✓	
1998	FAMILIA / LASER	1. 3L	B3	ABS	✓	✓	✓	✓	
1998	FAMILIA / LASER	1. 3L	B3	PCM	✓	✓	✓	✓	
1998	FAMILIA / LASER	1. 5L	ZL	ABS	✓	✓	✓	✓	
1998	FAMILIA / LASER	1. 5L	ZL	PCM	✓	✓	✓	✓	
1998	FAMILIA / LASER	1. 8L	FP	ABS	✓	✓	✓	✓	
1998	FAMILIA / LASER	1. 8L	FP	PCM	✓	✓	✓	✓	
1998	FAMILIA / LASER	2. 0L	RF	ABS	✓	✓	✓	✓	
1998	FAMILIA / LASER	2. 0L	RF	PCM	✓	✓	✓	✓	
1999	FAMILIA / LASER	2. 0L	FS	ABS	✓	✓	✓	✓	
1999	FAMILIA / LASER	2. 0L	FS	PCM	✓	✓	✓	✓	
2000	FAMILIA / LASER	1. 5L	ZL	ABS	✓	✓	✓	✓	
2000	FAMILIA / LASER	1. 5L	ZL	ABS/TCS	✓	✓	✓	✓	
2000	FAMILIA / LASER	1. 5L	ZL	PCM	✓	✓	✓	✓	
2000	FAMILIA / LASER	2. 0L	FS	ABS	✓	✓	✓	✓	
2000	FAMILIA / LASER	2. 0L	FS	PCM	✓	✓	✓	✓	
2002	FAMILIA / LASER	1. 5L	ZL	ABS/TCS	✓	✓	✓	✓	
2002	FAMILIA / LASER	1. 5L	ZL	PCM	✓	✓	✓	✓	
2002	FAMILIA / LASER	2. 0L	FS	ABS/TCS	✓	✓	✓	✓	
2002	FAMILIA / LASER	2. 0L	FS	PCM	✓	✓	✓	✓	
2010. 25	FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2010. 25	FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2010. 25	FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2010. 25	FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2010. 25	FIGO	1. 4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008
2010. 25	FIGO	1. 4L	DURATEC 16V	IC	✓	✓	✓	✓	
2010. 25	FIGO	1. 4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2010. 25	FIGO	1. 4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2010. 25	FIGO	1 19L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008
2010. 25	FIGO	1 19L	DURATEC 16V	IC	✓	✓	✓	✓	
2010. 25	FIGO	1 19L	DURATEC 16V	PCM	✓	✓	✓	✓	
2010. 25	FIGO	1 19L	DURATEC 16V	RCM	✓	✓	✓	✓	
2011. 25	FIGO	1. 4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2011. 25	FIGO	1. 4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008
2011. 25	FIGO	1. 4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2011. 25	FIGO	1. 4L	DURATEC 16V	IC	✓	✓	✓	✓	
2011. 25	FIGO	1. 4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2011. 25	FIGO	1. 4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2011. 25	FIGO	1. 6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2011. 25	FIGO	1. 6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008
2011. 25	FIGO	1. 6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2011. 25	FIGO	1. 6L	DURATEC 16V	IC	✓	✓	✓	✓	
2011. 25	FIGO	1. 6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2011. 25	FIGO	1. 6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2011. 25	FIGO	1. 6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2011. 25	FIGO	Other	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2011. 25	FIGO	Other	DURATEC 16V	GEM	✓	✓	✓	✓	
2011. 25	FIGO	Other	DURATEC 16V	IC	✓	✓	✓	✓	
2011. 25	FIGO	Other	DURATEC 16V	RCM	✓	✓	✓	✓	

2005	FORD GT	5.4L	4V	ABS/TCS	✓	✓	✓	✓	0008
2005	FORD GT	5.4L	4V	AFCM	✓	✓	✓	✓	
2005	FORD GT	5.4L	4V	GEM	✓	✓	✓	✓	
2005	FORD GT	5.4L	4V	IC	✓	✓	✓	✓	
2005	FORD GT	5.4L	4V	PATS	✓	✓	✓	✓	
2005	FORD GT	5.4L	4V	PCM	✓	✓	✓	✓	0025
2005	FORD GT	5.4L	4V	RCM	✓	✓	✓	✓	
2006	FORD GT	5.4L	4V	ABS/TCS	✓	✓	✓	✓	
2006	FORD GT	5.4L	4V	AFCM	✓	✓	✓	✓	
2006	FORD GT	5.4L	4V	GEM	✓	✓	✓	✓	
2006	FORD GT	5.4L	4V	IC	✓	✓	✓	✓	
2006	FORD GT	5.4L	4V	PATS	✓	✓	✓	✓	
2006	FORD GT	5.4L	4V	PCM	✓	✓	✓	✓	0025
2006	FORD GT	5.4L	4V	RCM	✓	✓	✓	✓	
1997	FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	PCM	✓	✓	✓	✓	
1999	FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	PCM	✓	✓	✓	✓	
1999	FRIENDEE / FRED A / BONGO FRIENDEE	2.5L	WL T	PCM	✓	✓	✓	✓	
2002	FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	PCM	✓	✓	✓	✓	
2002	FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	TCM	✓	✓	✓	✓	
2003	Fairlane / LTD	4.0L	DOHC VCT	ABS/TCS	✓	✓	✓	✓	0008
2003	Fairlane / LTD	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2003	Fairlane / LTD	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0005, 0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2003	Fairlane / LTD	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	0005, 003A
2003	Fairlane / LTD	4.0L	DOHC VCT	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2003	Fairlane / LTD	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2003	Fairlane / LTD	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	0005, 0025, 003A
2003	Fairlane / LTD	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	
2003	Fairlane / LTD	5.4L	3V	ABS/TCS	✓	✓	✓	✓	0008
2003	Fairlane / LTD	5.4L	3V	ACM	✓	✓	✓	✓	0040
2003	Fairlane / LTD	5.4L	3V	BEM	✓	✓	✓	✓	0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2003	Fairlane / LTD	5.4L	3V	HIM	✓	✓	✓	✓	003A
2003	Fairlane / LTD	5.4L	3V	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2003	Fairlane / LTD	5.4L	3V	PAM	✓	✓	✓	✓	0005
2003	Fairlane / LTD	5.4L	3V	PCM	✓	✓	✓	✓	0025, 003A
2003	Fairlane / LTD	5.4L	3V	RCM	✓	✓	✓	✓	
2006	Fairlane / LTD	4.0L	DOHC VCT	ABS	✓	✓	✓	✓	0005, 0008
2006	Fairlane / LTD	4.0L	DOHC VCT	ABS/TCS	✓	✓	✓	✓	0008
2006	Fairlane / LTD	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2006	Fairlane / LTD	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0005, 0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2006	Fairlane / LTD	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	0005, 003A
2006	Fairlane / LTD	4.0L	DOHC VCT	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2006	Fairlane / LTD	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2006	Fairlane / LTD	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	0025
2006	Fairlane / LTD	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	
2006	Fairlane / LTD	4.0L	DOHC VCT	TCM	✓	✓	✓	✓	
2006	Fairlane / LTD	5.4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2006	Fairlane / LTD	5.4L	3V	ABS/TCS	✓	✓	✓	✓	0008
2006	Fairlane / LTD	5.4L	3V	ACM	✓	✓	✓	✓	0040
2006	Fairlane / LTD	5.4L	3V	BEM	✓	✓	✓	✓	0005, 0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2006	Fairlane / LTD	5.4L	3V	HIM	✓	✓	✓	✓	0005, 003A
2006	Fairlane / LTD	5.4L	3V	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2006	Fairlane / LTD	5.4L	3V	PAM	✓	✓	✓	✓	0005
2006	Fairlane / LTD	5.4L	3V	PCM	✓	✓	✓	✓	0005, 0025, 003A
2006	Fairlane / LTD	5.4L	3V	RCM	✓	✓	✓	✓	
2006	Fairlane / LTD	5.4L	3V	TCM	✓	✓	✓	✓	
Other	Fairlane / LTD	4.0L	Other	ABS	✓	✓	✓	✓	0008
Other	Fairlane / LTD	4.0L	Other	ABS/TCS	✓	✓	✓	✓	
Other	Fairlane / LTD	4.0L	Other	ACM	✓	✓	✓	✓	
Other	Fairlane / LTD	4.0L	Other	BEM	✓	✓	✓	✓	
Other	Fairlane / LTD	4.0L	Other	IAB	✓	✓	✓	✓	
Other	Fairlane / LTD	4.0L	Other	IC	✓	✓	✓	✓	0005, F012, F013
Other	Fairlane / LTD	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025
Other	Fairlane / LTD	4.0L	Other	PCM	✓	✓	✓	✓	0025
Other	Fairlane / LTD	4.0L	Other	RCM	✓	✓	✓	✓	
Other	Fairlane / LTD	5.0L	Other	ABS	✓	✓	✓	✓	0008
Other	Fairlane / LTD	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
Other	Fairlane / LTD	5.0L	Other	ACM	✓	✓	✓	✓	
Other	Fairlane / LTD	5.0L	Other	BEM	✓	✓	✓	✓	
Other	Fairlane / LTD	5.0L	Other	IAB	✓	✓	✓	✓	
Other	Fairlane / LTD	5.0L	Other	IC	✓	✓	✓	✓	0005, F012, F013
Other	Fairlane / LTD	5.0L	Other	PCM	✓	✓	✓	✓	0025
Other	Fairlane / LTD	5.0L	Other	RCM	✓	✓	✓	✓	
2003	Fairmont	4.0L	DOHC VCT	ABS/TCS	✓	✓	✓	✓	0008

2003	Fairmont	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2003	Fairmont	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0005, 0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2003	Fairmont	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	0005, 003A
2003	Fairmont	4.0L	DOHC VCT	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2003	Fairmont	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2003	Fairmont	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	0005, 0025, 003A
2003	Fairmont	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	
2003	Fairmont	5.4L	3V	ABS/TCS	✓	✓	✓	✓	0008
2003	Fairmont	5.4L	3V	ACM	✓	✓	✓	✓	0040
2003	Fairmont	5.4L	3V	BEM	✓	✓	✓	✓	0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2003	Fairmont	5.4L	3V	HIM	✓	✓	✓	✓	003A
2003	Fairmont	5.4L	3V	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2003	Fairmont	5.4L	3V	PAM	✓	✓	✓	✓	
2003	Fairmont	5.4L	3V	PCM	✓	✓	✓	✓	0025, 003A
2003	Fairmont	5.4L	3V	RCM	✓	✓	✓	✓	
2006	Fairmont	4.0L	DOHC VCT	ABS	✓	✓	✓	✓	0005, 0008
2006	Fairmont	4.0L	DOHC VCT	ABS/TCS	✓	✓	✓	✓	0008
2006	Fairmont	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2006	Fairmont	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0005, 0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2006	Fairmont	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	0005, 003A
2006	Fairmont	4.0L	DOHC VCT	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2006	Fairmont	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2006	Fairmont	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	0025
2006	Fairmont	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	
2006	Fairmont	4.0L	DOHC VCT	TCM	✓	✓	✓	✓	
2006	Fairmont	5.4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2006	Fairmont	5.4L	3V	ABS/TCS	✓	✓	✓	✓	0008
2006	Fairmont	5.4L	3V	ACM	✓	✓	✓	✓	0040
2006	Fairmont	5.4L	3V	BEM	✓	✓	✓	✓	0005, 0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2006	Fairmont	5.4L	3V	HIM	✓	✓	✓	✓	0005, 003A
2006	Fairmont	5.4L	3V	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2006	Fairmont	5.4L	3V	PAM	✓	✓	✓	✓	0005
2006	Fairmont	5.4L	3V	PCM	✓	✓	✓	✓	0005, 0025, 003A
2006	Fairmont	5.4L	3V	RCM	✓	✓	✓	✓	
2006	Fairmont	5.4L	3V	TCM	✓	✓	✓	✓	
Other	Fairmont	4.0L	Other	ABS	✓	✓	✓	✓	0008
Other	Fairmont	4.0L	Other	ABS/TCS	✓	✓	✓	✓	
Other	Fairmont	4.0L	Other	ACM	✓	✓	✓	✓	
Other	Fairmont	4.0L	Other	BEM	✓	✓	✓	✓	
Other	Fairmont	4.0L	Other	IAB	✓	✓	✓	✓	
Other	Fairmont	4.0L	Other	IC	✓	✓	✓	✓	0005, F012, F013
Other	Fairmont	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025
Other	Fairmont	4.0L	Other	PCM	✓	✓	✓	✓	0025
Other	Fairmont	4.0L	Other	RCM	✓	✓	✓	✓	
Other	Fairmont	5.0L	Other	ABS	✓	✓	✓	✓	0008
Other	Fairmont	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
Other	Fairmont	5.0L	Other	ACM	✓	✓	✓	✓	
Other	Fairmont	5.0L	Other	BEM	✓	✓	✓	✓	
Other	Fairmont	5.0L	Other	IAB	✓	✓	✓	✓	
Other	Fairmont	5.0L	Other	IC	✓	✓	✓	✓	0005, F012, F013
Other	Fairmont	5.0L	Other	PCM	✓	✓	✓	✓	0025
Other	Fairmont	5.0L	Other	RCM	✓	✓	✓	✓	
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0005, F024
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BEM	✓	✓	✓	✓	0035
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BEM	✓	✓	✓	✓	0035, 0005
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	0005

2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HIM	✓	✓	✓	✓	
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HIM	✓	✓	✓	✓	0005
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	F020
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	0005
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Falcon	4.0L	DOHC VCT	ABS	✓	✓	✓	✓	00CA, 0012
2011	Falcon	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0017
2011	Falcon	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0017, 0005, F024
2011	Falcon	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0035
2011	Falcon	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0035, 0005
2011	Falcon	4.0L	DOHC VCT	FDIM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	FDIM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT	IPC	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	IPC	✓	✓	✓	✓	F020
2011	Falcon	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	0025
2011	Falcon	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	TCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Falcon	4.0L	DOHC VCT LPG	ACM	✓	✓	✓	✓	0017
2011	Falcon	4.0L	DOHC VCT LPG	ACM	✓	✓	✓	✓	0017, 0005, F024
2011	Falcon	4.0L	DOHC VCT LPG	BEM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT LPG	BEM	✓	✓	✓	✓	0035
2011	Falcon	4.0L	DOHC VCT LPG	FDIM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	FDIM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT LPG	HIM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	HIM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT LPG	IPC	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	IPC	✓	✓	✓	✓	F020
2011	Falcon	4.0L	DOHC VCT LPG	PAM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	PAM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT LPG	PCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	PCM	✓	✓	✓	✓	0025
2011	Falcon	4.0L	DOHC VCT LPG	RCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	RCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	TCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	TCM	✓	✓	✓	✓	
2011	Falcon	5.0L	4V	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Falcon	5.0L	4V	ACM	✓	✓	✓	✓	0017, 0005, F024
2011	Falcon	5.0L	4V	BEM	✓	✓	✓	✓	0035, 0005
2011	Falcon	5.0L	4V	FDIM	✓	✓	✓	✓	0005
2011	Falcon	5.0L	4V	HIM	✓	✓	✓	✓	0005
2011	Falcon	5.0L	4V	IPC	✓	✓	✓	✓	F020
2011	Falcon	5.0L	4V	PAM	✓	✓	✓	✓	0005
2011	Falcon	5.0L	4V	PCM	✓	✓	✓	✓	0025
2011	Falcon	5.0L	4V	RCM	✓	✓	✓	✓	
2011	Falcon	5.0L	4V	TCM	✓	✓	✓	✓	
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	ABS/TCS	✓	✓	✓	✓	0008
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0035, 0005, F002, F004, F005, F007, F008, F009, F00A, F011, F003, F00D, F00E, F010
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	003A, 0005
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	IC	✓	✓	✓	✓	005F, 0044, 0061, F00B, F00C, F006, F00F
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	0025
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	







Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	IC	✓	✓	✓	✓	0005, F012, F013
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	PCM	✓	✓	✓	✓	0025
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	RCM	✓	✓	✓	✓	
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	ABS	✓	✓	✓	✓	0008
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	ACM	✓	✓	✓	✓	
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	BEM	✓	✓	✓	✓	
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	IAB	✓	✓	✓	✓	
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	IC	✓	✓	✓	✓	0005, F012, F013
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	PCM	✓	✓	✓	✓	0025
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	RCM	✓	✓	✓	✓	
Other	Festiva	1.5L	Other	PCM	✓	✓	✓	✓	0025
Other	Festiva Sedan	1.5L	Other	PCM	✓	✓	✓	✓	
2002	Fiesta	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3
2002	Fiesta	1.25L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F020
2002	Fiesta	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fiesta	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fiesta	1.3L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta	1.3L	DURATEC 8V	GEM	✓	✓	✓	✓	
2002	Fiesta	1.3L	DURATEC 8V	IC	✓	✓	✓	✓	
2002	Fiesta	1.3L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2002	Fiesta	1.3L	DURATEC 8V	RCM	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0012
2002	Fiesta	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3
2002	Fiesta	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F020
2002	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fiesta	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	003F
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0012
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2002	Fiesta	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2002	Fiesta	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002	Fiesta	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2002	Fiesta	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2002	Fiesta	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fiesta	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fiesta	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2002	Fiesta	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	0070
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0096, 0097, 0099, 009A, 00AD, 00AE
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fiesta	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓	
2006	Fiesta	1.25L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fiesta	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fiesta	1.25L	DURATEC 16V	IC	✓	✓	✓	✓	
2006	Fiesta	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fiesta	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fiesta	1.25L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fiesta	1.3L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta	1.3L	DURATEC 8V	ACM	✓	✓	✓	✓	
2006	Fiesta	1.3L	DURATEC 8V	EATC	✓	✓	✓	✓	
2006	Fiesta	1.3L	DURATEC 8V	GEM	✓	✓	✓	✓	
2006	Fiesta	1.3L	DURATEC 8V	IC	✓	✓	✓	✓	
2006	Fiesta	1.3L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2006	Fiesta	1.3L	DURATEC 8V	RCM	✓	✓	✓	✓	
2006	Fiesta	1.3L	DURATEC 8V	SRM	✓	✓	✓	✓	

2006	Fiesta	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2006	Fiesta	1.4L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fiesta	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3, FOB6
2006	Fiesta	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	F020, F063, FOB5, FOB7
2006	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fiesta	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fiesta	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fiesta	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	003F
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F02D, F030, FOA2, FOB3, FOB6
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F02D, F030, FOA2, FOB3, FOB6, FOB7
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F020, F063, FOB5, FOB7
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F063, FOB5, FOB7
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2006	Fiesta	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	
2006	Fiesta	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fiesta	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fiesta	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2006	Fiesta	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fiesta	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fiesta	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0096, 0097, 0099, 009A, 00AD, 00AE
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.25L	DURATEC 16V	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.25L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.25L	DURATEC 16V	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.25L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.25L	DURATEC 16V	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	00BC
2008.75	Fiesta	1.25L	DURATEC 16V	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.25L	DURATEC 16V	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.25L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.3L	BZ	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.3L	BZ	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	IPC	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	PCM	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.3L	BZ	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.3L	BZ	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	DURATEC 16V	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.4L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	DURATEC 16V	IPC	✓	✓	✓	✓	F020

2008.75	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025, 00BC
2008.75	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	00BC
2008.75	Fiesta	1.4L	DURATEC 16V	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.4L	DURATEC 16V	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	00BC
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00B9, 00BD
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00F0
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.5L	BZ	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.5L	BZ	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.5L	BZ	PCM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.5L	BZ	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.5L	BZ	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	SRM	✓	✓	✓	✓	

2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0099, 009A, 00B4, 00BC
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	ABS	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.5L	TivCT	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	FCDIM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.5L	TivCT	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	IPC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	PCM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	PSCM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.5L	TivCT	RCM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.5L	TivCT	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	TCM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	TCM	✓	✓	✓	✓	0117
2008.75	Fiesta	1.5L	TivCT	TCM	✓	✓	✓	✓	0117, 0158
2008.75	Fiesta	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	DURATEC VCT	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	0025, 00BC
2008.75	Fiesta	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 00AA, 00B0, 00B1
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	00E9

2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00B9, 00BD
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00F0
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TDCi ECO II	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.6L	TDCi ECO II	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TDCi ECO II	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TDCi ECO II	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.6L	TDCi ECO II	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TDCi ECO II	IPC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TDCi ECO II	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00BD, 00C3
2008.75	Fiesta	1.6L	TDCi ECO II	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.6L	TDCi ECO II	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.6L	TDCi ECO II	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TDCi ECO II	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	ABS	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.6L	TivCT	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	FCDIM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.6L	TivCT	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	IPC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	PCM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	PSCM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.6L	TivCT	RCM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.6L	TivCT	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	TCM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	TCM	✓	✓	✓	✓	0117
2011	Fiesta	1.6L	Sigma	ABS	✓	✓	✓	✓	0008, 0012
2011	Fiesta	1.6L	Sigma	ACM	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	APIM	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	BCM#1	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	FCDIM	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	GPSM	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	IPC	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	OCSM	✓	✓	✓	✓	000C
2011	Fiesta	1.6L	Sigma	PCM	✓	✓	✓	✓	0025, 0096, 0097, 009A, 012B, 020A
2011	Fiesta	1.6L	Sigma	PSCM	✓	✓	✓	✓	00CB, 00CC, 011E
2011	Fiesta	1.6L	Sigma	RCM	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	RCM	✓	✓	✓	✓	000C
2011	Fiesta	1.6L	Sigma	RFA	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Fiesta	1.6L	Sigma	TCM	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	VSM	✓	✓	✓	✓	0042
2011	Fiesta	1.6L	TivCT	ABS	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	ABS	✓	✓	✓	✓	0008, 0012
2011	Fiesta	1.6L	TivCT	ACM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	APIM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	BCM#1	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	FCDIM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	GPSM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	IPC	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	OCSM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	OCSM	✓	✓	✓	✓	000C
2011	Fiesta	1.6L	TivCT	PCM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	PSCM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	PSCM	✓	✓	✓	✓	00CB, 00CC, 011E
2011	Fiesta	1.6L	TivCT	RCM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	RCM	✓	✓	✓	✓	000C
2011	Fiesta	1.6L	TivCT	RFA	✓	✓	✓	✓	

2011	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	0117
2011	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	0117, 0158
2011	Fiesta	1.6L	TiVCT	VSM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TiVCT	VSM	✓	✓	✓	✓	0042
2012	Fiesta	1.6L	Sigma	ABS	✓	✓	✓	✓	0008, 0012
2012	Fiesta	1.6L	Sigma	ACM	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	APIM	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	BCM#1	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	FCDIM	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	GPSM	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	IPC	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	OCSM	✓	✓	✓	✓	000C
2012	Fiesta	1.6L	Sigma	PCM	✓	✓	✓	✓	0025, 0096, 0097, 009A, 012B, 020A
2012	Fiesta	1.6L	Sigma	PSCM	✓	✓	✓	✓	00CB, 00CC, 011E
2012	Fiesta	1.6L	Sigma	RCM	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	RFA	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Fiesta	1.6L	Sigma	TCM	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	VSM	✓	✓	✓	✓	0042
2012	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	Fiesta	1.6L	TiVCT	ACM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	APIM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	BCM#1	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	FCDIM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	GPSM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	IPC	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓	000C
2012	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓	0025, 0095
2012	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓	00CB, 00CC
2012	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓	00CB, 00CC, 011E
2012	Fiesta	1.6L	TiVCT	RCM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	RCM	✓	✓	✓	✓	000C
2012	Fiesta	1.6L	TiVCT	RFA	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	0117, 0158
2012	Fiesta	1.6L	TiVCT	VSM	✓	✓	✓	✓	0042
2013	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	0012
2013	Fiesta	1.6L	TiVCT	ACM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	APIM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	BCM#1	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	IPC	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓	0095
2013	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓	00CB, 00CC, 011E
2013	Fiesta	1.6L	TiVCT	RCM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	RFA	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	0117, 0158
2013	Fiesta	1.6L	TiVCT	VSM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	VSM	✓	✓	✓	✓	0042
2013. 25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013. 25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013. 25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013. 25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	
2013. 25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013. 25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	00E9
2013. 25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2013. 25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013. 25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	

2013.25	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2013.25	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.0L	GTDI FGEC	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.0L	GTDI FGEC	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	PCM	✓	✓	✓	✓	00BC, 0115
2013.25	Fiesta	1.0L	GTDI FGEC	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.0L	GTDI FGEC	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.0L	GTDI FGEC	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	TCM	✓	✓	✓	✓	0117
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.25L	DURATEC 16V	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	00BC
2013.25	Fiesta	1.25L	DURATEC 16V	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.25L	DURATEC 16V	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.4L	DURATEC 16V	FDSM	✓	✓	✓	✓	



2013.25	Fiesta	1.4L	DURATEC 16V	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	00BC
2013.25	Fiesta	1.4L	DURATEC 16V	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.4L	DURATEC 16V	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.5L	DURATEC 16V	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.5L	DURATEC 16V	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.5L	DURATEC 16V	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.5L	DURATEC 16V	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00BD
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.5L	TivCT	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.5L	TivCT	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.5L	TivCT	RCM	✓	✓	✓	✓	00EF, 00F0, 0102

2013.25	Fiesta	1.5L	TiVCT	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TiVCT	TCM	✓	✓	✓	✓	0117, 0158
2013.25	Fiesta	1.5L	Zetec-SE	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.5L	Zetec-SE	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.5L	Zetec-SE	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.5L	Zetec-SE	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.5L	Zetec-SE	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.6L	DURATEC VCT	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	00BC
2013.25	Fiesta	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	TCM	✓	✓	✓	✓	0117
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00BD
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119

2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.6L	TDCi ECO II	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	FCDIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.6L	TDCi ECO II	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00BD
2013.25	Fiesta	1.6L	TDCi ECO II	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.6L	TDCi ECO II	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.6L	TDCi ECO II	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.6L	TiVCT	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.6L	TiVCT	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.6L	TiVCT	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.6L	TiVCT	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 010A
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	

2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓		
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 010A
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓		
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012, 010A
2014	Fiesta	1.6L	TiVCT	ACM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	APIM	✓	✓	✓	✓	

2014	Fiesta	1.6L	TiVCT	BCM#1	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	DDM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	IPC	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2014	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Fiesta	1.6L	TiVCT	RCM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	RFA	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	0117
2014	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	0117, 0158
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0025
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
1992	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1992	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	CSM	✓	✓	✓	✓	
1992	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	HEC	✓	✓	✓	✓	
1994	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1994	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	✓	
1994	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓	
1994.5	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1994.5	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	✓	
1994.5	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓	
1994.5	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1994.5	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	CSM	✓	✓	✓	✓	
1994.5	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	HEC	✓	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	CSM	✓	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	HEC	✓	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1996	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	CSM	✓	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	HEC	✓	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1996	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓	
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	ABS/TCS	✓	✓	✓	✓	
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	CSM	✓	✓	✓	✓	
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	ECS	✓	✓	✓	✓	
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	HEC	✓	✓	✓	✓	
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	FATS	✓	✓	✓	✓	
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	PCM	✓	✓	✓	✓	
1996.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1996.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	CSM	✓	✓	✓	✓	
1996.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
1996.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1996.75	Fiesta / Mazda 121 / Bantam	1.0L	HCS	ABS/TCS	✓	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.0L	HCS	CSM	✓	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.0L	HCS	HEC	✓	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.0L	HCS	PCM	✓	✓	✓	✓	0025
1996.75	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	CSM	✓	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	HEC	✓	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1996.75	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	CSM	✓	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1997	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1997	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	CSM	✓	✓	✓	✓	
1997	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
1997	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1997.5	Fiesta / Mazda 121 / Bantam	1.0L	HCS	ABS/TCS	✓	✓	✓	✓	
1997.5	Fiesta / Mazda 121 / Bantam	1.0L	HCS	CSM	✓	✓	✓	✓	



2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	ABS/TCS	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	CSM	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	ECS	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	HEC	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	PCM	✓	✓	✓	✓	
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	ABS/TCS	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	CSM	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	ECS	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	GEM	✓	✓	✓	✓	
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	HEC	✓	✓	✓	✓	
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	PCM	✓	✓	✓	✓	0025
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	ABS/TCS	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	CSM	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	ECS	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	FIP	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	GEM	✓	✓	✓	✓	
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	HEC	✓	✓	✓	✓	
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	PATS	✓	✓	✓	✓	
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	PCM	✓	✓	✓	✓	
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	ABS/TCS	✓	✓	✓		
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	CSM	✓	✓	✓		
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	GEM	✓	✓	✓	✓	
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	HEC	✓	✓	✓	✓	
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	PATS	✓	✓	✓	✓	
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	PCM	✓	✓	✓	✓	
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	ABS/TCS	✓	✓	✓		
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	CSM	✓	✓	✓		
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	ECS	✓	✓	✓		
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	HEC	✓	✓	✓	✓	
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	PATS	✓	✓	✓	✓	
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	PCM			✓	✓	
2002	Fiesta 3-Door	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3
2002	Fiesta 3-Door	1.25L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F020
2002	Fiesta 3-Door	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fiesta 3-Door	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.3L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	1.3L	DURATEC 8V	GEM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.3L	DURATEC 8V	IC	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.3L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2002	Fiesta 3-Door	1.3L	DURATEC 8V	RCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0012
2002	Fiesta 3-Door	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3
2002	Fiesta 3-Door	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F020
2002	Fiesta 3-Door	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fiesta 3-Door	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	003F
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0012
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2002	Fiesta 3-Door	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025, 0070
2002	Fiesta 3-Door	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	0070
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0096, 0097, 0099, 009A, 00AD, 00AE

2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.25L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.25L	DURATEC 16V	IC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fiesta 3-Door	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.25L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.3L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	1.3L	DURATEC 8V	ACM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.3L	DURATEC 8V	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.3L	DURATEC 8V	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.3L	DURATEC 8V	IC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.3L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2006	Fiesta 3-Door	1.3L	DURATEC 8V	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.3L	DURATEC 8V	SRM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2006	Fiesta 3-Door	1.4L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, F0A2, F0B3, F0B6
2006	Fiesta 3-Door	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	F020, F063, F0B5, F0B7
2006	Fiesta 3-Door	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fiesta 3-Door	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fiesta 3-Door	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	003F
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F02D, F030, F0A2, F0B3, F0B6
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F02D, F030, F0A2, F0B3, F0B6, F0B7
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F020, F063, F0B5, F0B7
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F063, F0B5, F0B7
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2006	Fiesta 3-Door	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	F02D, F030, F0A2, F0B3, F0B6, F0B7
2006	Fiesta 3-Door	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	F020, F063, F0B5
2006	Fiesta 3-Door	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fiesta 3-Door	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025, 0070
2006	Fiesta 3-Door	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fiesta 3-Door	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0096, 0097, 0099, 009A, 00AD, 00AE



2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	4X4	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	ABS	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	ABS	✓	✓	✓	✓	0005, 0008
2006	Five Hundred	3.0L	4V	ACM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2006	Five Hundred	3.0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2006	Five Hundred	3.0L	4V	DSM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	DSM	✓	✓	✓	✓	0005
2006	Five Hundred	3.0L	4V	EATC	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	GEM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	GEM	✓	✓	✓	✓	0005
2006	Five Hundred	3.0L	4V	IC	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	IC	✓	✓	✓	✓	0005
2006	Five Hundred	3.0L	4V	PAM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	PAM	✓	✓	✓	✓	006C
2006	Five Hundred	3.0L	4V	PCM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	PCM	✓	✓	✓	✓	0025
2006	Five Hundred	3.0L	4V	RCM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	RCM	✓	✓	✓	✓	0005, 000C, 006D
2006	Five Hundred	3.0L	4V	RETM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	TCM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	4X4	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	ABS	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	ABS	✓	✓	✓	✓	0008
2007	Five Hundred	3.0L	4V	ACM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Five Hundred	3.0L	4V	DSM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	EATC	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	GEM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	IC	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	PAM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	PAM	✓	✓	✓	✓	006C
2007	Five Hundred	3.0L	4V	PCM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	PCM	✓	✓	✓	✓	0025
2007	Five Hundred	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0037
2007	Five Hundred	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2007	Five Hundred	3.0L	4V	RCM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	RCM	✓	✓	✓	✓	000C
2007	Five Hundred	3.0L	4V	RETM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	SDARS	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	SDARS	✓	✓	✓	✓	0019
2007	Five Hundred	3.0L	4V	TCM	✓	✓	✓	✓	
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	4X4	✓	✓	✓	✓	
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	ABS	✓	✓	✓	✓	0005, 0008
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	DSM	✓	✓	✓	✓	0005
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	EATC	✓	✓	✓	✓	
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	GEM	✓	✓	✓	✓	
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	IC	✓	✓	✓	✓	
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	PAM	✓	✓	✓	✓	006C
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	PCM	✓	✓	✓	✓	0025
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	RCM	✓	✓	✓	✓	000C
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	RETM	✓	✓	✓	✓	
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	TCM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	4X4	✓	✓	✓	✓	
2009	Flex	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2009	Flex	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2009	Flex	3.5L	4V	APTM	✓	✓	✓	✓	0019, 001C
2009	Flex	3.5L	4V	DCSM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	DSM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	DSP	✓	✓	✓	✓	
2009	Flex	3.5L	4V	FCIM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	FDIM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Flex	3.5L	4V	HVAC	✓	✓	✓	✓	
2009	Flex	3.5L	4V	IC	✓	✓	✓	✓	
2009	Flex	3.5L	4V	LTM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2009	Flex	3.5L	4V	PAM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	PCM	✓	✓	✓	✓	0025
2009	Flex	3.5L	4V	RCM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	RETM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	SECM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	4X4	✓	✓	✓	✓	0108
2010	Flex	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2010	Flex	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018

2010	Flex	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Flex	3.5L	4V	C-CM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	DCSM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	DDM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	DSM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	DSP	✓	✓	✓	✓	
2010	Flex	3.5L	4V	FCIM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	FDIM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Flex	3.5L	4V	GPSM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	HCM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	HCM-2	✓	✓	✓	✓	
2010	Flex	3.5L	4V	HUD	✓	✓	✓	✓	
2010	Flex	3.5L	4V	HVAC	✓	✓	✓	✓	
2010	Flex	3.5L	4V	IC	✓	✓	✓	✓	
2010	Flex	3.5L	4V	ILCM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	LTM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Flex	3.5L	4V	PAM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	PCM	✓	✓	✓	✓	0025
2010	Flex	3.5L	4V	PSCM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	RCM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	RETM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	SASM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0018
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019, 001C
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	0005
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC	✓	✓	✓	✓	0005
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015

2010	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0005
2010	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	4X4	✓	✓	✓	✓	0108
2011	Flex	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2011	Flex	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Flex	3.5L	4V	ACM	✓	✓	✓	✓	0018
2011	Flex	3.5L	4V	APIM	✓	✓	✓	✓	0019
2011	Flex	3.5L	4V	C-CM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	DCSM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	DDM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	DSM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	DSP	✓	✓	✓	✓	
2011	Flex	3.5L	4V	FCIM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	FDIM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Flex	3.5L	4V	GPSM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	HCM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	HCM-2	✓	✓	✓	✓	
2011	Flex	3.5L	4V	HUD	✓	✓	✓	✓	
2011	Flex	3.5L	4V	HVAC	✓	✓	✓	✓	
2011	Flex	3.5L	4V	IC	✓	✓	✓	✓	
2011	Flex	3.5L	4V	ILCM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	LTM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Flex	3.5L	4V	PAM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Flex	3.5L	4V	PSCM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	RCM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	RETM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	SASM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	

2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IC	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	I LCM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	4X4	✓	✓	✓	✓	0108
2012	Flex	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2012	Flex	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2012	Flex	3.5L	4V	APIM	✓	✓	✓	✓	0019
2012	Flex	3.5L	4V	DCSM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	DDM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	DSM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	DSP	✓	✓	✓	✓	
2012	Flex	3.5L	4V	FCIM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	FDIM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Flex	3.5L	4V	GPSM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	HCM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	HCM-2	✓	✓	✓	✓	
2012	Flex	3.5L	4V	HVAC	✓	✓	✓	✓	
2012	Flex	3.5L	4V	IC	✓	✓	✓	✓	
2012	Flex	3.5L	4V	I LCM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	LTM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	Flex	3.5L	4V	PAM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2012	Flex	3.5L	4V	PSCM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	RCM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	RETM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	SASM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	

2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IC	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2012	Flex	Other	Other	4X4	✓	✓	✓	✓	
2012	Flex	Other	Other	ABS	✓	✓	✓	✓	
2012	Flex	Other	Other	ACM	✓	✓	✓	✓	
2012	Flex	Other	Other	APIM	✓	✓	✓	✓	
2012	Flex	Other	Other	DCSM	✓	✓	✓	✓	
2012	Flex	Other	Other	DDM	✓	✓	✓	✓	
2012	Flex	Other	Other	DSM	✓	✓	✓	✓	
2012	Flex	Other	Other	DSP	✓	✓	✓	✓	
2012	Flex	Other	Other	FCIM	✓	✓	✓	✓	
2012	Flex	Other	Other	FDIM	✓	✓	✓	✓	
2012	Flex	Other	Other	GEM / SJB	✓	✓	✓	✓	0042
2012	Flex	Other	Other	GPSM	✓	✓	✓	✓	
2012	Flex	Other	Other	HCM	✓	✓	✓	✓	
2012	Flex	Other	Other	HCM-2	✓	✓	✓	✓	
2012	Flex	Other	Other	HVAC	✓	✓	✓	✓	
2012	Flex	Other	Other	IC	✓	✓	✓	✓	
2012	Flex	Other	Other	ILCM	✓	✓	✓	✓	
2012	Flex	Other	Other	LTM	✓	✓	✓	✓	
2012	Flex	Other	Other	OCSM	✓	✓	✓	✓	
2012	Flex	Other	Other	PAM	✓	✓	✓	✓	
2012	Flex	Other	Other	PSCM	✓	✓	✓	✓	
2012	Flex	Other	Other	RCM	✓	✓	✓	✓	
2012	Flex	Other	Other	RETM	✓	✓	✓	✓	
2012	Flex	Other	Other	SASM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046

2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	ABS	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2013	Flex	3.5L	TiVCT	APIM	✓	✓	✓	✓	0019
2013	Flex	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Flex	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Flex	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	DDM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	HCM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	Flex	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108

2013	Flex	3.5L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0108
2013	Flex	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	RACM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPMS	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	

2014	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	ABS	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Flex	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Flex	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	DDM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	HCM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	Flex	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0108
2014	Flex	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	RACM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Flex	Other	Other	ABS	✓	✓	✓	✓	
2014	Flex	Other	Other	ACM	✓	✓	✓	✓	
2014	Flex	Other	Other	APIM	✓	✓	✓	✓	
2014	Flex	Other	Other	BCM#1	✓	✓	✓	✓	
2014	Flex	Other	Other	C-CM	✓	✓	✓	✓	
2014	Flex	Other	Other	DCSM	✓	✓	✓	✓	
2014	Flex	Other	Other	DDM	✓	✓	✓	✓	
2014	Flex	Other	Other	DSM	✓	✓	✓	✓	
2014	Flex	Other	Other	DSP	✓	✓	✓	✓	
2014	Flex	Other	Other	FCDIM	✓	✓	✓	✓	
2014	Flex	Other	Other	FCIM	✓	✓	✓	✓	
2014	Flex	Other	Other	GPSM	✓	✓	✓	✓	
2014	Flex	Other	Other	HCM	✓	✓	✓	✓	
2014	Flex	Other	Other	HUD	✓	✓	✓	✓	
2014	Flex	Other	Other	HVAC	✓	✓	✓	✓	
2014	Flex	Other	Other	IPC	✓	✓	✓	✓	
2014	Flex	Other	Other	LTM	✓	✓	✓	✓	
2014	Flex	Other	Other	OCSM	✓	✓	✓	✓	
2014	Flex	Other	Other	PAM	✓	✓	✓	✓	
2014	Flex	Other	Other	PSCM	✓	✓	✓	✓	
2014	Flex	Other	Other	RACM	✓	✓	✓	✓	
2014	Flex	Other	Other	RCM	✓	✓	✓	✓	
2014	Flex	Other	Other	RFA	✓	✓	✓	✓	
2014	Flex	Other	Other	RTM	✓	✓	✓	✓	
2014	Flex	Other	Other	SCCM	✓	✓	✓	✓	
2014	Flex	Other	Other	SOD-L	✓	✓	✓	✓	
2014	Flex	Other	Other	SOD-R	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	CSM	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	GSM	✓	✓	✓	✓	0008, 0012
1999	Focus	1.4L	Zetec-SE	CTM	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	ECS	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	MC	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	PATS	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1999	Focus	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec	CSM	✓	✓	✓	✓	0008, 0012
1999	Focus	1.6L	Zetec	CTM	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec	ECS	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec	HEC	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec	PATS	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec	PCM	✓	✓	✓	✓	0025
1999	Focus	1.6L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	CSM	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	CSM	✓	✓	✓	✓	0008, 0012
1999	Focus	1.6L	Zetec-SE	CTM	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	ECS	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	HEC	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	MC	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	PATS	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1999	Focus	1.8L	Endura DI	ABS/TCS	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	CSM	✓	✓	✓	✓	



1999	Focus	1.8L	Endura DI	CSM	✓	✓	✓	✓	0008, 0012
1999	Focus	1.8L	Endura DI	CTM	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	ECS	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	FFH	✓	✓	✓	✓	00CF
1999	Focus	1.8L	Endura DI	FIP	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	HEC	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	MC	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	PATS	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	PCM	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	PCM	✓	✓	✓	✓	0008, 0012, 0032
1999	Focus	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	AFCM	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	CSM	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	CSM	✓	✓	✓	✓	0008, 0012
1999	Focus	1.8L	Zetec	CTM	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	CTM	✓	✓	✓	✓	0008
1999	Focus	1.8L	Zetec	ECS	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	HEC	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	MC	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	PATS	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	PCM	✓	✓	✓	✓	0025
1999	Focus	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	GSM	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	CSM	✓	✓	✓	✓	0008, 0012
1999	Focus	2.0L	Zetec	CTM	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	CTM	✓	✓	✓	✓	0005
1999	Focus	2.0L	Zetec	ECS	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	HEC	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	HEC	✓	✓	✓	✓	0005
1999	Focus	2.0L	Zetec	MC	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	PATS	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2000	Focus	2.0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
2000	Focus	2.0L	SPI	GSM	✓	✓	✓	✓	
2000	Focus	2.0L	SPI	CSM	✓	✓	✓	✓	0008, 0012
2000	Focus	2.0L	SPI	CTM	✓	✓	✓	✓	
2000	Focus	2.0L	SPI	ECS	✓	✓	✓	✓	
2000	Focus	2.0L	SPI	HEC	✓	✓	✓	✓	
2000	Focus	2.0L	SPI	PCM	✓	✓	✓	✓	0025
2000	Focus	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2000	Focus	2.0L	Zetec	CSM	✓	✓	✓	✓	
2000	Focus	2.0L	Zetec	CSM	✓	✓	✓	✓	0008, 0012
2000	Focus	2.0L	Zetec	CTM	✓	✓	✓	✓	
2000	Focus	2.0L	Zetec	CTM	✓	✓	✓	✓	0005
2000	Focus	2.0L	Zetec	ECS	✓	✓	✓	✓	
2000	Focus	2.0L	Zetec	HEC	✓	✓	✓	✓	
2000	Focus	2.0L	Zetec	HEC	✓	✓	✓	✓	0005
2000	Focus	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	0012
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CTM	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ECS	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MC	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	1.4L	Zetec-SE	EATC	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	ECS	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	GEM	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	HCM	✓	✓	✓	✓	0032
2002	Focus	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	MC	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	PATS	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
2002	Focus	1.4L	Zetec-SE	RCM	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	1.6L	Zetec	EATC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec	ECS	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec	GEM	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec	HCM	✓	✓	✓	✓	0032
2002	Focus	1.6L	Zetec	HEC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec	MC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec	PCM	✓	✓	✓	✓	0025
2002	Focus	1.6L	Zetec	RCM	✓	✓	✓	✓	

2002	Focus	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	1.6L	Zetec Rocam	EATC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec Rocam	ECS	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec Rocam	GEM	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec Rocam	HCM	✓	✓	✓	✓	0032
2002	Focus	1.6L	Zetec Rocam	HEC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec Rocam	MC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2002	Focus	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	1.6L	Zetec-SE	EATC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	ECS	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	GEM	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	HCM	✓	✓	✓	✓	0032
2002	Focus	1.6L	Zetec-SE	HEC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	MC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	PATS	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	PCM	✓	✓	✓	✓	0025
2002	Focus	1.6L	Zetec-SE	RCM	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0012
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ECS	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F02D, F02F, F030, F03A, F09E, FOA1, FOA4
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	0005
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MC	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0005
2002	Focus	1.8L	Endura DI	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	1.8L	Endura DI	EATC	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	ECS	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	FFH	✓	✓	✓	✓	00CF
2002	Focus	1.8L	Endura DI	FIP	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	GEM	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	HCM	✓	✓	✓	✓	0032
2002	Focus	1.8L	Endura DI	HEC	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	MC	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	PATS	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	PCM	✓	✓	✓	✓	0008, 0012, 0032
2002	Focus	1.8L	Endura DI	RCM	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	1.8L	Zetec	AFCM	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	EATC	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	ECS	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	GEM	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	HCM	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	HCM	✓	✓	✓	✓	0032
2002	Focus	1.8L	Zetec	HEC	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	MC	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	PCM	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	PCM	✓	✓	✓	✓	0025
2002	Focus	1.8L	Zetec	RCM	✓	✓	✓	✓	
2002	Focus	2.0L	SPI	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	2.0L	SPI	EATC	✓	✓	✓	✓	
2002	Focus	2.0L	SPI	ECS	✓	✓	✓	✓	
2002	Focus	2.0L	SPI	GEM	✓	✓	✓	✓	
2002	Focus	2.0L	SPI	HCM	✓	✓	✓	✓	0032
2002	Focus	2.0L	SPI	HEC	✓	✓	✓	✓	
2002	Focus	2.0L	SPI	MC	✓	✓	✓	✓	
2002	Focus	2.0L	SPI	PCM	✓	✓	✓	✓	0025
2002	Focus	2.0L	SPI	RCM	✓	✓	✓	✓	
2002	Focus	2.0L	ZETEC ST	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	2.0L	ZETEC ST	EATC	✓	✓	✓	✓	

2002	Focus	2. 0L	ZETEC ST	ECS	✓	✓	✓	✓	
2002	Focus	2. 0L	ZETEC ST	GEM	✓	✓	✓	✓	
2002	Focus	2. 0L	ZETEC ST	HCM	✓	✓	✓	✓	0032
2002	Focus	2. 0L	ZETEC ST	HEC	✓	✓	✓	✓	
2002	Focus	2. 0L	ZETEC ST	MC	✓	✓	✓	✓	
2002	Focus	2. 0L	ZETEC ST	PCM	✓	✓	✓	✓	0025
2002	Focus	2. 0L	ZETEC ST	RCM	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	2. 0L	Zetec	EATC	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	ECS	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	GEM	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	GEM	✓	✓	✓	✓	0005, F02D, F02F, F030, F03A, F09E, F0A1, F0A4
2002	Focus	2. 0L	Zetec	HCM	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	HCM	✓	✓	✓	✓	0032
2002	Focus	2. 0L	Zetec	HEC	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	HEC	✓	✓	✓	✓	0005
2002	Focus	2. 0L	Zetec	MC	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
2002	Focus	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025, F020
2002	Focus	2. 0L	Zetec	RCM	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	RCM	✓	✓	✓	✓	0005
2003	Focus	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008, 0012
2003	Focus	2. 0L	SPI	GEM	✓	✓	✓	✓	
2003	Focus	2. 0L	SPI	HEC	✓	✓	✓	✓	
2003	Focus	2. 0L	SPI	PCM	✓	✓	✓	✓	0025
2003	Focus	2. 0L	SPI	RCM	✓	✓	✓	✓	
2003	Focus	2. 0L	ZETEC ST	ABS/TCS	✓	✓	✓	✓	0008, 0012
2003	Focus	2. 0L	ZETEC ST	GEM	✓	✓	✓	✓	
2003	Focus	2. 0L	ZETEC ST	HEC	✓	✓	✓	✓	
2003	Focus	2. 0L	ZETEC ST	PCM	✓	✓	✓	✓	0025
2003	Focus	2. 0L	ZETEC ST	RCM	✓	✓	✓	✓	
2003	Focus	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008, 0012
2003	Focus	2. 0L	Zetec	GEM	✓	✓	✓	✓	
2003	Focus	2. 0L	Zetec	HEC	✓	✓	✓	✓	
2003	Focus	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
2003	Focus	2. 0L	Zetec	RCM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2003. 25	Focus	1. 4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	CDP	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	EATC	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2003. 25	Focus	1. 4L	DURATEC 16V	GDM	✓	✓	✓	✓	0100
2003. 25	Focus	1. 4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2003. 25	Focus	1. 4L	DURATEC 16V	IC	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	NAV	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	PAM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	RETM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	RKE	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	RL DCU	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	RR DCU	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	ABS	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2003. 25	Focus	1. 6L	DURATEC 16V	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 00E8
2003. 25	Focus	1. 6L	DURATEC 16V	ACM	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2003. 25	Focus	1. 6L	DURATEC 16V	CDP	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	CDP	✓	✓	✓	✓	0005
2003. 25	Focus	1. 6L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	D DCU	✓	✓	✓	✓	F026
2003. 25	Focus	1. 6L	DURATEC 16V	EATC	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2003. 25	Focus	1. 6L	DURATEC 16V	FFH	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2003. 25	Focus	1. 6L	DURATEC 16V	GDM	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	GDM	✓	✓	✓	✓	0005
2003. 25	Focus	1. 6L	DURATEC 16V	GDM	✓	✓	✓	✓	0005, 0100
2003. 25	Focus	1. 6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2003. 25	Focus	1. 6L	DURATEC 16V	HCM	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	HCM	✓	✓	✓	✓	0005, 0155, 0156
2003. 25	Focus	1. 6L	DURATEC 16V	IC	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	IC	✓	✓	✓	✓	F01E, F020, F028, F032, F03E
2003. 25	Focus	1. 6L	DURATEC 16V	NAV	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	PAM	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005

2003.25	Focus	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2003.25	Focus	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	F027, F031
2003.25	Focus	1.6L	DURATEC 16V	RETM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	RETM	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	DURATEC 16V	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	RL_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	1.6L	DURATEC 16V	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	RR_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2003.25	Focus	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	0070, 00C5
2003.25	Focus	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB
2003.25	Focus	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	D_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	EATC	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	1.6L	DURATEC VCT	GDM	✓	✓	✓	✓	0100
2003.25	Focus	1.6L	DURATEC VCT	GEM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2003.25	Focus	1.6L	DURATEC VCT	IC	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	NAV	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	0025
2003.25	Focus	1.6L	DURATEC VCT	P_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	RETM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00E8
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	0005, 006B, 0094, 00A1
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0005, 0100
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0005, 0155, 0156
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	

2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F01E, F020, F028, F032, F03E
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0096, 0097, 0098, 0099, 009A
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	F027, F031
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	F026
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	F026
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F038, F039
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2003.25	Focus	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	0005
2003.25	Focus	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2003.25	Focus	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2003.25	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2003.25	Focus	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2003.25	Focus	1.8L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	0005
2003.25	Focus	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F027, F031
2003.25	Focus	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	RL_DCU	✓	✓	✓	✓	0005
2003.25	Focus	1.8L	DURATEC-HE / I4	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	RR_DCU	✓	✓	✓	✓	0005
2003.25	Focus	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	

2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 00B4
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2003.25	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8
2003.25	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2003.25	Focus	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02A, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2003.25	Focus	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0005, 0155, 0156
2003.25	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2003.25	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2003.25	Focus	2.0L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F027, F031
2003.25	Focus	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	RL_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	2.0L	DURATEC-HE / I4	RR_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0070, 00C5
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	0005, 006B, 0094, 00A1
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0005, 0100

2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	F027, F031
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F039, F03F
2003.25	Focus	2.5L	15	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2003.25	Focus	2.5L	15	ACM	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	ACM	✓	✓	✓	✓	0005
2003.25	Focus	2.5L	15	CDP	✓	✓	✓	✓	0005
2003.25	Focus	2.5L	15	D_DCU	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	EATC	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	EATC	✓	✓	✓	✓	0005
2003.25	Focus	2.5L	15	EPS	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	2.5L	15	GDM	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	GEM	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	HCM	✓	✓	✓	✓	0155, 0156
2003.25	Focus	2.5L	15	IC	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	MC	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	NAV	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	PAM	✓	✓	✓	✓	0005
2003.25	Focus	2.5L	15	PCM	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	P_DCU	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	RCM	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	RETM	✓	✓	✓	✓	0005
2003.25	Focus	2.5L	15	RKE	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	SRM	✓	✓	✓	✓	
2003.5	Focus	2.3L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 0012
2003.5	Focus	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2003.5	Focus	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2003.5	Focus	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2003.5	Focus	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2004	Focus	2.0L	SPI	ABS/TCS	✓	✓	✓	✓	0008, 0012
2004	Focus	2.0L	SPI	GEM	✓	✓	✓	✓	
2004	Focus	2.0L	SPI	HEC	✓	✓	✓	✓	
2004	Focus	2.0L	SPI	PCM	✓	✓	✓	✓	0025
2004	Focus	2.0L	SPI	RCM	✓	✓	✓	✓	
2004	Focus	2.0L	ZETEC ST	ABS/TCS	✓	✓	✓	✓	0008, 0012
2004	Focus	2.0L	ZETEC ST	GEM	✓	✓	✓	✓	
2004	Focus	2.0L	ZETEC ST	HEC	✓	✓	✓	✓	
2004	Focus	2.0L	ZETEC ST	PCM	✓	✓	✓	✓	0025
2004	Focus	2.0L	ZETEC ST	RCM	✓	✓	✓	✓	
2004	Focus	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008, 0012
2004	Focus	2.0L	Zetec	GEM	✓	✓	✓	✓	
2004	Focus	2.0L	Zetec	HEC	✓	✓	✓	✓	
2004	Focus	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2004	Focus	2.0L	Zetec	RCM	✓	✓	✓	✓	
2004	Focus	2.3L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 0012
2004	Focus	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2004	Focus	2.3L	DURATEC-HE / I4	HEC	✓	✓	✓	✓	
2004	Focus	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2004	Focus	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2004	Focus	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2005	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2005	Focus	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2005	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2005	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2005	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2005	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2005	Focus	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2005	Focus	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2005	Focus	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2005	Focus	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025

2005	Focus	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2005.5	Focus	2. 0L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2005.5	Focus	2. 0L	DURATEC 16V	EATC	✓	✓	✓	✓	
2005.5	Focus	2. 0L	DURATEC 16V	GEM	✓	✓	✓	✓	
2005.5	Focus	2. 0L	DURATEC 16V	HCM	✓	✓	✓	✓	0032
2005.5	Focus	2. 0L	DURATEC 16V	IC	✓	✓	✓	✓	
2005.5	Focus	2. 0L	DURATEC 16V	MC	✓	✓	✓	✓	
2005.5	Focus	2. 0L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2005.5	Focus	2. 0L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2006	Focus	2. 0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2006	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2006	Focus	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2006	Focus	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Focus	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Focus	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	Focus	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2007	Focus	1. 6L	FFV	ABS/TCS	✓	✓	✓	✓	0012
2007	Focus	1. 6L	FFV	GEM	✓	✓	✓	✓	
2007	Focus	1. 6L	FFV	IC	✓	✓	✓	✓	
2007	Focus	1. 6L	FFV	PCM	✓	✓	✓	✓	0025
2007	Focus	1. 6L	FFV	RCM	✓	✓	✓	✓	
2007	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2007	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2007	Focus	2. 0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2007	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2007	Focus	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2007	Focus	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007	Focus	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	Focus	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	Focus	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2007.5	Focus	1. 4L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8
2007.5	Focus	1. 4L	DURATEC 16V	ACM	✓	✓	✓	✓	011A
2007.5	Focus	1. 4L	DURATEC 16V	CDP	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2007.5	Focus	1. 4L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	1. 4L	DURATEC 16V	GDM	✓	✓	✓	✓	0100
2007.5	Focus	1. 4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	HCM	✓	✓	✓	✓	0156
2007.5	Focus	1. 4L	DURATEC 16V	IC	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	NAV	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2007.5	Focus	1. 4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	RETM	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	RKE	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8
2007.5	Focus	1. 6L	DURATEC 16V	ACM	✓	✓	✓	✓	011A
2007.5	Focus	1. 6L	DURATEC 16V	CDP	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2007.5	Focus	1. 6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	1. 6L	DURATEC 16V	GDM	✓	✓	✓	✓	0100
2007.5	Focus	1. 6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	HCM	✓	✓	✓	✓	0156
2007.5	Focus	1. 6L	DURATEC 16V	IC	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	NAV	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2007.5	Focus	1. 6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	RETM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	RKE	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2007.5	Focus	1. 6L	DURATEC VCT	ACM	✓	✓	✓	✓	0005
2007.5	Focus	1. 6L	DURATEC VCT	CDP	✓	✓	✓	✓	0005
2007.5	Focus	1. 6L	DURATEC VCT	D DCU	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC VCT	EATC	✓	✓	✓	✓	0005
2007.5	Focus	1. 6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	1. 6L	DURATEC VCT	GDM	✓	✓	✓	✓	0100
2007.5	Focus	1. 6L	DURATEC VCT	GEM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	1. 6L	DURATEC VCT	IC	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC VCT	NAV	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC VCT	PAM	✓	✓	✓	✓	0005



2007.5	Focus	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2007.5	Focus	1.6L	DURATEC VCT	P DCU	✓	✓	✓	✓	
2007.5	Focus	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2007.5	Focus	1.6L	DURATEC VCT	RETM	✓	✓	✓	✓	0005
2007.5	Focus	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	
2007.5	Focus	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	D_DCUI	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0096, 0097, 0098, 0099, 009A, 020A
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	P_DCUI	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 00DD, 00DE, 00E8
2007.5	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	DURATEC-HE / I4	D DCUI	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	D_DCUI	✓	✓	✓	✓	0005, F026
2007.5	Focus	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2007.5	Focus	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	F026, F02D, F02E, F02F, F032, F035, F03A, F03B, F03C
2007.5	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0005, 0155, 0156
2007.5	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	F028, F032, F03E
2007.5	Focus	1.8L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007.5	Focus	1.8L	DURATEC-HE / I4	P DCUI	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	P_DCUI	✓	✓	✓	✓	0005, F026
2007.5	Focus	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	F027, F031
2007.5	Focus	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	0005

2007.5	Focus	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	F037, F038, F039
2007.5	Focus	1.8L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 00B4
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2007.5	Focus	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007.5	Focus	2.0L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0070, 00C5
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1

2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0098, 0099, 00AB
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	2.5L	15	ACM	✓	✓	✓	✓	0005
2007.5	Focus	2.5L	15	CDP	✓	✓	✓	✓	0005
2007.5	Focus	2.5L	15	D DCU	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	EATC	✓	✓	✓	✓	0005
2007.5	Focus	2.5L	15	EPS	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	2.5L	15	GDM	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	GEM	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	2.5L	15	IC	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	MC	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	NAV	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	PAM	✓	✓	✓	✓	0005
2007.5	Focus	2.5L	15	PCM	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	P DCU	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	RCM	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	RETM	✓	✓	✓	✓	0005
2007.5	Focus	2.5L	15	RKE	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	SRM	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2008	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005, 0017, 0018, F021, F05A, F078, F079, F07A, F07B, F07C, F07D
2008	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2008	Focus	2.0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2008	Focus	2.0L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	0005, F05A, F078
2008	Focus	2.0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2008	Focus	2.0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F042, F04B, F04C
2008	Focus	2.0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F027
2008	Focus	2.0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2008	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2008	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	F022, F05D
2008	Focus	2.0L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	F062
2008.25	Focus	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	CDP	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	CMR	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	EATC	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	EPS	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	PAM	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2008.25	Focus	1.4L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	00EA
2008.25	Focus	1.4L	DURATEC 16V	RETM	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	RKE	✓	✓	✓	✓	

2008.25	Focus	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC 16V	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	CDP	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	CMR	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC 16V	D_DCU	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	EPS	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus	1.6L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F03E
2008.25	Focus	1.6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2008.25	Focus	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus	1.6L	DURATEC 16V	RETM	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2008.25	Focus	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	0070, 00C5
2008.25	Focus	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	CMR	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC VCT	D_DCU	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC VCT	EATC	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	EPS	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	1.6L	DURATEC VCT	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	1.6L	DURATEC VCT	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008.25	Focus	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	0025
2008.25	Focus	1.6L	DURATEC VCT	P_DCU	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus	1.6L	DURATEC VCT	RETM	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	F037, F038, F039
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0096, 0097, 0098, 0099, 009A, 020A
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EA
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	

2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	0005, 011A
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	D_DCU	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	EATC	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	EPS	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	EPS	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	FFH	✓	✓	✓	✓	002D, 002F
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	GEM	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	GEM	✓	✓	✓	✓	F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0155, 0156
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	IC	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0097, 0098, 0099, 009A, 00B0, 00B1, 00BA
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	P_DCU	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EA
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EA, F027, F031
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	RETM	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	RETM	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	RKE	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	RKE	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	F037, F038, F039
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	

2008.25	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8
2008.25	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	0005, F026
2008.25	Focus	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0005, 0155, 0156
2008.25	Focus	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008.25	Focus	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F020
2008.25	Focus	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008.25	Focus	1.8L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	0005, F026
2008.25	Focus	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, 00EA, F027, F031
2008.25	Focus	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	F037, F038, F039
2008.25	Focus	1.8L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	0005, 006B
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 00B4
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F038, F039
2008.25	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	

2008.25	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	F020
2008.25	Focus	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008.25	Focus	2.0L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, 00EA
2008.25	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EA
2008.25	Focus	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0070, 00C5
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCUI	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCUI	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 00AB
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCUI	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCUI	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0005, 00EA

2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EA
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2008.25	Focus	2.5L	Duratec RS	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	2.5L	Duratec RS	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 00EB, 00EC
2008.25	Focus	2.5L	Duratec RS	ACM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	CDP	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	CMR	✓	✓	✓	✓	
2008.25	Focus	2.5L	Duratec RS	D DCU	✓	✓	✓	✓	
2008.25	Focus	2.5L	Duratec RS	EATC	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	EPS	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	2.5L	Duratec RS	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus	2.5L	Duratec RS	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	2.5L	Duratec RS	IC	✓	✓	✓	✓	0005, 0113, F01E, F020, F028, F032, F036, F03E
2008.25	Focus	2.5L	Duratec RS	MC	✓	✓	✓	✓	
2008.25	Focus	2.5L	Duratec RS	PAM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	PCM	✓	✓	✓	✓	
2008.25	Focus	2.5L	Duratec RS	P DCU	✓	✓	✓	✓	
2008.25	Focus	2.5L	Duratec RS	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus	2.5L	Duratec RS	RETM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	RKE	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	SRM	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	2.5L	I5	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 0030, 00DD, 00DE
2008.25	Focus	2.5L	I5	ACM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	ACM	✓	✓	✓	✓	011A
2008.25	Focus	2.5L	I5	CDP	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	CDP	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	CMR	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	D DCU	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	EATC	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	EPS	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	2.5L	I5	GEM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus	2.5L	I5	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	2.5L	I5	HCM	✓	✓	✓	✓	0156
2008.25	Focus	2.5L	I5	IC	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	IC	✓	✓	✓	✓	0005, 0113, F01E, F020, F028, F032, F036, F03E
2008.25	Focus	2.5L	I5	MC	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	PAM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	PCM	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	P DCU	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	RCM	✓	✓	✓	✓	0005, 00EA
2008.25	Focus	2.5L	I5	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus	2.5L	I5	RETM	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	RETM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	RKE	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	SRM	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	SRM	✓	✓	✓	✓	F037, F038, F039
2009	Focus	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 0012
2009	Focus	1.6L	FFV	EATC	✓	✓	✓	✓	
2009	Focus	1.6L	FFV	GEM	✓	✓	✓	✓	
2009	Focus	1.6L	FFV	HCM	✓	✓	✓	✓	0032
2009	Focus	1.6L	FFV	IC	✓	✓	✓	✓	
2009	Focus	1.6L	FFV	MC	✓	✓	✓	✓	
2009	Focus	1.6L	FFV	PCM	✓	✓	✓	✓	0025
2009	Focus	1.6L	FFV	RCM	✓	✓	✓	✓	
2009	Focus	1.6L	OHC	ABS/TCS	✓	✓	✓	✓	0012
2009	Focus	1.6L	OHC	EATC	✓	✓	✓	✓	
2009	Focus	1.6L	OHC	GEM	✓	✓	✓	✓	
2009	Focus	1.6L	OHC	HCM	✓	✓	✓	✓	0032
2009	Focus	1.6L	OHC	IC	✓	✓	✓	✓	
2009	Focus	1.6L	OHC	MC	✓	✓	✓	✓	
2009	Focus	1.6L	OHC	PCM	✓	✓	✓	✓	0025
2009	Focus	1.6L	OHC	RCM	✓	✓	✓	✓	
2009	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012



2009	Focus	2. 0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2009	Focus	2. 0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2009	Focus	2. 0L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2009	Focus	2. 0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2009	Focus	2. 0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2009	Focus	2. 0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2009	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2009	Focus	2. 0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C
2009	Focus	2. 0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2009	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2009	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00EB, 00EC
2010	Focus	1. 6L	FFV	ACM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	D DCU	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	EATC	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	EPS	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	GEM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	HCM	✓	✓	✓	✓	0155
2010	Focus	1. 6L	FFV	IC	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	PAM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	PCM	✓	✓	✓	✓	0025, 0096, 0097, 009A, 00AB, 020A
2010	Focus	1. 6L	FFV	PCM	✓	✓	✓	✓	0096, 0097, 009A, 00AB, 020A
2010	Focus	1. 6L	FFV	P DCU	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	RCM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	RKE	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	SRM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Focus	1. 6L	FFV	TCM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	TCM	✓	✓	✓	✓	0070, 00C5
2010	Focus	1. 6L	Sigma	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00EB, 00EC
2010	Focus	1. 6L	Sigma	ACM	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	D DCU	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	EATC	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	EPS	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	GEM	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	HCM	✓	✓	✓	✓	0155
2010	Focus	1. 6L	Sigma	IC	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	PAM	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	PCM	✓	✓	✓	✓	0096, 0097, 009A, 00AB, 020A
2010	Focus	1. 6L	Sigma	P DCU	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	RCM	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	RKE	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	SRM	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Focus	1. 6L	Sigma	TCM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00EB, 00EC
2010	Focus	2. 0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018, F021, F05A, F078, F079, F07A, F07B, F07C, F07D
2010	Focus	2. 0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2010	Focus	2. 0L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	F05A, F078
2010	Focus	2. 0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F042, F04B, F04C
2010	Focus	2. 0L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155
2010	Focus	2. 0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F027
2010	Focus	2. 0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2010	Focus	2. 0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2010	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0096, 0097, 009A
2010	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0096, 0097, 009A
2010	Focus	2. 0L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2010	Focus	2. 0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Focus	2. 0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	ABS	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00EB, 00EC

2010	Focus	2. 0L	FFV	ACM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	D DCU	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	EATC	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	EPS	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	GEM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	HCM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	HCM	✓	✓	✓	✓	0155
2010	Focus	2. 0L	FFV	IC	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	PAM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	PCM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	PCM	✓	✓	✓	✓	0025, 0096, 0097, 009A, 00AB, 020A
2010	Focus	2. 0L	FFV	PCM	✓	✓	✓	✓	0096, 0097, 009A, 00AB, 020A
2010	Focus	2. 0L	FFV	P DCU	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	RCM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	RKE	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	SRM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	TBM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Focus	2. 0L	FFV	TCM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	TCM	✓	✓	✓	✓	0070, 00C5
2011	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0012
2011	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2011	Focus	2. 0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2011	Focus	2. 0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018, F021, F05A, F078, F079, F07A, F07B, F07C, F07D
2011	Focus	2. 0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2011	Focus	2. 0L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2011	Focus	2. 0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2011	Focus	2. 0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	F05A, F078
2011	Focus	2. 0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2011	Focus	2. 0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F042, F04B, F04C
2011	Focus	2. 0L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	
2011	Focus	2. 0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2011	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2011	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F027
2011	Focus	2. 0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2011	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2011	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2011	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	0140
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	F020

2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	0141
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0102
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011.25	Focus	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	AHCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	AHCM	✓	✓	✓	✓	00CF
2011.25	Focus	1.6L	DURATEC VCT	APIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	00D5
2011.25	Focus	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	00D5, 0101
2011.25	Focus	1.6L	DURATEC VCT	CCMii	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	CCMii	✓	✓	✓	✓	00F9
2011.25	Focus	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	00FB, 0140
2011.25	Focus	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	0140
2011.25	Focus	1.6L	DURATEC VCT	DSP	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	FCDIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	FCIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	FDSM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	GPSM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0032
2011.25	Focus	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	F020
2011.25	Focus	1.6L	DURATEC VCT	IPM-A	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	1.6L	DURATEC VCT	IPM-B	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	00BC, 0116, 0117
2011.25	Focus	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	0116
2011.25	Focus	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	00FC, 0141
2011.25	Focus	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	0141
2011.25	Focus	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	0102
2011.25	Focus	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	SASM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	SOD-L	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	SOD-R	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	TCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	TCM	✓	✓	✓	✓	0117
2011.25	Focus	1.6L	DURATEC VCT	TRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	

2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	00D5
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	0140
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	DSP	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FCIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FDSM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GPSM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-B	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00B1, 00B3, 00B7, 00B9, 00BC, 00BD, 00C1, 00C3
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	0141
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0102
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 0119
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	00FB, 0140
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	0140
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	

2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓		0032
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	00FC, 0141
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	0141
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0102
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SRM	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	ABS	✓	✓	✓		002B, 002C, 0053, 00D9, 00DB, 00ES, 0119
2011.25	Focus	1.6L	TDCi ECO III	ACM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	AHCM	✓	✓	✓	✓	00CF
2011.25	Focus	1.6L	TDCi ECO III	APIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	BCMii	✓	✓	✓		00D5
2011.25	Focus	1.6L	TDCi ECO III	BCMii	✓	✓	✓		00D5, 0101
2011.25	Focus	1.6L	TDCi ECO III	BCMii	✓	✓	✓	✓	00D5, 0101
2011.25	Focus	1.6L	TDCi ECO III	CCMii	✓	✓	✓	✓	00F9
2011.25	Focus	1.6L	TDCi ECO III	DDM	✓	✓	✓	✓	0140
2011.25	Focus	1.6L	TDCi ECO III	DSP	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	FCDIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	FCIM	✓	✓	✓		
2011.25	Focus	1.6L	TDCi ECO III	FDSM	✓	✓	✓		
2011.25	Focus	1.6L	TDCi ECO III	GPSM	✓	✓	✓		
2011.25	Focus	1.6L	TDCi ECO III	HCM	✓	✓	✓		0032
2011.25	Focus	1.6L	TDCi ECO III	HVAC	✓	✓	✓		
2011.25	Focus	1.6L	TDCi ECO III	IPC	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	1.6L	TDCi ECO III	IPM-B	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	PAM	✓	✓	✓	✓	

2011.25	Focus	1.6L	TDCi ECO III	PCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	PCM	✓	✓	✓	✓	0098, 00AF, 00B0, 00B2, 00B8, 00BD, 00C3
2011.25	Focus	1.6L	TDCi ECO III	PDM	✓	✓	✓	✓	0141
2011.25	Focus	1.6L	TDCi ECO III	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	1.6L	TDCi ECO III	RCM	✓	✓	✓	✓	0102
2011.25	Focus	1.6L	TDCi ECO III	RFA	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	SASM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	SOD-L	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	SOD-R	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	SRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	TRM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	00D5
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	0140
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	DSP	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FCIM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FDSM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GPMS	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPM-B	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1, 00E7, 0115, 0116, 013B
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1, 00E7
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	009A
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	0141
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0102
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	

2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓		00D5
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓		00D5, 0101
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	0140
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓		0032
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ICM#1	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	0141
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0102
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SRM	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Gasoline Direct injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119

2011.25	Focus	2.0L	Gasoline Direct injection	ACM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	AHCM	√	√	√	√	00CF
2011.25	Focus	2.0L	Gasoline Direct injection	APIM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	BCMii	√	√	√	√	00D5, 0101
2011.25	Focus	2.0L	Gasoline Direct injection	CCMii	√	√	√	√	00F9
2011.25	Focus	2.0L	Gasoline Direct injection	DDM	√	√	√	√	0140
2011.25	Focus	2.0L	Gasoline Direct injection	DSP	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	FCDIM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	FCIM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	FDSM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	GPSM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	HCM	√	√	√	√	0032
2011.25	Focus	2.0L	Gasoline Direct injection	HVAC	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	IPC	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	IPM-A	√	√	√	√	00E5
2011.25	Focus	2.0L	Gasoline Direct injection	IPM-B	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	PAM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	PCM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	PDM	√	√	√	√	0141
2011.25	Focus	2.0L	Gasoline Direct injection	PSCM	√	√	√	√	00DC, 00DF, 00E0, 00E1
2011.25	Focus	2.0L	Gasoline Direct injection	RCM	√	√	√	√	0102
2011.25	Focus	2.0L	Gasoline Direct injection	RFA	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	SASM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	SOD-L	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	SOD-R	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	SRM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	TCM	√	√	√	√	0117
2011.25	Focus	2.0L	Gasoline Direct injection	TRM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	ABS	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	ABS	√	√	√	√	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011.25	Focus	2.0L	Gasoline Direct injection	ACM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	ACM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	AHCM	√	√	√	√	00CF
2011.25	Focus	2.0L	Gasoline Direct injection	AHCM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	AHCM	√	√	√	√	00CF
2011.25	Focus	2.0L	Gasoline Direct injection	APIM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	APIM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	BCMii	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	BCMii	√	√	√	√	00D5
2011.25	Focus	2.0L	Gasoline Direct injection	BCMii	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	BCMii	√	√	√	√	00D5, 0101
2011.25	Focus	2.0L	Gasoline Direct injection	CCMii	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	CCMii	√	√	√	√	00F9
2011.25	Focus	2.0L	Gasoline Direct injection	DDM	√	√	√	√	



2011.25	Focus	2.0L	Gasoline_Direct_injection	DDM	√	√	√	√	0140
2011.25	Focus	2.0L	Gasoline_Direct_injection	DSP	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	FCDIM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	FCIM	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	FDSM	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	GPSM	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	HCM	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	HCM	√	√	√		0032
2011.25	Focus	2.0L	Gasoline_Direct_injection	HVAC	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	IPC	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	IPC	√	√	√	√	F020
2011.25	Focus	2.0L	Gasoline_Direct_injection	IPM-A	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	IPM-A	√	√	√	√	00E5
2011.25	Focus	2.0L	Gasoline_Direct_injection	IPM-B	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	PAM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	PCM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	PCM	√	√	√	√	0067, 00BC, 0115
2011.25	Focus	2.0L	Gasoline_Direct_injection	PCM	√	√	√	√	0067, 00BC, 0115, 0116
2011.25	Focus	2.0L	Gasoline_Direct_injection	PCM	√	√	√	√	0067, 00BC, 0115, 0117
2011.25	Focus	2.0L	Gasoline_Direct_injection	PDM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	PDM	√	√	√	√	0141
2011.25	Focus	2.0L	Gasoline_Direct_injection	PSCM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	PSCM	√	√	√	√	00DC, 00DF, 00E0, 00E1
2011.25	Focus	2.0L	Gasoline_Direct_injection	PSCM	√	√	√	√	00DC, 00DF, 00E1
2011.25	Focus	2.0L	Gasoline_Direct_injection	RCM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	RCM	√	√	√	√	0102
2011.25	Focus	2.0L	Gasoline_Direct_injection	RFA	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	SASM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	SOD-L	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	SOD-R	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	SRM	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	TCM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	TCM	√	√	√	√	0117
2011.25	Focus	2.0L	Gasoline_Direct_injection	TRM	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	ABS	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	ABS	√	√	√	√	0012
2012	Focus	2.0L	Gasoline_Direct_injection	ACM	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	ACM	√	√	√	√	0005
2012	Focus	2.0L	Gasoline_Direct_injection	APIM	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	BCM#1	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	BCM#1	√	√	√	√	00D5, 0101
2012	Focus	2.0L	Gasoline_Direct_injection	DDM	√	√	√		
2012	Focus	2.0L	Gasoline_Direct_injection	DDM	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	DSP	√	√	√		

2012	Focus	2.0L	Gasoline_Direct_injection	FCDIM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	FCIM	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	GPSM	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	HVAC	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	IPC	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	IPM-B	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	OCSM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	OCSM	✓	✓	✓	✓	000C
2012	Focus	2.0L	Gasoline_Direct_injection	PAM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	PCM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	PCM	✓	✓	✓	✓	0025, 0067, 0095
2012	Focus	2.0L	Gasoline_Direct_injection	PCM	✓	✓	✓	✓	0067, 0095
2012	Focus	2.0L	Gasoline_Direct_injection	PDM	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	PDM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	PSCM	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	PSCM	✓	✓	✓		00CB, 00CC
2012	Focus	2.0L	Gasoline_Direct_injection	PSCM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2012	Focus	2.0L	Gasoline_Direct_injection	RCM	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	RCM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	RFA	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	RFA	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	SASM	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	SASM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	TCM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	TCM	✓	✓	✓	✓	0117, 0158
2012	Focus	23kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	0012
2012	Focus	23kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	0012, 010A
2012	Focus	23kWh	Battery Electric Vehicle	ACC#2	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	ACM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	APIM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	BCCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	BCM#1	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	BCM#1	✓	✓	✓	✓	0101
2012	Focus	23kWh	Battery Electric Vehicle	BECM	✓	✓	✓		
2012	Focus	23kWh	Battery Electric Vehicle	BECM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	DCDC	✓	✓	✓		
2012	Focus	23kWh	Battery Electric Vehicle	DCDC	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	DDM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	DDM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	DSP	✓	✓	✓		
2012	Focus	23kWh	Battery Electric Vehicle	DSP	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	FCDIM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	FCIM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	GFM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	GPSM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	GWM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	HCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	HVAC	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	IPC	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	IPM-B	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	OCSM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2012	Focus	23kWh	Battery Electric Vehicle	PAM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	PCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	PCM	✓	✓	✓	✓	0095
2012	Focus	23kWh	Battery Electric Vehicle	PDM	✓	✓	✓		
2012	Focus	23kWh	Battery Electric Vehicle	PDM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	PSCM	✓	✓	✓		
2012	Focus	23kWh	Battery Electric Vehicle	PSCM	✓	✓	✓		00CB, 00CC
2012	Focus	23kWh	Battery Electric Vehicle	PSCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	RCM	✓	✓	✓		

2012	Focus	23kWh	Battery Electric Vehicl	RCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	RFA	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	RFA	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	SASM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	SASM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	SOBDM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	SOBDM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	TCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	TCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	TCU#1	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	TCU#1	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D5, 0101
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ICM#1	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0095
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	ABS	✓	✓	✓	✓	0012
2013	Focus	2.0L	Gasoline_Direct_injection	ACM	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	APIM	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	BCM#1	✓	✓	✓	✓	00D5, 0101
2013	Focus	2.0L	Gasoline_Direct_injection	DDM	✓	✓	✓	✓	

2013	Focus	2.0L	Gasoline_Direct_injection	DSP	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	FCDIM	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	FCIM	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	GPSM	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	HVAC	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	IPC	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	IPM-B	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	OCSM	✓	✓	✓	✓	000C
2013	Focus	2.0L	Gasoline_Direct_injection	PAM	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	PCM	✓	✓	✓	✓	0025
2013	Focus	2.0L	Gasoline_Direct_injection	PDM	✓	✓	✓		
2013	Focus	2.0L	Gasoline_Direct_injection	PSCM	✓	✓	✓		00CB, 00CC
2013	Focus	2.0L	Gasoline_Direct_injection	RCM	✓	✓	✓		
2013	Focus	2.0L	Gasoline_Direct_injection	RFA	✓	✓	✓		
2013	Focus	2.0L	Gasoline_Direct_injection	SASM	✓	✓	✓		
2013	Focus	2.0L	Gasoline_Direct_injection	TCM	✓	✓	✓	✓	0117, 0158
2013	Focus	23kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	0012, 010A
2013	Focus	23kWh	Battery Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	ACM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	APIM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	BCM#1	✓	✓	✓	✓	00D5, 0101
2013	Focus	23kWh	Battery Electric Vehicle	BCMii	✓	✓	✓	✓	0101
2013	Focus	23kWh	Battery Electric Vehicle	BECM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	DCDC	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	DDM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	DDM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	DSP	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	FCDIM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	FCIM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	GFM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	GPSM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	GWM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	HCM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	HVAC	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	IPC	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	IPM-B	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2013	Focus	23kWh	Battery Electric Vehicle	PAM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	PCM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	PDM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	PDM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	Focus	23kWh	Battery Electric Vehicle	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	Focus	23kWh	Battery Electric Vehicle	RCM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	RCM	✓	✓	✓	✓	00EF
2013	Focus	23kWh	Battery Electric Vehicle	RFA	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	RFA	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	SASM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	SASM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	SOBDM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	TCM	✓	✓	✓	✓	
2013	Focus	23kWh	Battery Electric Vehicle	TCU#1	✓	✓	✓	✓	
2013	Focus	Other	Other	ABS	✓	✓	✓	✓	
2013	Focus	Other	Other	ACM	✓	✓	✓	✓	
2013	Focus	Other	Other	APIM	✓	✓	✓	✓	
2013	Focus	Other	Other	BCM#1	✓	✓	✓	✓	
2013	Focus	Other	Other	BCM#1	✓	✓	✓	✓	00D5, 0101
2013	Focus	Other	Other	DDM	✓	✓	✓	✓	
2013	Focus	Other	Other	DSP	✓	✓	✓	✓	
2013	Focus	Other	Other	FCDIM	✓	✓	✓	✓	
2013	Focus	Other	Other	FCIM	✓	✓	✓	✓	
2013	Focus	Other	Other	GPSM	✓	✓	✓	✓	
2013	Focus	Other	Other	HVAC	✓	✓	✓	✓	
2013	Focus	Other	Other	IPC	✓	✓	✓	✓	
2013	Focus	Other	Other	IPM-B	✓	✓	✓	✓	
2013	Focus	Other	Other	OCSM	✓	✓	✓	✓	
2013	Focus	Other	Other	PAM	✓	✓	✓	✓	
2013	Focus	Other	Other	PDM	✓	✓	✓	✓	
2013	Focus	Other	Other	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	Focus	Other	Other	RCM	✓	✓	✓	✓	
2013	Focus	Other	Other	RFA	✓	✓	✓	✓	
2013	Focus	Other	Other	SASM	✓	✓	✓	✓	

2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	√	√	√	√	0012
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	√	√	√		
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	√	√	√		
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	√	√	√	√	00D5, 0101
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	√	√	√		
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	√	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	√	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	√	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	√	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	√	√	√		
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	√	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ICM#1	√	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	√	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B	√	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	√	√	√	√	000C
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	√	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	√	√	√	√	0025
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	√	√	√		
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	√	√	√		00CB, 00CC
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	√	√	√		
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	√	√	√		
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM	√	√	√		
2014	Focus	2.0L	Gasoline_Direct_injection	ABS	√	√	√	√	0012
2014	Focus	2.0L	Gasoline_Direct_injection	ACM	√	√	√		
2014	Focus	2.0L	Gasoline_Direct_injection	APIM	√	√	√		
2014	Focus	2.0L	Gasoline_Direct_injection	BCM#1	√	√	√	√	00D5, 0101
2014	Focus	2.0L	Gasoline_Direct_injection	DDM	√	√	√		
2014	Focus	2.0L	Gasoline_Direct_injection	DSP	√	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	FCDIM	√	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	FCIM	√	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	GPSM	√	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	HVAC	√	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	IPC	√	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	IPM-B	√	√	√	√	

2014	Focus	2.0L	Gasoline_Direct_injection	OCSM	✓	✓	✓	✓	000C
2014	Focus	2.0L	Gasoline_Direct_injection	PAM	✓	✓	✓	✓	
2014	Focus	2.0L	Gasoline_Direct_injection	PCM	✓	✓	✓	✓	0025
2014	Focus	2.0L	Gasoline_Direct_injection	PDM	✓	✓	✓		
2014	Focus	2.0L	Gasoline_Direct_injection	PSCM	✓	✓	✓		00CB, 00CC
2014	Focus	2.0L	Gasoline_Direct_injection	RCM	✓	✓	✓		
2014	Focus	2.0L	Gasoline_Direct_injection	RFA	✓	✓	✓		
2014	Focus	2.0L	Gasoline_Direct_injection	SASM	✓	✓	✓		
2014	Focus	2.0L	Gasoline_Direct_injection	TCM	✓	✓	✓	✓	0117, 0158
2014	Focus	23kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	0012, 010A
2014	Focus	23kWh	Battery Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	ACM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	APIM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	BCM#1	✓	✓	✓	✓	00D5, 0101
2014	Focus	23kWh	Battery Electric Vehicle	BECM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	DCDC	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	DDM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	DSP	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	FCDIM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	FCIM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	GFM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	GPSM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	GWM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	HCM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	HVAC	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	IPC	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	IPM-B	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2014	Focus	23kWh	Battery Electric Vehicle	PAM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	PCM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	PDM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Focus	23kWh	Battery Electric Vehicle	RCM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	RFA	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	SASM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	SOBDM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	TCM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	TCU#1	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DA	FACM	6E	0x0007A120	✓	✓	✓
2002.75	Focus C-MAX	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2002.75	Focus C-MAX	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	CDP	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	EATC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	EPB	✓	✓	✓	✓	001F
2002.75	Focus C-MAX	1.4L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	1.4L	DURATEC 16V	GDM	✓	✓	✓	✓	0100
2002.75	Focus C-MAX	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	NAV	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	PAM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002.75	Focus C-MAX	1.4L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	RETM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	RKE	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	RL DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	RR DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC 16V	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2002.75	Focus C-MAX	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	DURATEC 16V	CDP	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	DURATEC 16V	EPB	✓	✓	✓	✓	001F
2002.75	Focus C-MAX	1.6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	1.6L	DURATEC 16V	GDM	✓	✓	✓	✓	0005, 0100
2002.75	Focus C-MAX	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2002.75	Focus C-MAX	1.6L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC 16V	NAV	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005

2002.75	Focus C-MAX	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002.75	Focus C-MAX	1.6L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	F027, F031
2002.75	Focus C-MAX	1.6L	DURATEC 16V	RETM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	DURATEC 16V	RL DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC 16V	RR DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2002.75	Focus C-MAX	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB
2002.75	Focus C-MAX	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	D DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	EATC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	EPB	✓	✓	✓	✓	001F
2002.75	Focus C-MAX	1.6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	1.6L	DURATEC VCT	GDM	✓	✓	✓	✓	0100
2002.75	Focus C-MAX	1.6L	DURATEC VCT	GEM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	1.6L	DURATEC VCT	IC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	NAV	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	0025
2002.75	Focus C-MAX	1.6L	DURATEC VCT	P DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	RETM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	RL DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	RR DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00E8
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	001F
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	0005, 006B, 0094, 00A1
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002F
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0005, 0100
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	

2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0096, 0097, 0098, 0099, 009A
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0096, 0097, 0098, 0099, 009A, 020A
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	F027, F031
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F038, F039
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	EPB	✓	✓	✓	✓	001F
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002F
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F027, F031
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RL_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RR_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	001F
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	



2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 00B4
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	EPB	✓	✓	✓	✓	001F
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02A, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F027, F031
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RL_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RR_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0070, 00C5
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	0005, F026
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	0005, 001F, F0B8
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	0005, 006B, 0094, 00A1
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0005, 0100
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F01E, F020, F028, F032, F03E
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	0005, F026

2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	F027, F031
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	F026
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	F026
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F039, F03F
2007.5	Focus C-MAX	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8
2007.5	Focus C-MAX	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	011A
2007.5	Focus C-MAX	1.4L	DURATEC 16V	CDP	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.4L	DURATEC 16V	EPB	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	1.4L	DURATEC 16V	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	RETM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8
2007.5	Focus C-MAX	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	011A
2007.5	Focus C-MAX	1.6L	DURATEC 16V	CDP	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC 16V	EPB	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	1.6L	DURATEC 16V	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	RETM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2007.5	Focus C-MAX	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC VCT	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	EATC	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC VCT	EPB	✓	✓	✓	✓	001F
2007.5	Focus C-MAX	1.6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	1.6L	DURATEC VCT	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	1.6L	DURATEC VCT	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	1.6L	DURATEC VCT	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	RETM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	001F
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1

2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0096, 0097, 0098, 0099, 009A, 020A
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	EPB	✓	✓	✓	✓	001F
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	001F
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002F
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 00B4
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005

2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	EPB	✓	✓	✓	✓	001F
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	001F
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0098, 0099, 00AB
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus C-MAX	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC 16V	CDP	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC 16V	CMR	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC 16V	D_DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC 16V	EPS	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus C-MAX	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus C-MAX	1.6L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus C-MAX	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F03E
2008.25	Focus C-MAX	1.6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025

2008.25	Focus C-MAX	1.6L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus C-MAX	1.6L	DURATEC 16V	RETM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	0070, 00C5
2008.25	Focus C-MAX	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008.25	Focus C-MAX	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC VCT	CMR	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC VCT	D DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC VCT	EATC	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC VCT	EPS	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus C-MAX	1.6L	DURATEC VCT	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus C-MAX	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus C-MAX	1.6L	DURATEC VCT	IC	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC VCT	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008.25	Focus C-MAX	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC VCT	P DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus C-MAX	1.6L	DURATEC VCT	RETM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, 00EA, F027, F031
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002F
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F03E
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 00B4
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC

2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F031, F032, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F03E
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F01E, F028, F032, F03E
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 00AB
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EA
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	

2008. 25	Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	00FB, 0140
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	00FC, 0141
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0102
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	00FD, 013D
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	F026
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	F026
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	ABS	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8
2011	Focus C-MAX	1. 6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	AHCM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	AHCM	✓	✓	✓	✓	00CF
2011	Focus C-MAX	1. 6L	DURATEC VCT	APIM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	BCMii	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	DDM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	DDM	✓	✓	✓	✓	00FB, 0140
2011	Focus C-MAX	1. 6L	DURATEC VCT	FCDIM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	FDSM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	HCM	✓	✓	✓	✓	

2011	Focus C-MAX	1.6L	DURATEC VCT	HCM	✓	✓	✓		0032
2011	Focus C-MAX	1.6L	DURATEC VCT	HVAC	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	F020
2011	Focus C-MAX	1.6L	DURATEC VCT	IPM-A	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	IPM-A	✓	✓	✓	✓	00E5
2011	Focus C-MAX	1.6L	DURATEC VCT	IPM-B	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	PCM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	00BC, 0116, 0117
2011	Focus C-MAX	1.6L	DURATEC VCT	PDM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	00FC, 0141
2011	Focus C-MAX	1.6L	DURATEC VCT	PSCM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011	Focus C-MAX	1.6L	DURATEC VCT	RCM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	0102
2011	Focus C-MAX	1.6L	DURATEC VCT	RFA	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	RGTM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	RGTM	✓	✓	✓	✓	00FD, 013D
2011	Focus C-MAX	1.6L	DURATEC VCT	SASM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	SASM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	SOD-L	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	SOD-L	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	SOD-R	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	SOD-R	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	SRM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	TRM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	TRM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓		002B, 002C, 0053, 00D9, 00DB, 00E8
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓		00CF
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	00FB, 0140
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FDSM	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓		0032
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-B	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00B1, 00B3, 00B9, 00BC, 00BD, 00C1, 00C3, 00E7
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	00FC, 0141
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0102
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	



2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	00FD, 013D
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓		
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓		00CF
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓		
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	00FB, 0140
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓		
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓		
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓		0032
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓		
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	00FC, 0141
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0102
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	00FD, 013D
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	F026
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	F026
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓		

2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓		00CF
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	00FB, 0140
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FDSM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓		0032
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPM-B	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1, 00E7, 0116, 013B
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	00FC, 0141
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0102
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	00FD, 013D
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓		F026
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓		F026
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓		

2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	CDP	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	D_DCU	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	FTCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	GDM	✓	✓	✓	✓	0005, 0100
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	NAV	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	FTCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02A, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0070
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	0005, 006B, 0094, 00A1
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	FTCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0005, 0100
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	

2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F01E, F020, F028, F032, F03E
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	CDP	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	EPS	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	FTCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 002A, 002C, 0030, 00DD, 00DE, 00E8
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	D DCU	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	EATC	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	EPS	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	FTCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	IC	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	P_DCU	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	FTCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	

2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F031, F032, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	F020
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	ABS	✓	✓	✓	✓	0012, 0029, 002A, 002C, 0054
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	ABS	✓	✓	✓	✓	0012, 0029, 002A, 002C, 0054
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	D DCU	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	EATC	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	GEM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	HCM	✓	✓	✓	✓	0155, 0156
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	IC	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	PAM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	PCM	✓	✓	✓	✓	00C5
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	P DCU	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	RCM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	RL DCU	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	RR DCU	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0012, 0029, 002A, 002C, 0054
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0012, 0029, 002A, 002C, 0054
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F029, F032, F03E, F03F, F040
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F027, F031
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	RL DCU	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	RR DCU	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0012, 0029, 002A, 002C, 0054
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0012, 0029, 002A, 002C, 0054
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	0005, F026
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02A, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0005, 0155, 0156
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F029, F032, F03E, F03F, F040
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	0005, F026
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F027, F031
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	RL DCU	✓	✓	✓	✓	0005, F026
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	RR DCU	✓	✓	✓	✓	0005, F026
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0012, 0029, 002A, 0054





2007	Freestyle	3.0L	4V	ABS	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	ABS	✓	✓	✓	✓	0008
2007	Freestyle	3.0L	4V	ACM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Freestyle	3.0L	4V	DSM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	EATC	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	GEM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	IC	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	PAM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	PAM	✓	✓	✓	✓	006C
2007	Freestyle	3.0L	4V	PCM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	PCM	✓	✓	✓	✓	0025, 00C5
2007	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓	000C
2007	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓	000C, 006D
2007	Freestyle	3.0L	4V	RETM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	SDARS	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	SDARS	✓	✓	✓	✓	0019
2007	Freestyle	3.0L	4V	TCM	✓	✓	✓	✓	
2002	Fusion	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fusion	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3
2002	Fusion	1.25L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F020
2002	Fusion	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fusion	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fusion	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0012
2002	Fusion	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3
2002	Fusion	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F020
2002	Fusion	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fusion	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	003F
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0012
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2002	Fusion	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2002	Fusion	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fusion	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002	Fusion	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2002	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2002	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025, 0070
2002	Fusion	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fusion	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2002	Fusion	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	0070
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0096, 0097, 0099, 009A, 00AD, 00AE
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fusion	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fusion	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓	
2006	Fusion	1.25L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fusion	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fusion	1.25L	DURATEC 16V	IC	✓	✓	✓	✓	
2006	Fusion	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fusion	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fusion	1.25L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fusion	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fusion	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2006	Fusion	1.4L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fusion	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fusion	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2006	Fusion	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fusion	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	



2006	Fusion	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fusion	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	003F
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F02D, F030, FOA2, FOB3, FOB6, FOB7
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F020, F063, FOB5
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F020, F063, FOB5, FOB7
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2006	Fusion	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fusion	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2006	Fusion	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fusion	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	F02D, F030, FOA2, FOB3, FOB6, FOB7
2006	Fusion	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	F020, F063, FOB5
2006	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025, 0070
2006	Fusion	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fusion	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fusion	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0096, 0097, 0099, 009A, 00AD, 00AE
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2006	Fusion	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2006	Fusion	2.3L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	F044, F048, F04C, F057, F085
2006	Fusion	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2006	Fusion	2.3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2006	Fusion	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	Fusion	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2006	Fusion	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2006	Fusion	2.3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2006	Fusion	2.3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	ABS	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	ABS	✓	✓	✓	✓	0008
2006	Fusion	3.0L	4V	ACM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2006	Fusion	3.0L	4V	EATC	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	GEM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	IC	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	OCSM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2006	Fusion	3.0L	4V	PCM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2006	Fusion	3.0L	4V	RCM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	TBM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2006	Fusion	3.0L	4V	TCM	✓	✓	✓	✓	
2007	Fusion	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2007	Fusion	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2007	Fusion	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008

2007	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0016, 0017, 0018, F05A
2007	Fusion	2. 3L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	F044, F048, F04C, F057, F085
2007	Fusion	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005
2007	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2007	Fusion	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Fusion	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	0019
2007	Fusion	2. 3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2007	Fusion	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	4X4	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	ABS	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2007	Fusion	3. 0L	4V	ACM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Fusion	3. 0L	4V	EATC	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	GEM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	IC	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	IC	✓	✓	✓	✓	0005
2007	Fusion	3. 0L	4V	OCSM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2007	Fusion	3. 0L	4V	PCM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2007	Fusion	3. 0L	4V	RCM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	RCM	✓	✓	✓	✓	0005
2007	Fusion	3. 0L	4V	SDARS	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	SDARS	✓	✓	✓	✓	0019
2007	Fusion	3. 0L	4V	TBM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2007	Fusion	3. 0L	4V	TCM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2008	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0016, 0017, 0018, F05A, F062, F07A
2008	Fusion	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2008	Fusion	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2008	Fusion	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F044, F048, F04C, F057, F085, F086
2008	Fusion	2. 3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	F027
2008	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2008	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Fusion	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2008	Fusion	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	F022, F05D
2008	Fusion	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2008	Fusion	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	4X4	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	ABS	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2008	Fusion	3. 0L	4V	ACM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Fusion	3. 0L	4V	APIM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Fusion	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2008	Fusion	3. 0L	4V	HVAC	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	IC	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	OCSM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2008	Fusion	3. 0L	4V	PAM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	PCM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2008	Fusion	3. 0L	4V	RCM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	SDARS	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	TBM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3

2008	Fusion	3. 0L	4V	TCM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2009	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F05A, F062, F07A
2009	Fusion	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2009	Fusion	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0005, 0042, F044, F048, F04C, F057, F085, F086
2009	Fusion	2. 3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F027
2009	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Fusion	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2009	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2009	Fusion	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Fusion	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	0005
2009	Fusion	2. 3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	Fusion	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	4X4	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	ABS	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2009	Fusion	3. 0L	4V	ACM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Fusion	3. 0L	4V	APIM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Fusion	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Fusion	3. 0L	4V	HVAC	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	IC	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	OCSM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2009	Fusion	3. 0L	4V	PAM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	PCM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2009	Fusion	3. 0L	4V	RCM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	SDARS	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	TBM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	Fusion	3. 0L	4V	TCM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Fusion	2. 5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2010	Fusion	2. 5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	Fusion	2. 5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2010	Fusion	2. 5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2010	Fusion	2. 5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	0005
2010	Fusion	2. 5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	0005, F062
2010	Fusion	2. 5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2010	Fusion	2. 5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C
2010	Fusion	2. 5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	0005
2010	Fusion	2. 5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Fusion	2. 5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2010	Fusion	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	Fusion	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2010	Fusion	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0067
2010	Fusion	2. 5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	0005
2010	Fusion	2. 5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005
2010	Fusion	2. 5L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Fusion	2. 5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2010	Fusion	2. 5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2010	Fusion	2. 5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2010	Fusion	2. 5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	Fusion	2. 5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Fusion	2. 5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Fusion	2. 5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	

2010	Fusion	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓		
2010	Fusion	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓		0005
2010	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓		
2010	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	0005
2010	Fusion	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Fusion	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	Fusion	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	0005
2010	Fusion	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Fusion	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2010	Fusion	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	0005
2010	Fusion	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	0005
2010	Fusion	2.5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Fusion	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	4X4	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	ABS	✓	✓	✓	✓	0008, 0012
2010	Fusion	3.0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Fusion	3.0L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Fusion	3.0L	4V	DSP	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	FDIM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Fusion	3.0L	4V	GPSM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	HVAC	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	IPC	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	Fusion	3.0L	4V	PAM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	PCM	✓	✓	✓	✓	0067
2010	Fusion	3.0L	4V	PSCM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	RCM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	SOD-L	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	SOD-R	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Fusion	3.5L	4V	4X4	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2010	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	0018
2010	Fusion	3.5L	4V	APIM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Fusion	3.5L	4V	DSP	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	FDIM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	FDIM	✓	✓	✓	✓	0005, F062
2010	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C, F08A
2010	Fusion	3.5L	4V	GPSM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	HVAC	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	IPC	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Fusion	3.5L	4V	PAM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	PAM	✓	✓	✓	✓	0005
2010	Fusion	3.5L	4V	PCM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037
2010	Fusion	3.5L	4V	PSCM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	RCM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	RCM	✓	✓	✓	✓	0005
2010	Fusion	3.5L	4V	SOD-L	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	SOD-R	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	TBM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Fusion	3.5L	4V	TCM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2011	Fusion	2.5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2011	Fusion	2.5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019
2011	Fusion	2.5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2011	Fusion	2.5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	

2011	Fusion	2.5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2011	Fusion	2.5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2011	Fusion	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0067
2011	Fusion	2.5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Fusion	2.5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Fusion	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0018
2011	Fusion	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019
2011	Fusion	2.5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Fusion	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Fusion	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Fusion	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2011	Fusion	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Fusion	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	4X4	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	ABS	✓	✓	✓	✓	0008, 0012
2011	Fusion	3.0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Fusion	3.0L	4V	APIM	✓	✓	✓	✓	0019
2011	Fusion	3.0L	4V	DSP	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	FDIM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Fusion	3.0L	4V	GPSM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	HVAC	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	IPC	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Fusion	3.0L	4V	PAM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	PCM	✓	✓	✓	✓	0067
2011	Fusion	3.0L	4V	PSCM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	RCM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	SOD-L	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	SOD-R	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Fusion	3.5L	4V	4X4	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2011	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Fusion	3.5L	4V	APIM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	APIM	✓	✓	✓	✓	0019
2011	Fusion	3.5L	4V	DSP	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	FDIM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Fusion	3.5L	4V	GPSM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	HVAC	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	IPC	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Fusion	3.5L	4V	PAM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	PCM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037
2011	Fusion	3.5L	4V	PSCM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	RCM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	SOD-L	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	SOD-R	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	TBM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Fusion	3.5L	4V	TCM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2012	Fusion	2.5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	

2012	Fusion	2.5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2012	Fusion	2.5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019
2012	Fusion	2.5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2012	Fusion	2.5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C
2012	Fusion	2.5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2012	Fusion	2.5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0067
2012	Fusion	2.5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Fusion	2.5L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D3
2012	Fusion	2.5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2012	Fusion	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0018
2012	Fusion	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019
2012	Fusion	2.5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Fusion	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	Fusion	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2012	Fusion	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2012	Fusion	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Fusion	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	4X4	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	ABS	✓	✓	✓	✓	0008, 0012
2012	Fusion	3.0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2012	Fusion	3.0L	4V	APIM	✓	✓	✓	✓	0019
2012	Fusion	3.0L	4V	DSP	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	FDIM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Fusion	3.0L	4V	GPSM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	HVAC	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	IPC	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	Fusion	3.0L	4V	PAM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	PCM	✓	✓	✓	✓	0067
2012	Fusion	3.0L	4V	PSCM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	RCM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	SOD-L	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	SOD-R	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Fusion	3.5L	4V	4X4	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2012	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2012	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	0018
2012	Fusion	3.5L	4V	APIM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	APIM	✓	✓	✓	✓	0019
2012	Fusion	3.5L	4V	DSP	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	FDIM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Fusion	3.5L	4V	GPSM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	HVAC	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	IPC	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	Fusion	3.5L	4V	PAM	✓	✓	✓	✓	

2012	Fusion	3.5L	4V	PCM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037
2012	Fusion	3.5L	4V	PSCM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	RCM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	SOD-L	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	SOD-R	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	TBM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Fusion	3.5L	4V	TCM	✓	✓	✓	✓	
2012	Fusion	Other	Other	4X4	✓	✓	✓	✓	
2012	Fusion	Other	Other	ABS	✓	✓	✓	✓	
2012	Fusion	Other	Other	ACM	✓	✓	✓	✓	
2012	Fusion	Other	Other	APIM	✓	✓	✓	✓	
2012	Fusion	Other	Other	DSP	✓	✓	✓	✓	
2012	Fusion	Other	Other	FCIM	✓	✓	✓	✓	
2012	Fusion	Other	Other	FCIM	✓	✓	✓	✓	
2012	Fusion	Other	Other	FDIM	✓	✓	✓	✓	
2012	Fusion	Other	Other	GEM / SJB	✓	✓	✓	✓	0042
2012	Fusion	Other	Other	GPSM	✓	✓	✓	✓	
2012	Fusion	Other	Other	HVAC	✓	✓	✓	✓	
2012	Fusion	Other	Other	IPC	✓	✓	✓	✓	
2012	Fusion	Other	Other	OCSM	✓	✓	✓	✓	
2012	Fusion	Other	Other	PAM	✓	✓	✓	✓	
2012	Fusion	Other	Other	PSCM	✓	✓	✓	✓	
2012	Fusion	Other	Other	RCM	✓	✓	✓	✓	
2012	Fusion	Other	Other	SOD-L	✓	✓	✓	✓	
2012	Fusion	Other	Other	SOD-R	✓	✓	✓	✓	
2012	Fusion	Other	Other	TBM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DCDC	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E

2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0108
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067, 0108
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SCM-G	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SCM-H	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓		✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓		0008, 0012, 00F5, 010A, 020C
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓		
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓		
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓		00D4, 00D5, 00FE, 0112
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓		00D4, 00D5, 0112
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓		0046
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046



2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓		
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓		
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓		
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓		
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0108
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0108
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	

2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-G	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-H	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	ABS	✓	✓	✓	✓	0012, 00F5, 010A, 020C
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	ACM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	APIM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	BECM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	C-CM	✓	✓	✓	✓	0046
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DACM-C	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DCDC	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DDM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DSM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DSP	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	FCDIM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	FCIM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	GPSM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	GWM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	HUD	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	IPC	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	IPM-A	✓	✓	✓	✓	013E
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	PAM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	PDM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	PSCM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	RACM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	RCM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	RTM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SCCM	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SCM-E	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	✓	✓	✓	✓	013C
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SOD-L	✓	✓	✓	✓	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SOD-R	✓	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE
2013	Fusion	2.0L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	C-CM	✓	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	DACM-C	✓	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	DDM	✓	✓	✓	✓	

2013	Fusion	2. 0L	HEV / ATKINSON 4V	DSM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	FCDIM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	GFM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	GWM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	HCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	HSWM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	HUD	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	IPM-A	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0108
2013	Fusion	2. 0L	HEV / ATKINSON 4V	PDM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	RACM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	RGTM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	RTM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SCCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SCM-E	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SCM-G	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SCM-H	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SOBDM-C	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	VDM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	ABS	✓	✓	✓	✓	00F5, 010A, 020C
2013	Fusion	2. 0L	PHEV	ABS	✓	✓	✓	✓	0012, 00F5, 010A, 020C
2013	Fusion	2. 0L	PHEV	ACCM#2	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	ACCM#2	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	ACM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	ACM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	APIM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	APIM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	Fusion	2. 0L	PHEV	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	Fusion	2. 0L	PHEV	BECM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	C-CM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	C-CM	✓	✓	✓	✓	0046
2013	Fusion	2. 0L	PHEV	DACM-C	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	DCDC	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	DDM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	DSM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	DSP	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	FCDIM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	FCIM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	GFM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	GPSM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	GWM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	HCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	HSWM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	HUD	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	HUD	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	IPC	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	IPM-A	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	IPM-A	✓	✓	✓	✓	013E
2013	Fusion	2. 0L	PHEV	OCSM	✓	✓	✓	✓	000C
2013	Fusion	2. 0L	PHEV	PAM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2013	Fusion	2. 0L	PHEV	PDM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	PSCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	RACM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	RCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	RGTM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	RTM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SCCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SCM-E	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SCM-G	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SCM-H	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SOBDM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SOBDM-C	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SOBDM-C	✓	✓	✓	✓	013C
2013	Fusion	2. 0L	PHEV	SOD-L	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SOD-R	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	TCLU#1	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	VDM	✓	✓	✓	✓	
2013	Fusion	2. 5L	IVCT	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2013	Fusion	2. 5L	IVCT	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2013	Fusion	2. 5L	IVCT	ACM	✓	✓	✓	✓	
2013	Fusion	2. 5L	IVCT	ACM	✓	✓	✓	✓	
2013	Fusion	2. 5L	IVCT	APIM	✓	✓	✓	✓	
2013	Fusion	2. 5L	IVCT	APIM	✓	✓	✓	✓	
2013	Fusion	2. 5L	IVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 0112

2013	Fusion	2.5L	IVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	Fusion	2.5L	IVCT	C-CM	✓	✓	✓	✓	0046
2013	Fusion	2.5L	IVCT	C-CM	✓	✓	✓	✓	0046
2013	Fusion	2.5L	IVCT	DACM-C	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	DACM-C	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	DDM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	DDM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	DSM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	DSP	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	FCDIM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	FCIM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	GFM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	GPSM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	GWM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	HCM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	HSWM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	HUD	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	HUD	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	IPC	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	IPM-A	✓	✓	✓	✓	013E
2013	Fusion	2.5L	IVCT	OCSM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	OCSM	✓	✓	✓	✓	000C
2013	Fusion	2.5L	IVCT	PAM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0108
2013	Fusion	2.5L	IVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2013	Fusion	2.5L	IVCT	PDM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	PSCM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	RACM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	RCM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	RGTM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	RTM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	SCCM	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	SCM-E	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	SCM-G	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	SCM-H	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	SOD-L	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	SOD-R	✓	✓	✓	✓	
2013	Fusion	2.5L	IVCT	VDM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112, 020F
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DCDC	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	

2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0108
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112, 020F
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E

2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112, 020F
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	

2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	ABS	✓	✓	✓	✓	0012, 00F5, 010A, 020C
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	ACM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	APIM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112, 020F
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	BECM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	C-CM	✓	✓	✓	✓	0046
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DACM-C	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DCDC	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DDM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DSM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DSP	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	FCDIM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	FCIM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	GPSM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	GWM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	HUD	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	IPC	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	IPM-A	✓	✓	✓	✓	013E
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PAM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PCM	✓	✓	✓	✓	0025, 0108
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PDM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PSCM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	RACM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	RCM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	RTM	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SCCM	✓	✓	✓	✓	

2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SCM-E	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	✓	✓	✓	✓	013C
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SOD-L	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SOD-R	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	ABS	✓	✓	✓	✓	0012, 00F5, 010A, 020C
2014	Fusion	2.0L	PHEV	ACCM#2	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	ACM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	APIM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112, 020F
2014	Fusion	2.0L	PHEV	BECM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	C-CM	✓	✓	✓	✓	0046
2014	Fusion	2.0L	PHEV	DACM-C	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	DCDC	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	DDM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	DSM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	DSP	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	FCDIM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	FCIM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	GFM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	GPSM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	GWM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	HUD	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	IPC	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	IPM-A	✓	✓	✓	✓	013E
2014	Fusion	2.0L	PHEV	OCSM	✓	✓	✓	✓	000C
2014	Fusion	2.0L	PHEV	PAM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	PCM	✓	✓	✓	✓	0025, 0108
2014	Fusion	2.0L	PHEV	PDM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	PSCM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	RACM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	RCM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	RTM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	SCCM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	SCM-E	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	SOBDM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	SOBDM-C	✓	✓	✓	✓	013C
2014	Fusion	2.0L	PHEV	SOD-L	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	SOD-R	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	TCU#1	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2014	Fusion	2.5L	IVCT	ACM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	APIM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112, 020F
2014	Fusion	2.5L	IVCT	C-CM	✓	✓	✓	✓	0046
2014	Fusion	2.5L	IVCT	DACM-C	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	DDM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	DSM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	DSP	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	FCDIM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	FCIM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	GPSM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	GWM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	HUD	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	IPC	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	IPM-A	✓	✓	✓	✓	013E
2014	Fusion	2.5L	IVCT	OCSM	✓	✓	✓	✓	000C
2014	Fusion	2.5L	IVCT	PAM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Fusion	2.5L	IVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Fusion	2.5L	IVCT	PCM	✓	✓	✓	✓	0025, 0108
2014	Fusion	2.5L	IVCT	PDM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	PSCM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	RACM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	RCM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	RTM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	SCCM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	SCM-E	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	SOD-L	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	SOD-R	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	



2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0092, 0098, 0099, 009A, 00AB, 00AC, 00B4, 00C1, 020A
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0102
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	00CF
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	00AC
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0102
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RGTM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RHVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020

2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0092, 0098, 0099, 009A, 00AB, 00AC, 00B4, 00C1, 020A
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0102
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	0121, 0122, 0123, 0124, 0125
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00A5, 00AA, 00AF, 00B0, 00B1, 00B2, 00B8, 00B9, 00BB, 00C1
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	00CF

2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	F020
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RGTM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RHVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0121, 0122, 0123, 0124, 0125
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0121, 0123
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2006.5	GALAXY\S-Max	2.5L	15	ACM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	AHCM	✓	✓	✓	✓	00CF
2006.5	GALAXY\S-Max	2.5L	15	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2006.5	GALAXY\S-Max	2.5L	15	CCMii	✓	✓	✓	✓	00F9
2006.5	GALAXY\S-Max	2.5L	15	CDP	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	DDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	GDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	HCM	✓	✓	✓	✓	0032
2006.5	GALAXY\S-Max	2.5L	15	HVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	IPC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	NAV	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	PAM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2006.5	GALAXY\S-Max	2.5L	15	PCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	PDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	PSCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	RCM	✓	✓	✓	✓	0102
2006.5	GALAXY\S-Max	2.5L	15	RFA	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	RGTM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	RHVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	SASM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	SRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	TRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	15	VDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	DABM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8

2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00B1, 00B3, 00B7, 00B9, 00BC, 00BD, 00C1, 00C3
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	CDP	✓	✓	✓	✓	0005
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	CMR	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	DABM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	NAV	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	

2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	00CF
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	DABM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	DSM	✓	✓	✓	✓	00F2
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	IPM-A	✓	✓	✓	✓	00E5
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	00AC
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	DABM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	

2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0092, 0098, 0099, 009A, 00AB, 00AC, 00B4, 00C1, 020A
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	0121, 0122, 0123, 0124, 0125
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	00CF
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C, 0132
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	00F9
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	0005
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DABM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓	✓	00F2
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	

2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0032
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	F020
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-A	✓	✓	✓	✓	00E5
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	NAV	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1, 013B
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	009A
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	0102
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓	✓	F026

2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓		F026
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓		
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓		
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓		
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓		
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	011B, 011C
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	CDP	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	CMR	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DABM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	NAV	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	



2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF, 0102
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	DABM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00A5, 00AA, 00AF, 00B0, 00B1, 00B2, 00B8, 00B9, 00BB, 00C1
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	

2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	00CF
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	00CF
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C, 0132
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	00F9
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DABM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓	✓	00F2
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0032
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-A	✓	✓	✓	✓	00E5
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	NAV	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	

2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0092, 0099, 009A, 00B2, 00B8, 00BE
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	0102
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	00CF
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	DABM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	DSM	✓	✓	✓	✓	00F2
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	IPM-A	✓	✓	✓	✓	00E5
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0121, 0122, 0123, 0124, 0125
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	CCM	✓	✓	✓	✓	
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	CJB	✓	✓	✓	✓	
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	IC	✓	✓	✓	✓	
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓	



2001	Galaxy	1.9L	EDC 1.9	PAM	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	PATS	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	PCM	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	RADIO	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	RCC	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	RCM	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	RHID	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	RNS	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	TCM	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	ABS	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	CCM	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	CJB	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	IC	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	LHID	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	MFSW	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	PAM	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	PATS	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	PCM	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	RADIO	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	RCC	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	RCM	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	RHID	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	RNS	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	TCM	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	ABS	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	CCM	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	CJB	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	IC	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	PATS	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	PCM	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	RCM	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	TCM	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	ABS	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	CCM	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	CJB	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	IC	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	PATS	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	PCM	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	RCM	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	TCM	✓	✓	✓	✓	
1991 5	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓	
1991 5	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓	
1991 5	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓	
1991 5	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	
1991 5	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	0025
1991 5	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓	
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓	
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓	
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓	
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	0025
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓	
1995	Granada / Scorpio	2.0L	Other	ABS/TCS	✓	✓	✓	✓	
1995	Granada / Scorpio	2.0L	Other	GEM	✓	✓	✓	✓	
1995	Granada / Scorpio	2.0L	Other	PATS			✓	✓	
1995	Granada / Scorpio	2.0L	Other	PATS	✓	✓	✓	✓	
1995	Granada / Scorpio	2.0L	Other	PCM	✓	✓	✓	✓	0025
1995	Granada / Scorpio	2.0L	Other	RCM	✓	✓	✓	✓	
1995	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓	
1995	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓	
1995	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓	
1995	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	
1995	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	0025
1995	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	GEM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	PATS			✓	✓	
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	RCM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	GEM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	PATS			✓	✓	
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	PATS	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	PCM	✓	✓	✓	✓	0025
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	RCM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	0025
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓	
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓	
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	GEM	✓	✓	✓	✓	
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	PATS			✓	✓	
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	PATS	✓	✓	✓	✓	
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓	0025
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓	0025, 0025
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓	
1997	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	





2010	Grand Marquis	4. 6L	2V	ABS	✓	✓	✓	✓	0008
2010	Grand Marquis	4. 6L	2V	DDM	✓	✓	✓	✓	0042
2010	Grand Marquis	4. 6L	2V	HVAC	✓	✓	✓	✓	
2010	Grand Marquis	4. 6L	2V	IC	✓	✓	✓	✓	
2010	Grand Marquis	4. 6L	2V	LCM	✓	✓	✓	✓	
2010	Grand Marquis	4. 6L	2V	MC	✓	✓	✓	✓	
2010	Grand Marquis	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Grand Marquis	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2010	Grand Marquis	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2010	Grand Marquis	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2011	Grand Marquis	4. 6L	2V	ABS	✓	✓	✓	✓	0008
2011	Grand Marquis	4. 6L	2V	DDM	✓	✓	✓	✓	0042
2011	Grand Marquis	4. 6L	2V	HVAC	✓	✓	✓	✓	
2011	Grand Marquis	4. 6L	2V	IC	✓	✓	✓	✓	
2011	Grand Marquis	4. 6L	2V	LCM	✓	✓	✓	✓	
2011	Grand Marquis	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Grand Marquis	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2011	Grand Marquis	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
1999. 75	Ikon	1. 6L	Zetec Rocam	ECS	✓	✓	✓	✓	
1999. 75	Ikon	1. 6L	Zetec Rocam	HEC	✓	✓	✓	✓	
1999. 75	Ikon	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	
1999. 75	Ikon	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2000. 25	Ikon	1. 8L	Endura-DE	PCM			✓	✓	
2000. 5	Ikon	1. 3L	HCS	PCM	✓	✓	✓	✓	0025
2001	Ikon	1. 6L	Other	ECS	✓	✓	✓	✓	
2001	Ikon	1. 6L	Other	HEC	✓	✓	✓	✓	
2001	Ikon	1. 6L	Other	PCM	✓	✓	✓	✓	
2003	Ikon	1. 3L	Zetec Rocam	PCM	✓	✓	✓	✓	
2003	Ikon	1. 3L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2003	Ikon	1. 6L	Zetec Rocam	ECS	✓	✓	✓	✓	
2003	Ikon	1. 6L	Zetec Rocam	HEC	✓	✓	✓	✓	
2003	Ikon	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	
2003	Ikon	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2003. 25	Ikon	1. 3L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008
2003. 25	Ikon	1. 3L	Zetec Rocam	CSM	✓	✓	✓	✓	
2003. 25	Ikon	1. 3L	Zetec Rocam	ECS	✓	✓	✓	✓	
2003. 25	Ikon	1. 3L	Zetec Rocam	GEM	✓	✓	✓	✓	
2003. 25	Ikon	1. 3L	Zetec Rocam	PCM	✓	✓	✓	✓	
2003. 25	Ikon	1. 3L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2003. 25	Ikon	1. 6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2003. 25	Ikon	1. 6L	Zetec Rocam	CSM	✓	✓	✓	✓	
2003. 25	Ikon	1. 6L	Zetec Rocam	ECS	✓	✓	✓	✓	
2003. 25	Ikon	1. 6L	Zetec Rocam	GEM	✓	✓	✓	✓	
2003. 25	Ikon	1. 6L	Zetec Rocam	HEC	✓	✓	✓	✓	
2003. 25	Ikon	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	
2003. 25	Ikon	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2003. 25	Ikon	1. 6L	Zetec Rocam	TCM	✓	✓	✓	✓	
2009. 25	Ikon	1. 4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	0005
2009. 25	Ikon	1. 4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0025
2009	KA	1. 2L	DURATEC 8V	ABS	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	BCMii	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	CTMii	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	EATC	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	EPS	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	IPC	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	PAM	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	PCM	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	RCM	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	CTMii	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2009	KA	Other	Other	ABS	✓	✓	✓	✓	
2009	KA	Other	Other	BCMii	✓	✓	✓	✓	
2009	KA	Other	Other	CTMii	✓	✓	✓	✓	
2009	KA	Other	Other	EATC	✓	✓	✓	✓	
2009	KA	Other	Other	EPS	✓	✓	✓	✓	
2009	KA	Other	Other	IPC	✓	✓	✓	✓	
2009	KA	Other	Other	PAM	✓	✓	✓	✓	
2009	KA	Other	Other	PCM	✓	✓	✓	✓	
2009	KA	Other	Other	RCM	✓	✓	✓	✓	
1997	Ka	1. 3L	Endura-E	ABS/TCS	✓	✓	✓	✓	



1997	Ka	1.3L	Endura-E	CSM	✓	✓	✓		
1997	Ka	1.3L	Endura-E	PATS	✓	✓	✓		
1997	Ka	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1997.5	Ka	1.0L	HCS	ABS/TCS	✓	✓	✓	✓	
1997.5	Ka	1.0L	HCS	CSM	✓	✓	✓		
1997.5	Ka	1.0L	HCS	PATS	✓	✓	✓		
1997.5	Ka	1.0L	HCS	PCM	✓	✓	✓	✓	0025
1997.5	Ka	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1997.5	Ka	1.3L	Endura-E	GSM	✓	✓	✓		
1997.5	Ka	1.3L	Endura-E	PATS	✓	✓	✓		
1997.5	Ka	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1998.5	Ka	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1998.5	Ka	1.3L	Endura-E	CSM	✓	✓	✓		
1998.5	Ka	1.3L	Endura-E	PATS	✓	✓	✓		
1998.5	Ka	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1999	Ka	1.0L	HCS	ABS/TCS	✓	✓	✓	✓	
1999	Ka	1.0L	HCS	CSM	✓	✓	✓		
1999	Ka	1.0L	HCS	ECS	✓	✓	✓		
1999	Ka	1.0L	HCS	PCM	✓	✓	✓	✓	0025
1999	Ka	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1999	Ka	1.3L	Endura-E	CSM	✓	✓	✓		
1999	Ka	1.3L	Endura-E	ECS	✓	✓	✓		
1999	Ka	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1999.75	Ka	1.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
1999.75	Ka	1.0L	Zetec Rocam	CSM	✓	✓	✓		
1999.75	Ka	1.0L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2000	Ka	1.3L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	
2000	Ka	1.3L	DURATEC 8V	CSM	✓	✓	✓		
2000	Ka	1.3L	DURATEC 8V	ECS	✓	✓	✓		
2000	Ka	1.3L	DURATEC 8V	GEM	✓	✓	✓	✓	
2000	Ka	1.3L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2000	Ka	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
2000	Ka	1.3L	Endura-E	CSM	✓	✓	✓		
2000	Ka	1.3L	Endura-E	ECS	✓	✓	✓		
2000	Ka	1.3L	Endura-E	GEM	✓	✓	✓	✓	
2000	Ka	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
2000	Ka	1.6L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	
2000	Ka	1.6L	DURATEC 8V	CSM	✓	✓	✓		
2000	Ka	1.6L	DURATEC 8V	ECS	✓	✓	✓		
2000	Ka	1.6L	DURATEC 8V	GEM	✓	✓	✓	✓	
2000	Ka	1.6L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2001.5	Ka	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2001.5	Ka	1.6L	Zetec Rocam	CSM	✓	✓	✓		
2001.5	Ka	1.6L	Zetec Rocam	ECS	✓	✓	✓		
2001.5	Ka	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓		0005, 0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓		
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓		011A
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	AWD	✓	✓	✓	✓	0005
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	0005
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002F, 0090, 0092, 0098, 0099, 00AB, 00AC, 00B4, 00C1
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F025, F026, F02B, F02D, F02E, F02F, F030, F032, F034, F035, F03A, F03D
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 00AB, 00AC, 00B4, 00C1
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005

2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	011D
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0005, 0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓		
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓		0005, 011A
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓		011A
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	011A
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AWD	✓	✓	✓		0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AWD	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AWD	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓		
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	D_DCU	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	EATC	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	EPS	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	EPS	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	FFH	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	FFH	✓	✓	✓	✓	002D, 002F
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	FFH	✓	✓	✓	✓	002F
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	GEM	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	GEM	✓	✓	✓	✓	F025, F026, F02B, F02D, F02E, F02F, F030, F032, F034, F035, F03A
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	GEM	✓	✓	✓	✓	F025, F026, F02B, F02D, F02E, F02F, F030, F032, F034, F035, F03A, F03D
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0155, 0156
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IC	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IC	✓	✓	✓	✓	0005, F01E, F028, F032, F036, F03E
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	

2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1, 00E7, 013B
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	P_DCU	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EA
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EA, F027, F031
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RETM	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RETM	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RKE	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RKE	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	011D
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 0030, 00D9, 00DD, 00DE, 00E8
2008. 5	Kuga	2. 5L	15	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008. 5	Kuga	2. 5L	15	ACM	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	ACM	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	ACM	✓	✓	✓	✓	0005, 011A
2008. 5	Kuga	2. 5L	15	ACM	✓	✓	✓	✓	011A
2008. 5	Kuga	2. 5L	15	ACM	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	ACM	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	AWD	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	CMR	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	D DCU	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	EATC	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	EPS	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	FFH	✓	✓	✓	✓	002F
2008. 5	Kuga	2. 5L	15	GEM	✓	✓	✓	✓	0005, F025, F026, F02B, F02D, F02E, F02F, F030, F032, F034, F035, F03A, F03D
2008. 5	Kuga	2. 5L	15	HCM	✓	✓	✓	✓	0155, 0156
2008. 5	Kuga	2. 5L	15	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F031, F032, F036, F03E
2008. 5	Kuga	2. 5L	15	PAM	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	PCM	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	P_DCU	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	RCM	✓	✓	✓	✓	0005, 00EA, F027
2008. 5	Kuga	2. 5L	15	RETM	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	RKE	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	SRM	✓	✓	✓	✓	011D
2008. 5	Kuga	2. 5L	15	TCM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012, 00E8
2013. 25	Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017
2013. 25	Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2013. 25	Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013. 25	Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5, 0101

2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	0046
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	0140
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	0141
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	013D
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	ABS	✓	✓	✓	✓	0012, 00E8
2013. 25	Kuga	1. 6L	GTDI FGEC	ACM	✓	✓	✓	✓	0017
2013. 25	Kuga	1. 6L	GTDI FGEC	AHCM	✓	✓	✓	✓	00CF
2013. 25	Kuga	1. 6L	GTDI FGEC	APIM	✓	✓	✓	✓	0019
2013. 25	Kuga	1. 6L	GTDI FGEC	BCMii	✓	✓	✓	✓	00D5, 0101
2013. 25	Kuga	1. 6L	GTDI FGEC	CCMii	✓	✓	✓	✓	0046
2013. 25	Kuga	1. 6L	GTDI FGEC	DDM	✓	✓	✓	✓	0140
2013. 25	Kuga	1. 6L	GTDI FGEC	FCDIM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	FDSM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	GPSM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	HCM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	HVAC	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	IPC	✓	✓	✓	✓	F020
2013. 25	Kuga	1. 6L	GTDI FGEC	IPM-A	✓	✓	✓	✓	00E5
2013. 25	Kuga	1. 6L	GTDI FGEC	IPM-B	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	PAM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	PCM	✓	✓	✓	✓	00BC, 0108
2013. 25	Kuga	1. 6L	GTDI FGEC	PDM	✓	✓	✓	✓	0141
2013. 25	Kuga	1. 6L	GTDI FGEC	PSCM	✓	✓	✓	✓	00CB, 00CC
2013. 25	Kuga	1. 6L	GTDI FGEC	RCM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	RFA	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	RGTM	✓	✓	✓	✓	013D
2013. 25	Kuga	1. 6L	GTDI FGEC	SASM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	SOD-L	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	SOD-R	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	TRM	✓	✓	✓	✓	

2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0012, 00E8
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	0017
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	00CF
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	APTM	✓	✓	✓	✓	0019
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	00D5, 0101
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	0046
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	0140
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	FDSM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	GPSM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-A	✓	✓	✓	✓	00E5
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-B	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00B0, 00B1, 00B3, 00B8, 00B9, 00BC, 00BF, 00C1, 00E7, 0108, 0115, 013B
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	0141
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00CB, 00CC
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓	✓	013D
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓		0005, 0012, 00E8
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017

2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	0005, 00CF
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	0005, 00D5, 0101
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	0046
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	0005, 0140
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	0005, 00E5
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0108
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	0005, 0141
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	0005, 00CB, 00CC
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	0005, 013D
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	0005
1996	LASER / 323 / TIERRA	1. 3L	B3	ABS	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 3L	B3	PCM	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 5L	Z5	ABS	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 5L	Z5	PCM	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 6L	B6	ABS	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 6L	B6	PCM	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 8L	BP	ABS	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 8L	BP	PCM	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 3L	B3	ABS	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 3L	B3	PCM	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 5L	ZL	ABS	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 5L	ZL	PCM	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 6L	ZM	ABS	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 6L	ZM	PCM	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 8L	FP	ABS	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 8L	FP	PCM	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	2. 0L	RF	ABS	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	2. 0L	RF	PCM	✓	✓	✓	✓	

1998	LASER / 323 / TIERRA	2. 0L	RF-T	PCM	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 3L	B3	ABS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 3L	B3	ABS/TCS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 3L	B3	PCM	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 6L	ZM	ABS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 6L	ZM	ABS/TCS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 6L	ZM	PCM	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 8L	FP	ABS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 8L	FP	PCM	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	2. 0L	FS	ABS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	2. 0L	FS	ABS/TCS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	2. 0L	FS	PCM	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	2. 0L	RF-T	ABS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	2. 0L	RF-T	PCM	✓	✓	✓	✓	
2001	LASER / 323 / TIERRA	1. 3L	B3	ABS	✓	✓	✓	✓	
2001	LASER / 323 / TIERRA	1. 3L	B3	PCM	✓	✓	✓	✓	
2001	LASER / 323 / TIERRA	2. 0L	FS	ABS	✓	✓	✓	✓	
2001	LASER / 323 / TIERRA	2. 0L	FS	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 3L	B3	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 3L	B3	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 3L	Other	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 5L	Other	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 5L	Z5	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 5L	Z5	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 5L	ZL	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 5L	ZL	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 6L	B6	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 6L	B6	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 6L	Other	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 6L	ZM	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 6L	ZM	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 8L	BP	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 8L	BP	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 8L	FP	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 8L	FP	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 8L	Other	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	2. 0L	RF	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	2. 0L	RF	PCM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	LS	3. 0L	Other	ACM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	CPM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	DDM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	DSM	✓	✓	✓	✓	0011
2000	LS	3. 0L	Other	EATC	✓	✓	✓	✓	
2000	LS	3. 0L	Other	GEM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	HEC	✓	✓	✓	✓	
2000	LS	3. 0L	Other	MC	✓	✓	✓	✓	
2000	LS	3. 0L	Other	PCM	✓	✓	✓	✓	0025
2000	LS	3. 0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C7
2000	LS	3. 0L	Other	RCM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	REM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	RESCU	✓	✓	✓	✓	
2000	LS	3. 0L	Other	SCLM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	LS	3. 9L	Other	ACM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	CPM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	DDM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	DSM	✓	✓	✓	✓	0011
2000	LS	3. 9L	Other	EATC	✓	✓	✓	✓	
2000	LS	3. 9L	Other	GEM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	HEC	✓	✓	✓	✓	
2000	LS	3. 9L	Other	MC	✓	✓	✓	✓	
2000	LS	3. 9L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C7
2000	LS	3. 9L	Other	RCM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	REM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	RESCU	✓	✓	✓	✓	
2002	LS	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	LS	3. 0L	Other	ACM	✓	✓	✓	✓	
2002	LS	3. 0L	Other	CPM	✓	✓	✓	✓	
2002	LS	3. 0L	Other	DDM	✓	✓	✓	✓	
2002	LS	3. 0L	Other	DSM	✓	✓	✓	✓	0011
2002	LS	3. 0L	Other	EATC	✓	✓	✓	✓	
2002	LS	3. 0L	Other	GEM	✓	✓	✓	✓	
2002	LS	3. 0L	Other	HEC	✓	✓	✓	✓	
2002	LS	3. 0L	Other	MC	✓	✓	✓	✓	
2002	LS	3. 0L	Other	PCM	✓	✓	✓	✓	0025
2002	LS	3. 0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C7
2002	LS	3. 0L	Other	RCM	✓	✓	✓	✓	
2002	LS	3. 0L	Other	REM	✓	✓	✓	✓	
2002	LS	3. 0L	Other	RESCU	✓	✓	✓	✓	
2002	LS	3. 0L	Other	SCLM	✓	✓	✓	✓	
2002	LS	3. 9L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	LS	3. 9L	Other	ACM	✓	✓	✓	✓	
2002	LS	3. 9L	Other	CPM	✓	✓	✓	✓	
2002	LS	3. 9L	Other	DDM	✓	✓	✓	✓	
2002	LS	3. 9L	Other	DSM	✓	✓	✓	✓	0011

2002	LS	3.9L	Other	EATC	✓	✓	✓	✓	
2002	LS	3.9L	Other	GEM	✓	✓	✓	✓	
2002	LS	3.9L	Other	HEC	✓	✓	✓	✓	
2002	LS	3.9L	Other	MC	✓	✓	✓	✓	
2002	LS	3.9L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C7
2002	LS	3.9L	Other	RCM	✓	✓	✓	✓	
2002	LS	3.9L	Other	REM	✓	✓	✓	✓	
2002	LS	3.9L	Other	RESCU	✓	✓	✓	✓	
2003	LS	3.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2003	LS	3.0L	Other	ACM	✓	✓	✓	✓	
2003	LS	3.0L	Other	DCSM	✓	✓	✓	✓	
2003	LS	3.0L	Other	DDM	✓	✓	✓	✓	
2003	LS	3.0L	Other	DSM	✓	✓	✓	✓	0011
2003	LS	3.0L	Other	EATC	✓	✓	✓	✓	
2003	LS	3.0L	Other	EPB	✓	✓	✓	✓	
2003	LS	3.0L	Other	GEM	✓	✓	✓	✓	
2003	LS	3.0L	Other	HEC	✓	✓	✓	✓	00C7
2003	LS	3.0L	Other	MC	✓	✓	✓	✓	
2003	LS	3.0L	Other	NAV	✓	✓	✓	✓	
2003	LS	3.0L	Other	PAM	✓	✓	✓	✓	
2003	LS	3.0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	LS	3.0L	Other	PCSM	✓	✓	✓	✓	
2003	LS	3.0L	Other	RCM	✓	✓	✓	✓	000C
2003	LS	3.0L	Other	REM	✓	✓	✓	✓	
2003	LS	3.0L	Other	SCLM	✓	✓	✓	✓	
2003	LS	3.0L	Other	VEMS	✓	✓	✓	✓	
2003	LS	3.9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	LS	3.9L	4V	ACM	✓	✓	✓	✓	
2003	LS	3.9L	4V	DCSM	✓	✓	✓	✓	
2003	LS	3.9L	4V	DDM	✓	✓	✓	✓	
2003	LS	3.9L	4V	DSM	✓	✓	✓	✓	0011
2003	LS	3.9L	4V	EATC	✓	✓	✓	✓	
2003	LS	3.9L	4V	EPB	✓	✓	✓	✓	
2003	LS	3.9L	4V	GEM	✓	✓	✓	✓	
2003	LS	3.9L	4V	HEC	✓	✓	✓	✓	00C7
2003	LS	3.9L	4V	MC	✓	✓	✓	✓	
2003	LS	3.9L	4V	NAV	✓	✓	✓	✓	
2003	LS	3.9L	4V	PAM	✓	✓	✓	✓	
2003	LS	3.9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	LS	3.9L	4V	PCSM	✓	✓	✓	✓	
2003	LS	3.9L	4V	RCM	✓	✓	✓	✓	000C
2003	LS	3.9L	4V	REM	✓	✓	✓	✓	
2003	LS	3.9L	4V	SCLM	✓	✓	✓	✓	
2003	LS	3.9L	4V	VEMS	✓	✓	✓	✓	
2004	LS	3.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2004	LS	3.0L	Other	ACM	✓	✓	✓	✓	
2004	LS	3.0L	Other	DCSM	✓	✓	✓	✓	
2004	LS	3.0L	Other	DDM	✓	✓	✓	✓	
2004	LS	3.0L	Other	DSM	✓	✓	✓	✓	0011
2004	LS	3.0L	Other	EATC	✓	✓	✓	✓	
2004	LS	3.0L	Other	EPB	✓	✓	✓	✓	
2004	LS	3.0L	Other	GEM	✓	✓	✓	✓	
2004	LS	3.0L	Other	HEC	✓	✓	✓	✓	
2004	LS	3.0L	Other	MC	✓	✓	✓	✓	
2004	LS	3.0L	Other	NAV	✓	✓	✓	✓	
2004	LS	3.0L	Other	PAM	✓	✓	✓	✓	
2004	LS	3.0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	LS	3.0L	Other	PCSM	✓	✓	✓	✓	
2004	LS	3.0L	Other	RCM	✓	✓	✓	✓	000C
2004	LS	3.0L	Other	REM	✓	✓	✓	✓	
2004	LS	3.0L	Other	SCLM	✓	✓	✓	✓	
2004	LS	3.9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2004	LS	3.9L	4V	ACM	✓	✓	✓	✓	
2004	LS	3.9L	4V	DCSM	✓	✓	✓	✓	
2004	LS	3.9L	4V	DDM	✓	✓	✓	✓	
2004	LS	3.9L	4V	DSM	✓	✓	✓	✓	0011
2004	LS	3.9L	4V	EATC	✓	✓	✓	✓	
2004	LS	3.9L	4V	EPB	✓	✓	✓	✓	
2004	LS	3.9L	4V	GEM	✓	✓	✓	✓	
2004	LS	3.9L	4V	HEC	✓	✓	✓	✓	
2004	LS	3.9L	4V	MC	✓	✓	✓	✓	
2004	LS	3.9L	4V	NAV	✓	✓	✓	✓	
2004	LS	3.9L	4V	PAM	✓	✓	✓	✓	
2004	LS	3.9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	LS	3.9L	4V	PCSM	✓	✓	✓	✓	
2004	LS	3.9L	4V	RCM	✓	✓	✓	✓	000C
2004	LS	3.9L	4V	REM	✓	✓	✓	✓	
2004	LS	3.9L	4V	SCLM	✓	✓	✓	✓	
2005	LS	3.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2005	LS	3.0L	Other	ACM	✓	✓	✓	✓	
2005	LS	3.0L	Other	DCSM	✓	✓	✓	✓	
2005	LS	3.0L	Other	DDM	✓	✓	✓	✓	
2005	LS	3.0L	Other	DSM	✓	✓	✓	✓	0011
2005	LS	3.0L	Other	EATC	✓	✓	✓	✓	
2005	LS	3.0L	Other	EPB	✓	✓	✓	✓	
2005	LS	3.0L	Other	GEM	✓	✓	✓	✓	
2005	LS	3.0L	Other	HEC	✓	✓	✓	✓	
2005	LS	3.0L	Other	MC	✓	✓	✓	✓	



2005	LS	3.0L	Other	NAV	✓	✓	✓	✓	0016
2005	LS	3.0L	Other	PAM	✓	✓	✓	✓	
2005	LS	3.0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	LS	3.0L	Other	PCSM	✓	✓	✓	✓	
2005	LS	3.0L	Other	RCM	✓	✓	✓	✓	000C
2005	LS	3.0L	Other	REM	✓	✓	✓	✓	
2005	LS	3.0L	Other	SCLM	✓	✓	✓	✓	
2005	LS	3.9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2005	LS	3.9L	4V	ACM	✓	✓	✓	✓	
2005	LS	3.9L	4V	DCSM	✓	✓	✓	✓	
2005	LS	3.9L	4V	DDM	✓	✓	✓	✓	
2005	LS	3.9L	4V	DSM	✓	✓	✓	✓	0011
2005	LS	3.9L	4V	EATC	✓	✓	✓	✓	
2005	LS	3.9L	4V	EPB	✓	✓	✓	✓	
2005	LS	3.9L	4V	GEM	✓	✓	✓	✓	
2005	LS	3.9L	4V	HEC	✓	✓	✓	✓	
2005	LS	3.9L	4V	MC	✓	✓	✓	✓	
2005	LS	3.9L	4V	NAV	✓	✓	✓	✓	0016
2005	LS	3.9L	4V	PAM	✓	✓	✓	✓	
2005	LS	3.9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	LS	3.9L	4V	PCSM	✓	✓	✓	✓	
2005	LS	3.9L	4V	RCM	✓	✓	✓	✓	000C
2005	LS	3.9L	4V	REM	✓	✓	✓	✓	
2005	LS	3.9L	4V	SCLM	✓	✓	✓	✓	
2006	LS	3.9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2006	LS	3.9L	4V	ACM	✓	✓	✓	✓	
2006	LS	3.9L	4V	DCSM	✓	✓	✓	✓	
2006	LS	3.9L	4V	DDM	✓	✓	✓	✓	
2006	LS	3.9L	4V	DSM	✓	✓	✓	✓	0011
2006	LS	3.9L	4V	EATC	✓	✓	✓	✓	
2006	LS	3.9L	4V	EPB	✓	✓	✓	✓	
2006	LS	3.9L	4V	GEM	✓	✓	✓	✓	
2006	LS	3.9L	4V	HEC	✓	✓	✓	✓	
2006	LS	3.9L	4V	MC	✓	✓	✓	✓	
2006	LS	3.9L	4V	NAV	✓	✓	✓	✓	0016
2006	LS	3.9L	4V	PAM	✓	✓	✓	✓	
2006	LS	3.9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	LS	3.9L	4V	PCSM	✓	✓	✓	✓	
2006	LS	3.9L	4V	RCM	✓	✓	✓	✓	000C
2006	LS	3.9L	4V	REM	✓	✓	✓	✓	
2006	LS	3.9L	4V	SCLM	✓	✓	✓	✓	
Other	Liata	1.6L	Other	PCM	✓	✓	✓	✓	
Other	Liata	1.8L	Other	PCM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	ABS	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	ABS	✓	✓	✓	✓	001E
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	EATC	✓	✓	✓	✓	0020
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	EPS	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	GEM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	GEM	✓	✓	✓	✓	0021
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	IC	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	LPSDM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	PCM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	PCM	✓	✓	✓	✓	00C5
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	RCM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	RKE	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	RPSDM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	ABS	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	ABS	✓	✓	✓	✓	0005
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	ABS	✓	✓	✓	✓	001E
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	EATC	✓	✓	✓	✓	0020
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	EPS	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	GEM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	GEM	✓	✓	✓	✓	0021
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	IC	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	PCM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	PCM	✓	✓	✓	✓	00C5

2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RCM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RKE	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	ABS	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	ABS	✓	✓	✓	✓	001E
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	EATC	✓	✓	✓	✓	0020
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	FFH	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	FFH	✓	✓	✓	✓	002F
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	GEM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	GEM	✓	✓	✓	✓	0021
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	IC	✓	✓	✓		
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	PCM	✓	✓	✓	✓	0055, 0056, 005C
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	PCM	✓	✓	✓	✓	0055, 005C
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	RCM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	RKE	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	ABS	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	EATC	✓	✓	✓	✓	0020
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	EPS	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	IC	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	LPSDM	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	PCM	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	RCM	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	RKE	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	RPSDM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	TCM	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	ABS	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	ABS	✓	✓	✓	✓	0005, 001E
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	EATC	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	EATC	✓	✓	✓	✓	0020
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	EPS	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	EPS	✓	✓	✓	✓	0005
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	GEM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	GEM	✓	✓	✓	✓	0005, 0021
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	IC	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	IC	✓	✓	✓		0005, F022, F05D, FOA8, FOA9, FOAA
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	LPSDM	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	PCM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	PCM	✓	✓	✓	✓	00C5
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RCM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RCM	✓	✓	✓	✓	0005
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RKE	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RKE	✓	✓	✓	✓	0005, F093, F094, F095
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RPSDM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	TCM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	TCM	✓	✓	✓	✓	00C5

2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	ABS	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	ABS	✓	✓	✓	✓	001E
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	EATC	✓	✓	✓	✓	0020
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	FFH	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	FFH	✓	✓	✓	✓	002F
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	GEM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	GEM	✓	✓	✓	✓	0021
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	IC	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	LPSDM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	PCM	✓	✓	✓	✓	0055, 0056, 005C
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	PCM	✓	✓	✓	✓	0055, 005C
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	RCM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	RKE	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	RPSDM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	TCM	✓	✓	✓	✓	
1998	MILLENNIA / EUNOS 800	2. 0L	KF	ABS	✓	✓	✓	✓	
1998	MILLENNIA / EUNOS 800	2. 3L	KJ	ABS	✓	✓	✓	✓	
1998	MILLENNIA / EUNOS 800	2. 5L	KL	ABS	✓	✓	✓	✓	
2000	MILLENNIA / EUNOS 800	2. 0L	KF	ABS	✓	✓	✓	✓	
2000	MILLENNIA / EUNOS 800	2. 3L	KJ	ABS	✓	✓	✓	✓	
2000	MILLENNIA / EUNOS 800	2. 5L	KL	ABS	✓	✓	✓	✓	
2002	MILLENNIA / EUNOS 800	2. 5L	KL	ABS/TCS	✓	✓	✓	✓	
2002	MILLENNIA / EUNOS 800	2. 5L	KL	PCM	✓	✓	✓	✓	
2009	MKS	3. 7L	4V	4X4	✓	✓	✓	✓	
2009	MKS	3. 7L	4V	ABS	✓	✓	✓	✓	0005, 0008
2009	MKS	3. 7L	4V	ACM	✓	✓	✓	✓	0005, 0017, 0018
2009	MKS	3. 7L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	MKS	3. 7L	4V	C-CM	✓	✓	✓	✓	0046
2009	MKS	3. 7L	4V	DCSM	✓	✓	✓	✓	0005
2009	MKS	3. 7L	4V	DDM	✓	✓	✓	✓	
2009	MKS	3. 7L	4V	DDM	✓	✓	✓	✓	0005
2009	MKS	3. 7L	4V	DSM	✓	✓	✓	✓	F041, F087
2009	MKS	3. 7L	4V	DSP	✓	✓	✓	✓	0005
2009	MKS	3. 7L	4V	FCIM	✓	✓	✓	✓	
2009	MKS	3. 7L	4V	FDIM	✓	✓	✓	✓	0005, F05A, F07F
2009	MKS	3. 7L	4V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F04B, F04C, F05F, F088, F089, F08A
2009	MKS	3. 7L	4V	HCM	✓	✓	✓	✓	
2009	MKS	3. 7L	4V	HCM-2	✓	✓	✓	✓	0005
2009	MKS	3. 7L	4V	HD LVL	✓	✓	✓	✓	
2009	MKS	3. 7L	4V	HVAC	✓	✓	✓	✓	
2009	MKS	3. 7L	4V	IPC	✓	✓	✓	✓	0005
2009	MKS	3. 7L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	MKS	3. 7L	4V	PAM	✓	✓	✓	✓	
2009	MKS	3. 7L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	MKS	3. 7L	4V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	MKS	3. 7L	4V	RFA	✓	✓	✓	✓	
2009	MKS	3. 7L	4V	SECM	✓	✓	✓	✓	
2010	MKS	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2010	MKS	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008
2010	MKS	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2010	MKS	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019, 001C
2010	MKS	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2010	MKS	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2010	MKS	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2010	MKS	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	

2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HD_LVL	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2010	MKS	3.7L	4V	4X4	✓	✓	✓	✓	0108
2010	MKS	3.7L	4V	ABS	✓	✓	✓	✓	0008
2010	MKS	3.7L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	MKS	3.7L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	MKS	3.7L	4V	C-CM	✓	✓	✓	✓	0046
2010	MKS	3.7L	4V	DCSM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	DDM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	DSM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	DSP	✓	✓	✓	✓	
2010	MKS	3.7L	4V	FCIM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	FDIM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	MKS	3.7L	4V	GPSM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	HCM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	HCM-2	✓	✓	✓	✓	
2010	MKS	3.7L	4V	HD_LVL	✓	✓	✓	✓	
2010	MKS	3.7L	4V	HUD	✓	✓	✓	✓	
2010	MKS	3.7L	4V	HVAC	✓	✓	✓	✓	
2010	MKS	3.7L	4V	ILCM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	IPC	✓	✓	✓	✓	
2010	MKS	3.7L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	MKS	3.7L	4V	PAM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	PCM	✓	✓	✓	✓	0025
2010	MKS	3.7L	4V	PSCM	✓	✓	✓	✓	

2010	MKS	3.7L	4V	RCM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	RETM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	RFA	✓	✓	✓	✓	
2010	MKS	3.7L	4V	SASM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	SOD-L	✓	✓	✓	✓	
2010	MKS	3.7L	4V	SOD-R	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HD_LVL	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	

2011	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2011	MKS	3.7L	4V	4X4	✓	✓	✓	✓	0108
2011	MKS	3.7L	4V	ABS	✓	✓	✓	✓	0008
2011	MKS	3.7L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	MKS	3.7L	4V	APIM	✓	✓	✓	✓	0019
2011	MKS	3.7L	4V	C-CM	✓	✓	✓	✓	0046
2011	MKS	3.7L	4V	DCSM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	DDM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	DSM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	DSP	✓	✓	✓	✓	
2011	MKS	3.7L	4V	FCIM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	FDIM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	MKS	3.7L	4V	GPSM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	HCM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	HCM-2	✓	✓	✓	✓	
2011	MKS	3.7L	4V	HD_LVL	✓	✓	✓	✓	
2011	MKS	3.7L	4V	HUD	✓	✓	✓	✓	
2011	MKS	3.7L	4V	HVAC	✓	✓	✓	✓	
2011	MKS	3.7L	4V	ILCM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	IPC	✓	✓	✓	✓	
2011	MKS	3.7L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	MKS	3.7L	4V	PAM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	MKS	3.7L	4V	PSCM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	RCM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	RFA	✓	✓	✓	✓	
2011	MKS	3.7L	4V	SASM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	SOD-L	✓	✓	✓	✓	
2011	MKS	3.7L	4V	SOD-R	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HD_LVL	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	

2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2012	MKS	3.7L	4V	4X4	✓	✓	✓	✓	0108
2012	MKS	3.7L	4V	ABS	✓	✓	✓	✓	0008
2012	MKS	3.7L	4V	ACM	✓	✓	✓	✓	0017, 0018
2012	MKS	3.7L	4V	APIM	✓	✓	✓	✓	0019
2012	MKS	3.7L	4V	C-CM	✓	✓	✓	✓	0046
2012	MKS	3.7L	4V	DCSM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	DDM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	DSM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	DSP	✓	✓	✓	✓	
2012	MKS	3.7L	4V	FCIM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	FDIM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	MKS	3.7L	4V	GPSM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	HCM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	HCM-2	✓	✓	✓	✓	
2012	MKS	3.7L	4V	HD LVL	✓	✓	✓	✓	
2012	MKS	3.7L	4V	HUD	✓	✓	✓	✓	
2012	MKS	3.7L	4V	HVAC	✓	✓	✓	✓	
2012	MKS	3.7L	4V	ILCM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	IPC	✓	✓	✓	✓	
2012	MKS	3.7L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	MKS	3.7L	4V	PAM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2012	MKS	3.7L	4V	PSCM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	RCM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	RFA	✓	✓	✓	✓	
2012	MKS	3.7L	4V	SASM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	SOD-L	✓	✓	✓	✓	
2012	MKS	3.7L	4V	SOD-R	✓	✓	✓	✓	
2012	MKS	Other	Other	4X4	✓	✓	✓	✓	
2012	MKS	Other	Other	ABS	✓	✓	✓	✓	
2012	MKS	Other	Other	ACM	✓	✓	✓	✓	
2012	MKS	Other	Other	APIM	✓	✓	✓	✓	
2012	MKS	Other	Other	C-CM	✓	✓	✓	✓	
2012	MKS	Other	Other	DCSM	✓	✓	✓	✓	
2012	MKS	Other	Other	DDM	✓	✓	✓	✓	
2012	MKS	Other	Other	DSM	✓	✓	✓	✓	
2012	MKS	Other	Other	DSP	✓	✓	✓	✓	
2012	MKS	Other	Other	FCIM	✓	✓	✓	✓	
2012	MKS	Other	Other	FDIM	✓	✓	✓	✓	
2012	MKS	Other	Other	GEM / SJB	✓	✓	✓	✓	0042
2012	MKS	Other	Other	GPSM	✓	✓	✓	✓	
2012	MKS	Other	Other	HCM	✓	✓	✓	✓	
2012	MKS	Other	Other	HCM-2	✓	✓	✓	✓	
2012	MKS	Other	Other	HD LVL	✓	✓	✓	✓	
2012	MKS	Other	Other	HUD	✓	✓	✓	✓	
2012	MKS	Other	Other	HVAC	✓	✓	✓	✓	
2012	MKS	Other	Other	ILCM	✓	✓	✓	✓	
2012	MKS	Other	Other	IPC	✓	✓	✓	✓	
2012	MKS	Other	Other	OCSM	✓	✓	✓	✓	
2012	MKS	Other	Other	PAM	✓	✓	✓	✓	
2012	MKS	Other	Other	PSCM	✓	✓	✓	✓	
2012	MKS	Other	Other	RCM	✓	✓	✓	✓	
2012	MKS	Other	Other	RFA	✓	✓	✓	✓	
2012	MKS	Other	Other	SASM	✓	✓	✓	✓	
2012	MKS	Other	Other	SOD-L	✓	✓	✓	✓	

2012	MKS	Other	Other	SOD-R	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0018
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	



2013	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2013	MKS	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	ACM	✓	✓	✓	✓	0018
2013	MKS	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	MKS	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	MKS	3.7L	TiVCT	DACM-C	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	HCM-2	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2013	MKS	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	MKS	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	MKS	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	VDM	✓	✓	✓	✓	000E
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	

2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2014	MKS	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	APT	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	MKS	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	MKS	3.7L	TiVCT	DACM-C	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	HCM-2	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	MKS	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	MKS	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0108
2014	MKS	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	VDM	✓	✓	✓	✓	000E
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018

2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019, 001C
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	0005
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0005
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2010	MKT	3.7L	4V	4X4	✓	✓	✓	✓	0108
2010	MKT	3.7L	4V	ABS	✓	✓	✓	✓	0008, 0012
2010	MKT	3.7L	4V	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	MKT	3.7L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	MKT	3.7L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	MKT	3.7L	4V	C-CM	✓	✓	✓	✓	0046

2010	MKT	3.7L	4V	DCSM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	DDM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	DSM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	DSP	✓	✓	✓	✓	
2010	MKT	3.7L	4V	FCIM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	FDIM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	MKT	3.7L	4V	HCM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	HCM-2	✓	✓	✓	✓	
2010	MKT	3.7L	4V	HUD	✓	✓	✓	✓	
2010	MKT	3.7L	4V	HVAC	✓	✓	✓	✓	
2010	MKT	3.7L	4V	ILCM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	IPC	✓	✓	✓	✓	
2010	MKT	3.7L	4V	LTM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	MKT	3.7L	4V	PAM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	PCM	✓	✓	✓	✓	0025
2010	MKT	3.7L	4V	PCSM-2	✓	✓	✓	✓	
2010	MKT	3.7L	4V	PSCM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	RCM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	RCM	✓	✓	✓	✓	0005
2010	MKT	3.7L	4V	RETm	✓	✓	✓	✓	
2010	MKT	3.7L	4V	RFA	✓	✓	✓	✓	
2010	MKT	3.7L	4V	RHVAC	✓	✓	✓	✓	
2010	MKT	3.7L	4V	SASM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	SOD-L	✓	✓	✓	✓	
2010	MKT	3.7L	4V	SOD-R	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015

2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2011	MKT	3.7L	4V	4X4	✓	✓	✓	✓	0108
2011	MKT	3.7L	4V	ABS	✓	✓	✓	✓	0008, 0012
2011	MKT	3.7L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	MKT	3.7L	4V	APIM	✓	✓	✓	✓	0019
2011	MKT	3.7L	4V	C-CM	✓	✓	✓	✓	0046
2011	MKT	3.7L	4V	DCSM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	DDM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	DSM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	DSP	✓	✓	✓	✓	
2011	MKT	3.7L	4V	FCIM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	FDIM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	GEM / SJB	✓	✓	✓	✓	
2011	MKT	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	MKT	3.7L	4V	GPSM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	HCM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	HCM-2	✓	✓	✓	✓	
2011	MKT	3.7L	4V	HUD	✓	✓	✓	✓	
2011	MKT	3.7L	4V	HVAC	✓	✓	✓	✓	
2011	MKT	3.7L	4V	ILCM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	IPC	✓	✓	✓	✓	
2011	MKT	3.7L	4V	LTM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	MKT	3.7L	4V	PAM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	MKT	3.7L	4V	PCSM-2	✓	✓	✓	✓	
2011	MKT	3.7L	4V	PSCM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	RCM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	RETM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	RFA	✓	✓	✓	✓	
2011	MKT	3.7L	4V	RHVAC	✓	✓	✓	✓	
2011	MKT	3.7L	4V	SASM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	SOD-L	✓	✓	✓	✓	
2011	MKT	3.7L	4V	SOD-R	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	

2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓		
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2012	MKT	3.7L	4V	4X4	✓	✓	✓	✓	0108
2012	MKT	3.7L	4V	ABS	✓	✓	✓	✓	0008, 0012
2012	MKT	3.7L	4V	ACM	✓	✓	✓	✓	0017, 0018
2012	MKT	3.7L	4V	APIM	✓	✓	✓	✓	0019
2012	MKT	3.7L	4V	C-CM	✓	✓	✓	✓	0046
2012	MKT	3.7L	4V	DCSM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	DDM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	DSM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	DSP	✓	✓	✓	✓	
2012	MKT	3.7L	4V	FCIM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	FDIM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	GEM / SJB	✓	✓	✓	✓	
2012	MKT	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	MKT	3.7L	4V	GPSM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	HCM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	HCM-2	✓	✓	✓	✓	
2012	MKT	3.7L	4V	HUD	✓	✓	✓	✓	
2012	MKT	3.7L	4V	HVAC	✓	✓	✓	✓	

2012	MKT	3. 7L	4V	I LCM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	IPC	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	LTM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	MKT	3. 7L	4V	PAM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2012	MKT	3. 7L	4V	PCSM-2	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	PSCM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	RCM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	RETM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	RFA	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	RHVAC	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	SASM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	SOD-L	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	SOD-R	✓	✓	✓	✓	
2012	MKT	Other	Other	4X4	✓	✓	✓	✓	
2012	MKT	Other	Other	ABS	✓	✓	✓	✓	
2012	MKT	Other	Other	ACM	✓	✓	✓	✓	
2012	MKT	Other	Other	APIM	✓	✓	✓	✓	
2012	MKT	Other	Other	C-CM	✓	✓	✓	✓	
2012	MKT	Other	Other	DCSM	✓	✓	✓	✓	
2012	MKT	Other	Other	DDM	✓	✓	✓	✓	
2012	MKT	Other	Other	DSM	✓	✓	✓	✓	
2012	MKT	Other	Other	DSP	✓	✓	✓	✓	
2012	MKT	Other	Other	FCIM	✓	✓	✓	✓	
2012	MKT	Other	Other	FDIM	✓	✓	✓	✓	
2012	MKT	Other	Other	GEM / SJB	✓	✓	✓	✓	0042
2012	MKT	Other	Other	GPSM	✓	✓	✓	✓	
2012	MKT	Other	Other	HCM	✓	✓	✓	✓	
2012	MKT	Other	Other	HCM-2	✓	✓	✓	✓	
2012	MKT	Other	Other	HUD	✓	✓	✓	✓	
2012	MKT	Other	Other	HVAC	✓	✓	✓	✓	
2012	MKT	Other	Other	I LCM	✓	✓	✓	✓	
2012	MKT	Other	Other	IPC	✓	✓	✓	✓	
2012	MKT	Other	Other	LTM	✓	✓	✓	✓	
2012	MKT	Other	Other	OCSM	✓	✓	✓	✓	
2012	MKT	Other	Other	PAM	✓	✓	✓	✓	
2012	MKT	Other	Other	PCSM-2	✓	✓	✓	✓	
2012	MKT	Other	Other	PSCM	✓	✓	✓	✓	
2012	MKT	Other	Other	RCM	✓	✓	✓	✓	
2012	MKT	Other	Other	RETM	✓	✓	✓	✓	
2012	MKT	Other	Other	RFA	✓	✓	✓	✓	
2012	MKT	Other	Other	RHVAC	✓	✓	✓	✓	
2012	MKT	Other	Other	SASM	✓	✓	✓	✓	
2012	MKT	Other	Other	SOD-L	✓	✓	✓	✓	
2012	MKT	Other	Other	SOD-R	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	

2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	



2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2013	MKT	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2013	MKT	3.7L	TiVCT	APIM	✓	✓	✓	✓	0019
2013	MKT	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	MKT	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	MKT	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2013	MKT	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	MKT	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	MKT	3.7L	TiVCT	PCSM-2	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	RHVAC	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	SCCM	✓	✓	✓	✓	

2013	MKT	3. 7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	MKT	3. 7L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	MKT	3. 7L	TiVCT	VDM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	

2014	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	

2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2014	MKT	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	MKT	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	MKT	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	MKT	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	MKT	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0108
2014	MKT	3.7L	TiVCT	PCSM-2	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	RHVAC	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	VDM	✓	✓	✓	✓	
2014	MKT	Other	Other	ABS	✓	✓	✓	✓	
2014	MKT	Other	Other	ACM	✓	✓	✓	✓	
2014	MKT	Other	Other	APIM	✓	✓	✓	✓	
2014	MKT	Other	Other	BCM#1	✓	✓	✓	✓	
2014	MKT	Other	Other	C-CM	✓	✓	✓	✓	
2014	MKT	Other	Other	DCSM	✓	✓	✓	✓	
2014	MKT	Other	Other	DDM	✓	✓	✓	✓	
2014	MKT	Other	Other	DSM	✓	✓	✓	✓	
2014	MKT	Other	Other	DSP	✓	✓	✓	✓	
2014	MKT	Other	Other	FCIM	✓	✓	✓	✓	
2014	MKT	Other	Other	GPSM	✓	✓	✓	✓	
2014	MKT	Other	Other	HCM	✓	✓	✓	✓	
2014	MKT	Other	Other	HSWM	✓	✓	✓	✓	
2014	MKT	Other	Other	HUD	✓	✓	✓	✓	
2014	MKT	Other	Other	HVAC	✓	✓	✓	✓	
2014	MKT	Other	Other	IPC	✓	✓	✓	✓	
2014	MKT	Other	Other	IPM-A	✓	✓	✓	✓	
2014	MKT	Other	Other	LTM	✓	✓	✓	✓	
2014	MKT	Other	Other	OCSM	✓	✓	✓	✓	
2014	MKT	Other	Other	PAM	✓	✓	✓	✓	
2014	MKT	Other	Other	PCSM-2	✓	✓	✓	✓	
2014	MKT	Other	Other	PSCM	✓	✓	✓	✓	
2014	MKT	Other	Other	RACM	✓	✓	✓	✓	
2014	MKT	Other	Other	RCM	✓	✓	✓	✓	
2014	MKT	Other	Other	RFA	✓	✓	✓	✓	
2014	MKT	Other	Other	RHVAC	✓	✓	✓	✓	
2014	MKT	Other	Other	RTM	✓	✓	✓	✓	
2014	MKT	Other	Other	SCCM	✓	✓	✓	✓	
2014	MKT	Other	Other	SOD-L	✓	✓	✓	✓	
2014	MKT	Other	Other	SOD-R	✓	✓	✓	✓	
2014	MKT	Other	Other	VDM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	4X4	✓	✓	✓	✓	
2007	MKX	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2007	MKX	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	MKX	3.5L	4V	DCSM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	DSM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	DSP	✓	✓	✓	✓	
2007	MKX	3.5L	4V	EATC	✓	✓	✓	✓	
2007	MKX	3.5L	4V	GEM	✓	✓	✓	✓	001A
2007	MKX	3.5L	4V	HCM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	IC	✓	✓	✓	✓	

2007	MKX	3.5L	4V	LTM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2007	MKX	3.5L	4V	PAM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	MKX	3.5L	4V	RCM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	RETM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	SASM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2008	MKX	3.5L	4V	4X4	✓	✓	✓	✓	
2008	MKX	3.5L	4V	ABS	✓	✓	✓	✓	0005
2008	MKX	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0012
2008	MKX	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2008	MKX	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	MKX	3.5L	4V	DCSM	✓	✓	✓	✓	
2008	MKX	3.5L	4V	DSM	✓	✓	✓	✓	0005
2008	MKX	3.5L	4V	DSP	✓	✓	✓	✓	0005
2008	MKX	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C
2008	MKX	3.5L	4V	HCM	✓	✓	✓	✓	
2008	MKX	3.5L	4V	HVAC	✓	✓	✓	✓	
2008	MKX	3.5L	4V	IC	✓	✓	✓	✓	0005, F027, F047, F04A
2008	MKX	3.5L	4V	LTM	✓	✓	✓	✓	
2008	MKX	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	MKX	3.5L	4V	PAM	✓	✓	✓	✓	0005
2008	MKX	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	MKX	3.5L	4V	RCM	✓	✓	✓	✓	0005
2008	MKX	3.5L	4V	RETM	✓	✓	✓	✓	0005, F04D
2008	MKX	3.5L	4V	SASM	✓	✓	✓	✓	
2008	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0005, 0019
2009	MKX	3.5L	4V	4X4	✓	✓	✓	✓	
2009	MKX	3.5L	4V	ABS	✓	✓	✓	✓	
2009	MKX	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0012
2009	MKX	3.5L	4V	ACM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0019
2009	MKX	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	MKX	3.5L	4V	APIM	✓	✓	✓	✓	001C
2009	MKX	3.5L	4V	DCSM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	DCSM	✓	✓	✓	✓	0005
2009	MKX	3.5L	4V	DSM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	DSM	✓	✓	✓	✓	0005
2009	MKX	3.5L	4V	DSP	✓	✓	✓	✓	
2009	MKX	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	MKX	3.5L	4V	HCM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	HVAC	✓	✓	✓	✓	
2009	MKX	3.5L	4V	IC	✓	✓	✓	✓	
2009	MKX	3.5L	4V	IC	✓	✓	✓	✓	0005
2009	MKX	3.5L	4V	LTM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2009	MKX	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	MKX	3.5L	4V	PAM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	PAM	✓	✓	✓	✓	0005
2009	MKX	3.5L	4V	PCM	✓	✓	✓	✓	0025
2009	MKX	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	MKX	3.5L	4V	RCM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	RCM	✓	✓	✓	✓	0005
2009	MKX	3.5L	4V	RETM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	SASM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0005
2009	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0005, 0019
2009	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2010	MKX	3.5L	4V	4X4	✓	✓	✓	✓	
2010	MKX	3.5L	4V	ABS	✓	✓	✓	✓	0012
2010	MKX	3.5L	4V	ACM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0019
2010	MKX	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	MKX	3.5L	4V	DCSM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	DCSM	✓	✓	✓	✓	0005
2010	MKX	3.5L	4V	DSM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	DSM	✓	✓	✓	✓	0005
2010	MKX	3.5L	4V	DSP	✓	✓	✓	✓	
2010	MKX	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	MKX	3.5L	4V	GPSM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	HCM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	HVAC	✓	✓	✓	✓	
2010	MKX	3.5L	4V	IC	✓	✓	✓	✓	
2010	MKX	3.5L	4V	LTM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	MKX	3.5L	4V	PAM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	PAM	✓	✓	✓	✓	0005
2010	MKX	3.5L	4V	PCM	✓	✓	✓	✓	0025
2010	MKX	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5

2010	MKX	3.5L	4V	RCM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	RETM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	SASM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	
2010	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0005, 0019
2010	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2011	MKX	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2011	MKX	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	APIM	✓	✓	✓	✓	00D6
2011	MKX	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 0042, 00D4, 00D5, 00FE
2011	MKX	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	MKX	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2011	MKX	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2011	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2011	MKX	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	PCM	✓	✓	✓	✓	0067, 0095
2011	MKX	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	TPM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	MKX	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	MKX	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2012	MKX	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2012	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2012	MKX	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2012	MKX	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	TPM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	MKX	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	MKX	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	MKX	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	MKX	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108

2013	MKX	3.7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	MKX	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2014	MKX	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112
2014	MKX	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	MKX	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	MKX	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	MKX	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	MKX	Other	Other	ABS	✓	✓	✓	✓	
2014	MKX	Other	Other	ACM	✓	✓	✓	✓	
2014	MKX	Other	Other	APIM	✓	✓	✓	✓	
2014	MKX	Other	Other	BCM#1	✓	✓	✓	✓	
2014	MKX	Other	Other	C-CM	✓	✓	✓	✓	
2014	MKX	Other	Other	DCSM	✓	✓	✓	✓	
2014	MKX	Other	Other	DSM	✓	✓	✓	✓	
2014	MKX	Other	Other	DSP	✓	✓	✓	✓	
2014	MKX	Other	Other	FCDIM	✓	✓	✓	✓	
2014	MKX	Other	Other	FCIM	✓	✓	✓	✓	
2014	MKX	Other	Other	FLM	✓	✓	✓	✓	
2014	MKX	Other	Other	GPSM	✓	✓	✓	✓	
2014	MKX	Other	Other	HCM	✓	✓	✓	✓	
2014	MKX	Other	Other	HSWM	✓	✓	✓	✓	
2014	MKX	Other	Other	HUD	✓	✓	✓	✓	
2014	MKX	Other	Other	HVAC	✓	✓	✓	✓	
2014	MKX	Other	Other	IPC	✓	✓	✓	✓	
2014	MKX	Other	Other	LTM	✓	✓	✓	✓	
2014	MKX	Other	Other	OCSM	✓	✓	✓	✓	
2014	MKX	Other	Other	PAM	✓	✓	✓	✓	
2014	MKX	Other	Other	RCM	✓	✓	✓	✓	
2014	MKX	Other	Other	RFA	✓	✓	✓	✓	
2014	MKX	Other	Other	RTM	✓	✓	✓	✓	
2014	MKX	Other	Other	SCCM	✓	✓	✓	✓	
2014	MKX	Other	Other	SOD-L	✓	✓	✓	✓	
2014	MKX	Other	Other	SOD-R	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	

2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GSM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-G	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-H	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRCM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS	✓	✓	✓	✓	0012, 00F5, 010A, 020C
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM	✓	✓	✓	✓	



2013	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM	✓	✓	✓	✓	0046
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A	✓	✓	✓	✓	013E
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	✓	✓	✓	✓	013C
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM	✓	✓	✓	✓	000E
2013	MKZ	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2013	MKZ	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	MKZ	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	MKZ	3.7L	TiVCT	DACM-C	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	GFM	✓	✓	✓	✓	

2013	MKZ	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	GSM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	GWM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2013	MKZ	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	MKZ	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2013	MKZ	3.7L	TiVCT	PDM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	RGTM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	SCM-E	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	SCM-G	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	SCM-H	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	TRCM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	VDM	✓	✓	✓	✓	000E
2013	MKZ	Other	Other	ABS	✓	✓	✓	✓	
2013	MKZ	Other	Other	ACM	✓	✓	✓	✓	
2013	MKZ	Other	Other	APIM	✓	✓	✓	✓	
2013	MKZ	Other	Other	BCM#1	✓	✓	✓	✓	
2013	MKZ	Other	Other	C-CM	✓	✓	✓	✓	
2013	MKZ	Other	Other	DACM-C	✓	✓	✓	✓	
2013	MKZ	Other	Other	DDM	✓	✓	✓	✓	
2013	MKZ	Other	Other	DSM	✓	✓	✓	✓	
2013	MKZ	Other	Other	DSP	✓	✓	✓	✓	
2013	MKZ	Other	Other	FCDIM	✓	✓	✓	✓	
2013	MKZ	Other	Other	FCIM	✓	✓	✓	✓	
2013	MKZ	Other	Other	GFM	✓	✓	✓	✓	
2013	MKZ	Other	Other	GPSM	✓	✓	✓	✓	
2013	MKZ	Other	Other	GSM	✓	✓	✓	✓	
2013	MKZ	Other	Other	GWM	✓	✓	✓	✓	
2013	MKZ	Other	Other	HCM	✓	✓	✓	✓	
2013	MKZ	Other	Other	HSWM	✓	✓	✓	✓	
2013	MKZ	Other	Other	HUD	✓	✓	✓	✓	
2013	MKZ	Other	Other	IPC	✓	✓	✓	✓	
2013	MKZ	Other	Other	IPM-A	✓	✓	✓	✓	
2013	MKZ	Other	Other	OCSM	✓	✓	✓	✓	
2013	MKZ	Other	Other	PAM	✓	✓	✓	✓	
2013	MKZ	Other	Other	PDM	✓	✓	✓	✓	
2013	MKZ	Other	Other	PSCM	✓	✓	✓	✓	
2013	MKZ	Other	Other	RACM	✓	✓	✓	✓	
2013	MKZ	Other	Other	RCM	✓	✓	✓	✓	
2013	MKZ	Other	Other	RGTM	✓	✓	✓	✓	
2013	MKZ	Other	Other	RTM	✓	✓	✓	✓	
2013	MKZ	Other	Other	SCCM	✓	✓	✓	✓	
2013	MKZ	Other	Other	SCM-E	✓	✓	✓	✓	
2013	MKZ	Other	Other	SCM-G	✓	✓	✓	✓	
2013	MKZ	Other	Other	SCM-H	✓	✓	✓	✓	
2013	MKZ	Other	Other	SOD-L	✓	✓	✓	✓	
2013	MKZ	Other	Other	SOD-R	✓	✓	✓	✓	
2013	MKZ	Other	Other	TRCM	✓	✓	✓	✓	
2013	MKZ	Other	Other	VDM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 010A, 020C
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112, 020F
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	

2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GSM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-G	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-H	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRCM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS	✓	✓	✓	✓	0012, 010A, 020C
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM	✓	✓	✓	✓	

2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	APIM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112, 020F
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	BECM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	C-CM	✓	✓	✓	✓	0046
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	DACM-C	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	DCDC	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	DDM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	DSM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	DSP	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	FCDIM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	FCIM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	GFM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	GPSM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	GSM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	GWM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	HCM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	HSWM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	HUD	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	IPC	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	IPM-A	✓	✓	✓	✓	013E
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	PAM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	PDM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	PSCM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	RACM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	RCM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	RGTM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	RTM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SCCM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SCM-E	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SCM-G	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SCM-H	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SOBDM-C	✓	✓	✓	✓	013C
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SOD-L	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SOD-R	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	TRCM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	VDM	✓	✓	✓	✓	000E
2014	MKZ	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012, 010A, 020C
2014	MKZ	3. 7L	TiVCT	ACM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	APIM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112, 020F
2014	MKZ	3. 7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	MKZ	3. 7L	TiVCT	DACM-C	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	DDM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	DSM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	DSP	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	GFM	✓	✓	✓	✓	

2014	MKZ	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	GSM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	GWM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	MKZ	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	MKZ	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	MKZ	3.7L	TiVCT	PDM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	RGTM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	SCM-E	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	SCM-G	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	SCM-H	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	TRCM	✓	✓	✓	✓	
2014	MKZ	3.7L	TiVCT	VDM	✓	✓	✓	✓	000E
2007.25	MONDEO	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2007.25	MONDEO	1.6L	DURATEC VCT	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	CMR	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	0025, 00BC
2007.25	MONDEO	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	SASM	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	TRM	✓	✓	✓	✓	
2007.25	MONDEO	1.6L	DURATEC VCT	VDM	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0092, 0098, 0099, 009A, 00AB, 00AC, 00B4, 00C1
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102

2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	2.0L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2007.25	MONDEO	2.0L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2007.25	MONDEO	2.0L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	F020
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	00AC
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	2.0L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0092, 0098, 0099, 009A, 00AB, 00AC, 00B4, 00C1
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8

2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011C
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011C, 0132
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	009A
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	0102
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102

2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	011C
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF



2007.25	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	√	√	√	√	
2007.25	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	√	√	√	√	
2007.25	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SRM	√	√	√	√	
2007.25	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	√	√	√	√	
2007.25	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	√	√	√	√	
2007.25	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	ABS	√	√	√	√	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	ACM	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	AHCM	√	√	√	√	00CF
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	BCMii	√	√	√	√	0132, 0153
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CCMii	√	√	√	√	00F9
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CDP	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CMR	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DDM	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DSM	√	√	√	√	00F2
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	HCM	√	√	√	√	0032
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	HVAC	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	IPC	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PAM	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PBM	√	√	√	√	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PCM	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PDM	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PSCM	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RCM	√	√	√	√	00EF, 0102
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RFA	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SASM	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SRM	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	TCM	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	TRM	√	√	√	√	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	VDM	√	√	√	√	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	√	√	√	√	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	√	√	√	√	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	AHCM	√	√	√	√	00CF
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	√	√	√	√	011C, 0132, 0153
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	√	√	√	√	00F9
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	CDP	√	√	√	√	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	CMR	√	√	√	√	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	DDM	√	√	√	√	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	DSM	√	√	√	√	00F2
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	HCM	√	√	√	√	0032
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	HVAC	√	√	√	√	

2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00A5, 00AA, 00AF, 00B0, 00B1, 00B2, 00B8, 00B9, 00C1
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	2.3L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2007.25	MONDEO	2.3L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.3L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.3L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00AC
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	00AC
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	2.3L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0121, 0122, 0123, 0124, 0125
2007.25	MONDEO	2.3L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.5L	15	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	2.5L	15	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2007.25	MONDEO	2.5L	15	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.5L	15	CDP	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.5L	15	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.5L	15	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	IPC	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	PBM	✓	✓	✓	✓	00F3, 00F4, 00F5, 00F6, 00F7
2007.25	MONDEO	2.5L	15	PCM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	2.5L	15	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	VDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	AHCM	✓	✓	✓	✓	00CF
2011	MONDEO	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2011	MONDEO	1.6L	DURATEC VCT	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	

2011	MONDEO	1.6L	DURATEC VCT	CMR	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	DABM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0032
2011	MONDEO	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	PBM	✓	✓	✓	✓	00F3, 00F4, 00F5, 00F6, 00F7
2011	MONDEO	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	RGTM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	RHVAC	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	SASM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	SOD-L	✓	✓	✓	✓	00BC, F026
2011	MONDEO	1.6L	DURATEC VCT	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	TRM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	VDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	DABM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00F3, 00F4, 00F5, 00F6
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00B1, 00B7, 00B9, 00BC, 00BD, 00C1, 00C3
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	

2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	AHCM	✓	✓	✓		00CF
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	CDP	✓	✓	✓	✓	0005
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	CMR	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DABM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	F020
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PBM	✓	✓	✓	✓	00F3, 00F4, 00F5, 00F6, 00F7
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓		
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓		
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓		0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓		
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓		00CF
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153

2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	DABM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0092, 0098, 0099, 009A, 00AB, 00AC, 00B4, 00C1
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓		00CF
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011C, 0132
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	0005
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DABM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓		00F2

2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	F020
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓		0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	009A
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓		00EF, 0102
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓		0102
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RHVAC	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓		F026

2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓		F026
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓		
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓		0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓		
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓		00CF
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	CDP	✓	✓	✓	✓	0005
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	CMR	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DABM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	F020
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F7
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 0114
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	

2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	ACM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	AHCM	✓	✓	✓	✓	00CF
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	BCMii	✓	✓	✓	✓	0132, 0153
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CDP	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CMR	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DABM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DDM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	HVAC	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	IPC	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PAM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PCM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PDM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PSCM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RFA	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RGTM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SASM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SRM	✓	✓	✓	✓	



2011	MONDEO	2. 0L	Ecoboost GTDI Chinese market only	TCM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Ecoboost GTDI Chinese market only	TRM	✓	✓	✓		
2011	MONDEO	2. 0L	Ecoboost GTDI Chinese market only	VDM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	DABM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓		00CF
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C, 0132
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	

2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DABM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓		00F2
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PBM	✓	✓	✓	✓	00F3, 00F4, 00F5, 00F6
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PBM	✓	✓	✓	✓	00F3, 00F4, 00F5, 00F7
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0092, 0099, 009A, 00B2, 00B8, 00BE
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	0102
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓		

2011	MONDEO	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓		0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓		
2011	MONDEO	2. 3L	DURATEC-HE / I4	AHCM	✓	✓	✓		00CF
2011	MONDEO	2. 3L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2011	MONDEO	2. 3L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2. 3L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2011	MONDEO	2. 3L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	DABM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2. 3L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2. 3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	F020
2011	MONDEO	2. 3L	DURATEC-HE / I4	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6
2011	MONDEO	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	00AC
2011	MONDEO	2. 3L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2. 3L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	RGTM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2. 3L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2. 3L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
2003	Marauder	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	
2003	Marauder	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Marauder	4. 6L	4V	DDM	✓	✓	✓	✓	
2003	Marauder	4. 6L	4V	EATC	✓	✓	✓	✓	
2003	Marauder	4. 6L	4V	LCM	✓	✓	✓	✓	
2003	Marauder	4. 6L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Marauder	4. 6L	4V	RASM	✓	✓	✓	✓	
2003	Marauder	4. 6L	4V	RCM	✓	✓	✓	✓	000C
2003	Marauder	4. 6L	4V	VAPS	✓	✓	✓	✓	
2004	Marauder	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	
2004	Marauder	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2004	Marauder	4. 6L	4V	DDM	✓	✓	✓	✓	
2004	Marauder	4. 6L	4V	EATC	✓	✓	✓	✓	
2004	Marauder	4. 6L	4V	LCM	✓	✓	✓	✓	
2004	Marauder	4. 6L	4V	PCM	✓	✓	✓	✓	0013, 0025, 0028, 0031, 0033
2004	Marauder	4. 6L	4V	RASM	✓	✓	✓	✓	0013
2004	Marauder	4. 6L	4V	RCM	✓	✓	✓	✓	000C
2004	Marauder	4. 6L	4V	VAPS	✓	✓	✓	✓	
2006	Mariner	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2006	Mariner	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2006	Mariner	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Mariner	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Mariner	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2006	Mariner	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Mariner	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2006	Mariner	3. 0L	4V	4X4	✓	✓	✓	✓	
2006	Mariner	3. 0L	4V	ABS	✓	✓	✓	✓	0005, 0008
2006	Mariner	3. 0L	4V	GEM	✓	✓	✓	✓	F042, F04E, F04F, F050, F051, F056, F057, F058, F059
2006	Mariner	3. 0L	4V	GEM	✓	✓	✓	✓	F042, F04E, F04F, F050, F051, F056, F057, F058, F059, F090
2006	Mariner	3. 0L	4V	IC	✓	✓	✓	✓	0005, F040, F043, F04D, F052, F053, F054, F055
2006	Mariner	3. 0L	4V	PAM	✓	✓	✓	✓	
2006	Mariner	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Mariner	3. 0L	4V	RCM	✓	✓	✓	✓	000C
2007	Mariner	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2007	Mariner	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2007	Mariner	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007	Mariner	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	Mariner	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007	Mariner	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	Mariner	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Mariner	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2007	Mariner	3. 0L	4V	4X4	✓	✓	✓	✓	
2007	Mariner	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2007	Mariner	3. 0L	4V	GEM	✓	✓	✓	✓	
2007	Mariner	3. 0L	4V	IC	✓	✓	✓	✓	
2007	Mariner	3. 0L	4V	PAM	✓	✓	✓	✓	

2007	Mariner	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Mariner	3. 0L	4V	RCM	✓	✓	✓	✓	000C
2006	Mark LT	5. 4L	3V	4X4	✓	✓	✓	✓	
2006	Mark LT	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 000B
2006	Mark LT	5. 4L	3V	DSM	✓	✓	✓	✓	
2006	Mark LT	5. 4L	3V	EATC	✓	✓	✓	✓	
2006	Mark LT	5. 4L	3V	IC	✓	✓	✓	✓	
2006	Mark LT	5. 4L	3V	PAM	✓	✓	✓	✓	
2006	Mark LT	5. 4L	3V	PAM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Mark LT	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Mark LT	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2006	Mark LT	5. 4L	3V	VSM	✓	✓	✓	✓	
2007	Mark LT	5. 4L	3V	4X4	✓	✓	✓	✓	
2007	Mark LT	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2007	Mark LT	5. 4L	3V	DSM	✓	✓	✓	✓	
2007	Mark LT	5. 4L	3V	EATC	✓	✓	✓	✓	
2007	Mark LT	5. 4L	3V	IC	✓	✓	✓	✓	
2007	Mark LT	5. 4L	3V	PAM	✓	✓	✓	✓	
2007	Mark LT	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Mark LT	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2007	Mark LT	5. 4L	3V	VSM	✓	✓	✓	✓	
2008	Mark LT	5. 4L	3V	4X4	✓	✓	✓	✓	
2008	Mark LT	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2008	Mark LT	5. 4L	3V	DSM	✓	✓	✓	✓	
2008	Mark LT	5. 4L	3V	HVAC	✓	✓	✓	✓	
2008	Mark LT	5. 4L	3V	IC	✓	✓	✓	✓	
2008	Mark LT	5. 4L	3V	PAM	✓	✓	✓	✓	
2008	Mark LT	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Mark LT	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2008	Mark LT	5. 4L	3V	RETM	✓	✓	✓	✓	0018
2008	Mark LT	5. 4L	3V	VSM	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	CPM	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	DDM	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	DSM	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	HEC	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	PCM	✓	✓	✓	✓	0025
1996	Mark VIII	4. 6L	4V	PSM	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	SCIL	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1997	Mark VIII	4. 6L	4V	CPM	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	DDM	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	DSM	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	EATC	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	HEC	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	MC	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	PCM	✓	✓	✓	✓	0025
1997	Mark VIII	4. 6L	4V	PSM	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	SCIL	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1998	Mark VIII	4. 6L	4V	CPM	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	DDM	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	DSM	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	EATC	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	HEC	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	MC	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	PCM	✓	✓	✓	✓	0025
1998	Mark VIII	4. 6L	4V	PSM	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	SCIL	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2006	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2006	Milan	2. 3L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	F044, F048, F04C, F057, F085
2006	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2006	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2006	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2006	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2006	Milan	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2006	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2006	Milan	3. 0L	4V	EATC	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	GEM	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	IC	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2006	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5

2006	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	TCM	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2007	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0016, 0017, 0018, F05A
2007	Milan	2. 3L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	F044, F048, F04C, F057, F085
2007	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005
2007	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2007	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Milan	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	0019
2007	Milan	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	4X4	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2007	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Milan	3. 0L	4V	EATC	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	GEM	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	IC	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	IC	✓	✓	✓	✓	0005
2007	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2007	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2007	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	0005
2007	Milan	3. 0L	4V	SDARS	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	SDARS	✓	✓	✓	✓	0019
2007	Milan	3. 0L	4V	TCM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2008	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0016, 0017, 0018, F05A, F062, F07A
2008	Milan	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2008	Milan	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2008	Milan	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F044, F048, F04C, F057, F085, F086
2008	Milan	2. 3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	F027
2008	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2008	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Milan	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2008	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	F022, F05D
2008	Milan	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	4X4	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2008	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Milan	3. 0L	4V	APIM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Milan	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2008	Milan	3. 0L	4V	HVAC	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	IC	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2008	Milan	3. 0L	4V	PAM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2008	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	SDARS	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	TCM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	

2009	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2009	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F05A, F062, F07A
2009	Milan	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2009	Milan	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0005, 0042, F044, F048, F04C, F057, F085, F086
2009	Milan	2. 3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F027
2009	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Milan	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2009	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2009	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Milan	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	0005
2009	Milan	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	4X4	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2009	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Milan	3. 0L	4V	APIM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Milan	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Milan	3. 0L	4V	HVAC	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	IC	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2009	Milan	3. 0L	4V	PAM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2009	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	SDARS	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	TCM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Milan	2. 5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2010	Milan	2. 5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	Milan	2. 5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2010	Milan	2. 5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2010	Milan	2. 5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	0005
2010	Milan	2. 5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	0005, F062
2010	Milan	2. 5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2010	Milan	2. 5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C
2010	Milan	2. 5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	0005
2010	Milan	2. 5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Milan	2. 5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	Milan	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2010	Milan	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0067
2010	Milan	2. 5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	Milan	2. 5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Milan	2. 5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Milan	2. 5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	0005
2010	Milan	2. 5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042

2010	Milan	2. 5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	Milan	2. 5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Milan	2. 5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2010	Milan	2. 5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	4X4	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	0008, 0012
2010	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Milan	3. 0L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Milan	3. 0L	4V	DSP	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	FCIM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	FCIM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	FDIM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Milan	3. 0L	4V	GPSM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	HVAC	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	IPC	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	Milan	3. 0L	4V	PAM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	0067
2010	Milan	3. 0L	4V	PSCM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	SOD-L	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	SOD-R	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2011	Milan	2. 5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2011	Milan	2. 5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019
2011	Milan	2. 5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2011	Milan	2. 5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2011	Milan	2. 5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2011	Milan	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0067
2011	Milan	2. 5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Milan	2. 5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0018
2011	Milan	2. 5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019
2011	Milan	2. 5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Milan	2. 5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Milan	2. 5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Milan	2. 5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2011	Milan	2. 5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	4X4	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	0008, 0012
2011	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Milan	3. 0L	4V	APIM	✓	✓	✓	✓	0019
2011	Milan	3. 0L	4V	DSP	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	FCIM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	FCIM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	FDIM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	0042

2011	Milan	3. 0L	4V	GPSM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	HVAC	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	IPC	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Milan	3. 0L	4V	PAM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	0067
2011	Milan	3. 0L	4V	PSCM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	SOD-L	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	SOD-R	✓	✓	✓	✓	
1993. 5	Mondeo	1. 6L	Zetec	ABS	✓	✓	✓	✓	
1993. 5	Mondeo	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1993. 5	Mondeo	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1993. 5	Mondeo	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1993. 5	Mondeo	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1993. 5	Mondeo	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1993. 5	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1993. 5	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1993. 5	Mondeo	2. 0L	Zetec	ABS	✓	✓	✓	✓	
1993. 5	Mondeo	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1993. 5	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1993. 5	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1993. 75	Mondeo	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1993. 75	Mondeo	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1993. 75	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1993. 75	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1993. 75	Mondeo	2. 0L	Zetec	ABS	✓	✓	✓	✓	
1993. 75	Mondeo	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1993. 75	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1993. 75	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1994. 5	Mondeo	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1994. 5	Mondeo	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1994. 5	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1994. 5	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1994. 75	Mondeo	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	
1994. 75	Mondeo	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
1994. 75	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1994. 75	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1995	Mondeo	1. 6L	Zetec	ABS	✓	✓	✓	✓	
1995	Mondeo	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1995	Mondeo	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1995	Mondeo	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1995	Mondeo	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1995	Mondeo	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1995	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1995	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1995	Mondeo	2. 0L	Zetec	ABS	✓	✓	✓	✓	
1995	Mondeo	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1995	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1995	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1995	Mondeo	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	
1995	Mondeo	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
1995	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1995	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1996	Mondeo	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1996	Mondeo	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1996	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1996	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1996	Mondeo	2. 0L	Zetec	ABS	✓	✓	✓	✓	
1996	Mondeo	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1996	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1996	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1996	Mondeo	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	
1996	Mondeo	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
1996	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1996	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1997	Mondeo	1. 6L	Zetec	ABS	✓	✓	✓	✓	
1997	Mondeo	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1997	Mondeo	1. 6L	Zetec	FFH	✓	✓	✓	✓	
1997	Mondeo	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1997	Mondeo	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1997	Mondeo	1. 6L	Zetec	PCM	✓	✓	✓	✓	0025
1997	Mondeo	1. 8L	Endura-DE	ABS	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Endura-DE	CSM	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Endura-DE	FFH	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Endura-DE	PATS	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Endura-DE	PCM	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	FFH	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	PCM	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	PCM	✓	✓	✓	✓	0025
1997	Mondeo	2. 0L	Zetec	ABS	✓	✓	✓	✓	
1997	Mondeo	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1997	Mondeo	2. 0L	Zetec	FFH	✓	✓	✓	✓	
1997	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1997	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	





1999	Mondeo	2.5L	Duratec-VE	ABS	✓	✓	✓	✓	
1999	Mondeo	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1999	Mondeo	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1999	Mondeo	2.5L	Duratec-VE	FFH	✓	✓	✓	✓	
1999	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
1999	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	
1999	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1999.75	Mondeo	2.5L	Duratec-VE	ABS	✓	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	FFH	✓	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2000.25	Mondeo	1.8L	Zetec	ABS	✓	✓	✓	✓	
2000.25	Mondeo	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
2000.25	Mondeo	1.8L	Zetec	AFCM	✓	✓	✓	✓	
2000.25	Mondeo	1.8L	Zetec	CSM	✓	✓	✓	✓	
2000.25	Mondeo	1.8L	Zetec	PATS	✓	✓	✓	✓	
2000.25	Mondeo	1.8L	Zetec	PCM	✓	✓	✓	✓	0025
2000.5	Mondeo	2.0L	Zetec	ABS	✓	✓	✓	✓	
2000.5	Mondeo	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
2000.5	Mondeo	2.0L	Zetec	CSM	✓	✓	✓	✓	
2000.5	Mondeo	2.0L	Zetec	PATS	✓	✓	✓	✓	
2000.5	Mondeo	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2000.5	Mondeo	2.5L	Duratec-VE	ABS	✓	✓	✓	✓	
2000.5	Mondeo	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
2000.5	Mondeo	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
2000.5	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
2000.5	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
2000.5	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2001	Mondeo	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0032
2001	Mondeo	1.8L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	CSM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0008
2001	Mondeo	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0025
2001	Mondeo	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F027, F02D, F02F, F030, F03A, F09D, F09E, F09F, FOA0, FOA1, FOA2, FOA3, FOA4, FOA5
2001	Mondeo	1.8L	DURATEC-HE / I4	HEC	✓	✓	✓	✓	0005
2001	Mondeo	1.8L	DURATEC-HE / I4	LHID	✓	✓	✓	✓	0005, 0032
2001	Mondeo	1.8L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	PATS	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2001	Mondeo	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	RHID	✓	✓	✓	✓	0005
2001	Mondeo	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	ABS	✓	✓	✓	✓	0032
2001	Mondeo	1.8L	DURATEC-SCi	ABS/TCS	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	1.8L	DURATEC-SCi	ACM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	CDP	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	CSM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	EATC	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	GDM	✓	✓	✓	✓	0100
2001	Mondeo	1.8L	DURATEC-SCi	GEM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	HEC	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	LHID	✓	✓	✓	✓	0032
2001	Mondeo	1.8L	DURATEC-SCi	NAV	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	PATS	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	PCM	✓	✓	✓	✓	0025
2001	Mondeo	1.8L	DURATEC-SCi	RCM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	RETM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	RHID	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	SRM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0032
2001	Mondeo	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0032
2001	Mondeo	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	CSM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0008
2001	Mondeo	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F027, F02D, F02F, F030, F03A, F09D, F09E, F09F, FOA0, FOA1, FOA2, FOA3, FOA4, FOA5
2001	Mondeo	2.0L	DURATEC-HE / I4	HEC	✓	✓	✓	✓	0005
2001	Mondeo	2.0L	DURATEC-HE / I4	LHID	✓	✓	✓	✓	0005, 0032
2001	Mondeo	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	PATS	✓	✓	✓	✓	

2001	Mondeo	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2001	Mondeo	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	RHID	✓	✓	✓	✓	0005
2001	Mondeo	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	ABS	✓	✓	✓	✓	0008
2001	Mondeo	2.0L	DURATORQ DI	ABS/TCS	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	ACM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	CDP	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	CSM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	EATC	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	FFH	✓	✓	✓	✓	00CF
2001	Mondeo	2.0L	DURATORQ DI	FIP	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	GDM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	GDM	✓	✓	✓	✓	0100
2001	Mondeo	2.0L	DURATORQ DI	GEM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	HEC	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	LHID	✓	✓	✓	✓	0032
2001	Mondeo	2.0L	DURATORQ DI	NAV	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	PATS	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	PCM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	RCM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	RETM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	RHID	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	SRM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0032
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0032, 00CD
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0008
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	LHID	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	LHID	✓	✓	✓	✓	0032
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	PATS	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0008, 0032, 00CD, 00CD
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	00CD
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	RHID	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	00CD
2001	Mondeo	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008

2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	GSM	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	LHID	✓	✓	✓	✓	0032
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PATS	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RHID	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	0008
2001	Mondeo	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	0008, 0032
2001	Mondeo	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	2. 5L	Duratec-VE	ACM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	CDP	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	EATC	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	EATC	✓	✓	✓	✓	0008
2001	Mondeo	2. 5L	Duratec-VE	GDM	✓	✓	✓	✓	0100
2001	Mondeo	2. 5L	Duratec-VE	GEM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	HEC	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	LHID	✓	✓	✓	✓	0032
2001	Mondeo	2. 5L	Duratec-VE	NAV	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2001	Mondeo	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025, 00CD
2001	Mondeo	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	00CD
2001	Mondeo	2. 5L	Duratec-VE	RCM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	RETM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	RHID	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	SRM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	TCM	✓	✓	✓	✓	00CD
2001	Mondeo	3. 0L	Duratec SE	ABS	✓	✓	✓	✓	0008, 0032
2001	Mondeo	3. 0L	Duratec SE	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	3. 0L	Duratec SE	ACM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	CDP	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	CSM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	EATC	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	EATC	✓	✓	✓	✓	0008
2001	Mondeo	3. 0L	Duratec SE	GDM	✓	✓	✓	✓	0100
2001	Mondeo	3. 0L	Duratec SE	GEM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	HEC	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	LHID	✓	✓	✓	✓	0032
2001	Mondeo	3. 0L	Duratec SE	NAV	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	PATS	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	PCM	✓	✓	✓	✓	0025
2001	Mondeo	3. 0L	Duratec SE	RCM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	RETM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	RHID	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	SRM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	ABS	✓	✓	✓	✓	0008, 0032
2001	Mondeo	3. 0L	Duratec-ST	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	3. 0L	Duratec-ST	ACM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	CDP	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	CSM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	EATC	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	EATC	✓	✓	✓	✓	0008
2001	Mondeo	3. 0L	Duratec-ST	GDM	✓	✓	✓	✓	0100
2001	Mondeo	3. 0L	Duratec-ST	GEM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	HEC	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	LHID	✓	✓	✓	✓	0032

2001	Mondeo	3.0L	Duratec-ST	NAV	✓	✓	✓	✓	
2001	Mondeo	3.0L	Duratec-ST	PATS	✓	✓	✓	✓	
2001	Mondeo	3.0L	Duratec-ST	PCM	✓	✓	✓	✓	0025
2001	Mondeo	3.0L	Duratec-ST	RCM	✓	✓	✓	✓	
2001	Mondeo	3.0L	Duratec-ST	RETM	✓	✓	✓	✓	
2001	Mondeo	3.0L	Duratec-ST	RHID	✓	✓	✓	✓	
2001	Mondeo	3.0L	Duratec-ST	SRM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓		0008, 0012, 00F5, 010A, 020C
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓		00D4, 00D5, 00FE
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓		0046
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓		0151
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	GWM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓		013E
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0108
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G	✓	✓	✓		

2013	Mondeo	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SCM-H	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓		0008, 0012, 010A, 020C
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓		00D4, 00D5, 00FE
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓		0046
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓		0151
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GWM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓		013E
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0095, 0108
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-G	✓	✓	✓		

2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-H	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓		
Other	Mondeo	1.8L	Endura-DE	ABS	✓	✓	✓	✓	
Other	Mondeo	1.8L	Endura-DE	CSM	✓	✓	✓	✓	
Other	Mondeo	1.8L	Endura-DE	PATS			✓	✓	
Other	Mondeo	1.8L	Endura-DE	PATS	✓	✓	✓	✓	
2006	Montego	3.0L	4V	4X4	✓	✓	✓	✓	
2006	Montego	3.0L	4V	ABS	✓	✓	✓	✓	
2006	Montego	3.0L	4V	ABS	✓	✓	✓	✓	0005, 0008
2006	Montego	3.0L	4V	ACM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2006	Montego	3.0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2006	Montego	3.0L	4V	DSM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	DSM	✓	✓	✓	✓	0005
2006	Montego	3.0L	4V	EATC	✓	✓	✓	✓	
2006	Montego	3.0L	4V	GEM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	GEM	✓	✓	✓	✓	0005
2006	Montego	3.0L	4V	IC	✓	✓	✓	✓	
2006	Montego	3.0L	4V	IC	✓	✓	✓	✓	0005
2006	Montego	3.0L	4V	PAM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	PAM	✓	✓	✓	✓	006C
2006	Montego	3.0L	4V	PCM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	PCM	✓	✓	✓	✓	0025
2006	Montego	3.0L	4V	RCM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	RCM	✓	✓	✓	✓	0005, 000C, 006D
2006	Montego	3.0L	4V	RETM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	TCM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	4X4	✓	✓	✓	✓	
2007	Montego	3.0L	4V	ABS	✓	✓	✓	✓	
2007	Montego	3.0L	4V	ABS	✓	✓	✓	✓	0008
2007	Montego	3.0L	4V	ACM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Montego	3.0L	4V	DSM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	EATC	✓	✓	✓	✓	
2007	Montego	3.0L	4V	GEM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	IC	✓	✓	✓	✓	
2007	Montego	3.0L	4V	PAM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	PAM	✓	✓	✓	✓	006C
2007	Montego	3.0L	4V	PCM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	PCM	✓	✓	✓	✓	0025
2007	Montego	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0037
2007	Montego	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2007	Montego	3.0L	4V	RCM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	RCM	✓	✓	✓	✓	000C
2007	Montego	3.0L	4V	RETM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	SDARS	✓	✓	✓	✓	
2007	Montego	3.0L	4V	SDARS	✓	✓	✓	✓	0019
2007	Montego	3.0L	4V	TCM	✓	✓	✓	✓	
2004	Motorhome / Stripped Chassis / Step	6.8L	2V	ABS/TCS	✓	✓	✓	✓	0008
2004	Motorhome / Stripped Chassis / Step	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2006	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2006	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓	0008
2007	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2007	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓	0008
2008	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2008	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓	0008
2009	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2009	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2011	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓	
2011	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2011	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓	
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓	0008
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓	
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	PCM	✓	✓	✓	✓	0025
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2013	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓	
2013	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2013	Motorhome / Stripped Chassis / Step	6.8L	3V	PCM	✓	✓	✓	✓	0025
2013	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓	0012

2014	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2014	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Motorhome / Stripped Chassis / Step	Other	Other	ABS	✓	✓	✓	✓	
2014	Motorhome / Stripped Chassis / Step	Other	Other	IC	✓	✓	✓	✓	
1997	Mountaineer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓	
1997	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓	000E
1997	Mountaineer	5.0L	Other	GEM	✓	✓	✓	✓	0203
1997	Mountaineer	5.0L	Other	IAB	✓	✓	✓	✓	
1997	Mountaineer	5.0L	Other	PCM	✓	✓	✓	✓	0025
1997	Mountaineer	5.0L	Other	RAP	✓	✓	✓	✓	
1998	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
1998	Mountaineer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓	
1998	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
1998	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
1998	Mountaineer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
1998	Mountaineer	4.0L	V6 SOHC	IAB	✓	✓	✓	✓	
1998	Mountaineer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓	
1998	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
1998	Mountaineer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
1998	Mountaineer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓	
1998	Mountaineer	5.0L	Other	DSM	✓	✓	✓	✓	
1998	Mountaineer	5.0L	Other	EATC	✓	✓	✓	✓	
1998	Mountaineer	5.0L	Other	GEM	✓	✓	✓	✓	0203
1998	Mountaineer	5.0L	Other	IAB	✓	✓	✓	✓	
1998	Mountaineer	5.0L	Other	PATS	✓	✓	✓	✓	
1998	Mountaineer	5.0L	Other	PCM	✓	✓	✓	✓	0025
1998	Mountaineer	5.0L	Other	RAP	✓	✓	✓	✓	
1999	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
1999	Mountaineer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓	000E
1999	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
1999	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
1999	Mountaineer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
1999	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
1999	Mountaineer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓	
1999	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
1999	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
1999	Mountaineer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
1999	Mountaineer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓	000E
1999	Mountaineer	5.0L	Other	DSM	✓	✓	✓	✓	
1999	Mountaineer	5.0L	Other	EATC	✓	✓	✓	✓	
1999	Mountaineer	5.0L	Other	GEM	✓	✓	✓	✓	0005, 0203
1999	Mountaineer	5.0L	Other	IAB	✓	✓	✓	✓	
1999	Mountaineer	5.0L	Other	PAM	✓	✓	✓	✓	
1999	Mountaineer	5.0L	Other	PATS	✓	✓	✓	✓	
1999	Mountaineer	5.0L	Other	PCM	✓	✓	✓	✓	0005, 0008, 0025, 0028, 0031, 0033
1999	Mountaineer	5.0L	Other	RAP	✓	✓	✓	✓	0005, F044
2000	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2000	Mountaineer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓	000E
2000	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2000	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2000	Mountaineer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
2000	Mountaineer	4.0L	V6 SOHC	IAB	✓	✓	✓	✓	
2000	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2000	Mountaineer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓	
2000	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2000	Mountaineer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
2000	Mountaineer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0005, 0008
2000	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓	000E
2000	Mountaineer	5.0L	Other	DSM	✓	✓	✓	✓	
2000	Mountaineer	5.0L	Other	EATC	✓	✓	✓	✓	
2000	Mountaineer	5.0L	Other	GEM	✓	✓	✓	✓	0005, 0203
2000	Mountaineer	5.0L	Other	IAB	✓	✓	✓	✓	
2000	Mountaineer	5.0L	Other	PAM	✓	✓	✓	✓	
2000	Mountaineer	5.0L	Other	PATS	✓	✓	✓	✓	
2000	Mountaineer	5.0L	Other	PCM	✓	✓	✓	✓	0005, 0008, 0025, 0028, 0031, 0033
2000	Mountaineer	5.0L	Other	RAP	✓	✓	✓	✓	0005, F044
2002	Mountaineer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2002	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2002	Mountaineer	4.0L	V6 SOHC	CSM	✓	✓	✓	✓	
2002	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2002	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2002	Mountaineer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
2002	Mountaineer	4.0L	V6 SOHC	IC	✓	✓	✓	✓	
2002	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2002	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Mountaineer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2002	Mountaineer	4.6L	2V	4X4	✓	✓	✓	✓	
2002	Mountaineer	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2002	Mountaineer	4.6L	2V	CSM	✓	✓	✓	✓	
2002	Mountaineer	4.6L	2V	DSM	✓	✓	✓	✓	
2002	Mountaineer	4.6L	2V	EATC	✓	✓	✓	✓	



2002	Mountaineer	4. 6L	2V	GEM	✓	✓	✓	✓	0203
2002	Mountaineer	4. 6L	2V	IC	✓	✓	✓	✓	
2002	Mountaineer	4. 6L	2V	PAM	✓	✓	✓	✓	
2002	Mountaineer	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Mountaineer	4. 6L	2V	RCM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	4X4	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2002. 5	Mountaineer	4. 0L	V6 SOHC	CSM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	DSM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	EATC	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	HEC	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	PAM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002. 5	Mountaineer	4. 0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2002. 5	Mountaineer	4. 0L	V6 SOHC	TPM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	4X4	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2002. 5	Mountaineer	4. 6L	2V	CSM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	DSM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	EATC	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	HEC	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	PAM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002. 5	Mountaineer	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2002. 5	Mountaineer	4. 6L	2V	TPM	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	4X4	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2003	Mountaineer	4. 0L	V6 SOHC	DSM	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	EATC	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	HEC	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	PAM	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Mountaineer	4. 0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2003	Mountaineer	4. 0L	V6 SOHC	TPM	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	VSM	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	4X4	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	Mountaineer	4. 6L	2V	DSM	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	EATC	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	HEC	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	PAM	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Mountaineer	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2003	Mountaineer	4. 6L	2V	TPM	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	VSM	✓	✓	✓	✓	
2004	Mountaineer	4. 0L	V6 SOHC	4X4	✓	✓	✓	✓	
2004	Mountaineer	4. 0L	V6 SOHC	ABS	✓	✓	✓	✓	0005, 0008, 0012
2004	Mountaineer	4. 0L	V6 SOHC	DSM	✓	✓	✓	✓	
2004	Mountaineer	4. 0L	V6 SOHC	EATC	✓	✓	✓	✓	0005
2004	Mountaineer	4. 0L	V6 SOHC	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054, F071, F072
2004	Mountaineer	4. 0L	V6 SOHC	PAM	✓	✓	✓	✓	
2004	Mountaineer	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Mountaineer	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2004	Mountaineer	4. 0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2004	Mountaineer	4. 0L	V6 SOHC	TPM	✓	✓	✓	✓	0005
2004	Mountaineer	4. 0L	V6 SOHC	VSM	✓	✓	✓	✓	
2004	Mountaineer	4. 6L	2V	4X4	✓	✓	✓	✓	
2004	Mountaineer	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2004	Mountaineer	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0012
2004	Mountaineer	4. 6L	2V	DSM	✓	✓	✓	✓	
2004	Mountaineer	4. 6L	2V	EATC	✓	✓	✓	✓	0005
2004	Mountaineer	4. 6L	2V	IC	✓	✓	✓	✓	0005
2004	Mountaineer	4. 6L	2V	PAM	✓	✓	✓	✓	
2004	Mountaineer	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Mountaineer	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2004	Mountaineer	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2004	Mountaineer	4. 6L	2V	TPM	✓	✓	✓	✓	0005
2004	Mountaineer	4. 6L	2V	VSM	✓	✓	✓	✓	
2005	Mountaineer	4. 0L	V6 SOHC	4X4	✓	✓	✓	✓	
2005	Mountaineer	4. 0L	V6 SOHC	4X4	✓	✓	✓	✓	0111
2005	Mountaineer	4. 0L	V6 SOHC	ABS	✓	✓	✓	✓	0005, 0008, 0012
2005	Mountaineer	4. 0L	V6 SOHC	DSM	✓	✓	✓	✓	
2005	Mountaineer	4. 0L	V6 SOHC	EATC	✓	✓	✓	✓	
2005	Mountaineer	4. 0L	V6 SOHC	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054, F071, F072
2005	Mountaineer	4. 0L	V6 SOHC	PAM	✓	✓	✓	✓	
2005	Mountaineer	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Mountaineer	4. 0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2005	Mountaineer	4. 0L	V6 SOHC	TPM	✓	✓	✓	✓	0005
2005	Mountaineer	4. 0L	V6 SOHC	VSM	✓	✓	✓	✓	
2005	Mountaineer	4. 6L	2V	4X4	✓	✓	✓	✓	
2005	Mountaineer	4. 6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2005	Mountaineer	4. 6L	2V	DSM	✓	✓	✓	✓	
2005	Mountaineer	4. 6L	2V	EATC	✓	✓	✓	✓	
2005	Mountaineer	4. 6L	2V	IC	✓	✓	✓	✓	
2005	Mountaineer	4. 6L	2V	PAM	✓	✓	✓	✓	

2005	Mountaineer	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Mountaineer	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2005	Mountaineer	4. 6L	2V	TPM	✓	✓	✓	✓	
2005	Mountaineer	4. 6L	2V	VSM	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2006	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2006	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2006	Mountaineer	4. 0L	2V	DSM	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	EATC	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	GEM	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2006	Mountaineer	4. 0L	2V	IC	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2006	Mountaineer	4. 0L	2V	PAM	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Mountaineer	4. 0L	2V	PRB	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2006	Mountaineer	4. 0L	2V	RET	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	RET	✓	✓	✓	✓	F04D, F05A
2006	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005, 0019
2006	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	0019
2006	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	0111
2006	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2006	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2006	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	EATC	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	EATC	✓	✓	✓	✓	0005
2006	Mountaineer	4. 6L	3V	GEM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	GEM	✓	✓	✓	✓	0005
2006	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2006	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2006	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Mountaineer	4. 6L	3V	PRB	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	0005
2006	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	0005
2006	Mountaineer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2006	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2007	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	
2007	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2007	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Mountaineer	4. 0L	2V	DSM	✓	✓	✓	✓	F041, F074, F075
2007	Mountaineer	4. 0L	2V	EATC	✓	✓	✓	✓	
2007	Mountaineer	4. 0L	2V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2007	Mountaineer	4. 0L	2V	IC	✓	✓	✓	✓	F027, F040, F044, F04D, F054, F06B
2007	Mountaineer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Mountaineer	4. 0L	2V	PAM	✓	✓	✓	✓	
2007	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Mountaineer	4. 0L	2V	PRB	✓	✓	✓	✓	
2007	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Mountaineer	4. 0L	2V	RET	✓	✓	✓	✓	F04D, F05A
2007	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	0111
2007	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2007	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	EATC	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	EATC	✓	✓	✓	✓	0005
2007	Mountaineer	4. 6L	3V	GEM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2007	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	F044
2007	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2007	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	

2007	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2007	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Mountaineer	4. 6L	3V	PRB	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	0005, F04D, F05A
2007	Mountaineer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2008	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	
2008	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2008	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2008	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Mountaineer	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2008	Mountaineer	4. 0L	2V	DSM	✓	✓	✓	✓	F041, F074, F075
2008	Mountaineer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2008	Mountaineer	4. 0L	2V	HVAC	✓	✓	✓	✓	
2008	Mountaineer	4. 0L	2V	IC	✓	✓	✓	✓	
2008	Mountaineer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Mountaineer	4. 0L	2V	PAM	✓	✓	✓	✓	
2008	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Mountaineer	4. 0L	2V	PRB	✓	✓	✓	✓	
2008	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2008	Mountaineer	4. 0L	2V	RET	✓	✓	✓	✓	F04D, F05A
2008	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005
2008	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	0111
2008	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2008	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018, F04D, F05A, F073
2008	Mountaineer	4. 6L	3V	APIM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2008	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	F041, F074, F075
2008	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2008	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042, F042, F044, F04C
2008	Mountaineer	4. 6L	3V	HVAC	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2008	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2008	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0028, 0031, 0031, 0033, 0031, 0033, 0033, 00C5
2008	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2008	Mountaineer	4. 6L	3V	PRB	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	F022, F05D
2008	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	F05A
2008	Mountaineer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2009	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2009	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2009	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0018
2009	Mountaineer	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2009	Mountaineer	4. 0L	2V	DSM	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	DSM	✓	✓	✓	✓	0005, F041, F074, F075
2009	Mountaineer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2009	Mountaineer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	Mountaineer	4. 0L	2V	HVAC	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	HVAC	✓	✓	✓	✓	0005
2009	Mountaineer	4. 0L	2V	IC	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	IC	✓	✓	✓	✓	0005, F044
2009	Mountaineer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Mountaineer	4. 0L	2V	PAM	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Mountaineer	4. 0L	2V	PRB	✓	✓	✓	✓	

2009	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Mountaineer	4. 0L	2V	RET	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	RET	✓	✓	✓	✓	F04D, F05A, F076
2009	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005
2009	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2009	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2009	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0018
2009	Mountaineer	4. 6L	3V	APIM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	0005, F041, F074, F075
2009	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2009	Mountaineer	4. 6L	3V	HVAC	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	HVAC	✓	✓	✓	✓	0005
2009	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2009	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2009	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2009	Mountaineer	4. 6L	3V	PRB	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	F04D, F05A, F076
2009	Mountaineer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2010	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2010	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2010	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0018
2010	Mountaineer	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2010	Mountaineer	4. 0L	2V	DSM	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0042
2010	Mountaineer	4. 0L	2V	GPSM	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	HVAC	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	IC	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Mountaineer	4. 0L	2V	PAM	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025
2010	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Mountaineer	4. 0L	2V	PRB	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	RET	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2010	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0018
2010	Mountaineer	4. 6L	3V	APIM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2010	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	0005, F041, F074, F075
2010	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2010	Mountaineer	4. 6L	3V	GPSM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	HVAC	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	HVAC	✓	✓	✓	✓	0005
2010	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2010	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2010	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2010	Mountaineer	4. 6L	3V	PRB	✓	✓	✓	✓	

2010	Mountaineer	4.6L	3V	RCM	✓	✓	✓	✓	
2010	Mountaineer	4.6L	3V	RETM	✓	✓	✓	✓	
2010	Mountaineer	4.6L	3V	RETM	✓	✓	✓	✓	F04D, F05A, F076
2010	Mountaineer	4.6L	3V	SDARS	✓	✓	✓	✓	
2010	Mountaineer	4.6L	3V	TCM	✓	✓	✓	✓	
2010	Mountaineer	4.6L	3V	TCM	✓	✓	✓	✓	00CE
1994	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1994	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
1995	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1995	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
1996	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1996	Mustang	3.8L	Other	IAB	✓	✓	✓	✓	
1996	Mustang	3.8L	Other	PATS	✓	✓	✓	✓	
1996	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
1996	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1996	Mustang	4.6L	2V	IAB	✓	✓	✓	✓	
1996	Mustang	4.6L	2V	PATS	✓	✓	✓	✓	
1996	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025
1996	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	
1996	Mustang	4.6L	4V	IAB	✓	✓	✓	✓	
1996	Mustang	4.6L	4V	PATS	✓	✓	✓	✓	
1996	Mustang	4.6L	4V	PCM	✓	✓	✓	✓	0025
1996	Mustang	4.6L	Other	ABS/TCS	✓	✓	✓	✓	
1996	Mustang	4.6L	Other	PATS	✓	✓	✓	✓	
1996	Mustang	4.6L	Other	PCM	✓	✓	✓	✓	0025
1997	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1997	Mustang	3.8L	Other	IAB	✓	✓	✓	✓	
1997	Mustang	3.8L	Other	PATS	✓	✓	✓	✓	
1997	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
1997	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1997	Mustang	4.6L	2V	IAB	✓	✓	✓	✓	
1997	Mustang	4.6L	2V	PATS	✓	✓	✓	✓	
1997	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025
1997	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	
1997	Mustang	4.6L	4V	IAB	✓	✓	✓	✓	
1997	Mustang	4.6L	4V	PATS	✓	✓	✓	✓	
1997	Mustang	4.6L	4V	PCM	✓	✓	✓	✓	0025
1997	Mustang	4.6L	Other	ABS/TCS	✓	✓	✓	✓	
1997	Mustang	4.6L	Other	PATS	✓	✓	✓	✓	
1997	Mustang	4.6L	Other	PCM	✓	✓	✓	✓	0025
1998	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Mustang	3.8L	Other	IAB	✓	✓	✓	✓	
1998	Mustang	3.8L	Other	PATS	✓	✓	✓	✓	
1998	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
1998	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1998	Mustang	4.6L	2V	IAB	✓	✓	✓	✓	
1998	Mustang	4.6L	2V	PATS	✓	✓	✓	✓	
1998	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025
1998	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1998	Mustang	4.6L	4V	IAB	✓	✓	✓	✓	
1998	Mustang	4.6L	4V	PATS	✓	✓	✓	✓	
1998	Mustang	4.6L	4V	PCM	✓	✓	✓	✓	0025
1999	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1999	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Mustang	3.8L	Other	GEM	✓	✓	✓	✓	
1999	Mustang	3.8L	Other	HEC	✓	✓	✓	✓	
1999	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
1999	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1999	Mustang	3.8L	Other	RCM	✓	✓	✓	✓	
1999	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1999	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1999	Mustang	4.6L	2V	GEM	✓	✓	✓	✓	
1999	Mustang	4.6L	2V	HEC	✓	✓	✓	✓	
1999	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025
1999	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1999	Mustang	4.6L	2V	RCM	✓	✓	✓	✓	
1999	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	
1999	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1999	Mustang	4.6L	4V	GEM	✓	✓	✓	✓	
1999	Mustang	4.6L	4V	HEC	✓	✓	✓	✓	
1999	Mustang	4.6L	4V	PCM	✓	✓	✓	✓	0025
1999	Mustang	4.6L	4V	RCM	✓	✓	✓	✓	
2000	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
2000	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Mustang	3.8L	Other	GEM	✓	✓	✓	✓	
2000	Mustang	3.8L	Other	HEC	✓	✓	✓	✓	
2000	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
2000	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Mustang	3.8L	Other	RCM	✓	✓	✓	✓	
2000	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
2000	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2000	Mustang	4.6L	2V	GEM	✓	✓	✓	✓	
2000	Mustang	4.6L	2V	HEC	✓	✓	✓	✓	
2000	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025
2000	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Mustang	4.6L	2V	RCM	✓	✓	✓	✓	
2000	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	
2000	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2000	Mustang	4.6L	4V	GEM	✓	✓	✓	✓	



2006	Mustang	4.0L	V6 SOHC	IC	✓	✓	✓	✓	
2006	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	
2006	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
2006	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Mustang	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2006	Mustang	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2006	Mustang	4.6L	3V	ABS	✓	✓	✓	✓	
2006	Mustang	4.6L	3V	ABS	✓	✓	✓	✓	0008
2006	Mustang	4.6L	3V	ACM	✓	✓	✓	✓	
2006	Mustang	4.6L	3V	GEM	✓	✓	✓	✓	
2006	Mustang	4.6L	3V	IC	✓	✓	✓	✓	
2006	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	
2006	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025
2006	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0031, 0033
2006	Mustang	4.6L	3V	RCM	✓	✓	✓	✓	000C
2007	Mustang	4.0L	V6 SOHC	ABS	✓	✓	✓	✓	
2007	Mustang	4.0L	V6 SOHC	ABS	✓	✓	✓	✓	0008
2007	Mustang	4.0L	V6 SOHC	ACM	✓	✓	✓	✓	0005
2007	Mustang	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0005
2007	Mustang	4.0L	V6 SOHC	IC	✓	✓	✓	✓	0005
2007	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0005, 0005, 0005
2007	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0019
2007	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0019, 0025
2007	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
2007	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Mustang	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2007	Mustang	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2007	Mustang	4.0L	V6 SOHC	SDARS	✓	✓	✓	✓	
2007	Mustang	4.0L	V6 SOHC	SDARS	✓	✓	✓	✓	0019
2007	Mustang	4.6L	3V	ABS	✓	✓	✓	✓	0008
2007	Mustang	4.6L	3V	ACM	✓	✓	✓	✓	
2007	Mustang	4.6L	3V	GEM	✓	✓	✓	✓	
2007	Mustang	4.6L	3V	IC	✓	✓	✓	✓	0005
2007	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0005, 0019
2007	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0005, 0019, 0019
2007	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0005, 0019, 0019, 0019, 0042
2007	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025
2007	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Mustang	4.6L	3V	RCM	✓	✓	✓	✓	000C
2007	Mustang	4.6L	3V	SDARS	✓	✓	✓	✓	
2007	Mustang	4.6L	3V	SDARS	✓	✓	✓	✓	0019
2007	Mustang	5.4L	4V	ABS	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	ABS	✓	✓	✓	✓	0008
2007	Mustang	5.4L	4V	ACM	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	GEM	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	IC	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	PCM	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	PCM	✓	✓	✓	✓	0019
2007	Mustang	5.4L	4V	PCM	✓	✓	✓	✓	0025
2007	Mustang	5.4L	4V	RCM	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	RCM	✓	✓	✓	✓	000C
2007	Mustang	5.4L	4V	SDARS	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	SDARS	✓	✓	✓	✓	0019
2008	Mustang	4.0L	V6 SOHC	ABS	✓	✓	✓	✓	0008
2008	Mustang	4.0L	V6 SOHC	ACM	✓	✓	✓	✓	
2008	Mustang	4.0L	V6 SOHC	GEM / SJB	✓	✓	✓	✓	0042
2008	Mustang	4.0L	V6 SOHC	IC	✓	✓	✓	✓	
2008	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0019, 0025, 0042
2008	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0019, 0028, 0042
2008	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0019, 0042
2008	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
2008	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Mustang	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2008	Mustang	4.0L	V6 SOHC	SDARS	✓	✓	✓	✓	0019
2008	Mustang	4.6L	3V	ABS	✓	✓	✓	✓	0008
2008	Mustang	4.6L	3V	ACM	✓	✓	✓	✓	
2008	Mustang	4.6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2008	Mustang	4.6L	3V	IC	✓	✓	✓	✓	
2008	Mustang	4.6L	3V	IC	✓	✓	✓	✓	0005
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0005, 0019, 0019, 0019, 0042
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0019, 0042
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Mustang	4.6L	3V	RCM	✓	✓	✓	✓	000C
2008	Mustang	4.6L	3V	SDARS	✓	✓	✓	✓	0019
2008	Mustang	5.4L	4V	ABS	✓	✓	✓	✓	0008
2008	Mustang	5.4L	4V	ACM	✓	✓	✓	✓	

2008	Mustang	5. 4L	4V	GEM / SJB	✓	✓	✓	✓	0042
2008	Mustang	5. 4L	4V	IC	✓	✓	✓	✓	
2008	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0019, 0025, 0042
2008	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0019, 0042
2008	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0025
2008	Mustang	5. 4L	4V	RCM	✓	✓	✓	✓	000C
2008	Mustang	5. 4L	4V	SDARS	✓	✓	✓	✓	0019
2009	Mustang	4. 0L	V6 SOHC	ABS	✓	✓	✓	✓	0008
2009	Mustang	4. 0L	V6 SOHC	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Mustang	4. 0L	V6 SOHC	APIM	✓	✓	✓	✓	
2009	Mustang	4. 0L	V6 SOHC	GEM / SJB	✓	✓	✓	✓	0042
2009	Mustang	4. 0L	V6 SOHC	IC	✓	✓	✓	✓	
2009	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0016, 0016, 0017, 0017, 0018, 0018, 0019, 0025, 0042
2009	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0016, 0016, 0017, 0017, 0018, 0018, 0019, 0028, 0042
2009	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0016, 0016, 0017, 0017, 0018, 0018, 0019, 0042
2009	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
2009	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Mustang	4. 0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2009	Mustang	4. 0L	V6 SOHC	SDARS	✓	✓	✓	✓	0019
2009	Mustang	4. 6L	3V	ABS	✓	✓	✓	✓	0008
2009	Mustang	4. 6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Mustang	4. 6L	3V	APIM	✓	✓	✓	✓	
2009	Mustang	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	Mustang	4. 6L	3V	IC	✓	✓	✓	✓	
2009	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0016, 0016, 0017, 0017, 0018, 0018, 0019, 0028, 0042
2009	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0016, 0016, 0017, 0017, 0018, 0018, 0019, 0042
2009	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0025
2009	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Mustang	4. 6L	3V	RCM	✓	✓	✓	✓	000C
2009	Mustang	4. 6L	3V	SDARS	✓	✓	✓	✓	0019
2009	Mustang	5. 4L	4V	ABS	✓	✓	✓	✓	0008
2009	Mustang	5. 4L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Mustang	5. 4L	4V	APIM	✓	✓	✓	✓	
2009	Mustang	5. 4L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Mustang	5. 4L	4V	IC	✓	✓	✓	✓	
2009	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0016, 0016, 0017, 0017, 0018, 0018, 0019, 0042
2009	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0025
2009	Mustang	5. 4L	4V	RCM	✓	✓	✓	✓	000C
2009	Mustang	5. 4L	4V	SDARS	✓	✓	✓	✓	0019
2010	Mustang	4. 0L	V6 SOHC	ABS	✓	✓	✓	✓	0012
2010	Mustang	4. 0L	V6 SOHC	ACM	✓	✓	✓	✓	0017, 0018
2010	Mustang	4. 0L	V6 SOHC	APIM	✓	✓	✓	✓	0019
2010	Mustang	4. 0L	V6 SOHC	BCM-B	✓	✓	✓	✓	0109
2010	Mustang	4. 0L	V6 SOHC	FCIM	✓	✓	✓	✓	
2010	Mustang	4. 0L	V6 SOHC	FDIM	✓	✓	✓	✓	
2010	Mustang	4. 0L	V6 SOHC	GEM / SJB	✓	✓	✓	✓	0042
2010	Mustang	4. 0L	V6 SOHC	GPSM	✓	✓	✓	✓	
2010	Mustang	4. 0L	V6 SOHC	HVAC	✓	✓	✓	✓	
2010	Mustang	4. 0L	V6 SOHC	IPC	✓	✓	✓	✓	
2010	Mustang	4. 0L	V6 SOHC	OCSM	✓	✓	✓	✓	000C
2010	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0017, 0017, 0018, 0018
2010	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
2010	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Mustang	4. 0L	V6 SOHC	RCM	✓	✓	✓	✓	
2010	Mustang	4. 6L	3V	ABS	✓	✓	✓	✓	0012
2010	Mustang	4. 6L	3V	ACM	✓	✓	✓	✓	0017, 0018
2010	Mustang	4. 6L	3V	APIM	✓	✓	✓	✓	0019
2010	Mustang	4. 6L	3V	BCM-B	✓	✓	✓	✓	0109
2010	Mustang	4. 6L	3V	FCIM	✓	✓	✓	✓	
2010	Mustang	4. 6L	3V	FDIM	✓	✓	✓	✓	
2010	Mustang	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2010	Mustang	4. 6L	3V	GPSM	✓	✓	✓	✓	
2010	Mustang	4. 6L	3V	HVAC	✓	✓	✓	✓	
2010	Mustang	4. 6L	3V	IPC	✓	✓	✓	✓	
2010	Mustang	4. 6L	3V	OCSM	✓	✓	✓	✓	000C
2010	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0012, 0017, 0017, 0018, 0018
2010	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0025
2010	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Mustang	4. 6L	3V	RCM	✓	✓	✓	✓	
2010	Mustang	5. 4L	4V	ABS	✓	✓	✓	✓	0012
2010	Mustang	5. 4L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Mustang	5. 4L	4V	APIM	✓	✓	✓	✓	0019
2010	Mustang	5. 4L	4V	BCM-B	✓	✓	✓	✓	0109
2010	Mustang	5. 4L	4V	FCIM	✓	✓	✓	✓	
2010	Mustang	5. 4L	4V	FDIM	✓	✓	✓	✓	



2010	Mustang	5. 4L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Mustang	5. 4L	4V	GPSM	✓	✓	✓	✓	
2010	Mustang	5. 4L	4V	HVAC	✓	✓	✓	✓	
2010	Mustang	5. 4L	4V	IPC	✓	✓	✓	✓	
2010	Mustang	5. 4L	4V	OCSM	✓	✓	✓	✓	000C
2010	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0017, 0017, 0018, 0018
2010	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0025
2010	Mustang	5. 4L	4V	RCM	✓	✓	✓	✓	
2011	Mustang	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0012
2011	Mustang	3. 7L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2011	Mustang	3. 7L	TiVCT	APIM	✓	✓	✓	✓	0019
2011	Mustang	3. 7L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2011	Mustang	3. 7L	TiVCT	FCIM	✓	✓	✓	✓	
2011	Mustang	3. 7L	TiVCT	FDIM	✓	✓	✓	✓	
2011	Mustang	3. 7L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2011	Mustang	3. 7L	TiVCT	GPSM	✓	✓	✓	✓	
2011	Mustang	3. 7L	TiVCT	HVAC	✓	✓	✓	✓	
2011	Mustang	3. 7L	TiVCT	IPC	✓	✓	✓	✓	
2011	Mustang	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 006D
2011	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018
2011	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2011	Mustang	3. 7L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2011	Mustang	3. 7L	TiVCT	RCM	✓	✓	✓	✓	
2011	Mustang	5. 0L	TiVCT	ABS	✓	✓	✓	✓	0012
2011	Mustang	5. 0L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2011	Mustang	5. 0L	TiVCT	APIM	✓	✓	✓	✓	0019
2011	Mustang	5. 0L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2011	Mustang	5. 0L	TiVCT	FCIM	✓	✓	✓	✓	
2011	Mustang	5. 0L	TiVCT	FDIM	✓	✓	✓	✓	
2011	Mustang	5. 0L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2011	Mustang	5. 0L	TiVCT	GPSM	✓	✓	✓	✓	
2011	Mustang	5. 0L	TiVCT	HVAC	✓	✓	✓	✓	
2011	Mustang	5. 0L	TiVCT	IPC	✓	✓	✓	✓	
2011	Mustang	5. 0L	TiVCT	OCSM	✓	✓	✓	✓	000C
2011	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018
2011	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0025, 0028, 0031, 0033, 0067, 00CB, 0109
2011	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2011	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2011	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2011	Mustang	5. 0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2011	Mustang	5. 0L	TiVCT	RCM	✓	✓	✓	✓	
2011	Mustang	5. 4L	4V	ABS	✓	✓	✓	✓	0012
2011	Mustang	5. 4L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Mustang	5. 4L	4V	APIM	✓	✓	✓	✓	0019
2011	Mustang	5. 4L	4V	BCM-B	✓	✓	✓	✓	0109
2011	Mustang	5. 4L	4V	FCIM	✓	✓	✓	✓	
2011	Mustang	5. 4L	4V	FDIM	✓	✓	✓	✓	
2011	Mustang	5. 4L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Mustang	5. 4L	4V	GPSM	✓	✓	✓	✓	
2011	Mustang	5. 4L	4V	HVAC	✓	✓	✓	✓	
2011	Mustang	5. 4L	4V	IPC	✓	✓	✓	✓	
2011	Mustang	5. 4L	4V	OCSM	✓	✓	✓	✓	000C
2011	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018
2011	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0025, 0028, 0031, 0033, 0067, 00CB
2011	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2011	Mustang	5. 4L	4V	PSCM	✓	✓	✓	✓	00CB
2011	Mustang	5. 4L	4V	RCM	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0012
2012	Mustang	3. 7L	TiVCT	ACM	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	APIM	✓	✓	✓	✓	0019
2012	Mustang	3. 7L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2012	Mustang	3. 7L	TiVCT	FCIM	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	FDIM	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2012	Mustang	3. 7L	TiVCT	GPSM	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	HVAC	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	IPC	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2012	Mustang	3. 7L	TiVCT	PAM	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2012	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0109
2012	Mustang	3. 7L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2012	Mustang	3. 7L	TiVCT	RCM	✓	✓	✓	✓	
2012	Mustang	5. 0L	BOSS	ABS	✓	✓	✓	✓	0012
2012	Mustang	5. 0L	BOSS	ACM	✓	✓	✓	✓	
2012	Mustang	5. 0L	BOSS	APIM	✓	✓	✓	✓	0019
2012	Mustang	5. 0L	BOSS	BCM-B	✓	✓	✓	✓	0109
2012	Mustang	5. 0L	BOSS	FCIM	✓	✓	✓	✓	

2012	Mustang	5. 0L	BOSS	FDIM	✓	✓	✓	✓	
2012	Mustang	5. 0L	BOSS	GEM / SJB	✓	✓	✓	✓	0042
2012	Mustang	5. 0L	BOSS	GPSM	✓	✓	✓	✓	
2012	Mustang	5. 0L	BOSS	HVAC	✓	✓	✓	✓	
2012	Mustang	5. 0L	BOSS	IPC	✓	✓	✓	✓	00FA
2012	Mustang	5. 0L	BOSS	OCSM	✓	✓	✓	✓	000C
2012	Mustang	5. 0L	BOSS	PAM	✓	✓	✓	✓	
2012	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 00FA, 0109
2012	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	00FA, 0109
2012	Mustang	5. 0L	BOSS	PSCM	✓	✓	✓	✓	00CB
2012	Mustang	5. 0L	BOSS	RCM	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	ABS	✓	✓	✓	✓	0012
2012	Mustang	5. 0L	TiVCT	ACM	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	APIM	✓	✓	✓	✓	0019
2012	Mustang	5. 0L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2012	Mustang	5. 0L	TiVCT	FCIM	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	FDIM	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2012	Mustang	5. 0L	TiVCT	GPSM	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	HVAC	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	IPC	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	OCSM	✓	✓	✓	✓	000C
2012	Mustang	5. 0L	TiVCT	PAM	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0025, 0028, 0031, 0033, 0067, 00CB, 0109
2012	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2012	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2012	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0109
2012	Mustang	5. 0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2012	Mustang	5. 0L	TiVCT	RCM	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	ABS	✓	✓	✓	✓	0012
2012	Mustang	5. 4L	4V	ACM	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	APIM	✓	✓	✓	✓	0019
2012	Mustang	5. 4L	4V	BCM-B	✓	✓	✓	✓	0109
2012	Mustang	5. 4L	4V	FCIM	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	FDIM	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Mustang	5. 4L	4V	GPSM	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	HVAC	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	IPC	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	OCSM	✓	✓	✓	✓	000C
2012	Mustang	5. 4L	4V	PAM	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0109
2012	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	Mustang	5. 4L	4V	PSCM	✓	✓	✓	✓	00CB
2012	Mustang	5. 4L	4V	RCM	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0012
2013	Mustang	3. 7L	TiVCT	ACM	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	APIM	✓	✓	✓	✓	0019
2013	Mustang	3. 7L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2013	Mustang	3. 7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	FDIM	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2013	Mustang	3. 7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	IPC	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	Mustang	3. 7L	TiVCT	PAM	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 00CB, 0109
2013	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067, 00CB, 0109
2013	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2013	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0067
2013	Mustang	3. 7L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2013	Mustang	3. 7L	TiVCT	RCM	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	ABS	✓	✓	✓	✓	0012
2013	Mustang	5. 0L	BOSS	ACM	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	APIM	✓	✓	✓	✓	0019
2013	Mustang	5. 0L	BOSS	BCM-B	✓	✓	✓	✓	0109
2013	Mustang	5. 0L	BOSS	FCIM	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	FDIM	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	GEM / SJB	✓	✓	✓	✓	0042
2013	Mustang	5. 0L	BOSS	GPSM	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	HVAC	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	IPC	✓	✓	✓	✓	00FA
2013	Mustang	5. 0L	BOSS	OCSM	✓	✓	✓	✓	000C
2013	Mustang	5. 0L	BOSS	PAM	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	0025, 0033, 0067

2013	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	0025, 0033, 0067, 00FA, 0109
2013	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	0067
2013	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	00FA, 0109
2013	Mustang	5. 0L	BOSS	PSCM	✓	✓	✓	✓	00CB
2013	Mustang	5. 0L	BOSS	RCM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	Mustang	5. 0L	TiVCT	ABS	✓	✓	✓	✓	0012
2013	Mustang	5. 0L	TiVCT	ACM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	APIM	✓	✓	✓	✓	0019
2013	Mustang	5. 0L	TiVCT	BCM-B	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2013	Mustang	5. 0L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	FDIM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	GEM / SJB	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2013	Mustang	5. 0L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	IPC	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	Mustang	5. 0L	TiVCT	PAM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	PAM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025
2013	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2013	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0109
2013	Mustang	5. 0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2013	Mustang	5. 0L	TiVCT	RCM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	ABS	✓	✓	✓	✓	0012
2013	Mustang	5. 8L	4V	ACM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	APIM	✓	✓	✓	✓	0019
2013	Mustang	5. 8L	4V	BCM-B	✓	✓	✓	✓	0109
2013	Mustang	5. 8L	4V	FCIM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	FDIM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	GEM / SJB	✓	✓	✓	✓	0042
2013	Mustang	5. 8L	4V	GPSM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	HVAC	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	IPC	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	OCSM	✓	✓	✓	✓	000C
2013	Mustang	5. 8L	4V	PAM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	Mustang	5. 8L	4V	PCM	✓	✓	✓	✓	0109
2013	Mustang	5. 8L	4V	PSCM	✓	✓	✓	✓	00CB
2013	Mustang	5. 8L	4V	RCM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	VDM	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0012
2014	Mustang	3. 7L	TiVCT	ACM	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	APIM	✓	✓	✓	✓	0019
2014	Mustang	3. 7L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2014	Mustang	3. 7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	FDIM	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2014	Mustang	3. 7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	IPC	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Mustang	3. 7L	TiVCT	PAM	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 00CB, 0109
2014	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2014	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067, 00CB, 0109
2014	Mustang	3. 7L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2014	Mustang	3. 7L	TiVCT	RCM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	ABS	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	ABS	✓	✓	✓	✓	0012
2014	Mustang	5. 0L	TiVCT	ACM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	APIM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	APIM	✓	✓	✓	✓	0019
2014	Mustang	5. 0L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2014	Mustang	5. 0L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	FDIM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	GEM / SJB	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2014	Mustang	5. 0L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	IPC	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Mustang	5. 0L	TiVCT	PAM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025
2014	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2014	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067, 00CB, 0109
2014	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 00CB, 0109
2014	Mustang	5. 0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2014	Mustang	5. 0L	TiVCT	RCM	✓	✓	✓	✓	
2014	Mustang	Other	Other	ABS	✓	✓	✓	✓	

2014	Mustang	Other	Other	ACM	✓	✓	✓	✓	
2014	Mustang	Other	Other	APIM	✓	✓	✓	✓	
2014	Mustang	Other	Other	BCM-B	✓	✓	✓	✓	
2014	Mustang	Other	Other	FCIM	✓	✓	✓	✓	
2014	Mustang	Other	Other	FDIM	✓	✓	✓	✓	
2014	Mustang	Other	Other	GEM / SIB	✓	✓	✓	✓	
2014	Mustang	Other	Other	GPSM	✓	✓	✓	✓	
2014	Mustang	Other	Other	HVAC	✓	✓	✓	✓	
2014	Mustang	Other	Other	IPC	✓	✓	✓	✓	
2014	Mustang	Other	Other	OCSM	✓	✓	✓	✓	
2014	Mustang	Other	Other	PAM	✓	✓	✓	✓	
2014	Mustang	Other	Other	PCM	✓	✓	✓	✓	
2014	Mustang	Other	Other	PSCM	✓	✓	✓	✓	
2014	Mustang	Other	Other	RCM	✓	✓	✓	✓	
1996	Mystique	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1996	Mystique	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1996	Mystique	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
1996	Mystique	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1996	Mystique	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
1996	Mystique	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1997	Mystique	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1997	Mystique	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1997	Mystique	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1997	Mystique	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
1997	Mystique	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1997	Mystique	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
1997	Mystique	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1997	Mystique	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1998	Mystique	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1998	Mystique	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
1998	Mystique	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1998	Mystique	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1998	Mystique	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
1998	Mystique	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1998	Mystique	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
1998	Mystique	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
1998	Mystique	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1998	Mystique	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1999	Mystique	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
1999	Mystique	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1999	Mystique	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
1999	Mystique	2. 0L	Zetec	RCM	✓	✓	✓	✓	
1999	Mystique	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
1999	Mystique	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
1999	Mystique	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1999	Mystique	2. 5L	Duratec-VE	RCM	✓	✓	✓	✓	
2000	Mystique	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2000	Mystique	2. 0L	Zetec	GSM	✓	✓	✓	✓	
2000	Mystique	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
2000	Mystique	2. 0L	Zetec	RCM	✓	✓	✓	✓	
2000	Mystique	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
2000	Mystique	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
2000	Mystique	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2000	Mystique	2. 5L	Duratec-VE	RCM	✓	✓	✓	✓	
2008	NOVO KA	1. 0L	FFV	IC	✓	✓	✓	✓	
2008	NOVO KA	1. 0L	FFV	PCM	✓	✓	✓	✓	0025
2008	NOVO KA	1. 0L	FFV	RCM	✓	✓	✓	✓	
2008	NOVO KA	1. 0L	FFV	RKE	✓	✓	✓	✓	
2008	NOVO KA	1. 0L	Zetec Rocam	IC	✓	✓	✓	✓	
2008	NOVO KA	1. 0L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2008	NOVO KA	1. 0L	Zetec Rocam	RCM	✓	✓	✓	✓	
2008	NOVO KA	1. 0L	Zetec Rocam	RKE	✓	✓	✓	✓	
2008	NOVO KA	1. 6L	FFV	IC	✓	✓	✓	✓	
2008	NOVO KA	1. 6L	FFV	PCM	✓	✓	✓	✓	0025
2008	NOVO KA	1. 6L	FFV	RCM	✓	✓	✓	✓	
2008	NOVO KA	1. 6L	FFV	RKE	✓	✓	✓	✓	
2008	NOVO KA	1. 6L	Zetec Rocam	IC	✓	✓	✓	✓	
2008	NOVO KA	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2008	NOVO KA	1. 6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2008	NOVO KA	1. 6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2008	NOVO KA	Other	Other	IC	✓	✓	✓	✓	
2008	NOVO KA	Other	Other	PCM	✓	✓	✓	✓	0025
2008	NOVO KA	Other	Other	RCM	✓	✓	✓	✓	
2008	NOVO KA	Other	Other	RKE	✓	✓	✓	✓	
2009	NOVO KA	1. 0L	FFV	IC	✓	✓	✓	✓	
2009	NOVO KA	1. 0L	FFV	PCM	✓	✓	✓	✓	0025
2009	NOVO KA	1. 0L	FFV	RCM	✓	✓	✓	✓	
2009	NOVO KA	1. 0L	FFV	RKE	✓	✓	✓	✓	
2009	NOVO KA	1. 0L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	NOVO KA	1. 0L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	NOVO KA	1. 0L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2009	NOVO KA	1. 0L	Zetec Rocam	RCM	✓	✓	✓	✓	
2009	NOVO KA	1. 0L	Zetec Rocam	RKE	✓	✓	✓	✓	
2009	NOVO KA	1. 0L	Zetec Rocam	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	NOVO KA	1. 6L	FFV	IC	✓	✓	✓	✓	
2009	NOVO KA	1. 6L	FFV	PCM	✓	✓	✓	✓	0025
2009	NOVO KA	1. 6L	FFV	RCM	✓	✓	✓	✓	
2009	NOVO KA	1. 6L	FFV	RKE	✓	✓	✓	✓	
2009	NOVO KA	1. 6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3

2009	NOVO KA	1. 6L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	NOVO KA	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	
2009	NOVO KA	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2009	NOVO KA	1. 6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2009	NOVO KA	1. 6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2009	NOVO KA	1. 6L	Zetec Rocam	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	NOVO KA	1. 0L	FFV	IC	✓	✓	✓	✓	
2011	NOVO KA	1. 0L	FFV	PCM	✓	✓	✓	✓	012E
2011	NOVO KA	1. 0L	FFV	RCM	✓	✓	✓	✓	
2011	NOVO KA	1. 0L	FFV	RKE	✓	✓	✓	✓	
2011	NOVO KA	1. 0L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	NOVO KA	1. 6L	FFV	IC	✓	✓	✓	✓	
2011	NOVO KA	1. 6L	FFV	PCM	✓	✓	✓	✓	012E
2011	NOVO KA	1. 6L	FFV	RCM	✓	✓	✓	✓	
2011	NOVO KA	1. 6L	FFV	RKE	✓	✓	✓	✓	
2011	NOVO KA	1. 6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
1998	Navigator	5. 4L	Other	4WAS	✓	✓	✓	✓	
1998	Navigator	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Navigator	5. 4L	Other	DSM	✓	✓	✓	✓	
1998	Navigator	5. 4L	Other	GEM	✓	✓	✓	✓	
1998	Navigator	5. 4L	Other	IAB	✓	✓	✓	✓	
1998	Navigator	5. 4L	Other	PATS	✓	✓	✓	✓	
1998	Navigator	5. 4L	Other	PCM	✓	✓	✓	✓	0025
1998	Navigator	5. 4L	Other	RAP	✓	✓	✓	✓	
1998	Navigator	5. 4L	Other	RCC	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	4WAS	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	4WAS	✓	✓	✓	✓	000E
1999	Navigator	5. 4L	4V	ABS/TCS	✓	✓	✓	✓	0008
1999	Navigator	5. 4L	4V	DSM	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	EATC	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	GEM	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	HEC	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	0025
1999	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1999	Navigator	5. 4L	4V	RAP	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	RCM	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	4WAS	✓	✓	✓	✓	000E
2000	Navigator	5. 4L	4V	ABS/TCS	✓	✓	✓	✓	0008
2000	Navigator	5. 4L	4V	DSM	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	EATC	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	GEM	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	HEC	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	PAM	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Navigator	5. 4L	4V	RAP	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	RCM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	4X4	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Navigator	5. 4L	4V	DCSM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	DSM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	EATC	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	HEC	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	LTM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	NAV	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	PAM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	000E, 0013, 0014, 0025, 0028, 0031, 0033
2003	Navigator	5. 4L	4V	PCSM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	RCM	✓	✓	✓	✓	000C
2003	Navigator	5. 4L	4V	TPM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2003	Navigator	5. 4L	4V	VSM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	4X4	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	ABS/TCS	✓	✓	✓	✓	0008
2004	Navigator	5. 4L	4V	DCSM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	DSM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	EATC	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	HEC	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	LTM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	NAV	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	PAM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	000E, 0013, 0014, 0025, 0028, 0031, 0033
2004	Navigator	5. 4L	4V	PCSM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	RCM	✓	✓	✓	✓	000C
2004	Navigator	5. 4L	4V	TPM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2004	Navigator	5. 4L	4V	VSM	✓	✓	✓	✓	
2005	Navigator	5. 4L	3V	4X4	✓	✓	✓	✓	
2005	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	
2005	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2005	Navigator	5. 4L	3V	DCSM	✓	✓	✓	✓	
2005	Navigator	5. 4L	3V	DSM	✓	✓	✓	✓	
2005	Navigator	5. 4L	3V	DSM	✓	✓	✓	✓	F041
2005	Navigator	5. 4L	3V	EATC	✓	✓	✓	✓	
2005	Navigator	5. 4L	3V	EATC	✓	✓	✓	✓	0005
2005	Navigator	5. 4L	3V	IC	✓	✓	✓	✓	

2005	Navigator	5.4L	3V	LTM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	LTM	✓	✓	✓	✓	0005
2005	Navigator	5.4L	3V	NAV	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	NAV	✓	✓	✓	✓	0016
2005	Navigator	5.4L	3V	PAM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0005, F041
2005	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2005	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	F041
2005	Navigator	5.4L	3V	RCM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	RCM	✓	✓	✓	✓	000C
2005	Navigator	5.4L	3V	TCM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	TCM	✓	✓	✓	✓	00C5
2005	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2005	Navigator	5.4L	3V	VSM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	VSM	✓	✓	✓	✓	0005, F044
2005	Navigator	5.4L	3V	VSM	✓	✓	✓	✓	F044
2006	Navigator	5.4L	3V	4X4	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	ABS	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2006	Navigator	5.4L	3V	DCSM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	DSM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	DSM	✓	✓	✓	✓	F041
2006	Navigator	5.4L	3V	EATC	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	EATC	✓	✓	✓	✓	0005
2006	Navigator	5.4L	3V	IC	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	IC	✓	✓	✓	✓	0005
2006	Navigator	5.4L	3V	LTM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	LTM	✓	✓	✓	✓	0005
2006	Navigator	5.4L	3V	NAV	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	NAV	✓	✓	✓	✓	0016
2006	Navigator	5.4L	3V	PAM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0005
2006	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0005, F041
2006	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2006	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Navigator	5.4L	3V	RCM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	RCM	✓	✓	✓	✓	000C
2006	Navigator	5.4L	3V	TCM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2006	Navigator	5.4L	3V	VSM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	VSM	✓	✓	✓	✓	0005
2006	Navigator	5.4L	3V	VSM	✓	✓	✓	✓	0005, F044
2007	Navigator	5.4L	3V	4X4	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	ABS	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2007	Navigator	5.4L	3V	ACM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F063
2007	Navigator	5.4L	3V	DCSM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	DCSM	✓	✓	✓	✓	F070
2007	Navigator	5.4L	3V	DSM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	DSM	✓	✓	✓	✓	0005, F041, F06C, F06D, F06F
2007	Navigator	5.4L	3V	DSM	✓	✓	✓	✓	F041, F06C, F06D, F06F
2007	Navigator	5.4L	3V	DSP	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	DSP	✓	✓	✓	✓	0005
2007	Navigator	5.4L	3V	EATC	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	GEM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	GEM	✓	✓	✓	✓	F042, F049, F04B, F04C, F05C, F060
2007	Navigator	5.4L	3V	IC	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	IC	✓	✓	✓	✓	0005, F027, F041, F044, F04A, F04C, F04D, F06B, F06E
2007	Navigator	5.4L	3V	IC	✓	✓	✓	✓	F027, F041, F044, F04A, F04C, F04D, F06B, F06E
2007	Navigator	5.4L	3V	LTM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	PAM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0005, 0005, 0005, 0005, 0016, 0016, 0016, 0017, 0017, 0017, 0018, 0018, 0018, 0019, 0025, 0028, 0031, 0033, 00C5, F04D, F05A, F05A, F063, F063, F063

2007	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0005, 0005, 0005, 0016, 0016, 0016, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0019, 0025, 0028, 0031, 0033, 00C5, F04D, F05A, F05A, F063, F063, F063
2007	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Navigator	5. 4L	3V	PRB	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	RCM	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Navigator	5. 4L	3V	RCM	✓	✓	✓	✓	F022, F05D
2007	Navigator	5. 4L	3V	RCU	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	RCU	✓	✓	✓	✓	F05A
2007	Navigator	5. 4L	3V	RETM	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	RETM	✓	✓	✓	✓	0005, F04D, F05A
2007	Navigator	5. 4L	3V	SDARS	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Navigator	5. 4L	3V	SDARS	✓	✓	✓	✓	0019
2007	Navigator	5. 4L	3V	TCM	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	VDM	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2008	Navigator	5. 4L	3V	4X4	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2008	Navigator	5. 4L	3V	ACM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F063
2008	Navigator	5. 4L	3V	APIM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2008	Navigator	5. 4L	3V	DCSM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	DCSM	✓	✓	✓	✓	F070
2008	Navigator	5. 4L	3V	DSM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	DSM	✓	✓	✓	✓	0005
2008	Navigator	5. 4L	3V	DSP	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	DSP	✓	✓	✓	✓	0005
2008	Navigator	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	HVAC	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	IC	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	IC	✓	✓	✓	✓	0005
2008	Navigator	5. 4L	3V	LTM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	PAM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0005, 0005, 0005, 0005, 0016, 0016, 0016, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0019, 0025, 0028, 0031, 0033, 00C5, F04D, F05A, F05A, F063, F063, F063
2008	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0005, 0005, 0005, 0016, 0016, 0016, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0019, 0025, 0028, 0031, 0033, 00C5, F04D, F05A, F05A, F063, F063, F063
2008	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Navigator	5. 4L	3V	PRB	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	RCM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	RCM	✓	✓	✓	✓	0005
2008	Navigator	5. 4L	3V	RCU	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	RCU	✓	✓	✓	✓	F05A
2008	Navigator	5. 4L	3V	RETM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	RETM	✓	✓	✓	✓	0005, F04D, F05A
2008	Navigator	5. 4L	3V	SDARS	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	SDARS	✓	✓	✓	✓	0005
2008	Navigator	5. 4L	3V	TCM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	VDM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2009	Navigator	5. 4L	3V	4X4	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012, 0067
2009	Navigator	5. 4L	3V	ACM	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Navigator	5. 4L	3V	APIM	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Navigator	5. 4L	3V	DCSM	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	DSM	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	DSP	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	Navigator	5. 4L	3V	HVAC	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	IC	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	LTM	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	PAM	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	





2012	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0018, 0025, 0028, 0028, 0031, 0031, 0033, 0067, 0108
2012	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025
2012	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2012	Navigator	5.4L	3V	PRB	✓	✓	✓	✓	
2012	Navigator	5.4L	3V	RCM	✓	✓	✓	✓	
2012	Navigator	5.4L	3V	RCU	✓	✓	✓	✓	
2012	Navigator	5.4L	3V	RCU	✓	✓	✓	✓	
2012	Navigator	5.4L	3V	RETM	✓	✓	✓	✓	
2012	Navigator	5.4L	3V	SDARS	✓	✓	✓	✓	
2012	Navigator	5.4L	3V	TCCM	✓	✓	✓	✓	
2012	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	
2012	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2013	Navigator	5.4L	3V	ABS	✓	✓	✓	✓	0012
2013	Navigator	5.4L	3V	ACM	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2013	Navigator	5.4L	3V	APIM	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	APIM	✓	✓	✓	✓	0019
2013	Navigator	5.4L	3V	DCSM	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	DSM	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	DSP	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2013	Navigator	5.4L	3V	GPSM	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	HVAC	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	IC	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	LTM	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	PAM	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0018, 0025, 0028, 0028, 0031, 0031, 0033, 0067, 0108
2013	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033
2013	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	Navigator	5.4L	3V	PRB	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	RCM	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	RCU	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	SDARS	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	TBC	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	TCCM	✓	✓	✓	✓	
2013	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2013	Navigator	Other	Other	ABS	✓	✓	✓	✓	
2013	Navigator	Other	Other	ACM	✓	✓	✓	✓	
2013	Navigator	Other	Other	APIM	✓	✓	✓	✓	
2013	Navigator	Other	Other	DCSM	✓	✓	✓	✓	
2013	Navigator	Other	Other	DSM	✓	✓	✓	✓	
2013	Navigator	Other	Other	DSP	✓	✓	✓	✓	
2013	Navigator	Other	Other	GEM / SJB	✓	✓	✓	✓	
2013	Navigator	Other	Other	GPSM	✓	✓	✓	✓	
2013	Navigator	Other	Other	HVAC	✓	✓	✓	✓	
2013	Navigator	Other	Other	IC	✓	✓	✓	✓	
2013	Navigator	Other	Other	LTM	✓	✓	✓	✓	
2013	Navigator	Other	Other	PAM	✓	✓	✓	✓	
2013	Navigator	Other	Other	PCM	✓	✓	✓	✓	
2013	Navigator	Other	Other	PCM	✓	✓	✓	✓	
2013	Navigator	Other	Other	PRB	✓	✓	✓	✓	
2013	Navigator	Other	Other	RCM	✓	✓	✓	✓	
2013	Navigator	Other	Other	RCU	✓	✓	✓	✓	
2013	Navigator	Other	Other	SDARS	✓	✓	✓	✓	
2013	Navigator	Other	Other	TBC	✓	✓	✓	✓	
2013	Navigator	Other	Other	TCCM	✓	✓	✓	✓	
2013	Navigator	Other	Other	VDM	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2014	Navigator	5.4L	3V	ABS	✓	✓	✓	✓	0012
2014	Navigator	5.4L	3V	ACM	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2014	Navigator	5.4L	3V	APIM	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	APIM	✓	✓	✓	✓	0019
2014	Navigator	5.4L	3V	DCSM	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	DSM	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	DSP	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2014	Navigator	5.4L	3V	GPSM	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	HVAC	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	IC	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	LTM	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	PAM	✓	✓	✓	✓	

2014	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0018, 0025, 0028, 0028, 0031, 0031, 0033, 0067, 0108
2014	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025
2014	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033
2014	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Navigator	5.4L	3V	PRB	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	RCM	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	RCU	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	SDARS	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	TBC	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	TCCM	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2007	Navigator L	5.4L	3V	4X4	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2007	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	DSM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	DSP	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	EATC	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	GEM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	IC	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	LTM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	PAM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Navigator L	5.4L	3V	PRB	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	RCM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	RCU	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	RET	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	SDARS	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	SDARS	✓	✓	✓	✓	0019
2007	Navigator L	5.4L	3V	TCM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2008	Navigator L	5.4L	3V	4X4	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2008	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2008	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	DSM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	DSP	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	HVAC	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	IC	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	LTM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	PAM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Navigator L	5.4L	3V	PRB	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	RCM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	RCU	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	RET	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	SDARS	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	TCM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2009	Navigator L	5.4L	3V	4X4	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012, 0067
2009	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	0016
2009	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	DSM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	DSP	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	Navigator L	5.4L	3V	HVAC	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	IC	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	LTM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	PAM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	0067
2009	Navigator L	5.4L	3V	PRB	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	RCM	✓	✓	✓	✓	



2012	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓	
2012	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2013	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	0012
2013	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2013	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓	0019
2013	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	DSP	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	DSP	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2013	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	GPSM	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	HVAC	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	IC	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	LTM	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	LTM	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	PAM	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	Navigator L	5.4L	3V	PRB	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	RCM	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	RCU	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	SDARS	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	TBC	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	TCCM	✓	✓	✓	✓	
2013	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2013	Navigator L	Other	Other	ABS	✓	✓	✓	✓	
2013	Navigator L	Other	Other	ACM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	APIM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	DCSM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	DCSM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	DCSM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	DCSM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	DSP	✓	✓	✓	✓	
2013	Navigator L	Other	Other	DSP	✓	✓	✓	✓	
2013	Navigator L	Other	Other	GEM / SJB	✓	✓	✓	✓	
2013	Navigator L	Other	Other	GEM / SJB	✓	✓	✓	✓	
2013	Navigator L	Other	Other	GPSM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	HVAC	✓	✓	✓	✓	
2013	Navigator L	Other	Other	IC	✓	✓	✓	✓	
2013	Navigator L	Other	Other	IC	✓	✓	✓	✓	
2013	Navigator L	Other	Other	LTM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	LTM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	PAM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	PCM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	PRB	✓	✓	✓	✓	
2013	Navigator L	Other	Other	RCM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	RCU	✓	✓	✓	✓	
2013	Navigator L	Other	Other	SDARS	✓	✓	✓	✓	
2013	Navigator L	Other	Other	TBC	✓	✓	✓	✓	
2013	Navigator L	Other	Other	TCCM	✓	✓	✓	✓	
2013	Navigator L	Other	Other	VDM	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	0012
2014	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2014	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓	0019
2014	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	DSP	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	DSP	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2014	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	GPSM	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	HVAC	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	HVAC	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	IC	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	IC	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	LTM	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	LTM	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	PAM	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Navigator L	5.4L	3V	PRB	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	RCM	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	RCU	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	SDARS	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	TBC	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	TCCM	✓	✓	✓	✓	
2014	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
1999	PREMACY / IXION	1.8L	FP	ABS	✓	✓	✓	✓	
1999	PREMACY / IXION	1.8L	FP	PCM	✓	✓	✓	✓	
1999	PREMACY / IXION	1.8L	FP DE	ABS	✓	✓	✓	✓	
1999	PREMACY / IXION	1.8L	FP DE	PCM	✓	✓	✓	✓	
1999	PREMACY / IXION	2.0L	RF-T	ABS	✓	✓	✓	✓	
1999	PREMACY / IXION	2.0L	RF-T	PCM	✓	✓	✓	✓	
2001	PREMACY / IXION	2.0L	FS	ABS/TCS	✓	✓	✓	✓	
2001	PREMACY / IXION	2.0L	FS	PCM	✓	✓	✓	✓	
2002	PREMACY / IXION	1.8L	FP	ABS/TCS	✓	✓	✓	✓	
2002	PREMACY / IXION	1.8L	FP	PCM	✓	✓	✓	✓	
1996	PROBE / MX-6	2.0L	Other	PCM	✓	✓	✓	✓	0025
1996	PROBE / MX-6	2.5L	KL	PCM	✓	✓	✓	✓	
1997	PROBE / MX-6	2.0L	Other	PCM	✓	✓	✓	✓	0025
1997	PROBE / MX-6	2.0L	Other	PCM	✓	✓	✓	✓	0025, 0025
1997	PROBE / MX-6	2.5L	KL	PCM	✓	✓	✓	✓	
1997.5	Puma	1.7L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1997.5	Puma	1.7L	Zetec-SE	HEC	✓	✓	✓	✓	
1997.5	Puma	1.7L	Zetec-SE	PATS	✓	✓	✓	✓	
1997.5	Puma	1.7L	Zetec-SE	PCM	✓	✓	✓	✓	0025

1998.5	Puma	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1998.5	Puma	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
1998.5	Puma	1.4L	Zetec-SE	PATS			✓	✓	
1998.5	Puma	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1999.5	Puma	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1999.5	Puma	1.4L	Zetec-SE	GEM	✓	✓	✓	✓	
1999.5	Puma	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
1999.5	Puma	1.4L	Zetec-SE	PATS			✓	✓	
1999.5	Puma	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1999.5	Puma	1.7L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1999.5	Puma	1.7L	Zetec-SE	GEM	✓	✓	✓	✓	
1999.5	Puma	1.7L	Zetec-SE	HEC	✓	✓	✓	✓	
1999.5	Puma	1.7L	Zetec-SE	PATS	✓	✓	✓	✓	
1999.5	Puma	1.7L	Zetec-SE	PCM	✓	✓	✓	✓	0025
2001	Puma	1.6L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
2001	Puma	1.6L	Zetec-SE	GEM	✓	✓	✓	✓	
2001	Puma	1.6L	Zetec-SE	HEC	✓	✓	✓	✓	
2001	Puma	1.6L	Zetec-SE	PATS	✓	✓	✓	✓	
2001	Puma	1.6L	Zetec-SE	PCM	✓	✓	✓	✓	0025
2001	Puma	1.7L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
2001	Puma	1.7L	Zetec-SE	GEM	✓	✓	✓	✓	
2001	Puma	1.7L	Zetec-SE	HEC	✓	✓	✓	✓	
2001	Puma	1.7L	Zetec-SE	PATS	✓	✓	✓	✓	
2001	Puma	1.7L	Zetec-SE	PCM	✓	✓	✓	✓	0025
2000	ROADSTER / MX-5	1.6L	B6	ABS	✓	✓	✓	✓	
2000	ROADSTER / MX-5	1.8L	BP	ABS	✓	✓	✓	✓	
2002	ROADSTER / MX-5	1.6L	B6	ABS/TCS	✓	✓	✓	✓	
2002	ROADSTER / MX-5	1.6L	B6	PCM	✓	✓	✓	✓	
2002	ROADSTER / MX-5	1.8L	BP	ABS/TCS	✓	✓	✓	✓	
2002	ROADSTER / MX-5	1.8L	BP	PCM	✓	✓	✓	✓	
2003	ROADSTER / MX-5	1.8L	BP Turbo	ABS/TCS	✓	✓	✓	✓	
2003	ROADSTER / MX-5	1.8L	BP Turbo	PCM	✓	✓	✓	✓	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	ABS	✓	✓	✓	✓	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	ABS	✓	✓	✓	✓	001E
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	IC	✓	✓	✓		
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	PCM	✓	✓	✓	✓	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RCM	✓	✓	✓	✓	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RHT	✓	✓	✓	✓	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RKE	✓	✓	✓	✓	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	TCM	✓	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	ABS	✓	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	ABS	✓	✓	✓	✓	001E
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	IC	✓	✓	✓		
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	PCM	✓	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RCM	✓	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RHT	✓	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RKE	✓	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	TCM	✓	✓	✓	✓	
2005.5	Ranger	3.0L	I4 DSL Electronic	4X4	✓	✓	✓	✓	
2005.5	Ranger	3.0L	I4 DSL Electronic	ABS/TCS	✓	✓	✓	✓	0008
2005.5	Ranger	3.0L	I4 DSL Electronic	GEM	✓	✓	✓	✓	0063
2005.5	Ranger	3.0L	I4 DSL Electronic	IC	✓	✓	✓	✓	
2005.5	Ranger	3.0L	I4 DSL Electronic	PCM	✓	✓	✓	✓	
2005.5	Ranger	3.0L	I4 DSL Electronic	RCM	✓	✓	✓	✓	
2005.5	Ranger	3.0L	I4 DSL Electronic	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2006	Ranger	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2006	Ranger	2.3L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008
2006	Ranger	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Ranger	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Ranger	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	Ranger	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2009.5	Ranger	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2009.5	Ranger	2.3L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008
2009.5	Ranger	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0063
2009.5	Ranger	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2009.5	Ranger	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2009.5	Ranger	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2009.5	Ranger	2.3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2003	Ranger / Courier / Mazda B Series /Bravo	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2003	Ranger / Courier / Mazda B Series /Bravo	4.0L	V6 SOHC	ESOF	✓	✓	✓	✓	













2011	Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 001E, 00CA
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	00D5
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00B0, 00B1, 00B3, 00BC, 00BD, 00C1, 00E7, 0133
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	TBM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	ABS	✓	✓	✓	✓	0008, 0012
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	GEM / SJB	✓	✓	✓	✓	0042
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	IC	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	OCSM	✓	✓	✓	✓	000C
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0008, 0012, 0019, 0042
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	SDARS	✓	✓	✓	✓	0019
2011	Ranger / Mazda B-Series / Courier	Other	Other	ABS	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	ABS	✓	✓	✓	✓	00CA
2011	Ranger / Mazda B-Series / Courier	Other	Other	ACM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	BCMii	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	DDM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	FCDIM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	HVAC	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	IPC	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	PAM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	PDM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	RCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	SRM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Ranger / Mazda B-Series / Courier	Other	Other	TCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	TRM	✓	✓	✓	✓	
2007	S. A. Courier	1.6L	FFV	PCM	✓	✓	✓	✓	0025
2009	S. A. Courier	1.6L	FFV	IC	✓	✓	✓	✓	
2009	S. A. Courier	1.6L	FFV	PCM	✓	✓	✓	✓	0025
2009	S. A. Courier	1.6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	S. A. Courier	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	S. A. Courier	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2009	S. A. Courier	1.6L	Zetec Rocam	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	S. A. Courier	1.6L	FFV	IC	✓	✓	✓	✓	
2011	S. A. Courier	1.6L	FFV	PCM	✓	✓	✓	✓	012E
2011	S. A. Courier	1.6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2002.5	S. A. Fiesta	1.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008
2002.5	S. A. Fiesta	1.0L	Zetec Rocam	IC	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.0L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2002.5	S. A. Fiesta	1.0L	Zetec Rocam	RCM	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.0L	Zetec Rocam	RKE	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2002.5	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	

2002.5	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓		
2002.5	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2002.5	S. A. Fiesta	1.6L	FFV	IC	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2002.5	S. A. Fiesta	1.6L	FFV	RCM	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	FFV	RKE	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008
2002.5	S. A. Fiesta	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2002.5	S. A. Fiesta	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2006	S. A. Fiesta	1.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2006	S. A. Fiesta	1.0L	FFV	ABS/TCS	✓	✓	✓	✓	000B
2006	S. A. Fiesta	1.0L	FFV	IC	✓	✓	✓	✓	
2006	S. A. Fiesta	1.0L	FFV	PCM	✓	✓	✓	✓	0025
2006	S. A. Fiesta	1.0L	FFV	RCM	✓	✓	✓	✓	
2006	S. A. Fiesta	1.0L	FFV	RKE	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2006	S. A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	000B
2006	S. A. Fiesta	1.6L	FFV	IC	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2006	S. A. Fiesta	1.6L	FFV	RCM	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	FFV	RKE	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008
2006	S. A. Fiesta	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2006	S. A. Fiesta	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	Zetec Rocam	TCM	✓	✓	✓	✓	
2009	S. A. Fiesta	1.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2009	S. A. Fiesta	1.0L	FFV	IC	✓	✓	✓	✓	
2009	S. A. Fiesta	1.0L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2009	S. A. Fiesta	1.0L	FFV	RCM	✓	✓	✓	✓	
2009	S. A. Fiesta	1.0L	FFV	RKE	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2009	S. A. Fiesta	1.6L	FFV	IC	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2009	S. A. Fiesta	1.6L	FFV	RCM	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	FFV	RKE	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2009	S. A. Fiesta	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	Zetec Rocam	TCM	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	Zetec Rocam	TCM	✓	✓	✓	✓	00CE
2010	S. A. Fiesta	1.0L	FFV	ABS/TCS	✓	✓	✓	✓	000B
2010	S. A. Fiesta	1.0L	FFV	IC	✓	✓	✓	✓	
2010	S. A. Fiesta	1.0L	FFV	PCM	✓	✓	✓	✓	012E
2010	S. A. Fiesta	1.0L	FFV	RCM	✓	✓	✓	✓	
2010	S. A. Fiesta	1.0L	FFV	RKE	✓	✓	✓	✓	
2010	S. A. Fiesta	1.0L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2011	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2011	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0025
2011	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓		
2011	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2011	S. A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	000B
2011	S. A. Fiesta	1.6L	FFV	IC	✓	✓	✓	✓	
2011	S. A. Fiesta	1.6L	FFV	PCM	✓	✓	✓	✓	012E
2011	S. A. Fiesta	1.6L	FFV	RCM	✓	✓	✓	✓	
2011	S. A. Fiesta	1.6L	FFV	RKE	✓	✓	✓	✓	
2011	S. A. Fiesta	1.6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	ABS	✓	✓	✓	✓	
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	PCM	✓	✓	✓	✓	
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	RCM	✓	✓	✓	✓	
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A T	ABS	✓	✓	✓	✓	
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A T	PCM	✓	✓	✓	✓	
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A T	RCM	✓	✓	✓	✓	
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A T	TCM	✓	✓	✓	✓	
1996	Sable	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
1996	Sable	3.0L	4V	GEM	✓	✓	✓	✓	
1996	Sable	3.0L	4V	IAB	✓	✓	✓	✓	
1996	Sable	3.0L	4V	PATS	✓	✓	✓	✓	
1996	Sable	3.0L	4V	PCM	✓	✓	✓	✓	0025



2003	Sable	3.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Sable	3.0L	2V	RCM	✓	✓	✓	✓	
2003	Sable	3.0L	4V	ABS/TCS	✓	✓	✓	✓	
2003	Sable	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Sable	3.0L	4V	EATC	✓	✓	✓	✓	
2003	Sable	3.0L	4V	GEM	✓	✓	✓	✓	0203
2003	Sable	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Sable	3.0L	4V	RCM	✓	✓	✓	✓	
2003	Sable	3.0L	FFV	ABS/TCS	✓	✓	✓	✓	
2003	Sable	3.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
2003	Sable	3.0L	FFV	EATC	✓	✓	✓	✓	
2003	Sable	3.0L	FFV	GEM	✓	✓	✓	✓	0203
2003	Sable	3.0L	FFV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Sable	3.0L	FFV	RCM	✓	✓	✓	✓	
2004	Sable	3.0L	2V	ABS	✓	✓	✓	✓	0008
2004	Sable	3.0L	2V	EATC	✓	✓	✓	✓	
2004	Sable	3.0L	2V	GEM	✓	✓	✓	✓	0203
2004	Sable	3.0L	2V	IC	✓	✓	✓	✓	
2004	Sable	3.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Sable	3.0L	2V	RCM	✓	✓	✓	✓	000C
2004	Sable	3.0L	4V	ABS	✓	✓	✓	✓	0008
2004	Sable	3.0L	4V	EATC	✓	✓	✓	✓	
2004	Sable	3.0L	4V	GEM	✓	✓	✓	✓	0203
2004	Sable	3.0L	4V	IC	✓	✓	✓	✓	
2004	Sable	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Sable	3.0L	4V	RCM	✓	✓	✓	✓	000C
2005	Sable	3.0L	2V	ABS	✓	✓	✓	✓	0008
2005	Sable	3.0L	2V	EATC	✓	✓	✓	✓	
2005	Sable	3.0L	2V	GEM	✓	✓	✓	✓	0203
2005	Sable	3.0L	2V	IC	✓	✓	✓	✓	0005
2005	Sable	3.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Sable	3.0L	2V	RCM	✓	✓	✓	✓	000C
2005	Sable	3.0L	4V	ABS	✓	✓	✓	✓	0008
2005	Sable	3.0L	4V	EATC	✓	✓	✓	✓	
2005	Sable	3.0L	4V	GEM	✓	✓	✓	✓	0203
2005	Sable	3.0L	4V	IC	✓	✓	✓	✓	0005
2005	Sable	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Sable	3.0L	4V	RCM	✓	✓	✓	✓	000C
2008	Sable	3.5L	4V	4X4	✓	✓	✓	✓	
2008	Sable	3.5L	4V	ABS	✓	✓	✓	✓	0008
2008	Sable	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Sable	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Sable	3.5L	4V	DSM	✓	✓	✓	✓	
2008	Sable	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2008	Sable	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, 0203
2008	Sable	3.5L	4V	HVAC	✓	✓	✓	✓	
2008	Sable	3.5L	4V	IC	✓	✓	✓	✓	
2008	Sable	3.5L	4V	OCSM	✓	✓	✓	✓	000C
2008	Sable	3.5L	4V	PAM	✓	✓	✓	✓	006C
2008	Sable	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Sable	3.5L	4V	RCM	✓	✓	✓	✓	
2008	Sable	3.5L	4V	RETM	✓	✓	✓	✓	
2008	Sable	3.5L	4V	SDARS	✓	✓	✓	✓	
2008	Sable	3.5L	4V	SECM	✓	✓	✓	✓	
2009	Sable	3.5L	4V	4X4	✓	✓	✓	✓	
2009	Sable	3.5L	4V	ABS	✓	✓	✓	✓	0008
2009	Sable	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Sable	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Sable	3.5L	4V	DSM	✓	✓	✓	✓	
2009	Sable	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Sable	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, 0203
2009	Sable	3.5L	4V	HVAC	✓	✓	✓	✓	
2009	Sable	3.5L	4V	IC	✓	✓	✓	✓	
2009	Sable	3.5L	4V	OCSM	✓	✓	✓	✓	000C
2009	Sable	3.5L	4V	PAM	✓	✓	✓	✓	006C
2009	Sable	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Sable	3.5L	4V	RCM	✓	✓	✓	✓	
2009	Sable	3.5L	4V	RETM	✓	✓	✓	✓	
2009	Sable	3.5L	4V	SDARS	✓	✓	✓	✓	
2009	Sable	3.5L	4V	SECM	✓	✓	✓	✓	
2003.5	Street Ka	1.6L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	
2003.5	Street Ka	1.6L	DURATEC 8V	CSM	✓	✓	✓	✓	
2003.5	Street Ka	1.6L	DURATEC 8V	ECS	✓	✓	✓	✓	
2003.5	Street Ka	1.6L	DURATEC 8V	GEM	✓	✓	✓	✓	
2003.5	Street Ka	1.6L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2004	TITAN (Isuzu OEM)	3.1L	4JG2	PCM	✓	✓	✓	✓	
2004	TITAN (Isuzu OEM)	3.1L	4JG2 LPG	PCM	✓	✓	✓	✓	
2004	TITAN (Isuzu OEM)	4.3L	4HF1 CNG	PCM	✓	✓	✓	✓	0149
2004	TITAN (Isuzu OEM)	4.6L	4HG1 LPG	PCM	✓	✓	✓	✓	0149
2004	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	PCM	✓	✓	✓	✓	
2004	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	TCM	✓	✓	✓	✓	
2004	TITAN (Isuzu OEM)	4.8L	4HL1	PCM	✓	✓	✓	✓	0149
2004	TITAN (Isuzu OEM)	4.8L	4HL1	TCM	✓	✓	✓	✓	
2004	TITAN (Isuzu OEM)	4.8L	4HL1 T	PCM	✓	✓	✓	✓	0149
2004	TITAN (Isuzu OEM)	4.8L	4HL1 T	TCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	3.0L	4J11 T	ABS	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	3.0L	4J11 T	GEM	✓	✓	✓	✓	

2007	TITAN (Isuzu OEM)	3.0L	4J11 T	PATS	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	3.0L	4J11 T	PCM	✓	✓	✓	✓	0149
2007	TITAN (Isuzu OEM)	3.0L	4J11 T	RCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	3.0L	4J11 T	TCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	ABS	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	GEM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	PCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	RCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	TCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	5.2L	4HK1 T	ABS	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	5.2L	4HK1 T	GEM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	5.2L	4HK1 T	PATS	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	5.2L	4HK1 T	PCM	✓	✓	✓	✓	0149
2007	TITAN (Isuzu OEM)	5.2L	4HK1 T	RCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	5.2L	4HK1 T	TCM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	3.0L	4J11 T	ABS	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	3.0L	4J11 T	GEM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	3.0L	4J11 T	PATS	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	3.0L	4J11 T	PCM	✓	✓	✓	✓	0149
2011	TITAN (Isuzu OEM)	3.0L	4J11 T	RCM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	3.0L	4J11 T	TCM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	ABS	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	GEM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	PCM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	RCM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	TCM	✓	✓	✓	✓	
1996	Taurus	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
1996	Taurus	3.0L	4V	GEM	✓	✓	✓	✓	
1996	Taurus	3.0L	4V	IAB	✓	✓	✓	✓	
1996	Taurus	3.0L	4V	PATS	✓	✓	✓	✓	
1996	Taurus	3.0L	4V	PCM	✓	✓	✓	✓	0025
1996	Taurus	3.0L	4V	RAP	✓	✓	✓	✓	
1996	Taurus	3.0L	4V	RCC	✓	✓	✓	✓	
1996	Taurus	3.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
1996	Taurus	3.0L	FFV	GEM	✓	✓	✓	✓	
1996	Taurus	3.0L	FFV	IAB	✓	✓	✓	✓	
1996	Taurus	3.0L	FFV	PATS	✓	✓	✓	✓	
1996	Taurus	3.0L	FFV	PCM	✓	✓	✓	✓	0025
1996	Taurus	3.0L	FFV	RAP	✓	✓	✓	✓	
1996	Taurus	3.0L	FFV	RCC	✓	✓	✓	✓	
1996	Taurus	3.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1996	Taurus	3.0L	Other	GEM	✓	✓	✓	✓	
1996	Taurus	3.0L	Other	IAB	✓	✓	✓	✓	
1996	Taurus	3.0L	Other	PATS	✓	✓	✓	✓	
1996	Taurus	3.0L	Other	PCM	✓	✓	✓	✓	0025
1996	Taurus	3.0L	Other	RAP	✓	✓	✓	✓	
1996	Taurus	3.0L	Other	RCC	✓	✓	✓	✓	
1996	Taurus	3.4L	SHO	ABS/TCS	✓	✓	✓	✓	0008
1996	Taurus	3.4L	SHO	GEM	✓	✓	✓	✓	
1996	Taurus	3.4L	SHO	IAB	✓	✓	✓	✓	
1996	Taurus	3.4L	SHO	PATS	✓	✓	✓	✓	
1996	Taurus	3.4L	SHO	PCM	✓	✓	✓	✓	0025
1996	Taurus	3.4L	SHO	RAP	✓	✓	✓	✓	
1996	Taurus	3.4L	SHO	RCC	✓	✓	✓	✓	
1996	Taurus	3.4L	SHO	SARC	✓	✓	✓	✓	
1997	Taurus	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
1997	Taurus	3.0L	4V	GEM	✓	✓	✓	✓	0203
1997	Taurus	3.0L	4V	IAB	✓	✓	✓	✓	
1997	Taurus	3.0L	4V	PATS	✓	✓	✓	✓	
1997	Taurus	3.0L	4V	PCM	✓	✓	✓	✓	0025
1997	Taurus	3.0L	4V	RAP	✓	✓	✓	✓	
1997	Taurus	3.0L	4V	RCC	✓	✓	✓	✓	
1997	Taurus	3.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
1997	Taurus	3.0L	FFV	GEM	✓	✓	✓	✓	
1997	Taurus	3.0L	FFV	IAB	✓	✓	✓	✓	
1997	Taurus	3.0L	FFV	PATS	✓	✓	✓	✓	
1997	Taurus	3.0L	FFV	PCM	✓	✓	✓	✓	0025
1997	Taurus	3.0L	FFV	RAP	✓	✓	✓	✓	
1997	Taurus	3.0L	FFV	RCC	✓	✓	✓	✓	
1997	Taurus	3.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Taurus	3.0L	Other	GEM	✓	✓	✓	✓	0203
1997	Taurus	3.0L	Other	IAB	✓	✓	✓	✓	
1997	Taurus	3.0L	Other	PATS	✓	✓	✓	✓	
1997	Taurus	3.0L	Other	PCM	✓	✓	✓	✓	0025
1997	Taurus	3.0L	Other	RAP	✓	✓	✓	✓	
1997	Taurus	3.0L	Other	RCC	✓	✓	✓	✓	
1997	Taurus	3.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Taurus	3.4L	Other	GEM	✓	✓	✓	✓	0203
1997	Taurus	3.4L	Other	PATS	✓	✓	✓	✓	
1997	Taurus	3.4L	Other	PCM	✓	✓	✓	✓	0025
1997	Taurus	3.4L	SHO	ABS/TCS	✓	✓	✓	✓	0008
1997	Taurus	3.4L	SHO	GEM	✓	✓	✓	✓	
1997	Taurus	3.4L	SHO	IAB	✓	✓	✓	✓	
1997	Taurus	3.4L	SHO	PATS	✓	✓	✓	✓	
1997	Taurus	3.4L	SHO	PCM	✓	✓	✓	✓	0025
1997	Taurus	3.4L	SHO	RAP	✓	✓	✓	✓	
1997	Taurus	3.4L	SHO	RCC	✓	✓	✓	✓	
1997	Taurus	3.4L	SHO	SARC	✓	✓	✓	✓	
1998	Taurus	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008

1998	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
1998	Taurus	3. 0L	4V	IAB	✓	✓	✓	✓	
1998	Taurus	3. 0L	4V	PATS	✓	✓	✓	✓	
1998	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025
1998	Taurus	3. 0L	4V	RAP	✓	✓	✓	✓	
1998	Taurus	3. 0L	4V	RCC	✓	✓	✓	✓	
1998	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
1998	Taurus	3. 0L	FFV	GEM	✓	✓	✓	✓	
1998	Taurus	3. 0L	FFV	IAB	✓	✓	✓	✓	
1998	Taurus	3. 0L	FFV	PATS	✓	✓	✓	✓	
1998	Taurus	3. 0L	FFV	PCM	✓	✓	✓	✓	0025
1998	Taurus	3. 0L	FFV	RAP	✓	✓	✓	✓	
1998	Taurus	3. 0L	FFV	RCC	✓	✓	✓	✓	
1998	Taurus	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Taurus	3. 0L	Other	GEM	✓	✓	✓	✓	0203
1998	Taurus	3. 0L	Other	IAB	✓	✓	✓	✓	
1998	Taurus	3. 0L	Other	PATS	✓	✓	✓	✓	
1998	Taurus	3. 0L	Other	PCM	✓	✓	✓	✓	0025
1998	Taurus	3. 0L	Other	RAP	✓	✓	✓	✓	
1998	Taurus	3. 0L	Other	RAP	✓	✓	✓	✓	0005, F044
1998	Taurus	3. 0L	Other	RCC	✓	✓	✓	✓	
1998	Taurus	3. 4L	SHO	ABS/TCS	✓	✓	✓	✓	0008
1998	Taurus	3. 4L	SHO	GEM	✓	✓	✓	✓	
1998	Taurus	3. 4L	SHO	IAB	✓	✓	✓	✓	
1998	Taurus	3. 4L	SHO	PATS	✓	✓	✓	✓	
1998	Taurus	3. 4L	SHO	PCM	✓	✓	✓	✓	0025
1998	Taurus	3. 4L	SHO	RAP	✓	✓	✓	✓	
1998	Taurus	3. 4L	SHO	RCC	✓	✓	✓	✓	
1998	Taurus	3. 4L	SHO	SARC	✓	✓	✓	✓	
1999	Taurus	3. 0L	4V	ABS/TCS	✓	✓	✓	✓	0008
1999	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
1999	Taurus	3. 0L	4V	IAB	✓	✓	✓	✓	
1999	Taurus	3. 0L	4V	PATS	✓	✓	✓	✓	
1999	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025
1999	Taurus	3. 0L	4V	RAP	✓	✓	✓	✓	
1999	Taurus	3. 0L	4V	RCC	✓	✓	✓	✓	
1999	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
1999	Taurus	3. 0L	FFV	GEM	✓	✓	✓	✓	
1999	Taurus	3. 0L	FFV	IAB	✓	✓	✓	✓	
1999	Taurus	3. 0L	FFV	PATS	✓	✓	✓	✓	
1999	Taurus	3. 0L	FFV	PCM	✓	✓	✓	✓	0025
1999	Taurus	3. 0L	FFV	RAP	✓	✓	✓	✓	
1999	Taurus	3. 0L	FFV	RCC	✓	✓	✓	✓	
1999	Taurus	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Taurus	3. 0L	Other	GEM	✓	✓	✓	✓	0203
1999	Taurus	3. 0L	Other	IAB	✓	✓	✓	✓	
1999	Taurus	3. 0L	Other	PATS	✓	✓	✓	✓	
1999	Taurus	3. 0L	Other	PCM	✓	✓	✓	✓	0025
1999	Taurus	3. 0L	Other	RAP	✓	✓	✓	✓	
1999	Taurus	3. 0L	Other	RCC	✓	✓	✓	✓	
1999	Taurus	3. 4L	SHO	ABS/TCS	✓	✓	✓	✓	0008
1999	Taurus	3. 4L	SHO	PATS	✓	✓	✓	✓	
1999	Taurus	3. 4L	SHO	PCM	✓	✓	✓	✓	0025
1999	Taurus	3. 4L	SHO	RAP	✓	✓	✓	✓	
1999	Taurus	3. 4L	SHO	RCC	✓	✓	✓	✓	
2000	Taurus	3. 0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2000	Taurus	3. 0L	4V	EATC	✓	✓	✓	✓	
2000	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
2000	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Taurus	3. 0L	4V	RCM	✓	✓	✓	✓	
2000	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
2000	Taurus	3. 0L	FFV	EATC	✓	✓	✓	✓	
2000	Taurus	3. 0L	FFV	GEM	✓	✓	✓	✓	0203
2000	Taurus	3. 0L	FFV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Taurus	3. 0L	FFV	RCM	✓	✓	✓	✓	
2000	Taurus	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Taurus	3. 0L	Other	EATC	✓	✓	✓	✓	
2000	Taurus	3. 0L	Other	GEM	✓	✓	✓	✓	0203
2000	Taurus	3. 0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Taurus	3. 0L	Other	RCM	✓	✓	✓	✓	
2002	Taurus	3. 0L	4V	ABS/TCS	✓	✓	✓	✓	
2002	Taurus	3. 0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2002	Taurus	3. 0L	4V	EATC	✓	✓	✓	✓	
2002	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
2002	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Taurus	3. 0L	4V	RCM	✓	✓	✓	✓	
2002	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	
2002	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
2002	Taurus	3. 0L	FFV	EATC	✓	✓	✓	✓	
2002	Taurus	3. 0L	FFV	GEM	✓	✓	✓	✓	0203
2002	Taurus	3. 0L	FFV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Taurus	3. 0L	FFV	RCM	✓	✓	✓	✓	
2002	Taurus	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	
2002	Taurus	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	Taurus	3. 0L	Other	EATC	✓	✓	✓	✓	
2002	Taurus	3. 0L	Other	GEM	✓	✓	✓	✓	0203
2002	Taurus	3. 0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Taurus	3. 0L	Other	RCM	✓	✓	✓	✓	
2003	Taurus	3. 0L	2V	ABS/TCS	✓	✓	✓	✓	



2003	Taurus	3. 0L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	Taurus	3. 0L	2V	EATC	✓	✓	✓		
2003	Taurus	3. 0L	2V	GEM	✓	✓	✓	✓	0203
2003	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Taurus	3. 0L	2V	RCM	✓	✓	✓		
2003	Taurus	3. 0L	4V	ABS/TCS	✓	✓	✓	✓	
2003	Taurus	3. 0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Taurus	3. 0L	4V	EATC	✓	✓	✓		
2003	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
2003	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Taurus	3. 0L	4V	RCM	✓	✓	✓		
2003	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	
2003	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
2003	Taurus	3. 0L	FFV	EATC	✓	✓	✓		
2003	Taurus	3. 0L	FFV	GEM	✓	✓	✓	✓	0203
2003	Taurus	3. 0L	FFV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Taurus	3. 0L	FFV	RCM	✓	✓	✓		
2004	Taurus	3. 0L	2V	ABS	✓	✓	✓	✓	0008
2004	Taurus	3. 0L	2V	EATC	✓	✓	✓	✓	
2004	Taurus	3. 0L	2V	GEM	✓	✓	✓	✓	0203
2004	Taurus	3. 0L	2V	IC	✓	✓	✓	✓	
2004	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	
2004	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Taurus	3. 0L	2V	RCM	✓	✓	✓	✓	000C
2004	Taurus	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2004	Taurus	3. 0L	4V	EATC	✓	✓	✓	✓	
2004	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
2004	Taurus	3. 0L	4V	IC	✓	✓	✓	✓	
2004	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	
2004	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Taurus	3. 0L	4V	RCM	✓	✓	✓	✓	000C
2005	Taurus	3. 0L	2V	ABS	✓	✓	✓	✓	0008
2005	Taurus	3. 0L	2V	EATC	✓	✓	✓	✓	
2005	Taurus	3. 0L	2V	GEM	✓	✓	✓	✓	0203
2005	Taurus	3. 0L	2V	IC	✓	✓	✓	✓	0005
2005	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	
2005	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Taurus	3. 0L	2V	RCM	✓	✓	✓	✓	000C
2005	Taurus	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2005	Taurus	3. 0L	4V	EATC	✓	✓	✓	✓	
2005	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
2005	Taurus	3. 0L	4V	IC	✓	✓	✓	✓	0005
2005	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	
2005	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Taurus	3. 0L	4V	RCM	✓	✓	✓	✓	000C
2006	Taurus	3. 0L	2V	ABS	✓	✓	✓	✓	0008
2006	Taurus	3. 0L	2V	EATC	✓	✓	✓	✓	
2006	Taurus	3. 0L	2V	GEM	✓	✓	✓	✓	0203
2006	Taurus	3. 0L	2V	IC	✓	✓	✓	✓	0005
2006	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	
2006	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Taurus	3. 0L	2V	RCM	✓	✓	✓	✓	000C
2007	Taurus	3. 0L	2V	ABS	✓	✓	✓	✓	0008
2007	Taurus	3. 0L	2V	EATC	✓	✓	✓	✓	
2007	Taurus	3. 0L	2V	GEM	✓	✓	✓	✓	0203
2007	Taurus	3. 0L	2V	IC	✓	✓	✓	✓	0005
2007	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	0203
2007	Taurus	3. 0L	2V	RCM	✓	✓	✓	✓	000C
2008	Taurus	3. 5L	4V	4X4	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	ABS	✓	✓	✓	✓	0008
2008	Taurus	3. 5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Taurus	3. 5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Taurus	3. 5L	4V	DSM	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2008	Taurus	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	0042, 0203
2008	Taurus	3. 5L	4V	HVAC	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	IC	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	OCSM	✓	✓	✓	✓	000C
2008	Taurus	3. 5L	4V	PAM	✓	✓	✓	✓	006C
2008	Taurus	3. 5L	4V	PCM	✓	✓	✓	✓	0019, 001C
2008	Taurus	3. 5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Taurus	3. 5L	4V	RCM	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	RETN	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	SDARS	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	SECM	✓	✓	✓	✓	
2009	Taurus	3. 5L	4V	4X4	✓	✓	✓	✓	
2009	Taurus	3. 5L	4V	ABS	✓	✓	✓	✓	0008
2009	Taurus	3. 5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Taurus	3. 5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Taurus	3. 5L	4V	DSM	✓	✓	✓	✓	
2009	Taurus	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Taurus	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	0042, 0203
2009	Taurus	3. 5L	4V	HVAC	✓	✓	✓	✓	
2009	Taurus	3. 5L	4V	IC	✓	✓	✓	✓	
2009	Taurus	3. 5L	4V	OCSM	✓	✓	✓	✓	000C
2009	Taurus	3. 5L	4V	PAM	✓	✓	✓	✓	006C
2009	Taurus	3. 5L	4V	PCM	✓	✓	✓	✓	0019, 001C

2009	Taurus	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Taurus	3.5L	4V	RCM	✓	✓	✓	✓	
2009	Taurus	3.5L	4V	RETM	✓	✓	✓	✓	
2009	Taurus	3.5L	4V	SDARS	✓	✓	✓	✓	
2009	Taurus	3.5L	4V	SECM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	4X4	✓	✓	✓	✓	0108
2010	Taurus	3.5L	4V	ABS	✓	✓	✓	✓	0008
2010	Taurus	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	Taurus	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Taurus	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Taurus	3.5L	4V	C-CM	✓	✓	✓	✓	0046
2010	Taurus	3.5L	4V	DCSM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	DDM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	DSM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	DSP	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	FCIM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	FCIM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	FDIM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Taurus	3.5L	4V	GPSM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	HCM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	HCM-2	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	HUD	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	HVAC	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	ILCM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	IPC	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 006D
2010	Taurus	3.5L	4V	PAM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	PCM	✓	✓	✓	✓	0025
2010	Taurus	3.5L	4V	PSCM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	RCM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	RETM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	RFA	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	SASM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	SOD-L	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	SOD-R	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019, 001C
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	

2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	4X4	✓	✓	✓	✓	0108
2011	Taurus	3.5L	4V	ABS	✓	✓	✓	✓	0008
2011	Taurus	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Taurus	3.5L	4V	ACM	✓	✓	✓	✓	0018
2011	Taurus	3.5L	4V	APIM	✓	✓	✓	✓	0019
2011	Taurus	3.5L	4V	C-CM	✓	✓	✓	✓	0046
2011	Taurus	3.5L	4V	DCSM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	DDM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	DSM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	DSP	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	FCIM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	FCIM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	FDIM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Taurus	3.5L	4V	GPSM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	HCM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	HCM-2	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	HUD	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	HVAC	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	ILCM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	IPC	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	OCSM	✓	✓	✓	✓	000C
2011	Taurus	3.5L	4V	PAM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	PCM	✓	✓	✓	✓	000C, 000C, 0025, 0028, 0031, 0033
2011	Taurus	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Taurus	3.5L	4V	PSCM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	RCM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	RETM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	RFA	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	SASM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	SOD-L	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	SOD-R	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019

2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 000C, 0017, 0018
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	4X4	✓	✓	✓	✓	0108
2012	Taurus	3.5L	4V	ABS	✓	✓	✓	✓	0008
2012	Taurus	3.5L	4V	ACM	✓	✓	✓	✓	0018
2012	Taurus	3.5L	4V	APIM	✓	✓	✓	✓	0019
2012	Taurus	3.5L	4V	C-CM	✓	✓	✓	✓	0046
2012	Taurus	3.5L	4V	DCSM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	DDM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	DSM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	DSP	✓	✓	✓	✓	

2012	Taurus	3.5L	4V	FCIM	✓	✓	✓		
2012	Taurus	3.5L	4V	FCIM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	FDIM	✓	✓	✓		
2012	Taurus	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Taurus	3.5L	4V	GPSM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	HCM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	HCM-2	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	HUD	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	HVAC	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	IHCM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	IPC	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	OCSM	✓	✓	✓	✓	000C
2012	Taurus	3.5L	4V	PAM	✓	✓	✓		
2012	Taurus	3.5L	4V	PCM	✓	✓	✓	✓	000C, 000C, 0025, 0028, 0031, 0033
2012	Taurus	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2012	Taurus	3.5L	4V	PSCM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	RCM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	RETM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	RFA	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	SASM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	SOD-L	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	SOD-R	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0018
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓		
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓		
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IHCM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C

2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓		
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 000C, 0017, 0018
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2012	Taurus	Other	Other	4X4	✓	✓	✓	✓	
2012	Taurus	Other	Other	ABS	✓	✓	✓	✓	
2012	Taurus	Other	Other	ACM	✓	✓	✓	✓	
2012	Taurus	Other	Other	APIM	✓	✓	✓	✓	
2012	Taurus	Other	Other	C-CM	✓	✓	✓	✓	
2012	Taurus	Other	Other	DCSM	✓	✓	✓	✓	
2012	Taurus	Other	Other	DDM	✓	✓	✓	✓	
2012	Taurus	Other	Other	DSM	✓	✓	✓	✓	
2012	Taurus	Other	Other	DSP	✓	✓	✓	✓	
2012	Taurus	Other	Other	FCIM	✓	✓	✓	✓	
2012	Taurus	Other	Other	FCIM	✓	✓	✓	✓	
2012	Taurus	Other	Other	FDIM	✓	✓	✓	✓	
2012	Taurus	Other	Other	GEM / SJB	✓	✓	✓	✓	0042
2012	Taurus	Other	Other	GPSM	✓	✓	✓	✓	
2012	Taurus	Other	Other	HCM	✓	✓	✓	✓	
2012	Taurus	Other	Other	HCM-2	✓	✓	✓	✓	
2012	Taurus	Other	Other	HUD	✓	✓	✓	✓	
2012	Taurus	Other	Other	HVAC	✓	✓	✓	✓	
2012	Taurus	Other	Other	ILCM	✓	✓	✓	✓	
2012	Taurus	Other	Other	IPC	✓	✓	✓	✓	
2012	Taurus	Other	Other	OCSM	✓	✓	✓	✓	
2012	Taurus	Other	Other	PAM	✓	✓	✓	✓	
2012	Taurus	Other	Other	PCM	✓	✓	✓	✓	
2012	Taurus	Other	Other	PSCM	✓	✓	✓	✓	
2012	Taurus	Other	Other	RCM	✓	✓	✓	✓	
2012	Taurus	Other	Other	RETM	✓	✓	✓	✓	
2012	Taurus	Other	Other	RFA	✓	✓	✓	✓	
2012	Taurus	Other	Other	SASM	✓	✓	✓	✓	
2012	Taurus	Other	Other	SOD-L	✓	✓	✓	✓	
2012	Taurus	Other	Other	SOD-R	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0018
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	

2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 0015, 0018, 0028, 0031, 0033, 0046, 0067, 0095
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 0015, 0018, 0028, 0031, 0033, 0046, 0067, 0095, 0108
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0018
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	

2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 0015, 0018, 0028, 0031, 0033, 0046, 0067, 0095, 0108
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	ABS	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	ACM	✓	✓	✓	✓	0018
2013	Taurus	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Taurus	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Taurus	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	DDM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	FCD1M	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	GFM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	HCM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	HSWM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	IPC	✓	✓	✓	✓	



2013	Taurus	3.5L	TiVCT	IPM-A	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	Taurus	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	PCM	✓	✓	✓	✓	000C, 0015, 0018, 0025, 0028, 0031, 0033, 0046, 0067, 0095, 0108
2013	Taurus	3.5L	TiVCT	PCM	✓	✓	✓	✓	000C, 0015, 0018, 0028, 0031, 0033, 0046, 0067, 0095, 0108
2013	Taurus	3.5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2013	Taurus	3.5L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	Taurus	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	RACM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	ACM	✓	✓	✓	✓	0018
2013	Taurus	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE
2013	Taurus	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Taurus	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	GFM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	Taurus	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	PCM	✓	✓	✓	✓	000C, 0025, 0028, 0031, 0033, 0046, 00D4, 00D5, 00FE
2013	Taurus	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	Taurus	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	

2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 0046, 00D4, 00D5, 00FE, 0112, 013E
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	

2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 0046, 00D4, 00D5, 00FE, 0112, 013E
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	ABS	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Taurus	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Taurus	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	DDM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	GFM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	HSWM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	Taurus	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Taurus	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	PCM	✓	✓	✓	✓	000C, 0046, 00D4, 00D5, 00FE, 0112, 013E
2014	Taurus	3.5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Taurus	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	RACM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112

2014	Taurus	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Taurus	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	GFM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	Taurus	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Taurus	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	PCM	✓	✓	✓	✓	000C, 0046, 00D4, 00D5, 00FE, 0112, 013E
2014	Taurus	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Taurus	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	4X4	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	ABS	✓	✓	✓	✓	0008
2008	Taurus X	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Taurus X	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Taurus X	3.5L	4V	DSM	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2008	Taurus X	3.5L	4V	HVAC	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	IC	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	LTM	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	OCSM	✓	✓	✓	✓	000C
2008	Taurus X	3.5L	4V	PAM	✓	✓	✓	✓	006C
2008	Taurus X	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Taurus X	3.5L	4V	RCM	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	RETM	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	SDARS	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	SECM	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	4X4	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	ABS	✓	✓	✓	✓	0008
2009	Taurus X	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Taurus X	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Taurus X	3.5L	4V	DSM	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Taurus X	3.5L	4V	HVAC	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	IC	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	LTM	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	OCSM	✓	✓	✓	✓	000C
2009	Taurus X	3.5L	4V	PAM	✓	✓	✓	✓	006C
2009	Taurus X	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Taurus X	3.5L	4V	RCM	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	RETM	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	SDARS	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	SECM	✓	✓	✓	✓	
Other	Telstar	1.8L	Other	PCM	✓	✓	✓	✓	
Other	Telstar	2.0L	Other	PCM	✓	✓	✓	✓	
Other	Telstar	2.5L	Other	PCM	✓	✓	✓	✓	
2004	Territory	4.0L	DOHC VCT	ABS	✓	✓	✓	✓	0008, 0005
2004	Territory	4.0L	DOHC VCT	ABS/TCS	✓	✓	✓	✓	0008
2004	Territory	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2004	Territory	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0035, 0005, F002, F004, F005, F007, F008, F009, F00A, F011, F014, F015, F016, F00D, F010
2004	Territory	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0035, 0005, F002, F004, F005, F007, F008, F009, F00A, F011, F014, F015, F016, F010
2004	Territory	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	003A, 0005
2004	Territory	4.0L	DOHC VCT	IC	✓	✓	✓	✓	005F, 0044, 0061, F00B, F00C, F00F
2004	Territory	4.0L	DOHC VCT	IC	✓	✓	✓	✓	005F, 0044, 0061, F00B, F00C, F00F, F017, F018
2004	Territory	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2004	Territory	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	003A, 0005, 0025
2004	Territory	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	
2006	Territory	4.0L	DOHC VCT	ABS	✓	✓	✓	✓	0008, 0005
2006	Territory	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2006	Territory	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0035, 0005, F002, F004, F005, F007, F008, F009, F00A, F011, F014, F015, F016, F00D, F010

2006	Territory	4. 0L	DOHC VCT	BEM	✓	✓	✓	✓	0035, 0005, F002, F004, F005, F007, F008, F009, F00A, F011, F014, F015, F016, F00D, F010
2006	Territory	4. 0L	DOHC VCT	HIM	✓	✓	✓	✓	003A, 0005
2006	Territory	4. 0L	DOHC VCT	IC	✓	✓	✓	✓	005F, 0044, 0061, F00B, F00F, F019
2006	Territory	4. 0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2006	Territory	4. 0L	DOHC VCT	PCM	✓	✓	✓	✓	003A, 0005, 0025
2006	Territory	4. 0L	DOHC VCT	RCM	✓	✓	✓	✓	
2006	Territory	4. 0L	DOHC VCT	TCM	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Territory	2 7L	Direct Injection -	ACM	✓	✓	✓	✓	0017
2011	Territory	2 7L	Direct Injection -	ACM	✓	✓	✓	✓	0017, 0005, F024
2011	Territory	2 7L	Direct Injection -	AWD#1	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	BEM	✓	✓	✓	✓	0005
2011	Territory	2 7L	Direct Injection -	BEM	✓	✓	✓	✓	0005, 0035
2011	Territory	2 7L	Direct Injection -	BEM	✓	✓	✓	✓	0035
2011	Territory	2 7L	Direct Injection -	FDIM	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	FDIM	✓	✓	✓	✓	0005
2011	Territory	2 7L	Direct Injection -	HIM	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	HIM	✓	✓	✓	✓	0005
2011	Territory	2 7L	Direct Injection -	IPC	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	IPC	✓	✓	✓	✓	F020
2011	Territory	2 7L	Direct Injection -	PAM	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	PAM	✓	✓	✓	✓	0005
2011	Territory	2 7L	Direct Injection -	PCM	✓	✓	✓	✓	0025
2011	Territory	2 7L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	00BB, 009A, 0099, 00C1, 00B3, 00B2
2011	Territory	2 7L	Direct Injection -	PSCM	✓	✓	✓	✓	00CB, 00CC
2011	Territory	2 7L	Direct Injection -	RCM	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	RCM	✓	✓	✓	✓	0005
2011	Territory	2 7L	Direct Injection -	TCM	✓	✓	✓	✓	
2011	Territory	4. 0L	DOHC VCT	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Territory	4. 0L	DOHC VCT	ACM	✓	✓	✓	✓	0017, F024
2011	Territory	4. 0L	DOHC VCT	BEM	✓	✓	✓	✓	0035
2011	Territory	4. 0L	DOHC VCT	FDIM	✓	✓	✓	✓	
2011	Territory	4. 0L	DOHC VCT	HIM	✓	✓	✓	✓	
2011	Territory	4. 0L	DOHC VCT	IPC	✓	✓	✓	✓	F020
2011	Territory	4. 0L	DOHC VCT	PAM	✓	✓	✓	✓	
2011	Territory	4. 0L	DOHC VCT	PCM	✓	✓	✓	✓	0025
2011	Territory	4. 0L	DOHC VCT	PSCM	✓	✓	✓	✓	00CB, 00CC
2011	Territory	4. 0L	DOHC VCT	RCM	✓	✓	✓	✓	
2011	Territory	4. 0L	DOHC VCT	TCM	✓	✓	✓	✓	
2011	Territory	Other	Other	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Territory	Other	Other	ACM	✓	✓	✓	✓	0017, 0005, F024
2011	Territory	Other	Other	BEM	✓	✓	✓	✓	0005
2011	Territory	Other	Other	FDIM	✓	✓	✓	✓	0005
2011	Territory	Other	Other	HIM	✓	✓	✓	✓	0005
2011	Territory	Other	Other	IPC	✓	✓	✓	✓	F020
2011	Territory	Other	Other	PAM	✓	✓	✓	✓	0005
2011	Territory	Other	Other	PSCM	✓	✓	✓	✓	00CB, 00CC
2011	Territory	Other	Other	RCM	✓	✓	✓	✓	0005
1994	Thunderbird	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1995	Thunderbird	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1996	Thunderbird	3. 8L	Other	PCM	✓	✓	✓	✓	0025
1996	Thunderbird	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1996	Thunderbird	4. 6L	Other	PCM	✓	✓	✓	✓	0025
1997	Thunderbird	3. 8L	Other	PCM	✓	✓	✓	✓	0025
1997	Thunderbird	4. 6L	2V	PCM	✓	✓	✓	✓	0025
2002	Thunderbird	3. 9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2002	Thunderbird	3. 9L	4V	ACM	✓	✓	✓	✓	
2002	Thunderbird	3. 9L	4V	DDM	✓	✓	✓	✓	
2002	Thunderbird	3. 9L	4V	EATC	✓	✓	✓	✓	
2002	Thunderbird	3. 9L	4V	GEM	✓	✓	✓	✓	
2002	Thunderbird	3. 9L	4V	HEC	✓	✓	✓	✓	
2002	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	0025
2002	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 00C7
2002	Thunderbird	3. 9L	4V	RCM	✓	✓	✓	✓	
2002	Thunderbird	3. 9L	4V	REM	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Thunderbird	3. 9L	4V	ACM	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	DDM	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	EATC	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	GEM	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	HEC	✓	✓	✓	✓	00C7
2003	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Thunderbird	3. 9L	4V	RCM	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	REM	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2004	Thunderbird	3. 9L	4V	ACM	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	DDM	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	EATC	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	GEM	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	HEC	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Thunderbird	3. 9L	4V	RCM	✓	✓	✓	✓	

2004	Thunderbird	3. 9L	4V	RCM	✓	✓	✓	✓	000C
2004	Thunderbird	3. 9L	4V	REM	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2005	Thunderbird	3. 9L	4V	ACM	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	DDM	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	EATC	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	GEM	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	HEC	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Thunderbird	3. 9L	4V	RCM	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	REM	✓	✓	✓	✓	
2000	Titan	4. 0L	TF	PCM	✓	✓	✓	✓	
2002	Titan	4. 0L	TF	PCM	✓	✓	✓	✓	
1995	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1995	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
1995	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
1995	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
1995	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
1995	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1996	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1996	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
1996	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
1996	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
1996	Town Car	4. 6L	2V	IAB	✓	✓	✓	✓	
1996	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
1996	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1997	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1997	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
1997	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
1997	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
1997	Town Car	4. 6L	2V	IAB	✓	✓	✓	✓	
1997	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
1997	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1998	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1998	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	CPM	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	IAB	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	NGSC	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1998	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1999	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	0005
1999	Town Car	4. 6L	2V	CPM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	0005
1999	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	0005
1999	Town Car	4. 6L	2V	NGSC	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1999	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2000	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008, 0008
2000	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	CPM	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	F044, F045
2000	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	F041
2000	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	F027, F042, F043
2000	Town Car	4. 6L	2V	NGSC	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2002	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008, 0008
2002	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	0005
2002	Town Car	4. 6L	2V	CPM	✓	✓	✓	✓	
2002	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	0005, F044, F045
2002	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	F041
2002	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2002	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
2002	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	0005, F027, F042, F043
2002	Town Car	4. 6L	2V	NGSC	✓	✓	✓	✓	
2002	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	000C, 0025, 0028, 0031, 0033
2002	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	
2002	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2002	Town Car	4. 6L	2V	RESCU	✓	✓	✓	✓	

2003	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	CPM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	NGSC	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	0013
2003	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2003	Town Car	4. 6L	2V	RESCU	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2004	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	0005, F044, F045
2004	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	F041
2004	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	0005, F042, F043
2004	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2004	Town Car	4. 6L	2V	NGSC	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	0005, 0013
2004	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2004	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0008
2005	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2005	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0008, 000C
2005	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	0013
2005	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2006	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0008
2006	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	IC	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2006	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0008, 000C
2006	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	0013
2006	Town Car	4. 6L	2V	RATC	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2007	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0008
2007	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	IC	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2007	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0008, 000C
2007	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Town Car	4. 6L	2V	RATC	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2007	Town Car	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2008	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0008
2008	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	0042
2008	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	HVAC	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	IC	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	

2008	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2008	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0008, 000C, 0016
2008	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Town Car	4. 6L	2V	RATC	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2008	Town Car	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2009	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0008
2009	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	0042
2009	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	HVAC	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	IC	✓	✓	✓	✓	0005
2009	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2009	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0005, 0008, 000C, 0016, 0042
2009	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0005, 0008, 000C, 0016, 0042, 00C5
2009	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Town Car	4. 6L	2V	RATC	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2009	Town Car	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2010	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0008, F046
2010	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
2010	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	F041
2010	Town Car	4. 6L	2V	HVAC	✓	✓	✓	✓	
2010	Town Car	4. 6L	2V	IC	✓	✓	✓	✓	0005
2010	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	F042, F043
2010	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2010	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2010	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2010	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2010	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0005, 0008, 000C, 0016, F046
2010	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2010	Town Car	4. 6L	2V	RATC	✓	✓	✓	✓	
2010	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2010	Town Car	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2011	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0008, F046
2011	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
2011	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	F041
2011	Town Car	4. 6L	2V	HVAC	✓	✓	✓	✓	
2011	Town Car	4. 6L	2V	IC	✓	✓	✓	✓	0005
2011	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	F042, F043
2011	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2011	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2011	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0005, 0008, 000C, F046
2011	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Town Car	4. 6L	2V	RATC	✓	✓	✓	✓	
2011	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2011	Town Car	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
1996	Tracer	1. 9L	1. 4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1996	Tracer	1. 9L	1. 4 PT-E SFI	PCM	✓	✓	✓	✓	0025
1996	Tracer	1. 9L	1. 4 PT-E SFI	RAP	✓	✓	✓	✓	
1997	Tracer	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
1997	Tracer	2. 0L	SPI	PCM	✓	✓	✓	✓	0025
1997	Tracer	2. 0L	SPI	RAP	✓	✓	✓	✓	
1998	Tracer	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
1998	Tracer	2. 0L	SPI	ECS	✓	✓	✓	✓	
1998	Tracer	2. 0L	SPI	PCM	✓	✓	✓	✓	0008, 0025
1998	Tracer	2. 0L	SPI	RAP	✓	✓	✓	✓	
1999	Tracer	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
1999	Tracer	2. 0L	SPI	IAB	✓	✓	✓	✓	
1999	Tracer	2. 0L	SPI	PCM	✓	✓	✓	✓	0008, 0025
1999	Tracer	2. 0L	SPI	PCM	✓	✓	✓	✓	0025
1999	Tracer	2. 0L	SPI	RAP	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	00DD, 00E8
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	AWD#1	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	FCIM	✓	✓	✓	✓	



2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	GPSM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	IPM-B	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PRB	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓		
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	00DD, 00E8
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	00CF
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	APIM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AWD#1	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011C
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	00F9
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	FCIM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	GPSM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-A	✓	✓	✓	✓	00E5
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-B	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PRB	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓		
2014	Transit	2. 2L	TDCi StgVI	ABS	✓	✓	✓		00DD, 00E8
2014	Transit	2. 2L	TDCi StgVI	ACM	✓	✓	✓		
2014	Transit	2. 2L	TDCi StgVI	AHCM	✓	✓	✓		00CF
2014	Transit	2. 2L	TDCi StgVI	APIM	✓	✓	✓		
2014	Transit	2. 2L	TDCi StgVI	AWD#1	✓	✓	✓		
2014	Transit	2. 2L	TDCi StgVI	BCMii	✓	✓	✓	✓	011C
2014	Transit	2. 2L	TDCi StgVI	CCMii	✓	✓	✓	✓	00F9
2014	Transit	2. 2L	TDCi StgVI	FCDIM	✓	✓	✓	✓	

2014	Transit	2.2L	TDCi StgVI	FCIM	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	GPSM	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	HCM	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	IPC	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	IPM-A	✓	✓	✓	✓	00E5
2014	Transit	2.2L	TDCi StgVI	IPM-B	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	PAM	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	PCM	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	PRB	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	RCM	✓	✓	✓	✓	00EF
2014	Transit	2.2L	TDCi StgVI	SASM	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	TRM	✓	✓	✓	✓	
2014	Transit	3.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0025, 0059, 0091, 009C, 009D, 009E, 009F, 00A0
2014	Transit	3.2L	Duratorq Turbo Diesel Common Rail Injection	RDCM#1	✓	✓	✓	✓	
2014	Transit	3.2L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓	
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓	
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓	
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓	
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓	
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓	
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓	
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	GSM	✓	✓	✓	✓	
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	AFCM	✓	✓	✓	✓	
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓	
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
2000	Transit Connect	2.4L	DURATORQ DI	ABS/TCS	✓	✓	✓	✓	0008
2000	Transit Connect	2.4L	DURATORQ DI	CSM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	EPB	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	FFH	✓	✓	✓	✓	00CF
2000	Transit Connect	2.4L	DURATORQ DI	FIP	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	HEC	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	PAM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	PCM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	PCM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	RASM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	RCM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	RCM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	TCM	✓	✓	✓	✓	003F
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	ABS/TCS	✓	✓	✓	✓	0008
2001	Transit Connect	2.0L	DURATORQ DI	CSM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	EPB	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	FFH	✓	✓	✓	✓	00CF

2001	Transit Connect	2.0L	DURATORQ DI	FIP	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	HEC	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	PAM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	PCM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	RASM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	RCM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	TCM	✓	✓	✓	✓	003F
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	FIP	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓		
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	RASM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2001	Transit Connect	2.3L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓	0008
2001	Transit Connect	2.3L	DOHC SFI (16V)	GSM	✓	✓	✓	✓	
2001	Transit Connect	2.3L	DOHC SFI (16V)	HEC	✓	✓	✓	✓	
2001	Transit Connect	2.3L	DOHC SFI (16V)	PAM	✓	✓	✓	✓	
2001	Transit Connect	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓	0025
2001	Transit Connect	2.3L	DOHC SFI (16V)	RASM	✓	✓	✓	✓	
2001	Transit Connect	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0053, 00DD, 00E3, 00E4, 00E8, 011F, 0135
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 00A6, 00A7, 00A8, 00A9, 00B0, 00B1, 00B5, 00B6, 00C0, 00C1, 00C2
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	ABS	✓	✓	✓	✓	0053, 00E3, 00E4, 00E8, 011F, 0135
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	ABS/TCS	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	FFH	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	IPC	✓	✓	✓	✓	F020
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	PCM	✓	✓	✓	✓	0090, 0098, 0099, 009A, 00B0, 00B1, 00B7, 00B9
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	SRM	✓	✓	✓	✓	

2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	ABS	✓	✓	✓	✓	0053, 00DD, 00E3, 00E4, 011F, 0135
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	FFH	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0098, 0099, 009A, 00B0, 00B1, 00B7, 00B9
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0053, 00DD, 00E3, 00E4, 00E8, 011F, 0135
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	00CF
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00AC
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0053, 00DD, 00E3, 00E4, 00E8, 011F, 0135
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 00A6, 00A7, 00A8, 00A9, 00B0, 00B1, 00B5, 00B6, 00C0, 00C1, 00C2
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	TBM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0053, 00DD, 00E3, 00E4, 00E8, 011F, 0135
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 00A6, 00A7, 00A8, 00A9, 00B0, 00B1, 00B5, 00B6, 00C0, 00C1, 00C2
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	ABS	✓	✓	✓	✓	0053, 00DD, 00E3, 00E4, 011F, 0135
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	ABS/TCS	✓	✓	✓	✓	

2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_C ommon Rail Injection	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_C ommon Rail Injection	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_C ommon Rail Injection	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_C ommon Rail Injection	FFH	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_C ommon Rail Injection	IPC	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_C ommon Rail Injection	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_C ommon Rail Injection	PCM	✓	✓	✓	✓	0090, 0098, 0099, 009A, 00B0, 00B1, 00B7, 00B9
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_C ommon Rail Injection	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_C ommon Rail Injection	SRM	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0012
2010	Transit Connect	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2010	Transit Connect	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2010	Transit Connect	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	VSM	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0012
2011	Transit Connect	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2011	Transit Connect	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2011	Transit Connect	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	VSM	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicl	ABS	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicl	ABS	✓	✓	✓	✓	0012
2011	Transit Connect	28kWh	Battery Electric Vehicl	ACCM#2	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicl	ACM	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicl	GEM / SJB	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicl	IC	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicl	OCSM	✓	✓	✓	✓	000C
2011	Transit Connect	28kWh	Battery Electric Vehicl	PAM	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicl	PSCM	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicl	RCM	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicl	SRM	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicl	VSM	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0012
2012	Transit Connect	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2012	Transit Connect	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2012	Transit Connect	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	VSM	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicl	ABS	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicl	ABS	✓	✓	✓	✓	0012
2013	Transit Connect	28kWh	Battery Electric Vehicl	ACCM#2	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicl	ACM	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicl	APIM	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicl	GEM / SJB	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicl	IC	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicl	OCSM	✓	✓	✓	✓	000C
2013	Transit Connect	28kWh	Battery Electric Vehicl	PAM	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicl	PSCM	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicl	RCM	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicl	VSM	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	ABS	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	ACM	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	APIM	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	GEM / SJB	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	IC	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	OCSM	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	PAM	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	RCM	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	VSM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012

2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 0114
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CC
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0012
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓		0017
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓		00CF
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	APIM	✓	✓	✓		0019
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	00D5, 0101
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FCIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FDSM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	GPSM	✓	✓	✓	✓	

2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-B	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00CC
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 0101, 020F
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓		

2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	00BC, 0108
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CC
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	ABS	✓	✓	✓	✓	0012
2014	Transit Connect	1.6L	TDCi ECO III	ACM	✓	✓	✓	✓	0017
2014	Transit Connect	1.6L	TDCi ECO III	AHCM	✓	✓	✓	✓	00CF
2014	Transit Connect	1.6L	TDCi ECO III	APIM	✓	✓	✓	✓	0019
2014	Transit Connect	1.6L	TDCi ECO III	BCMii	✓	✓	✓	✓	00D5, 0101
2014	Transit Connect	1.6L	TDCi ECO III	DDM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	FCDIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	FCIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	FDSM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	GPSM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	HCM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	HVAC	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	IPC	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	IPM-B	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	PAM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	PCM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	PDM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	PSCM	✓	✓	✓	✓	00CC
2014	Transit Connect	1.6L	TDCi ECO III	RCM	✓	✓	✓	✓	00EF
2014	Transit Connect	1.6L	TDCi ECO III	SASM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	TRM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	ABS	✓	✓	✓	✓	0012
2014	Transit Connect	2.5L	IVCT	ABS	✓	✓	✓	✓	0012
2014	Transit Connect	2.5L	IVCT	ACM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	APIM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 0101, 020F
2014	Transit Connect	2.5L	IVCT	DDM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	FCDIM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	FCIM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	GPSM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	HCM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	HVAC	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	IPC	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	IPM-B	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	OCSM	✓	✓	✓	✓	000C
2014	Transit Connect	2.5L	IVCT	PAM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	PCM	✓	✓	✓	✓	0025
2014	Transit Connect	2.5L	IVCT	PDM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	PSCM	✓	✓	✓	✓	



2014	Transit Connect	2.5L	IVCT	RCM	✓	✓	✓		
2014	Transit Connect	2.5L	IVCT	SASM	✓	✓	✓		
2014	Transit Connect	2.5L	IVCT	TRM	✓	✓	✓		
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	ABS	✓	✓	✓	✓	
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	ABS/TCS	✓	✓	✓	✓	
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	CSM	✓	✓	✓	✓	
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	PCM			✓	✓	
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	PCM	✓	✓	✓	✓	0025
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ECS	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	ABS/TCS	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	CSM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	ECS	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	FFH	✓	✓	✓	✓	00CF
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	FIP	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	HEC	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	PAM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	PCM	✓	✓	✓	✓	0008, 0012, 0032
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	AFCM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	CSM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	ECS	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	FFH	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	FFH	✓	✓	✓	✓	00CF
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	HEC	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	PAM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	PCM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	PCM	✓	✓	✓	✓	0025, 00CF
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ECS	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0098, 0099, 00AB, 00AC, 00B4, 00C1
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0029, 002B, 0054, 00D7, 00DD, 00E8
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0029, 00E8
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 0054, 00D7, 00DD, 00E8
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	00E8
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F02D, F030, F0A2
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F020

2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0098, 0099, 00AB, 00AC, 00B4, 00C1
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	00DD, 00E8
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓		
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	GPSM	✓	✓	✓		
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓		
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓		
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓		00E5
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPM-B	✓	✓	✓		
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓		
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00B0, 00B1, 00B3, 00BC, 00BD, 00C1, 00C3, 00E7, 013B
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	PRB	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	TBC	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓		
Other	VX-1	1.4L	K14B	ABS	✓	✓	✓	✓	0212
Other	VX-1	1.4L	K14B	BCM#1	✓	✓	✓	✓	
Other	VX-1	1.4L	K14B	EPS	✓	✓	✓	✓	
Other	VX-1	1.4L	K14B	IC	✓	✓	✓	✓	
Other	VX-1	1.4L	K14B	PCM	✓	✓	✓	✓	
Other	VX-1	1.4L	K14B	RCM	✓	✓	✓	✓	
2001	Villager	3.3L	Other	PCM	✓	✓	✓	✓	
2002	Villager	3.3L	Other	PCM	✓	✓	✓	✓	
1995	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1995	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1995	Windstar	3.0L	V6 OHV	GEM	✓	✓	✓	✓	
1995	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1995.5	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1996	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1996	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1996	Windstar	3.0L	V6 OHV	GEM	✓	✓	✓	✓	
1996	Windstar	3.0L	V6 OHV	IAB	✓	✓	✓	✓	
1996	Windstar	3.0L	V6 OHV	PATS	✓	✓	✓	✓	
1996	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1996	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1996	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1996	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1996	Windstar	3.8L	V6 OHV	GEM	✓	✓	✓	✓	
1996	Windstar	3.8L	V6 OHV	IAB	✓	✓	✓	✓	
1996	Windstar	3.8L	V6 OHV	PATS	✓	✓	✓	✓	
1996	Windstar	3.8L	V6 OHV	PCM	✓	✓	✓	✓	0025
1997	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1997	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1997	Windstar	3.0L	V6 OHV	GEM	✓	✓	✓	✓	
1997	Windstar	3.0L	V6 OHV	IAB	✓	✓	✓	✓	
1997	Windstar	3.0L	V6 OHV	PATS	✓	✓	✓	✓	
1997	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1997	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1997	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1997	Windstar	3.8L	V6 OHV	GEM	✓	✓	✓	✓	
1997	Windstar	3.8L	V6 OHV	IAB	✓	✓	✓	✓	
1997	Windstar	3.8L	V6 OHV	PATS	✓	✓	✓	✓	

1997	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025
1998	Windstar	3. 0L	V6 OHV	ABS/TCS	✓	✓	✓		
1998	Windstar	3. 0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1998	Windstar	3. 0L	V6 OHV	GEM	✓	✓	✓	✓	
1998	Windstar	3. 0L	V6 OHV	IAB	✓	✓	✓	✓	
1998	Windstar	3. 0L	V6 OHV	PATS	✓	✓	✓		
1998	Windstar	3. 0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1998	Windstar	3. 0L	V6 OHV	RAP	✓	✓	✓	✓	
1998	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓		
1998	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1998	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	0008
1998	Windstar	3. 8L	V6 OHV	GEM	✓	✓	✓	✓	
1998	Windstar	3. 8L	V6 OHV	IAB	✓	✓	✓	✓	
1998	Windstar	3. 8L	V6 OHV	PATS	✓	✓	✓		
1998	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025
1998	Windstar	3. 8L	V6 OHV	RAP	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	DDM	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	FEM	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	IC	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	MC	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	NGSC	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	PAM	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1999	Windstar	3. 0L	V6 OHV	RCM	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	REM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	DDM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	0005, F042, F045, F08D, F090, F091, F092
1999	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	0005, F042, F045, F08D, F090, F091, F092, F0B4
1999	Windstar	3. 8L	V6 OHV	IC	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	LPSDM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	MC	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	NGSC	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	PAM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025
1999	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1999	Windstar	3. 8L	V6 OHV	RCM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	REM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	RPSDM	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	0005
2000	Windstar	3. 8L	V6 OHV	DDM	✓	✓	✓	✓	0005
2000	Windstar	3. 8L	V6 OHV	DDM	✓	✓	✓	✓	0005, F045
2000	Windstar	3. 8L	V6 OHV	DSM	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	0005, F042, F045, F08D, F090, F091, F092
2000	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	0005, F042, F045, F08D, F090, F091, F092, F0B4
2000	Windstar	3. 8L	V6 OHV	IC	✓	✓	✓	✓	F027, F08E, F08F
2000	Windstar	3. 8L	V6 OHV	LPSDM	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	MC	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	NGSC	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	PAM	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Windstar	3. 8L	V6 OHV	RCM	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	RCM	✓	✓	✓	✓	000C
2000	Windstar	3. 8L	V6 OHV	REM	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	RPSDM	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	0005
2002	Windstar	3. 8L	V6 OHV	DDM	✓	✓	✓	✓	0005
2002	Windstar	3. 8L	V6 OHV	DSM	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	0005
2002	Windstar	3. 8L	V6 OHV	IC	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	LPSDM	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	MC	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	NGSC	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	PAM	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Windstar	3. 8L	V6 OHV	RCM	✓	✓	✓	✓	000C
2002	Windstar	3. 8L	V6 OHV	REM	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	RPSDM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	DDM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	DSM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	IC	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	LPSDM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	MC	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	NGSC	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	PAM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Windstar	3. 8L	V6 OHV	RCM	✓	✓	✓	✓	000C
2003	Windstar	3. 8L	V6 OHV	REM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	RPSDM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	ABS	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	ABS	✓	✓	✓	✓	0008

2006	Zephyr/MKZ	3. 0L	4V	ACM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2006	Zephyr/MKZ	3. 0L	4V	DCSM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	DDM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	DSM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	DSP	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	EATC	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	GEM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	IC	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	OCSM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2006	Zephyr/MKZ	3. 0L	4V	PCM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2006	Zephyr/MKZ	3. 0L	4V	RCM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	TCM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	4X4	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	ABS	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	ABS	✓	✓	✓	✓	0008
2007	Zephyr/MKZ	3. 5L	4V	ACM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Zephyr/MKZ	3. 5L	4V	DCSM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	DDM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	DSM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	DSP	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	EATC	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	GEM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	IC	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	OCSM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2007	Zephyr/MKZ	3. 5L	4V	PCM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2007	Zephyr/MKZ	3. 5L	4V	RCM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	SDARS	✓	✓	✓	✓	
2007	Zephyr/MKZ	3. 5L	4V	SDARS	✓	✓	✓	✓	0019
2007	Zephyr/MKZ	3. 5L	4V	TCM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	4X4	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	ABS	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	ABS	✓	✓	✓	✓	0008
2008	Zephyr/MKZ	3. 5L	4V	ACM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018, F05A, F062, F07A
2008	Zephyr/MKZ	3. 5L	4V	APIM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Zephyr/MKZ	3. 5L	4V	DCSM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	DDM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	DSM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	DSM	✓	✓	✓	✓	0005, F041
2008	Zephyr/MKZ	3. 5L	4V	DSM	✓	✓	✓	✓	F041
2008	Zephyr/MKZ	3. 5L	4V	DSP	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F044, F048, F04C, F057, F085, F086, F08A
2008	Zephyr/MKZ	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	0042, F044, F048, F04C, F057, F085, F086, F08A
2008	Zephyr/MKZ	3. 5L	4V	HVAC	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	IC	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	IC	✓	✓	✓	✓	0005, F027
2008	Zephyr/MKZ	3. 5L	4V	IC	✓	✓	✓	✓	F027
2008	Zephyr/MKZ	3. 5L	4V	OCSM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2008	Zephyr/MKZ	3. 5L	4V	PAM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	PAM	✓	✓	✓	✓	0005
2008	Zephyr/MKZ	3. 5L	4V	PCM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2008	Zephyr/MKZ	3. 5L	4V	RCM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	RCM	✓	✓	✓	✓	F022, F05D
2008	Zephyr/MKZ	3. 5L	4V	SDARS	✓	✓	✓	✓	
2008	Zephyr/MKZ	3. 5L	4V	SDARS	✓	✓	✓	✓	0005
2008	Zephyr/MKZ	3. 5L	4V	TCM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3. 5L	4V	4X4	✓	✓	✓	✓	
2009	Zephyr/MKZ	3. 5L	4V	ABS	✓	✓	✓	✓	
2009	Zephyr/MKZ	3. 5L	4V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2009	Zephyr/MKZ	3. 5L	4V	ACM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3. 5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Zephyr/MKZ	3. 5L	4V	APIM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3. 5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Zephyr/MKZ	3. 5L	4V	DCSM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3. 5L	4V	DCSM	✓	✓	✓	✓	0005
2009	Zephyr/MKZ	3. 5L	4V	DDM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3. 5L	4V	DSM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3. 5L	4V	DSM	✓	✓	✓	✓	0005, F041
2009	Zephyr/MKZ	3. 5L	4V	DSP	✓	✓	✓	✓	
2009	Zephyr/MKZ	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	
2009	Zephyr/MKZ	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F044, F048, F04C, F057, F085, F086, F08A
2009	Zephyr/MKZ	3. 5L	4V	HVAC	✓	✓	✓	✓	
2009	Zephyr/MKZ	3. 5L	4V	IC	✓	✓	✓	✓	

2009	Zephyr/MKZ	3.5L	4V	IC	✓	✓	✓	✓	0005, F027
2009	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2009	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	0005
2009	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2009	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	F022, F05D
2009	Zephyr/MKZ	3.5L	4V	SDARS	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	SDARS	✓	✓	✓	✓	0005
2009	Zephyr/MKZ	3.5L	4V	TCM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	4X4	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2010	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	0017
2010	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Zephyr/MKZ	3.5L	4V	DCSM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	DCSM	✓	✓	✓	✓	0005
2010	Zephyr/MKZ	3.5L	4V	DDM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	DDM	✓	✓	✓	✓	0005
2010	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	0005, F041
2010	Zephyr/MKZ	3.5L	4V	DSP	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	DSP	✓	✓	✓	✓	0005
2010	Zephyr/MKZ	3.5L	4V	FCIM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	FDIM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	FDIM	✓	✓	✓	✓	0005, F062
2010	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C, F08A
2010	Zephyr/MKZ	3.5L	4V	GPSM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	HCM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	HVAC	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	IILCM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	IPC	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	IPC	✓	✓	✓	✓	0005
2010	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	0005
2010	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037
2010	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	0005
2010	Zephyr/MKZ	3.5L	4V	SOD-L	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	SOD-R	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	TCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DCSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DDM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	HCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	IILCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	4X4	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2011	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	0019

2011	Zephyr/MKZ	3.5L	4V	DCSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	DDM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	DSP	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	FCIM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	FDIM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Zephyr/MKZ	3.5L	4V	GPSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	HCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	HVAC	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	I LCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	IPC	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037
2011	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	SOD-L	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	SOD-R	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	TCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DCSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DDM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	HCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	I LCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	4X4	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2012	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2012	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	0019
2012	Zephyr/MKZ	3.5L	4V	DCSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	DDM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	DSP	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	FCIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	FDIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Zephyr/MKZ	3.5L	4V	GPSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	HCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	HVAC	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	I LCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	IPC	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037
2012	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	SOD-L	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	SOD-R	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	TCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	4X4	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	ABS	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	ACM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	APIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	DCSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	DDM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	DSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	DSP	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	FCIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	FDIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	GEM / SJB	✓	✓	✓	✓	0042

2012	Zephyr/MKZ	Other	Other	GPSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	HCM	✓	✓	✓		
2012	Zephyr/MKZ	Other	Other	HVAC	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	IILCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	IPC	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	OCSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	PAM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	RCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	SOD-L	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	SOD-R	✓	✓	✓	✓	

XTool