



深圳市朗仁科技有限公司
Shenzhen Xtooltech Co.,
Ltd

BAOJUN AUTOMOBILE V26.50

| Car series | System type | Model | Function menu | Password required | Password can be read/calculated | Password digits |
|---------------|------------------|--|--|-------------------|---------------------------------|-----------------|
| BAOJUN | Immobiliser | 330 | 1. Read the number of keys 2. Add key 3. Clear key 4. New system matching | YES | NO | 4 |
| | | 310 | 1. Read the number of keys | YES | NO | 8 |
| | | 360 | 2. Read BCM status | | | |
| | | 510 | 3. Add key | | | |
| | | 530 | 4. Clear key | | | |
| | | 560 | 5. ECM reset | | | |
| | | 310 wagon | 6. BCM Program | | | |
| | | 730 | 7. ECM Program | | | |
| | 610 | 1. Read the number of keys 2. Remote matching | NO | | | |
| | 630 | 3. Key match 4. Key removal | | | | |
| | Smart key system | 310 Wagon | 1. Read ECU Information | NO | | |
| | | 510 | 2. Add key | | | |
| | | 530 | 3. Lost all keys | | | |
| | | 560 | 4. Reset PEPS | | | |
| 730 | | 5. Reset ESCL | | | | |
| E100 | | 6. Match PEPS | | | | |
| E200 | 7. Match ESCL | | | | | |
| Remote system | 360 | 1. Remote matching | 否 | | | |
| | E100 | | | | | |

| | | | | | | |
|---------------|------------------|--------------------|----------------------------|-----|----|---|
| New BAOJUN | Immobiliser | E200 | | | | |
| | | RC-6 | 1. Read the number of keys | YES | NO | 8 |
| | | RM-5 | 2. Read BCM status | | | |
| | | RS-3 | 3. Add key | | | |
| | | RS-5 | 4. Clear key | | | |
| | | RS-7 | 5. ECM reset | | | |
| | | E300 LV2/LV3 | 6. BCM Program | | | |
| | | 7. ECM Program | | | | |
| | Smart key system | RC-6 | | NO | | |
| | | RM-5 | | | | |
| | | RS-3 | 1. Add key | | | |
| | | RS-5 | 2. Lost all keys | | | |
| | | RS-7 | | | | |
| Remote system | E300 LV1 | 1. Remote matching | NO | | | |

*XT*TOOL