

Immobiliser Function List			
Software Version: 26.92			
Automaker	Model/Protocol	System	Function
Chrysler	Auto		
Chrysler	Manual(CAN Type 1)	Immobiliser	1.Number of keys 2.Program old keys 3.Program new keys 4.Erase keys 5.Program remote
Chrysler	Manual(CAN Type 2)	Immobiliser	1.Live data 2.Program old key 3.Program new key 4.Erase keys 5.Read security code
Chrysler	Manual(CAN Type 3)	Immobiliser	1.Live data 2.Program old key 3.Program new key 4.Erase keys 5.Read security code
Chrysler	Manual(CAN Type 4)	Immobiliser	1.Live data 2.Program old key 3.Program new key 4.Erase keys 5.Read security code
Chrysler	Manual(VPW Type)	Immobiliser	1.Program keys 2.Erase keys
Chrysler	Grand Cherokee	Synchronous Smart	1.Synchronous smart key
Chrysler	300(11-)	Smart key	1.Add smart key 2.Erase smart keys 3.Read security code
Chrysler	Freemont	Smart key	1.Add smart key 2.Erase smart keys 3.Read security code

Jeep	G.cherokee(14-)	Smart key	1.Add smart key 2.Erase smart keys
Dodge	Challenger(-14)	Smart key	1.Live data 2.Program old key 3.Program new key 4.Erase keys 5.Read security code
Dodge	Challenger(15-)	Smart key	1.Add smart key 2.Erase smart keys 3.Read security code
Dodge	Charger (11-)	Smart key	1.Add smart key 2.Erase smart keys 3.Read security code
Dodge	Durango (14-)	Smart key	1.Add smart key 2.Erase smart keys
Dodge	Journey (11-)	Smart key	1.Add smart key 2.Erase smart keys 3.Read security code
Dodge	Magnum (11-)	Smart key	1.Add smart key 2.Erase smart keys 3.Read security code
Dodge	Ram truck (13-)	Smart key	1.Add smart key 2.Erase smart keys
Dodge	Viper (13-)	Smart key	1.Add smart key 2.Erase smart keys 3.Read security code
Chrysler	300M (99-00)	Remote	1.Program remotes
Chrysler	Concorde(98-04)	Remote	1.Program remotes
Chrysler	LHS(99-01)	Remote	1.Program remotes
Chrysler	PT cruiser(01-05)	Remote	1.Program remotes
Chrysler	Sebring(01-06)	Remote	1.Program remotes
Chrysler	Town&country(01-03)	Remote	1.Program remotes
Dodge	Caravan(01-03)	Remote	1.Program remotes
Dodge	Dakota(01-04)	Remote	1.Program remotes
Dodge	Durango(01-03)	Remote	1.Program remotes
Dodge	Intrepid(98-04)	Remote	1.Program remotes
Dodge	Neon(00-05)	Remote	1.Program remotes

Dodge	Ram(02-05)	Remote	1.Program remotes
Dodge	Startus(01-06)	Remote	1.Program remotes
Jeep	G.Cherokee(01-03)	Remote	1.Program remotes
Jeep	Liberty(02-04)	Remote	1.Program remotes
Select from Type	Type1	Remote	1.Program remotes
Select from Type	Type2	Remote	1.Program remotes
Select from Type	Type3	Remote	1.Program remotes
Select from Type	Type4	Remote	1.Proximity 2.Read security code
Select from Type	Type5	Remote	1.Program remote 2.Erase remote
Select from Type	Type6	Remote	1.Program remotes
Select from Type	Type7	Remote	1.Program remotes
Select from Type	Type8	Remote	1.Program remotes

XTOOL