

### Immobiliser Function List

**Software Version: 26.75**

Automaker	Model/Ecu	System	Year	Function
Nissan/Infiniti	Type 1(4 pincode)	Pin Calculator		
Nissan/Infiniti	Type 2(4 pincode)	Pin Calculator		1. Made in Mexico 2. Made in Germany 3. Made in Europe
Nissan/Infiniti	Type 3(20 pincode)	Pin Calculator		
Nissan/Infiniti	Help			
Nissan/Infiniti	Read bcm code and Release steering lock			1. Read BCM code 2. Release steering lock
Nissan/Infiniti	4 pincode - type 1	Immobiliser system		1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	4 pincode - type 2	Immobiliser system		1. Erase DTC 2. Program keys
Nissan/Infiniti	12 pincode - type 1	Immobiliser system		1. Number of keys 2. Program keys
Nissan/Infiniti	12 pincode - type 2	Immobiliser system		1. Read number of keys 2. Program keys
Nissan/Infiniti	20 pincode - type 2	Immobiliser system		1. Program keys
Nissan/Infiniti	4 pincode - type 1	Smart key system		1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	4 pincode - type 2	Smart key system		1. Erase DTC 2. Program keys
Nissan/Infiniti	4 pincode - type 3	Smart key system		1. Program smart keys 2. Erase all smart keys 3. Program steering lock

Nissan/Infiniti	4 pincode - type 4	Smart key system		1. Program smart keys 2. Erase all smart keys
Nissan/Infiniti	4 pincode - type 5	Smart key system		1. Read BCM code 2. Release steering lock 3. Program smart keys
Nissan/Infiniti	4 pincode - type 6	Smart key system		1. Release steering lock 2. Program smart keys
Nissan/Infiniti	12 pincode	Smart key system		1. Read number of keys 2. Program keys 3. Program remote 4. Erase remotes
Nissan/Infiniti	20 pincode - type1	Smart key system		1. Program smart keys
Nissan/Infiniti	20 pincode - type2	Smart key system		1. Program smart keys 2. Replace engine ECU
Nissan/Infiniti	Teana	Body System(BCM)	-2012	1. Read BCM code 2. Release steering lock
Nissan/Infiniti	Teana	Smart key system	-2012	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Teana	Smart key system	-2012	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Teana	Smart key system	2013-	1. Program smart keys 2. Replace engine ECU
Nissan/Infiniti	New March	Smart key system		1. Read BCM code 2. Release steering lock 3. Program smart keys
Nissan/Infiniti	New Sunny	Smart key system		1. Read BCM code 2. Release steering lock 3. Program smart keys

Nissan/Infiniti	New Tiida	Smart key system		1. Read BCM code 2. Release steering lock 3. Program smart keys
Nissan/Infiniti	Altima Hybrid	Smart key system	07-11	1. Release steering lock 2. Program smart keys
Nissan/Infiniti	LANNIA(2015-)	Smart key system		1. Read BCM code 2. Release steering lock 3. Program smart keys
Nissan/Infiniti	Qichen	Body System(BCM)		1. Read BCM code 2. Release steering lock
Nissan/Infiniti	Qichen	Immobiliser system		1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Qichen	Immobiliser system		1. Erase DTC 2. Program keys
Nissan/Infiniti	New Sylphy	Without Smart key system		1. Erase DTC 2. Program keys
Nissan/Infiniti	New Sylphy	With Smart key system		1. Read BCM code 2. Release steering lock
Nissan/Infiniti	New X-Trail	With Smart key system		1. Program smart keys
Nissan/Infiniti	New X-Trail	Without Smart key system		1. Program keys
Nissan/Infiniti	Murano	Smart key system		1. Program smart keys 2. Replace engine ECU
Nissan/Infiniti	Qashqai	With Smart key system		1. Program smart keys
Nissan/Infiniti	Qashqai	Without Smart key system		1. Program keys
Nissan/Infiniti	Qashqai	Without Smart key system		1. Erase DTC 2. Program keys
Nissan/Infiniti	JX35	Smart key system		1. Program smart keys 2. Replace engine ECU
Nissan/Infiniti	Q50	Smart key system		1. Program smart keys 2. Replace engine ECU
Nissan/Infiniti	QX60	Smart key system		1. Program smart keys 2. Replace engine ECU

Nissan/Infiniti	Cima	Smart key system		1. Program smart keys 2. Replace engine ECU
Nissan/Infiniti	type 1	Remote		1. Program a remote key 2. Erase remote keys
Nissan/Infiniti	type 2	Remote		1. Program remote 2. Erase remotes

*XTOOL*