



# Shenzhen Xtooltech Co., Ltd

## LEXUS Function list V12.80

Tips and Instructions:

- \* This feature is new.
- √ This feature is supported.
- This feature is not supported.
- ※ This feature is partially supported.

Area	Vehicle Type	Mode	Year	System	Read Trouble Code	Clear Trouble Code	Live Data	Read Freeze Frame	Actuation Test	Special Functions
Europe or Others	CT200h	ZWA	All years	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0101
Europe or Others	CT200h	ZWA	All years	Hybrid Control	√	√	√	√	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058

Europe or Others	CT200h	ZWA	All years	Cruise Control	√	√	√	√		
Europe or Others	CT200h	ZWA	All years	ABS/VSC/TPC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0088
Europe or Others	CT200h	ZWA	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002
Europe or Others	CT200h	ZWA	All years	EMPS	√	√	√	√		SP0001, SP0009, SP0010
Europe or Others	CT200h	ZWA	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	CT200h	ZWA	All years	Transmission Control	√	√	√	√		

Europe or Others	CT200h	ZWA	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	CT200h	ZWA	All years	Theft Deterrent	✓	✓	✓		0329, 0333, 0494, 0495, 0496, 0497, 0498, 0499, 0500, 0501, 0502	
Europe or Others	CT200h	ZWA	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	CT200h	ZWA	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	CT200h	ZWA	All years	PM1 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	CT200h	ZWA	All years	PM2 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	CT200h	ZWA	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	CT200h	ZWA	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	CT200h	ZWA	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	CT200h	ZWA	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	CT200h	ZWA	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	CT200h	ZWA	All years	Master Switch	✓	✓	✓			

Europe or Others	CT200h	ZWA	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	CT200h	ZWA	All years	Combinati on Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	CT200h	ZWA	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	CT200h	ZWA	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	CT200h	ZWA	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	CT200h	ZWA	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0007, SP0008	

Europe or Others	CT200h	ZWA	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015
Europe or Others	CT200h	ZWA	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	CT200h	ZWA	All years	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036
Europe or Others	CT200h	ZWA	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
Europe or Others	CT200h	ZWA	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050
Europe or Others	CT200h	ZWA	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
Europe or Others	CT200h	ZWA	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	CT200h	ZWA	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0040, SP0044
Europe or Others	CT200h	ZWA	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
Europe or Others	CT200h	ZWA	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	
Europe or Others	CT200h	ZWA	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	CT200h	ZWA	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	

Europe or Others	CT200h	ZWA	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				✓		
Europe or Others	CT200h	ZWA	All years	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	
Europe or Others	CT200h	ZWA	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	CT200h	ZWA	All years	Road Sign Assist	✓	✓	✓	✓	1183	
Europe or Others	CT200h	ZWA	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	CT200h	ZWA	All years	Telematics	✓	✓	✓	✓		SP0059, SP0060
Europe or Others	ES200	ASV61	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	SP0004, SP0026, SP0029, SP0032, SP0042, SP0073, SP0075, SP0101, SP0102

Europe or Others	ES200	ASV61	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	ES200	ASV61	All years	Stop and Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	SP0004, SP0030, SP0035, SP0092, SP0093, SP0094, SP0095, SP0096, SP0097
Europe or Others	ES200	ASV61	All years	Cruise Control	✓	✓	✓	✓		



Europe or Others	ES200	ASV61	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	ES200	ASV61	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP002
Europe or Others	ES200	ASV61	All years	EMPS	✓	✓	✓	✓		SP0001, SP009, SP0010
Europe or Others	ES200	ASV61	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	ES200	ASV61	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0087
Europe or Others	ES200	ASV61	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	

Europe or Others	ES200	ASV61	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
Europe or Others	ES200	ASV61	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
Europe or Others	ES200	ASV61	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001
Europe or Others	ES200	ASV61	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

Europe or Others	ES200	ASV61	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	ES200	ASV61	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	ES200	ASV61	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	ES200	ASV61	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES200	ASV61	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES200	ASV61	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES200	ASV61	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES200	ASV61	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	ES200	ASV61	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	ES200	ASV61	All years	Master Switch	✓	✓	✓			
Europe or Others	ES200	ASV61	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	ES200	ASV61	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	ES200	ASV61	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	ES200	ASV61	All years	Road Sign Assist	✓	✓	✓	✓	1183	
Europe or Others	ES200	ASV61	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

Europe or Others	ES200	ASV61	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	ES200	ASV61	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	ES200	ASV61	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	ES200	ASV61	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	ES200	ASV61	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	ES200	ASV61	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	ES200	ASV61	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	ES200	ASV61	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	ES200	ASV61	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	ES200	ASV61	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	ES200	ASV61	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	ES200	ASV61	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	SP0061, SP0069

Europe or Others	ES200	ASZ10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	
------------------------	-------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

Europe or Others	ES200	ASZ10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	ES200	ASZ10	All years	Stop and Start	✓	✓	✓		1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
Europe or Others	ES200	ASZ10	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	ES200	ASZ10	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	
Europe or Others	ES200	ASZ10	All years	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
Europe or Others	ES200	ASZ10	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	ES200	ASZ10	All years	EMPS	✓	✓	✓	✓		
Europe or Others	ES200	ASZ10	All years	Front Recognition Camera	✓	✓	✓			

Europe or Others	ES200	ASZ10	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	ES200	ASZ10	All years	Panoramic view monitor	✓	✓	✓	✓		
Europe or Others	ES200	ASZ10	All years	Steering Angle Sensor	✓	✓	✓			
Europe or Others	ES200	ASZ10	All years	Parking Assist Camera	✓	✓	✓	✓		
Europe or Others	ES200	ASZ10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	ES200	ASZ10	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
Europe or Others	ES200	ASZ10	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	



Europe or Others	ES200	ASZ10	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	ES200	ASZ10	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	ES200	ASZ10	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	ES200	ASZ10	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	ES200	ASZ10	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	ES200	ASZ10	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	ES200	ASZ10	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	ES200	ASZ10	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	ES200	ASZ10	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	ES200	ASZ10	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	ES200	ASZ10	All years	Master Switch	✓	✓	✓			
Europe or Others	ES200	ASZ10	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	ES200	ASZ10	All years	Tilt&Telescopic	✓	✓	✓		1513, 1514	
Europe or Others	ES200	ASZ10	All years	Combination Meter	✓	✓	✓		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
Europe or Others	ES200	ASZ10	All years	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
Europe or Others	ES200	ASZ10	All years	Road Sign Assist	✓	✓	✓			

Europe or Others	ES200	ASZ10	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	ES200	ASZ10	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	ES200	ASZ10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
Europe or Others	ES200	ASZ10	All years	Rain and/or Humidity Sensor	✓	✓	✓			
Europe or Others	ES200	ASZ10	All years	Wiper	✓	✓	✓	✓	0031, 0032	
Europe or Others	ES200	ASZ10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	ES200	ASZ10	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
Europe or Others	ES200	ASZ10	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	ES200	ASZ10	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	
Europe or Others	ES200	ASZ10	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			

Europe or Others	ES200	ASZ10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	ES200	ASZ10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	ES200	ASZ10	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	ES200	ASZ10	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	ES200	ASZ10	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	ES200	ASZ10	All years	Front Radar Sensor	✓	✓	✓			
Europe or Others	ES200	ASZ10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	ES200	ASZ10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	ES200	ASZ10	All years	Grill Shutter	✓	✓	✓		0037, 0038, 0039, 0040	
Europe or Others	ES200	ASZ10	All years	Pedestrian Protection	✓	✓	✓			
Europe or Others	ES200	ASZ10	All years	Telematics	✓	✓	✓	✓	0036, 1521, 1522	
Europe or Others	ES200	ASZ10	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	ES200	MXZA1 0	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	
------------------------	-------	------------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

Europe or Others	ES200	MXZA10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	ES200	MXZA10	All years	Stop and Start	✓	✓	✓		1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
Europe or Others	ES200	MXZA10	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	ES200	MXZA10	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	
Europe or Others	ES200	MXZA10	All years	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
Europe or Others	ES200	MXZA10	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	ES200	MXZA10	All years	EMPS	✓	✓	✓	✓		
Europe or Others	ES200	MXZA10	All years	Front Recognition Camera	✓	✓	✓			

Europe or Others	ES200	MXZA10	All years	Lane Control	√	√	√		0824, 0989	
Europe or Others	ES200	MXZA10	All years	Steering Angle Sensor	√	√	√			
Europe or Others	ES200	MXZA10	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	ES200	MXZA10	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	ES200	MXZA10	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		
Europe or Others	ES200	MXZA10	All years	Pre-Collision System	√	√	√		1524, 1525, 1526	

Europe or Others	ES200	MXZA10	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	ES200	MXZA10	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	ES200	MXZA10	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	ES200	MXZA10	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	ES200	MXZA10	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	ES200	MXZA10	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	ES200	MXZA10	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	ES200	MXZA10	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	ES200	MXZA10	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	



Europe or Others	ES200	MXZA10	All years	Master Switch	✓	✓	✓			
Europe or Others	ES200	MXZA10	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	ES200	MXZA10	All years	Tilt&Telescopic	✓	✓	✓		1513, 1514	
Europe or Others	ES200	MXZA10	All years	Combination Meter	✓	✓	✓		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
Europe or Others	ES200	MXZA10	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	ES200	MXZA10	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

Europe or Others	ES200	MXZA10	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
Europe or Others	ES200	MXZA10	All years	Rain and/or Humidity Sensor	√	√	√			
Europe or Others	ES200	MXZA10	All years	Wiper	√	√	√	√	0031, 0032	
Europe or Others	ES200	MXZA10	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	ES200	MXZA10	All years	Adaptive Front Lighting System (AFS) (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	
Europe or Others	ES200	MXZA10	All years	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	ES200	MXZA10	All years	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0006	
Europe or Others	ES200	MXZA10	All years	Front Recognition Camera (Front Lighting Control)	√	√	√			

Europe or Others	ES200	MXZA10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	ES200	MXZA10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	ES200	MXZA10	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	ES200	MXZA10	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	ES200	MXZA10	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	ES200	MXZA10	All years	Front Radar Sensor	✓	✓	✓			
Europe or Others	ES200	MXZA10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	ES200	MXZA10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	ES200	MXZA10	All years	Pedestrian Protection	✓	✓	✓			
Europe or Others	ES200	MXZA10	All years	Telematics	✓	✓	✓		1521, 1522	

Europe or Others	ES240	ACV	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101
Europe or Others	ES240	ACV	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	ES240	ACV	All years	ABS/VSC/T RC	✓	✓	✓	✓	0026, 0376, 0 377, 0379, 03 80, 0382, 038 3, 0471, 0821 , 0822, 0825, 0826, 0827, 0 828, 0829, 08 30, 0831, 083 2, 0833, 0834 , 0835, 0836, 0837, 0838, 0 839, 0840, 08 41, 0842, 084 3, 0844, 0845 , 0846, 0847, 0848, 0849, 0 850, 0851, 08 52, 0853, 085 4, 0855, 0856 , 0857, 0858, 0859, 0860, 0 861, 0862, 08 63, 0864, 086 5, 0866, 0867 , 0868, 0869, 0870, 0871, 0 872, 0873, 08 74, 0875, 087 6, 0877, 0878 , 0879, 0880,	SP0001, SP0 003, SP0021 , SP0022, SP 0023, SP002 4
------------------------	-------	-----	--------------	-----------------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------

Europe or Others	ES240	ACV	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	ES240	ACV	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	ES240	ACV	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	ES240	ACV	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	ES240	ACV	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	ES240	ACV	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	ES240	ACV	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	ES240	ACV	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	ES240	ACV	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	ES240	ACV	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	

Europe or Others	ES240	ACV	All years	Master Switch	✓	✓	✓			
Europe or Others	ES240	ACV	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	ES240	ACV	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	ES240	ACV	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	ES240	ACV	All years	Mirror	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0433, 0434, 0435, 0436, 0437	
Europe or Others	ES240	ACV	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	ES240	ACV	All years	AFS	✓	✓	✓	✓	0007, SP0008	



Europe or Others	ES240	ACV	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015
Europe or Others	ES240	ACV	All years	Navigation System	√	√	√	√		SP0049, SP0050
Europe or Others	ES250/ES260	ASV	All years	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	ES250/ES260	ASV	All years	Cruise Control	√	√	√	√		

Europe or Others	ES250/ES260	ASV	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	ES250/ES260	ASV	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	ES250/ES260	ASV	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	ES250/ES260	ASV	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087

Europe or Others	ES250/ES260	ASV	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	ES250/ES260	ASV	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	ES250/ES260	ASV	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	ES250/ES260	ASV	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	ES250/ES260	ASV	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	ES250/ES260	ASV	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES250/ES260	ASV	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES250/ES260	ASV	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES250/ES260	ASV	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES250/ES260	ASV	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	ES250/ES260	ASV	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	ES250/ES260	ASV	All years	Master Switch	✓	✓	✓		
Europe or Others	ES250/ES260	ASV	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	ES250/ES260	ASV	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	ES250/ES260	ASV	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	ES250/ES260	ASV	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	ES250/ES260	ASV	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	ES250/ES260	ASV	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	ES250/ES260	ASV	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0007, SP0008	
Europe or Others	ES250/ES260	ASV	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	ES250/ES260	ASV	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	ES250/ES260	ASV	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	ES250/ES260	ASV	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	ES250/ES260	ASV	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	ES250/ES260	ASV	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	ES250/ES260	ASV	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	ES250/ES260	ASV	All years	Stop and Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	SP0004, SP0030, SP0035, SP0093, SP0094, SP0095, SP0096, SP0097

Europe or Others	ES250/ES260	ASV	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	ES250/ES260	ASV	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0087
Europe or Others	ES250/ES260	ASV	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	ES250/ES260	ASV	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	ES250/ES260	ASV	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	ES250/ES260	ASV	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	ES250/ES260	ASV	All years	Road Sign Assist	✓	✓	✓	✓	1183	
Europe or Others	ES250/ES260	ASV	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	ES250/ES260	ASV	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	ES250/ES260	ASV	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	SP0061, SP0069

Europe or Others	ES250/ES 260	AXZA1 0	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	
------------------------	-----------------	------------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--



Europe or Others	ES250/ES260	AXZA10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	ES250/ES260	AXZA10	All years	Stop and Start	✓	✓	✓		1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
Europe or Others	ES250/ES260	AXZA10	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	ES250/ES260	AXZA10	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	
Europe or Others	ES250/ES260	AXZA10	All years	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
Europe or Others	ES250/ES260	AXZA10	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	ES250/ES260	AXZA10	All years	EMPS	✓	✓	✓	✓		
Europe or Others	ES250/ES260	AXZA10	All years	Front Recognition Camera	✓	✓	✓			

Europe or Others	ES250/ES260	AXZA10	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	ES250/ES260	AXZA10	All years	Panoramic view monitor	✓	✓	✓	✓		
Europe or Others	ES250/ES260	AXZA10	All years	Steering Angle Sensor	✓	✓	✓			
Europe or Others	ES250/ES260	AXZA10	All years	Parking Assist Camera	✓	✓	✓	✓		
Europe or Others	ES250/ES260	AXZA10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	ES250/ES260	AXZA10	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
Europe or Others	ES250/ES260	AXZA10	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	

Europe or Others	ES250/ES260	AXZA10	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818
Europe or Others	ES250/ES260	AXZA10	All years	Accessory Gateway	✓	✓	✓	✓	
Europe or Others	ES250/ES260	AXZA10	All years	Central Gateway	✓	✓	✓	✓	
Europe or Others	ES250/ES260	AXZA10	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526
Europe or Others	ES250/ES260	AXZA10	All years	Driver Door Motor	✓	✓	✓		0528
Europe or Others	ES250/ES260	AXZA10	All years	Passenger Door Motor	✓	✓	✓		0528
Europe or Others	ES250/ES260	AXZA10	All years	Left Rear Door Motor	✓	✓	✓		0528
Europe or Others	ES250/ES260	AXZA10	All years	Right Rear Door Motor	✓	✓	✓		0528
Europe or Others	ES250/ES260	AXZA10	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519

Europe or Others	ES250/ES260	AXZA10	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	ES250/ES260	AXZA10	All years	Master Switch	√	√	√			
Europe or Others	ES250/ES260	AXZA10	All years	Sliding Roof	√	√	√		0529	
Europe or Others	ES250/ES260	AXZA10	All years	Tilt&Telescopic	√	√	√		1513, 1514	
Europe or Others	ES250/ES260	AXZA10	All years	Combination Meter	√	√	√		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
Europe or Others	ES250/ES260	AXZA10	All years	Head Up Display	√	√	√		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
Europe or Others	ES250/ES260	AXZA10	All years	Road Sign Assist	√	√	√			

Europe or Others	ES250/ES260	AXZA10	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	ES250/ES260	AXZA10	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	ES250/ES260	AXZA10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026
Europe or Others	ES250/ES260	AXZA10	All years	Rain and/or Humidity Sensor	✓	✓	✓		
Europe or Others	ES250/ES260	AXZA10	All years	Wiper	✓	✓	✓	✓	0031, 0032
Europe or Others	ES250/ES260	AXZA10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
Europe or Others	ES250/ES260	AXZA10	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028
Europe or Others	ES250/ES260	AXZA10	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015
Europe or Others	ES250/ES260	AXZA10	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006
Europe or Others	ES250/ES260	AXZA10	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓		

Europe or Others	ES250/ES260	AXZA10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	ES250/ES260	AXZA10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	ES250/ES260	AXZA10	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	ES250/ES260	AXZA10	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	ES250/ES260	AXZA10	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	ES250/ES260	AXZA10	All years	Front Radar Sensor	✓	✓	✓			
Europe or Others	ES250/ES260	AXZA10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	ES250/ES260	AXZA10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	ES250/ES260	AXZA10	All years	Pedestrian Protection	✓	✓	✓			
Europe or Others	ES250/ES260	AXZA10	All years	Telematics	✓	✓	✓	✓	0036, 1521, 1522	
Europe or Others	ES250/ES260	AXZA10	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	ES300	MCV	All years	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1 126, 1127, 11 28, 1129, 113 0, 1131, 1132 , 1133, 1134, 1135, 1136, 1 137, 1138, 11 39, 1140, 114 1, 1142, 1143 , 1144, 1145, 1146, 1147, 1 148, 1149, 11 50, 1151, 115 2, 1153, 1154 , 1155, 1156, 1157, 1158, 1 159, 1160, 11 61, 1162, 116 3, 1164, 1165 , 1166, 1167, 1168, 1169, 1 170, 1171, 11 72, 1173, 117 4, 1175, 1176 , 1177, 1178, 1179, 1180	SP0003, SP0 004
------------------------	-------	-----	--------------	-------------------	---	---	---	---	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------

Europe or Others	ES300	MCV	All years	ABS/VSC/TRC	√	√	√	√	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021, SP0023
Europe or Others	ES300	MCV	All years	Supplement Restraint System (SRS) Airbag	√	√	√			SP0001, SP0004
Europe or Others	ES300	MCV	All years	Cruise Control	√	√	√	√		
Europe or Others	ES300	MCV	All years	EMS	√	√	√		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001
Europe or Others	ES300	MCV	All years	Immobiliser	√	√	√			SP0011, SP0013, SP0148



Europe or Others	ES300	MCV	All years	Theft Deterrent	✓	✓	✓	0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	
Europe or Others	ES300	MCV	All years	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
Europe or Others	ES300	MCV	All years	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	ES300	MCV	All years	Passenger Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	

Europe or Others	ES300h	AVV	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	ES300h	AVV	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058
Europe or Others	ES300h	AVV	All years	Cruise Control	✓	✓	✓	✓	0017, 0018	SP0061, SP0069

Europe or Others	ES300h	AVV	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0088
Europe or Others	ES300h	AVV	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	ES300h	AVV	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	ES300h	AVV	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087

Europe or Others	ES300h	AVV	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	ES300h	AVV	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	ES300h	AVV	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	ES300h	AVV	All years	PM1 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	ES300h	AVV	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	ES300h	AVV	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES300h	AVV	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES300h	AVV	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES300h	AVV	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES300h	AVV	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	ES300h	AVV	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	ES300h	AVV	All years	Master Switch	✓	✓	✓		
Europe or Others	ES300h	AVV	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	ES300h	AVV	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	ES300h	AVV	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	ES300h	AVV	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	ES300h	AVV	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	ES300h	AVV	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	ES300h	AVV	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0007, SP0008	
Europe or Others	ES300h	AVV	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	ES300h	AVV	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	ES300h	AVV	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	ES300h	AVV	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	ES300h	AVV	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	ES300h	AVV	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	ES300h	AVV	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	ES300h	AVV	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	SP0061, SP0069
Europe or Others	ES300h	AVV	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	ES300h	AVV	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

Europe or Others	ES300h	AVV	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	ES300h	AVV	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0087
Europe or Others	ES300h	AVV	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	ES300h	AVV	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	ES300h	AVV	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	ES300h	AVV	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	ES300h	AVV	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
Europe or Others	ES300h	AVV	All years	Radar Cruise 1	✓	✓	✓	✓		



Europe or Others	ES300h	AXZH10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	
Europe or Others	ES300h	AXZH10	All years	Hybrid Control	✓	✓	✓		0070, 0071, 0079, 0081, 0180, 0194, 0195, 1207, 1208, 1493, 1494, 1495, 1496, 1497	
Europe or Others	ES300h	AXZH10	All years	Motor Generator	✓	✓	✓	✓		
Europe or Others	ES300h	AXZH10	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	ES300h	AXZH10	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	

Europe or Others	ES300h	AXZH10	All years	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
Europe or Others	ES300h	AXZH10	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	ES300h	AXZH10	All years	Tire Pressure Monitor	√	√	√			
Europe or Others	ES300h	AXZH10	All years	EMPS	√	√	√	√		

Europe or Others	ES300h	AXZH10	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397
Europe or Others	ES300h	AXZH10	All years	Front Recognition Camera	✓	✓	✓		
Europe or Others	ES300h	AXZH10	All years	Lane Control	✓	✓	✓		0824, 0989
Europe or Others	ES300h	AXZH10	All years	Panoramic view monitor	✓	✓	✓	✓	
Europe or Others	ES300h	AXZH10	All years	Steering Angle Sensor	✓	✓	✓		
Europe or Others	ES300h	AXZH10	All years	Parking Assist Camera	✓	✓	✓	✓	
Europe or Others	ES300h	AXZH10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615

Europe or Others	ES300h	AXZH10	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		
Europe or Others	ES300h	AXZH10	All years	Pre-Collision System	√	√	√		1524, 1525, 1526	
Europe or Others	ES300h	AXZH10	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	ES300h	AXZH10	All years	Accessory Gateway	√	√	√	√		
Europe or Others	ES300h	AXZH10	All years	Central Gateway	√	√	√	√		
Europe or Others	ES300h	AXZH10	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	ES300h	AXZH10	All years	Driver Door Motor	√	√	√		0528	
Europe or Others	ES300h	AXZH10	All years	Passenger Door Motor	√	√	√		0528	
Europe or Others	ES300h	AXZH10	All years	Left Rear Door Motor	√	√	√		0528	

Europe or Others	ES300h	AXZH10	All years	Right Rear Door Motor	√	√	√		0528	
Europe or Others	ES300h	AXZH10	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	ES300h	AXZH10	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	ES300h	AXZH10	All years	Master Switch	√	√	√			
Europe or Others	ES300h	AXZH10	All years	Sliding Roof	√	√	√		0529	
Europe or Others	ES300h	AXZH10	All years	Tilt&Telescopic	√	√	√		1513, 1514	
Europe or Others	ES300h	AXZH10	All years	Combination Meter	√	√	√		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	

Europe or Others	ES300h	AXZH10	All years	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
Europe or Others	ES300h	AXZH10	All years	Road Sign Assist	✓	✓	✓			
Europe or Others	ES300h	AXZH10	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	ES300h	AXZH10	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	ES300h	AXZH10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
Europe or Others	ES300h	AXZH10	All years	Rain and/or Humidity Sensor	✓	✓	✓			
Europe or Others	ES300h	AXZH10	All years	Wiper	✓	✓	✓	✓	0031, 0032	
Europe or Others	ES300h	AXZH10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	ES300h	AXZH10	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
Europe or Others	ES300h	AXZH10	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	ES300h	AXZH10	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	

Europe or Others	ES300h	AXZH10	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
Europe or Others	ES300h	AXZH10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	ES300h	AXZH10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	ES300h	AXZH10	All years	Detection Of Occupant	✓	✓	✓	✓		
Europe or Others	ES300h	AXZH10	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	ES300h	AXZH10	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	ES300h	AXZH10	All years	Front Radar Sensor	✓	✓	✓			
Europe or Others	ES300h	AXZH10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	ES300h	AXZH10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	ES300h	AXZH10	All years	Grill Shutter	✓	✓	✓		0037, 0038, 0039, 0040	
Europe or Others	ES300h	AXZH10	All years	Vehicle proximity notification system	✓	✓	✓	✓	0044, 0045, 0046	
Europe or Others	ES300h	AXZH10	All years	Active Noise Control	✓	✓	✓		1515, 1516, 1517, 1518, 1519	

Europe or Others	ES300h	AXZH10	All years	Pedestrian Protection	✓	✓	✓			
Europe or Others	ES300h	AXZH10	All years	Telematics	✓	✓	✓	✓	0036, 1521, 1522	
Europe or Others	ES300h	AXZH10	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	ES330	MCV	All years	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180	SP0003, SP0004
Europe or Others	ES330	MCV	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	ES330	MCV	All years	EMS	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001



Europe or Others	ES330	MCV	All years	ABS/VSC/TRC	✓	✓	✓	✓	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021, SP0023
Europe or Others	ES330	MCV	All years	Immobiliser	✓	✓	✓		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066
Europe or Others	ES330	MCV	All years	Theft Deterrent	✓	✓	✓		0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	
Europe or Others	ES330	MCV	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓			SP0001

Europe or Others	ES330	MCV	All years	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
Europe or Others	ES330	MCV	All years	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	ES330	MCV	All years	Passenger Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	ES330	MCV	All years	Detection Of Occupant	✓	✓	✓		SP0034, SP0035, SP0036

Europe or Others	ES350	GSV	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0090, 0 091, 0092, 00 93, 0094, 009 5, 0096, 0097 , 0098, 0099, 0100, 0101, 0 102, 0103, 01 04, 0105, 010 6, 0107, 0108 , 0109, 0110, 0111, 0112, 0 113, 0114, 01 15, 0116, 011 7, 0118, 0119 , 0120, 0121, 0122, 0123, 0 124, 0125, 01 26, 0127, 012 8, 0129, 0130 , 0131, 0132, 0133, 0134, 0 135, 0136, 01 37, 0138, 013 9, 0140, 0141 , 0142, 0143,	SP0004, SP0 026, SP0027 , SP0028, SP 0029, SP003 0, SP0031, S P0032, SP00 33, SP0073, SP0074, SP0 075, SP0076 , SP0101, SP 0116
------------------------	-------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------

Europe or Others	ES350	GSV	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	ES350	GSV	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	ES350	GSV	All years	E-ACM	✓	✓	✓		0432	

Europe or Others	ES350	GSV	All years	ABS/VSC/T RC	✓	✓	✓	✓	0026, 0376, 0 377, 0379, 03 80, 0382, 038 3, 0471, 0821 , 0822, 0825, 0826, 0827, 0 828, 0829, 08 30, 0831, 083 2, 0833, 0834 , 0835, 0836, 0837, 0838, 0 839, 0840, 08 41, 0842, 084 3, 0844, 0845 , 0846, 0847, 0848, 0849, 0 850, 0851, 08 52, 0853, 085 4, 0855, 0856 , 0857, 0858, 0859, 0860, 0 861, 0862, 08 63, 0864, 086 5, 0866, 0867 , 0868, 0869, 0870, 0871, 0 872, 0873, 08 74, 0875, 087 6, 0877, 0878 , 0879, 0880,	SP0001, SP0 003, SP0021 , SP0022, SP 0023, SP002 4, SP0084
------------------------	-------	-----	--------------	-----------------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------

Europe or Others	ES350	GSV	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	ES350	GSV	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	ES350	GSV	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	ES350	GSV	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	ES350	GSV	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES350	GSV	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES350	GSV	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES350	GSV	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	ES350	GSV	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	ES350	GSV	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	

Europe or Others	ES350	GSV	All years	Master Switch	✓	✓	✓			
Europe or Others	ES350	GSV	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	ES350	GSV	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	ES350	GSV	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	ES350	GSV	All years	Mirror	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0433, 0434, 0435, 0436, 0437	
Europe or Others	ES350	GSV	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006, SP0156
Europe or Others	ES350	GSV	All years	AFS	✓	✓	✓	✓	0007, SP0008	



Europe or Others	ES350	GSV	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	ES350	GSV	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062, SP0069
Europe or Others	ES350	GSV	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	ES350	GSV	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	ES350	GSV	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	ES350	GSV	All years	Telematics	✓	✓	✓	✓		SP0059, SP0060
Europe or Others	ES350	GSV	All years	EMPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
Europe or Others	ES350	GSV	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
Europe or Others	ES350	GSV	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	ES350	GSV	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	ES350	GSV	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	ES350	GSV	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0007, SP0008	

Europe or Others	ES350	GSV	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	ES350	GSV	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	ES350	GSV	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	ES350	GSV	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	ES350	GSV	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	ES350	GSV	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	ES350	GSV	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	ES350	GSV	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	ES350	GSV	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	ES350	GSV	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0087
Europe or Others	ES350	GSV	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	

Europe or Others	ES350	GSV	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				✓			
Europe or Others	ES350	GSV	All years	Central Gateway	✓	✓	✓	✓			
Europe or Others	ES350	GSV	All years	Radar Cruise 1	✓	✓	✓	✓			
Europe or Others	ES350	GSV	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	SP0061, SP0069	
Europe or Others	ES350	GSZ10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,		

Europe or Others	ES350	GSZ10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	ES350	GSZ10	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	ES350	GSZ10	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	
Europe or Others	ES350	GSZ10	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	

Europe or Others	ES350	GSZ10	All years	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
Europe or Others	ES350	GSZ10	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	ES350	GSZ10	All years	EMPS	✓	✓	✓	✓		
Europe or Others	ES350	GSZ10	All years	Front Recognition Camera	✓	✓	✓			
Europe or Others	ES350	GSZ10	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	ES350	GSZ10	All years	Panoramic view monitor	✓	✓	✓	✓		
Europe or Others	ES350	GSZ10	All years	Steering Angle Sensor	✓	✓	✓			
Europe or Others	ES350	GSZ10	All years	Parking Assist Camera	✓	✓	✓	✓		
Europe or Others	ES350	GSZ10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	

Europe or Others	ES350	GSZ10	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
Europe or Others	ES350	GSZ10	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	
Europe or Others	ES350	GSZ10	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	ES350	GSZ10	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	ES350	GSZ10	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	ES350	GSZ10	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	ES350	GSZ10	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	ES350	GSZ10	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	ES350	GSZ10	All years	Left Rear Door Motor	✓	✓	✓		0528	

Europe or Others	ES350	GSZ10	All years	Right Rear Door Motor	√	√	√		0528	
Europe or Others	ES350	GSZ10	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	ES350	GSZ10	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	ES350	GSZ10	All years	Master Switch	√	√	√			
Europe or Others	ES350	GSZ10	All years	Sliding Roof	√	√	√		0529	
Europe or Others	ES350	GSZ10	All years	Tilt&Telescopic	√	√	√		1513, 1514	
Europe or Others	ES350	GSZ10	All years	Combination Meter	√	√	√		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	

Europe or Others	ES350	GSZ10	All years	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
Europe or Others	ES350	GSZ10	All years	Road Sign Assist	✓	✓	✓			
Europe or Others	ES350	GSZ10	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	ES350	GSZ10	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	ES350	GSZ10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
Europe or Others	ES350	GSZ10	All years	Rain and/or Humidity Sensor	✓	✓	✓			
Europe or Others	ES350	GSZ10	All years	Wiper	✓	✓	✓	✓	0031, 0032	
Europe or Others	ES350	GSZ10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	ES350	GSZ10	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
Europe or Others	ES350	GSZ10	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	ES350	GSZ10	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	



Europe or Others	ES350	GSZ10	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓				
Europe or Others	ES350	GSZ10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553		
Europe or Others	ES350	GSZ10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305		
Europe or Others	ES350	GSZ10	All years	Detection Of Occupant	✓	✓	✓				
Europe or Others	ES350	GSZ10	All years	Remote Engine Starter	✓	✓	✓	✓			
Europe or Others	ES350	GSZ10	All years	Starting Control	✓	✓	✓	✓	0256, 0257		
Europe or Others	ES350	GSZ10	All years	Navigation System	✓	✓	✓	✓			
Europe or Others	ES350	GSZ10	All years	Front Radar Sensor	✓	✓	✓				
Europe or Others	ES350	GSZ10	All years	Master Blind Spot Monitor	✓	✓	✓	✓			
Europe or Others	ES350	GSZ10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓			
Europe or Others	ES350	GSZ10	All years	Active Noise Control	✓	✓	✓		1515, 1516, 1517, 1518, 1519		
Europe or Others	ES350	GSZ10	All years	Pedestrian Protection	✓	✓	✓				

Europe or Others	ES350	GSZ10	All years	Telematics	✓	✓	✓	✓	0036	
Europe or Others	ES350	GSZ10	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	GS F	URL10	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101

Europe or Others	GS F	URL10	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP004, SP0031, SP0032, SP0072, SP0101
Europe or Others	GS F	URL10	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	GS F	URL10	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	

Europe or Others	GS F	URL10	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	GS F	URL10	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP002
Europe or Others	GS F	URL10	All years	EMPS	✓	✓	✓	✓		SP0001, SP009, SP0010
Europe or Others	GS F	URL10	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP004
Europe or Others	GS F	URL10	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		

Europe or Others	GS F	URL10	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0087
Europe or Others	GS F	URL10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	GS F	URL10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	GS F	URL10	All years	TVD	✓	✓	✓	✓	0042, 0043	SP0004
Europe or Others	GS F	URL10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017

Europe or Others	GS F	URL10	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
Europe or Others	GS F	URL10	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	GS F	URL10	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	GS F	URL10	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	GS F	URL10	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	GS F	URL10	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS F	URL10	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS F	URL10	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003

Europe or Others	GS F	URL10	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS F	URL10	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	GS F	URL10	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	GS F	URL10	All years	Master Switch	✓	✓	✓			
Europe or Others	GS F	URL10	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	GS F	URL10	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	GS F	URL10	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	

Europe or Others	GS F	URL10	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
Europe or Others	GS F	URL10	All years	Road Sign Assist	✓	✓	✓	✓	1183	
Europe or Others	GS F	URL10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	GS F	URL10	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	GS F	URL10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	GS F	URL10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	GS F	URL10	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	GS F	URL10	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	GS F	URL10	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	GS F	URL10	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	GS F	URL10	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS F	URL10	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	



Europe or Others	GS F	URL10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	GS F	URL10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	GS F	URL10	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	GS F	URL10	All years	Telematics	✓	✓	✓	✓		
Europe or Others	GS F	URL10	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	
Europe or Others	GS F	URL10	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	GS200t	ARL10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	SP0004, SP0026, SP0029, SP0032, SP0042, SP0073, SP0075, SP0101, SP0102

Europe or Others	GS200t	ARL10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	GS200t	ARL10	All years	Stop and Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	
Europe or Others	GS200t	ARL10	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	GS200t	ARL10	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	GS200t	ARL10	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	GS200t	ARL10	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	GS200t	ARL10	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010

Europe or Others	GS200t	ARL10	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
Europe or Others	GS200t	ARL10	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	GS200t	ARL10	All years	Front Recognition Camera	√	√	√	√	0052	SP0086, SP0087
Europe or Others	GS200t	ARL10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
Europe or Others	GS200t	ARL10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		

Europe or Others	GS200t	ARL10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
Europe or Others	GS200t	ARL10	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
Europe or Others	GS200t	ARL10	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

Europe or Others	GS200t	ARL10	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	GS200t	ARL10	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	GS200t	ARL10	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	GS200t	ARL10	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS200t	ARL10	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS200t	ARL10	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS200t	ARL10	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS200t	ARL10	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	GS200t	ARL10	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	GS200t	ARL10	All years	Master Switch	✓	✓	✓			
Europe or Others	GS200t	ARL10	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	GS200t	ARL10	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	GS200t	ARL10	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	GS200t	ARL10	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
Europe or Others	GS200t	ARL10	All years	Road Sign Assist	✓	✓	✓	✓	1183	
Europe or Others	GS200t	ARL10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006

Europe or Others	GS200t	ARL10	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	GS200t	ARL10	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
Europe or Others	GS200t	ARL10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	GS200t	ARL10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	GS200t	ARL10	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	GS200t	ARL10	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	GS200t	ARL10	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	GS200t	ARL10	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	GS200t	ARL10	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS200t	ARL10	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS200t	ARL10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071



Europe or Others	GS200t	ARL10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓			
Europe or Others	GS200t	ARL10	All years	Telematics	✓	✓	✓	✓	0036		
Europe or Others	GS200t	ARL10	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018		
Europe or Others	GS250	GRL	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101	
Europe or Others	GS250	GRL	All years	Cruise Control	✓	✓	✓	✓			

Europe or Others	GS250	GRL	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	GS250	GRL	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	GS250	GRL	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	GS250	GRL	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010

Europe or Others	GS250	GRL	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
Europe or Others	GS250	GRL	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	GS250	GRL	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
Europe or Others	GS250	GRL	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	

Europe or Others	GS250	GRL	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	GS250	GRL	All years	Gateway Controller Area Network (CAN)	✓	✓	✓	✓		
Europe or Others	GS250	GRL	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	GS250	GRL	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS250	GRL	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS250	GRL	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS250	GRL	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS250	GRL	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	GS250	GRL	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	GS250	GRL	All years	Master Switch	✓	✓	✓			
Europe or Others	GS250	GRL	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	GS250	GRL	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	GS250	GRL	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	GS250	GRL	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	GS250	GRL	All years	AFS	✓	✓	✓	✓	0007, SP0008	

Europe or Others	GS250	GRL	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	GS250	GRL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	GS250	GRL	All years	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036
Europe or Others	GS250	GRL	All years	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274	SP0067, SP0068
Europe or Others	GS250	GRL	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	GS250	GRL	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	GS250	GRL	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	GS250	GRL	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS250	GRL	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS250	GRL	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	GS250	GRL	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	GS250	GRL	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	SP0061, SP0069

Europe or Others	GS250	GRL	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038, SP0039
Europe or Others	GS250	GRL	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	GS300	ARL10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	

Europe or Others	GS300	ARL10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	GS300	ARL10	All years	Stop and Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	
Europe or Others	GS300	ARL10	All years	Cruise Control	✓	✓	✓	✓		



Europe or Others	GS300	ARL10	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
Europe or Others	GS300	ARL10	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	GS300	ARL10	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	GS300	ARL10	All years	EMPS	✓	✓	✓	✓		

Europe or Others	GS300	ARL10	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	GS300	ARL10	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	GS300	ARL10	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	GS300	ARL10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	GS300	ARL10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				✓		

Europe or Others	GS300	ARL10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615
Europe or Others	GS300	ARL10	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓	
Europe or Others	GS300	ARL10	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298

Europe or Others	GS300	ARL10	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	GS300	ARL10	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	GS300	ARL10	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	GS300	ARL10	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	GS300	ARL10	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	GS300	ARL10	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	GS300	ARL10	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	GS300	ARL10	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	GS300	ARL10	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	GS300	ARL10	All years	Master Switch	✓	✓	✓		
Europe or Others	GS300	ARL10	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	GS300	ARL10	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	GS300	ARL10	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	GS300	ARL10	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051
Europe or Others	GS300	ARL10	All years	Road Sign Assist	✓	✓	✓	✓	1183
Europe or Others	GS300	ARL10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026

Europe or Others	GS300	ARL10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
Europe or Others	GS300	ARL10	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015
Europe or Others	GS300	ARL10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553
Europe or Others	GS300	ARL10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305
Europe or Others	GS300	ARL10	All years	Detection Of Occupant	✓	✓	✓		
Europe or Others	GS300	ARL10	All years	Remote Engine Starter	✓	✓	✓	✓	
Europe or Others	GS300	ARL10	All years	Starting Control	✓	✓	✓	✓	0256, 0257
Europe or Others	GS300	ARL10	All years	Navigation System	✓	✓	✓	✓	
Europe or Others	GS300	ARL10	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	GS300	ARL10	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	GS300	ARL10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	GS300	ARL10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	GS300	ARL10	All years	Telematics	✓	✓	✓	✓	0036	
Europe or Others	GS300	ARL10	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
Europe or Others	GS300	GRS1	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101

Europe or Others	GS300	GRS1_	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	GS300	GRS1_	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	GS300	GRS1_	All years	EMS	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001



Europe or Others	GS300	GRS1_	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	GS300	GRS1_	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	GS300	GRS1_	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	GS300	GRS1_	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017

Europe or Others	GS300	GRS1_	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓			SP0001	
Europe or Others	GS300	GRS1_	All years	Body	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969		SP0005
Europe or Others	GS300	GRS1_	All years	Gateway	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935		

Europe or Others	GS300	GRS1_	All years	Body No. 3	✓	✓	✓	0031, 0032, 0 312, 0313, 03 14, 0315, 031 6, 0320, 0321 , 0325, 0329, 0330, 0332, 0 337, 0338, 08 05, 0912, 091 7, 0918, 0929 , 0931, 0943, 0944, 0945, 0 946, 0947, 09 48, 0949, 095 0, 0951, 0952 , 0953, 0954, 0955, 0956, 0 957, 0958, 09 59, 0960, 096 1, 0962, 0963 , 0964, 0965, 0966, 0967
Europe or Others	GS300	GRS1_	All years	Body No. 4	✓		✓	0031, 0032, 0 312, 0313, 03 14, 0315, 031 6, 0320, 0321 , 0325, 0329, 0330, 0332, 0 337, 0338, 08 05, 0912, 091 7, 0918, 0929 , 0931, 0943, 0947, 0948, 0 949, 0950, 09 51, 0952, 095 3, 0954, 0955 , 0956, 0957, 0958, 0959, 0 960, 0961, 09 62, 0963, 096 4, 0965, 0966 , 0967

Europe or Others	GS300	GRS1_	All years	Body No. 5			√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	GS300	GRS1_	All years	Driver Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	GS300	GRS1_	All years	Passenger Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	GS300	GRS1_	All years	Left Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	GS300	GRS1_	All years	Right Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	GS300	GRS1_	All years	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	

Europe or Others	GS300	GRS1_	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	GS300	GRS1_	All years	Master Switch			√		0939, 0940, 0941, 0942	
Europe or Others	GS300	GRS1_	All years	Driver Seat Switch			√			
Europe or Others	GS300	GRS1_	All years	Sliding Roof			√		0529	
Europe or Others	GS300	GRS1_	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
Europe or Others	GS300	GRS1_	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	GS300	GRS1_	All years	Combination Switch			√			
Europe or Others	GS300	GRS1_	All years	Clearance Sonar	√	√	√		0023, 0024	
Europe or Others	GS300	GRS1_	All years	Rain Sensor			√			

Europe or Others	GS300	GRS1_	All years	AFS	✓	✓	✓		0008, 0475, 0476, 0477, 0968	
Europe or Others	GS300	GRS1_	All years	Entry&Start	✓	✓	✓		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015
Europe or Others	GS300	GRS1_	All years	Power Source Control	✓	✓	✓		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
Europe or Others	GS300	GRS1_	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
Europe or Others	GS300	GRS1_	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	GS300	GRS1_	All years	Stabilizer	✓	✓	✓			SP0063
Europe or Others	GS300	GRS1_	All years	Body Electronic Area Network (BEAN) Gateway	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	
Europe or Others	GS300	GRS1_	All years	Gateway Controller Area Network (CAN)	✓	✓	✓	✓		
Europe or Others	GS300	GRS1_	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036

Europe or Others	GS300	GRS1_	All years	VGRS	✓	✓	✓	✓		SP0001, SP0009, SP0037
Europe or Others	GS300	GRS1_	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052
Europe or Others	GS300	GRS1_	All years	Telematics	✓	✓	✓	✓		SP0059, SP0060
Europe or Others	GS300	GRS1_	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	GS300	GRS1_	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050
Europe or Others	GS300	JZS	All years	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180	SP0003, SP0004
Europe or Others	GS300	JZS	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	GS300	JZS	All years	ABS/VSC/TPC	√	√	√	√	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021, SP0023
Europe or Others	GS300	JZS	All years	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
Europe or Others	GS300	JZS	All years	Immobiliser	√	√	√			SP0011, SP0013, SP0148
Europe or Others	GS300	JZS	All years	Supplement Restraint System (SRS) Airbag	√	√				SP0004



Europe or Others	GS300	JZS	All years	Body	✓	✓	✓	0031, 0032, 0319, 0333, 0337, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0922, 0923, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020
Europe or Others	GS300	JZS	All years	Body No. 2			✓	0031, 0032, 0319, 0333, 0337, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	
Europe or Others	GS300	JZS	All years	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	GS300	JZS	All years	Passenger Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	GS300	JZS	All years	Left Rear Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	

Europe or Others	GS300	JZS	All years	Right Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	GS300	JZS	All years	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	GS300	JZS	All years	Sliding Roof			√	0529	
Europe or Others	GS300	JZS	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005
Europe or Others	GS300	JZS	All years	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	

Europe or Others	GS300h	AWL10	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0101
Europe or Others	GS300h	AWL10	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058
Europe or Others	GS300h	AWL10	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	GS300h	AWL10	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	GS300h	AWL10	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023
Europe or Others	GS300h	AWL10	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	GS300h	AWL10	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010

Europe or Others	GS300h	AWL10	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
Europe or Others	GS300h	AWL10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	GS300h	AWL10	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	GS300h	AWL10	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	GS300h	AWL10	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	GS300h	AWL10	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	GS300h	AWL10	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	GS300h	AWL10	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	GS300h	AWL10	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	GS300h	AWL10	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	GS300h	AWL10	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	GS300h	AWL10	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	GS300h	AWL10	All years	Master Switch	✓	✓	✓			
Europe or Others	GS300h	AWL10	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	GS300h	AWL10	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	GS300h	AWL10	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	GS300h	AWL10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	GS300h	AWL10	All years	AFS	✓	✓	✓	✓	0007, SP0008	

Europe or Others	GS300h	AWL10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	GS300h	AWL10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	GS300h	AWL10	All years	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274	SP0067, SP0068
Europe or Others	GS300h	AWL10	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
Europe or Others	GS300h	AWL10	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050
Europe or Others	GS300h	AWL10	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS300h	AWL10	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS300h	AWL10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	GS300h	AWL10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	GS300h	AWL10	All years	Grill Shutter	✓	✓	✓		0037, 0038, 0039, 0040	SP0080
Europe or Others	GS300h	AWL10	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
Europe or Others	GS300h	AWL10	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038, SP0039



Europe or Others	GS300h	AWL10	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	GS300h	AWL10	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	GS300h	AWL10	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	GS300h	AWL10	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	GS300h	AWL10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	GS300h	AWL10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	GS300h	AWL10	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	GS300h	AWL10	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
Europe or Others	GS300h	AWL10	All years	Vehicle proximity notification system	✓	✓	✓	✓		
Europe or Others	GS300h	AWL10	All years	Telematics	✓	✓	✓	✓		

Europe or Others	GS350	GRL	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	GS350	GRL	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	GS350	GRL	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

Europe or Others	GS350	GRL	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	GS350	GRL	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
Europe or Others	GS350	GRL	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	GS350	GRL	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	GS350	GRL	All years	VGRS	✓	✓	✓	✓		SP0004, SP0037
Europe or Others	GS350	GRL	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
Europe or Others	GS350	GRL	All years	DRS	✓	✓	✓	✓		SP0004, SP0081, SP0082, SP0083

Europe or Others	GS350	GRL	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	GS350	GRL	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
Europe or Others	GS350	GRL	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	

Europe or Others	GS350	GRL	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	GS350	GRL	All years	Gateway Controller Area Network (CAN)	✓	✓	✓	✓		
Europe or Others	GS350	GRL	All years	Multi Bus Gateway	✓	✓	✓	✓		
Europe or Others	GS350	GRL	All years	No. 1 Multi Bus Monitor	✓	✓	✓	✓		SP0005
Europe or Others	GS350	GRL	All years	No. 2 Multi Bus Monitor	✓	✓	✓	✓		SP0005
Europe or Others	GS350	GRL	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	GS350	GRL	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS350	GRL	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS350	GRL	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003

Europe or Others	GS350	GRL	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS350	GRL	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	GS350	GRL	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	GS350	GRL	All years	Master Switch	✓	✓	✓			
Europe or Others	GS350	GRL	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	GS350	GRL	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	GS350	GRL	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	

Europe or Others	GS350	GRL	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	GS350	GRL	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	GS350	GRL	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	GS350	GRL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	GS350	GRL	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	GS350	GRL	All years	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274	SP0067, SP0068
Europe or Others	GS350	GRL	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	GS350	GRL	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	GS350	GRL	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	GS350	GRL	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS350	GRL	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS350	GRL	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071

Europe or Others	GS350	GRL	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	GS350	GRL	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
Europe or Others	GS350	GRL	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038, SP0039
Europe or Others	GS350	GRL	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044, SP0128, SP0134, SP0143, SP0144
Europe or Others	GS350	GRL	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101



Europe or Others	GS350	GRL	All years	ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP004, SP0031, SP0032, SP0072, SP0101
Europe or Others	GS350	GRL	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		

Europe or Others	GS350	GRL1#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	SP0004, SP0 026, SP0029 , SP0032, SP 0042, SP007 3, SP0075, S P0101, SP01 02
------------------------	-------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------

Europe or Others	GS350	GRL1#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	GS350	GRL1#	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	GS350	GRL1#	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

Europe or Others	GS350	GRL1#	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	GS350	GRL1#	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
Europe or Others	GS350	GRL1#	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	GS350	GRL1#	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	GS350	GRL1#	All years	VGRS	✓	✓	✓	✓		SP0004, SP0037
Europe or Others	GS350	GRL1#	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004

Europe or Others	GS350	GRL1#	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	GS350	GRL1#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0087
Europe or Others	GS350	GRL1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	GS350	GRL1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	GS350	GRL1#	All years	DRS	✓	✓	✓	✓		SP0004, SP0081, SP0082, SP0083

Europe or Others	GS350	GRL1#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
Europe or Others	GS350	GRL1#	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
Europe or Others	GS350	GRL1#	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

Europe or Others	GS350	GRL1#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	GS350	GRL1#	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	GS350	GRL1#	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	GS350	GRL1#	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS350	GRL1#	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS350	GRL1#	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS350	GRL1#	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS350	GRL1#	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	GS350	GRL1#	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	GS350	GRL1#	All years	Master Switch	✓	✓	✓			
Europe or Others	GS350	GRL1#	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	GS350	GRL1#	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	GS350	GRL1#	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	GS350	GRL1#	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
Europe or Others	GS350	GRL1#	All years	Road Sign Assist	✓	✓	✓	✓	1183	
Europe or Others	GS350	GRL1#	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006



Europe or Others	GS350	GRL1#	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	GS350	GRL1#	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
Europe or Others	GS350	GRL1#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	GS350	GRL1#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	GS350	GRL1#	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	GS350	GRL1#	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	GS350	GRL1#	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	GS350	GRL1#	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	GS350	GRL1#	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS350	GRL1#	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS350	GRL1#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071

Europe or Others	GS350	GRL1#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	GS350	GRL1#	All years	Telematics	✓	✓	✓	✓	0036	
Europe or Others	GS350	GRL1#	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
Europe or Others	GS350	GRS1_	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101

Europe or Others	GS350	GRS1_	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	GS350	GRS1_	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	GS350	GRS1_	All years	EMS	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001
Europe or Others	GS350	GRS1_	All years	Stabilizer	✓	✓	✓			SP0063

Europe or Others	GS350	GRS1_	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	GS350	GRS1_	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052
Europe or Others	GS350	GRS1_	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	GS350	GRS1_	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	GS350	GRS1_	All years	VGRS	✓	✓	✓	✓		SP0001, SP0009, SP0037

Europe or Others	GS350	GRS1_	All years	Air Conditioner	√	√	√	0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017
Europe or Others	GS350	GRS1_	All years	Supplement Restraint System (SRS) Airbag	√	√	√		SP0001
Europe or Others	GS350	GRS1_	All years	Body	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005

Europe or Others	GS350	GRS1_	All years	Body Electronic Area Network (BEAN) Gateway	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935
Europe or Others	GS350	GRS1_	All years	Gateway Controller Area Network (CAN)	✓	✓	✓	✓
Europe or Others	GS350	GRS1_	All years	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

Europe or Others	GS350	GRS1_	All years	Body No. 4	✓		✓	0031, 0032, 0 312, 0313, 03 14, 0315, 031 6, 0320, 0321 , 0325, 0329, 0330, 0332, 0 337, 0338, 08 05, 0912, 091 7, 0918, 0929 , 0931, 0943, 0947, 0948, 0 949, 0950, 09 51, 0952, 095 3, 0954, 0955 , 0956, 0957, 0958, 0959, 0 960, 0961, 09 62, 0963, 096 4, 0965, 0966 , 0967	
Europe or Others	GS350	GRS1_	All years	Body No. 5			✓	0031, 0032, 0 312, 0313, 03 14, 0315, 031 6, 0320, 0321 , 0329, 0330, 0331, 0332, 0 333, 0337, 03 38, 0805, 091 2, 0917, 0918 , 0929, 0931, 0943, 0947, 0 948, 0949, 09 50, 0951, 095 2, 0953, 0954 , 0955, 0956, 0957, 0958, 0 959, 0960, 09 61, 0962, 096 3, 0964, 0965 , 0966, 0967	
Europe or Others	GS350	GRS1_	All years	Driver Door	✓	✓	✓	0279, 0280, 0 281, 0282, 02 83, 0284, 031 7, 0429, 0430 , 0437, 0503, 0507, 0508, 0 509, 0528, 09 90, 0991	
Europe or Others	GS350	GRS1_	All years	Passenger Door	✓	✓	✓	0279, 0280, 0 281, 0282, 02 83, 0284, 031 7, 0429, 0430 , 0437, 0503, 0507, 0508, 0 509, 0528, 09 90, 0991	

Europe or Others	GS350	GRS1_	All years	Left Rear Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
Europe or Others	GS350	GRS1_	All years	Right Rear Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
Europe or Others	GS350	GRS1_	All years	Driver Seat			✓	0422, 0423, 0424, 0515, 0516, 0517
Europe or Others	GS350	GRS1_	All years	Passenger Seat			✓	0422, 0423, 0424, 0515, 0516, 0517
Europe or Others	GS350	GRS1_	All years	Master Switch			✓	0939, 0940, 0941, 0942
Europe or Others	GS350	GRS1_	All years	Driver Seat Switch			✓	
Europe or Others	GS350	GRS1_	All years	Sliding Roof			✓	0529
Europe or Others	GS350	GRS1_	All years	Tilt&Telescopic	✓	✓	✓	0472, 0473, 1005



Europe or Others	GS350	GRS1_	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	GS350	GRS1_	All years	Combination Switch			√			
Europe or Others	GS350	GRS1_	All years	Clearance Sonar	√	√	√		0023, 0024	
Europe or Others	GS350	GRS1_	All years	Rain Sensor			√			
Europe or Others	GS350	GRS1_	All years	AFS	√	√	√		0008, 0475, 0476, 0477, 0968	
Europe or Others	GS350	GRS1_	All years	Entry&Start	√	√	√		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015
Europe or Others	GS350	GRS1_	All years	Power Source Control	√	√	√		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	

Europe or Others	GS350	GRS1_	All years	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
Europe or Others	GS350	GRS1_	All years	Radar Cruise	√	√	√	√		SP0061, SP0062
Europe or Others	GS350	GRS1_	All years	Pre-Crash	√	√	√	√	0347, 0348, 0349, 0350	
Europe or Others	GS350	GRS1_	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	GS350	GRS1_	All years	Navigation System	√	√	√	√		SP0049, SP0050
Europe or Others	GS430	UZS	All years	Engine	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101

Europe or Others	GS430	UZS	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	GS430	UZS	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	GS430	UZS	All years	EMS	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001

Europe or Others	GS430	UZS	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0149
Europe or Others	GS430	UZS	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	GS430	UZS	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	GS430	UZS	All years	VGRS	✓	✓	✓	✓		SP0001, SP0009, SP0037
Europe or Others	GS430	UZS	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017

Europe or Others	GS430	UZS	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓		SP0001, SP0004
Europe or Others	GS430	UZS	All years	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020
Europe or Others	GS430	UZS	All years	Gateway	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	

Europe or Others	GS430	UZS	All years	Body No. 3	✓	✓	✓	0031, 0032, 0 312, 0313, 03 14, 0315, 031 6, 0320, 0321 , 0325, 0329, 0330, 0332, 0 337, 0338, 08 05, 0912, 091 7, 0918, 0929 , 0931, 0943, 0944, 0945, 0 946, 0947, 09 48, 0949, 095 0, 0951, 0952 , 0953, 0954, 0955, 0956, 0 957, 0958, 09 59, 0960, 096 1, 0962, 0963 , 0964, 0965, 0966, 0967
Europe or Others	GS430	UZS	All years	Body No. 4	✓		✓	0031, 0032, 0 312, 0313, 03 14, 0315, 031 6, 0320, 0321 , 0325, 0329, 0330, 0332, 0 337, 0338, 08 05, 0912, 091 7, 0918, 0929 , 0931, 0943, 0947, 0948, 0 949, 0950, 09 51, 0952, 095 3, 0954, 0955 , 0956, 0957, 0958, 0959, 0 960, 0961, 09 62, 0963, 096 4, 0965, 0966 , 0967

Europe or Others	GS430	UZS	All years	Body No. 5			√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	GS430	UZS	All years	Driver Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	GS430	UZS	All years	Passenger Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	GS430	UZS	All years	Left Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	GS430	UZS	All years	Right Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	GS430	UZS	All years	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	

Europe or Others	GS430	UZS	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	GS430	UZS	All years	Master Switch			√		0939, 0940, 0941, 0942	
Europe or Others	GS430	UZS	All years	Driver Seat Switch			√			
Europe or Others	GS430	UZS	All years	Sliding Roof			√		0529	
Europe or Others	GS430	UZS	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
Europe or Others	GS430	UZS	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	GS430	UZS	All years	Combination Switch			√			
Europe or Others	GS430	UZS	All years	Clearance Sonar	√	√	√		0023, 0024	
Europe or Others	GS430	UZS	All years	Rain Sensor			√			



Europe or Others	GS430	UZS	All years	AFS	✓	✓	✓		0008, 0475, 0476, 0477, 0968	
Europe or Others	GS430	UZS	All years	Entry&Start	✓	✓	✓		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015
Europe or Others	GS430	UZS	All years	Power Source Control	✓	✓	✓		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
Europe or Others	GS430	UZS	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
Europe or Others	GS430	UZS	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	GS430	UZS	All years	Stabilizer	✓	✓	✓			SP0063
Europe or Others	GS430	UZS	All years	Body Electronic Area Network (BEAN) Gateway	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	
Europe or Others	GS430	UZS	All years	Gateway Controller Area Network (CAN)	✓	✓	✓	✓		
Europe or Others	GS430	UZS	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036

Europe or Others	GS430	UZS	All years	4WD	√	√	√	√	0819, 0820, 0821, 0822	SP0003, SP0052
Europe or Others	GS430	UZS	All years	Engine and ECT	√	√	√	√	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180	SP0003, SP0004
Europe or Others	GS430	UZS	All years	Immobiliser	√	√	√			SP0011, SP0013, SP0148
Europe or Others	GS430	UZS	All years	Body No.2			√		0031, 0032, 0319, 0333, 0337, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	
Europe or Others	GS430	UZS	All years	Switch Of Steering Pad			√			

Europe or Others	GS450h	GWL	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	GS450h	GWL	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058
Europe or Others	GS450h	GWL	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	GS450h	GWL	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	GS450h	GWL	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023
Europe or Others	GS450h	GWL	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	GS450h	GWL	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	GS450h	GWL	All years	VGRS	✓	✓	✓	✓		SP0004, SP0037

Europe or Others	GS450h	GWL	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
Europe or Others	GS450h	GWL	All years	DRS	√	√	√	√		SP0004, SP0081, SP0082, SP0083
Europe or Others	GS450h	GWL	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	GS450h	GWL	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001

Europe or Others	GS450h	GWL	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	GS450h	GWL	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	GS450h	GWL	All years	Multi Bus Gateway	✓	✓	✓	✓		
Europe or Others	GS450h	GWL	All years	No. 1 Multi Bus Monitor	✓	✓	✓	✓		SP0005
Europe or Others	GS450h	GWL	All years	No. 2 Multi Bus Monitor	✓	✓	✓	✓		SP0005
Europe or Others	GS450h	GWL	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	GS450h	GWL	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS450h	GWL	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS450h	GWL	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GS450h	GWL	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003

Europe or Others	GS450h	GWL	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	GS450h	GWL	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	GS450h	GWL	All years	Master Switch	✓	✓	✓			
Europe or Others	GS450h	GWL	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	GS450h	GWL	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	GS450h	GWL	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	GS450h	GWL	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006

Europe or Others	GS450h	GWL	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	GS450h	GWL	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	GS450h	GWL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	GS450h	GWL	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	GS450h	GWL	All years	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274	SP0067, SP0068
Europe or Others	GS450h	GWL	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	GS450h	GWL	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	GS450h	GWL	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS450h	GWL	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GS450h	GWL	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	GS450h	GWL	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	GS450h	GWL	All years	Grill Shutter	✓	✓	✓		0037, 0038, 0039, 0040	SP0080, SP0142



Europe or Others	GS450h	GWL	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
Europe or Others	GS450h	GWL	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038, SP0039
Europe or Others	GS450h	GWL	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	GS450h	GWL	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	GS450h	GWL	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
Europe or Others	GS450h	GWL	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	GS450h	GWL	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0087
Europe or Others	GS450h	GWL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	GS450h	GWL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	GS450h	GWL	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	GS450h	GWL	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
Europe or Others	GS450h	GWL	All years	Road Sign Assist	✓	✓	✓	✓	1183	

Europe or Others	GS450h	GWL	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
Europe or Others	GS450h	GWL	All years	Vehicle proximity notification system	✓	✓	✓	✓		
Europe or Others	GS450h	GWS	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101
Europe or Others	GS450h	GWS	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026
Europe or Others	GS450h	GWS	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	GS450h	GWS	All years	EMS	√	√	√		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001
Europe or Others	GS450h	GWS	All years	Stabilizer	√	√	√			SP0063
Europe or Others	GS450h	GWS	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023
Europe or Others	GS450h	GWS	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002
Europe or Others	GS450h	GWS	All years	EMPS	√	√	√	√		SP0001, SP0009, SP0010
Europe or Others	GS450h	GWS	All years	VGRS	√	√	√	√		SP0001, SP0009, SP0037

Europe or Others	GS450h	GWS	All years	Air Conditioner	√	√	√	0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017
Europe or Others	GS450h	GWS	All years	Supplement Restraint System (SRS) Airbag	√	√	√		SP0001
Europe or Others	GS450h	GWS	All years	Body	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005

Europe or Others	GS450h	GWS	All years	Gateway	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	
Europe or Others	GS450h	GWS	All years	HV Gateway	✓	✓	✓	✓	SP0005
Europe or Others	GS450h	GWS	All years	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	

Europe or Others	GS450h	GWS	All years	Body No. 4	✓		✓	0031, 0032, 0 312, 0313, 03 14, 0315, 031 6, 0320, 0321 , 0325, 0329, 0330, 0332, 0 337, 0338, 08 05, 0912, 091 7, 0918, 0929 , 0931, 0943, 0947, 0948, 0 949, 0950, 09 51, 0952, 095 3, 0954, 0955 , 0956, 0957, 0958, 0959, 0 960, 0961, 09 62, 0963, 096 4, 0965, 0966 , 0967	
Europe or Others	GS450h	GWS	All years	Body No. 5			✓	0031, 0032, 0 312, 0313, 03 14, 0315, 031 6, 0320, 0321 , 0329, 0330, 0331, 0332, 0 333, 0337, 03 38, 0805, 091 2, 0917, 0918 , 0929, 0931, 0943, 0947, 0 948, 0949, 09 50, 0951, 095 2, 0953, 0954 , 0955, 0956, 0957, 0958, 0 959, 0960, 09 61, 0962, 096 3, 0964, 0965 , 0966, 0967	
Europe or Others	GS450h	GWS	All years	Driver Door	✓	✓	✓	0279, 0280, 0 281, 0282, 02 83, 0284, 031 7, 0429, 0430 , 0437, 0503, 0507, 0508, 0 509, 0528, 09 90, 0991	
Europe or Others	GS450h	GWS	All years	Passenger Door	✓	✓	✓	0279, 0280, 0 281, 0282, 02 83, 0284, 031 7, 0429, 0430 , 0437, 0503, 0507, 0508, 0 509, 0528, 09 90, 0991	

Europe or Others	GS450h	GWS	All years	Left Rear Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
Europe or Others	GS450h	GWS	All years	Right Rear Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
Europe or Others	GS450h	GWS	All years	Driver Seat			✓	0422, 0423, 0424, 0515, 0516, 0517
Europe or Others	GS450h	GWS	All years	Passenger Seat			✓	0422, 0423, 0424, 0515, 0516, 0517
Europe or Others	GS450h	GWS	All years	Master Switch			✓	0939, 0940, 0941, 0942
Europe or Others	GS450h	GWS	All years	Driver Seat Switch			✓	
Europe or Others	GS450h	GWS	All years	Sliding Roof			✓	0529
Europe or Others	GS450h	GWS	All years	Tilt&Telescopic	✓	✓	✓	0472, 0473, 1005

Europe or Others	GS450h	GWS	All years	Combination Meter			✓		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	GS450h	GWS	All years	Combination Switch			✓			
Europe or Others	GS450h	GWS	All years	Clearance Sonar	✓	✓	✓		0023, 0024	
Europe or Others	GS450h	GWS	All years	Rain Sensor			✓			
Europe or Others	GS450h	GWS	All years	AFS	✓	✓	✓		0008, 0475, 0476, 0477, 0968	
Europe or Others	GS450h	GWS	All years	Entry&Start	✓	✓	✓		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015
Europe or Others	GS450h	GWS	All years	Power Source Control	✓	✓	✓		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	



Europe or Others	GS450h	GWS	All years	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
Europe or Others	GS450h	GWS	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	GS450h	GWS	All years	Navigation System	√	√	√	√		SP0049, SP0050
Europe or Others	GS450h	GWS	All years	Radar Cruise	√	√	√	√		SP0062
Europe or Others	GS450h	GWS	All years	Pre-Crash	√	√	√	√	0347, 0348, 0349, 0350	
Europe or Others	GS460	URS	All years	Engine	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101

Europe or Others	GS460	URS	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	GS460	URS	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	GS460	URS	All years	EMS	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001
Europe or Others	GS460	URS	All years	Stabilizer	✓	✓	✓			SP0063

Europe or Others	GS460	URS	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	GS460	URS	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052
Europe or Others	GS460	URS	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	GS460	URS	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	GS460	URS	All years	VGRS	✓	✓	✓	✓		SP0001, SP0009, SP0037

Europe or Others	GS460	URS	All years	Air Conditioner	√	√	√	0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017
Europe or Others	GS460	URS	All years	Supplement Restraint System (SRS) Airbag	√	√	√		SP0001
Europe or Others	GS460	URS	All years	Body	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005

Europe or Others	GS460	URS	All years	Body Electronic Area Network (BEAN) Gateway	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935
Europe or Others	GS460	URS	All years	Gateway Controller Area Network (CAN)	√	√	√	√
Europe or Others	GS460	URS	All years	Body No. 3	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

Europe or Others	GS460	URS	All years	Body No. 4	√		√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967
Europe or Others	GS460	URS	All years	Body No. 5			√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967
Europe or Others	GS460	URS	All years	Driver Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
Europe or Others	GS460	URS	All years	Passenger Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991

Europe or Others	GS460	URS	All years	Left Rear Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
Europe or Others	GS460	URS	All years	Right Rear Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
Europe or Others	GS460	URS	All years	Driver Seat			✓	0422, 0423, 0424, 0515, 0516, 0517
Europe or Others	GS460	URS	All years	Passenger Seat			✓	0422, 0423, 0424, 0515, 0516, 0517
Europe or Others	GS460	URS	All years	Master Switch			✓	0939, 0940, 0941, 0942
Europe or Others	GS460	URS	All years	Driver Seat Switch			✓	
Europe or Others	GS460	URS	All years	Sliding Roof			✓	0529
Europe or Others	GS460	URS	All years	Tilt&Telescopic	✓	✓	✓	0472, 0473, 1005

Europe or Others	GS460	URS	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	GS460	URS	All years	Combination Switch			√			
Europe or Others	GS460	URS	All years	Clearance Sonar	√	√	√		0023, 0024	
Europe or Others	GS460	URS	All years	Rain Sensor			√			
Europe or Others	GS460	URS	All years	AFS	√	√	√		0008, 0475, 0476, 0477, 0968	
Europe or Others	GS460	URS	All years	Entry&Start	√	√	√		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015
Europe or Others	GS460	URS	All years	Power Source Control	√	√	√		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	



Europe or Others	GS460	URS	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	GS460	URS	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	GS460	URS	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050
Europe or Others	GS460	URS	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
Europe or Others	GS460	URS	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	GX400	GRJ	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	GX400	GRJ	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	GX400	GRJ	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001
Europe or Others	GX400	GRJ	All years	KDSS	✓	✓	✓		0554, 0555	
Europe or Others	GX400	GRJ	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084

Europe or Others	GX400	GRJ	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	GX400	GRJ	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	GX400	GRJ	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	GX400	GRJ	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	GX400	GRJ	All years	PM1 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	GX400	GRJ	All years	PM2 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	GX400	GRJ	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GX400	GRJ	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GX400	GRJ	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GX400	GRJ	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GX400	GRJ	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	GX400	GRJ	All years	Master Switch	✓	✓	✓			

Europe or Others	GX400	GRJ	All years	Driver Seat Switch	√	√	√	√	0355, 0398, 0399, 0400, 0401, 0402, 0403, 0404, 0405, 0406, 0407, 0408, 0409, 0410, 0411, 0412, 0413, 0414, 0415, 0416, 0417, 0418, 0419, 0420
Europe or Others	GX400	GRJ	All years	Sliding Roof	√	√	√		0529
Europe or Others	GX400	GRJ	All years	Tilt&Telescopic	√	√	√	√	0472, 0473
Europe or Others	GX400	GRJ	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	GX400	GRJ	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	GX400	GRJ	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GX400	GRJ	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	GX400	GRJ	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	GX400	GRJ	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015
Europe or Others	GX400	GRJ	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	GX400	GRJ	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	GX400	GRJ	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	GX400	GRJ	All years	Radar Cruise	✓	✓	✓	✓		
Europe or Others	GX400	GRJ	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	GX400	GRJ	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0040, SP0044
Europe or Others	GX400	GRJ	All years	Tire Pressure Monitor	✓	✓	✓	✓		SP0001, SP0002
Europe or Others	GX400	GRJ	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071

Europe or Others	GX400	GRJ	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	GX460	URJ	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	GX460	URJ	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	GX460	URJ	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001

Europe or Others	GX460	URJ	All years	KDSS	✓	✓	✓		0554, 0555	
Europe or Others	GX460	URJ	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	GX460	URJ	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	GX460	URJ	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓		



Europe or Others	GX460	URJ	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	GX460	URJ	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	GX460	URJ	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	GX460	URJ	All years	PM1 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	GX460	URJ	All years	PM2 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	GX460	URJ	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GX460	URJ	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GX460	URJ	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GX460	URJ	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	GX460	URJ	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	GX460	URJ	All years	Master Switch	✓	✓	✓			

Europe or Others	GX460	URJ	All years	Driver Seat Switch	√	√	√	√	0355, 0398, 0399, 0400, 0401, 0402, 0403, 0404, 0405, 0406, 0407, 0408, 0409, 0410, 0411, 0412, 0413, 0414, 0415, 0416, 0417, 0418, 0419, 0420	
Europe or Others	GX460	URJ	All years	Sliding Roof	√	√	√		0529	
Europe or Others	GX460	URJ	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	
Europe or Others	GX460	URJ	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	GX460	URJ	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

Europe or Others	GX460	URJ	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	GX460	URJ	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	GX460	URJ	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	GX460	URJ	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015
Europe or Others	GX460	URJ	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	GX460	URJ	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	GX460	URJ	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	GX460	URJ	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	GX460	URJ	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0069
Europe or Others	GX460	URJ	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	GX460	URJ	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0040, SP0044
Europe or Others	GX460	URJ	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	GX460	URJ	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071

Europe or Others	GX460	URJ	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	GX460	URJ	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	GX460	URJ	All years	Telematics	✓	✓	✓	✓		
Europe or Others	GX460	URJ	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	GX460	URJ	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	GX460	URJ	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	GX460	URJ	All years	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	
Europe or Others	GX460	URJ	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	GX460	URJ	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	GX460	URJ	All years	Road Sign Assist	✓	✓	✓	✓	1183	
Europe or Others	GX460	URJ	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	GX460	URJ	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	GX460	URJ	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	

Europe or Others	GX470	UZJ	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101
Europe or Others	GX470	UZJ	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	GX470	UZJ	All years	Air suspension	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001
Europe or Others	GX470	UZJ	All years	KDSS	✓	✓	✓		0554, 0555	SP0001, SP0138

Europe or Others	GX470	UZJ	All years	ABS/VSC/TRC	✓	✓	✓	✓	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021, SP0023
Europe or Others	GX470	UZJ	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	GX470	UZJ	All years	Immobiliser	✓	✓	✓		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066
Europe or Others	GX470	UZJ	All years	Theft Deterrent	✓	✓	✓		0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	
Europe or Others	GX470	UZJ	All years	Supplement Restraint System (SRS) Airbag	✓	✓				SP0004

Europe or Others	GX470	UZJ	All years	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005, SP0019, SP0020
Europe or Others	GX470	UZJ	All years	Body No. 2	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	
Europe or Others	GX470	UZJ	All years	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	GX470	UZJ	All years	Driver Seat			✓	0422, 0423, 0424, 0515, 0516, 0517	



Europe or Others	GX470	UZJ	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
Europe or Others	GX470	UZJ	All years	Mirror				√	0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	GX470	UZJ	All years	Rain Sensor				√		
Europe or Others	GX470	UZJ	All years	Wiper				√	0031, 0032, 0332	
Europe or Others	GX470	UZJ	All years	Detection Of Occupant	√	√		√		SP0034, SP0035, SP0036
Europe or Others	HS250h	ANF	All years	Engine and ECT	√	√		√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101
Europe or Others	HS250h	ANF	All years	Hybrid Control	√	√		√	√	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117, SP0003, SP0004, SP0005, SP0024, SP0025, SP0026

Europe or Others	HS250h	ANF	All years	Cruise Control	√	√	√	√		
Europe or Others	HS250h	ANF	All years	ABS/VSC/TPC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0088
Europe or Others	HS250h	ANF	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002
Europe or Others	HS250h	ANF	All years	EMPS	√	√	√	√		SP0001, SP0009, SP0010
Europe or Others	HS250h	ANF	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	HS250h	ANF	All years	Transmission Control	√	√	√	√		

Europe or Others	HS250h	ANF	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
Europe or Others	HS250h	ANF	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	HS250h	ANF	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	HS250h	ANF	All years	PM1 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	HS250h	ANF	All years	PM2 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	HS250h	ANF	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	HS250h	ANF	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	HS250h	ANF	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	HS250h	ANF	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	HS250h	ANF	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	HS250h	ANF	All years	Master Switch	✓	✓	✓			

Europe or Others	HS250h	ANF	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	HS250h	ANF	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	HS250h	ANF	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	HS250h	ANF	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	HS250h	ANF	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	HS250h	ANF	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	HS250h	ANF	All years	AFS	✓	✓	✓	✓	0007, SP0008	

Europe or Others	HS250h	ANF	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015
Europe or Others	HS250h	ANF	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	HS250h	ANF	All years	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036
Europe or Others	HS250h	ANF	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
Europe or Others	HS250h	ANF	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050
Europe or Others	HS250h	ANF	All years	Radar Cruise	✓	✓	✓	✓		
Europe or Others	HS250h	ANF	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038, SP0039
Europe or Others	HS250h	ANF	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	HS250h	ANF	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0040, SP0044

Europe or Others	IS F	USE	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0090, 0 091, 0092, 00 93, 0094, 009 5, 0096, 0097 , 0098, 0099, 0100, 0101, 0 102, 0103, 01 04, 0105, 010 6, 0107, 0108 , 0109, 0110, 0111, 0112, 0 113, 0114, 01 15, 0116, 011 7, 0118, 0119 , 0120, 0121, 0122, 0123, 0 124, 0125, 01 26, 0127, 012 8, 0129, 0130 , 0131, 0132, 0133, 0134, 0 135, 0136, 01 37, 0138, 013 9, 0140, 0141 , 0142, 0143,	SP0004, SP0 026, SP0027 , SP0028, SP 0029, SP003 0, SP0031, S P0032, SP00 33, SP0101
------------------------	------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------

Europe or Others	IS F	USE	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	IS F	USE	All years	Cruise Control	✓	✓	✓	✓		



Europe or Others	IS F	USE	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	IS F	USE	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	IS F	USE	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017
Europe or Others	IS F	USE	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓			SP0001

Europe or Others	IS F	USE	All years	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
Europe or Others	IS F	USE	All years	Gateway	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	

Europe or Others	IS F	USE	All years	Body No. 3	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS F	USE	All years	Body No. 5			√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS F	USE	All years	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	IS F	USE	All years	Passenger Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	IS F	USE	All years	Master Switch			√	0939, 0940, 0941, 0942	
Europe or Others	IS F	USE	All years	Sliding Roof			√	0529	
Europe or Others	IS F	USE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005

Europe or Others	IS F	USE	All years	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	IS F	USE	All years	Left Mirror			√	0279, 0280, 0281, 0282, 0283	
Europe or Others	IS F	USE	All years	Right Mirror			√	0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	IS F	USE	All years	Combination Switch			√		
Europe or Others	IS F	USE	All years	Clearance Sonar	√	√	√	0023, 0024	
Europe or Others	IS F	USE	All years	Rain Sensor			√		
Europe or Others	IS F	USE	All years	AFS	√	√	√	0008, 0475, 0476, 0477, 0968	

Europe or Others	IS F	USE	All years	Entry&Start	✓	✓	✓		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015
Europe or Others	IS F	USE	All years	Power Source Control	✓	✓	✓		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
Europe or Others	IS F	USE	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	IS F	USE	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050
Europe or Others	IS F	USE	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
Europe or Others	IS F	USE	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	IS F	USE	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	IS F	USE	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	IS F	USE	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036

Europe or Others	IS200	GXE	All years	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1 126, 1127, 11 28, 1129, 113 0, 1131, 1132 , 1133, 1134, 1135, 1136, 1 137, 1138, 11 39, 1140, 114 1, 1142, 1143 , 1144, 1145, 1146, 1147, 1 148, 1149, 11 50, 1151, 115 2, 1153, 1154 , 1155, 1156, 1157, 1158, 1 159, 1160, 11 61, 1162, 116 3, 1164, 1165 , 1166, 1167, 1168, 1169, 1 170, 1171, 11 72, 1173, 117 4, 1175, 1176 , 1177, 1178, 1179, 1180	SP0003, SP0 004
Europe or Others	IS200	GXE	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	IS200	GXE	All years	ABS/VSC/TRC	✓	✓	✓	✓	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021, SP0023
Europe or Others	IS200	GXE	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
Europe or Others	IS200	GXE	All years	Immobiliser	✓	✓	✓			SP0011, SP0013, SP0148
Europe or Others	IS200	GXE	All years	Supplement Restraint System (SRS) Airbag	✓	✓				SP0004

Europe or Others	IS200	GXE	All years	Body	✓	✓	✓	0031, 0032, 0319, 0333, 0337, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0922, 0923, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020
Europe or Others	IS200	GXE	All years	Combination Meter			✓	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	IS200	GXE	All years	Theft Deterrent	✓	✓	✓	0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	



Europe or Others	IS200D	ALE	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0031, SP0032, SP0033, SP0101, SP0103, SP0104, SP0105, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0112, SP0113, SP0139, SP0140
Europe or Others	IS200D	ALE	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	IS200D	ALE	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	IS200D	ALE	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	IS200D	ALE	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		

Europe or Others	IS200D	ALE	All years	Air Conditioner	√	√	√	0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017
Europe or Others	IS200D	ALE	All years	Supplement Restraint System (SRS) Airbag	√	√	√		SP0001
Europe or Others	IS200D	ALE	All years	Body	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005

Europe or Others	IS200D	ALE	All years	Gateway	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935
Europe or Others	IS200D	ALE	All years	Body No. 3	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

Europe or Others	IS200D	ALE	All years	Body No. 5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS200D	ALE	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	IS200D	ALE	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	IS200D	ALE	All years	Master Switch			√		0939, 0940, 0941, 0942	
Europe or Others	IS200D	ALE	All years	Sliding Roof			√		0529	
Europe or Others	IS200D	ALE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	

Europe or Others	IS200D	ALE	All years	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	IS200D	ALE	All years	Left Mirror			√	0279, 0280, 0281, 0282, 0283	
Europe or Others	IS200D	ALE	All years	Right Mirror			√	0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	IS200D	ALE	All years	Combination Switch			√		
Europe or Others	IS200D	ALE	All years	Clearance Sonar	√	√	√	0023, 0024	
Europe or Others	IS200D	ALE	All years	Rain Sensor			√		

Europe or Others	IS200D	ALE	All years	Entry&Start	√	√	√		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015
Europe or Others	IS200D	ALE	All years	Power Source Control	√	√	√		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
Europe or Others	IS200D	ALE	All years	Navigation System	√	√	√	√		SP0049, SP0050
Europe or Others	IS200t	ASE30	All years	Engine	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	SP0004, SP0026, SP0029, SP0032, SP0042, SP0073, SP0075, SP0101, SP0102

Europe or Others	IS200t	ASE30	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	IS200t	ASE30	All years	Stop and Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	SP0004, SP0030, SP0035, SP0092, SP0093, SP0094, SP0095, SP0096, SP0097
Europe or Others	IS200t	ASE30	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	



Europe or Others	IS200t	ASE30	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	IS200t	ASE30	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	IS200t	ASE30	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	IS200t	ASE30	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	IS200t	ASE30	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087

Europe or Others	IS200t	ASE30	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
Europe or Others	IS200t	ASE30	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
Europe or Others	IS200t	ASE30	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

Europe or Others	IS200t	ASE30	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	IS200t	ASE30	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	IS200t	ASE30	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	IS200t	ASE30	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	IS200t	ASE30	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	IS200t	ASE30	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	IS200t	ASE30	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	IS200t	ASE30	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	IS200t	ASE30	All years	Master Switch	✓	✓	✓			

Europe or Others	IS200t	ASE30	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	IS200t	ASE30	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	IS200t	ASE30	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	IS200t	ASE30	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	IS200t	ASE30	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	IS200t	ASE30	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	IS200t	ASE30	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	

Europe or Others	IS200t	ASE30	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	IS200t	ASE30	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	IS200t	ASE30	All years	Detection Of Occupant	√	√	√	√		SP0034, SP0035, SP0036
Europe or Others	IS200t	ASE30	All years	Remote Engine Starter	√	√	√	√		SP0046, SP0047, SP0048
Europe or Others	IS200t	ASE30	All years	Starting Control	√	√	√	√	0256, 0257	
Europe or Others	IS200t	ASE30	All years	Navigation System	√	√	√	√		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	IS200t	ASE30	All years	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071
Europe or Others	IS200t	ASE30	All years	Slave Blind Spot Monitor	√	√	√	√		
Europe or Others	IS200t	ASE30	All years	Telematics	√	√	√	√	0036	
Europe or Others	IS200t	ASE30	All years	Cruise Control	√	√	√	√		

Europe or Others	IS200t	ASE30	All years	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
Europe or Others	IS200t	ASE30	All years	Front Recognition Camera	√	√	√	√	0052	
Europe or Others	IS200t	ASE30	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
Europe or Others	IS200t	ASE30	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			√			
Europe or Others	IS200t	ASE30	All years	Central Gateway	√	√	√	√		
Europe or Others	IS200t	ASE30	All years	Road Sign Assist	√	√	√	√	1183	
Europe or Others	IS200t	ASE30	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	IS200t	ASE30	All years	ASC	√	√	√	√	1182	

Europe or Others	IS220D	ALE	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0031, SP0032, SP0033, SP0101, SP0103, SP0104, SP0105, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0112, SP0113, SP0139, SP0140
Europe or Others	IS220D	ALE	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	IS220D	ALE	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	IS220D	ALE	All years	EMPS	√	√	√	√		SP0001, SP0009, SP0010
Europe or Others	IS220D	ALE	All years	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017
Europe or Others	IS220D	ALE	All years	Supplement Restraint System (SRS) Airbag	√	√	√			SP0001



Europe or Others	IS220D	ALE	All years	Body	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
Europe or Others	IS220D	ALE	All years	Gateway	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	

Europe or Others	IS220D	ALE	All years	Body No. 3	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS220D	ALE	All years	Body No. 5			√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS220D	ALE	All years	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	IS220D	ALE	All years	Passenger Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	IS220D	ALE	All years	Master Switch			√	0939, 0940, 0941, 0942	
Europe or Others	IS220D	ALE	All years	Sliding Roof			√	0529	
Europe or Others	IS220D	ALE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005

Europe or Others	IS220D	ALE	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	IS220D	ALE	All years	Left Mirror			√		0279, 0280, 0281, 0282, 0283	
Europe or Others	IS220D	ALE	All years	Right Mirror			√		0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	IS220D	ALE	All years	Combination Switch			√			
Europe or Others	IS220D	ALE	All years	Clearance Sonar	√	√	√		0023, 0024	
Europe or Others	IS220D	ALE	All years	Rain Sensor			√			
Europe or Others	IS220D	ALE	All years	AFS	√	√	√		0008, 0475, 0476, 0477, 0968	

Europe or Others	IS220D	ALE	All years	Entry&Start	√	√	√		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015
Europe or Others	IS220D	ALE	All years	Power Source Control	√	√	√		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
Europe or Others	IS220D	ALE	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	IS220D	ALE	All years	Navigation System	√	√	√	√		SP0049, SP0050
Europe or Others	IS250	GSE	All years	Engine	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101

Europe or Others	IS250	GSE	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	IS250	GSE	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	IS250	GSE	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	IS250	GSE	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002
Europe or Others	IS250	GSE	All years	EMPS	√	√	√	√		SP0001, SP0009, SP0010

Europe or Others	IS250	GSE	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019,	SP0016, SP0017, SP0051
Europe or Others	IS250	GSE	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	IS250	GSE	All years	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
Europe or Others	IS250	GSE	All years	Gateway	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	SP0005



Europe or Others	IS250	GSE	All years	Body No. 3	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS250	GSE	All years	Body No. 5			√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS250	GSE	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
Europe or Others	IS250	GSE	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517
Europe or Others	IS250	GSE	All years	Master Switch	√	√	√		0939, 0940, 0941, 0942
Europe or Others	IS250	GSE	All years	Sliding Roof	√	√	√		0529

Europe or Others	IS250	GSE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
Europe or Others	IS250	GSE	All years	Combination Meter	√	√	√	√	0274, 0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679,	
Europe or Others	IS250	GSE	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	IS250	GSE	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	IS250	GSE	All years	Combination Switch			√			
Europe or Others	IS250	GSE	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	SP0006
Europe or Others	IS250	GSE	All years	Rain Sensor			√			

Europe or Others	IS250	GSE	All years	AFS	√	√	√		0008, 0475, 0476, 0477, 0968	
Europe or Others	IS250	GSE	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	IS250	GSE	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	SP0045
Europe or Others	IS250	GSE	All years	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
Europe or Others	IS250	GSE	All years	4WD	√	√	√	√	0819, 0820, 0821, 0822	SP0003, SP0052
Europe or Others	IS250	GSE	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	IS250	GSE	All years	Accessory Gateway	√	√	√	√		SP0005
Europe or Others	IS250	GSE	All years	Navigation System	√	√	√	√		SP0049, SP0050

Europe or Others	IS250	GSE	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0101
Europe or Others	IS250	GSE	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	IS250	GSE	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087

Europe or Others	IS250	GSE	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	IS250	GSE	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	IS250	GSE	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	IS250	GSE	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	IS250	GSE	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	IS250	GSE	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
Europe or Others	IS250	GSE	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
Europe or Others	IS250	GSE	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	IS250	GSE	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071

Europe or Others	IS250	GSE	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	IS250	GSE	All years	Telematics	✓	✓	✓	✓		SP0059, SP0060
Europe or Others	IS250	GSE	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
Europe or Others	IS250	GSE	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	IS250	GSE	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
Europe or Others	IS250	GSE	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	IS250C	GSE	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0043, SP0101

Europe or Others	IS250C	GSE	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	IS250C	GSE	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	IS250C	GSE	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	IS250C	GSE	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002
Europe or Others	IS250C	GSE	All years	EMPS	√	√	√	√		SP0001, SP0009, SP0010
Europe or Others	IS250C	GSE	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		



Europe or Others	IS250C	GSE	All years	Air Conditioner	√	√	√	0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017
Europe or Others	IS250C	GSE	All years	Supplement Restraint System (SRS) Airbag	√	√	√		SP0001
Europe or Others	IS250C	GSE	All years	Body	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005

Europe or Others	IS250C	GSE	All years	Gateway	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935
Europe or Others	IS250C	GSE	All years	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

Europe or Others	IS250C	GSE	All years	Body No. 5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS250C	GSE	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	IS250C	GSE	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	IS250C	GSE	All years	Master Switch			√		0939, 0940, 0941, 0942	
Europe or Others	IS250C	GSE	All years	P Master Switch			√		0941	
Europe or Others	IS250C	GSE	All years	Hardtop Retractable	√	√	√		0970	
Europe or Others	IS250C	GSE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	

Europe or Others	IS250C	GSE	All years	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	IS250C	GSE	All years	Left Mirror			√	0279, 0280, 0281, 0282, 0283	
Europe or Others	IS250C	GSE	All years	Right Mirror			√	0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	IS250C	GSE	All years	Combination Switch			√		
Europe or Others	IS250C	GSE	All years	Clearance Sonar	√	√	√	0023, 0024	
Europe or Others	IS250C	GSE	All years	Rain Sensor			√		
Europe or Others	IS250C	GSE	All years	AFS	√	√	√	0008, 0475, 0476, 0477, 0968	

Europe or Others	IS250C	GSE	All years	Entry&Start	√	√	√		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015
Europe or Others	IS250C	GSE	All years	Power Source Control	√	√	√		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
Europe or Others	IS250C	GSE	All years	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
Europe or Others	IS250C	GSE	All years	Navigation System	√	√	√	√		SP0049, SP0050
Europe or Others	IS250C	GSE	All years	Accessory Gateway	√	√	√	√		SP0005
Europe or Others	IS250C	GSE	All years	Radar Cruise	√	√	√	√		
Europe or Others	IS250C	GSE	All years	Pre-Crash	√	√	√	√	0347, 0348, 0349, 0350	

Europe or Others	IS300	ASE30	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	
------------------------	-------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

Europe or Others	IS300	ASE30	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	IS300	ASE30	All years	Stop and Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	
Europe or Others	IS300	ASE30	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	

Europe or Others	IS300	ASE30	All years	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
Europe or Others	IS300	ASE30	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	IS300	ASE30	All years	Tire Pressure Monitor	√	√	√			
Europe or Others	IS300	ASE30	All years	EMPS	√	√	√	√		



Europe or Others	IS300	ASE30	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	IS300	ASE30	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	IS300	ASE30	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	IS300	ASE30	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	IS300	ASE30	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	

Europe or Others	IS300	ASE30	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		
Europe or Others	IS300	ASE30	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
Europe or Others	IS300	ASE30	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	IS300	ASE30	All years	Accessory Gateway	√	√	√	√		
Europe or Others	IS300	ASE30	All years	Central Gateway	√	√	√	√		
Europe or Others	IS300	ASE30	All years	Driver Door Motor	√	√	√		0528	
Europe or Others	IS300	ASE30	All years	Passenger Door Motor	√	√	√		0528	
Europe or Others	IS300	ASE30	All years	Left Rear Door Motor	√	√	√		0528	
Europe or Others	IS300	ASE30	All years	Right Rear Door Motor	√	√	√		0528	

Europe or Others	IS300	ASE30	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
Europe or Others	IS300	ASE30	All years	Master Switch	✓	✓	✓		
Europe or Others	IS300	ASE30	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	IS300	ASE30	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	IS300	ASE30	All years	Road Sign Assist	✓	✓	✓	✓	1183
Europe or Others	IS300	ASE30	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	IS300	ASE30	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	IS300	ASE30	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	IS300	ASE30	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
Europe or Others	IS300	ASE30	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
Europe or Others	IS300	ASE30	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	IS300	ASE30	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	IS300	ASE30	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	IS300	ASE30	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	IS300	ASE30	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	IS300	ASE30	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	IS300	ASE30	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	IS300	ASE30	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	IS300	ASE30	All years	Telematics	✓	✓	✓	✓	0036	

Europe or Others	IS300	ASE30	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	IS300	ASE30	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	IS300	ASE30	All years	Detection Of Occupant	✓	✓	✓			
Europe or Others	IS300	GSE	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101

Europe or Others	IS300	GSE	All years	ECT	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0096, 0 097, 0100, 01 01, 0102, 010 3, 0104, 0105 , 0106, 0107, 0108, 0109, 0 110, 0111, 01 12, 0113, 011 5, 0116, 0117 , 0118, 0119, 0120, 0121, 0 122, 0123, 01 24, 0125, 012 6, 0127, 0128 , 0129, 0130, 0131, 0132, 0 133, 0134, 01 35, 0136, 013 7, 0138, 0139 , 0140, 0141, 0149, 0159, 0 161, 0162, 01 63, 0164, 016 5, 0166, 0167 , 0168, 0169,	SP0003, SPO 004, SP0031 , SP0032, SP 0101
Europe or Others	IS300	GSE	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	IS300	GSE	All years	ABS/VSC/TC RC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	IS300	GSE	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010

Europe or Others	IS300	GSE	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019,	SP0016, SP0017
Europe or Others	IS300	GSE	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001



Europe or Others	IS300	GSE	All years	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
Europe or Others	IS300	GSE	All years	Gateway	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	SP0005

Europe or Others	IS300	GSE	All years	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS300	GSE	All years	Body No. 5			✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS300	GSE	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
Europe or Others	IS300	GSE	All years	Passenger Seat			✓		0422, 0423, 0424, 0515, 0516, 0517
Europe or Others	IS300	GSE	All years	Master Switch	✓	✓	✓		0939, 0940, 0941, 0942
Europe or Others	IS300	GSE	All years	Sliding Roof	✓	✓	✓		0529

Europe or Others	IS300	GSE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
Europe or Others	IS300	GSE	All years	Combination Meter	√	√	√	√	0274, 0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679,	
Europe or Others	IS300	GSE	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	IS300	GSE	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	IS300	GSE	All years	Combination Switch			√			
Europe or Others	IS300	GSE	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	SP0006
Europe or Others	IS300	GSE	All years	Rain Sensor			√			

Europe or Others	IS300	GSE	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493, 0968	
Europe or Others	IS300	GSE	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	IS300	GSE	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	SP0045
Europe or Others	IS300	GSE	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	IS300	GSE	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	IS300	GSE	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	IS300	GSE	All years	Telematics	✓	✓	✓	✓		SP0059, SP0060
Europe or Others	IS300	GSE	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
Europe or Others	IS300	GSE	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	

Europe or Others	IS300	GSE	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	IS300	GSE	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
Europe or Others	IS300	GSE	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	IS300	GSE	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
Europe or Others	IS300	GSE	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002

Europe or Others	IS300	GSE	All years	VGRS	✓	✓	✓	✓		SP0004, SP0037
Europe or Others	IS300	GSE	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
Europe or Others	IS300	GSE	All years	DRS	✓	✓	✓	✓		SP0004, SP0081, SP0082, SP0083
Europe or Others	IS300	GSE	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	IS300	GSE	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	IS300	GSE	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	IS300	GSE	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	IS300	GSE	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	IS300	GSE	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003

Europe or Others	IS300	GSE	All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
Europe or Others	IS300	GSE	All years	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
Europe or Others	IS300	GSE	All years	Remote Engine Starter	√	√	√	√		SP0046, SP0047, SP0048
Europe or Others	IS300	GSE	All years	Starting Control	√	√	√	√	0256, 0257	
Europe or Others	IS300	GSE	All years	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071
Europe or Others	IS300	GSE	All years	Slave Blind Spot Monitor	√	√	√	√		
Europe or Others	IS300	GSE	All years	Front Recognition Camera	√	√	√	√	0052	
Europe or Others	IS300	GSE	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
Europe or Others	IS300	GSE	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
Europe or Others	IS300	GSE	All years	Pre-Collision 2	√	√	√	√	0022	
Europe or Others	IS300	GSE	All years	Central Gateway	√	√	√	√		

Europe or Others	IS300	JCE	All years	Engine and ECT	√	√	√	√	0169, 0255, 1 126, 1127, 11 28, 1129, 113 0, 1131, 1132 , 1133, 1134, 1135, 1136, 1 137, 1138, 11 39, 1140, 114 1, 1142, 1143 , 1144, 1145, 1146, 1147, 1 148, 1149, 11 50, 1151, 115 2, 1153, 1154 , 1155, 1156, 1157, 1158, 1 159, 1160, 11 61, 1162, 116 3, 1164, 1165 , 1166, 1167, 1168, 1169, 1 170, 1171, 11 72, 1173, 117 4, 1175, 1176 , 1177, 1178, 1179, 1180	SP0003, SP0 004
Europe or Others	IS300	JCE	All years	Cruise Control	√	√	√	√		



Europe or Others	IS300	JCE	All years	ABS/VSC/TPC	✓	✓	✓	✓	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021, SP0023
Europe or Others	IS300	JCE	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
Europe or Others	IS300	JCE	All years	Immobiliser	✓	✓	✓			SP0011, SP0013, SP0148

Europe or Others	IS300	JCE	All years	Theft Deterrent	✓	✓	✓	0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	
Europe or Others	IS300	JCE	All years	Supplement Restraint System (SRS) Airbag	✓	✓			SP0004
Europe or Others	IS300	JCE	All years	Body	✓	✓	✓	0031, 0032, 0319, 0333, 0337, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0922, 0923, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020

Europe or Others	IS300	JCE	All years	Combinati on Meter			√	0274, 0616, 0 617, 0618, 06 19, 0629, 066 2, 0665, 0669 , 0670, 0671, 0672, 0673, 0 675, 0676, 06 77, 0678, 067 9, 0680, 0681 , 0692, 0719, 0745, 0746, 0 749, 0756, 07 60, 0761, 076 2, 0763, 0764 , 0765, 0766, 0767, 0768, 0 769, 0770, 07 71, 0772, 077 3, 0774, 0775 , 0776, 0777, 0778, 0779, 0 780, 0781, 07 82, 1000, 102 9, 1030, 1031 , 1032, 1033, 1034, 1035, 1 036, 1037, 10 38, 1039, 104 0, 1041, 1042 , 1043, 1044,	
------------------------	-------	-----	--------------	-----------------------	--	--	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

Europe or Others	IS300C	GSE	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0090, 0 091, 0092, 00 93, 0094, 009 5, 0096, 0097 , 0098, 0099, 0100, 0101, 0 102, 0103, 01 04, 0105, 010 6, 0107, 0108 , 0109, 0110, 0111, 0112, 0 113, 0114, 01 15, 0116, 011 7, 0118, 0119 , 0120, 0121, 0122, 0123, 0 124, 0125, 01 26, 0127, 012 8, 0129, 0130 , 0131, 0132, 0133, 0134, 0 135, 0136, 01 37, 0138, 013 9, 0140, 0141 , 0142, 0143,	SP0004, SP0 026, SP0027 , SP0028, SP 0029, SP003 0, SP0031, S P0032, SP00 33, SP0101
------------------------	--------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------

Europe or Others	IS300C	GSE	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	IS300C	GSE	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	IS300C	GSE	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	IS300C	GSE	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002
Europe or Others	IS300C	GSE	All years	EMPS	√	√	√	√		SP0001, SP0009, SP0010
Europe or Others	IS300C	GSE	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		

Europe or Others	IS300C	GSE	All years	Air Conditioner	√	√	√	0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017
Europe or Others	IS300C	GSE	All years	Supplement Restraint System (SRS) Airbag	√	√	√		SP0001
Europe or Others	IS300C	GSE	All years	Body	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005

Europe or Others	IS300C	GSE	All years	Gateway	√	√	√	0031, 0032, 0 319, 0331, 03 33, 0335, 033 7, 0339, 0429 , 0499, 0500, 0501, 0783, 0 784, 0785, 08 01, 0802, 080 5, 0806, 0807 , 0809, 0815, 0816, 0912, 0 913, 0914, 09 15, 0916, 091 7, 0918, 0919 , 0920, 0921, 0922, 0923, 0 924, 0925, 09 26, 0927, 092 8, 0929, 0930 , 0931, 0932, 0933, 0934, 0 935
Europe or Others	IS300C	GSE	All years	Body No. 3	√	√	√	0031, 0032, 0 312, 0313, 03 14, 0315, 031 6, 0320, 0321 , 0325, 0329, 0330, 0332, 0 337, 0338, 08 05, 0912, 091 7, 0918, 0929 , 0931, 0943, 0944, 0945, 0 946, 0947, 09 48, 0949, 095 0, 0951, 0952 , 0953, 0954, 0955, 0956, 0 957, 0958, 09 59, 0960, 096 1, 0962, 0963 , 0964, 0965, 0966, 0967



Europe or Others	IS300C	GSE	All years	Body No. 5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS300C	GSE	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	IS300C	GSE	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	IS300C	GSE	All years	Master Switch			√		0939, 0940, 0941, 0942	
Europe or Others	IS300C	GSE	All years	P Master Switch			√		0941	
Europe or Others	IS300C	GSE	All years	Hardtop Retractable	√	√	√		0970	
Europe or Others	IS300C	GSE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	

Europe or Others	IS300C	GSE	All years	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	IS300C	GSE	All years	Left Mirror			√	0279, 0280, 0281, 0282, 0283	
Europe or Others	IS300C	GSE	All years	Right Mirror			√	0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	IS300C	GSE	All years	Combination Switch			√		
Europe or Others	IS300C	GSE	All years	Clearance Sonar	√	√	√	0023, 0024	
Europe or Others	IS300C	GSE	All years	Rain Sensor			√		
Europe or Others	IS300C	GSE	All years	AFS	√	√	√	0008, 0475, 0476, 0477, 0968	

Europe or Others	IS300C	GSE	All years	Entry&Start	√	√	√		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015
Europe or Others	IS300C	GSE	All years	Power Source Control	√	√	√		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
Europe or Others	IS300C	GSE	All years	Navigation System	√	√	√	√		SP0049, SP0050
Europe or Others	IS300C	GSE	All years	Accessory Gateway	√	√	√	√		SP0005
Europe or Others	IS300C	GSE	All years	Radar Cruise	√	√	√	√		SP0061, SP0062
Europe or Others	IS300C	GSE	All years	Pre-Crash	√	√	√	√	0347, 0348, 0349, 0350	
Europe or Others	IS300h	AVE30	All years	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101

Europe or Others	IS300h	AVE30	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058
Europe or Others	IS300h	AVE30	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	IS300h	AVE30	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

Europe or Others	IS300h	AVE30	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023
Europe or Others	IS300h	AVE30	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	IS300h	AVE30	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	IS300h	AVE30	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087

Europe or Others	IS300h	AVE30	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	IS300h	AVE30	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	IS300h	AVE30	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	IS300h	AVE30	All years	Gateway	√	√		√		SP0005
Europe or Others	IS300h	AVE30	All years	Driver Door Motor	√	√	√		0528	SP0003
Europe or Others	IS300h	AVE30	All years	Passenger Door Motor	√	√	√		0528	SP0003
Europe or Others	IS300h	AVE30	All years	Left Rear Door Motor	√	√	√		0528	SP0003
Europe or Others	IS300h	AVE30	All years	Right Rear Door Motor	√	√	√		0528	SP0003
Europe or Others	IS300h	AVE30	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	IS300h	AVE30	All years	Master Switch	√	√	√			
Europe or Others	IS300h	AVE30	All years	Sliding Roof	√	√	√		0529	

Europe or Others	IS300h	AVE30	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	
Europe or Others	IS300h	AVE30	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	IS300h	AVE30	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	IS300h	AVE30	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	IS300h	AVE30	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	SP0006
Europe or Others	IS300h	AVE30	All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	



Europe or Others	IS300h	AVE30	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	IS300h	AVE30	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	IS300h	AVE30	All years	Navigation System	√	√	√	√		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	IS300h	AVE30	All years	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071
Europe or Others	IS300h	AVE30	All years	Slave Blind Spot Monitor	√	√	√	√		
Europe or Others	IS300h	AVE30	All years	Grill Shutter	√	√	√		0037, 0038, 0039, 0040	SP0080
Europe or Others	IS300h	AVE30	All years	ASC	√	√	√	√	1182	
Europe or Others	IS300h	AVE30	All years	Radar Cruise 2	√	√	√	√	0017, 0018	
Europe or Others	IS300h	AVE30	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	IS300h	AVE30	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	IS300h	AVE30	All years	Front Recognition Camera	√	√	√	√	0052	

Europe or Others	IS300h	AVE30	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
Europe or Others	IS300h	AVE30	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			√			
Europe or Others	IS300h	AVE30	All years	Central Gateway	√	√	√	√		
Europe or Others	IS300h	AVE30	All years	Vehicle proximity notification system	√	√	√	√		
Europe or Others	IS300h	AVE30	All years	Telematics	√	√	√	√	0036	

Europe or Others	IS350	GSE	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0090, 0 091, 0092, 00 93, 0094, 009 5, 0096, 0097 , 0098, 0099, 0100, 0101, 0 102, 0103, 01 04, 0105, 010 6, 0107, 0108 , 0109, 0110, 0111, 0112, 0 113, 0114, 01 15, 0116, 011 7, 0118, 0119 , 0120, 0121, 0122, 0123, 0 124, 0125, 01 26, 0127, 012 8, 0129, 0130 , 0131, 0132, 0133, 0134, 0 135, 0136, 01 37, 0138, 013 9, 0140, 0141 , 0142, 0143,	SP0004, SP0 026, SP0027 , SP0028, SP 0029, SP003 0, SP0031, S P0032, SP00 33, SP0042, SP0043, SP0 101
------------------------	-------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------

Europe or Others	IS350	GSE	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	IS350	GSE	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	IS350	GSE	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP003, SP0021, SP0022, SP0023, SP0024
Europe or Others	IS350	GSE	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	IS350	GSE	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		

Europe or Others	IS350	GSE	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019,	SP0016, SP0017, SP0051
Europe or Others	IS350	GSE	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	IS350	GSE	All years	Body	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
Europe or Others	IS350	GSE	All years	Gateway	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	SP0005

Europe or Others	IS350	GSE	All years	Body No. 3	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS350	GSE	All years	Body No. 5			√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS350	GSE	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
Europe or Others	IS350	GSE	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517
Europe or Others	IS350	GSE	All years	Master Switch	√	√	√		0939, 0940, 0941, 0942
Europe or Others	IS350	GSE	All years	Sliding Roof	√	√	√		0529



Europe or Others	IS350	GSE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
Europe or Others	IS350	GSE	All years	Combination Meter	√	√	√	√	0274, 0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679,	
Europe or Others	IS350	GSE	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	IS350	GSE	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	IS350	GSE	All years	Combination Switch			√			
Europe or Others	IS350	GSE	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	SP0006
Europe or Others	IS350	GSE	All years	Rain Sensor			√			

Europe or Others	IS350	GSE	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	IS350	GSE	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	SP0045
Europe or Others	IS350	GSE	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050
Europe or Others	IS350	GSE	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
Europe or Others	IS350	GSE	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	IS350	GSE	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	IS350	GSE	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	IS350	GSE	All years	VGRS	✓	✓	✓	✓		SP0004, SP0037
Europe or Others	IS350	GSE	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087

Europe or Others	IS350	GSE	All years	DRS	√	√	√	√		SP0004, SP0081, SP0082, SP0083
Europe or Others	IS350	GSE	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	IS350	GSE	All years	Accessory Gateway	√	√	√	√		SP0005
Europe or Others	IS350	GSE	All years	Driver Door Motor	√	√	√		0528	
Europe or Others	IS350	GSE	All years	Passenger Door Motor	√	√	√		0528	
Europe or Others	IS350	GSE	All years	Left Rear Door Motor	√	√	√		0528	
Europe or Others	IS350	GSE	All years	Right Rear Door Motor	√	√	√		0528	
Europe or Others	IS350	GSE	All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
Europe or Others	IS350	GSE	All years	Detection Of Occupant	√	√	√	√		

Europe or Others	IS350	GSE	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
Europe or Others	IS350	GSE	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	IS350	GSE	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	IS350	GSE	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	IS350	GSE	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
Europe or Others	IS350	GSE	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	IS350	GSE	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	
Europe or Others	IS350	GSE	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	

Europe or Others	IS350	GSE	All years	Front Recognition Camera	√	√	√	√	0052	
Europe or Others	IS350	GSE	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
Europe or Others	IS350	GSE	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			√			
Europe or Others	IS350	GSE	All years	Pre-Collision 2	√	√	√	√	0022	
Europe or Others	IS350	GSE	All years	Central Gateway	√	√	√	√		
Europe or Others	IS350	GSE	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	

Europe or Others	IS350	GSE3#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	
------------------------	-------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

Europe or Others	IS350	GSE3#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
Europe or Others	IS350	GSE3#	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018
Europe or Others	IS350	GSE3#	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471

Europe or Others	IS350	GSE3#	All years	ABS/VSC/TRC/EPB	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	IS350	GSE3#	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	
Europe or Others	IS350	GSE3#	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	IS350	GSE3#	All years	EMPS	✓	✓	✓	✓		
Europe or Others	IS350	GSE3#	All years	VGRS	✓	✓	✓	✓		
Europe or Others	IS350	GSE3#	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	IS350	GSE3#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	



Europe or Others	IS350	GSE3#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824
Europe or Others	IS350	GSE3#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			√		
Europe or Others	IS350	GSE3#	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615
Europe or Others	IS350	GSE3#	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√	
Europe or Others	IS350	GSE3#	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298

Europe or Others	IS350	GSE3#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	IS350	GSE3#	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	IS350	GSE3#	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	IS350	GSE3#	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	IS350	GSE3#	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	IS350	GSE3#	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	IS350	GSE3#	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	IS350	GSE3#	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	IS350	GSE3#	All years	Master Switch	✓	✓	✓			

Europe or Others	IS350	GSE3#	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	IS350	GSE3#	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	IS350	GSE3#	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	IS350	GSE3#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	IS350	GSE3#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

Europe or Others	IS350	GSE3#	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
Europe or Others	IS350	GSE3#	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	IS350	GSE3#	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	IS350	GSE3#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	IS350	GSE3#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	IS350	GSE3#	All years	Detection Of Occupant	✓	✓	✓			
Europe or Others	IS350	GSE3#	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	IS350	GSE3#	All years	Starting Control	✓	✓	✓	✓	0256, 0257	

Europe or Others	IS350	GSE3#	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	IS350	GSE3#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	IS350	GSE3#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	IS350	GSE3#	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	IS350C	GSE	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0043, SP0101

Europe or Others	IS350C	GSE	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	IS350C	GSE	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	IS350C	GSE	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	IS350C	GSE	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002
Europe or Others	IS350C	GSE	All years	EMPS	√	√	√	√		SP0001, SP0009, SP0010
Europe or Others	IS350C	GSE	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		

Europe or Others	IS350C	GSE	All years	Air Conditioner	√	√	√	0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017
Europe or Others	IS350C	GSE	All years	Supplement Restraint System (SRS) Airbag	√	√	√		SP0001
Europe or Others	IS350C	GSE	All years	Body	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005



Europe or Others	IS350C	GSE	All years	Gateway	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935
Europe or Others	IS350C	GSE	All years	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

Europe or Others	IS350C	GSE	All years	Body No. 5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	IS350C	GSE	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	IS350C	GSE	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	IS350C	GSE	All years	Master Switch			√		0939, 0940, 0941, 0942	
Europe or Others	IS350C	GSE	All years	P Master Switch			√		0941	
Europe or Others	IS350C	GSE	All years	Hardtop Retractable	√	√	√		0970	
Europe or Others	IS350C	GSE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	

Europe or Others	IS350C	GSE	All years	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	IS350C	GSE	All years	Left Mirror			√	0279, 0280, 0281, 0282, 0283	
Europe or Others	IS350C	GSE	All years	Right Mirror			√	0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	IS350C	GSE	All years	Combination Switch			√		
Europe or Others	IS350C	GSE	All years	Clearance Sonar	√	√	√	0023, 0024	
Europe or Others	IS350C	GSE	All years	Rain Sensor			√		
Europe or Others	IS350C	GSE	All years	AFS	√	√	√	0008, 0475, 0476, 0477, 0968	

Europe or Others	IS350C	GSE	All years	Entry&Start	✓	✓	✓		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015
Europe or Others	IS350C	GSE	All years	Power Source Control	✓	✓	✓		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
Europe or Others	IS350C	GSE	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	IS350C	GSE	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050
Europe or Others	IS350C	GSE	All years	Radar Cruise	✓	✓	✓	✓		
Europe or Others	IS350C	GSE	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	LC500	URZ100	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	

Europe or Others	LC500	URZ100	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	LC500	URZ100	All years	Cruise Control	✓	✓	✓	✓	0017, 0018	
Europe or Others	LC500	URZ100	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	

Europe or Others	LC500	URZ100	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0024
Europe or Others	LC500	URZ100	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	LC500	URZ100	All years	EMPS	✓	✓	✓	✓		
Europe or Others	LC500	URZ100	All years	VGRS	✓	✓	✓	✓		
Europe or Others	LC500	URZ100	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	

Europe or Others	LC500	URZ100	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	LC500	URZ100	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	LC500	URZ100	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	LC500	URZ100	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	LC500	URZ100	All years	DRS	✓	✓	✓	✓		
Europe or Others	LC500	URZ100	All years	Steering Angle Sensor	✓	✓	✓			

Europe or Others	LC500	URZ100	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615
Europe or Others	LC500	URZ100	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓	
Europe or Others	LC500	URZ100	All years	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298



Europe or Others	LC500	URZ10 0	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0 300, 0301, 03 17, 0319, 033 3, 0335, 0337 , 0339, 0426, 0427, 0429, 0 433, 0434, 04 35, 0436, 049 0, 0496, 0497 , 0498, 0499, 0500, 0501, 0 502, 0783, 07 84, 0785, 078 6, 0787, 0788 , 0789, 0790, 0791, 0792, 0 793, 0794, 07 95, 0796, 079 7, 0798, 0799 , 0800, 0801, 0802, 0803, 0 804, 0805, 08 06, 0807, 080 8, 0809, 0810 , 0811, 0812, 0813, 0814, 0 815, 0816, 08 17, 0818	
Europe or Others	LC500	URZ10 0	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	LC500	URZ10 0	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	LC500	URZ10 0	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	LC500	URZ10 0	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	LC500	URZ10 0	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	LC500	URZ10 0	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	LC500	URZ10 0	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0 422, 0423, 04 24, 0513, 051 4, 0515, 0516 , 0517, 0518, 0519	

Europe or Others	LC500	URZ100	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	LC500	URZ100	All years	Master Switch	✓	✓	✓		
Europe or Others	LC500	URZ100	All years	Tilt&Telescopic	✓	✓	✓		1513, 1514
Europe or Others	LC500	URZ100	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	LC500	URZ100	All years	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512
Europe or Others	LC500	URZ100	All years	Road Sign Assist	✓	✓	✓	✓	1183
Europe or Others	LC500	URZ100	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026

Europe or Others	LC500	URZ100	All years	Rain and/or Humidity Sensor	✓	✓	✓			
Europe or Others	LC500	URZ100	All years	Wiper	✓	✓	✓	✓	0031, 0032	
Europe or Others	LC500	URZ100	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	LC500	URZ100	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
Europe or Others	LC500	URZ100	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	LC500	URZ100	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	
Europe or Others	LC500	URZ100	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	LC500	URZ100	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	

Europe or Others	LC500	URZ100	All years	Detection Of Occupant	✓	✓	✓			
Europe or Others	LC500	URZ100	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	LC500	URZ100	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	LC500	URZ100	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	LC500	URZ100	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LC500	URZ100	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LC500	URZ100	All years	Active Rear Wing	✓	✓	✓		1189, 1190, 1191, 1192, 1193	
Europe or Others	LC500	URZ100	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LC500	URZ100	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LC500	URZ100	All years	Active Noise Control	✓	✓	✓		1515, 1516, 1517, 1518, 1519	
Europe or Others	LC500	URZ100	All years	Pedestrian Protection	✓	✓	✓			
Europe or Others	LC500	URZ100	All years	Sub Battery Module	✓	✓	✓		0029, 0030	
Europe or Others	LC500	URZ100	All years	Power Integration No. 1	✓	✓	✓			
Europe or Others	LC500	URZ100	All years	Power Integration No. 3	✓	✓	✓			
Europe or Others	LC500	URZ100	All years	Telematics	✓	✓	✓	✓		
Europe or Others	LC500	URZ100	All years	Radar Cruise 1	✓	✓	✓	✓		

Europe or Others	LC500c	URZ10 0	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0090, 0 091, 0092, 00 93, 0094, 009 5, 0096, 0097 , 0098, 0099, 0100, 0101, 0 102, 0103, 01 04, 0105, 010 6, 0107, 0108 , 0109, 0110, 0111, 0112, 0 113, 0114, 01 15, 0116, 011 7, 0118, 0119 , 0120, 0121, 0122, 0123, 0 124, 0125, 01 26, 0127, 012 8, 0129, 0130 , 0131, 0132, 0133, 0134, 0 135, 0136, 01 37, 0138, 013 9, 0140, 0141 , 0142, 0143,	
------------------------	--------	------------	--------------	-------------------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

Europe or Others	LC500c	URZ100	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
Europe or Others	LC500c	URZ100	All years	Cruise Control	✓	✓	✓	✓	0017, 0018
Europe or Others	LC500c	URZ100	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471

Europe or Others	LC500c	URZ100	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	LC500c	URZ100	All years	Tire Pressure Monitor	√	√	√			
Europe or Others	LC500c	URZ100	All years	EMPS	√	√	√	√		
Europe or Others	LC500c	URZ100	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	LC500c	URZ100	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		

Europe or Others	LC500c	URZ100	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	LC500c	URZ100	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	LC500c	URZ100	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	LC500c	URZ100	All years	Steering Angle Sensor	✓	✓	✓			
Europe or Others	LC500c	URZ100	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	



Europe or Others	LC500c	URZ100	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		
Europe or Others	LC500c	URZ100	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
Europe or Others	LC500c	URZ100	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	LC500c	URZ100	All years	Accessory Gateway	√	√	√	√		
Europe or Others	LC500c	URZ100	All years	Central Gateway	√	√	√	√		
Europe or Others	LC500c	URZ100	All years	Driver Door Motor	√	√	√		0528	
Europe or Others	LC500c	URZ100	All years	Passenger Door Motor	√	√	√		0528	
Europe or Others	LC500c	URZ100	All years	Left Rear Door Motor	√	√	√		0528	
Europe or Others	LC500c	URZ100	All years	Right Rear Door Motor	√	√	√		0528	

Europe or Others	LC500c	URZ100	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	LC500c	URZ100	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	LC500c	URZ100	All years	Master Switch	✓	✓	✓			
Europe or Others	LC500c	URZ100	All years	Tilt&Telescopic	✓	✓	✓		1513, 1514	
Europe or Others	LC500c	URZ100	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	LC500c	URZ100	All years	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
Europe or Others	LC500c	URZ100	All years	Road Sign Assist	✓	✓	✓	✓	1183	

Europe or Others	LC500c	URZ100	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026
Europe or Others	LC500c	URZ100	All years	Rain and/or Humidity Sensor	√	√	√		
Europe or Others	LC500c	URZ100	All years	Wiper	√	√	√	√	0031, 0032
Europe or Others	LC500c	URZ100	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
Europe or Others	LC500c	URZ100	All years	Adaptive Front Lighting System (AFS) (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028
Europe or Others	LC500c	URZ100	All years	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015
Europe or Others	LC500c	URZ100	All years	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0006
Europe or Others	LC500c	URZ100	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553

Europe or Others	LC500c	URZ100	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305
Europe or Others	LC500c	URZ100	All years	Detection Of Occupant	✓	✓	✓		
Europe or Others	LC500c	URZ100	All years	Remote Engine Starter	✓	✓	✓	✓	
Europe or Others	LC500c	URZ100	All years	Starting Control	✓	✓	✓	✓	0256, 0257
Europe or Others	LC500c	URZ100	All years	Navigation System	✓	✓	✓	✓	
Europe or Others	LC500c	URZ100	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	LC500c	URZ100	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	LC500c	URZ100	All years	Active Rear Wing	✓	✓	✓		1189, 1190, 1191, 1192, 1193
Europe or Others	LC500c	URZ100	All years	Master Blind Spot Monitor	✓	✓	✓	✓	
Europe or Others	LC500c	URZ100	All years	Slave Blind Spot Monitor	✓	✓	✓	✓	
Europe or Others	LC500c	URZ100	All years	Active Noise Control	✓	✓	✓		1515, 1516, 1517, 1518, 1519
Europe or Others	LC500c	URZ100	All years	Pedestrian Protection	✓	✓	✓		
Europe or Others	LC500c	URZ100	All years	Sub Battery Module	✓	✓	✓		0029, 0030
Europe or Others	LC500c	URZ100	All years	Power Integration No. 1	✓	✓	✓		
Europe or Others	LC500c	URZ100	All years	Power Integration No. 3	✓	✓	✓		
Europe or Others	LC500c	URZ100	All years	Telematics	✓	✓	✓		1521, 1522

Europe or Others	LC500c	URZ100	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	
Europe or Others	LC500h	GWZ100	All years	Hybrid Control	✓	✓	✓		0070, 0071, 0079, 0081, 0180, 0194, 0195, 1207, 1208, 1493, 1494, 1495, 1496, 1497	
Europe or Others	LC500h	GWZ100	All years	Motor Generator	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	High Voltage (HV) Battery	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	Radar Cruise 2	✓	✓	✓	✓		

Europe or Others	LC500h	GWZ100	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
Europe or Others	LC500h	GWZ100	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	LC500h	GWZ100	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	LC500h	GWZ100	All years	EMPS	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	VGRS	✓	✓	✓	✓		

Europe or Others	LC500h	GWZ100	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	LC500h	GWZ100	All years	Parking Assist Camera	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	LC500h	GWZ100	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	LC500h	GWZ100	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	LC500h	GWZ100	All years	DRS	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	Steering Angle Sensor	✓	✓	✓			

Europe or Others	LC500h	GWZ100	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	LC500h	GWZ100	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	Pre-Collision 2	✓	✓	✓	✓	0022	



Europe or Others	LC500h	GWZ100	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	LC500h	GWZ100	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	LC500h	GWZ100	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	LC500h	GWZ100	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	LC500h	GWZ100	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	LC500h	GWZ100	All years	Master Switch	✓	✓	✓			

Europe or Others	LC500h	GWZ100	All years	Tilt&Telescopic	√	√	√		1513, 1514	
Europe or Others	LC500h	GWZ100	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	LC500h	GWZ100	All years	Head Up Display	√	√	√		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
Europe or Others	LC500h	GWZ100	All years	Road Sign Assist	√	√	√	√	1183	
Europe or Others	LC500h	GWZ100	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
Europe or Others	LC500h	GWZ100	All years	Rain and/or Humidity Sensor	√	√	√			

Europe or Others	LC500h	GWZ100	All years	Wiper	✓	✓	✓	✓	0031, 0032	
Europe or Others	LC500h	GWZ100	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	LC500h	GWZ100	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
Europe or Others	LC500h	GWZ100	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	LC500h	GWZ100	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	
Europe or Others	LC500h	GWZ100	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	LC500h	GWZ100	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	LC500h	GWZ100	All years	Detection Of Occupant	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	Remote Engine Starter	✓	✓	✓	✓		

Europe or Others	LC500h	GWZ100	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LC500h	GWZ100	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LC500h	GWZ100	All years	Active Rear Wing	✓	✓	✓		1189, 1190, 1191, 1192, 1193	
Europe or Others	LC500h	GWZ100	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LC500h	GWZ100	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
Europe or Others	LC500h	GWZ100	All years	Active Noise Control	✓	✓	✓		1515, 1516, 1517, 1518, 1519	
Europe or Others	LC500h	GWZ100	All years	Pedestrian Protection	✓	✓	✓			SP0004
Europe or Others	LC500h	GWZ100	All years	Sub Battery Module	✓	✓	✓		0029, 0030	
Europe or Others	LC500h	GWZ100	All years	Power Integration No. 1	✓	✓	✓			
Europe or Others	LC500h	GWZ100	All years	Power Integration No. 2	✓	✓	✓			
Europe or Others	LC500h	GWZ100	All years	Power Integration No. 3	✓	✓	✓			
Europe or Others	LC500h	GWZ100	All years	Telematics	✓	✓	✓	✓	0036, 1521, 1522	
Europe or Others	LC500h	GWZ100	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	LC500h	GWZ100	All years	Vehicle proximity notification system	✓	✓	✓	✓	0044, 0045, 0046	
Europe or Others	LFA	LFA	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0027, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0043, SP0101

Europe or Others	LFA	LFA	All years	Engine2	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0096, 0 097, 0098, 00 99, 0100, 010 1, 0102, 0103 , 0104, 0105, 0106, 0107, 0 108, 0109, 01 10, 0111, 011 2, 0113, 0114 , 0115, 0116, 0117, 0118, 0 119, 0120, 01 21, 0122, 012 3, 0124, 0125 , 0126, 0127, 0128, 0129, 0 130, 0131, 01 32, 0133, 013 4, 0135, 0136 , 0137, 0138, 0139, 0140, 0 141, 0142, 01 43, 0144, 014 5, 0146, 0147 , 0148, 0149,	SP0004, SP0 141
Europe or Others	LFA	LFA	All years	ASG	✓	✓	✓	✓	1184, 1185, 1 186, 1187, 11 88	SP0135

Europe or Others	LFA	LFA	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	LFA	LFA	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	LFA	LFA	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	LFA	LFA	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004

Europe or Others	LFA	LFA	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	LFA	LFA	All years	Immobiliser	✓	✓	✓		0501	SP0065, SP0066
Europe or Others	LFA	LFA	All years	Theft Deterrent	✓	✓	✓		0329, 0333, 0494, 0495, 0496, 0497, 0498, 0499, 0500, 0501, 0502	
Europe or Others	LFA	LFA	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001



Europe or Others	LFA	LFA	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	LFA	LFA	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	LFA	LFA	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	LFA	LFA	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	LFA	LFA	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	LFA	LFA	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	

Europe or Others	LFA	LFA	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	LFA	LFA	All years	Electric Power Control	✓	✓	✓	✓	0342, 0343, 0344, 0345, 0346	
Europe or Others	LFA	LFA	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050
Europe or Others	LFA	LFA	All years	Active Rear Wing	✓	✓	✓		1189, 1190, 1191, 1192, 1193	SP0136

Europe or Others	LM300h	AYH3	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	
Europe or Others	LM300h	AYH3	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	
Europe or Others	LM300h	AYH3	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	LM300h	AYH3	All years	ABS/VSC/TPC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	LM300h	AYH3	All years	Tire Pressure Monitor	√	√	√			
Europe or Others	LM300h	AYH3	All years	EMPS	√	√	√	√		
Europe or Others	LM300h	AYH3	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	LM300h	AYH3	All years	Front Recognition Camera	√	√	√			
Europe or Others	LM300h	AYH3	All years	Lane Control	√	√	√		0824, 0989	
Europe or Others	LM300h	AYH3	All years	Panoramic view monitor	√	√	√	√		

Europe or Others	LM300h	AYH3	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	LM300h	AYH3	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		
Europe or Others	LM300h	AYH3	All years	Pre-Collision System	√	√	√		1524, 1525, 1526	

Europe or Others	LM300h	AYH3	All years	Main Body	√	√	√	√	0005, 0282, 0 300, 0301, 03 17, 0319, 033 3, 0335, 0337 , 0339, 0426, 0427, 0429, 0 433, 0434, 04 35, 0436, 049 0, 0496, 0497 , 0498, 0499, 0500, 0501, 0 502, 0783, 07 84, 0785, 078 6, 0787, 0788 , 0789, 0790, 0791, 0792, 0 793, 0794, 07 95, 0796, 079 7, 0798, 0799 , 0800, 0801, 0802, 0803, 0 804, 0805, 08 06, 0807, 080 8, 0809, 0810 , 0811, 0812, 0813, 0814, 0 815, 0816, 08 17, 0818	
Europe or Others	LM300h	AYH3	All years	Central Gateway	√	√	√	√		
Europe or Others	LM300h	AYH3	All years	Left Rear Door	√	√	√	√	0278, 0284, 0 317, 0428, 04 29, 0437, 050 3, 0504, 0505 , 0506, 0507, 0508, 0509, 0 510, 0511, 05 12	
Europe or Others	LM300h	AYH3	All years	Right Rear Door	√	√	√	√	0278, 0284, 0 317, 0428, 04 29, 0437, 050 3, 0504, 0505 , 0506, 0507, 0508, 0509, 0 510, 0511, 05 12	
Europe or Others	LM300h	AYH3	All years	Back Door	√	√	√	√	0520, 0521, 0 522, 0523, 05 24, 0525, 052 6	
Europe or Others	LM300h	AYH3	All years	Driver Door Motor	√	√	√		0528	

Europe or Others	LM300h	AYH3	All years	Passenger Door Motor	√	√	√		0528	
Europe or Others	LM300h	AYH3	All years	Left Rear Door Motor	√	√	√		0528	
Europe or Others	LM300h	AYH3	All years	Right Rear Door Motor	√	√	√		0528	
Europe or Others	LM300h	AYH3	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	LM300h	AYH3	All years	Left Rear Seat	√	√	√		0026, 0421, 0422, 0423, 0424, 0425	
Europe or Others	LM300h	AYH3	All years	Right Rear Seat	√	√	√		0026, 0421, 0422, 0423, 0424, 0425	
Europe or Others	LM300h	AYH3	All years	Master Switch	√	√	√			
Europe or Others	LM300h	AYH3	All years	Rear Console Switch	√	√	√		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
Europe or Others	LM300h	AYH3	All years	Sliding Roof	√	√	√		0529	

Europe or Others	LM300h	AYH3	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	LM300h	AYH3	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LM300h	AYH3	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LM300h	AYH3	All years	Clearance Warning	✓	✓	✓		0023, 0024	
Europe or Others	LM300h	AYH3	All years	Rain and/or Humidity Sensor	✓	✓	✓			



Europe or Others	LM300h	AYH3	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	LM300h	AYH3	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	LM300h	AYH3	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
Europe or Others	LM300h	AYH3	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	LM300h	AYH3	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	LM300h	AYH3	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	LM300h	AYH3	All years	Front Radar Sensor	✓	✓	✓			
Europe or Others	LM300h	AYH3	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LM300h	AYH3	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		

Europe or Others	LM300h	AYH3	All years	Vehicle proximity notification system	✓	✓	✓	✓	0044, 0045, 0046
Europe or Others	LM300h	AYH3	All years	ILLUMINATION	✓	✓	✓	✓	0053, 0054, 0055, 0056, 0057, 0058, 0059, 0060, 0061, 0062, 0063, 0064, 0065, 0066, 0067
Europe or Others	LM300h	AYH3	All years	Telematics	✓	✓	✓		1521, 1522
Europe or Others	LM350	GGH	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,

Europe or Others	LM350	GGH	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	
Europe or Others	LM350	GGH	All years	Stop and Start	✓	✓	✓		1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
Europe or Others	LM350	GGH	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	LM350	GGH	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	

Europe or Others	LM350	GGH	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	LM350	GGH	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	LM350	GGH	All years	EMPS	✓	✓	✓	✓		
Europe or Others	LM350	GGH	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	LM350	GGH	All years	Front Recognition Camera	✓	✓	✓			
Europe or Others	LM350	GGH	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	LM350	GGH	All years	Panoramic view monitor	✓	✓	✓	✓		

Europe or Others	LM350	GGH	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	LM350	GGH	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
Europe or Others	LM350	GGH	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	

Europe or Others	LM350	GGH	All years	Main Body	√	√	√	√	0005, 0282, 0 300, 0301, 03 17, 0319, 033 3, 0335, 0337 , 0339, 0426, 0427, 0429, 0 433, 0434, 04 35, 0436, 049 0, 0496, 0497 , 0498, 0499, 0500, 0501, 0 502, 0783, 07 84, 0785, 078 6, 0787, 0788 , 0789, 0790, 0791, 0792, 0 793, 0794, 07 95, 0796, 079 7, 0798, 0799 , 0800, 0801, 0802, 0803, 0 804, 0805, 08 06, 0807, 080 8, 0809, 0810 , 0811, 0812, 0813, 0814, 0 815, 0816, 08 17, 0818	
Europe or Others	LM350	GGH	All years	Central Gateway	√	√	√	√		
Europe or Others	LM350	GGH	All years	Left Rear Door	√	√	√	√	0278, 0284, 0 317, 0428, 04 29, 0437, 050 3, 0504, 0505 , 0506, 0507, 0508, 0509, 0 510, 0511, 05 12	
Europe or Others	LM350	GGH	All years	Right Rear Door	√	√	√	√	0278, 0284, 0 317, 0428, 04 29, 0437, 050 3, 0504, 0505 , 0506, 0507, 0508, 0509, 0 510, 0511, 05 12	
Europe or Others	LM350	GGH	All years	Back Door	√	√	√	√	0520, 0521, 0 522, 0523, 05 24, 0525, 052 6	
Europe or Others	LM350	GGH	All years	Driver Door Motor	√	√	√		0528	

Europe or Others	LM350	GGH	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	LM350	GGH	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	LM350	GGH	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	LM350	GGH	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	LM350	GGH	All years	Left Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
Europe or Others	LM350	GGH	All years	Right Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
Europe or Others	LM350	GGH	All years	Master Switch	✓	✓	✓			
Europe or Others	LM350	GGH	All years	Rear Console Switch	✓	✓	✓		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
Europe or Others	LM350	GGH	All years	Sliding Roof	✓	✓	✓		0529	

Europe or Others	LM350	GGH	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	LM350	GGH	All years	Road Sign Assist	✓	✓	✓			
Europe or Others	LM350	GGH	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LM350	GGH	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LM350	GGH	All years	Clearance Warning	✓	✓	✓		0023, 0024	
Europe or Others	LM350	GGH	All years	Rain and/or Humidity Sensor	✓	✓	✓			



Europe or Others	LM350	GGH	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	LM350	GGH	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	LM350	GGH	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
Europe or Others	LM350	GGH	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	LM350	GGH	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	LM350	GGH	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	LM350	GGH	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	LM350	GGH	All years	Front Radar Sensor	✓	✓	✓			
Europe or Others	LM350	GGH	All years	Master Blind Spot Monitor	✓	✓	✓	✓		

Europe or Others	LM350	GGH	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LM350	GGH	All years	ILLUMINATION	✓	✓	✓	✓	0053, 0054, 0055, 0056, 0057, 0058, 0059, 0060, 0061, 0062, 0063, 0064, 0065, 0066, 0067	
Europe or Others	LM350	GGH31	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	

Europe or Others	LM350	GGH31	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	LM350	GGH31	All years	Stop and Start	✓	✓	✓		1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
Europe or Others	LM350	GGH31	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	LM350	GGH31	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	

Europe or Others	LM350	GGH31	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	LM350	GGH31	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	LM350	GGH31	All years	EMPS	✓	✓	✓	✓		
Europe or Others	LM350	GGH31	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	LM350	GGH31	All years	Front Recognition Camera	✓	✓	✓			
Europe or Others	LM350	GGH31	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	LM350	GGH31	All years	Panoramic view monitor	✓	✓	✓	✓		

Europe or Others	LM350	GGH31	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	LM350	GGH31	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
Europe or Others	LM350	GGH31	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	

Europe or Others	LM350	GGH31	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0 300, 0301, 03 17, 0319, 033 3, 0335, 0337 , 0339, 0426, 0427, 0429, 0 433, 0434, 04 35, 0436, 049 0, 0496, 0497 , 0498, 0499, 0500, 0501, 0 502, 0783, 07 84, 0785, 078 6, 0787, 0788 , 0789, 0790, 0791, 0792, 0 793, 0794, 07 95, 0796, 079 7, 0798, 0799 , 0800, 0801, 0802, 0803, 0 804, 0805, 08 06, 0807, 080 8, 0809, 0810 , 0811, 0812, 0813, 0814, 0 815, 0816, 08 17, 0818	
Europe or Others	LM350	GGH31	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	LM350	GGH31	All years	Left Rear Door	✓	✓	✓	✓	0278, 0284, 0 317, 0428, 04 29, 0437, 050 3, 0504, 0505 , 0506, 0507, 0508, 0509, 0 510, 0511, 05 12	
Europe or Others	LM350	GGH31	All years	Right Rear Door	✓	✓	✓	✓	0278, 0284, 0 317, 0428, 04 29, 0437, 050 3, 0504, 0505 , 0506, 0507, 0508, 0509, 0 510, 0511, 05 12	
Europe or Others	LM350	GGH31	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0 522, 0523, 05 24, 0525, 052 6	
Europe or Others	LM350	GGH31	All years	Driver Door Motor	✓	✓	✓		0528	

Europe or Others	LM350	GGH31	All years	Passenger Door Motor	√	√	√		0528	
Europe or Others	LM350	GGH31	All years	Left Rear Door Motor	√	√	√		0528	
Europe or Others	LM350	GGH31	All years	Right Rear Door Motor	√	√	√		0528	
Europe or Others	LM350	GGH31	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	LM350	GGH31	All years	Left Rear Seat	√	√	√		0026, 0421, 0422, 0423, 0424, 0425	
Europe or Others	LM350	GGH31	All years	Right Rear Seat	√	√	√		0026, 0421, 0422, 0423, 0424, 0425	
Europe or Others	LM350	GGH31	All years	Master Switch	√	√	√			
Europe or Others	LM350	GGH31	All years	Rear Console Switch	√	√	√		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
Europe or Others	LM350	GGH31	All years	Sliding Roof	√	√	√		0529	

Europe or Others	LM350	GGH31	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	LM350	GGH31	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LM350	GGH31	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LM350	GGH31	All years	Clearance Warning	✓	✓	✓		0023, 0024	
Europe or Others	LM350	GGH31	All years	Rain and/or Humidity Sensor	✓	✓	✓			



Europe or Others	LM350	GGH31	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	LM350	GGH31	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	LM350	GGH31	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
Europe or Others	LM350	GGH31	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	LM350	GGH31	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	LM350	GGH31	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	LM350	GGH31	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	LM350	GGH31	All years	Front Radar Sensor	✓	✓	✓			
Europe or Others	LM350	GGH31	All years	Master Blind Spot Monitor	✓	✓	✓	✓		

Europe or Others	LM350	GGH31	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LM350	GGH31	All years	ILLUMINATION	✓	✓	✓	✓	0053, 0054, 0055, 0056, 0057, 0058, 0059, 0060, 0061, 0062, 0063, 0064, 0065, 0066, 0067	
Europe or Others	LS350	GSF50	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	

Europe or Others	LS350	GSF50	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	LS350	GSF50	All years	Stop and Start	✓	✓	✓		1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
Europe or Others	LS350	GSF50	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	LS350	GSF50	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018, 1504, 1505	
Europe or Others	LS350	GSF50	All years	Air suspension	✓	✓	✓			SP0007, SP0130, SP0131, SP0132, SP0133

Europe or Others	LS350	GSF50	All years	Adaptive Variable Suspension (AVS) System	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
Europe or Others	LS350	GSF50	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	LS350	GSF50	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	LS350	GSF50	All years	EMPS	✓	✓	✓	✓		
Europe or Others	LS350	GSF50	All years	VGRS	✓	✓	✓	✓		

Europe or Others	LS350	GSF50	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	LS350	GSF50	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	LS350	GSF50	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	LS350	GSF50	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	LS350	GSF50	All years	Panoramic view monitor	✓	✓	✓	✓		
Europe or Others	LS350	GSF50	All years	DRS	✓	✓	✓	✓		
Europe or Others	LS350	GSF50	All years	Steering Angle Sensor	✓	✓	✓			
Europe or Others	LS350	GSF50	All years	Parking Assist Camera	✓	✓	✓	✓		

Europe or Others	LS350	GSF50	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615
Europe or Others	LS350	GSF50	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓	
Europe or Others	LS350	GSF50	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298

Europe or Others	LS350	GSF50	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0 300, 0301, 03 17, 0319, 033 3, 0335, 0337 , 0339, 0426, 0427, 0429, 0 433, 0434, 04 35, 0436, 049 0, 0496, 0497 , 0498, 0499, 0500, 0501, 0 502, 0783, 07 84, 0785, 078 6, 0787, 0788 , 0789, 0790, 0791, 0792, 0 793, 0794, 07 95, 0796, 079 7, 0798, 0799 , 0800, 0801, 0802, 0803, 0 804, 0805, 08 06, 0807, 080 8, 0809, 0810 , 0811, 0812, 0813, 0814, 0 815, 0816, 08 17, 0818	
Europe or Others	LS350	GSF50	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	LS350	GSF50	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	LS350	GSF50	All years	Left Rear Door	✓	✓	✓	✓	0278, 0284, 0 317, 0428, 04 29, 0437, 050 3, 0504, 0505 , 0506, 0507, 0508, 0509, 0 510, 0511, 05 12	
Europe or Others	LS350	GSF50	All years	Right Rear Door	✓	✓	✓	✓	0278, 0284, 0 317, 0428, 04 29, 0437, 050 3, 0504, 0505 , 0506, 0507, 0508, 0509, 0 510, 0511, 05 12	
Europe or Others	LS350	GSF50	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0 522, 0523, 05 24, 0525, 052 6	

Europe or Others	LS350	GSF50	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	LS350	GSF50	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	LS350	GSF50	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	LS350	GSF50	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	LS350	GSF50	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	LS350	GSF50	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	LS350	GSF50	All years	Left Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
Europe or Others	LS350	GSF50	All years	Right Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
Europe or Others	LS350	GSF50	All years	Master Switch	✓	✓	✓			
Europe or Others	LS350	GSF50	All years	Rear Console Switch	✓	✓	✓		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
Europe or Others	LS350	GSF50	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	LS350	GSF50	All years	Tilt&Telescopic	✓	✓	✓		1513, 1514	



Europe or Others	LS350	GSF50	All years	Combination Meter	√	√	√		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
Europe or Others	LS350	GSF50	All years	Head Up Display	√	√	√		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
Europe or Others	LS350	GSF50	All years	Road Sign Assist	√	√	√	√	1183	
Europe or Others	LS350	GSF50	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
Europe or Others	LS350	GSF50	All years	Rain and/or Humidity Sensor	√	√	√			
Europe or Others	LS350	GSF50	All years	Wiper	√	√	√	√	0031, 0032	

Europe or Others	LS350	GSF50	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	LS350	GSF50	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
Europe or Others	LS350	GSF50	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0014
Europe or Others	LS350	GSF50	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	LS350	GSF50	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	LS350	GSF50	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	LS350	GSF50	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	LS350	GSF50	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LS350	GSF50	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

Europe or Others	LS350	GSF50	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LS350	GSF50	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LS350	GSF50	All years	Active Noise Control	✓	✓	✓		1515, 1516, 1517, 1518, 1519	
Europe or Others	LS350	GSF50	All years	Pedestrian Protection	✓	✓	✓			
Europe or Others	LS350	GSF50	All years	Sub Battery Module	✓	✓	✓		0029, 0030	
Europe or Others	LS350	GSF50	All years	Power Integration No. 1	✓	✓	✓			
Europe or Others	LS350	GSF50	All years	Power Integration No. 2	✓	✓	✓			
Europe or Others	LS350	GSF50	All years	Power Integration No. 3	✓	✓	✓			
Europe or Others	LS350	GSF50	All years	Telematics	✓	✓	✓	✓	0036	
Europe or Others	LS350	GSF50	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	LS350	GSF50	All years	Air suspension 2	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
Europe or Others	LS350	GSF50	All years	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	

Europe or Others	LS350	GSF50	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	LS350	GSF50	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	
Europe or Others	LS350	GSF50	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	LS350	GSF50	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	
Europe or Others	LS350	GSF50	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
Europe or Others	LS350	GSF50	All years	Front Radar Sensor	✓	✓	✓			
Europe or Others	LS400	UCF	All years	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180	SP0003, SP0004
Europe or Others	LS400	UCF	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	LS400	UCF	All years	ABS/VSC/TRC	√	√	√	√	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021
Europe or Others	LS400	UCF	All years	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
Europe or Others	LS400	UCF	All years	Immobiliser	√	√	√			SP0011, SP0013, SP0148
Europe or Others	LS400	UCF	All years	Supplement Restraint System (SRS) Airbag	√	√				SP0004

Europe or Others	LS400	UCF	All years	Body	√	√	√	0031, 0032, 0319, 0333, 0337, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0922, 0923, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020
Europe or Others	LS400	UCF	All years	Driver Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	LS400	UCF	All years	Passenger Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	LS400	UCF	All years	Left Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	LS400	UCF	All years	Right Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	LS400	UCF	All years	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	LS400	UCF	All years	Sliding Roof			√	0529	
Europe or Others	LS400	UCF	All years	Tilt&Telescopic	√	√	√	0472, 0473, 1005	

Europe or Others	LS400	UCF	All years	Combinati on Meter			√	0274, 0616, 0 617, 0618, 06 19, 0629, 066 2, 0665, 0669 , 0670, 0671, 0672, 0673, 0 675, 0676, 06 77, 0678, 067 9, 0680, 0681 , 0692, 0719, 0745, 0746, 0 749, 0756, 07 60, 0761, 076 2, 0763, 0764 , 0765, 0766, 0767, 0768, 0 769, 0770, 07 71, 0772, 077 3, 0774, 0775 , 0776, 0777, 0778, 0779, 0 780, 0781, 07 82, 1000, 102 9, 1030, 1031 , 1032, 1033, 1034, 1035, 1 036, 1037, 10 38, 1039, 104 0, 1041, 1042 , 1043, 1044,	
------------------------	-------	-----	--------------	-----------------------	--	--	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

Europe or Others	LS430	UCF	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0090, 0 091, 0092, 00 93, 0094, 009 5, 0096, 0097 , 0098, 0099, 0100, 0101, 0 102, 0103, 01 04, 0105, 010 6, 0107, 0108 , 0109, 0110, 0111, 0112, 0 113, 0114, 01 15, 0116, 011 7, 0118, 0119 , 0120, 0121, 0122, 0123, 0 124, 0125, 01 26, 0127, 012 8, 0129, 0130 , 0131, 0132, 0133, 0134, 0 135, 0136, 01 37, 0138, 013 9, 0140, 0141 , 0142, 0143,	SP0004, SP0 026, SP0027 , SP0028, SP 0029, SP003 0, SP0031, S P0032, SP00 33, SP0101
------------------------	-------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------



Europe or Others	LS430	UCF	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	LS430	UCF	All years	Laser Cruise	✓	✓	✓	✓		
Europe or Others	LS430	UCF	All years	Air suspension	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001

Europe or Others	LS430	UCF	All years	ABS/VSC/TRC	✓	✓	✓	✓	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021, SP0023
Europe or Others	LS430	UCF	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
Europe or Others	LS430	UCF	All years	Steering Lock	✓	✓	✓		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0014, SP0065, SP0066, SP0145, SP0146

Europe or Others	LS430	UCF	All years	Theft Deterrent	✓	✓	✓	0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	SP0011, SP0013, SP0018, SP0019, SP0020, SP0145, SP0146, SP0147
Europe or Others	LS430	UCF	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓		SP0001, SP0004
Europe or Others	LS430	UCF	All years	Gateway	✓	✓			
Europe or Others	LS430	UCF	All years	Body No. 2	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	

Europe or Others	LS430	UCF	All years	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967
Europe or Others	LS430	UCF	All years	Body No. 4	✓		✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

Europe or Others	LS430	UCF	All years	Body No. 5			√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	LS430	UCF	All years	Driver Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	LS430	UCF	All years	Passenger Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	LS430	UCF	All years	Left Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	LS430	UCF	All years	Right Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	LS430	UCF	All years	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	

Europe or Others	LS430	UCF	All years	Left Rear Seat			√		0422, 0424, 0981, 0982	
Europe or Others	LS430	UCF	All years	Right Rear Seat			√		0422, 0424, 0981, 0982	
Europe or Others	LS430	UCF	All years	Rear Seat Switch			√			
Europe or Others	LS430	UCF	All years	Sliding Roof			√		0529	
Europe or Others	LS430	UCF	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
Europe or Others	LS430	UCF	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	LS430	UCF	All years	Combination Switch			√			
Europe or Others	LS430	UCF	All years	Switch Of Steering Pad			√			
Europe or Others	LS430	UCF	All years	Clearance Sonar	√	√	√		0023, 0024	

Europe or Others	LS430	UCF	All years	Rain Sensor			✓			
Europe or Others	LS430	UCF	All years	AFS	✓	✓	✓		0008, 0475, 0476, 0477, 0968	
Europe or Others	LS430	UCF	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	LS430	UCF	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
Europe or Others	LS430	UCF	All years	Pre-Crash	✓	✓	✓		0348, 0349, 0350	
Europe or Others	LS430	UCF	All years	Immobiliser	✓	✓	✓		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066, SP0145, SP0146
Europe or Others	LS430	UCF	All years	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180	SP0003, SP0004

Europe or Others	LS460	USF	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0090, 0 091, 0092, 00 93, 0094, 009 5, 0096, 0097 , 0098, 0099, 0100, 0101, 0 102, 0103, 01 04, 0105, 010 6, 0107, 0108 , 0109, 0110, 0111, 0112, 0 113, 0114, 01 15, 0116, 011 7, 0118, 0119 , 0120, 0121, 0122, 0123, 0 124, 0125, 01 26, 0127, 012 8, 0129, 0130 , 0131, 0132, 0133, 0134, 0 135, 0136, 01 37, 0138, 013 9, 0140, 0141 , 0142, 0143,	SP0004, SP0 026, SP0027 , SP0028, SP 0029, SP003 0, SP0031, S P0032, SP00 33, SP0073, SP0074, SP0 075, SP0076 , SP0101
------------------------	-------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------



Europe or Others	LS460	USF	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	LS460	USF	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	LS460	USF	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

Europe or Others	LS460	USF	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	LS460	USF	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	LS460	USF	All years	EMPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
Europe or Others	LS460	USF	All years	Rain and/or Humidity Sensor	✓	✓	✓			
Europe or Others	LS460	USF	All years	VGRS	✓	✓	✓	✓		SP0001, SP0009, SP0037
Europe or Others	LS460	USF	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004

Europe or Others	LS460	USF	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	LS460	USF	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	LS460	USF	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	LS460	USF	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	LS460	USF	All years	Engine Control Module (ECM) Gateway	✓	✓	✓	✓		SP0005
Europe or Others	LS460	USF	All years	Electronic Controlled Braking (ECB) Gateway	✓	✓	✓	✓		SP0005
Europe or Others	LS460	USF	All years	Whiplash Injury Lessening (WIL) Gateway	✓	✓	✓	✓		SP0005
Europe or Others	LS460	USF	All years	Body No. 4	✓	✓	✓		0310, 0311, 0312, 0313, 0314, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0327, 0328, 0329	

Europe or Others	LS460	USF	All years	Body No. 5	✓	✓	✓		0031, 0032, 0330, 0331, 0332, 0333, 0334, 0335, 0336, 0337, 0338, 0339, 0340, 0341	
Europe or Others	LS460	USF	All years	Driver Door	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0433, 0434, 0435, 0436, 0437	
Europe or Others	LS460	USF	All years	Passenger Door	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0430, 0431	
Europe or Others	LS460	USF	All years	Left Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
Europe or Others	LS460	USF	All years	Right Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
Europe or Others	LS460	USF	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	LS460	USF	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LS460	USF	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LS460	USF	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LS460	USF	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003

Europe or Others	LS460	USF	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
Europe or Others	LS460	USF	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	LS460	USF	All years	Left Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425
Europe or Others	LS460	USF	All years	Right Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425
Europe or Others	LS460	USF	All years	Master Switch	✓	✓	✓		
Europe or Others	LS460	USF	All years	Driver Seat Switch	✓	✓	✓	✓	0355, 0398, 0399, 0400, 0401, 0402, 0403, 0404, 0405, 0406, 0407, 0408, 0409, 0410, 0411, 0412, 0413, 0414, 0415, 0416, 0417, 0418, 0419, 0420
Europe or Others	LS460	USF	All years	Switch Of Center Console			✓		0355, 0356, 0357
Europe or Others	LS460	USF	All years	Rear Console Switch	✓	✓	✓		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375
Europe or Others	LS460	USF	All years	Left Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354
Europe or Others	LS460	USF	All years	Right Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354
Europe or Others	LS460	USF	All years	Left Rear Seat Air Conditioner (A/C)	✓	✓	✓		0351, 0352, 0353, 0354

Europe or Others	LS460	USF	All years	Right Rear Seat Air Conditioner (A/C)	✓	✓	✓		0351, 0352, 0353, 0354	
Europe or Others	LS460	USF	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	LS460	USF	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	LS460	USF	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	LS460	USF	All years	Combination Switch			✓			
Europe or Others	LS460	USF	All years	Switch Of Steering Pad			✓			
Europe or Others	LS460	USF	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	LS460	USF	All years	Rain Sensor	✓	✓	✓			
Europe or Others	LS460	USF	All years	AFS	✓	✓	✓	✓	0007, SP0008	

Europe or Others	LS460	USF	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015
Europe or Others	LS460	USF	All years	Electric Power Control	✓	✓	✓	✓	0342, 0343, 0344, 0345, 0346	
Europe or Others	LS460	USF	All years	Active Headrest Right	✓	✓	✓		0306, 0307, 0308, 0309	
Europe or Others	LS460	USF	All years	Active Headrest Left	✓	✓	✓		0306, 0307, 0308, 0309	
Europe or Others	LS460	USF	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079, SP0154, SP0155
Europe or Others	LS460	USF	All years	Telematics	✓	✓	✓	✓		SP0059, SP0060
Europe or Others	LS460	USF	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	SP0061, SP0069, SP0134
Europe or Others	LS460	USF	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038, SP0039
Europe or Others	LS460	USF	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	LS460	USF	All years	Pre-Crash 2	✓	✓	✓	✓	0022	SP0005, SP0038, SP0039, SP0040, SP0041, SP0153
Europe or Others	LS460	USF	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	LS460	USF	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	LS460	USF	All years	Gateway	✓	✓		✓		SP0005



Europe or Others	LS460	USF	All years	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274	SP0067, SP0068
Europe or Others	LS460	USF	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	LS460	USF	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0137
Europe or Others	LS460	USF	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	
Europe or Others	LS500	VXFA5 #	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	

Europe or Others	LS500	VXFA5 #	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	LS500	VXFA5 #	All years	Stop and Start	✓	✓	✓		1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
Europe or Others	LS500	VXFA5 #	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018, 1504, 1505	
Europe or Others	LS500	VXFA5 #	All years	Air suspension	✓	✓	✓			

Europe or Others	LS500	VXFA5 #	All years	Adaptive Variable Suspension (AVS) System	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
Europe or Others	LS500	VXFA5 #	All years	Front Stabilizer	√	√	√		0527	
Europe or Others	LS500	VXFA5 #	All years	Rear Stabilizer	√	√	√		0527	
Europe or Others	LS500	VXFA5 #	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	LS500	VXFA5 #	All years	Tire Pressure Monitor	√	√	√			

Europe or Others	LS500	VXFA5 #	All years	EMPS	✓	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	VGRS	✓	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	LS500	VXFA5 #	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0087, SP0126
Europe or Others	LS500	VXFA5 #	All years	Lane Control	✓	✓	✓	✓	0824, 0989	
Europe or Others	LS500	VXFA5 #	All years	Panoramic view monitor	✓	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	DRS	✓	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	Steering Angle Sensor	✓	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	Parking Assist Camera	✓	✓	✓	✓		

Europe or Others	LS500	VXFA5 #	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	LS500	VXFA5 #	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	Driving Support System	✓	✓	✓			
Europe or Others	LS500	VXFA5 #	All years	Seat Belt Control	✓	✓	✓			
Europe or Others	LS500	VXFA5 #	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	

Europe or Others	LS500	VXFA5 #	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	LS500	VXFA5 #	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	Left Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
Europe or Others	LS500	VXFA5 #	All years	Right Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
Europe or Others	LS500	VXFA5 #	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	

Europe or Others	LS500	VXFA5 #	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	LS500	VXFA5 #	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	LS500	VXFA5 #	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	LS500	VXFA5 #	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	LS500	VXFA5 #	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	LS500	VXFA5 #	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	LS500	VXFA5 #	All years	Left Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
Europe or Others	LS500	VXFA5 #	All years	Right Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
Europe or Others	LS500	VXFA5 #	All years	Master Switch	✓	✓	✓			
Europe or Others	LS500	VXFA5 #	All years	Rear Console Switch	✓	✓	✓		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
Europe or Others	LS500	VXFA5 #	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	LS500	VXFA5 #	All years	Sliding Sunshade - Rear	✓	✓	✓		0027	
Europe or Others	LS500	VXFA5 #	All years	Tilt&Telescopic	✓	✓	✓		1513, 1514	

Europe or Others	LS500	VXFA5 #	All years	Combination Meter	✓	✓	✓	0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
Europe or Others	LS500	VXFA5 #	All years	Head Up Display	✓	✓	✓	0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
Europe or Others	LS500	VXFA5 #	All years	Road Sign Assist	✓	✓	✓	1183	
Europe or Others	LS500	VXFA5 #	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	✓	✓	✓	0023, 0024, 0025, 0026	
Europe or Others	LS500	VXFA5 #	All years	Rain and/or Humidity Sensor	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	Wiper	✓	✓	✓	0031, 0032	



Europe or Others	LS500	VXFA5 #	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
Europe or Others	LS500	VXFA5 #	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028
Europe or Others	LS500	VXFA5 #	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553
Europe or Others	LS500	VXFA5 #	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305
Europe or Others	LS500	VXFA5 #	All years	Detection Of Occupant	✓	✓	✓	✓	
Europe or Others	LS500	VXFA5 #	All years	Remote Engine Starter	✓	✓	✓	✓	
Europe or Others	LS500	VXFA5 #	All years	Starting Control	✓	✓	✓	✓	0256, 0257
Europe or Others	LS500	VXFA5 #	All years	Navigation System	✓	✓	✓	✓	

Europe or Others	LS500	VXFA5 #	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LS500	VXFA5 #	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LS500	VXFA5 #	All years	Front Radar Sensor	✓	✓	✓			SP0127, SP0128, SP0129
Europe or Others	LS500	VXFA5 #	All years	Front Side Radar Master	✓	✓	✓			SP0120, SP0121, SP0122
Europe or Others	LS500	VXFA5 #	All years	Front Side Radar Slave	✓	✓	✓			SP0123, SP0124, SP0125
Europe or Others	LS500	VXFA5 #	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	Active Noise Control	✓	✓	✓		1515, 1516, 1517, 1518, 1519	
Europe or Others	LS500	VXFA5 #	All years	Pedestrian Protection	✓	✓	✓			
Europe or Others	LS500	VXFA5 #	All years	Sub Battery Module	✓	✓	✓		0029, 0030	
Europe or Others	LS500	VXFA5 #	All years	Power Integration No. 1	✓	✓	✓			
Europe or Others	LS500	VXFA5 #	All years	Power Integration No. 2	✓	✓	✓			
Europe or Others	LS500	VXFA5 #	All years	Power Integration No. 3	✓	✓	✓			
Europe or Others	LS500	VXFA5 #	All years	Telematics	✓	✓	✓	✓	0036	

Europe or Others	LS500	VXFA5 #	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	LS500	VXFA5 #	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	
Europe or Others	LS500	VXFA5 #	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	LS500	VXFA5 #	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	LS500	VXFA5 #	All years	Pre-Collision 2	✓	✓	✓	✓	0022	
Europe or Others	LS500	VXFA5 #	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	LS500	VXFA5 #	All years	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	

Europe or Others	LS500h	GVF5#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	
Europe or Others	LS500h	GVF5#	All years	Hybrid Control	✓	✓	✓		0070, 0071, 0079, 0081, 0180, 0194, 0195, 1207, 1208, 1493, 1494, 1495, 1496, 1497	
Europe or Others	LS500h	GVF5#	All years	Motor Generator	✓	✓	✓	✓		
Europe or Others	LS500h	GVF5#	All years	High Voltage (HV) Battery	✓	✓	✓	✓		
Europe or Others	LS500h	GVF5#	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	LS500h	GVF5#	All years	Radar Cruise 2	✓	✓	✓	✓	1504, 1505	
Europe or Others	LS500h	GVF5#	All years	Air suspension	✓	✓	✓			

Europe or Others	LS500h	GVF5#	All years	Adaptive Variable Suspension (AVS) System	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
Europe or Others	LS500h	GVF5#	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	LS500h	GVF5#	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	LS500h	GVF5#	All years	EMPS	✓	✓	✓	✓		
Europe or Others	LS500h	GVF5#	All years	VGRS	✓	✓	✓	✓		

Europe or Others	LS500h	GVF5#	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	LS500h	GVF5#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	LS500h	GVF5#	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	LS500h	GVF5#	All years	Panoramic view monitor	✓	✓	✓	✓		
Europe or Others	LS500h	GVF5#	All years	DRS	✓	✓	✓	✓		
Europe or Others	LS500h	GVF5#	All years	Steering Angle Sensor	✓	✓	✓			
Europe or Others	LS500h	GVF5#	All years	Parking Assist Camera	✓	✓	✓	✓		
Europe or Others	LS500h	GVF5#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	

Europe or Others	LS500h	GVF5#	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
Europe or Others	LS500h	GVF5#	All years	Driving Support System	✓	✓	✓			
Europe or Others	LS500h	GVF5#	All years	Seat Belt Control	✓	✓	✓			
Europe or Others	LS500h	GVF5#	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	
Europe or Others	LS500h	GVF5#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	LS500h	GVF5#	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	LS500h	GVF5#	All years	Central Gateway	✓	✓	✓	✓		

Europe or Others	LS500h	GVF5#	All years	Left Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512
Europe or Others	LS500h	GVF5#	All years	Right Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512
Europe or Others	LS500h	GVF5#	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526
Europe or Others	LS500h	GVF5#	All years	Driver Door Motor	✓	✓	✓		0528
Europe or Others	LS500h	GVF5#	All years	Passenger Door Motor	✓	✓	✓		0528
Europe or Others	LS500h	GVF5#	All years	Left Rear Door Motor	✓	✓	✓		0528
Europe or Others	LS500h	GVF5#	All years	Right Rear Door Motor	✓	✓	✓		0528
Europe or Others	LS500h	GVF5#	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
Europe or Others	LS500h	GVF5#	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	LS500h	GVF5#	All years	Left Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425
Europe or Others	LS500h	GVF5#	All years	Right Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425
Europe or Others	LS500h	GVF5#	All years	Master Switch	✓	✓	✓		



Europe or Others	LS500h	GVF5#	All years	Rear Console Switch	√	√	√		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
Europe or Others	LS500h	GVF5#	All years	Sliding Roof	√	√	√		0529	
Europe or Others	LS500h	GVF5#	All years	Tilt&Telescopic	√	√	√		1513, 1514	
Europe or Others	LS500h	GVF5#	All years	Combination Meter	√	√	√		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
Europe or Others	LS500h	GVF5#	All years	Head Up Display	√	√	√		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
Europe or Others	LS500h	GVF5#	All years	Road Sign Assist	√	√	√	√	1183	

Europe or Others	LS500h	GVF5#	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
Europe or Others	LS500h	GVF5#	All years	Rain and/or Humidity Sensor	√	√	√			
Europe or Others	LS500h	GVF5#	All years	Wiper	√	√	√	√	0031, 0032	
Europe or Others	LS500h	GVF5#	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	LS500h	GVF5#	All years	Adaptive Front Lighting System (AFS) (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	
Europe or Others	LS500h	GVF5#	All years	Front Recognition Camera (Front Lighting Control)	√	√	√			
Europe or Others	LS500h	GVF5#	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	

Europe or Others	LS500h	GVF5#	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	LS500h	GVF5#	All years	Detection Of Occupant	√	√	√	√		
Europe or Others	LS500h	GVF5#	All years	Remote Engine Starter	√	√	√	√		
Europe or Others	LS500h	GVF5#	All years	Navigation System	√	√	√	√		
Europe or Others	LS500h	GVF5#	All years	Right Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LS500h	GVF5#	All years	Left Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LS500h	GVF5#	All years	Front Radar Sensor	√	√	√			
Europe or Others	LS500h	GVF5#	All years	Front Side Radar Master	√	√	√			
Europe or Others	LS500h	GVF5#	All years	Front Side Radar Slave	√	√	√			
Europe or Others	LS500h	GVF5#	All years	Master Blind Spot Monitor	√	√	√	√		
Europe or Others	LS500h	GVF5#	All years	Slave Blind Spot Monitor	√	√	√	√		
Europe or Others	LS500h	GVF5#	All years	Grill Shutter	√	√	√		0037, 0038, 0039, 0040	
Europe or Others	LS500h	GVF5#	All years	Vehicle proximity notification system	√	√	√	√	0044, 0045, 0046	
Europe or Others	LS500h	GVF5#	All years	Active Noise Control	√	√	√		1515, 1516, 1517, 1518, 1519	

Europe or Others	LS500h	GVF5#	All years	Pedestrian Protection	√	√	√			
Europe or Others	LS500h	GVF5#	All years	Sub Battery Module	√	√	√		0029, 0030	
Europe or Others	LS500h	GVF5#	All years	Power Integration No.1	√	√	√			
Europe or Others	LS500h	GVF5#	All years	Power Integration No.2	√	√	√			
Europe or Others	LS500h	GVF5#	All years	Power Integration No.3	√	√	√			
Europe or Others	LS500h	GVF5#	All years	Telematics	√	√	√	√	0036	
Europe or Others	LS500h	GVF5#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
Europe or Others	LS500h	GVF5#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			√			
Europe or Others	LS500h	GVF5#	All years	Pre-Collision 2	√	√	√	√	0022	
Europe or Others	LS500h	GVF5#	All years	Cruise Control	√	√	√	√		
Europe or Others	LS500h	GVF5#	All years	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	LS500h	GVF5#	All years	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0006	

Europe or Others	LS600h	UVF	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	LS600h	UVF	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026
Europe or Others	LS600h	UVF	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	LS600h	UVF	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

Europe or Others	LS600h	UVF	All years	Front Stabilizer	✓	✓	✓		0527	SP0151, SP0152
Europe or Others	LS600h	UVF	All years	Rear Stabilizer	✓	✓	✓		0527	SP0151, SP0152
Europe or Others	LS600h	UVF	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023
Europe or Others	LS600h	UVF	All years	Rain and/or Humidity Sensor	✓	✓	✓			
Europe or Others	LS600h	UVF	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	LS600h	UVF	All years	EMPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
Europe or Others	LS600h	UVF	All years	VGRS	✓	✓	✓	✓		SP0001, SP0009, SP0037

Europe or Others	LS600h	UVF	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
Europe or Others	LS600h	UVF	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	LS600h	UVF	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	LS600h	UVF	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001

Europe or Others	LS600h	UVF	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	LS600h	UVF	All years	Engine Control Module (ECM) Gateway	✓	✓	✓	✓		SP0005
Europe or Others	LS600h	UVF	All years	Electronic Controlled Braking (ECB) Gateway	✓	✓	✓	✓		SP0005
Europe or Others	LS600h	UVF	All years	Whiplash Injury Lessening (WIL) Gateway	✓	✓	✓	✓		SP0005
Europe or Others	LS600h	UVF	All years	Body No. 4	✓	✓	✓		0310, 0311, 0312, 0313, 0314, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0327, 0328, 0329	



Europe or Others	LS600h	UVF	All years	Body No. 5	✓	✓	✓		0031, 0032, 0 330, 0331, 03 32, 0333, 033 4, 0335, 0336 , 0337, 0338, 0339, 0340, 0 341	
Europe or Others	LS600h	UVF	All years	Driver Door	✓	✓	✓		0278, 0280, 0 281, 0282, 02 83, 0317, 042 6, 0427, 0428 , 0429, 0433, 0434, 0435, 0 436, 0437	
Europe or Others	LS600h	UVF	All years	Passenger Door	✓	✓	✓		0278, 0280, 0 281, 0282, 02 83, 0317, 042 6, 0427, 0428 , 0429, 0430, 0431	
Europe or Others	LS600h	UVF	All years	Left Rear Door	✓	✓	✓	✓	0278, 0284, 0 317, 0428, 04 29, 0437, 050 3, 0504, 0505 , 0506, 0507, 0508, 0509, 0 510, 0511, 05 12	
Europe or Others	LS600h	UVF	All years	Right Rear Door	✓	✓	✓	✓	0278, 0284, 0 317, 0428, 04 29, 0437, 050 3, 0504, 0505 , 0506, 0507, 0508, 0509, 0 510, 0511, 05 12	
Europe or Others	LS600h	UVF	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0 522, 0523, 05 24, 0525, 052 6	
Europe or Others	LS600h	UVF	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LS600h	UVF	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LS600h	UVF	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LS600h	UVF	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003

Europe or Others	LS600h	UVF	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
Europe or Others	LS600h	UVF	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	LS600h	UVF	All years	Left Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425
Europe or Others	LS600h	UVF	All years	Right Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425
Europe or Others	LS600h	UVF	All years	Master Switch	✓	✓	✓		
Europe or Others	LS600h	UVF	All years	Driver Seat Switch	✓	✓	✓	✓	0355, 0398, 0399, 0400, 0401, 0402, 0403, 0404, 0405, 0406, 0407, 0408, 0409, 0410, 0411, 0412, 0413, 0414, 0415, 0416, 0417, 0418, 0419, 0420
Europe or Others	LS600h	UVF	All years	Switch Of Center Console			✓		0355, 0356, 0357
Europe or Others	LS600h	UVF	All years	Rear Console Switch	✓	✓	✓		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375
Europe or Others	LS600h	UVF	All years	Left Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354
Europe or Others	LS600h	UVF	All years	Right Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354
Europe or Others	LS600h	UVF	All years	Left Rear Seat Air Conditioner (A/C)	✓	✓	✓		0351, 0352, 0353, 0354

Europe or Others	LS600h	UVF	All years	Right Rear Seat Air Conditioner (A/C)	✓	✓	✓		0351, 0352, 0353, 0354	
Europe or Others	LS600h	UVF	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	LS600h	UVF	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	LS600h	UVF	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	LS600h	UVF	All years	Combination Switch			✓			
Europe or Others	LS600h	UVF	All years	Switch Of Steering Pad			✓			
Europe or Others	LS600h	UVF	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	LS600h	UVF	All years	Rain Sensor	✓	✓	✓			
Europe or Others	LS600h	UVF	All years	AFS	✓	✓	✓	✓	0007, SP0008	

Europe or Others	LS600h	UVF	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015
Europe or Others	LS600h	UVF	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	LS600h	UVF	All years	Active Headrest Right	✓	✓	✓		0306, 0307, 0308, 0309	
Europe or Others	LS600h	UVF	All years	Active Headrest Left	✓	✓	✓		0306, 0307, 0308, 0309	
Europe or Others	LS600h	UVF	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
Europe or Others	LS600h	UVF	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038, SP0039
Europe or Others	LS600h	UVF	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	LS600h	UVF	All years	Pre-Crash 2	✓	✓	✓	✓	0022	SP0005, SP0038, SP0039, SP0040, SP0041
Europe or Others	LS600h	UVF	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	LS600h	UVF	All years	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274	SP0067, SP0068
Europe or Others	LS600h	UVF	All years	Navigatio n System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	LS600h	UVF	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	LS600h	UVF	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		

Europe or Others	LS600h	UVF	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	LS600h	UVF	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	
Europe or Others	LX450d	VDJ	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0031, SP0032, SP0072, SP0073, SP0074, SP0075, SP0101, SP0103, SP0104, SP0105, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0112, SP0113
Europe or Others	LX450d	VDJ	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	LX450d	VDJ	All years	4-Wheel Drive (4WD)	✓	✓	✓			

Europe or Others	LX450d	VDJ	All years	AHC	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	LX450d	VDJ	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	LX450d	VDJ	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	LX450d	VDJ	All years	PPS	✓	✓	✓	✓		
Europe or Others	LX450d	VDJ	All years	VGRS	✓	✓	✓	✓		SP0004, SP0037

Europe or Others	LX450d	VDJ	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
Europe or Others	LX450d	VDJ	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	LX450d	VDJ	All years	Front Recognition Camera	√	√	√	√	0052	SP0086, SP0087
Europe or Others	LX450d	VDJ	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
Europe or Others	LX450d	VDJ	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		

Europe or Others	LX450d	VDJ	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
Europe or Others	LX450d	VDJ	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
Europe or Others	LX450d	VDJ	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044



Europe or Others	LX450d	VDJ	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	LX450d	VDJ	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	LX450d	VDJ	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	LX450d	VDJ	All years	Body No. 4	✓	✓	✓		0310, 0311, 0312, 0313, 0314, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0327, 0328, 0329	
Europe or Others	LX450d	VDJ	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	LX450d	VDJ	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LX450d	VDJ	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LX450d	VDJ	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003

Europe or Others	LX450d	VDJ	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LX450d	VDJ	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	LX450d	VDJ	All years	Master Switch	✓	✓	✓			
Europe or Others	LX450d	VDJ	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	LX450d	VDJ	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	LX450d	VDJ	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	LX450d	VDJ	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
Europe or Others	LX450d	VDJ	All years	Road Sign Assist	✓	✓	✓	✓	1183	

Europe or Others	LX450d	VDJ	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LX450d	VDJ	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LX450d	VDJ	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	LX450d	VDJ	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	LX450d	VDJ	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	LX450d	VDJ	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	LX450d	VDJ	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	LX450d	VDJ	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	LX450d	VDJ	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	LX450d	VDJ	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	LX450d	VDJ	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LX450d	VDJ	All years	Automatic high beam	✓	✓		✓	0035	

Europe or Others	LX450d	VDJ	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	LX450d	VDJ	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	SP0061, SP0069
Europe or Others	LX460	URJ	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101
Europe or Others	LX460	URJ	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	LX460	URJ	All years	AHC	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

Europe or Others	LX460	URJ	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	LX460	URJ	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	LX460	URJ	All years	VGRS	✓	✓	✓	✓		SP0001, SP0009, SP0037
Europe or Others	LX460	URJ	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		

Europe or Others	LX460	URJ	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	LX460	URJ	All years	Rain and/or Humidity Sensor	✓	✓	✓			
Europe or Others	LX460	URJ	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
Europe or Others	LX460	URJ	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	

Europe or Others	LX460	URJ	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	LX460	URJ	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	LX460	URJ	All years	Body No. 4	✓	✓	✓		0310, 0311, 0312, 0313, 0314, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0327, 0328, 0329	
Europe or Others	LX460	URJ	All years	Body No. 5	✓	✓	✓		0031, 0032, 0033, 0331, 0332, 0333, 0334, 0335, 0336, 0337, 0338, 0339, 0340, 0341	
Europe or Others	LX460	URJ	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	LX460	URJ	All years	Driver Door Motor	✓	✓	✓		0528	

Europe or Others	LX460	URJ	All years	Passenger Door Motor	√	√	√		0528	
Europe or Others	LX460	URJ	All years	Left Rear Door Motor	√	√	√		0528	
Europe or Others	LX460	URJ	All years	Right Rear Door Motor	√	√	√		0528	
Europe or Others	LX460	URJ	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	LX460	URJ	All years	Master Switch	√	√	√			
Europe or Others	LX460	URJ	All years	Sliding Roof	√	√	√		0529	
Europe or Others	LX460	URJ	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	
Europe or Others	LX460	URJ	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	



Europe or Others	LX460	URJ	All years	Mirror	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0433, 0434, 0435, 0436, 0437	
Europe or Others	LX460	URJ	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	LX460	URJ	All years	Rain Sensor	✓	✓	✓			
Europe or Others	LX460	URJ	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	LX460	URJ	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015
Europe or Others	LX460	URJ	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050

Europe or Others	LX470	UZJ	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101
Europe or Others	LX470	UZJ	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	LX470	UZJ	All years	AHC	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001, SP0007

Europe or Others	LX470	UZJ	All years	ABS/VSC/TPC	✓	✓	✓	✓	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021, SP0023
Europe or Others	LX470	UZJ	All years	VGRS	✓	✓	✓	✓		SP0001, SP0009, SP0037
Europe or Others	LX470	UZJ	All years	Immobiliser	✓	✓	✓		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0011, SP0013, SP0065, SP0066, SP0148
Europe or Others	LX470	UZJ	All years	Theft Deterrent	✓	✓	✓		0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	
Europe or Others	LX470	UZJ	All years	Supplement Restraint System (SRS) Airbag	✓	✓				SP0004

Europe or Others	LX470	UZJ	All years	Body	✓	✓	✓	0031, 0032, 0 319, 0331, 03 33, 0335, 033 7, 0339, 0429 , 0498, 0499, 0500, 0501, 0 783, 0784, 07 85, 0801, 080 2, 0805, 0806 , 0807, 0809, 0815, 0816, 0 912, 0913, 09 14, 0915, 091 6, 0917, 0918 , 0919, 0920, 0921, 0922, 0 923, 0924, 09 25, 0926, 092 7, 0928, 0929 , 0930, 0931, 0932, 0933, 0 934, 0935, 09 69, 1006, 100 7, 1008, 1009 , 1010, 1011, 1012, 1013	SP0005, SP0 019, SP0020
Europe or Others	LX470	UZJ	All years	Body No. 2	✓	✓	✓	0031, 0032, 0 319, 0331, 03 33, 0335, 033 7, 0339, 0429 , 0499, 0500, 0501, 0783, 0 784, 0785, 08 01, 0802, 080 5, 0806, 0807 , 0809, 0815, 0816, 0912, 0 913, 0914, 09 15, 0916, 091 7, 0918, 0919 , 0920, 0921, 0922, 0923, 0 924, 0925, 09 26, 0927, 092 8, 0929, 0930 , 0931, 0932, 0933, 0934, 0 935	
Europe or Others	LX470	UZJ	All years	Driver Door	✓	✓	✓	0279, 0280, 0 281, 0282, 02 83, 0284, 031 7, 0429, 0430 , 0437, 0503, 0507, 0508, 0 509, 0528, 09 90, 0991	

Europe or Others	LX470	UZJ	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	LX470	UZJ	All years	Sliding Roof			√		0529	
Europe or Others	LX470	UZJ	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
Europe or Others	LX470	UZJ	All years	Mirror			√		0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	LX470	UZJ	All years	Rain Sensor			√			
Europe or Others	LX470	UZJ	All years	Wiper			√		0031, 0032, 0332	
Europe or Others	LX470	UZJ	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002
Europe or Others	LX570	URJ	All years	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101

Europe or Others	LX570	URJ	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	LX570	URJ	All years	AHC	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	LX570	URJ	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	LX570	URJ	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	LX570	URJ	All years	VGRS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0037

Europe or Others	LX570	URJ	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	LX570	URJ	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	LX570	URJ	All years	Rain and/or Humidity Sensor	√	√	√			
Europe or Others	LX570	URJ	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001
Europe or Others	LX570	URJ	All years	Pre-Crash	√	√	√	√	0347, 0348, 0349, 0350	

Europe or Others	LX570	URJ	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	LX570	URJ	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	LX570	URJ	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	LX570	URJ	All years	Body No. 4	✓	✓	✓		0310, 0311, 0312, 0313, 0314, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0327, 0328, 0329	
Europe or Others	LX570	URJ	All years	Body No. 5	✓	✓	✓		0031, 0032, 0033, 0331, 0332, 0333, 0334, 0335, 0336, 0337, 0338, 0339, 0340, 0341	
Europe or Others	LX570	URJ	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	



Europe or Others	LX570	URJ	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LX570	URJ	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LX570	URJ	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LX570	URJ	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	LX570	URJ	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	LX570	URJ	All years	Master Switch	✓	✓	✓			
Europe or Others	LX570	URJ	All years	Left Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354	
Europe or Others	LX570	URJ	All years	Right Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354	
Europe or Others	LX570	URJ	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	LX570	URJ	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	

Europe or Others	LX570	URJ	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	LX570	URJ	All years	Mirror	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0433, 0434, 0435, 0436, 0437	
Europe or Others	LX570	URJ	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	LX570	URJ	All years	Rain Sensor	✓	✓	✓			
Europe or Others	LX570	URJ	All years	AFS	✓	✓	✓	✓	0007, SP0008	

Europe or Others	LX570	URJ	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	LX570	URJ	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	LX570	URJ	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	LX570	URJ	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
Europe or Others	LX570	URJ	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101

Europe or Others	LX570	URJ	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0072, SP0101
Europe or Others	LX570	URJ	All years	4-Wheel Drive (4WD)	✓	✓	✓			
Europe or Others	LX570	URJ	All years	PPS	✓	✓	✓	✓		
Europe or Others	LX570	URJ	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
Europe or Others	LX570	URJ	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0087

Europe or Others	LX570	URJ	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	LX570	URJ	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				✓		
Europe or Others	LX570	URJ	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	LX570	URJ	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	LX570	URJ	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
Europe or Others	LX570	URJ	All years	Road Sign Assist	✓	✓	✓	✓	1183	
Europe or Others	LX570	URJ	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LX570	URJ	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	LX570	URJ	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	LX570	URJ	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	LX570	URJ	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	LX570	URJ	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071

Europe or Others	LX570	URJ	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	LX570	URJ	All years	Automatic high beam	✓	✓		✓	0035	
Europe or Others	LX570	URJ	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	LX570	URJ	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	SP0061, SP0069
Europe or Others	NX200	ZGZ1#	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0029, SP0042, SP0072, SP0073, SP0074, SP0075

Europe or Others	NX200	ZGZ1#	All years	Stop and Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297, 1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
Europe or Others	NX200	ZGZ1#	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	NX200	ZGZ1#	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	NX200	ZGZ1#	All years	4-Wheel Drive (4WD)	✓	✓	✓	✓	0819, 0820, 0821, 0822	
Europe or Others	NX200	ZGZ1#	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0117, SP0118, SP0119

Europe or Others	NX200	ZGZ1#	All years	EMPS	√	√	√	√		
Europe or Others	NX200	ZGZ1#	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	NX200	ZGZ1#	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	NX200	ZGZ1#	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		



Europe or Others	NX200	ZGZ1#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0 300, 0301, 03 17, 0319, 033 3, 0335, 0337 , 0339, 0426, 0427, 0429, 0 433, 0434, 04 35, 0436, 049 0, 0496, 0497 , 0498, 0499, 0500, 0501, 0 502, 0783, 07 84, 0785, 078 6, 0787, 0788 , 0789, 0790, 0791, 0792, 0 793, 0794, 07 95, 0796, 079 7, 0798, 0799 , 0800, 0801, 0802, 0803, 0 804, 0805, 08 06, 0807, 080 8, 0809, 0810 , 0811, 0812, 0813, 0814, 0 815, 0816, 08 17, 0818	
Europe or Others	NX200	ZGZ1#	All years	Gateway	✓	✓		✓		
Europe or Others	NX200	ZGZ1#	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0 522, 0523, 05 24, 0525, 052 6	
Europe or Others	NX200	ZGZ1#	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	NX200	ZGZ1#	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	NX200	ZGZ1#	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	NX200	ZGZ1#	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	NX200	ZGZ1#	All years	Master Switch	✓	✓	✓			
Europe or Others	NX200	ZGZ1#	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	NX200	ZGZ1#	All years	Tilt&Tele scopic	✓	✓	✓	✓	0472, 0473	

Europe or Others	NX200	ZGZ1#	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	NX200	ZGZ1#	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
Europe or Others	NX200	ZGZ1#	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	NX200	ZGZ1#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018

Europe or Others	NX200	ZGZ1#	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	NX200	ZGZ1#	All years	Starting Control	√	√	√	√	0256, 0257	
Europe or Others	NX200	ZGZ1#	All years	Navigation System	√	√	√	√		
Europe or Others	NX200	ZGZ1#	All years	ASC	√	√	√	√	1182	
Europe or Others	NX200	ZGZ1#	All years	Telematics	√	√	√	√	1521, 1522	
Europe or Others	NX200	ZGZ1#	All years	Radar Cruise 1	√	√	√	√		
Europe or Others	NX200	ZGZ1#	All years	Radar Cruise 2	√	√	√	√	0017, 0018, 1504, 1505	
Europe or Others	NX200	ZGZ1#	All years	Front Recognition Camera	√	√	√	√	0052	
Europe or Others	NX200	ZGZ1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
Europe or Others	NX200	ZGZ1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			√			
Europe or Others	NX200	ZGZ1#	All years	Parking Assist Camera	√	√	√	√		
Europe or Others	NX200	ZGZ1#	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0019, 0020, 0021, 0022	
Europe or Others	NX200	ZGZ1#	All years	Accessory Gateway	√	√	√	√		
Europe or Others	NX200	ZGZ1#	All years	Central Gateway	√	√	√	√		

Europe or Others	NX200	ZGZ1#	All years	Road Sign Assist	✓	✓	✓	✓	1183	
Europe or Others	NX200	ZGZ1#	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
Europe or Others	NX200	ZGZ1#	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	NX200	ZGZ1#	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	NX200	ZGZ1#	All years	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	SP0001, SP0003, SP0023, SP0024, SP0157
Europe or Others	NX200	ZGZ1#	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	NX200	ZGZ1#	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	
Europe or Others	NX200	ZGZ1#	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
Europe or Others	NX200	ZGZ1#	All years	Front Radar Sensor	✓	✓	✓			

Europe or Others	NX200t	AGZ1#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	SP0004, SP0 026, SP0029 , SP0032, SP 0042, SP007 3, SP0075, S P0098, SP00 99, SP0100, SP0101, SP0 102
------------------------	--------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------

Europe or Others	NX200t	AGZ1#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	SP0029, SP0032
Europe or Others	NX200t	AGZ1#	All years	Stop and Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	SP0004, SP0030, SP0035, SP0092, SP0093, SP0094, SP0095, SP0096, SP0097
Europe or Others	NX200t	AGZ1#	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	NX200t	AGZ1#	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	NX200t	AGZ1#	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	NX200t	AGZ1#	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
Europe or Others	NX200t	AGZ1#	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	NX200t	AGZ1#	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010

Europe or Others	NX200t	AGZ1#	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
Europe or Others	NX200t	AGZ1#	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	NX200t	AGZ1#	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
Europe or Others	NX200t	AGZ1#	All years	Panoramic view monitor	✓	✓	✓	✓		
Europe or Others	NX200t	AGZ1#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017



Europe or Others	NX200t	AGZ1#	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001
Europe or Others	NX200t	AGZ1#	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	NX200t	AGZ1#	All years	Gateway	√	√		√		SP0005
Europe or Others	NX200t	AGZ1#	All years	Accessory Gateway	√	√	√	√		SP0005
Europe or Others	NX200t	AGZ1#	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	NX200t	AGZ1#	All years	Driver Door Motor	√	√	√		0528	SP0003
Europe or Others	NX200t	AGZ1#	All years	Passenger Door Motor	√	√	√		0528	SP0003
Europe or Others	NX200t	AGZ1#	All years	Left Rear Door Motor	√	√	√		0528	SP0003
Europe or Others	NX200t	AGZ1#	All years	Right Rear Door Motor	√	√	√		0528	SP0003

Europe or Others	NX200t	AGZ1#	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
Europe or Others	NX200t	AGZ1#	All years	Master Switch	✓	✓	✓		
Europe or Others	NX200t	AGZ1#	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	NX200t	AGZ1#	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	NX200t	AGZ1#	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	NX200t	AGZ1#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	NX200t	AGZ1#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	NX200t	AGZ1#	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	NX200t	AGZ1#	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
Europe or Others	NX200t	AGZ1#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	NX200t	AGZ1#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	NX200t	AGZ1#	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	NX200t	AGZ1#	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	NX200t	AGZ1#	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	NX200t	AGZ1#	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	NX200t	AGZ1#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	NX200t	AGZ1#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	NX200t	AGZ1#	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	NX200t	AGZ1#	All years	Telematics	✓	✓	✓	✓	0036	
Europe or Others	NX200t	AGZ1#	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	

Europe or Others	NX200t	AGZ1#	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0 018, 0020, 00 21, 0022, 029 8
Europe or Others	NX300	AGZ1#	All years	Engine	√	√	√	√	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,

Europe or Others	NX300	AGZ1#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
Europe or Others	NX300	AGZ1#	All years	Stop and Start	✓	✓	✓		1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492
Europe or Others	NX300	AGZ1#	All years	Cruise Control	✓	✓	✓	✓	
Europe or Others	NX300	AGZ1#	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471

Europe or Others	NX300	AGZ1#	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	NX300	AGZ1#	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	
Europe or Others	NX300	AGZ1#	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	NX300	AGZ1#	All years	EMPS	✓	✓	✓	✓		
Europe or Others	NX300	AGZ1#	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	NX300	AGZ1#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0126

Europe or Others	NX300	AGZ1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	NX300	AGZ1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				✓		
Europe or Others	NX300	AGZ1#	All years	Panoramic view monitor	✓	✓	✓	✓		
Europe or Others	NX300	AGZ1#	All years	Parking Assist Camera	✓	✓	✓	✓		
Europe or Others	NX300	AGZ1#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	

Europe or Others	NX300	AGZ1#	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
Europe or Others	NX300	AGZ1#	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	
Europe or Others	NX300	AGZ1#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	NX300	AGZ1#	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	NX300	AGZ1#	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	NX300	AGZ1#	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	NX300	AGZ1#	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	NX300	AGZ1#	All years	Left Rear Door Motor	✓	✓	✓		0528	



Europe or Others	NX300	AGZ1#	All years	Right Rear Door Motor	√	√	√		0528	
Europe or Others	NX300	AGZ1#	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	NX300	AGZ1#	All years	Master Switch	√	√	√			
Europe or Others	NX300	AGZ1#	All years	Sliding Roof	√	√	√		0529	
Europe or Others	NX300	AGZ1#	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	
Europe or Others	NX300	AGZ1#	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	NX300	AGZ1#	All years	Head Up Display	√	√	√	√	0047, 0048, 0049, 0050, 0051	
Europe or Others	NX300	AGZ1#	All years	Road Sign Assist	√	√	√	√	1183	

Europe or Others	NX300	AGZ1#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	NX300	AGZ1#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	NX300	AGZ1#	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026
Europe or Others	NX300	AGZ1#	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
Europe or Others	NX300	AGZ1#	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015
Europe or Others	NX300	AGZ1#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553
Europe or Others	NX300	AGZ1#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305
Europe or Others	NX300	AGZ1#	All years	Starting Control	✓	✓	✓	✓	0256, 0257
Europe or Others	NX300	AGZ1#	All years	Navigation System	✓	✓	✓	✓	

Europe or Others	NX300	AGZ1#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	NX300	AGZ1#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	NX300	AGZ1#	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	NX300	AGZ1#	All years	Telematics	✓	✓	✓	✓	0036	
Europe or Others	NX300	AGZ1#	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	NX300	AGZ1#	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018, 1504, 1505	
Europe or Others	NX300	AGZ1#	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	NX300	AGZ1#	All years	Detection Of Occupant	✓	✓	✓			
Europe or Others	NX300	AGZ1#	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	NX300	AGZ1#	All years	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
Europe or Others	NX300	AGZ1#	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	NX300	AGZ1#	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	
Europe or Others	NX300	AGZ1#	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
Europe or Others	NX300	AGZ1#	All years	Front Radar Sensor	✓	✓	✓			

Europe or Others	NX300h	AYZ1#	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	NX300h	AYZ1#	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058, SP0089
Europe or Others	NX300h	AYZ1#	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	NX300h	AYZ1#	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	NX300h	AYZ1#	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0088
Europe or Others	NX300h	AYZ1#	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	NX300h	AYZ1#	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010

Europe or Others	NX300h	AYZ1#	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
Europe or Others	NX300h	AYZ1#	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	NX300h	AYZ1#	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
Europe or Others	NX300h	AYZ1#	All years	Panoramic view monitor	✓	✓	✓	✓		
Europe or Others	NX300h	AYZ1#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017

Europe or Others	NX300h	AYZ1#	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
Europe or Others	NX300h	AYZ1#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	NX300h	AYZ1#	All years	HV Gateway	✓	✓	✓	✓		SP0005
Europe or Others	NX300h	AYZ1#	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	NX300h	AYZ1#	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	NX300h	AYZ1#	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	NX300h	AYZ1#	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	NX300h	AYZ1#	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	NX300h	AYZ1#	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003

Europe or Others	NX300h	AYZ1#	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
Europe or Others	NX300h	AYZ1#	All years	Master Switch	✓	✓	✓		
Europe or Others	NX300h	AYZ1#	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	NX300h	AYZ1#	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	NX300h	AYZ1#	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	NX300h	AYZ1#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	NX300h	AYZ1#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284



Europe or Others	NX300h	AYZ1#	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006, SP0090, SP0091
Europe or Others	NX300h	AYZ1#	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
Europe or Others	NX300h	AYZ1#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	NX300h	AYZ1#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	NX300h	AYZ1#	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	NX300h	AYZ1#	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	NX300h	AYZ1#	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	NX300h	AYZ1#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	NX300h	AYZ1#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	NX300h	AYZ1#	All years	Vehicle proximity notification system	✓	✓	✓	✓		
Europe or Others	NX300h	AYZ1#	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	NX300h	AYZ1#	All years	Telematics	✓	✓	✓	✓	0036, 1521, 1522	

Europe or Others	NX300h	AYZ1#	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	
Europe or Others	NX300h	AYZ1#	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	NX300h	AYZ1#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	NX300h	AYZ1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	NX300h	AYZ1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	NX300h	AYZ1#	All years	Parking Assist Camera	✓	✓	✓	✓		
Europe or Others	NX300h	AYZ1#	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	NX300h	AYZ1#	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
Europe or Others	NX300h	AYZ1#	All years	Road Sign Assist	✓	✓	✓	✓	1183	
Europe or Others	NX300h	AYZ1#	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	NX300h	AYZ1#	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	NX300h	AYZ1#	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018, 1504, 1505	SP0061, SP0069, SP0134

Europe or Others	NX300h	AYZ1#	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	NX300h	AYZ1#	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	
Europe or Others	NX300h	AYZ1#	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
Europe or Others	NX300h	AYZ1#	All years	Front Radar Sensor	✓	✓	✓			
Europe or Others	RC-F	USC10	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0043, SP0101

Europe or Others	RC-F	USC10	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	RC-F	USC10	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	RC-F	USC10	All years	ABS/VSC/TC RC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	RC-F	USC10	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	RC-F	USC10	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	RC-F	USC10	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	RC-F	USC10	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
Europe or Others	RC-F	USC10	All years	TVD	✓	✓	✓	✓	0042, 0043	SP0004

Europe or Others	RC-F	USC10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	RC-F	USC10	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	RC-F	USC10	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	RC-F	USC10	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	RC-F	USC10	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	RC-F	USC10	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	RC-F	USC10	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	RC-F	USC10	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	RC-F	USC10	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	RC-F	USC10	All years	Master Switch	✓	✓	✓			

Europe or Others	RC-F	USC10	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	RC-F	USC10	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	RC-F	USC10	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	RC-F	USC10	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	RC-F	USC10	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	RC-F	USC10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006



Europe or Others	RC-F	USC10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	RC-F	USC10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	RC-F	USC10	All years	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036
Europe or Others	RC-F	USC10	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	RC-F	USC10	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	RC-F	USC10	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050
Europe or Others	RC-F	USC10	All years	Active Rear Wing	✓	✓	✓	✓	1189, 1190, 1191, 1192, 1193	SP0136
Europe or Others	RC-F	USC10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	RC-F	USC10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	RC-F	USC10	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	RC-F	USC10	All years	Telematics	✓	✓	✓	✓		
Europe or Others	RC-F	USC10	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	
Europe or Others	RC-F	USC10	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

Europe or Others	RC-F	USC10	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
Europe or Others	RC-F	USC10	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	RC-F	USC10	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	RC-F	USC10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	RC-F	USC10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	RC-F	USC10	All years	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	
Europe or Others	RC-F	USC10	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	RC-F	USC10	All years	Road Sign Assist	✓	✓	✓	✓	1183	

Europe or Others	RC-F	USC10	All years	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
Europe or Others	RC-F	USC10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	RC200t	ASC10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	SP0004, SP0026, SP0029, SP0032, SP0042, SP0073, SP0075, SP0101, SP0102

Europe or Others	RC200t	ASC10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	RC200t	ASC10	All years	Stop and Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	SP0004, SP0030, SP0035, SP0092, SP0093, SP0094, SP0095, SP0096, SP0097
Europe or Others	RC200t	ASC10	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	RC200t	ASC10	All years	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	RC200t	ASC10	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	RC200t	ASC10	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002
Europe or Others	RC200t	ASC10	All years	EMPS	√	√	√	√		SP0001, SP0009, SP0010

Europe or Others	RC200t	ASC10	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	RC200t	ASC10	All years	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	SP0086, SP0087
Europe or Others	RC200t	ASC10	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
Europe or Others	RC200t	ASC10	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001
Europe or Others	RC200t	ASC10	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

Europe or Others	RC200t	ASC10	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	RC200t	ASC10	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	RC200t	ASC10	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	RC200t	ASC10	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RC200t	ASC10	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RC200t	ASC10	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	RC200t	ASC10	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	RC200t	ASC10	All years	Master Switch	✓	✓	✓			

Europe or Others	RC200t	ASC10	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	RC200t	ASC10	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	RC200t	ASC10	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	RC200t	ASC10	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	RC200t	ASC10	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	RC200t	ASC10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006



Europe or Others	RC200t	ASC10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	RC200t	ASC10	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
Europe or Others	RC200t	ASC10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	RC200t	ASC10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	RC200t	ASC10	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	RC200t	ASC10	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	RC200t	ASC10	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	RC200t	ASC10	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	RC200t	ASC10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	RC200t	ASC10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		

Europe or Others	RC200t	ASC10	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	RC200t	ASC10	All years	Telematics	✓	✓	✓	✓	0036	
Europe or Others	RC200t	ASC10	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
Europe or Others	RC300	ASC10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	

Europe or Others	RC300	ASC10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	RC300	ASC10	All years	Stop and Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	
Europe or Others	RC300	ASC10	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	RC300	ASC10	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
Europe or Others	RC300	ASC10	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	RC300	ASC10	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	RC300	ASC10	All years	EMPS	✓	✓	✓	✓		

Europe or Others	RC300	ASC10	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	RC300	ASC10	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	RC300	ASC10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	RC300	ASC10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	RC300	ASC10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	

Europe or Others	RC300	ASC10	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		
Europe or Others	RC300	ASC10	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
Europe or Others	RC300	ASC10	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	RC300	ASC10	All years	Central Gateway	√	√	√	√		
Europe or Others	RC300	ASC10	All years	Driver Door Motor	√	√	√		0528	
Europe or Others	RC300	ASC10	All years	Passenger Door Motor	√	√	√		0528	
Europe or Others	RC300	ASC10	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	RC300	ASC10	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	RC300	ASC10	All years	Master Switch	√	√	√		
Europe or Others	RC300	ASC10	All years	Sliding Roof	√	√	√		0529
Europe or Others	RC300	ASC10	All years	Tilt&Telescopic	√	√	√	√	0472, 0473
Europe or Others	RC300	ASC10	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	RC300	ASC10	All years	Road Sign Assist	√	√	√	√	1183
Europe or Others	RC300	ASC10	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	RC300	ASC10	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	RC300	ASC10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026
Europe or Others	RC300	ASC10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
Europe or Others	RC300	ASC10	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015
Europe or Others	RC300	ASC10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553
Europe or Others	RC300	ASC10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305
Europe or Others	RC300	ASC10	All years	Starting Control	✓	✓	✓	✓	0256, 0257
Europe or Others	RC300	ASC10	All years	Navigation System	✓	✓	✓	✓	
Europe or Others	RC300	ASC10	All years	Master Blind Spot Monitor	✓	✓	✓	✓	



Europe or Others	RC300	ASC10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓			
Europe or Others	RC300	ASC10	All years	ASC	✓	✓	✓	✓	1182		
Europe or Others	RC300	ASC10	All years	Telematics	✓	✓	✓	✓	0036, 1521, 1522		
Europe or Others	RC300	ASC10	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018		
Europe or Others	RC300	ASC10	All years	Accessory Gateway	✓	✓	✓	✓			
Europe or Others	RC300	ASC10	All years	Detection Of Occupant	✓	✓	✓	✓			
Europe or Others	RC300	ASC10	All years	Remote Engine Starter	✓	✓	✓	✓			
Europe or Others	RC300	GSC1#	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101	
Europe or Others	RC300	GSC1#	All years	Cruise Control	✓	✓	✓	✓	0017, 0018		

Europe or Others	RC300	GSC1#	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	RC300	GSC1#	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	RC300	GSC1#	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
Europe or Others	RC300	GSC1#	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	RC300	GSC1#	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010

Europe or Others	RC300	GSC1#	All years	VGRS	√	√	√	√		SP0004, SP0037
Europe or Others	RC300	GSC1#	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	RC300	GSC1#	All years	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	SP0086, SP0087
Europe or Others	RC300	GSC1#	All years	DRS	√	√	√	√		SP0004, SP0081, SP0082, SP0083
Europe or Others	RC300	GSC1#	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
Europe or Others	RC300	GSC1#	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001

Europe or Others	RC300	GSC1#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	RC300	GSC1#	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	RC300	GSC1#	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	RC300	GSC1#	All years	Multi Bus Gateway	✓	✓	✓	✓		
Europe or Others	RC300	GSC1#	All years	No. 1 Multi Bus Monitor	✓	✓	✓	✓		SP0005
Europe or Others	RC300	GSC1#	All years	No. 2 Multi Bus Monitor	✓	✓	✓	✓		SP0005
Europe or Others	RC300	GSC1#	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RC300	GSC1#	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RC300	GSC1#	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	RC300	GSC1#	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	RC300	GSC1#	All years	Master Switch	✓	✓	✓		
Europe or Others	RC300	GSC1#	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	RC300	GSC1#	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	RC300	GSC1#	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	RC300	GSC1#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	RC300	GSC1#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	RC300	GSC1#	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	RC300	GSC1#	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	RC300	GSC1#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	RC300	GSC1#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	RC300	GSC1#	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	RC300	GSC1#	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	RC300	GSC1#	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	RC300	GSC1#	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	RC300	GSC1#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	RC300	GSC1#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	RC300	GSC1#	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	RC300	GSC1#	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

Europe or Others	RC300	GSC1#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	
------------------------	-------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

Europe or Others	RC300	GSC1#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	RC300	GSC1#	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	



Europe or Others	RC300	GSC1#	All years	ABS/VSC/TCR/EPB	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	RC300	GSC1#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	RC300	GSC1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	RC300	GSC1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	RC300	GSC1#	All years	Central Gateway	✓	✓	✓	✓		

Europe or Others	RC300	GSC1#	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026
Europe or Others	RC300	GSC1#	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
Europe or Others	RC300	GSE3#	All years	Engine	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,

Europe or Others	RC300	GSE3#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
Europe or Others	RC300	GSE3#	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018
Europe or Others	RC300	GSE3#	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471

Europe or Others	RC300	GSE3#	All years	ABS/VSC/TCR/EPB	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	RC300	GSE3#	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	
Europe or Others	RC300	GSE3#	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	RC300	GSE3#	All years	EMPS	✓	✓	✓	✓		
Europe or Others	RC300	GSE3#	All years	VGRS	✓	✓	✓	✓		
Europe or Others	RC300	GSE3#	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	RC300	GSE3#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	

Europe or Others	RC300	GSE3#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
Europe or Others	RC300	GSE3#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
Europe or Others	RC300	GSE3#	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	RC300	GSE3#	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		
Europe or Others	RC300	GSE3#	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	

Europe or Others	RC300	GSE3#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	RC300	GSE3#	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	RC300	GSE3#	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	RC300	GSE3#	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	RC300	GSE3#	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	RC300	GSE3#	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	RC300	GSE3#	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	RC300	GSE3#	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	RC300	GSE3#	All years	Master Switch	✓	✓	✓			

Europe or Others	RC300	GSE3#	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	RC300	GSE3#	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
Europe or Others	RC300	GSE3#	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	RC300	GSE3#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	RC300	GSE3#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

Europe or Others	RC300	GSE3#	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
Europe or Others	RC300	GSE3#	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	RC300	GSE3#	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	RC300	GSE3#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	RC300	GSE3#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	RC300	GSE3#	All years	Detection Of Occupant	✓	✓	✓			
Europe or Others	RC300	GSE3#	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	RC300	GSE3#	All years	Starting Control	✓	✓	✓	✓	0256, 0257	



Europe or Others	RC300	GSE3#	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	RC300	GSE3#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	RC300	GSE3#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	RC300h	AVC10	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	RC300h	AVC10	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058
Europe or Others	RC300h	AVC10	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	RC300h	AVC10	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	RC300h	AVC10	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023
Europe or Others	RC300h	AVC10	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	RC300h	AVC10	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010

Europe or Others	RC300h	AVC10	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	RC300h	AVC10	All years	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	SP0086, SP0087
Europe or Others	RC300h	AVC10	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
Europe or Others	RC300h	AVC10	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001

Europe or Others	RC300h	AVC10	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	RC300h	AVC10	All years	Gateway	√	√		√		SP0005
Europe or Others	RC300h	AVC10	All years	Driver Door Motor	√	√	√		0528	SP0003
Europe or Others	RC300h	AVC10	All years	Passenger Door Motor	√	√	√		0528	SP0003
Europe or Others	RC300h	AVC10	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	RC300h	AVC10	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	RC300h	AVC10	All years	Master Switch	√	√	√			
Europe or Others	RC300h	AVC10	All years	Sliding Roof	√	√	√		0529	

Europe or Others	RC300h	AVC10	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	
Europe or Others	RC300h	AVC10	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	RC300h	AVC10	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	RC300h	AVC10	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	RC300h	AVC10	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	SP0006
Europe or Others	RC300h	AVC10	All years	Auto Leveling Of Headlamp	√	√	√	√	0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	

Europe or Others	RC300h	AVC10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	RC300h	AVC10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	RC300h	AVC10	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	RC300h	AVC10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	RC300h	AVC10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	RC300h	AVC10	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
Europe or Others	RC300h	AVC10	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	RC300h	AVC10	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	
Europe or Others	RC300h	AVC10	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	RC300h	AVC10	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	RC300h	AVC10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	

Europe or Others	RC300h	AVC10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			√			
Europe or Others	RC300h	AVC10	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
Europe or Others	RC300h	AVC10	All years	Central Gateway	√	√	√	√		
Europe or Others	RC300h	AVC10	All years	Road Sign Assist	√	√	√	√	1183	
Europe or Others	RC300h	AVC10	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	

Europe or Others	RC300h	AVE30	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	RC300h	AVE30	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058
Europe or Others	RC300h	AVE30	All years	Cruise Control	✓	✓	✓	✓		



Europe or Others	RC300h	AVE30	All years	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	RC300h	AVE30	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023
Europe or Others	RC300h	AVE30	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002
Europe or Others	RC300h	AVE30	All years	EMPS	√	√	√	√		SP0001, SP0009, SP0010

Europe or Others	RC300h	AVE30	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	RC300h	AVE30	All years	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	SP0086, SP0087
Europe or Others	RC300h	AVE30	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
Europe or Others	RC300h	AVE30	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001

Europe or Others	RC300h	AVE30	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	RC300h	AVE30	All years	Gateway	√	√		√		SP0005
Europe or Others	RC300h	AVE30	All years	Driver Door Motor	√	√	√		0528	SP0003
Europe or Others	RC300h	AVE30	All years	Passenger Door Motor	√	√	√		0528	SP0003
Europe or Others	RC300h	AVE30	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
Europe or Others	RC300h	AVE30	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
Europe or Others	RC300h	AVE30	All years	Master Switch	√	√	√			
Europe or Others	RC300h	AVE30	All years	Sliding Roof	√	√	√		0529	

Europe or Others	RC300h	AVE30	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	
Europe or Others	RC300h	AVE30	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
Europe or Others	RC300h	AVE30	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	RC300h	AVE30	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	RC300h	AVE30	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	SP0006
Europe or Others	RC300h	AVE30	All years	Auto Leveling Of Headlamp	√	√	√	√	0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	

Europe or Others	RC300h	AVE30	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	RC300h	AVE30	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	RC300h	AVE30	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	RC300h	AVE30	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	RC300h	AVE30	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	RC300h	AVE30	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
Europe or Others	RC300h	AVE30	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	RC300h	AVE30	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	
Europe or Others	RC300h	AVE30	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	RC300h	AVE30	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	RC300h	AVE30	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	

Europe or Others	RC300h	AVE30	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
Europe or Others	RC300h	AVE30	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
Europe or Others	RC300h	AVE30	All years	Central Gateway	√	√	√	√		
Europe or Others	RC300h	AVE30	All years	Road Sign Assist	√	√	√	√	1183	
Europe or Others	RC300h	AVE30	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	

Europe or Others	RC350	GSC1#	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0090, 0 091, 0092, 00 93, 0094, 009 5, 0096, 0097 , 0098, 0099, 0100, 0101, 0 102, 0103, 01 04, 0105, 010 6, 0107, 0108 , 0109, 0110, 0111, 0112, 0 113, 0114, 01 15, 0116, 011 7, 0118, 0119 , 0120, 0121, 0122, 0123, 0 124, 0125, 01 26, 0127, 012 8, 0129, 0130 , 0131, 0132, 0133, 0134, 0 135, 0136, 01 37, 0138, 013 9, 0140, 0141 , 0142, 0143,	SP0004, SP0 026, SP0028 , SP0029, SP 0030, SP003 1, SP0032, S P0033, SP00 42, SP0043, SP0072, SP0 073, SP0074 , SP0075, SP 0076, SP010 1
------------------------	-------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Europe or Others	RC350	GSC1#	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP004, SP0031, SP0032, SP0072, SP0101
Europe or Others	RC350	GSC1#	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	RC350	GSC1#	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007



Europe or Others	RC350	GSC1#	All years	ABS/VSC/TC RC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	RC350	GSC1#	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	RC350	GSC1#	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	RC350	GSC1#	All years	VGRS	✓	✓	✓	✓		SP0004, SP0037
Europe or Others	RC350	GSC1#	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
Europe or Others	RC350	GSC1#	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
Europe or Others	RC350	GSC1#	All years	DRS	✓	✓	✓	✓		SP0004, SP0081, SP0082, SP0083

Europe or Others	RC350	GSC1#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
Europe or Others	RC350	GSC1#	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	RC350	GSC1#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	RC350	GSC1#	All years	Gateway	✓	✓		✓		SP0005
Europe or Others	RC350	GSC1#	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	RC350	GSC1#	All years	Multi Bus Gateway	✓	✓	✓	✓		
Europe or Others	RC350	GSC1#	All years	No. 1 Multi Bus Monitor	✓	✓	✓	✓		SP0005
Europe or Others	RC350	GSC1#	All years	No. 2 Multi Bus Monitor	✓	✓	✓	✓		SP0005
Europe or Others	RC350	GSC1#	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RC350	GSC1#	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RC350	GSC1#	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	RC350	GSC1#	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	RC350	GSC1#	All years	Master Switch	✓	✓	✓		
Europe or Others	RC350	GSC1#	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	RC350	GSC1#	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	RC350	GSC1#	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	RC350	GSC1#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	RC350	GSC1#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	RC350	GSC1#	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	RC350	GSC1#	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	RC350	GSC1#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	RC350	GSC1#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	RC350	GSC1#	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	RC350	GSC1#	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	RC350	GSC1#	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	RC350	GSC1#	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	RC350	GSC1#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	RC350	GSC1#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	RC350	GSC1#	All years	ASC	✓	✓	✓	✓	1182	

Europe or Others	RC350	GSC1#	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	RC350	GSC1#	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
Europe or Others	RC350	GSC1#	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
Europe or Others	RC350	GSC1#	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
Europe or Others	RC350	GSC1#	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	

Europe or Others	RC350	GSC1#	All years	Transmiss ion	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0168 , 0180, 0182, 0185, 0187, 0 188, 0190, 01 91, 0192, 019 3, 0194, 0195 , 0204, 0206, 0211, 0236, 0 237, 0249, 02 50, 0254, 025 8, 0262, 1194 , 1195, 1196, 1197, 1198, 1 199, 1200, 12 01, 1202, 120 3, 1204, 1205 , 1206, 1207, 1208, 1209, 1 210, 1211, 12 12, 1213, 121 4, 1215, 1216 , 1217, 1218, 1219, 1220, 1 221, 1222, 12 23, 1224, 122 5, 1226, 1227 , 1228, 1229,	
------------------------	-------	-------	--------------	------------------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

Europe or Others	RC350	GSC1#	All years	ABS/VSC/TCR/EPB	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	RC350	GSC1#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	RC350	GSC1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	RC350	GSC1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	RC350	GSC1#	All years	Central Gateway	✓	✓	✓	✓		



Europe or Others	RC350	GSC1#	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
Europe or Others	RC350	GSC1#	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	RC350	GSC1#	All years	Telematics	✓	✓	✓	✓	0036	
Europe or Others	RX200t	AGL2#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	SP0004, SP0026, SP0029, SP0032, SP0042, SP0073, SP0075, SP0101, SP0102, SP0114, SP0115, SP0116

Europe or Others	RX200t	AGL2#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	SP0101
Europe or Others	RX200t	AGL2#	All years	Stop and Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	SP0004, SP0030, SP0035, SP0092, SP0093, SP0094, SP0095, SP0096, SP0097
Europe or Others	RX200t	AGL2#	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	RX200t	AGL2#	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	SP0061, SP0069

Europe or Others	RX200t	AGL2#	All years	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	RX200t	AGL2#	All years	ABS/VSC/TRC/EPB	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0004
Europe or Others	RX200t	AGL2#	All years	Rain and/or Humidity Sensor	√	√	√			
Europe or Others	RX200t	AGL2#	All years	4WD	√	√	√	√	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085

Europe or Others	RX200t	AGL2#	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	RX200t	AGL2#	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	RX200t	AGL2#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0087
Europe or Others	RX200t	AGL2#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	RX200t	AGL2#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	RX200t	AGL2#	All years	Panoramic view monitor	✓	✓	✓	✓		
Europe or Others	RX200t	AGL2#	All years	Parking Assist Camera	✓	✓	✓	✓		

Europe or Others	RX200t	AGL2#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
Europe or Others	RX200t	AGL2#	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
Europe or Others	RX200t	AGL2#	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

Europe or Others	RX200t	AGL2#	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	RX200t	AGL2#	All years	Accessory Gateway	√	√	√	√		SP0005
Europe or Others	RX200t	AGL2#	All years	Central Gateway	√	√	√	√		
Europe or Others	RX200t	AGL2#	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	RX200t	AGL2#	All years	Driver Door Motor	√	√	√		0528	SP0003
Europe or Others	RX200t	AGL2#	All years	Passenger Door Motor	√	√	√		0528	SP0003
Europe or Others	RX200t	AGL2#	All years	Left Rear Door Motor	√	√	√		0528	SP0003
Europe or Others	RX200t	AGL2#	All years	Right Rear Door Motor	√	√	√		0528	SP0003
Europe or Others	RX200t	AGL2#	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	RX200t	AGL2#	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	RX200t	AGL2#	All years	Master Switch	✓	✓	✓		
Europe or Others	RX200t	AGL2#	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	RX200t	AGL2#	All years	Sliding Sunshade	✓	✓	✓		1181
Europe or Others	RX200t	AGL2#	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	RX200t	AGL2#	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	RX200t	AGL2#	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051
Europe or Others	RX200t	AGL2#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	RX200t	AGL2#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	RX200t	AGL2#	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006, SP0091
Europe or Others	RX200t	AGL2#	All years	Rain Sensor	✓	✓	✓	✓		
Europe or Others	RX200t	AGL2#	All years	Wiper	✓	✓	✓	✓	0031, 0032	
Europe or Others	RX200t	AGL2#	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	RX200t	AGL2#	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
Europe or Others	RX200t	AGL2#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	RX200t	AGL2#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	RX200t	AGL2#	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	RX200t	AGL2#	All years	Starting Control	✓	✓	✓	✓	0256, 0257	



Europe or Others	RX200t	AGL2#	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	RX200t	AGL2#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	RX200t	AGL2#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	RX200t	AGL2#	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	RX200t	AGL2#	All years	Telematics	✓	✓	✓	✓	0036	
Europe or Others	RX270	AGL	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101

Europe or Others	RX270	AGL	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	RX270	AGL	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	RX270	AGL	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
Europe or Others	RX270	AGL	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052
Europe or Others	RX270	AGL	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	RX270	AGL	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		

Europe or Others	RX270	AGL	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	RX270	AGL	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	RX270	AGL	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	RX270	AGL	All years	PM1 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	RX270	AGL	All years	PM2 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	RX270	AGL	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	RX270	AGL	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RX270	AGL	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	RX270	AGL	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	RX270	AGL	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	RX270	AGL	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	RX270	AGL	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	RX270	AGL	All years	Master Switch	√	√	√		
Europe or Others	RX270	AGL	All years	Sliding Roof	√	√	√		0529
Europe or Others	RX270	AGL	All years	Tilt&Telescopic	√	√	√	√	0472, 0473
Europe or Others	RX270	AGL	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	RX270	AGL	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	RX270	AGL	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	RX270	AGL	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	RX270	AGL	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	RX270	AGL	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015
Europe or Others	RX270	AGL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	RX270	AGL	All years	Charging Control	✓	✓	✓	✓	0258	
Europe or Others	RX270	AGL	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	RX270	AGL	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	RX270	AGL	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002

Europe or Others	RX300	AGL2#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	
------------------------	-------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--



Europe or Others	RX300	AGL2#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	RX300	AGL2#	All years	Stop and Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297, 1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
Europe or Others	RX300	AGL2#	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	RX300	AGL2#	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018, 1504, 1505	

Europe or Others	RX300	AGL2#	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471
Europe or Others	RX300	AGL2#	All years	ABS/VSC/TRC/EPB	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,
Europe or Others	RX300	AGL2#	All years	Rain and/or Humidity Sensor	✓	✓	✓		
Europe or Others	RX300	AGL2#	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822

Europe or Others	RX300	AGL2#	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	RX300	AGL2#	All years	EMPS	✓	✓	✓	✓		
Europe or Others	RX300	AGL2#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
Europe or Others	RX300	AGL2#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	RX300	AGL2#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	RX300	AGL2#	All years	Panoramic view monitor	✓	✓	✓	✓		
Europe or Others	RX300	AGL2#	All years	Parking Assist Camera	✓	✓	✓	✓		

Europe or Others	RX300	AGL2#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615
Europe or Others	RX300	AGL2#	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓	
Europe or Others	RX300	AGL2#	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298

Europe or Others	RX300	AGL2#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	RX300	AGL2#	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	RX300	AGL2#	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	RX300	AGL2#	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	RX300	AGL2#	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	RX300	AGL2#	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	RX300	AGL2#	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	RX300	AGL2#	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	RX300	AGL2#	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	RX300	AGL2#	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	RX300	AGL2#	All years	Master Switch	✓	✓	✓		
Europe or Others	RX300	AGL2#	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	RX300	AGL2#	All years	Sliding Sunshade	✓	✓	✓		1181
Europe or Others	RX300	AGL2#	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	RX300	AGL2#	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	RX300	AGL2#	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051
Europe or Others	RX300	AGL2#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	RX300	AGL2#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	RX300	AGL2#	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
Europe or Others	RX300	AGL2#	All years	Wiper	✓	✓	✓	✓	0031, 0032	
Europe or Others	RX300	AGL2#	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	RX300	AGL2#	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
Europe or Others	RX300	AGL2#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	RX300	AGL2#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	RX300	AGL2#	All years	Remote Engine Starter	✓	✓	✓	✓		

Europe or Others	RX300	AGL2#	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	RX300	AGL2#	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	RX300	AGL2#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	RX300	AGL2#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	RX300	AGL2#	All years	Telematics	✓	✓	✓	✓	0036, 1521, 1522	
Europe or Others	RX300	AGL2#	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	RX300	AGL2#	All years	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
Europe or Others	RX300	AGL2#	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	RX300	AGL2#	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	
Europe or Others	RX300	AGL2#	All years	Road Sign Assist	✓	✓	✓			
Europe or Others	RX300	AGL2#	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
Europe or Others	RX300	AGL2#	All years	Front Radar Sensor	✓	✓	✓			



Europe or Others	RX300	MCU	All years	Engine and ECT	√	√	√	√	0169, 0255, 1 126, 1127, 11 28, 1129, 113 0, 1131, 1132 , 1133, 1134, 1135, 1136, 1 137, 1138, 11 39, 1140, 114 1, 1142, 1143 , 1144, 1145, 1146, 1147, 1 148, 1149, 11 50, 1151, 115 2, 1153, 1154 , 1155, 1156, 1157, 1158, 1 159, 1160, 11 61, 1162, 116 3, 1164, 1165 , 1166, 1167, 1168, 1169, 1 170, 1171, 11 72, 1173, 117 4, 1175, 1176 , 1177, 1178, 1179, 1180	SP0003, SP0 004
------------------------	-------	-----	--------------	-------------------	---	---	---	---	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------

Europe or Others	RX300	MCU	All years	ABS/VSC/TRC	✓	✓	✓	✓	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021, SP0023
Europe or Others	RX300	MCU	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
Europe or Others	RX300	MCU	All years	Immobiliser	✓	✓	✓		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0011, SP0013, SP0065, SP0066, SP0148

Europe or Others	RX300	MCU	All years	Theft Deterrent	✓	✓	✓	0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	
Europe or Others	RX300	MCU	All years	Supplement Restraint System (SRS) Airbag	✓	✓			SP0004
Europe or Others	RX300	MCU	All years	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020
Europe or Others	RX300	MCU	All years	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	

Europe or Others	RX300	MCU	All years	Passenger Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
Europe or Others	RX300	MCU	All years	Left Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
Europe or Others	RX300	MCU	All years	Right Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
Europe or Others	RX300	MCU	All years	Sliding Roof			√	0529

Europe or Others	RX300	MCU	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	RX300	MCU	All years	Cruise Control	√	√	√	√		
Europe or Others	RX300	MCU	All years	Air suspension	√	√	√		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001, SP0007
Europe or Others	RX300	MCU	All years	Back Door	√	√	√		0316, 0429, 0521, 0522, 0523, 0524, 0526, 0528, 0967, 0992	
Europe or Others	RX300	MCU	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	

Europe or Others	RX300	MCU	All years	Master Switch			√		0939, 0940, 0941, 0942	
Europe or Others	RX300	MCU	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
Europe or Others	RX300	MCU	All years	Left Mirror			√		0279, 0280, 0281, 0282, 0283	
Europe or Others	RX300	MCU	All years	Right Mirror			√		0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	RX300	MCU	All years	Rain Sensor			√			
Europe or Others	RX300	MCU	All years	Wiper			√		0031, 0032, 0332	
Europe or Others	RX300	MCU	All years	AFS	√	√	√		0008, 0475, 0476, 0477, 0968	SP0064
Europe or Others	RX330	MCU	All years	Engine and ECT	√	√	√	√	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180	SP0003, SP0004
Europe or Others	RX330	MCU	All years	Cruise Control	√	√	√	√		

Europe or Others	RX330	MCU	All years	ABS/VSC/TRC	√	√	√	√	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021, SP0023
Europe or Others	RX330	MCU	All years	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
Europe or Others	RX330	MCU	All years	Immobiliser	√	√	√		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066
Europe or Others	RX330	MCU	All years	Supplement Restraint System (SRS) Airbag	√	√				SP0004

Europe or Others	RX330	MCU	All years	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005, SP0019, SP0020
Europe or Others	RX330	MCU	All years	Back Door	✓	✓	✓	0316, 0429, 0521, 0522, 0523, 0524, 0526, 0528, 0967, 0992	
Europe or Others	RX330	MCU	All years	Driver Seat			✓	0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	RX330	MCU	All years	Master Switch			✓	0939, 0940, 0941, 0942	
Europe or Others	RX330	MCU	All years	Sliding Roof			✓	0529	
Europe or Others	RX330	MCU	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473, 1005



Europe or Others	RX330	MCU	All years	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	RX330	MCU	All years	Left Mirror			√	0279, 0280, 0281, 0282, 0283	
Europe or Others	RX330	MCU	All years	Right Mirror			√	0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	RX330	MCU	All years	Rain Sensor			√		
Europe or Others	RX330	MCU	All years	Wiper			√	0031, 0032, 0332	
Europe or Others	RX330	MCU	All years	AFS	√	√	√	0008, 0475, 0476, 0477, 0968	SP0064

Europe or Others	RX330	MCU	All years	Air suspension	✓	✓	✓	0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001, SP0007	
Europe or Others	RX330	MCU	All years	Detection Of Occupant	✓	✓	✓		SP0034, SP0035, SP0036	
Europe or Others	RX350	GGL	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0043, SP0101

Europe or Others	RX350	GGL	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0031, SP0032, SP0101
Europe or Others	RX350	GGL	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	RX350	GGL	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

Europe or Others	RX350	GGL	All years	ABS/VSC/TRC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024
Europe or Others	RX350	GGL	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052
Europe or Others	RX350	GGL	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	RX350	GGL	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		

Europe or Others	RX350	GGL	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	RX350	GGL	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

Europe or Others	RX350	GGL	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	RX350	GGL	All years	PM1 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	RX350	GGL	All years	PM2 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	RX350	GGL	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	RX350	GGL	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	RX350	GGL	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	RX350	GGL	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	RX350	GGL	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	RX350	GGL	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	RX350	GGL	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	RX350	GGL	All years	Master Switch	✓	✓	✓		
Europe or Others	RX350	GGL	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	RX350	GGL	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	RX350	GGL	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	RX350	GGL	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	RX350	GGL	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	RX350	GGL	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	RX350	GGL	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	RX350	GGL	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015
Europe or Others	RX350	GGL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	RX350	GGL	All years	Charging Control	✓	✓	✓	✓	0258	
Europe or Others	RX350	GGL	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	RX350	GGL	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050
Europe or Others	RX350	GGL	All years	Telematics	✓	✓	✓	✓		SP0059, SP0060
Europe or Others	RX350	GGL	All years	Radar Cruise	✓	✓	✓	✓		
Europe or Others	RX350	GGL	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	RX350	GGL	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0040, SP0044



Europe or Others	RX350	GGL	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	RX350	GGL	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	RX350	GGL	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	RX350	GGL	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	RX350	GGL	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	RX350	GGL2#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	SP0004, SP0026, SP0029, SP0032, SP0042, SP0073, SP0075, SP0101, SP0102

Europe or Others	RX350	GGL2#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	RX350	GGL2#	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	RX350	GGL2#	All years	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

Europe or Others	RX350	GGL2#	All years	ABS/VSC/TRC/EPB	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	RX350	GGL2#	All years	4WD	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
Europe or Others	RX350	GGL2#	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	RX350	GGL2#	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	RX350	GGL2#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0087
Europe or Others	RX350	GGL2#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	

Europe or Others	RX350	GGL2#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				✓			
Europe or Others	RX350	GGL2#	All years	Panoramic view monitor	✓	✓	✓	✓			
Europe or Others	RX350	GGL2#	All years	Parking Assist Camera	✓	✓	✓	✓			
Europe or Others	RX350	GGL2#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017	
Europe or Others	RX350	GGL2#	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓			SP0001
Europe or Others	RX350	GGL2#	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044	

Europe or Others	RX350	GGL2#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0 300, 0301, 03 17, 0319, 033 3, 0335, 0337 , 0339, 0426, 0427, 0429, 0 433, 0434, 04 35, 0436, 049 0, 0496, 0497 , 0498, 0499, 0500, 0501, 0 502, 0783, 07 84, 0785, 078 6, 0787, 0788 , 0789, 0790, 0791, 0792, 0 793, 0794, 07 95, 0796, 079 7, 0798, 0799 , 0800, 0801, 0802, 0803, 0 804, 0805, 08 06, 0807, 080 8, 0809, 0810 , 0811, 0812, 0813, 0814, 0 815, 0816, 08 17, 0818	SP0005, SP0 018, SP0019 , SP0020
Europe or Others	RX350	GGL2#	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	RX350	GGL2#	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0 522, 0523, 05 24, 0525, 052 6	
Europe or Others	RX350	GGL2#	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RX350	GGL2#	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RX350	GGL2#	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RX350	GGL2#	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RX350	GGL2#	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0 422, 0423, 04 24, 0513, 051 4, 0515, 0516 , 0517, 0518, 0519	

Europe or Others	RX350	GGL2#	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	RX350	GGL2#	All years	Master Switch	✓	✓	✓		
Europe or Others	RX350	GGL2#	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	RX350	GGL2#	All years	Sliding Sunshade	✓	✓	✓		1181
Europe or Others	RX350	GGL2#	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	RX350	GGL2#	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	RX350	GGL2#	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051
Europe or Others	RX350	GGL2#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	RX350	GGL2#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	RX350	GGL2#	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	RX350	GGL2#	All years	Rain and/or Humidity Sensor	✓	✓	✓			
Europe or Others	RX350	GGL2#	All years	Wiper	✓	✓	✓	✓	0031, 0032	
Europe or Others	RX350	GGL2#	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	RX350	GGL2#	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	RX350	GGL2#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0013, SP0014, SP0015, SP0018
Europe or Others	RX350	GGL2#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	RX350	GGL2#	All years	Starting Control	✓	✓	✓	✓	0256, 0257	

Europe or Others	RX350	GGL2#	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	RX350	GGL2#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	RX350	GGL2#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	RX350	GGL2#	All years	Telematics	✓	✓	✓	✓	0036	
Europe or Others	RX350	GGL2#	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	RX350	GGL2#	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018, 1504, 1505	SP0061, SP0069
Europe or Others	RX350	GGL2#	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	RX350	GGL2#	All years	Detection Of Occupant	✓	✓	✓	✓		
Europe or Others	RX350	GGL2#	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	RX350	GGL2#	All years	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
Europe or Others	RX350	GGL2#	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	RX350	GGL2#	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	
Europe or Others	RX350	GGL2#	All years	Road Sign Assist	✓	✓	✓			
Europe or Others	RX350	GGL2#	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
Europe or Others	RX350	GGL2#	All years	Front Radar Sensor	✓	✓	✓			



Europe or Others	RX350	GSU	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101
Europe or Others	RX350	GSU	All years	Laser Cruise	✓	✓	✓	✓		
Europe or Others	RX350	GSU	All years	Air suspension	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001, SP0007

Europe or Others	RX350	GSU	All years	ABS/VSC/TPC	✓	✓	✓	✓	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021, SP0023
Europe or Others	RX350	GSU	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
Europe or Others	RX350	GSU	All years	Immobiliser	✓	✓	✓		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066
Europe or Others	RX350	GSU	All years	Supplement Restraint System (SRS) Airbag	✓	✓				SP0004

Europe or Others	RX350	GSU	All years	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005, SP0019, SP0020
Europe or Others	RX350	GSU	All years	Back Door	✓	✓	✓	0316, 0429, 0521, 0522, 0523, 0524, 0526, 0528, 0967, 0992	
Europe or Others	RX350	GSU	All years	Driver Seat			✓	0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	RX350	GSU	All years	Master Switch			✓	0939, 0940, 0941, 0942	
Europe or Others	RX350	GSU	All years	Sliding Roof			✓	0529	
Europe or Others	RX350	GSU	All years	Tilt&Telescopic	✓	✓	✓	0472, 0473, 1005	

Europe or Others	RX350	GSU	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	RX350	GSU	All years	Left Mirror			√		0279, 0280, 0281, 0282, 0283	
Europe or Others	RX350	GSU	All years	Right Mirror			√		0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	RX350	GSU	All years	Rain Sensor			√			
Europe or Others	RX350	GSU	All years	Wiper			√		0031, 0032, 0332	
Europe or Others	RX350	GSU	All years	AFS	√	√	√		0008, 0475, 0476, 0477, 0968	SP0064
Europe or Others	RX350	GSU	All years	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
Europe or Others	RX350	GSU	All years	Cruise Control	√	√	√	√		

Europe or Others	RX350	GSU	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002
Europe or Others	RX400h	MHU	All years	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0101
Europe or Others	RX400h	MHU	All years	Hybrid Control	√	√	√	√	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117	SP0003, SP0004, SP0005, SP0024, SP0026
Europe or Others	RX400h	MHU	All years	Laser Cruise	√	√	√	√		

Europe or Others	RX400h	MHU	All years	ABS/VSC/TC RC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0150
Europe or Others	RX400h	MHU	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
Europe or Others	RX400h	MHU	All years	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
Europe or Others	RX400h	MHU	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
Europe or Others	RX400h	MHU	All years	Immobiliser	✓	✓	✓		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066

Europe or Others	RX400h	MHU	All years	Supplement Restraint System (SRS) Airbag	✓	✓				SP0004
Europe or Others	RX400h	MHU	All years	Body	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005, SP0019, SP0020
Europe or Others	RX400h	MHU	All years	Gateway	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	
Europe or Others	RX400h	MHU	All years	Back Door	✓	✓	✓		0316, 0429, 0521, 0522, 0523, 0524, 0526, 0528, 0967, 0992	

Europe or Others	RX400h	MHU	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	RX400h	MHU	All years	Master Switch			√		0939, 0940, 0941, 0942	
Europe or Others	RX400h	MHU	All years	Sliding Roof			√		0529	
Europe or Others	RX400h	MHU	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
Europe or Others	RX400h	MHU	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	RX400h	MHU	All years	Left Mirror			√		0279, 0280, 0281, 0282, 0283	
Europe or Others	RX400h	MHU	All years	Right Mirror			√		0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
Europe or Others	RX400h	MHU	All years	Rain Sensor			√			



Europe or Others	RX400h	MHU	All years	Wiper			✓		0031, 0032, 0332	
Europe or Others	RX400h	MHU	All years	AFS	✓	✓	✓		0008, 0475, 0476, 0477, 0968	SP0064
Europe or Others	RX400h	MHU	All years	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
Europe or Others	RX400h	MHU	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	RX450h	GYL	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143,	SP0003, SP0004, SP0026, SP0027, SP0028, SP0029, SP0030, SP0031, SP0032, SP0033, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
Europe or Others	RX450h	GYL	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058
Europe or Others	RX450h	GYL	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	RX450h	GYL	All years	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
Europe or Others	RX450h	GYL	All years	Front Stabilizer	√	√	√		0527	
Europe or Others	RX450h	GYL	All years	Rear Stabilizer	√	√	√		0527	
Europe or Others	RX450h	GYL	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	SP0001, SP0003, SP0021, SP0022, SP0023
Europe or Others	RX450h	GYL	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002

Europe or Others	RX450h	GYL	All years	EMPS	√	√	√	√		SP0001, SP0009, SP0010
Europe or Others	RX450h	GYL	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
Europe or Others	RX450h	GYL	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051
Europe or Others	RX450h	GYL	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001

Europe or Others	RX450h	GYL	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020
Europe or Others	RX450h	GYL	All years	PM1 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	RX450h	GYL	All years	PM2 Gateway	✓	✓	✓	✓		SP0005
Europe or Others	RX450h	GYL	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	RX450h	GYL	All years	Driver Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RX450h	GYL	All years	Passenger Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RX450h	GYL	All years	Left Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RX450h	GYL	All years	Right Rear Door Motor	✓	✓	✓		0528	SP0003
Europe or Others	RX450h	GYL	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

Europe or Others	RX450h	GYL	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
Europe or Others	RX450h	GYL	All years	Master Switch	✓	✓	✓		
Europe or Others	RX450h	GYL	All years	Sliding Roof	✓	✓	✓		0529
Europe or Others	RX450h	GYL	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
Europe or Others	RX450h	GYL	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
Europe or Others	RX450h	GYL	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	RX450h	GYL	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

Europe or Others	RX450h	GYL	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	RX450h	GYL	All years	AFS	✓	✓	✓	✓	0007, SP0008	
Europe or Others	RX450h	GYL	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0005, SP0011, SP0012, SP0013, SP0014, SP0015, SP0018
Europe or Others	RX450h	GYL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
Europe or Others	RX450h	GYL	All years	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036
Europe or Others	RX450h	GYL	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
Europe or Others	RX450h	GYL	All years	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0077, SP0078, SP0079
Europe or Others	RX450h	GYL	All years	Telematics	✓	✓	✓	✓	1521, 1522	SP0059, SP0060
Europe or Others	RX450h	GYL	All years	Radar Cruise 2	✓	✓	✓	✓	0017, 0018, 1504, 1505	SP0061, SP0069
Europe or Others	RX450h	GYL	All years	Pre-Crash	✓	✓	✓	✓	0347, 0348, 0349, 0350	
Europe or Others	RX450h	GYL	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0040, SP0044
Europe or Others	RX450h	GYL	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
Europe or Others	RX450h	GYL	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		

Europe or Others	RX450h	GYL	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
Europe or Others	RX450h	GYL	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0087
Europe or Others	RX450h	GYL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
Europe or Others	RX450h	GYL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
Europe or Others	RX450h	GYL	All years	Panoramic view monitor	✓	✓	✓	✓		
Europe or Others	RX450h	GYL	All years	Parking Assist Camera	✓	✓	✓	✓		
Europe or Others	RX450h	GYL	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
Europe or Others	RX450h	GYL	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	RX450h	GYL	All years	Sliding Sunshade	✓	✓	✓		1181	
Europe or Others	RX450h	GYL	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	

Europe or Others	RX450h	GYL	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
Europe or Others	RX450h	GYL	All years	Rain and/or Humidity Sensor	✓	✓	✓			
Europe or Others	RX450h	GYL	All years	Wiper	✓	✓	✓	✓	0031, 0032	
Europe or Others	RX450h	GYL	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	RX450h	GYL	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
Europe or Others	RX450h	GYL	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	RX450h	GYL	All years	Road Sign Assist	✓	✓	✓	✓	1183	
Europe or Others	RX450h	GYL	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	RX450h	GYL	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	
Europe or Others	RX450h	GYL	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
Europe or Others	RX450h	GYL	All years	Front Radar Sensor	✓	✓	✓			
Europe or Others	RX450h	GYL	All years	Vehicle proximity notification system	✓	✓	✓	✓	0044, 0045, 0046	



Europe or Others	SC300	JZZ	All years	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180	SP0003, SP0004
Europe or Others	SC300	JZZ	All years	Cruise Control	✓	✓	✓	✓		
Europe or Others	SC300	JZZ	All years	Immobiliser	✓	✓	✓			SP0011, SP0013, SP0148

Europe or Others	SC430	UZZ	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0090, 0 091, 0092, 00 93, 0094, 009 5, 0096, 0097 , 0098, 0099, 0100, 0101, 0 102, 0103, 01 04, 0105, 010 6, 0107, 0108 , 0109, 0110, 0111, 0112, 0 113, 0114, 01 15, 0116, 011 7, 0118, 0119 , 0120, 0121, 0122, 0123, 0 124, 0125, 01 26, 0127, 012 8, 0129, 0130 , 0131, 0132, 0133, 0134, 0 135, 0136, 01 37, 0138, 013 9, 0140, 0141 , 0142, 0143,	SP0004, SP0 026, SP0027 , SP0028, SP 0029, SP003 0, SP0031, S P0032, SP00 33, SP0101
------------------------	-------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------

Europe or Others	SC430	UZZ	All years	ECT	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0096, 0 097, 0100, 01 01, 0102, 010 3, 0104, 0105 , 0106, 0107, 0108, 0109, 0 110, 0111, 01 12, 0113, 011 5, 0116, 0117 , 0118, 0119, 0120, 0121, 0 122, 0123, 01 24, 0125, 012 6, 0127, 0128 , 0129, 0130, 0131, 0132, 0 133, 0134, 01 35, 0136, 013 7, 0138, 0139 , 0140, 0141, 0149, 0159, 0 161, 0162, 01 63, 0164, 016 5, 0166, 0167 , 0168, 0169,	SP0003, SPO 004, SP0031 , SP0032, SP 0101
Europe or Others	SC430	UZZ	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	SC430	UZZ	All years	ABS/VSC/TPC	√	√	√	√	0821, 0822, 0825, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112,	SP0001, SP0003, SP0021, SP0023
Europe or Others	SC430	UZZ	All years	Tire Pressure Monitor	√	√	√		SP0001, SP0002	
Europe or Others	SC430	UZZ	All years	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
Europe or Others	SC430	UZZ	All years	Immobiliser	√	√	√		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066, SP0145, SP0146

Europe or Others	SC430	UZZ	All years	Theft Deterrent	✓	✓	✓	0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	SP0018, SP0019, SP0020
Europe or Others	SC430	UZZ	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓		SP0001, SP0004
Europe or Others	SC430	UZZ	All years	Gateway	✓	✓			
Europe or Others	SC430	UZZ	All years	Body No. 2	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	

Europe or Others	SC430	UZZ	All years	Body No. 3	✓	✓	✓	0031, 0032, 0 312, 0313, 03 14, 0315, 031 6, 0320, 0321 , 0325, 0329, 0330, 0332, 0 337, 0338, 08 05, 0912, 091 7, 0918, 0929 , 0931, 0943, 0944, 0945, 0 946, 0947, 09 48, 0949, 095 0, 0951, 0952 , 0953, 0954, 0955, 0956, 0 957, 0958, 09 59, 0960, 096 1, 0962, 0963 , 0964, 0965, 0966, 0967
Europe or Others	SC430	UZZ	All years	Body No. 4	✓		✓	0031, 0032, 0 312, 0313, 03 14, 0315, 031 6, 0320, 0321 , 0325, 0329, 0330, 0332, 0 337, 0338, 08 05, 0912, 091 7, 0918, 0929 , 0931, 0943, 0947, 0948, 0 949, 0950, 09 51, 0952, 095 3, 0954, 0955 , 0956, 0957, 0958, 0959, 0 960, 0961, 09 62, 0963, 096 4, 0965, 0966 , 0967

Europe or Others	SC430	UZZ	All years	Body No. 5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
Europe or Others	SC430	UZZ	All years	Driver Door	√	√	√		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	SC430	UZZ	All years	Passenger Door	√	√	√		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
Europe or Others	SC430	UZZ	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	SC430	UZZ	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
Europe or Others	SC430	UZZ	All years	Hardtop Retractable	√	√	√		0970	
Europe or Others	SC430	UZZ	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	

Europe or Others	SC430	UZZ	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
Europe or Others	SC430	UZZ	All years	Combination Switch			√			
Europe or Others	SC430	UZZ	All years	Switch Of Steering Pad			√			
Europe or Others	SC430	UZZ	All years	AFS	√	√	√		0008, 0475, 0476, 0477, 0968	
Europe or Others	SC430	UZZ	All years	Detection Of Occupant	√	√	√		SP0034, SP0035, SP0036	



Europe or Others	SC430	UZZ	All years	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180	SP0003, SP0004
Europe or Others	UX EV	KMA10	All years	EV	✓	✓	✓		0070, 0071, 0079, 0081, 0180, 0194, 0195, 1207, 1208, 1493, 1494, 1495, 1496, 1497	
Europe or Others	UX EV	KMA10	All years	Motor Generator	✓	✓	✓			
Europe or Others	UX EV	KMA10	All years	EV Battery	✓	✓	✓		1494, 1520	
Europe or Others	UX EV	KMA10	All years	Plug-in Control	✓	✓	✓		1523	
Europe or Others	UX EV	KMA10	All years	Direct Current (DC) Quick Charging Control	✓	✓	✓			
Europe or Others	UX EV	KMA10	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	UX EV	KMA10	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	

Europe or Others	UX EV	KMA10	All years	ABS/VSC/TPC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,	
Europe or Others	UX EV	KMA10	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	UX EV	KMA10	All years	EMPS	✓	✓	✓	✓		
Europe or Others	UX EV	KMA10	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	UX EV	KMA10	All years	Front Recognition Camera	✓	✓	✓			
Europe or Others	UX EV	KMA10	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	UX EV	KMA10	All years	Panoramic view monitor	✓	✓	✓	✓		

Europe or Others	UX EV	KMA10	All years	Steering Angle Sensor	✓	✓	✓			
Europe or Others	UX EV	KMA10	All years	Parking Assist Camera	✓	✓	✓	✓		
Europe or Others	UX EV	KMA10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	UX EV	KMA10	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
Europe or Others	UX EV	KMA10	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	

Europe or Others	UX EV	KMA10	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
Europe or Others	UX EV	KMA10	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	UX EV	KMA10	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
Europe or Others	UX EV	KMA10	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	UX EV	KMA10	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	UX EV	KMA10	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	UX EV	KMA10	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	UX EV	KMA10	All years	Master Switch	✓	✓	✓			
Europe or Others	UX EV	KMA10	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	UX EV	KMA10	All years	Tilt&Telescopic	✓	✓	✓		1513, 1514	

Europe or Others	UX EV	KMA10	All years	Combination Meter	✓	✓	✓	0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
Europe or Others	UX EV	KMA10	All years	Head Up Display	✓	✓	✓	0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
Europe or Others	UX EV	KMA10	All years	Road Sign Assist	✓	✓	✓		
Europe or Others	UX EV	KMA10	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	UX EV	KMA10	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
Europe or Others	UX EV	KMA10	All years	Clearance Warning	✓	✓	✓		0023, 0024
Europe or Others	UX EV	KMA10	All years	Rain and/or Humidity Sensor	✓	✓	✓		

Europe or Others	UX EV	KMA10	All years	Wiper	✓	✓	✓		0031, 0032, 0033, 0034	
Europe or Others	UX EV	KMA10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	UX EV	KMA10	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
Europe or Others	UX EV	KMA10	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	UX EV	KMA10	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	
Europe or Others	UX EV	KMA10	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
Europe or Others	UX EV	KMA10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	UX EV	KMA10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	

Europe or Others	UX EV	KMA10	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	UX EV	KMA10	All years	Front Radar Sensor	✓	✓	✓			
Europe or Others	UX EV	KMA10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	UX EV	KMA10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	UX EV	KMA10	All years	Grill shutter	✓	✓	✓	✓	0037, 0038, 0039, 0040, 0041	
Europe or Others	UX EV	KMA10	All years	Vehicle proximity notification system	✓	✓	✓	✓	0044, 0045, 0046	
Europe or Others	UX EV	KMA10	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	UX EV	KMA10	All years	Telematics	✓	✓	✓		1521, 1522	

Europe or Others	UX200	MZAA1 0	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	
------------------------	-------	------------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--



Europe or Others	UX200	MZAA10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
Europe or Others	UX200	MZAA10	All years	Stop and Start	✓	✓	✓		1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
Europe or Others	UX200	MZAA10	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	UX200	MZAA10	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	

Europe or Others	UX200	MZAA10	All years	Adaptive Variable Suspension (AVS) System	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
Europe or Others	UX200	MZAA10	All years	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
Europe or Others	UX200	MZAA10	All years	Tire Pressure Monitor	✓	✓	✓			
Europe or Others	UX200	MZAA10	All years	EMPS	✓	✓	✓	✓		
Europe or Others	UX200	MZAA10	All years	Front Recognition Camera	✓	✓	✓			
Europe or Others	UX200	MZAA10	All years	Lane Control	✓	✓	✓		0824, 0989	
Europe or Others	UX200	MZAA10	All years	Panoramic View Monitor	✓	✓	✓	✓		
Europe or Others	UX200	MZAA10	All years	Steering Angle Sensor	✓	✓	✓			
Europe or Others	UX200	MZAA10	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		

Europe or Others	UX200	MZAA10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	UX200	MZAA10	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
Europe or Others	UX200	MZAA10	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	

Europe or Others	UX200	MZAA1 0	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0 300, 0301, 03 17, 0319, 033 3, 0335, 0337 , 0339, 0426, 0427, 0429, 0 433, 0434, 04 35, 0436, 049 0, 0496, 0497 , 0498, 0499, 0500, 0501, 0 502, 0783, 07 84, 0785, 078 6, 0787, 0788 , 0789, 0790, 0791, 0792, 0 793, 0794, 07 95, 0796, 079 7, 0798, 0799 , 0800, 0801, 0802, 0803, 0 804, 0805, 08 06, 0807, 080 8, 0809, 0810 , 0811, 0812, 0813, 0814, 0 815, 0816, 08 17, 0818	
Europe or Others	UX200	MZAA1 0	All years	Accessory Gateway	✓	✓	✓	✓		
Europe or Others	UX200	MZAA1 0	All years	Central Gateway	✓	✓	✓	✓		
Europe or Others	UX200	MZAA1 0	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0 522, 0523, 05 24, 0525, 052 6	
Europe or Others	UX200	MZAA1 0	All years	Driver Door Motor	✓	✓	✓		0528	
Europe or Others	UX200	MZAA1 0	All years	Passenger Door Motor	✓	✓	✓		0528	
Europe or Others	UX200	MZAA1 0	All years	Left Rear Door Motor	✓	✓	✓		0528	
Europe or Others	UX200	MZAA1 0	All years	Right Rear Door Motor	✓	✓	✓		0528	
Europe or Others	UX200	MZAA1 0	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0 422, 0423, 04 24, 0513, 051 4, 0515, 0516 , 0517, 0518, 0519	

Europe or Others	UX200	MZAA10	All years	Master Switch	✓	✓	✓			
Europe or Others	UX200	MZAA10	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	UX200	MZAA10	All years	Tilt&Telescopic	✓	✓	✓		1513, 1514	
Europe or Others	UX200	MZAA10	All years	Combination Meter	✓	✓	✓		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
Europe or Others	UX200	MZAA10	All years	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
Europe or Others	UX200	MZAA10	All years	Road Sign Assist	✓	✓	✓			
Europe or Others	UX200	MZAA10	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	UX200	MZAA10	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

Europe or Others	UX200	MZAA10	All years	Clearance Warning	✓	✓	✓		0023, 0024	
Europe or Others	UX200	MZAA10	All years	Rain and/or Humidity Sensor	✓	✓	✓			
Europe or Others	UX200	MZAA10	All years	Wiper	✓	✓	✓	✓	0031, 0032	
Europe or Others	UX200	MZAA10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	UX200	MZAA10	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
Europe or Others	UX200	MZAA10	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	UX200	MZAA10	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	
Europe or Others	UX200	MZAA10	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			

Europe or Others	UX200	MZAA10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	UX200	MZAA10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	UX200	MZAA10	All years	Detection Of Occupant	✓	✓	✓	✓		
Europe or Others	UX200	MZAA10	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	UX200	MZAA10	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
Europe or Others	UX200	MZAA10	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	UX200	MZAA10	All years	Front Radar Sensor	✓	✓	✓	✓		
Europe or Others	UX200	MZAA10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	UX200	MZAA10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	UX200	MZAA10	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	UX200	MZAA10	All years	Telematics	✓	✓	✓	✓	0036, 1521, 1522	
Europe or Others	UX200	MZAA10	All years	Cruise Control	✓	✓	✓	✓		

Europe or Others	UX250h/UX260h	MZAH1#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Hybrid Control	✓	✓	✓		0070, 0071, 0079, 0081, 0180, 0194, 0195, 1207, 1208, 1493, 1494, 1495, 1496, 1497	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Motor Generator	✓	✓	✓	✓		
Europe or Others	UX250h/UX260h	MZAH1#	All years	Rear Motor Generator	✓	✓	✓	✓		
Europe or Others	UX250h/UX260h	MZAH1#	All years	Radar Cruise 1	✓	✓	✓	✓		
Europe or Others	UX250h/UX260h	MZAH1#	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	



Europe or Others	UX250h/UX260h	MZAH1#	All years	Adaptive Variable Suspension (AVS) System	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471
Europe or Others	UX250h/UX260h	MZAH1#	All years	ABS/VSC/TRC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0825, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0879, 0880,
Europe or Others	UX250h/UX260h	MZAH1#	All years	Tire Pressure Monitor	√	√	√		
Europe or Others	UX250h/UX260h	MZAH1#	All years	EMPS	√	√	√	√	

Europe or Others	UX250h/UX260h	MZAH1#	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Front Recognition Camera	√	√	√			
Europe or Others	UX250h/UX260h	MZAH1#	All years	Lane Control	√	√	√		0824, 0989	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Panoramic view monitor	√	√	√	√		
Europe or Others	UX250h/UX260h	MZAH1#	All years	Steering Angle Sensor	√	√	√			
Europe or Others	UX250h/UX260h	MZAH1#	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		

Europe or Others	UX250h/UX260h	MZAH1#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
Europe or Others	UX250h/UX260h	MZAH1#	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	

Europe or Others	UX250h/UX260h	MZAH1#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818
Europe or Others	UX250h/UX260h	MZAH1#	All years	Accessory Gateway	✓	✓	✓	✓	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Central Gateway	✓	✓	✓	✓	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526
Europe or Others	UX250h/UX260h	MZAH1#	All years	Driver Door Motor	✓	✓	✓		0528
Europe or Others	UX250h/UX260h	MZAH1#	All years	Passenger Door Motor	✓	✓	✓		0528
Europe or Others	UX250h/UX260h	MZAH1#	All years	Left Rear Door Motor	✓	✓	✓		0528
Europe or Others	UX250h/UX260h	MZAH1#	All years	Right Rear Door Motor	✓	✓	✓		0528
Europe or Others	UX250h/UX260h	MZAH1#	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519

Europe or Others	UX250h/UX260h	MZAH1#	All years	Master Switch	✓	✓	✓			
Europe or Others	UX250h/UX260h	MZAH1#	All years	Sliding Roof	✓	✓	✓		0529	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Tilt&Telescopic	✓	✓	✓		1513, 1514	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Combination Meter	✓	✓	✓		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Road Sign Assist	✓	✓	✓			
Europe or Others	UX250h/UX260h	MZAH1#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

Europe or Others	UX250h/UX260h	MZAH1#	All years	Clearance Warning	✓	✓	✓		0023, 0024	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Rain and/or Humidity Sensor	✓	✓	✓			
Europe or Others	UX250h/UX260h	MZAH1#	All years	Wiper	✓	✓	✓	✓	0031, 0032	
Europe or Others	UX250h/UX260h	MZAH1#	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			

Europe or Others	UX250h/UX260h	MZAH1#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Detection Of Occupant	✓	✓	✓	✓		
Europe or Others	UX250h/UX260h	MZAH1#	All years	Remote Engine Starter	✓	✓	✓	✓		
Europe or Others	UX250h/UX260h	MZAH1#	All years	Navigation System	✓	✓	✓	✓		
Europe or Others	UX250h/UX260h	MZAH1#	All years	Front Radar Sensor	✓	✓	✓	✓		
Europe or Others	UX250h/UX260h	MZAH1#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	UX250h/UX260h	MZAH1#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
Europe or Others	UX250h/UX260h	MZAH1#	All years	Vehicle proximity notification system	✓	✓	✓	✓	0044, 0045, 0046	
Europe or Others	UX250h/UX260h	MZAH1#	All years	ASC	✓	✓	✓	✓	1182	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Telematics	✓	✓	✓	✓	0036	
Europe or Others	UX250h/UX260h	MZAH1#	All years	Cruise Control	✓	✓	✓	✓		

USA	CT200h	ZWA	2011-2017	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
USA	CT200h	ZWA	2011-2017	Hybrid Control	√	√	√	√	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058
USA	CT200h	ZWA	2011-2017	Cruise Control	√	√	√	√		



USA	CT200h	ZWA	2011-2017	ABS/VSC/TRAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0088, SP0175
USA	CT200h	ZWA	2011-2017	Tire Pressure Monitor	√	√	√			SP0001, SP0002
USA	CT200h	ZWA	2011-2017	EMPS	√	√	√	√		SP0001, SP0009, SP0010
USA	CT200h	ZWA	2011-2017	Transmission Control	√	√	√	√		

USA	CT200h	ZWA	2011-2017	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	CT200h	ZWA	2011-2017	Theft Deterrent	✓	✓	✓		0329, 0333, 0494, 0495, 0496, 0497, 0498, 0499, 0500, 0501, 0502	
USA	CT200h	ZWA	2011-2017	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	CT200h	ZWA	2011-2017	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	CT200h	ZWA	2011-2017	PM1 Gateway	✓	✓	✓	✓		SP0005
USA	CT200h	ZWA	2011-2017	Driver Door Motor	✓	✓	✓		0528	SP0003
USA	CT200h	ZWA	2011-2017	Passenger Door Motor	✓	✓	✓		0528	SP0003
USA	CT200h	ZWA	2011-2017	Left Rear Door Motor	✓	✓	✓		0528	SP0003
USA	CT200h	ZWA	2011-2017	Right Rear Door Motor	✓	✓	✓		0528	SP0003
USA	CT200h	ZWA	2011-2017	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	CT200h	ZWA	2011-2017	Master Switch	✓	✓	✓			
USA	CT200h	ZWA	2011-2017	Sliding Roof	✓	✓	✓		0529	

USA	CT200h	ZWA	2011-2017	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	CT200h	ZWA	2011-2017	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	CT200h	ZWA	2011-2017	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	CT200h	ZWA	2011-2017	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
USA	CT200h	ZWA	2011-2017	Auto Leveling Of Headlamp	✓	✓	✓	✓	0007, SP0008	

USA	CT200h	ZWA	2011-2017	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0168
USA	CT200h	ZWA	2011-2017	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	CT200h	ZWA	2011-2017	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036
USA	CT200h	ZWA	2011-2017	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	CT200h	ZWA	2011-2017	Navigation System	✓	✓	✓	✓		
USA	CT200h	ZWA	2011-2017	PM2 Gateway	✓	✓	✓	✓		SP0005
USA	CT200h	ZWA	2011-2017	Telematics	✓	✓	✓	✓		
USA	CT200h	ZWA	2011-2017	Radar Cruise	✓	✓	✓	✓		
USA	CT200h	ZWA	2011-2017	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	CT200h	ZWA	2011-2017	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
USA	CT200h	ZWA	2011-2017	Advanced Parking Guidance/Parking Assist Monitor	✓	✓	✓	✓		
USA	CT200h	ZWA	2011-2017	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	

USA	CT200h	ZWA	2011-2017	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	ES300	MCV	1994-2003	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004, SP0026
USA	ES300	MCV	1994-2003	Immobiliser	✓	✓	✓			SP0065, SP0066, SP0148
USA	ES300	MCV	1994-2003	Supplement Restraint System (SRS) Airbag	✓	✓				SP0004

USA	ES300	MCV	1994-2003	ABS/VSC/TRAC	✓	✓	✓	✓	0821, 0822, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1083, 1096, 1098, 1099, 1101, 1102, 1104, 1105, 1106, 1117, 1118, 1121, 1122, 1123, 1124, 1125, 1538, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561,	SP0001, SP0003, SP0021, SP0023
USA	ES300	MCV	1994-2003	Cruise Control	✓	✓	✓	✓		
USA	ES300	MCV	1994-2003	EMS	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001
USA	ES300	MCV	1994-2003	Theft Deterrent	✓	✓	✓		0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	

USA	ES300	MCV	1994-2003	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
USA	ES300	MCV	1994-2003	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	ES300	MCV	1994-2003	Passenger Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	



USA	ES300h	***	2019-2021	Engine	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	
USA	ES300h	***	2019-2021	Hybrid Control	√	√	√		0070, 0071, 0079, 0081, 0180, 0194, 0195, 1207, 1208, 1493, 1494, 1495, 1496, 1497	
USA	ES300h	***	2019-2021	Motor Generator	√	√	√			
USA	ES300h	***	2019-2021	Radar Cruise 1	√	√	√	√		
USA	ES300h	***	2019-2021	Radar Cruise 2	√	√	√		1504, 1505	

USA	ES300h	***	2019-2021	ABS/VSC/T RAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	
USA	ES300h	***	2019-2021	Tire Pressure Monitor	√	√	√			
USA	ES300h	***	2019-2021	EMPS	√	√	√	√		
USA	ES300h	***	2019-2021	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
USA	ES300h	***	2019-2021	Front Recognition Camera	√	√	√			
USA	ES300h	***	2019-2021	Lane Control	√	√	√		0824, 0989	
USA	ES300h	***	2019-2021	Panoramic view monitor	√	√	√	√		

USA	ES300h	***	2019-2021	Steering Angle Sensor	√	√	√		
USA	ES300h	***	2019-2021	Parking Assist Camera	√	√	√	√	
USA	ES300h	***	2019-2021	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615
USA	ES300h	***	2019-2021	Supplement Restraint System (SRS) Airbag	√	√	√	√	
USA	ES300h	***	2019-2021	Pre-Collision System	√	√	√		1524, 1525, 1526

USA	ES300h	***	2019-2021	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
USA	ES300h	***	2019-2021	Accessory Gateway	√	√	√	√		
USA	ES300h	***	2019-2021	Central Gateway	√	√	√	√		
USA	ES300h	***	2019-2021	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	ES300h	***	2019-2021	Driver Door Motor	√	√	√		0528	
USA	ES300h	***	2019-2021	Passenger Door Motor	√	√	√		0528	
USA	ES300h	***	2019-2021	Left Rear Door Motor	√	√	√		0528	
USA	ES300h	***	2019-2021	Right Rear Door Motor	√	√	√		0528	
USA	ES300h	***	2019-2021	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

USA	ES300h	***	2019-2021	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	ES300h	***	2019-2021	Master Switch	√	√	√			
USA	ES300h	***	2019-2021	Sliding Roof	√	√	√		0529	
USA	ES300h	***	2019-2021	Tilt&Telescopic	√	√	√		1513, 1514	
USA	ES300h	***	2019-2021	Combination Meter	√	√	√		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
USA	ES300h	***	2019-2021	Head Up Display	√	√	√		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
USA	ES300h	***	2019-2021	Road Sign Assist	√	√	√			
USA	ES300h	***	2019-2021	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

USA	ES300h	***	2019-2021	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	ES300h	***	2019-2021	Advanced Parking Guidance/ Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A)	√	√	√	√	0023, 0024, 0025, 0026	
USA	ES300h	***	2019-2021	Rain and/or Humidity Sensor	√	√	√			
USA	ES300h	***	2019-2021	Wiper	√	√	√	√	0031, 0032	
USA	ES300h	***	2019-2021	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	ES300h	***	2019-2021	Adaptive Front Lighting System (AFS) (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	
USA	ES300h	***	2019-2021	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
USA	ES300h	***	2019-2021	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	

USA	ES300h	***	2019-2021	Front Recognition Camera (Front Lighting Control)	✓	✓	✓		
USA	ES300h	***	2019-2021	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553
USA	ES300h	***	2019-2021	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305
USA	ES300h	***	2019-2021	Detection Of Occupant	✓	✓	✓	✓	
USA	ES300h	***	2019-2021	Remote Engine Starter	✓	✓	✓	✓	
USA	ES300h	***	2019-2021	Navigation System	✓	✓	✓	✓	
USA	ES300h	***	2019-2021	Front Radar Sensor	✓	✓	✓		
USA	ES300h	***	2019-2021	Master Blind Spot Monitor	✓	✓	✓	✓	
USA	ES300h	***	2019-2021	Slave Blind Spot Monitor	✓	✓	✓	✓	
USA	ES300h	***	2019-2021	Grill shutter	✓	✓	✓	✓	0037, 0038, 0039, 0040, 0041
USA	ES300h	***	2019-2021	Vehicle proximity notification system	✓	✓	✓	✓	0044, 0045, 0046
USA	ES300h	***	2019-2021	Active Noise Control	✓	✓	✓		1515, 1516, 1517, 1518, 1519

USA	ES300h	***	2019-2021	Pedestrian Protection	✓	✓	✓			
USA	ES300h	***	2019-2021	Telematics	✓	✓	✓	✓	1521, 1522	
USA	ES300h	AVV	2013-2018	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
USA	ES300h	AVV	2013-2018	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058
USA	ES300h	AVV	2013-2018	Cruise Control	✓	✓	✓	✓		



USA	ES300h	AVV	2013-2018	ABS/VSC/TRAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0088, SP0175
USA	ES300h	AVV	2013-2018	Tire Pressure Monitor	√	√	√			SP0001, SP0002
USA	ES300h	AVV	2013-2018	EMPS	√	√	√	√		SP0001, SP0009, SP0010
USA	ES300h	AVV	2013-2018	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	SP0086, SP0087

USA	ES300h	AVV	2013-2018	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	ES300h	AVV	2013-2018	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	ES300h	AVV	2013-2018	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	ES300h	AVV	2013-2018	PM1 Gateway	√	√	√	√		SP0005
USA	ES300h	AVV	2013-2018	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	ES300h	AVV	2013-2018	Driver Door Motor	√	√	√		0528	SP0003
USA	ES300h	AVV	2013-2018	Passenger Door Motor	√	√	√		0528	SP0003
USA	ES300h	AVV	2013-2018	Left Rear Door Motor	√	√	√		0528	SP0003
USA	ES300h	AVV	2013-2018	Right Rear Door Motor	√	√	√		0528	SP0003
USA	ES300h	AVV	2013-2018	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

USA	ES300h	AVV	2013-2018	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	ES300h	AVV	2013-2018	Master Switch	✓	✓	✓			
USA	ES300h	AVV	2013-2018	Sliding Roof	✓	✓	✓		0529	
USA	ES300h	AVV	2013-2018	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
USA	ES300h	AVV	2013-2018	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	ES300h	AVV	2013-2018	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	ES300h	AVV	2013-2018	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	ES300h	AVV	2013-2018	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	

USA	ES300h	AVV	2013-2018	Auto Leveling Of Headlamp	✓	✓	✓	✓	0007, SP0008	
USA	ES300h	AVV	2013-2018	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	ES300h	AVV	2013-2018	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	ES300h	AVV	2013-2018	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	ES300h	AVV	2013-2018	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	ES300h	AVV	2013-2018	Navigation System	✓	✓	✓	✓		
USA	ES300h	AVV	2013-2018	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	ES300h	AVV	2013-2018	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	ES300h	AVV	2013-2018	Telematics	✓	✓	✓	✓		
USA	ES300h	AVV	2013-2018	Radar Cruise	✓	✓	✓	✓		
USA	ES300h	AVV	2013-2018	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	ES300h	AVV	2013-2018	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
USA	ES300h	AVV	2013-2018	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		

USA	ES300h	AVV	2013-2018	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
USA	ES300h	AVV	2013-2018	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086
USA	ES300h	AVV	2013-2018	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
USA	ES300h	AVV	2013-2018	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	✓	✓	✓	✓		
USA	ES300h	AVV	2013-2018	Central Gateway	✓	✓	✓	✓		
USA	ES300h	AVV	2013-2018	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	ES300h	AVV	2013-2018	Radar Cruise 1	✓	✓	✓	✓		
USA	ES300h	AVV	2013-2018	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	SP0061, SP0069
USA	ES300h	AVV	2013-2018	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	

USA	ES330	MCV	2004-2006	Engine and ECT	√	√	√	√	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004, SP0026
USA	ES330	MCV	2004-2006	Cruise Control	√	√	√	√		
USA	ES330	MCV	2004-2006	EMS	√	√	√		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001

USA	ES330	MCV	2004-2006	ABS/VSC/TRAC	✓	✓	✓	✓	0821, 0822, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1083, 1096, 1098, 1099, 1101, 1102, 1104, 1105, 1106, 1117, 1118, 1121, 1122, 1123, 1124, 1125, 1538, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561,	SP0001, SP0003, SP0021, SP0023
USA	ES330	MCV	2004-2006	Immobiliser	✓	✓	✓		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066
USA	ES330	MCV	2004-2006	Theft Deterrent	✓	✓	✓		0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	
USA	ES330	MCV	2004-2006	Supplement Restraint System (SRS) Airbag	✓	✓	✓			SP0001



USA	ES330	MCV	2004-2006	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
USA	ES330	MCV	2004-2006	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	ES330	MCV	2004-2006	Passenger Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	ES330	MCV	2004-2006	Detection Of Occupant	✓	✓	✓		SP0034, SP0035, SP0036

USA	ES350	***	2019- 2021	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	
-----	-------	-----	---------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

USA	ES350	***	2019-2021	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
USA	ES350	***	2019-2021	Radar Cruise 1	✓	✓	✓	✓		
USA	ES350	***	2019-2021	Radar Cruise 2	✓	✓	✓		1504, 1505	
USA	ES350	***	2019-2021	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
USA	ES350	***	2019-2021	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	

USA	ES350	***	2019-2021	Tire Pressure Monitor	√	√	√			
USA	ES350	***	2019-2021	EMPS	√	√	√	√		
USA	ES350	***	2019-2021	Front Recognition Camera	√	√	√			
USA	ES350	***	2019-2021	Lane Control	√	√	√		0824, 0989	
USA	ES350	***	2019-2021	Panoramic view monitor	√	√	√	√		
USA	ES350	***	2019-2021	Steering Angle Sensor	√	√	√			
USA	ES350	***	2019-2021	Parking Assist Camera	√	√	√	√		
USA	ES350	***	2019-2021	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
USA	ES350	***	2019-2021	Supplement Restraint System (SRS) Airbag	√	√	√	√		
USA	ES350	***	2019-2021	Pre-Collision System	√	√	√		1524, 1525, 1526	

USA	ES350	***	2019-2021	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
USA	ES350	***	2019-2021	Accessory Gateway	√	√	√	√		
USA	ES350	***	2019-2021	Central Gateway	√	√	√	√		
USA	ES350	***	2019-2021	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	ES350	***	2019-2021	Driver Door Motor	√	√	√		0528	
USA	ES350	***	2019-2021	Passenger Door Motor	√	√	√		0528	
USA	ES350	***	2019-2021	Left Rear Door Motor	√	√	√		0528	
USA	ES350	***	2019-2021	Right Rear Door Motor	√	√	√		0528	
USA	ES350	***	2019-2021	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	ES350	***	2019-2021	Master Switch	√	√	√			

USA	ES350	***	2019-2021	Sliding Roof	√	√	√		0529	
USA	ES350	***	2019-2021	Tilt&Telescopic	√	√	√		1513, 1514	
USA	ES350	***	2019-2021	Combination Meter	√	√	√		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
USA	ES350	***	2019-2021	Head Up Display	√	√	√		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
USA	ES350	***	2019-2021	Road Sign Assist	√	√	√			
USA	ES350	***	2019-2021	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	ES350	***	2019-2021	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

USA	ES350	***	2019-2021	Advanced Parking Guidance/ Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A)	√	√	√	√	0023, 0024, 0025, 0026	
USA	ES350	***	2019-2021	Rain and/or Humidity Sensor	√	√	√			
USA	ES350	***	2019-2021	Remote Engine Starter	√	√	√	√		
USA	ES350	***	2019-2021	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	ES350	***	2019-2021	Adaptive Front Lighting System (AFS) (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	
USA	ES350	***	2019-2021	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
USA	ES350	***	2019-2021	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	
USA	ES350	***	2019-2021	Automatic high beam	√	√	√			

USA	ES350	***	2019-2021	Smart Key	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	ES350	***	2019-2021	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	
USA	ES350	***	2019-2021	Detection Of Occupant	√	√	√	√		
USA	ES350	***	2019-2021	Starting Control	√	√	√	√	0256, 0257	
USA	ES350	***	2019-2021	Navigation System	√	√	√	√		
USA	ES350	***	2019-2021	Front Radar Sensor	√	√	√			
USA	ES350	***	2019-2021	Master Blind Spot Monitor	√	√	√	√		
USA	ES350	***	2019-2021	Slave Blind Spot Monitor	√	√	√	√		
USA	ES350	***	2019-2021	Active Noise Control	√	√	√		1515, 1516, 1517, 1518, 1519	
USA	ES350	***	2019-2021	Pedestrian Protection	√	√	√			
USA	ES350	***	2019-2021	Telematics	√	√	√	√	1521, 1522	



USA	ES350	GSV	2007-2018	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0030, SP0032, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
-----	-------	-----	-----------	--------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------

USA	ES350	GSV	2007-2018	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0072, SP0101
USA	ES350	GSV	2007-2018	Cruise Control	✓	✓	✓	✓		
USA	ES350	GSV	2007-2018	E-ACM	✓	✓	✓		0432	

USA	ES350	GSV	2007-2018	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084, SP0175
USA	ES350	GSV	2007-2018	Tire Pressure Monitor	✓	✓	✓		SP0001, SP0002	

USA	ES350	GSV	2007-2018	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	ES350	GSV	2007-2018	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	ES350	GSV	2007-2018	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	ES350	GSV	2007-2018	Gateway	√	√	√	√		SP0005
USA	ES350	GSV	2007-2018	Driver Door Motor	√	√	√		0528	SP0003
USA	ES350	GSV	2007-2018	Passenger Door Motor	√	√	√		0528	SP0003
USA	ES350	GSV	2007-2018	Left Rear Door Motor	√	√	√		0528	SP0003
USA	ES350	GSV	2007-2018	Right Rear Door Motor	√	√	√		0528	SP0003
USA	ES350	GSV	2007-2018	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	ES350	GSV	2007-2018	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	ES350	GSV	2007-2018	Master Switch	√	√	√			

USA	ES350	GSV	2007-2018	Sliding Roof	✓	✓	✓		0529	
USA	ES350	GSV	2007-2018	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
USA	ES350	GSV	2007-2018	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	ES350	GSV	2007-2018	Mirror	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0433, 0434, 0435, 0436, 0437	
USA	ES350	GSV	2007-2018	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
USA	ES350	GSV	2007-2018	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	

USA	ES350	GSV	2007-2018	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	ES350	GSV	2007-2018	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	ES350	GSV	2007-2018	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
USA	ES350	GSV	2007-2018	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	ES350	GSV	2007-2018	Navigation System	✓	✓	✓	✓		
USA	ES350	GSV	2007-2018	Telematics	✓	✓	✓	✓		
USA	ES350	GSV	2007-2018	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	ES350	GSV	2007-2018	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
USA	ES350	GSV	2007-2018	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	ES350	GSV	2007-2018	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	ES350	GSV	2007-2018	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	ES350	GSV	2007-2018	Auto Leveling Of Headlamp	✓	✓	✓	✓	0007, SP0008	
USA	ES350	GSV	2007-2018	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	ES350	GSV	2007-2018	Remote Engine Starter	✓	✓	✓	✓		SP0046

USA	ES350	GSV	2007-2018	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	ES350	GSV	2007-2018	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	ES350	GSV	2007-2018	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	ES350	GSV	2007-2018	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
USA	ES350	GSV	2007-2018	Advanced Parking Guidance/Parking Assist Monitor	✓	✓	✓	✓		
USA	ES350	GSV	2007-2018	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086
USA	ES350	GSV	2007-2018	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
USA	ES350	GSV	2007-2018	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	✓	✓	✓	✓		
USA	ES350	GSV	2007-2018	Central Gateway	✓	✓	✓	✓		
USA	ES350	GSV	2007-2018	Radar Cruise 1	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	ES350	GSV	2007-2018	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	SP0061, SP0069



USA	ES350	GSV	2007-2018	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	GS F	URL	2016-2020	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0030, SP0032, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101

USA	GS F	URL	2016-2020	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0072, SP0101
USA	GS F	URL	2016-2020	Cruise Control	✓	✓	✓	✓		

USA	GS F	URL	2016-2020	ABS/VSC/T RAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
USA	GS F	URL	2016-2020	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	GS F	URL	2016-2020	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	GS F	URL	2016-2020	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
USA	GS F	URL	2016-2020	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		
USA	GS F	URL	2016-2020	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086

USA	GS F	URL	2016-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
USA	GS F	URL	2016-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	GS F	URL	2016-2020	TVD	√	√	√	√	0042, 0043	SP0004
USA	GS F	URL	2016-2020	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	GS F	URL	2016-2020	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001

USA	GS F	URL	2016-2020	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
USA	GS F	URL	2016-2020	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	GS F	URL	2016-2020	Central Gateway	√	√	√	√		
USA	GS F	URL	2016-2020	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	GS F	URL	2016-2020	Driver Door Motor	√	√	√		0528	SP0003
USA	GS F	URL	2016-2020	Passenger Door Motor	√	√	√		0528	SP0003
USA	GS F	URL	2016-2020	Left Rear Door Motor	√	√	√		0528	SP0003
USA	GS F	URL	2016-2020	Right Rear Door Motor	√	√	√		0528	SP0003
USA	GS F	URL	2016-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

USA	GS F	URL	2016-2020	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
USA	GS F	URL	2016-2020	Master Switch	✓	✓	✓		
USA	GS F	URL	2016-2020	Sliding Roof	✓	✓	✓		0529
USA	GS F	URL	2016-2020	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
USA	GS F	URL	2016-2020	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
USA	GS F	URL	2016-2020	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051
USA	GS F	URL	2016-2020	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026

USA	GS F	URL	2016-2020	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	GS F	URL	2016-2020	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	GS F	URL	2016-2020	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	GS F	URL	2016-2020	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	GS F	URL	2016-2020	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	GS F	URL	2016-2020	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	GS F	URL	2016-2020	Navigation System	✓	✓	✓	✓		
USA	GS F	URL	2016-2020	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	GS F	URL	2016-2020	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	GS F	URL	2016-2020	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071

USA	GS F	URL	2016-2020	Slave Blind Spot Monitor	✓	✓	✓	✓		
USA	GS F	URL	2016-2020	ASC	✓	✓	✓	✓	1182	
USA	GS F	URL	2016-2020	Telematics	✓	✓	✓	✓		
USA	GS F	URL	2016-2020	Radar Cruise	✓	✓	✓	✓		
USA	GS F	URL	2016-2020	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
USA	GS F	URL	2016-2020	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	



USA	GS200t	***	2016-2017	Engine	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	SP0004, SP0026, SP0032, SP0042, SP0073, SP0075, SP0101, SP0102
-----	--------	-----	-----------	--------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------

USA	GS200t	***	2016-2017	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
USA	GS200t	***	2016-2017	Cruise Control	✓	✓	✓	✓		
USA	GS200t	***	2016-2017	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

USA	GS200t	***	2016-2017	ABS/VSC/T RAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
USA	GS200t	***	2016-2017	Tire Pressure Monitor	√	√	√			SP0001, SP0002
USA	GS200t	***	2016-2017	EMPS	√	√	√	√		SP0001, SP0009, SP0010
USA	GS200t	***	2016-2017	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
USA	GS200t	***	2016-2017	Advanced Parking Guidance/Parking Assist Monitor	√	√	√	√		
USA	GS200t	***	2016-2017	Front Recognition Camera	√	√	√	√	0052	SP0086

USA	GS200t	***	2016-2017	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
USA	GS200t	***	2016-2017	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	GS200t	***	2016-2017	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	GS200t	***	2016-2017	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001
USA	GS200t	***	2016-2017	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

USA	GS200t	***	2016-2017	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	GS200t	***	2016-2017	Central Gateway	√	√	√	√		
USA	GS200t	***	2016-2017	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	GS200t	***	2016-2017	Driver Door Motor	√	√	√		0528	SP0003
USA	GS200t	***	2016-2017	Passenger Door Motor	√	√	√		0528	SP0003
USA	GS200t	***	2016-2017	Left Rear Door Motor	√	√	√		0528	SP0003
USA	GS200t	***	2016-2017	Right Rear Door Motor	√	√	√		0528	SP0003
USA	GS200t	***	2016-2017	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

USA	GS200t	***	2016-2017	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
USA	GS200t	***	2016-2017	Master Switch	✓	✓	✓		
USA	GS200t	***	2016-2017	Sliding Roof	✓	✓	✓		0529
USA	GS200t	***	2016-2017	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
USA	GS200t	***	2016-2017	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
USA	GS200t	***	2016-2017	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051
USA	GS200t	***	2016-2017	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026

USA	GS200t	***	2016-2017	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	GS200t	***	2016-2017	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	GS200t	***	2016-2017	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	GS200t	***	2016-2017	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	GS200t	***	2016-2017	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	GS200t	***	2016-2017	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	GS200t	***	2016-2017	Navigation System	✓	✓	✓	✓		
USA	GS200t	***	2016-2017	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	GS200t	***	2016-2017	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	GS200t	***	2016-2017	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071

USA	GS200t	***	2016-2017	Slave Blind Spot Monitor	√	√	√	√			
USA	GS200t	***	2016-2017	Telematics	√	√	√	√			
USA	GS200t	***	2016-2017	Radar Cruise	√	√	√	√			
USA	GS300	***	2018-2020	Engine	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,		



USA	GS300	***	2018-2020	Transmission	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
USA	GS300	***	2018-2020	Radar Cruise	√	√	√	√	
USA	GS300	***	2018-2020	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471

USA	GS300	***	2018-2020	ABS/VSC/T RAC/EPB	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	
USA	GS300	***	2018-2020	Tire Pressure Monitor	√	√	√			
USA	GS300	***	2018-2020	EMPS	√	√	√	√		
USA	GS300	***	2018-2020	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
USA	GS300	***	2018-2020	Advanced Parking Guidance/ Parking Assist Monitor	√	√	√	√		
USA	GS300	***	2018-2020	Front Recognition Camera	√	√	√	√	0052	

USA	GS300	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824
USA	GS300	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√	
USA	GS300	***	2018-2020	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615
USA	GS300	***	2018-2020	Supplement Restraint System (SRS) Airbag	√	√	√	√	
USA	GS300	***	2018-2020	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298

USA	GS300	***	2018-2020	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
USA	GS300	***	2018-2020	Central Gateway	√	√	√	√		
USA	GS300	***	2018-2020	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	GS300	***	2018-2020	Driver Door Motor	√	√	√		0528	
USA	GS300	***	2018-2020	Passenger Door Motor	√	√	√		0528	
USA	GS300	***	2018-2020	Left Rear Door Motor	√	√	√		0528	
USA	GS300	***	2018-2020	Right Rear Door Motor	√	√	√		0528	
USA	GS300	***	2018-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	GS300	***	2018-2020	Master Switch	√	√	√			
USA	GS300	***	2018-2020	Sliding Roof	√	√	√		0529	

USA	GS300	***	2018-2020	Tilt&Telescopic	√	√	√	√	0472, 0473	
USA	GS300	***	2018-2020	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	GS300	***	2018-2020	Head Up Display	√	√	√	√	0047, 0048, 0049, 0050, 0051	
USA	GS300	***	2018-2020	Intuitive Parking Assist	√	√	√	√	0023, 0024, 0025, 0026	
USA	GS300	***	2018-2020	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	

USA	GS300	***	2018-2020	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
USA	GS300	***	2018-2020	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	GS300	***	2018-2020	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
USA	GS300	***	2018-2020	Detection Of Occupant	✓	✓	✓			
USA	GS300	***	2018-2020	Remote Engine Starter	✓	✓	✓	✓		
USA	GS300	***	2018-2020	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	GS300	***	2018-2020	Navigation System	✓	✓	✓	✓		
USA	GS300	***	2018-2020	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	GS300	***	2018-2020	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	GS300	***	2018-2020	Master Blind Spot Monitor	✓	✓	✓	✓		
USA	GS300	***	2018-2020	Slave Blind Spot Monitor	✓	✓	✓	✓		
USA	GS300	***	2018-2020	Telematics	✓	✓	✓	✓		

USA	GS300	***	2018-2020	Cruise Control	√	√	√	√		
USA	GS300	GRS	2006	Engine	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0032, SP0101

USA	GS300	GRS	2006	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0101
USA	GS300	GRS	2006	Cruise Control	✓	✓	✓	✓		
USA	GS300	GRS	2006	EMS	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001



USA	GS300	GRS	2006	ABS/VSC/TRAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0175
USA	GS300	GRS	2006	4-Wheel Drive (4WD)	√	√	√	√	0819, 0820, 0821, 0822	SP0003, SP0052
USA	GS300	GRS	2006	Tire Pressure Monitor	√	√	√			SP0001, SP0002
USA	GS300	GRS	2006	EMPS	√	√	√	√		SP0001, SP0009, SP0010
USA	GS300	GRS	2006	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017

USA	GS300	GRS	2006	Supplement Restraint System (SRS) Airbag	✓	✓	✓		SP0001
USA	GS300	GRS	2006	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
USA	GS300	GRS	2006	Gateway	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	

USA	GS300	GRS	2006	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967
USA	GS300	GRS	2006	Body No. 4	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

USA	GS300	GRS	2006	Body No. 5					0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	GS300	GRS	2006	Driver Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS300	GRS	2006	Passenger Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS300	GRS	2006	Left Rear Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS300	GRS	2006	Right Rear Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS300	GRS	2006	Driver Seat			✓		0422, 0423, 0424, 0515, 0516, 0517	

USA	GS300	GRS	2006	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
USA	GS300	GRS	2006	Master Switch			√		0939, 0940, 0941, 0942	
USA	GS300	GRS	2006	Driver Seat Switch			√			
USA	GS300	GRS	2006	Sliding Roof			√		0529	
USA	GS300	GRS	2006	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
USA	GS300	GRS	2006	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
USA	GS300	GRS	2006	Combination Switch			√			
USA	GS300	GRS	2006	Intuitive Parking Assist	√	√	√		0023, 0024	SP0006
USA	GS300	GRS	2006	Rain Sensor			√			
USA	GS300	GRS	2006	AFS	√	√	√		0008, 0475, 0476, 0477, 0968	

USA	GS300	GRS	2006	Smart Access	✓	✓	✓		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015, SP0168
USA	GS300	GRS	2006	Power Source Control	✓	✓	✓		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
USA	GS300	GRS	2006	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
USA	GS300	GRS	2006	Pre-Collision	✓	✓	✓		0348, 0349, 0350	
USA	GS300	JZS	1996-2005	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004, SP0026
USA	GS300	JZS	1996-2005	Cruise Control	✓	✓	✓	✓		

USA	GS300	JZS	1996-2005	ABS/VSC/TRAC	✓	✓	✓	✓	0821, 0822, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1083, 1096, 1098, 1099, 1101, 1102, 1104, 1105, 1106, 1117, 1118, 1121, 1122, 1123, 1124, 1125, 1538, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561,	SP0001, SP0003, SP0021, SP0023
USA	GS300	JZS	1996-2005	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
USA	GS300	JZS	1996-2005	Immobilizer	✓	✓	✓			SP0065, SP0066, SP0148
USA	GS300	JZS	1996-2005	Supplement Restraint System (SRS) Airbag	✓	✓				SP0004

USA	GS300	JZS	1996-2005	Body	✓	✓	✓	0031, 0032, 0319, 0333, 0337, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0922, 0923, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020
USA	GS300	JZS	1996-2005	Body No. 2			✓	0031, 0032, 0319, 0333, 0337, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	
USA	GS300	JZS	1996-2005	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS300	JZS	1996-2005	Passenger Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS300	JZS	1996-2005	Left Rear Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	



USA	GS300	JZS	1996-2005	Right Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS300	JZS	1996-2005	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
USA	GS300	JZS	1996-2005	Sliding Roof			√	0529	
USA	GS300	JZS	1996-2005	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005
USA	GS300	JZS	1996-2005	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	

USA	GS350	***	2016- 2020	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	SP0004, SP0 026, SP0032 , SP0042, SP 0073, SP007 5, SP0101, S P0102
-----	-------	-----	---------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------

USA	GS350	***	2016-2020	Transmission	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
USA	GS350	***	2016-2020	Cruise Control	√	√	√	√		
USA	GS350	***	2016-2020	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

USA	GS350	***	2016-2020	ABS/VSC/T RAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
USA	GS350	***	2016-2020	4-Wheel Drive (4WD)	√	√	√	√	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
USA	GS350	***	2016-2020	Tire Pressure Monitor	√	√	√			SP0001, SP0002
USA	GS350	***	2016-2020	EMPS	√	√	√	√		SP0001, SP0009, SP0010
USA	GS350	***	2016-2020	VGRS	√	√	√	√		SP0004, SP0037
USA	GS350	***	2016-2020	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004

USA	GS350	***	2016-2020	Advanced Parking Guidance/Parking Assist Monitor	✓	✓	✓	✓		
USA	GS350	***	2016-2020	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086
USA	GS350	***	2016-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
USA	GS350	***	2016-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	✓	✓	✓	✓		
USA	GS350	***	2016-2020	DRS	✓	✓	✓	✓		SP0004, SP0081, SP0082, SP0083

USA	GS350	***	2016-2020	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	GS350	***	2016-2020	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001
USA	GS350	***	2016-2020	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

USA	GS350	***	2016-2020	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	GS350	***	2016-2020	Central Gateway	√	√	√	√		
USA	GS350	***	2016-2020	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	GS350	***	2016-2020	Driver Door Motor	√	√	√		0528	SP0003
USA	GS350	***	2016-2020	Passenger Door Motor	√	√	√		0528	SP0003
USA	GS350	***	2016-2020	Left Rear Door Motor	√	√	√		0528	SP0003
USA	GS350	***	2016-2020	Right Rear Door Motor	√	√	√		0528	SP0003
USA	GS350	***	2016-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

USA	GS350	***	2016-2020	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	GS350	***	2016-2020	Master Switch	✓	✓	✓			
USA	GS350	***	2016-2020	Sliding Roof	✓	✓	✓		0529	
USA	GS350	***	2016-2020	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
USA	GS350	***	2016-2020	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	GS350	***	2016-2020	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
USA	GS350	***	2016-2020	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	



USA	GS350	***	2016-2020	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	GS350	***	2016-2020	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	GS350	***	2016-2020	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	GS350	***	2016-2020	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	GS350	***	2016-2020	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	GS350	***	2016-2020	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	GS350	***	2016-2020	Navigation System	✓	✓	✓	✓		
USA	GS350	***	2016-2020	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	GS350	***	2016-2020	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	GS350	***	2016-2020	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071

USA	GS350	***	2016-2020	Slave Blind Spot Monitor	✓	✓	✓	✓		
USA	GS350	***	2016-2020	Telematics	✓	✓	✓	✓		
USA	GS350	***	2016-2020	Radar Cruise	✓	✓	✓	✓		
USA	GS350	***	2016-2020	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
USA	GS350	GRL	2013-2015	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
USA	GS350	GRL	2013-2015	Cruise Control	✓	✓	✓	✓		

USA	GS350	GRL	2013-2015	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
USA	GS350	GRL	2013-2015	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084, SP0175
USA	GS350	GRL	2013-2015	4-Wheel Drive (4WD)	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
USA	GS350	GRL	2013-2015	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	GS350	GRL	2013-2015	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010

USA	GS350	GRL	2013-2015	VGRS	√	√	√	√		SP0004, SP0037
USA	GS350	GRL	2013-2015	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
USA	GS350	GRL	2013-2015	DRS	√	√	√	√		SP0004, SP0081, SP0082, SP0083
USA	GS350	GRL	2013-2015	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	GS350	GRL	2013-2015	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001

USA	GS350	GRL	2013-2015	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	GS350	GRL	2013-2015	Gateway Controller Area Network (CAN)	√	√	√	√		SP0005
USA	GS350	GRL	2013-2015	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	GS350	GRL	2013-2015	Driver Door Motor	√	√	√		0528	SP0003
USA	GS350	GRL	2013-2015	Passenger Door Motor	√	√	√		0528	SP0003
USA	GS350	GRL	2013-2015	Left Rear Door Motor	√	√	√		0528	SP0003
USA	GS350	GRL	2013-2015	Right Rear Door Motor	√	√	√		0528	SP0003
USA	GS350	GRL	2013-2015	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

USA	GS350	GRL	2013-2015	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	GS350	GRL	2013-2015	Master Switch	✓	✓	✓			
USA	GS350	GRL	2013-2015	Sliding Roof	✓	✓	✓		0529	
USA	GS350	GRL	2013-2015	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
USA	GS350	GRL	2013-2015	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	GS350	GRL	2013-2015	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	

USA	GS350	GRL	2013-2015	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	GS350	GRL	2013-2015	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	GS350	GRL	2013-2015	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	GS350	GRL	2013-2015	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	GS350	GRL	2013-2015	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274	
USA	GS350	GRL	2013-2015	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	GS350	GRL	2013-2015	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	GS350	GRL	2013-2015	Navigation System	✓	✓	✓	✓		
USA	GS350	GRL	2013-2015	Multi Bus Gateway	✓	✓	✓	✓		
USA	GS350	GRL	2013-2015	No. 1 Multi Bus Monitor	✓	✓	✓	✓		
USA	GS350	GRL	2013-2015	No. 2 Multi Bus Monitor	✓	✓	✓	✓		
USA	GS350	GRL	2013-2015	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

USA	GS350	GRL	2013-2015	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	GS350	GRL	2013-2015	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	GS350	GRL	2013-2015	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	GS350	GRL	2013-2015	Telematics	✓	✓	✓	✓		
USA	GS350	GRL	2013-2015	Radar Cruise	✓	✓	✓	✓		
USA	GS350	GRL	2013-2015	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038, SP0039
USA	GS350	GRL	2013-2015	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	GS350	GRL	2013-2015	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044



USA	GS350	GRL	2013-2015	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0030, SP0032, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
-----	-------	-----	-----------	--------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------

USA	GS350	GRL	2013-2015	ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0072, SP0101
USA	GS350	GRL	2013-2015	Advanced Parking Guidance/ Parking Assist Monitor	√	√	√	√		

USA	GS350	GRS	2007-2012	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0030, SP0032, SP0042, SP0101
-----	-------	-----	-----------	--------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------

USA	GS350	GRS	2007-2012	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0101
USA	GS350	GRS	2007-2012	Cruise Control	✓	✓	✓	✓		
USA	GS350	GRS	2007-2012	EMS	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001

USA	GS350	GRS	2007-2012	ABS/VSC/TRAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0175
USA	GS350	GRS	2007-2012	4-Wheel Drive (4WD)	√	√	√	√	0819, 0820, 0821, 0822	SP0003, SP0052
USA	GS350	GRS	2007-2012	Tire Pressure Monitor	√	√	√			SP0001, SP0002
USA	GS350	GRS	2007-2012	EMPS	√	√	√	√		SP0001, SP0009, SP0010
USA	GS350	GRS	2007-2012	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017

USA	GS350	GRS	2007-2012	Supplement Restraint System (SRS) Airbag	✓	✓	✓			SP0001	
USA	GS350	GRS	2007-2012	Body	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969		SP0005
USA	GS350	GRS	2007-2012	Body Electronic Area Network (BEAN) Gateway	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935		
USA	GS350	GRS	2007-2012	Gateway Controller Area Network (CAN)	✓	✓	✓	✓			SP0005

USA	GS350	GRS	2007-2012	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967
USA	GS350	GRS	2007-2012	Body No. 4	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

USA	GS350	GRS	2007-2012	Body No. 5					0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	GS350	GRS	2007-2012	Driver Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS350	GRS	2007-2012	Passenger Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS350	GRS	2007-2012	Left Rear Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS350	GRS	2007-2012	Right Rear Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS350	GRS	2007-2012	Driver Seat			✓		0422, 0423, 0424, 0515, 0516, 0517	



USA	GS350	GRS	2007-2012	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
USA	GS350	GRS	2007-2012	Master Switch			√		0939, 0940, 0941, 0942	
USA	GS350	GRS	2007-2012	Driver Seat Switch			√			
USA	GS350	GRS	2007-2012	Sliding Roof			√		0529	
USA	GS350	GRS	2007-2012	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
USA	GS350	GRS	2007-2012	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
USA	GS350	GRS	2007-2012	Combination Switch			√			
USA	GS350	GRS	2007-2012	Intuitive Parking Assist	√	√	√		0023, 0024	SP0006
USA	GS350	GRS	2007-2012	Rain Sensor			√			
USA	GS350	GRS	2007-2012	AFS	√	√	√		0008, 0475, 0476, 0477, 0968	

USA	GS350	GRS	2007-2012	Smart Access	√	√	√		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015, SP0168
USA	GS350	GRS	2007-2012	Power Source Control	√	√	√		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
USA	GS350	GRS	2007-2012	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
USA	GS350	GRS	2007-2012	Radar Cruise	√	√	√	√		SP0061, SP0062
USA	GS350	GRS	2007-2012	Pre-Collision	√	√	√	√	0347, 0348, 0349, 0350	
USA	GS350	GRS	2007-2012	Stabilizer	√	√	√			SP0063
USA	GS350	GRS	2007-2012	VGRS	√	√	√	√		SP0001, SP0009, SP0037
USA	GS350	GRS	2007-2012	Telematics	√	√	√	√		
USA	GS350	GRS	2007-2012	Advanced Parking Guidance/ Parking Assist Monitor	√	√	√	√		
USA	GS350	GRS	2007-2012	Navigation System	√	√	√	√		
USA	GS350	GRS	2007-2012	Accessory Gateway	√	√	√	√		SP0005

USA	GS400	UZS	1998-2000	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004
USA	GS400	UZS	1998-2000	Cruise Control	✓	✓	✓	✓		

USA	GS400	UZS	1998-2000	ABS/VSC/TRAC	✓	✓	✓	✓	0821, 0822, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1083, 1096, 1098, 1099, 1101, 1102, 1104, 1105, 1106, 1117, 1118, 1121, 1122, 1123, 1124, 1125, 1538, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561,	SP0001, SP0003, SP0021, SP0023
USA	GS400	UZS	1998-2000	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
USA	GS400	UZS	1998-2000	Immobiliser	✓	✓	✓			SP0065, SP0066, SP0148
USA	GS400	UZS	1998-2000	Supplement Restraint System (SRS) Airbag	✓	✓				SP0004

USA	GS400	UZS	1998-2000	Body	✓	✓	✓	0031, 0032, 0319, 0333, 0337, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0922, 0923, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020
USA	GS400	UZS	1998-2000	Body No. 2			✓	0031, 0032, 0319, 0333, 0337, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	
USA	GS400	UZS	1998-2000	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS400	UZS	1998-2000	Passenger Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS400	UZS	1998-2000	Left Rear Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	

USA	GS400	UZS	1998-2000	Right Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS400	UZS	1998-2000	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
USA	GS400	UZS	1998-2000	Sliding Roof			√	0529	
USA	GS400	UZS	1998-2000	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005
USA	GS400	UZS	1998-2000	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	

USA	GS430	UZS	2001- 2007	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0096, 0 097, 0098, 00 99, 0100, 010 1, 0102, 0103 , 0104, 0105, 0106, 0107, 0 108, 0109, 01 10, 0111, 011 2, 0113, 0114 , 0115, 0116, 0117, 0118, 0 119, 0120, 01 21, 0122, 012 3, 0124, 0125 , 0126, 0127, 0128, 0129, 0 130, 0131, 01 32, 0133, 013 4, 0135, 0136 , 0137, 0138, 0139, 0140, 0 141, 0142, 01 43, 0144, 014 5, 0146, 0147 , 0148, 0149,	SP0004, SP0 026, SP0032 , SP0101
-----	-------	-----	---------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------

USA	GS430	UZS	2001-2007	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0101
USA	GS430	UZS	2001-2007	Cruise Control	✓	✓	✓	✓		
USA	GS430	UZS	2001-2007	EMS	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001



USA	GS430	UZS	2001-2007	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0175
USA	GS430	UZS	2001-2007	4-Wheel Drive (4WD)	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052
USA	GS430	UZS	2001-2007	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	GS430	UZS	2001-2007	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	GS430	UZS	2001-2007	VGRS	✓	✓	✓	✓		SP0001, SP0009, SP0037
USA	GS430	UZS	2001-2007	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017

USA	GS430	UZS	2001-2007	Supplement Restraint System (SRS) Airbag	✓	✓	✓		SP0001, SP0004
USA	GS430	UZS	2001-2007	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020
USA	GS430	UZS	2001-2007	Gateway	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	

USA	GS430	UZS	2001-2007	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967
USA	GS430	UZS	2001-2007	Body No. 4	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

USA	GS430	UZS	2001-2007	Body No. 5					0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	GS430	UZS	2001-2007	Driver Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS430	UZS	2001-2007	Passenger Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS430	UZS	2001-2007	Left Rear Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS430	UZS	2001-2007	Right Rear Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS430	UZS	2001-2007	Driver Seat			✓		0422, 0423, 0424, 0515, 0516, 0517	

USA	GS430	UZS	2001-2007	Passenger Seat			✓		0422, 0423, 0424, 0515, 0516, 0517	
USA	GS430	UZS	2001-2007	Master Switch			✓		0939, 0940, 0941, 0942	
USA	GS430	UZS	2001-2007	Driver Seat Switch			✓			
USA	GS430	UZS	2001-2007	Sliding Roof			✓		0529	
USA	GS430	UZS	2001-2007	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473, 1005	
USA	GS430	UZS	2001-2007	Combination Meter			✓		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
USA	GS430	UZS	2001-2007	Combination Switch			✓			
USA	GS430	UZS	2001-2007	Intuitive Parking Assist	✓	✓	✓		0023, 0024	SP0006
USA	GS430	UZS	2001-2007	Rain Sensor			✓			
USA	GS430	UZS	2001-2007	AFS	✓	✓	✓		0008, 0475, 0476, 0477, 0968	

USA	GS430	UZS	2001-2007	Smart Access	√	√	√		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015, SP0168
USA	GS430	UZS	2001-2007	Power Source Control	√	√	√		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
USA	GS430	UZS	2001-2007	Radar Cruise	√	√	√	√		SP0061, SP0062
USA	GS430	UZS	2001-2007	Pre-Collision	√	√	√		0348, 0349, 0350	
USA	GS430	UZS	2001-2007	Body Electronic Area Network (BEAN) Gateway	√	√	√		0031, 0032, 00319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	
USA	GS430	UZS	2001-2007	Gateway Controller Area Network (CAN)	√	√	√	√		SP0005
USA	GS430	UZS	2001-2007	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036

USA	GS430	UZS	2001-2007	Engine and ECT	√	√	√	√	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004, SP0026
USA	GS430	UZS	2001-2007	Immobiliser	√	√	√			SP0065, SP0066, SP0148
USA	GS430	UZS	2001-2007	Body No. 2				√	0031, 0032, 0319, 0333, 0337, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	
USA	GS430	UZS	2001-2007	Switch Of Steering Pad				√		

USA	GS450h	GWL	2013-2018	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
USA	GS450h	GWL	2013-2018	Hybrid Control	√	√	√	√	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058
USA	GS450h	GWL	2013-2018	Cruise Control	√	√	√	√		



USA	GS450h	GWL	2013-2018	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
USA	GS450h	GWL	2013-2018	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0175
USA	GS450h	GWL	2013-2018	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	GS450h	GWL	2013-2018	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	GS450h	GWL	2013-2018	VGRS	✓	✓	✓	✓		SP0004, SP0037

USA	GS450h	GWL	2013-2018	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
USA	GS450h	GWL	2013-2018	DRS	√	√	√	√		SP0004, SP0081, SP0082, SP0083
USA	GS450h	GWL	2013-2018	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	GS450h	GWL	2013-2018	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001

USA	GS450h	GWL	2013-2018	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	GS450h	GWL	2013-2018	Gateway	√	√	√	√		SP0005
USA	GS450h	GWL	2013-2018	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	GS450h	GWL	2013-2018	Driver Door Motor	√	√	√		0528	SP0003
USA	GS450h	GWL	2013-2018	Passenger Door Motor	√	√	√		0528	SP0003
USA	GS450h	GWL	2013-2018	Left Rear Door Motor	√	√	√		0528	SP0003
USA	GS450h	GWL	2013-2018	Right Rear Door Motor	√	√	√		0528	SP0003
USA	GS450h	GWL	2013-2018	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

USA	GS450h	GWL	2013-2018	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	GS450h	GWL	2013-2018	Master Switch	✓	✓	✓			
USA	GS450h	GWL	2013-2018	Sliding Roof	✓	✓	✓		0529	
USA	GS450h	GWL	2013-2018	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
USA	GS450h	GWL	2013-2018	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	GS450h	GWL	2013-2018	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	

USA	GS450h	GWL	2013-2018	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	GS450h	GWL	2013-2018	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	GS450h	GWL	2013-2018	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	GS450h	GWL	2013-2018	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	GS450h	GWL	2013-2018	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274	
USA	GS450h	GWL	2013-2018	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	GS450h	GWL	2013-2018	Navigation System	✓	✓	✓	✓		
USA	GS450h	GWL	2013-2018	Multi Bus Gateway	✓	✓	✓	✓		
USA	GS450h	GWL	2013-2018	No. 1 Multi Bus Monitor	✓	✓	✓	✓		
USA	GS450h	GWL	2013-2018	No. 2 Multi Bus Monitor	✓	✓	✓	✓		
USA	GS450h	GWL	2013-2018	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

USA	GS450h	GWL	2013-2018	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	GS450h	GWL	2013-2018	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	GS450h	GWL	2013-2018	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	GS450h	GWL	2013-2018	Telematics	✓	✓	✓	✓		
USA	GS450h	GWL	2013-2018	Radar Cruise	✓	✓	✓	✓		
USA	GS450h	GWL	2013-2018	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038, SP0039
USA	GS450h	GWL	2013-2018	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	GS450h	GWL	2013-2018	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
USA	GS450h	GWL	2013-2018	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
USA	GS450h	GWL	2013-2018	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		
USA	GS450h	GWL	2013-2018	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086
USA	GS450h	GWL	2013-2018	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	

USA	GS450h	GWL	2013-2018	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	✓	✓	✓	✓		
USA	GS450h	GWL	2013-2018	Central Gateway	✓	✓	✓	✓		
USA	GS450h	GWL	2013-2018	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
USA	GS450h	GWL	2013-2018	Auto Leveling Of Headlamp	✓	✓	✓	✓	0001, 0002, 0003, 0004, 0005, 0006, 0007, SP0008	
USA	GS450h	GWL	2013-2018	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	

USA	GS450h	GWS	2007-2012	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0032, SP0076, SP0101
USA	GS450h	GWS	2007-2012	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026
USA	GS450h	GWS	2007-2012	Cruise Control	✓	✓	✓	✓		
USA	GS450h	GWS	2007-2012	EMS	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001
USA	GS450h	GWS	2007-2012	Stabilizer	✓	✓	✓			SP0063



USA	GS450h	GWS	2007-2012	ABS/VSC/T RAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0175
USA	GS450h	GWS	2007-2012	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	GS450h	GWS	2007-2012	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	GS450h	GWS	2007-2012	VGRS	✓	✓	✓	✓		SP0001, SP0009, SP0037
USA	GS450h	GWS	2007-2012	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017

USA	GS450h	GWS	2007-2012	Supplement Restraint System (SRS) Airbag	√	√	√			SP0001
USA	GS450h	GWS	2007-2012	Pre-Collision	√	√	√	√	0347, 0348, 0349, 0350	
USA	GS450h	GWS	2007-2012	Body	√	√	√		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
USA	GS450h	GWS	2007-2012	Gateway	√	√	√		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	
USA	GS450h	GWS	2007-2012	HV Gateway	√	√	√	√		SP0005

USA	GS450h	GWS	2007-2012	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967
USA	GS450h	GWS	2007-2012	Body No. 4	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

USA	GS450h	GWS	2007-2012	Body No. 5			✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967
USA	GS450h	GWS	2007-2012	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
USA	GS450h	GWS	2007-2012	Passenger Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
USA	GS450h	GWS	2007-2012	Left Rear Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
USA	GS450h	GWS	2007-2012	Right Rear Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
USA	GS450h	GWS	2007-2012	Driver Seat			✓	0422, 0423, 0424, 0515, 0516, 0517

USA	GS450h	GWS	2007-2012	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
USA	GS450h	GWS	2007-2012	Master Switch			√		0939, 0940, 0941, 0942	
USA	GS450h	GWS	2007-2012	Driver Seat Switch			√			
USA	GS450h	GWS	2007-2012	Sliding Roof			√		0529	
USA	GS450h	GWS	2007-2012	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
USA	GS450h	GWS	2007-2012	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
USA	GS450h	GWS	2007-2012	Combination Switch			√			
USA	GS450h	GWS	2007-2012	Intuitive Parking Assist	√	√	√		0023, 0024	SP0006
USA	GS450h	GWS	2007-2012	Rain Sensor			√			
USA	GS450h	GWS	2007-2012	AFS	√	√	√		0008, 0475, 0476, 0477, 0968	

USA	GS450h	GWS	2007-2012	Smart Access	√	√	√		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015, SP0168
USA	GS450h	GWS	2007-2012	Power Source Control	√	√	√		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
USA	GS450h	GWS	2007-2012	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
USA	GS450h	GWS	2007-2012	Radar Cruise	√	√	√	√		
USA	GS450h	GWS	2007-2012	Advanced Parking Guidance/ Parking Assist Monitor	√	√	√	√		
USA	GS450h	GWS	2007-2012	Navigation System	√	√	√	√		
USA	GS450h	GWS	2007-2012	Telematics	√	√	√	√		
USA	GS450h	GWS	2007-2012	Accessory Gateway	√	√	√	√		SP0005

USA	GS460	URS	2008-2011	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0030, SP0032, SP0042, SP0101
-----	-------	-----	-----------	--------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------

USA	GS460	URS	2008-2011	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0101
USA	GS460	URS	2008-2011	Cruise Control	✓	✓	✓	✓		
USA	GS460	URS	2008-2011	EMS	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001
USA	GS460	URS	2008-2011	Stabilizer	✓	✓	✓			SP0063



USA	GS460	URS	2008-2011	ABS/VSC/T RAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0175
USA	GS460	URS	2008-2011	4-Wheel Drive (4WD)	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052
USA	GS460	URS	2008-2011	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	GS460	URS	2008-2011	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	GS460	URS	2008-2011	VGRS	✓	✓	✓	✓		SP0001, SP0009, SP0037
USA	GS460	URS	2008-2011	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017

USA	GS460	URS	2008-2011	Supplement Restraint System (SRS) Airbag	✓	✓	✓			SP0001	
USA	GS460	URS	2008-2011	Body	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969		SP0005
USA	GS460	URS	2008-2011	Body Electronic Area Network (BEAN) Gateway	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935		
USA	GS460	URS	2008-2011	Gateway Controller Area Network (CAN)	✓	✓	✓	✓			SP0005

USA	GS460	URS	2008-2011	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967
USA	GS460	URS	2008-2011	Body No. 4	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

USA	GS460	URS	2008-2011	Body No. 5					0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	GS460	URS	2008-2011	Driver Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS460	URS	2008-2011	Passenger Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS460	URS	2008-2011	Left Rear Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS460	URS	2008-2011	Right Rear Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	GS460	URS	2008-2011	Driver Seat			✓		0422, 0423, 0424, 0515, 0516, 0517	

USA	GS460	URS	2008-2011	Passenger Seat			✓		0422, 0423, 0424, 0515, 0516, 0517	
USA	GS460	URS	2008-2011	Master Switch			✓		0939, 0940, 0941, 0942	
USA	GS460	URS	2008-2011	Driver Seat Switch			✓			
USA	GS460	URS	2008-2011	Sliding Roof			✓		0529	
USA	GS460	URS	2008-2011	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473, 1005	
USA	GS460	URS	2008-2011	Combination Meter			✓		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
USA	GS460	URS	2008-2011	Combination Switch			✓			
USA	GS460	URS	2008-2011	Intuitive Parking Assist	✓	✓	✓		0023, 0024	SP0006
USA	GS460	URS	2008-2011	Rain Sensor			✓			
USA	GS460	URS	2008-2011	AFS	✓	✓	✓		0008, 0475, 0476, 0477, 0968	

USA	GS460	URS	2008-2011	Smart Access	✓	✓	✓		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015, SP0168
USA	GS460	URS	2008-2011	Power Source Control	✓	✓	✓		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
USA	GS460	URS	2008-2011	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	GS460	URS	2008-2011	Telematics	✓	✓	✓	✓		
USA	GS460	URS	2008-2011	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
USA	GS460	URS	2008-2011	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	GS460	URS	2008-2011	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		
USA	GS460	URS	2008-2011	Navigation System	✓	✓	✓	✓		
USA	GS460	URS	2008-2011	Accessory Gateway	✓	✓	✓	✓		SP0005

USA	GX460	URJ	2010-2020	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0029, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0098, SP0099, SP0100, SP0101, SP0116, SP0161, SP0162
USA	GX460	URJ	2010-2020	Cruise Control	✓	✓	✓	✓		
USA	GX460	URJ	2010-2020	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001
USA	GX460	URJ	2010-2020	KDSS	✓	✓	✓		0554, 0555	

USA	GX460	URJ	2010-2020	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084, SP0149, SP0175
USA	GX460	URJ	2010-2020	Tire Pressure Monitor	✓	✓	✓		SP0001, SP0002	
USA	GX460	URJ	2010-2020	Advanced Parking Guidance/Parking Assist Monitor	✓	✓	✓	✓		



USA	GX460	URJ	2010-2020	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051, SP0169, SP0170, SP0171, SP0172, SP0173
USA	GX460	URJ	2010-2020	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	GX460	URJ	2010-2020	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	GX460	URJ	2010-2020	PM1 Gateway	√	√	√	√		SP0005
USA	GX460	URJ	2010-2020	Driver Door Motor	√	√	√		0528	SP0003
USA	GX460	URJ	2010-2020	Passenger Door Motor	√	√	√		0528	SP0003
USA	GX460	URJ	2010-2020	Left Rear Door Motor	√	√	√		0528	SP0003
USA	GX460	URJ	2010-2020	Right Rear Door Motor	√	√	√		0528	SP0003
USA	GX460	URJ	2010-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	GX460	URJ	2010-2020	Master Switch	√	√	√			
USA	GX460	URJ	2010-2020	Driver Seat Switch			√			
USA	GX460	URJ	2010-2020	Sliding Roof	√	√	√		0529	

USA	GX460	URJ	2010-2020	Tilt&Telescopic	√	√	√	√	0472, 0473	
USA	GX460	URJ	2010-2020	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	SP0174
USA	GX460	URJ	2010-2020	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	GX460	URJ	2010-2020	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	GX460	URJ	2010-2020	Intuitive Parking Assist	√	√	√	√	0023, 0024, 0025, 0026	

USA	GX460	URJ	2010-2020	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	SP0166
USA	GX460	URJ	2010-2020	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0168
USA	GX460	URJ	2010-2020	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	GX460	URJ	2010-2020	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036, SP0176
USA	GX460	URJ	2010-2020	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	GX460	URJ	2010-2020	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0078, SP0079, SP0154, SP0155, SP0163, SP0164, SP0165
USA	GX460	URJ	2010-2020	PM2 Gateway	✓	✓	✓	✓		SP0005
USA	GX460	URJ	2010-2020	Telematics	✓	✓	✓	✓		SP0158, SP0159, SP0160
USA	GX460	URJ	2010-2020	Radar Cruise	✓	✓	✓	✓		
USA	GX460	URJ	2010-2020	Lane Departure Alert (LDA)	✓	✓	✓	✓		SP0038, SP0039
USA	GX460	URJ	2010-2020	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	

USA	GX460	URJ	2010-2020	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
USA	GX460	URJ	2010-2020	Remote Engine Starter	√	√	√	√		SP0046, SP0047, SP0048
USA	GX460	URJ	2010-2020	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071, SP0177, SP0178
USA	GX460	URJ	2010-2020	Slave Blind Spot Monitor	√	√	√	√		SP0070, SP0071, SP0137, SP0179, SP0180, SP0181
USA	GX460	URJ	2010-2020	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0012, SP0014, SP0015, SP0167, SP0168
USA	GX460	URJ	2010-2020		√	√	√	√		
USA	GX460	URJ	2010-2020	Radar Cruise 2	√	√	√	√	0017, 0018	
USA	GX460	URJ	2010-2020	4-Wheel Drive (4WD)	√	√	√	√	0819, 0820, 0821, 0822	
USA	GX460	URJ	2010-2020	Front Recognition Camera	√	√	√	√	0052	
USA	GX460	URJ	2010-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	

USA	GX460	URJ	2010-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	GX460	URJ	2010-2020	Central Gateway	√	√	√	√		
USA	GX460	URJ	2010-2020	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
USA	GX470	UZJ	2003-2009	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0032, SP0076, SP0101
USA	GX470	UZJ	2003-2009	Cruise Control	√	√	√	√		

USA	GX470	UZJ	2003-2009	Air suspension	√	√	√		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001
USA	GX470	UZJ	2003-2009	KDSS	√	√	√		0554, 0555	SP0001, SP0138
USA	GX470	UZJ	2003-2009	ABS/VSC/TRAC	√	√	√	√	0821, 0822, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1083, 1096, 1098, 1099, 1101, 1102, 1104, 1105, 1106, 1117, 1118, 1121, 1122, 1123, 1124, 1125, 1538, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561,	SP0001, SP0003, SP0021, SP0023
USA	GX470	UZJ	2003-2009	Tire Pressure Monitor	√	√	√			SP0001, SP0002
USA	GX470	UZJ	2003-2009	Immobiliser	√	√	√		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066

USA	GX470	UZJ	2003-2009	Theft Deterrent	✓	✓	✓	0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	
USA	GX470	UZJ	2003-2009	Supplement Restraint System (SRS) Airbag	✓	✓			SP0004
USA	GX470	UZJ	2003-2009	Body	✓	✓	✓	0031, 0032, 00319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005, SP0019, SP0020



USA	GX470	UZJ	2003-2009	Body No. 2	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935		
USA	GX470	UZJ	2003-2009	Driver Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991		
USA	GX470	UZJ	2003-2009	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517		
USA	GX470	UZJ	2003-2009	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
USA	GX470	UZJ	2003-2009	Mirror			√	0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980		
USA	GX470	UZJ	2003-2009	Rain Sensor			√			
USA	GX470	UZJ	2003-2009	Wiper			√		0031, 0032, 0332	
USA	GX470	UZJ	2003-2009	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036

USA	HS250h	ANF	2010-2012	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0032, SP0076, SP0101
USA	HS250h	ANF	2010-2012	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026
USA	HS250h	ANF	2010-2012	Cruise Control	✓	✓	✓	✓		

USA	HS250h	ANF	2010-2012	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0088, SP0175
USA	HS250h	ANF	2010-2012	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	HS250h	ANF	2010-2012	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	HS250h	ANF	2010-2012	Advanced Parking Guidance/Parking Assist Monitor	✓	✓	✓	✓		
USA	HS250h	ANF	2010-2012	Transmission Control	✓	✓	✓	✓		

USA	HS250h	ANF	2010-2012	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	HS250h	ANF	2010-2012	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	HS250h	ANF	2010-2012	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	HS250h	ANF	2010-2012	PM1 Gateway	√	√	√	√		SP0005
USA	HS250h	ANF	2010-2012	Driver Door Motor	√	√	√		0528	
USA	HS250h	ANF	2010-2012	Passenger Door Motor	√	√	√		0528	
USA	HS250h	ANF	2010-2012	Left Rear Door Motor	√	√	√		0528	
USA	HS250h	ANF	2010-2012	Right Rear Door Motor	√	√	√		0528	
USA	HS250h	ANF	2010-2012	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	HS250h	ANF	2010-2012	Master Switch	√	√	√			
USA	HS250h	ANF	2010-2012	Sliding Roof	√	√	√		0529	
USA	HS250h	ANF	2010-2012	Tilt&Telescopic	√	√	√	√	0472, 0473	

USA	HS250h	ANF	2010-2012	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
USA	HS250h	ANF	2010-2012	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	HS250h	ANF	2010-2012	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	HS250h	ANF	2010-2012	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026
USA	HS250h	ANF	2010-2012	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493

USA	HS250h	ANF	2010-2012	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0168
USA	HS250h	ANF	2010-2012	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	HS250h	ANF	2010-2012	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036
USA	HS250h	ANF	2010-2012	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	HS250h	ANF	2010-2012	Navigation System	✓	✓	✓	✓		
USA	HS250h	ANF	2010-2012	PM2 Gateway	✓	✓	✓	✓		SP0005
USA	HS250h	ANF	2010-2012	Telematics	✓	✓	✓	✓		
USA	HS250h	ANF	2010-2012	Radar Cruise	✓	✓	✓	✓		
USA	HS250h	ANF	2010-2012	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038, SP0039
USA	HS250h	ANF	2010-2012	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	HS250h	ANF	2010-2012	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

USA	IS F	USE	2008-2014	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0096, 0 097, 0098, 00 99, 0100, 010 1, 0102, 0103 , 0104, 0105, 0106, 0107, 0 108, 0109, 01 10, 0111, 011 2, 0113, 0114 , 0115, 0116, 0117, 0118, 0 119, 0120, 01 21, 0122, 012 3, 0124, 0125 , 0126, 0127, 0128, 0129, 0 130, 0131, 01 32, 0133, 013 4, 0135, 0136 , 0137, 0138, 0139, 0140, 0 141, 0142, 01 43, 0144, 014 5, 0146, 0147 , 0148, 0149,	SP0004, SP0 026, SP0030 , SP0032, SP 0042, SP010 1
-----	------	-----	-----------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------



USA	IS F	USE	2008-2014	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0101
USA	IS F	USE	2008-2014	Cruise Control	✓	✓	✓	✓		

USA	IS F	USE	2008-2014	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0175
USA	IS F	USE	2008-2014	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	IS F	USE	2008-2014	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	IS F	USE	2008-2014	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017

USA	IS F	USE	2008-2014	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
USA	IS F	USE	2008-2014	Body	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
USA	IS F	USE	2008-2014	Gateway	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	

USA	IS F	USE	2008-2014	Body No. 3	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	IS F	USE	2008-2014	Body No. 5			√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	IS F	USE	2008-2014	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
USA	IS F	USE	2008-2014	Passenger Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
USA	IS F	USE	2008-2014	Master Switch			√	0939, 0940, 0941, 0942	
USA	IS F	USE	2008-2014	Sliding Roof			√	0529	
USA	IS F	USE	2008-2014	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005

USA	IS F	USE	2008-2014	Combinati on Meter			√	0274, 0616, 0 617, 0618, 06 19, 0629, 066 2, 0665, 0669 , 0670, 0671, 0672, 0673, 0 675, 0676, 06 77, 0678, 067 9, 0680, 0681 , 0692, 0719, 0745, 0746, 0 749, 0756, 07 60, 0761, 076 2, 0763, 0764 , 0765, 0766, 0767, 0768, 0 769, 0770, 07 71, 0772, 077 3, 0774, 0775 , 0776, 0777, 0778, 0779, 0 780, 0781, 07 82, 1000, 102 9, 1030, 1031 , 1032, 1033, 1034, 1035, 1 036, 1037, 10 38, 1039, 104 0, 1041, 1042 , 1043, 1044,	
USA	IS F	USE	2008-2014	Left Mirror			√	0279, 0280, 0 281, 0282, 02 83	
USA	IS F	USE	2008-2014	Right Mirror			√	0279, 0280, 0 281, 0282, 02 83, 0971, 097 2, 0973, 0974 , 0975, 0976, 0977, 0978, 0 979, 0980	
USA	IS F	USE	2008-2014	Combinati on Switch			√		
USA	IS F	USE	2008-2014	Intuitive Parking Assist	√	√	√	0023, 0024	
USA	IS F	USE	2008-2014	Rain Sensor			√		
USA	IS F	USE	2008-2014	AFS	√	√	√	0008, 0475, 0 476, 0477, 09 68	

USA	IS F	USE	2008-2014	Smart Access	√	√	√		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015, SP0168
USA	IS F	USE	2008-2014	Power Source Control	√	√	√		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
USA	IS F	USE	2008-2014	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
USA	IS F	USE	2008-2014	Radar Cruise	√	√	√	√		SP0061, SP0062
USA	IS F	USE	2008-2014	Pre-Collision	√	√	√	√	0347, 0348, 0349, 0350	
USA	IS F	USE	2008-2014	Advanced Parking Guidance/Parking Assist Monitor	√	√	√	√		
USA	IS F	USE	2008-2014	Navigation System	√	√	√	√		
USA	IS F	USE	2008-2014	Telematics	√	√	√	√		
USA	IS F	USE	2008-2014	Accessory Gateway	√	√	√	√		SP0005

USA	IS200t	***	2016- 2017	Engine	√	√	√	√	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	SP0004, SP0 026, SP0032 , SP0042, SP 0073, SP007 5, SP0101, S P0102
-----	--------	-----	---------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------

USA	IS200t	***	2016-2017	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
USA	IS200t	***	2016-2017	Radar Cruise	✓	✓	✓	✓		



USA	IS200t	***	2016-2017	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
USA	IS200t	***	2016-2017	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	IS200t	***	2016-2017	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	IS200t	***	2016-2017	Advanced Parking Guidance/Parking Assist Monitor	✓	✓	✓	✓		
USA	IS200t	***	2016-2017	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087

USA	IS200t	***	2016-2017	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	IS200t	***	2016-2017	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001
USA	IS200t	***	2016-2017	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

USA	IS200t	***	2016-2017	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	IS200t	***	2016-2017	Gateway	√	√	√	√		SP0005
USA	IS200t	***	2016-2017	Accessory Gateway	√	√	√	√		SP0005
USA	IS200t	***	2016-2017	Driver Door Motor	√	√	√		0528	SP0003
USA	IS200t	***	2016-2017	Passenger Door Motor	√	√	√		0528	SP0003
USA	IS200t	***	2016-2017	Left Rear Door Motor	√	√	√		0528	SP0003
USA	IS200t	***	2016-2017	Right Rear Door Motor	√	√	√		0528	SP0003
USA	IS200t	***	2016-2017	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	IS200t	***	2016-2017	Master Switch	√	√	√			
USA	IS200t	***	2016-2017	Sliding Roof	√	√	√		0529	
USA	IS200t	***	2016-2017	Tilt&Telescopic	√	√	√	√	0472, 0473	

USA	IS200t	***	2016-2017	Combinati on Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	IS200t	***	2016-2017	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	IS200t	***	2016-2017	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	IS200t	***	2016-2017	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
USA	IS200t	***	2016-2017	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, SP0008	

USA	IS200t	***	2016-2017	Smart Key	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	IS200t	***	2016-2017	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	IS200t	***	2016-2017	Detection Of Occupant	√	√	√	√		SP0034, SP0035, SP0036
USA	IS200t	***	2016-2017	Remote Engine Starter	√	√	√	√		SP0046
USA	IS200t	***	2016-2017	Starting Control	√	√	√	√	0256, 0257	
USA	IS200t	***	2016-2017	Navigation System	√	√	√	√		
USA	IS200t	***	2016-2017	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071
USA	IS200t	***	2016-2017	Slave Blind Spot Monitor	√	√	√	√		
USA	IS200t	***	2016-2017	Telematics	√	√	√	√		
USA	IS200t	***	2016-2017	Cruise Control	√	√	√	√		
USA	IS200t	***	2016-2017	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	

USA	IS200t	***	2016-2017	Front Recognition Camera	√	√	√	√	0052	
USA	IS200t	***	2016-2017	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
USA	IS200t	***	2016-2017	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	IS200t	***	2016-2017	Central Gateway	√	√	√	√		
USA	IS200t	***	2016-2017	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	IS200t	***	2016-2017	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	IS200t	***	2016-2017	ASC	√	√	√	√	1182	

USA	IS250	GSE	2006-2015	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0030, SP0032, SP0042, SP0101
-----	-------	-----	-----------	--------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------

USA	IS250	GSE	2006-2015	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0101
USA	IS250	GSE	2006-2015	Cruise Control	✓	✓	✓	✓		



USA	IS250	GSE	2006-2015	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084, SP0175
USA	IS250	GSE	2006-2015	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	IS250	GSE	2006-2015	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010

USA	IS250	GSE	2006-2015	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019,	SP0016, SP0017
USA	IS250	GSE	2006-2015	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	IS250	GSE	2006-2015	Body	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
USA	IS250	GSE	2006-2015	Gateway	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	SP0005

USA	IS250	GSE	2006-2015	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	IS250	GSE	2006-2015	Body No. 5			✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	IS250	GSE	2006-2015	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
USA	IS250	GSE	2006-2015	Passenger Seat			✓		0422, 0423, 0424, 0515, 0516, 0517
USA	IS250	GSE	2006-2015	Master Switch	✓	✓	✓		0939, 0940, 0941, 0942
USA	IS250	GSE	2006-2015	Sliding Roof	✓	✓	✓		0529
USA	IS250	GSE	2006-2015	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473, 1005

USA	IS250	GSE	2006-2015	Combinati on Meter	√	√	√	√	0274, 0398, 0 616, 0617, 06 18, 0619, 062 0, 0621, 0622 , 0623, 0624, 0625, 0626, 0 627, 0628, 06 29, 0630, 063 1, 0632, 0633 , 0634, 0635, 0636, 0637, 0 638, 0639, 06 40, 0641, 064 2, 0643, 0644 , 0645, 0646, 0647, 0648, 0 649, 0650, 06 51, 0652, 065 3, 0654, 0655 , 0656, 0657, 0658, 0659, 0 660, 0661, 06 62, 0663, 066 4, 0665, 0666 , 0667, 0668, 0669, 0670, 0 671, 0672, 06 73, 0674, 067 5, 0676, 0677 , 0678, 0679,	
USA	IS250	GSE	2006-2015	Left Mirror	√	√	√	√	0275, 0276, 0 277, 0278, 02 79, 0280, 028 1, 0282, 0283 , 0284	
USA	IS250	GSE	2006-2015	Right Mirror	√	√	√	√	0275, 0276, 0 277, 0278, 02 79, 0280, 028 1, 0282, 0283 , 0284, 0971, 0972, 0973, 0 974, 0975, 09 76, 0977, 097 8, 0979, 0980	
USA	IS250	GSE	2006-2015	Combinati on Switch			√			
USA	IS250	GSE	2006-2015	Intuitive Parking Assist	√	√	√	√	0023, 0024, 0 025, 0026	
USA	IS250	GSE	2006-2015	Rain Sensor			√			
USA	IS250	GSE	2006-2015	AFS	√	√	√		0008, 0475, 0 476, 0477, 09 68	

USA	IS250	GSE	2006-2015	Smart Access	✓	✓	✓		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015, SP0168
USA	IS250	GSE	2006-2015	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	SP0045
USA	IS250	GSE	2006-2015	4-Wheel Drive (4WD)	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
USA	IS250	GSE	2006-2015	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
USA	IS250	GSE	2006-2015	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	IS250	GSE	2006-2015	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	IS250	GSE	2006-2015	Telematics	✓	✓	✓	✓		
USA	IS250	GSE	2006-2015	Advanced Parking Guidance/Parking Assist Monitor	✓	✓	✓	✓		
USA	IS250	GSE	2006-2015	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0078, SP0079, SP0154, SP0155, SP0163, SP0164, SP0165

USA	IS250	GSE	2006-2015	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
USA	IS250	GSE	2006-2015	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
USA	IS250	GSE	2006-2015	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087

USA	IS250	GSE	2006-2015	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	IS250	GSE	2006-2015	Accessory Gateway	✓	✓	✓	✓		SP0005
USA	IS250	GSE	2006-2015	Driver Door Motor	✓	✓	✓		0528	SP0003
USA	IS250	GSE	2006-2015	Passenger Door Motor	✓	✓	✓		0528	SP0003
USA	IS250	GSE	2006-2015	Left Rear Door Motor	✓	✓	✓		0528	SP0003
USA	IS250	GSE	2006-2015	Right Rear Door Motor	✓	✓	✓		0528	SP0003
USA	IS250	GSE	2006-2015	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, SP0008	



USA	IS250	GSE	2006-2015	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	IS250	GSE	2006-2015	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	IS250	GSE	2006-2015	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	IS250	GSE	2006-2015	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	IS250	GSE	2006-2015	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	IS250	GSE	2006-2015	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

USA	IS250C	GSE	2010-2015	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0030, SP0032, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
-----	--------	-----	-----------	--------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------

USA	IS250C	GSE	2010-2015	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0072, SP0101
USA	IS250C	GSE	2010-2015	Cruise Control	✓	✓	✓	✓		

USA	IS250C	GSE	2010-2015	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084, SP0175
USA	IS250C	GSE	2010-2015	Tire Pressure Monitor	✓	✓	✓		SP0001, SP0002	
USA	IS250C	GSE	2010-2015	EMPS	✓	✓	✓	✓	SP0001, SP0009, SP0010	
USA	IS250C	GSE	2010-2015	Advanced Parking Guidance/Parking Assist Monitor	✓	✓	✓	✓		

USA	IS250C	GSE	2010-2015	Air Conditioner	✓	✓	✓	0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017
USA	IS250C	GSE	2010-2015	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓	SP0001
USA	IS250C	GSE	2010-2015	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005

USA	IS250C	GSE	2010-2015	Gateway	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935
USA	IS250C	GSE	2010-2015	Body No. 3	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

USA	IS250C	GSE	2010-2015	Body No. 5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	IS250C	GSE	2010-2015	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
USA	IS250C	GSE	2010-2015	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
USA	IS250C	GSE	2010-2015	Master Switch			√		0939, 0940, 0941, 0942	
USA	IS250C	GSE	2010-2015	P Master Switch			√		0941	
USA	IS250C	GSE	2010-2015	Hardtop Retractable	√	√	√		0970	
USA	IS250C	GSE	2010-2015	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	

USA	IS250C	GSE	2010-2015	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
USA	IS250C	GSE	2010-2015	Left Mirror			√	0279, 0280, 0281, 0282, 0283	
USA	IS250C	GSE	2010-2015	Right Mirror			√	0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
USA	IS250C	GSE	2010-2015	Combination Switch			√		
USA	IS250C	GSE	2010-2015	Intuitive Parking Assist	√	√	√	0023, 0024	
USA	IS250C	GSE	2010-2015	Rain Sensor			√		
USA	IS250C	GSE	2010-2015	AFS	√	√	√	0008, 0475, 0476, 0477, 0968	



USA	IS250C	GSE	2010-2015	Smart Access	√	√	√		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015, SP0168
USA	IS250C	GSE	2010-2015	Power Source Control	√	√	√		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
USA	IS250C	GSE	2010-2015	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
USA	IS250C	GSE	2010-2015	Navigation System	√	√	√	√		
USA	IS250C	GSE	2010-2015	Telematics	√	√	√	√		
USA	IS250C	GSE	2010-2015	Radar Cruise	√	√	√	√		
USA	IS250C	GSE	2010-2015	Pre-Collision	√	√	√	√	0347, 0348, 0349, 0350	
USA	IS300	***	2018-2020	Engine	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	

USA	IS300	***	2018-2020	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
USA	IS300	***	2018-2020	Radar Cruise	✓	✓	✓	✓	
USA	IS300	***	2018-2020	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471

USA	IS300	***	2018-2020	ABS/VSC/T RAC/EPB	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	
USA	IS300	***	2018-2020	Tire Pressure Monitor	√	√	√			
USA	IS300	***	2018-2020	EMPS	√	√	√	√		
USA	IS300	***	2018-2020	Advanced Parking Guidance/ Parking Assist Monitor	√	√	√	√		
USA	IS300	***	2018-2020	Front Recognition Camera	√	√	√	√	0052	
USA	IS300	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	

USA	IS300	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	IS300	***	2018-2020	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
USA	IS300	***	2018-2020	Supplement Restraint System (SRS) Airbag	√	√	√	√		
USA	IS300	***	2018-2020	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	

USA	IS300	***	2018-2020	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
USA	IS300	***	2018-2020	Accessory Gateway	√	√	√	√		
USA	IS300	***	2018-2020	Central Gateway	√	√	√	√		
USA	IS300	***	2018-2020	Driver Door Motor	√	√	√		0528	
USA	IS300	***	2018-2020	Passenger Door Motor	√	√	√		0528	
USA	IS300	***	2018-2020	Left Rear Door Motor	√	√	√		0528	
USA	IS300	***	2018-2020	Right Rear Door Motor	√	√	√		0528	
USA	IS300	***	2018-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	IS300	***	2018-2020	Master Switch	√	√	√			
USA	IS300	***	2018-2020	Sliding Roof	√	√	√		0529	
USA	IS300	***	2018-2020	Tilt&Telescopic	√	√	√	√	0472, 0473	

USA	IS300	***	2018-2020	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
USA	IS300	***	2018-2020	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	IS300	***	2018-2020	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	IS300	***	2018-2020	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026
USA	IS300	***	2018-2020	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493

USA	IS300	***	2018-2020	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
USA	IS300	***	2018-2020	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	IS300	***	2018-2020	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	
USA	IS300	***	2018-2020	Detection Of Occupant	√	√	√			
USA	IS300	***	2018-2020	Remote Engine Starter	√	√	√	√		
USA	IS300	***	2018-2020	Starting Control	√	√	√	√	0256, 0257	
USA	IS300	***	2018-2020	Navigation System	√	√	√	√		
USA	IS300	***	2018-2020	Master Blind Spot Monitor	√	√	√	√		
USA	IS300	***	2018-2020	Slave Blind Spot Monitor	√	√	√	√		
USA	IS300	***	2018-2020	ASC	√	√	√	√	1182	
USA	IS300	***	2018-2020	Telematics	√	√	√	√		
USA	IS300	***	2018-2020	Cruise Control	√	√	√	√		
USA	IS300	***	2018-2020	4-Wheel Drive (4WD)	√	√	√	√	0819, 0820, 0821, 0822	

USA	IS300	GSE	2016-2017	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
USA	IS300	GSE	2016-2017	Cruise Control	✓	✓	✓	✓		
USA	IS300	GSE	2016-2017	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007



USA	IS300	GSE	2016-2017	ABS/VSC/T RAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
USA	IS300	GSE	2016-2017	4-Wheel Drive (4WD)	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
USA	IS300	GSE	2016-2017	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	IS300	GSE	2016-2017	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	IS300	GSE	2016-2017	VGRS	✓	✓	✓	✓		SP0004, SP0037
USA	IS300	GSE	2016-2017	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		
USA	IS300	GSE	2016-2017	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
USA	IS300	GSE	2016-2017	DRS	✓	✓	✓	✓		SP0004, SP0081, SP0082, SP0083

USA	IS300	GSE	2016-2017	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	IS300	GSE	2016-2017	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	IS300	GSE	2016-2017	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	IS300	GSE	2016-2017	Gateway	√	√	√	√		SP0005
USA	IS300	GSE	2016-2017	Accessory Gateway	√	√	√	√		SP0005
USA	IS300	GSE	2016-2017	Driver Door Motor	√	√	√		0528	SP0003
USA	IS300	GSE	2016-2017	Passenger Door Motor	√	√	√		0528	SP0003
USA	IS300	GSE	2016-2017	Left Rear Door Motor	√	√	√		0528	SP0003
USA	IS300	GSE	2016-2017	Right Rear Door Motor	√	√	√		0528	SP0003
USA	IS300	GSE	2016-2017	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	IS300	GSE	2016-2017	Master Switch	√	√	√			
USA	IS300	GSE	2016-2017	Sliding Roof	√	√	√		0529	
USA	IS300	GSE	2016-2017	Tilt&Telescopic	√	√	√	√	0472, 0473	

USA	IS300	GSE	2016-2017	Combinati on Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	IS300	GSE	2016-2017	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	IS300	GSE	2016-2017	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	IS300	GSE	2016-2017	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
USA	IS300	GSE	2016-2017	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, SP008	

USA	IS300	GSE	2016-2017	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	IS300	GSE	2016-2017	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	IS300	GSE	2016-2017	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036
USA	IS300	GSE	2016-2017	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	IS300	GSE	2016-2017	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	IS300	GSE	2016-2017	Navigation System	✓	✓	✓	✓		
USA	IS300	GSE	2016-2017	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	IS300	GSE	2016-2017	Slave Blind Spot Monitor	✓	✓	✓	✓		
USA	IS300	GSE	2016-2017	Telematics	✓	✓	✓	✓		
USA	IS300	GSE	2016-2017	Radar Cruise	✓	✓	✓	✓		
USA	IS300	GSE	2016-2017	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
USA	IS300	GSE	2016-2017	Front Recognition Camera	✓	✓	✓	✓	0052	
USA	IS300	GSE	2016-2017	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	

USA	IS300	GSE	2016-2017	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	✓	✓	✓	✓		
USA	IS300	GSE	2016-2017	Central Gateway	✓	✓	✓	✓		
USA	IS300	GSE	2016-2017	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	IS300	GSE	2016-2017	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	

USA	IS300	JCE	2001-2005	Engine and ECT	√	√	√	√	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004, SP0026
USA	IS300	JCE	2001-2005	Cruise Control	√	√	√	√		

USA	IS300	JCE	2001-2005	ABS/VSC/TRAC	✓	✓	✓	✓	0821, 0822, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1083, 1096, 1098, 1099, 1101, 1102, 1104, 1105, 1106, 1117, 1118, 1121, 1122, 1123, 1124, 1125, 1538, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561,	SP0001, SP0003, SP0021, SP0023
USA	IS300	JCE	2001-2005	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
USA	IS300	JCE	2001-2005	Immobiliser	✓	✓	✓			SP0065, SP0066, SP0148



USA	IS300	JCE	2001-2005	Theft Deterrent	✓	✓	✓	0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	
USA	IS300	JCE	2001-2005	Supplement Restraint System (SRS) Airbag	✓	✓			SP0004
USA	IS300	JCE	2001-2005	Body	✓	✓	✓	0031, 0032, 0319, 0333, 0337, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0922, 0923, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020

USA	IS300	JCE	2001- 2005	Combinati on Meter		√	0274, 0616, 0 617, 0618, 06 19, 0629, 066 2, 0665, 0669 , 0670, 0671, 0672, 0673, 0 675, 0676, 06 77, 0678, 067 9, 0680, 0681 , 0692, 0719, 0745, 0746, 0 749, 0756, 07 60, 0761, 076 2, 0763, 0764 , 0765, 0766, 0767, 0768, 0 769, 0770, 07 71, 0772, 077 3, 0774, 0775 , 0776, 0777, 0778, 0779, 0 780, 0781, 07 82, 1000, 102 9, 1030, 1031 , 1032, 1033, 1034, 1035, 1 036, 1037, 10 38, 1039, 104 0, 1041, 1042 , 1043, 1044,	
-----	-------	-----	---------------	-----------------------	--	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

USA	IS350	***	2018- 2020	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	
-----	-------	-----	---------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

USA	IS350	***	2018-2020	Transmission	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
USA	IS350	***	2018-2020	Radar Cruise	√	√	√	√	
USA	IS350	***	2018-2020	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471

USA	IS350	***	2018-2020	ABS/VSC/T RAC/EPB	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	
USA	IS350	***	2018-2020	4-Wheel Drive (4WD)	√	√	√	√	0819, 0820, 0821, 0822	
USA	IS350	***	2018-2020	Tire Pressure Monitor	√	√	√			
USA	IS350	***	2018-2020	EMPS	√	√	√	√		
USA	IS350	***	2018-2020	Advanced Parking Guidance/ Parking Assist Monitor	√	√	√	√		
USA	IS350	***	2018-2020	Front Recognition Camera	√	√	√	√	0052	
USA	IS350	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	

USA	IS350	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	IS350	***	2018-2020	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
USA	IS350	***	2018-2020	Supplement Restraint System (SRS) Airbag	√	√	√	√		
USA	IS350	***	2018-2020	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	

USA	IS350	***	2018-2020	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
USA	IS350	***	2018-2020	Accessory Gateway	√	√	√	√		
USA	IS350	***	2018-2020	Central Gateway	√	√	√	√		
USA	IS350	***	2018-2020	Driver Door Motor	√	√	√		0528	
USA	IS350	***	2018-2020	Passenger Door Motor	√	√	√		0528	
USA	IS350	***	2018-2020	Left Rear Door Motor	√	√	√		0528	
USA	IS350	***	2018-2020	Right Rear Door Motor	√	√	√		0528	
USA	IS350	***	2018-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	IS350	***	2018-2020	Master Switch	√	√	√			
USA	IS350	***	2018-2020	Sliding Roof	√	√	√		0529	
USA	IS350	***	2018-2020	Tilt&Telescopic	√	√	√	√	0472, 0473	

USA	IS350	***	2018-2020	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
USA	IS350	***	2018-2020	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	IS350	***	2018-2020	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	IS350	***	2018-2020	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026
USA	IS350	***	2018-2020	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493



USA	IS350	***	2018-2020	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
USA	IS350	***	2018-2020	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	IS350	***	2018-2020	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	
USA	IS350	***	2018-2020	Detection Of Occupant	√	√	√			
USA	IS350	***	2018-2020	Remote Engine Starter	√	√	√	√		
USA	IS350	***	2018-2020	Starting Control	√	√	√	√	0256, 0257	
USA	IS350	***	2018-2020	Navigation System	√	√	√	√		
USA	IS350	***	2018-2020	Master Blind Spot Monitor	√	√	√	√		
USA	IS350	***	2018-2020	Slave Blind Spot Monitor	√	√	√	√		
USA	IS350	***	2018-2020	Telematics	√	√	√	√		

USA	IS350	GSE	2006-2017	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0096, 0 097, 0098, 00 99, 0100, 010 1, 0102, 0103 , 0104, 0105, 0106, 0107, 0 108, 0109, 01 10, 0111, 011 2, 0113, 0114 , 0115, 0116, 0117, 0118, 0 119, 0120, 01 21, 0122, 012 3, 0124, 0125 , 0126, 0127, 0128, 0129, 0 130, 0131, 01 32, 0133, 013 4, 0135, 0136 , 0137, 0138, 0139, 0140, 0 141, 0142, 01 43, 0144, 014 5, 0146, 0147 , 0148, 0149,	SP0004, SP0 026, SP0030 , SP0032, SP 0042, SP004 3, SP0072, S P0073, SP00 74, SP0075, SP0076, SP0 101
-----	-------	-----	-----------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------

USA	IS350	GSE	2006-2017	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0072, SP0101
USA	IS350	GSE	2006-2017	Cruise Control	✓	✓	✓	✓		

USA	IS350	GSE	2006-2017	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084, SP0175
USA	IS350	GSE	2006-2017	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	IS350	GSE	2006-2017	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010

USA	IS350	GSE	2006-2017	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019,	SP0016, SP0017
USA	IS350	GSE	2006-2017	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	IS350	GSE	2006-2017	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005
USA	IS350	GSE	2006-2017	Gateway	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	SP0005

USA	IS350	GSE	2006-2017	Body No. 3	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	IS350	GSE	2006-2017	Body No. 5			√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	IS350	GSE	2006-2017	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
USA	IS350	GSE	2006-2017	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517
USA	IS350	GSE	2006-2017	Master Switch	√	√	√		0939, 0940, 0941, 0942
USA	IS350	GSE	2006-2017	Sliding Roof	√	√	√		0529
USA	IS350	GSE	2006-2017	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005

USA	IS350	GSE	2006-2017	Combination Meter	✓	✓	✓	✓	0274, 0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679,	
USA	IS350	GSE	2006-2017	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	IS350	GSE	2006-2017	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
USA	IS350	GSE	2006-2017	Combination Switch			✓			
USA	IS350	GSE	2006-2017	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
USA	IS350	GSE	2006-2017	Rain Sensor			✓			



USA	IS350	GSE	2006-2017	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493, 0968	
USA	IS350	GSE	2006-2017	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015, SP0168
USA	IS350	GSE	2006-2017	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	SP0045
USA	IS350	GSE	2006-2017	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
USA	IS350	GSE	2006-2017	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	IS350	GSE	2006-2017	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	IS350	GSE	2006-2017	Telematics	✓	✓	✓	✓		
USA	IS350	GSE	2006-2017	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		
USA	IS350	GSE	2006-2017	Navigation System	✓	✓	✓	✓		
USA	IS350	GSE	2006-2017	4-Wheel Drive (4WD)	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085

USA	IS350	GSE	2006-2017	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
USA	IS350	GSE	2006-2017	VGRS	✓	✓	✓	✓		SP0004, SP0037
USA	IS350	GSE	2006-2017	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
USA	IS350	GSE	2006-2017	DRS	✓	✓	✓	✓		SP0004, SP0081, SP0082, SP0083
USA	IS350	GSE	2006-2017	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	IS350	GSE	2006-2017	Accessory Gateway	✓	✓	✓	✓		SP0005

USA	IS350	GSE	2006-2017	Driver Door Motor	✓	✓	✓		0528	SP0003
USA	IS350	GSE	2006-2017	Passenger Door Motor	✓	✓	✓		0528	SP0003
USA	IS350	GSE	2006-2017	Left Rear Door Motor	✓	✓	✓		0528	SP0003
USA	IS350	GSE	2006-2017	Right Rear Door Motor	✓	✓	✓		0528	SP0003
USA	IS350	GSE	2006-2017	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, SP0008	
USA	IS350	GSE	2006-2017	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	IS350	GSE	2006-2017	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	IS350	GSE	2006-2017	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	IS350	GSE	2006-2017	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	IS350	GSE	2006-2017	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071

USA	IS350	GSE	2006-2017	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
USA	IS350	GSE	2006-2017	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
USA	IS350	GSE	2006-2017	Front Recognition Camera	✓	✓	✓	✓	0052	
USA	IS350	GSE	2006-2017	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
USA	IS350	GSE	2006-2017	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	✓	✓	✓	✓		

USA	IS350	GSE	2006-2017	Central Gateway	√	√	√	√		
									0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	
USA	IS350C	GSE	2010-2015	Engine	√	√	√	√		SP0004, SP0026, SP0030, SP0032, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101

USA	IS350C	GSE	2010-2015	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0072, SP0101
USA	IS350C	GSE	2010-2015	Cruise Control	✓	✓	✓	✓		

USA	IS350C	GSE	2010-2015	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084, SP0175
USA	IS350C	GSE	2010-2015	Tire Pressure Monitor	✓	✓	✓		SP0001, SP0002	
USA	IS350C	GSE	2010-2015	EMPS	✓	✓	✓	✓	SP0001, SP0009, SP0010	
USA	IS350C	GSE	2010-2015	Advanced Parking Guidance/Parking Assist Monitor	✓	✓	✓	✓		

USA	IS350C	GSE	2010-2015	Air Conditioner	√	√	√	0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	SP0017
USA	IS350C	GSE	2010-2015	Supplement Restraint System (SRS) Airbag	√	√	√		SP0001
USA	IS350C	GSE	2010-2015	Body	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005



USA	IS350C	GSE	2010-2015	Gateway	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935
USA	IS350C	GSE	2010-2015	Body No. 3	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

USA	IS350C	GSE	2010-2015	Body No. 5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	IS350C	GSE	2010-2015	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
USA	IS350C	GSE	2010-2015	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
USA	IS350C	GSE	2010-2015	Master Switch			√		0939, 0940, 0941, 0942	
USA	IS350C	GSE	2010-2015	P Master Switch			√		0941	
USA	IS350C	GSE	2010-2015	Hardtop Retractable	√	√	√		0970	
USA	IS350C	GSE	2010-2015	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	

USA	IS350C	GSE	2010-2015	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
USA	IS350C	GSE	2010-2015	Left Mirror			√	0279, 0280, 0281, 0282, 0283	
USA	IS350C	GSE	2010-2015	Right Mirror			√	0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
USA	IS350C	GSE	2010-2015	Combination Switch			√		
USA	IS350C	GSE	2010-2015	Intuitive Parking Assist	√	√	√	0023, 0024	
USA	IS350C	GSE	2010-2015	Rain Sensor			√		
USA	IS350C	GSE	2010-2015	AFS	√	√	√	0008, 0475, 0476, 0477, 0968	

USA	IS350C	GSE	2010-2015	Smart Access	✓	✓	✓		0532, 0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0807, 0937, 0938	SP0011, SP0013, SP0014, SP0015, SP0168
USA	IS350C	GSE	2010-2015	Power Source Control	✓	✓	✓		0300, 0301, 0302, 0303, 0304, 0305, 0818, 0936	
USA	IS350C	GSE	2010-2015	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	IS350C	GSE	2010-2015	Navigation System	✓	✓	✓	✓		
USA	IS350C	GSE	2010-2015	Telematics	✓	✓	✓	✓		
USA	IS350C	GSE	2010-2015	Radar Cruise	✓	✓	✓	✓		
USA	IS350C	GSE	2010-2015	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	LC500	URZ	2018-2021	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	

USA	LC500	URZ	2018-2021	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
USA	LC500	URZ	2018-2021	Radar Cruise 1	✓	✓	✓	✓		
USA	LC500	URZ	2018-2021	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
USA	LC500	URZ	2018-2021	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	

USA	LC500	URZ	2018-2021	ABS/VSC/T RAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	
USA	LC500	URZ	2018-2021	Tire Pressure Monitor	✓	✓	✓			
USA	LC500	URZ	2018-2021	EMPS	✓	✓	✓	✓		
USA	LC500	URZ	2018-2021	VGRS	✓	✓	✓	✓		
USA	LC500	URZ	2018-2021	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
USA	LC500	URZ	2018-2021	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		

USA	LC500	URZ	2018-2021	Front Recognition Camera	✓	✓	✓	✓	0052	
USA	LC500	URZ	2018-2021	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
USA	LC500	URZ	2018-2021	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	✓	✓	✓	✓		
USA	LC500	URZ	2018-2021	DRS	✓	✓	✓	✓		
USA	LC500	URZ	2018-2021	Steering Angle Sensor	✓	✓	✓			
USA	LC500	URZ	2018-2021	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	

USA	LC500	URZ	2018-2021	Theft Deterrent	✓	✓	✓		0329, 0333, 0494, 0495, 0496, 0497, 0498, 0499, 0500, 0501, 0502	
USA	LC500	URZ	2018-2021	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
USA	LC500	URZ	2018-2021	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	
USA	LC500	URZ	2018-2021	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
USA	LC500	URZ	2018-2021	Central Gateway	✓	✓	✓	✓		
USA	LC500	URZ	2018-2021	Driver Door Motor	✓	✓	✓		0528	
USA	LC500	URZ	2018-2021	Passenger Door Motor	✓	✓	✓		0528	



USA	LC500	URZ	2018-2021	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
USA	LC500	URZ	2018-2021	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
USA	LC500	URZ	2018-2021	Master Switch	✓	✓	✓		
USA	LC500	URZ	2018-2021	Tilt&Telescopic	✓	✓	✓		1513, 1514
USA	LC500	URZ	2018-2021	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
USA	LC500	URZ	2018-2021	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512
USA	LC500	URZ	2018-2021	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026

USA	LC500	URZ	2018-2021	Rain and/or Humidity Sensor	✓	✓	✓		
USA	LC500	URZ	2018-2021	Wiper	✓	✓	✓		0031, 0032, 0033, 0034
USA	LC500	URZ	2018-2021	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015
USA	LC500	URZ	2018-2021	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028
USA	LC500	URZ	2018-2021	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553
USA	LC500	URZ	2018-2021	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305
USA	LC500	URZ	2018-2021	Detection Of Occupant	✓	✓	✓		
USA	LC500	URZ	2018-2021	Starting Control	✓	✓	✓	✓	0256, 0257
USA	LC500	URZ	2018-2021	Navigation System	✓	✓	✓	✓	
USA	LC500	URZ	2018-2021	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	LC500	URZ	2018-2021	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	LC500	URZ	2018-2021	Active Rear Wing	✓	✓	✓		1189, 1190, 1191, 1192, 1193

USA	LC500	URZ	2018-2021	Master Blind Spot Monitor	✓	✓	✓	✓		
USA	LC500	URZ	2018-2021	Slave Blind Spot Monitor	✓	✓	✓	✓		
USA	LC500	URZ	2018-2021	Active Noise Control	✓	✓	✓		1515, 1516, 1517, 1518, 1519	
USA	LC500	URZ	2018-2021	Pedestrian Protection	✓	✓	✓			
USA	LC500	URZ	2018-2021	Sub Battery Module	✓	✓	✓		0029, 0030	
USA	LC500	URZ	2018-2021	Power Integration No. 1	✓	✓	✓			
USA	LC500	URZ	2018-2021	Power Integration No. 3	✓	✓	✓			
USA	LC500	URZ	2018-2021	Telematics	✓	✓	✓	✓	1521, 1522	
USA	LC500	URZ	2018-2021	Cruise Control	✓	✓	✓	✓		
USA	LC500	URZ	2018-2021	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	LC500	URZ	2018-2021	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	

USA	LC500c	URZ	2021	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0096, 0 097, 0098, 00 99, 0100, 010 1, 0102, 0103 , 0104, 0105, 0106, 0107, 0 108, 0109, 01 10, 0111, 011 2, 0113, 0114 , 0115, 0116, 0117, 0118, 0 119, 0120, 01 21, 0122, 012 3, 0124, 0125 , 0126, 0127, 0128, 0129, 0 130, 0131, 01 32, 0133, 013 4, 0135, 0136 , 0137, 0138, 0139, 0140, 0 141, 0142, 01 43, 0144, 014 5, 0146, 0147 , 0148, 0149,	
-----	--------	-----	------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

USA	LC500c	URZ	2021	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
USA	LC500c	URZ	2021	Radar Cruise 1	✓	✓	✓	✓		
USA	LC500c	URZ	2021	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	
USA	LC500c	URZ	2021	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	

USA	LC500c	URZ	2021	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	
USA	LC500c	URZ	2021	Tire Pressure Monitor	✓	✓	✓			
USA	LC500c	URZ	2021	EMPS	✓	✓	✓	✓		
USA	LC500c	URZ	2021	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
USA	LC500c	URZ	2021	Advanced Parking Guidance/Parking Assist Monitor	✓	✓	✓	✓		
USA	LC500c	URZ	2021	Front Recognition Camera	✓	✓	✓	✓	0052	

USA	LC500c	URZ	2021	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
USA	LC500c	URZ	2021	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	LC500c	URZ	2021	Steering Angle Sensor	√	√	√			
USA	LC500c	URZ	2021	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
USA	LC500c	URZ	2021	Supplement Restraint System (SRS) Airbag	√	√	√	√		

USA	LC500c	URZ	2021	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
USA	LC500c	URZ	2021	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
USA	LC500c	URZ	2021	Central Gateway	√	√	√	√		
USA	LC500c	URZ	2021	Driver Door Motor	√	√	√		0528	
USA	LC500c	URZ	2021	Passenger Door Motor	√	√	√		0528	
USA	LC500c	URZ	2021	Left Rear Door Motor	√	√	√		0528	
USA	LC500c	URZ	2021	Right Rear Door Motor	√	√	√		0528	
USA	LC500c	URZ	2021	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	



USA	LC500c	URZ	2021	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
USA	LC500c	URZ	2021	Master Switch	✓	✓	✓		
USA	LC500c	URZ	2021	Sliding Roof	✓	✓	✓		
USA	LC500c	URZ	2021	Tilt&Telescopic	✓	✓	✓		1513, 1514
USA	LC500c	URZ	2021	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
USA	LC500c	URZ	2021	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512
USA	LC500c	URZ	2021	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026
USA	LC500c	URZ	2021	Rain and/or Humidity Sensor	✓	✓	✓		
USA	LC500c	URZ	2021	Wiper	✓	✓	✓		0031, 0032, 0033, 0034

USA	LC500c	URZ	2021	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	LC500c	URZ	2021	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
USA	LC500c	URZ	2021	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
USA	LC500c	URZ	2021	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
USA	LC500c	URZ	2021	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	LC500c	URZ	2021	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
USA	LC500c	URZ	2021	Detection Of Occupant	✓	✓	✓			
USA	LC500c	URZ	2021	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	LC500c	URZ	2021	Navigation System	✓	✓	✓	✓		

USA	LC500c	URZ	2021	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	LC500c	URZ	2021	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	LC500c	URZ	2021	Master Blind Spot Monitor	✓	✓	✓	✓		
USA	LC500c	URZ	2021	Slave Blind Spot Monitor	✓	✓	✓	✓		
USA	LC500c	URZ	2021	Active Noise Control	✓	✓	✓	✓	1515, 1516, 1517, 1518, 1519	
USA	LC500c	URZ	2021	Pedestrian Protection	✓	✓	✓	✓		
USA	LC500c	URZ	2021	Sub Battery Module	✓	✓	✓	✓	0029, 0030	
USA	LC500c	URZ	2021	Power Integration No. 1	✓	✓	✓	✓		
USA	LC500c	URZ	2021	Power Integration No. 3	✓	✓	✓	✓		
USA	LC500c	URZ	2021	Telematics	✓	✓	✓	✓	1521, 1522	

USA	LC500h	***	2018-2021	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	SP0004, SP0026, SP0029, SP0032, SP0042, SP0073, SP0075, SP0098, SP0099, SP0100, SP0101, SP0102, SP0114, SP0115, SP0116, SP0162
USA	LC500h	***	2018-2021	Hybrid Control	✓	✓	✓		0070, 0071, 0079, 0081, 0180, 0194, 0195, 1207, 1208, 1493, 1494, 1495, 1496, 1497	
USA	LC500h	***	2018-2021	Motor Generator	✓	✓	✓			
USA	LC500h	***	2018-2021	High Voltage (HV) Battery	✓	✓	✓		1494, 1520	SP0004, SP0055, SP0056, SP0058
USA	LC500h	***	2018-2021	Radar Cruise 1	✓	✓	✓	✓		
USA	LC500h	***	2018-2021	Radar Cruise 2	✓	✓	✓	✓	0017, 0018	SP0061, SP0069, SP0134

USA	LC500h	***	2018-2021	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
USA	LC500h	***	2018-2021	ABS/VSC/TRAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0175
USA	LC500h	***	2018-2021	Tire Pressure Monitor	√	√	√			SP0001, SP0002, SP0117, SP0118, SP0119
USA	LC500h	***	2018-2021	EMPS	√	√	√	√		SP0001, SP0009, SP0010
USA	LC500h	***	2018-2021	VGRS	√	√	√	√		SP0004, SP0037

USA	LC500h	***	2018-2021	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
USA	LC500h	***	2018-2021	Advanced Parking Guidance/Parking Assist Monitor	√	√	√	√		
USA	LC500h	***	2018-2021	Front Recognition Camera	√	√	√	√	0052	SP0126, SP0134, SP0182, SP0183, SP0184
USA	LC500h	***	2018-2021	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
USA	LC500h	***	2018-2021	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	LC500h	***	2018-2021	DRS	√	√	√	√		SP0004, SP0081, SP0082, SP0083
USA	LC500h	***	2018-2021	Steering Angle Sensor	√	√	√			SP0192

USA	LC500h	***	2018-2021	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0051, SP0169, SP0170, SP0171, SP0172, SP0173
USA	LC500h	***	2018-2021	Theft Deterrent	√	√	√		0329, 0333, 0494, 0495, 0496, 0497, 0498, 0499, 0500, 0501, 0502	
USA	LC500h	***	2018-2021	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001
USA	LC500h	***	2018-2021	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044, SP0127, SP0128, SP0134, SP0143, SP0144

USA	LC500h	***	2018-2021	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189, SP0193
USA	LC500h	***	2018-2021	Central Gateway	√	√	√	√		SP0005
USA	LC500h	***	2018-2021	Driver Door Motor	√	√	√		0528	SP0003
USA	LC500h	***	2018-2021	Passenger Door Motor	√	√	√		0528	SP0003
USA	LC500h	***	2018-2021	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	LC500h	***	2018-2021	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	LC500h	***	2018-2021	Master Switch	√	√	√			
USA	LC500h	***	2018-2021	Tilt&Teleopic	√	√	√		1513, 1514	



USA	LC500h	***	2018-2021	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	SP0174
USA	LC500h	***	2018-2021	Head Up Display	√	√	√		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
USA	LC500h	***	2018-2021	Intuitive Parking Assist	√	√	√	√	0023, 0024, 0025, 0026	
USA	LC500h	***	2018-2021	Rain and/or Humidity Sensor	√	√	√			
USA	LC500h	***	2018-2021	Wiper	√	√	√		0031, 0032, 0033, 0034	
USA	LC500h	***	2018-2021	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	SP0008, SP0166
USA	LC500h	***	2018-2021	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	

USA	LC500h	***	2018-2021	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0012, SP0014, SP0015, SP0018, SP0167, SP0168
USA	LC500h	***	2018-2021	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	LC500h	***	2018-2021	Detection Of Occupant	√	√	√	√		
USA	LC500h	***	2018-2021	Navigation System	√	√	√	√		SP0049, SP0050, SP0078, SP0079, SP0154, SP0155, SP0163, SP0164, SP0165
USA	LC500h	***	2018-2021	Right Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	LC500h	***	2018-2021	Left Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	LC500h	***	2018-2021	Active Rear Wing	√	√	√		1189, 1190, 1191, 1192, 1193	SP0136
USA	LC500h	***	2018-2021	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071, SP0177, SP0178
USA	LC500h	***	2018-2021	Slave Blind Spot Monitor	√	√	√	√		SP0137, SP0179, SP0180, SP0181
USA	LC500h	***	2018-2021	Vehicle proximity notification system	√	√	√	√	0044, 0045, 0046	

USA	LC500h	***	2018-2021	Active Noise Control	√	√	√		1515, 1516, 1517, 1518, 1519	
USA	LC500h	***	2018-2021	Pedestrian Protection	√	√	√			SP0004
USA	LC500h	***	2018-2021	Sub Battery Module	√	√	√		0029, 0030	
USA	LC500h	***	2018-2021	Power Integration No. 1	√	√	√			SP0191
USA	LC500h	***	2018-2021	Power Integration No. 2	√	√	√			SP0191
USA	LC500h	***	2018-2021	Power Integration No. 3	√	√	√			SP0191
USA	LC500h	***	2018-2021	Telematics	√	√	√	√	1521, 1522	SP0158, SP0159, SP0160
USA	LC500h	***	2018-2021	Cruise Control	√	√	√	√		
USA	LC500h	***	2018-2021	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	SP0008, SP0166
USA	LC500h	***	2018-2021	Adaptive Front Lighting System (AFS) (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	

USA	LFA	LFA	2012- 2013	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0096, 0 097, 0098, 00 99, 0100, 010 1, 0102, 0103 , 0104, 0105, 0106, 0107, 0 108, 0109, 01 10, 0111, 011 2, 0113, 0114 , 0115, 0116, 0117, 0118, 0 119, 0120, 01 21, 0122, 012 3, 0124, 0125 , 0126, 0127, 0128, 0129, 0 130, 0131, 01 32, 0133, 013 4, 0135, 0136 , 0137, 0138, 0139, 0140, 0 141, 0142, 01 43, 0144, 014 5, 0146, 0147 , 0148, 0149,	SP0004, SP0 026, SP0030 , SP0032, SP 0042, SP010 1
-----	-----	-----	---------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------

USA	LFA	LFA	2012-2013	Engine2	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	
USA	LFA	LFA	2012-2013	ASG	✓	✓	✓	✓	1184, 1185, 1186, 1187, 1188	SP0135

USA	LFA	LFA	2012-2013	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0175
USA	LFA	LFA	2012-2013	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	LFA	LFA	2012-2013	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	LFA	LFA	2012-2013	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004

USA	LFA	LFA	2012-2013	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	LFA	LFA	2012-2013	Immobiliser	✓	✓	✓		0501	SP0065, SP0066
USA	LFA	LFA	2012-2013	Theft Deterrent	✓	✓	✓		0329, 0333, 0494, 0495, 0496, 0497, 0498, 0499, 0500, 0501, 0502	
USA	LFA	LFA	2012-2013	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	LFA	LFA	2012-2013	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	LFA	LFA	2012-2013	Gateway	√	√	√	√		SP0005
USA	LFA	LFA	2012-2013	Driver Door Motor	√	√	√		0528	
USA	LFA	LFA	2012-2013	Passenger Door Motor	√	√	√		0528	
USA	LFA	LFA	2012-2013	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	LFA	LFA	2012-2013	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	



USA	LFA	LFA	2012-2013	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	LFA	LFA	2012-2013	Electric Power Control	✓	✓	✓	✓	0342, 0343, 0344, 0345, 0346	
USA	LFA	LFA	2012-2013	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	LFA	LFA	2012-2013	Navigation System	✓	✓	✓	✓		
USA	LFA	LFA	2012-2013	Active Rear Wing	✓	✓	✓		1189, 1190, 1191, 1192, 1193	SP0136
USA	LFA	LFA	2012-2013	Telematics	✓	✓	✓	✓		

USA	LS400	UCF	1995-2000	Engine and ECT	√	√	√	√	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004
USA	LS400	UCF	1995-2000	Cruise Control	√	√	√	√		

USA	LS400	UCF	1995-2000	ABS/VSC/TRAC	✓	✓	✓	✓	0821, 0822, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1083, 1096, 1098, 1099, 1101, 1102, 1104, 1105, 1106, 1117, 1118, 1121, 1122, 1123, 1124, 1125, 1538, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561,	SP0001, SP0003, SP0021
USA	LS400	UCF	1995-2000	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
USA	LS400	UCF	1995-2000	Immobilizer	✓	✓	✓			SP0065, SP0066, SP0148
USA	LS400	UCF	1995-2000	Supplement Restraint System (SRS) Airbag	✓	✓				SP0004

USA	LS400	UCF	1995-2000	Body	√	√	√	0031, 0032, 0319, 0333, 0337, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0922, 0923, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020
USA	LS400	UCF	1995-2000	Driver Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	LS400	UCF	1995-2000	Passenger Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	LS400	UCF	1995-2000	Left Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	LS400	UCF	1995-2000	Right Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	LS400	UCF	1995-2000	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
USA	LS400	UCF	1995-2000	Sliding Roof			√	0529	
USA	LS400	UCF	1995-2000	Tilt&Telescopic	√	√	√	0472, 0473, 1005	

USA	LS400	UCF	1995-2000	Combinati on Meter			√	0274, 0616, 0 617, 0618, 06 19, 0629, 066 2, 0665, 0669 , 0670, 0671, 0672, 0673, 0 675, 0676, 06 77, 0678, 067 9, 0680, 0681 , 0692, 0719, 0745, 0746, 0 749, 0756, 07 60, 0761, 076 2, 0763, 0764 , 0765, 0766, 0767, 0768, 0 769, 0770, 07 71, 0772, 077 3, 0774, 0775 , 0776, 0777, 0778, 0779, 0 780, 0781, 07 82, 1000, 102 9, 1030, 1031 , 1032, 1033, 1034, 1035, 1 036, 1037, 10 38, 1039, 104 0, 1041, 1042 , 1043, 1044,	
-----	-------	-----	-----------	-----------------------	--	--	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

USA	LS430	UCF	2001- 2006	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0096, 0 097, 0098, 00 99, 0100, 010 1, 0102, 0103 , 0104, 0105, 0106, 0107, 0 108, 0109, 01 10, 0111, 011 2, 0113, 0114 , 0115, 0116, 0117, 0118, 0 119, 0120, 01 21, 0122, 012 3, 0124, 0125 , 0126, 0127, 0128, 0129, 0 130, 0131, 01 32, 0133, 013 4, 0135, 0136 , 0137, 0138, 0139, 0140, 0 141, 0142, 01 43, 0144, 014 5, 0146, 0147 , 0148, 0149,	SP0004, SP0 026, SP0032 , SP0073, SP 0074, SP007 5, SP0076, S P0098, SP00 99, SP0100, SP0101, SP0 116, SP0161 , SP0162
-----	-------	-----	---------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------

USA	LS430	UCF	2001-2006	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0101
USA	LS430	UCF	2001-2006	Laser Cruise	✓	✓	✓	✓		SP0061, SP0062
USA	LS430	UCF	2001-2006	Air suspension	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001

USA	LS430	UCF	2001-2006	ABS/VSC/TRAC	√	√	√	√	0821, 0822, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1083, 1096, 1098, 1099, 1101, 1102, 1104, 1105, 1106, 1117, 1118, 1121, 1122, 1123, 1124, 1125, 1538, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561,	SP0001, SP0003, SP0021, SP0023
USA	LS430	UCF	2001-2006	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
USA	LS430	UCF	2001-2006	Steering Lock	√	√	√		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0014, SP0065, SP0066, SP0196
USA	LS430	UCF	2001-2006	Supplement Restraint System (SRS) Airbag	√	√	√			SP0001, SP0004



USA	LS430	UCF	2001-2006	Gateway	√	√	√			SP0005
USA	LS430	UCF	2001-2006	Body No. 2	√	√	√		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	
USA	LS430	UCF	2001-2006	Body No. 3	√	√	√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	

USA	LS430	UCF	2001-2006	Body No. 4	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967
USA	LS430	UCF	2001-2006	Body No. 5			√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967
USA	LS430	UCF	2001-2006	Driver Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991
USA	LS430	UCF	2001-2006	Passenger Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991

USA	LS430	UCF	2001-2006	Left Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	LS430	UCF	2001-2006	Right Rear Door	√	√	√	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	LS430	UCF	2001-2006	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
USA	LS430	UCF	2001-2006	Left Rear Seat			√	0422, 0424, 0981, 0982	
USA	LS430	UCF	2001-2006	Right Rear Seat			√	0422, 0424, 0981, 0982	
USA	LS430	UCF	2001-2006	Rear Seat Switch			√		
USA	LS430	UCF	2001-2006	Sliding Roof			√	0529	
USA	LS430	UCF	2001-2006	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005

USA	LS430	UCF	2001-2006	Combinati on Meter			√		0274, 0616, 0 617, 0618, 06 19, 0629, 066 2, 0665, 0669 , 0670, 0671, 0672, 0673, 0 675, 0676, 06 77, 0678, 067 9, 0680, 0681 , 0692, 0719, 0745, 0746, 0 749, 0756, 07 60, 0761, 076 2, 0763, 0764 , 0765, 0766, 0767, 0768, 0 769, 0770, 07 71, 0772, 077 3, 0774, 0775 , 0776, 0777, 0778, 0779, 0 780, 0781, 07 82, 1000, 102 9, 1030, 1031 , 1032, 1033, 1034, 1035, 1 036, 1037, 10 38, 1039, 104 0, 1041, 1042 , 1043, 1044,	
USA	LS430	UCF	2001-2006	Combinati on Switch			√			
USA	LS430	UCF	2001-2006	Switch Of Steering Pad			√			
USA	LS430	UCF	2001-2006	Intuitive Parking Assist	√	√	√		0023, 0024	
USA	LS430	UCF	2001-2006	Rain Sensor			√			
USA	LS430	UCF	2001-2006	AFS	√	√	√		0008, 0475, 0 476, 0477, 09 68	
USA	LS430	UCF	2001-2006	Smart Key	√	√	√		0321, 0333, 0 337, 0494, 04 95, 0498, 050 0, 0501, 0785 , 0993, 0994, SP0011, SP0 0995, 0996, 0 997, 0998, 09 99, 1000, 100 1, 1002, 1003 , 1004 013, SP0147	
USA	LS430	UCF	2001-2006	Cruise Control	√	√	√	√		

USA	LS430	UCF	2001-2006	Radar Cruise	√	√	√	√		SP0061, SP0062
USA	LS430	UCF	2001-2006	Pre-Collision	√	√	√		0348, 0349, 0350	
USA	LS430	UCF	2001-2006	Immobiliser	√	√	√		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066
USA	LS430	UCF	2001-2006	Theft Deterrent	√	√	√		0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	SP0018, SP0019, SP0020
USA	LS430	UCF	2001-2006	Engine and ECT	√	√	√	√	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004, SP0026

USA	LS460	USF	2007-2017	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0029, SP0030, SP0032, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0098, SP0099, SP0100, SP0101, SP0116, SP0161, SP0162
-----	-------	-----	-----------	--------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------

USA	LS460	USF	2007-2017	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0072, SP0101
USA	LS460	USF	2007-2017	Cruise Control	✓	✓	✓	✓		
USA	LS460	USF	2007-2017	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

USA	LS460	USF	2007-2017	ABS/VSC/T RAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP003, SP0021, SP0022, SP0023, SP0024, SP0175
USA	LS460	USF	2007-2017	Tire Pressure Monitor	√	√	√			SP0001, SP0002, SP0117, SP0118, SP0119
USA	LS460	USF	2007-2017	EMPS	√	√	√	√		SP0001, SP0009, SP0010
USA	LS460	USF	2007-2017	VGRS	√	√	√	√		SP0001, SP0009, SP0037
USA	LS460	USF	2007-2017	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
USA	LS460	USF	2007-2017	Advanced Parking Guidance/Parking Assist Monitor	√	√	√	√		



USA	LS460	USF	2007-2017	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051, SP0169, SP0170, SP0171, SP0172, SP0173
USA	LS460	USF	2007-2017	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	LS460	USF	2007-2017	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	LS460	USF	2007-2017	Engine Control Module (ECM) Gateway	✓	✓	✓	✓		SP0005
USA	LS460	USF	2007-2017	Electronic Controlled Braking (ECB) Gateway	✓	✓	✓	✓		SP0005
USA	LS460	USF	2007-2017	Mayday Gateway	✓	✓	✓			
USA	LS460	USF	2007-2017	Body No. 4	✓	✓	✓		0310, 0311, 0312, 0313, 0314, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0327, 0328, 0329	

USA	LS460	USF	2007-2017	Body No. 5	✓	✓	✓		0031, 0032, 0330, 0331, 0332, 0333, 0334, 0335, 0336, 0337, 0338, 0339, 0340, 0341	
USA	LS460	USF	2007-2017	Driver Door	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0433, 0434, 0435, 0436, 0437	
USA	LS460	USF	2007-2017	Passenger Door	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0430, 0431	
USA	LS460	USF	2007-2017	Left Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
USA	LS460	USF	2007-2017	Right Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
USA	LS460	USF	2007-2017	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	LS460	USF	2007-2017	Driver Door Motor	✓	✓	✓		0528	SP0003
USA	LS460	USF	2007-2017	Passenger Door Motor	✓	✓	✓		0528	SP0003
USA	LS460	USF	2007-2017	Left Rear Door Motor	✓	✓	✓		0528	SP0003
USA	LS460	USF	2007-2017	Right Rear Door Motor	✓	✓	✓		0528	SP0003

USA	LS460	USF	2007-2017	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	LS460	USF	2007-2017	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	LS460	USF	2007-2017	Left Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
USA	LS460	USF	2007-2017	Right Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
USA	LS460	USF	2007-2017	Master Switch	✓	✓	✓			
USA	LS460	USF	2007-2017	Driver Seat Switch			✓			
USA	LS460	USF	2007-2017	Switch Of Center Console			✓		0355, 0356, 0357	
USA	LS460	USF	2007-2017	Rear Console Switch	✓	✓	✓		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
USA	LS460	USF	2007-2017	Left Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354	
USA	LS460	USF	2007-2017	Right Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354	
USA	LS460	USF	2007-2017	Left Rear Seat Air Conditioner (A/C)	✓	✓	✓		0351, 0352, 0353, 0354	
USA	LS460	USF	2007-2017	Right Rear Seat Air Conditioner (A/C)	✓	✓	✓		0351, 0352, 0353, 0354	
USA	LS460	USF	2007-2017	Sliding Roof	✓	✓	✓		0529	
USA	LS460	USF	2007-2017	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	

USA	LS460	USF	2007-2017	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	SP0174
USA	LS460	USF	2007-2017	Combination Switch			✓			
USA	LS460	USF	2007-2017	Switch Of Steering Pad			✓			
USA	LS460	USF	2007-2017	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
USA	LS460	USF	2007-2017	Rain Sensor	✓	✓	✓			
USA	LS460	USF	2007-2017	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	SP0166

USA	LS460	USF	2007-2017	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0168
USA	LS460	USF	2007-2017	Electric Power Control	✓	✓	✓	✓	0342, 0343, 0344, 0345, 0346	
USA	LS460	USF	2007-2017	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036, SP0176
USA	LS460	USF	2007-2017	Radar Cruise	✓	✓	✓	✓		
USA	LS460	USF	2007-2017	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038, SP0039
USA	LS460	USF	2007-2017	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	LS460	USF	2007-2017	Pre-Collision 2	✓	✓	✓	✓	0022	SP0005, SP0038, SP0039
USA	LS460	USF	2007-2017	Telematics	✓	✓	✓	✓		SP0158, SP0159, SP0160
USA	LS460	USF	2007-2017	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0078, SP0079, SP0154, SP0155, SP0163, SP0164, SP0165
USA	LS460	USF	2007-2017	Accessory Gateway	✓	✓	✓	✓		SP0005
USA	LS460	USF	2007-2017	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274	SP0067, SP0068
USA	LS460	USF	2007-2017	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071, SP0177, SP0178
USA	LS460	USF	2007-2017	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071, SP0137, SP0179, SP0180, SP0181
USA	LS460	USF	2007-2017	Gateway	✓	✓	✓	✓		SP0005

USA	LS460	USF	2007-2017	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0012, SP0014, SP0015, SP0167, SP0168
USA	LS500	***	2018-2020	Engine	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	SP0004, SP0026, SP0029, SP0032, SP0042, SP0073, SP0075, SP0098, SP0099, SP0100, SP0101, SP0102, SP0114, SP0115, SP0116, SP0162

USA	LS500	***	2018-2020	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	SP0004, SP0029, SP0032, SP0101
USA	LS500	***	2018-2020	Radar Cruise 1	✓	✓	✓	✓		
USA	LS500	***	2018-2020	Radar Cruise 2	✓	✓	✓	✓	0017, 0018, 1504, 1505	
USA	LS500	***	2018-2020	Air suspension	✓	✓	✓			SP0007, SP0130, SP0131, SP0132, SP0133
USA	LS500	***	2018-2020	Adaptive Variable Suspension (AVS) System	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007



USA	LS500	***	2018-2020	Front Stabilizer	√	√	√		0527	SP0151, SP0152
USA	LS500	***	2018-2020	Rear Stabilizer	√	√	√		0527	
USA	LS500	***	2018-2020	ABS/VSC/TRAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0175
USA	LS500	***	2018-2020	Tire Pressure Monitor	√	√	√			SP0001, SP0002, SP0117, SP0118, SP0119
USA	LS500	***	2018-2020	EMPS	√	√	√	√		SP0001, SP0009, SP0010
USA	LS500	***	2018-2020	VGRS	√	√	√	√		SP0004, SP0037
USA	LS500	***	2018-2020	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004

USA	LS500	***	2018-2020	Front Recognition Camera	√	√	√	√	0052	SP0087, SP0126, SP0182, SP0183
USA	LS500	***	2018-2020	Lane Control	√	√	√		0824, 0989	
USA	LS500	***	2018-2020	Panoramic view monitor	√	√	√	√		
USA	LS500	***	2018-2020	DRS	√	√	√	√		SP0004, SP0081, SP0082, SP0083
USA	LS500	***	2018-2020	Steering Angle Sensor	√	√	√			SP0192
USA	LS500	***	2018-2020	Parking Assist Camera	√	√	√	√		
USA	LS500	***	2018-2020	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0051, SP0169, SP0170, SP0171, SP0172, SP0173
USA	LS500	***	2018-2020	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001
USA	LS500	***	2018-2020	Driving Support System	√	√	√			
USA	LS500	***	2018-2020	Seat Belt Control	√	√	√			

USA	LS500	***	2018-2020	Pre-Collision System	√	√	√		1524, 1525, 1526	
USA	LS500	***	2018-2020	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	LS500	***	2018-2020	Central Gateway	√	√	√	√		SP0005
USA	LS500	***	2018-2020	Left Rear Door	√	√	√	√	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
USA	LS500	***	2018-2020	Right Rear Door	√	√	√	√	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
USA	LS500	***	2018-2020	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	LS500	***	2018-2020	Driver Door Motor	√	√	√		0528	SP0003

USA	LS500	***	2018-2020	Passenger Door Motor	√	√	√		0528	SP0003
USA	LS500	***	2018-2020	Left Rear Door Motor	√	√	√		0528	SP0003
USA	LS500	***	2018-2020	Right Rear Door Motor	√	√	√		0528	SP0003
USA	LS500	***	2018-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	LS500	***	2018-2020	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	LS500	***	2018-2020	Left Rear Seat	√	√	√		0026, 0421, 0422, 0423, 0424, 0425	
USA	LS500	***	2018-2020	Right Rear Seat	√	√	√		0026, 0421, 0422, 0423, 0424, 0425	
USA	LS500	***	2018-2020	Master Switch	√	√	√			
USA	LS500	***	2018-2020	Rear Console Switch	√	√	√		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
USA	LS500	***	2018-2020	Sliding Roof	√	√	√		0529	
USA	LS500	***	2018-2020	Sliding Sunshade - Rear	√	√	√		0027	
USA	LS500	***	2018-2020	Tilt&Telescopic	√	√	√		1513, 1514	

USA	LS500	***	2018-2020	Combination Meter	✓	✓	✓	0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	SP0174
USA	LS500	***	2018-2020	Head Up Display	✓	✓	✓	0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
USA	LS500	***	2018-2020	Road Sign Assist	✓	✓	✓		
USA	LS500	***	2018-2020	Advanced Parking Guidance/Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A)	✓	✓	✓	✓	0023, 0024, 0025, 0026
USA	LS500	***	2018-2020	Rain and/or Humidity Sensor	✓	✓	✓		
USA	LS500	***	2018-2020	Wiper	✓	✓	✓		0031, 0032, 0033, 0034

USA	LS500	***	2018-2020	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	SP0166
USA	LS500	***	2018-2020	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
USA	LS500	***	2018-2020	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
USA	LS500	***	2018-2020	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0012, SP0014, SP0015, SP0018, SP0168, SP0195
USA	LS500	***	2018-2020	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	LS500	***	2018-2020	Detection Of Occupant	✓	✓	✓			
USA	LS500	***	2018-2020	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0078, SP0079, SP0154, SP0155, SP0163, SP0164, SP0165
USA	LS500	***	2018-2020	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

USA	LS500	***	2018-2020	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	LS500	***	2018-2020	Front Radar Sensor	✓	✓	✓			SP0127, SP0128, SP0129
USA	LS500	***	2018-2020	Front Side Radar Master	✓	✓	✓			SP0120, SP0121, SP0122
USA	LS500	***	2018-2020	Front Side Radar Slave	✓	✓	✓			SP0123, SP0124, SP0125
USA	LS500	***	2018-2020	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071, SP0177, SP0178
USA	LS500	***	2018-2020	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0137, SP0179, SP0180, SP0181
USA	LS500	***	2018-2020	Active Noise Control	✓	✓	✓		1515, 1516, 1517, 1518, 1519	
USA	LS500	***	2018-2020	Pedestrian Protection	✓	✓	✓			SP0004
USA	LS500	***	2018-2020	Sub Battery Module	✓	✓	✓		0029, 0030	
USA	LS500	***	2018-2020	Power Integration No. 1	✓	✓	✓			SP0191
USA	LS500	***	2018-2020	Power Integration No. 2	✓	✓	✓			SP0191
USA	LS500	***	2018-2020	Power Integration No. 3	✓	✓	✓			SP0191
USA	LS500	***	2018-2020	Telematics	✓	✓	✓	✓		SP0158, SP0159, SP0160
USA	LS500	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	

USA	LS500	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	LS500	***	2018-2020	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
USA	LS500	***	2018-2020	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	SP0008, SP0166
USA	LS500	***	2018-2020	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	
USA	LS500h	***	2018-2020	Engine	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	



USA	LS500h	***	2018-2020	Hybrid Control	√	√	√		0070, 0071, 0079, 0081, 0180, 0194, 0195, 1207, 1208, 1493, 1494, 1495, 1496, 1497
USA	LS500h	***	2018-2020	Motor Generator	√	√	√		
USA	LS500h	***	2018-2020	High Voltage (HV) Battery	√	√	√		1494, 1520
USA	LS500h	***	2018-2020	Radar Cruise 1	√	√	√	√	
USA	LS500h	***	2018-2020	Radar Cruise 2	√	√	√	√	0017, 0018, 1504, 1505
USA	LS500h	***	2018-2020	Air suspension	√	√	√		
USA	LS500h	***	2018-2020	Adaptive Variable Suspension (AVS) System	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471

USA	LS500h	***	2018-2020	ABS/VSC/T RAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	
USA	LS500h	***	2018-2020	Tire Pressure Monitor	√	√	√			
USA	LS500h	***	2018-2020	EMPS	√	√	√	√		
USA	LS500h	***	2018-2020	VGRS	√	√	√	√		
USA	LS500h	***	2018-2020	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
USA	LS500h	***	2018-2020	Front Recognition Camera	√	√	√	√	0052	
USA	LS500h	***	2018-2020	Lane Control	√	√	√		0824, 0989	
USA	LS500h	***	2018-2020	Panoramic view monitor	√	√	√	√		

USA	LS500h	***	2018-2020	DRS	√	√	√	√			
USA	LS500h	***	2018-2020	Steering Angle Sensor	√	√	√				
USA	LS500h	***	2018-2020	Parking Assist Camera	√	√	√	√			
USA	LS500h	***	2018-2020	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615		
USA	LS500h	***	2018-2020	Supplement Restraint System (SRS) Airbag	√	√	√	√			
USA	LS500h	***	2018-2020	Driving Support System	√	√	√				
USA	LS500h	***	2018-2020	Seat Belt Control	√	√	√				
USA	LS500h	***	2018-2020	Pre-Collision System	√	√	√		1524, 1525, 1526		

USA	LS500h	***	2018-2020	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
USA	LS500h	***	2018-2020	Central Gateway	√	√	√	√		
USA	LS500h	***	2018-2020	Left Rear Door	√	√	√	√	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
USA	LS500h	***	2018-2020	Right Rear Door	√	√	√	√	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
USA	LS500h	***	2018-2020	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	LS500h	***	2018-2020	Driver Door Motor	√	√	√		0528	
USA	LS500h	***	2018-2020	Passenger Door Motor	√	√	√		0528	

USA	LS500h	***	2018-2020	Left Rear Door Motor	√	√	√		0528	
USA	LS500h	***	2018-2020	Right Rear Door Motor	√	√	√		0528	
USA	LS500h	***	2018-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	LS500h	***	2018-2020	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	LS500h	***	2018-2020	Left Rear Seat	√	√	√		0026, 0421, 0422, 0423, 0424, 0425	
USA	LS500h	***	2018-2020	Right Rear Seat	√	√	√		0026, 0421, 0422, 0423, 0424, 0425	
USA	LS500h	***	2018-2020	Master Switch	√	√	√			
USA	LS500h	***	2018-2020	Rear Console Switch	√	√	√		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
USA	LS500h	***	2018-2020	Sliding Roof	√	√	√		0529	
USA	LS500h	***	2018-2020	Tilt&Telescopic	√	√	√		1513, 1514	

USA	LS500h	***	2018-2020	Combination Meter	√	√	√	0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
USA	LS500h	***	2018-2020	Head Up Display	√	√	√	0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
USA	LS500h	***	2018-2020	Road Sign Assist	√	√	√		
USA	LS500h	***	2018-2020	Advanced Parking Guidance/Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A)	√	√	√	√	0023, 0024, 0025, 0026
USA	LS500h	***	2018-2020	Rain and/or Humidity Sensor	√	√	√		
USA	LS500h	***	2018-2020	Wiper	√	√	√		0031, 0032, 0033, 0034

USA	LS500h	***	2018-2020	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
USA	LS500h	***	2018-2020	Adaptive Front Lighting System (AFS) (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028
USA	LS500h	***	2018-2020	Front Recognition Camera (Front Lighting Control)	√	√	√		
USA	LS500h	***	2018-2020	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553
USA	LS500h	***	2018-2020	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305
USA	LS500h	***	2018-2020	Detection Of Occupant	√	√	√		
USA	LS500h	***	2018-2020	Navigation System	√	√	√	√	
USA	LS500h	***	2018-2020	Right Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	LS500h	***	2018-2020	Left Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284

USA	LS500h	***	2018-2020	Front Radar Sensor	√	√	√			
USA	LS500h	***	2018-2020	Front Side Radar Master	√	√	√			
USA	LS500h	***	2018-2020	Front Side Radar Slave	√	√	√			
USA	LS500h	***	2018-2020	Master Blind Spot Monitor	√	√	√	√		
USA	LS500h	***	2018-2020	Slave Blind Spot Monitor	√	√	√	√		
USA	LS500h	***	2018-2020	Notification System Of Vehicle Proximity	√	√	√		0044, 0045, 0046	
USA	LS500h	***	2018-2020	Active Noise Control	√	√	√		1515, 1516, 1517, 1518, 1519	
USA	LS500h	***	2018-2020	Pedestrian Protection	√	√	√			
USA	LS500h	***	2018-2020	Sub Battery Module	√	√	√		0029, 0030	
USA	LS500h	***	2018-2020	Power Integration No. 1	√	√	√			
USA	LS500h	***	2018-2020	Power Integration No. 2	√	√	√			
USA	LS500h	***	2018-2020	Power Integration No. 3	√	√	√			
USA	LS500h	***	2018-2020	Telematics	√	√	√	√		
USA	LS500h	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	



USA	LS500h	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	LS500h	***	2018-2020	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
USA	LS500h	***	2018-2020	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
USA	LS500h	***	2018-2020	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	
USA	LS600h	UVF	2008-2016	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0032, SP0073, SP0074, SP0075, SP0076, SP0101

USA	LS600h	UVF	2008-2016	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026
USA	LS600h	UVF	2008-2016	Cruise Control	✓	✓	✓	✓		
USA	LS600h	UVF	2008-2016	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
USA	LS600h	UVF	2008-2016	Front Stabilizer	✓	✓	✓		0527	
USA	LS600h	UVF	2008-2016	Rear Stabilizer	✓	✓	✓		0527	

USA	LS600h	UVF	2008-2016	ABS/VSC/T RAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0175
USA	LS600h	UVF	2008-2016	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	LS600h	UVF	2008-2016	EMPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
USA	LS600h	UVF	2008-2016	VGRS	✓	✓	✓	✓		SP0001, SP0009, SP0037
USA	LS600h	UVF	2008-2016	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
USA	LS600h	UVF	2008-2016	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		

USA	LS600h	UVF	2008-2016	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0197
USA	LS600h	UVF	2008-2016	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	LS600h	UVF	2008-2016	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	LS600h	UVF	2008-2016	Engine Control Module (ECM) Gateway	✓	✓	✓	✓		SP0005
USA	LS600h	UVF	2008-2016	Electronic Controlled Braking (ECB) Gateway	✓	✓	✓	✓		SP0005
USA	LS600h	UVF	2008-2016	Mayday Gateway	✓	✓	✓			
USA	LS600h	UVF	2008-2016	Body No. 4	✓	✓	✓		0310, 0311, 0312, 0313, 0314, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0327, 0328, 0329	

USA	LS600h	UVF	2008-2016	Body No. 5	✓	✓	✓		0031, 0032, 0330, 0331, 0332, 0333, 0334, 0335, 0336, 0337, 0338, 0339, 0340, 0341	
USA	LS600h	UVF	2008-2016	Driver Door	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0433, 0434, 0435, 0436, 0437	
USA	LS600h	UVF	2008-2016	Passenger Door	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0430, 0431	
USA	LS600h	UVF	2008-2016	Left Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
USA	LS600h	UVF	2008-2016	Right Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
USA	LS600h	UVF	2008-2016	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	LS600h	UVF	2008-2016	Driver Door Motor	✓	✓	✓		0528	SP0003
USA	LS600h	UVF	2008-2016	Passenger Door Motor	✓	✓	✓		0528	SP0003
USA	LS600h	UVF	2008-2016	Left Rear Door Motor	✓	✓	✓		0528	SP0003
USA	LS600h	UVF	2008-2016	Right Rear Door Motor	✓	✓	✓		0528	SP0003

USA	LS600h	UVF	2008-2016	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	LS600h	UVF	2008-2016	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	LS600h	UVF	2008-2016	Left Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
USA	LS600h	UVF	2008-2016	Right Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
USA	LS600h	UVF	2008-2016	Master Switch	✓	✓	✓			
USA	LS600h	UVF	2008-2016	Driver Seat Switch			✓			
USA	LS600h	UVF	2008-2016	Switch Of Center Console			✓		0355, 0356, 0357	
USA	LS600h	UVF	2008-2016	Rear Console Switch	✓	✓	✓		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
USA	LS600h	UVF	2008-2016	Left Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354	
USA	LS600h	UVF	2008-2016	Right Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354	
USA	LS600h	UVF	2008-2016	Left Rear Seat Air Conditioner (A/C)	✓	✓	✓		0351, 0352, 0353, 0354	
USA	LS600h	UVF	2008-2016	Right Rear Seat Air Conditioner (A/C)	✓	✓	✓		0351, 0352, 0353, 0354	
USA	LS600h	UVF	2008-2016	Sliding Roof	✓	✓	✓		0529	
USA	LS600h	UVF	2008-2016	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	

USA	LS600h	UVF	2008-2016	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	LS600h	UVF	2008-2016	Combination Switch			✓			
USA	LS600h	UVF	2008-2016	Switch Of Steering Pad			✓			
USA	LS600h	UVF	2008-2016	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
USA	LS600h	UVF	2008-2016	Rain Sensor	✓	✓	✓			
USA	LS600h	UVF	2008-2016	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	



USA	LS600h	UVF	2008-2016	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0168
USA	LS600h	UVF	2008-2016	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036
USA	LS600h	UVF	2008-2016	Radar Cruise	✓	✓	✓	✓		
USA	LS600h	UVF	2008-2016	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038, SP0039
USA	LS600h	UVF	2008-2016	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	LS600h	UVF	2008-2016	Pre-Collision 2	✓	✓	✓	✓	0022	SP0005, SP0038, SP0039
USA	LS600h	UVF	2008-2016	Navigation System	✓	✓	✓	✓		
USA	LS600h	UVF	2008-2016	Telematics	✓	✓	✓	✓		
USA	LS600h	UVF	2008-2016	Accessory Gateway	✓	✓	✓	✓		SP0005
USA	LS600h	UVF	2008-2016	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274	
USA	LS600h	UVF	2008-2016	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	LS600h	UVF	2008-2016	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	LS600h	UVF	2008-2016	Gateway	✓	✓	✓	✓		SP0005

USA	LX450	FZJ	1996-1997	Engine and ECT	√	√	√	√	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004
-----	-------	-----	-----------	----------------	---	---	---	---	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------

USA	LX470	UZJ	1998-2007	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0032, SP0076, SP0101
USA	LX470	UZJ	1998-2007	Cruise Control	✓	✓	✓	✓		
USA	LX470	UZJ	1998-2007	AHC	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001, SP0007

USA	LX470	UZJ	1998-2007	ABS/VSC/TRAC	√	√	√	√	0821, 0822, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1083, 1096, 1098, 1099, 1101, 1102, 1104, 1105, 1106, 1117, 1118, 1121, 1122, 1123, 1124, 1125, 1538, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561,	SP0001, SP0003, SP0021, SP0023
USA	LX470	UZJ	1998-2007	Tire Pressure Monitor	√	√	√			SP0001, SP0002
USA	LX470	UZJ	1998-2007	VGRS	√	√	√	√		SP0001, SP0009, SP0037
USA	LX470	UZJ	1998-2007	Immobiliser	√	√	√		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066, SP0148
USA	LX470	UZJ	1998-2007	Theft Deterrent	√	√	√		0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	
USA	LX470	UZJ	1998-2007	Supplement Restraint System (SRS) Airbag	√	√				SP0004

USA	LX470	UZJ	1998-2007	Body	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020
USA	LX470	UZJ	1998-2007	Body No. 2	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	
USA	LX470	UZJ	1998-2007	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	

USA	LX470	UZJ	1998-2007	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
USA	LX470	UZJ	1998-2007	Sliding Roof			√		0529	
USA	LX470	UZJ	1998-2007	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
USA	LX470	UZJ	1998-2007	Mirror			√		0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
USA	LX470	UZJ	1998-2007	Rain Sensor			√			
USA	LX470	UZJ	1998-2007	Wiper			√		0031, 0032, 0332	
USA	LX470	UZJ	1998-2007	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
USA	LX570	URJ	2008-2020	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
USA	LX570	URJ	2008-2020	Cruise Control	√	√	√	√		

USA	LX570	URJ	2008-2020	AHC	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	
USA	LX570	URJ	2008-2020	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP003, SP0021, SP0022, SP0023, SP0024, SP0084, SP0175
USA	LX570	URJ	2008-2020	Tire Pressure Monitor	✓	✓	✓			SP0001, SP002
USA	LX570	URJ	2008-2020	VGRS	✓	✓	✓	✓		SP0001, SP004, SP0009, SP0037

USA	LX570	URJ	2008-2020	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	LX570	URJ	2008-2020	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001



USA	LX570	URJ	2008-2020	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	LX570	URJ	2008-2020	Gateway	✓	✓	✓	✓		SP0005
USA	LX570	URJ	2008-2020	Accessory Gateway	✓	✓	✓	✓		SP0005
USA	LX570	URJ	2008-2020	Mayday Gateway	✓	✓	✓			
USA	LX570	URJ	2008-2020	Body No. 4	✓	✓	✓		0310, 0311, 0312, 0313, 0314, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0327, 0328, 0329	
USA	LX570	URJ	2008-2020	Body No. 5	✓	✓	✓		0031, 0032, 0033, 0331, 0332, 0333, 0334, 0335, 0336, 0337, 0338, 0339, 0340, 0341	
USA	LX570	URJ	2008-2020	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	

USA	LX570	URJ	2008-2020	Driver Door Motor	√	√	√		0528	SP0003
USA	LX570	URJ	2008-2020	Passenger Door Motor	√	√	√		0528	SP0003
USA	LX570	URJ	2008-2020	Left Rear Door Motor	√	√	√		0528	SP0003
USA	LX570	URJ	2008-2020	Right Rear Door Motor	√	√	√		0528	SP0003
USA	LX570	URJ	2008-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	LX570	URJ	2008-2020	Master Switch	√	√	√			
USA	LX570	URJ	2008-2020	Left Front Seat A/C	√	√	√		0351, 0352, 0353, 0354	
USA	LX570	URJ	2008-2020	Right Front Seat A/C	√	√	√		0351, 0352, 0353, 0354	
USA	LX570	URJ	2008-2020	Sliding Roof	√	√	√		0529	
USA	LX570	URJ	2008-2020	Tilt&Telescopic	√	√	√	√	0472, 0473	

USA	LX570	URJ	2008-2020	Combinati on Meter	✓	✓	✓	✓	0398, 0616, 0 617, 0618, 06 19, 0620, 062 1, 0622, 0623 , 0624, 0625, 0626, 0627, 0 628, 0629, 06 30, 0631, 063 2, 0633, 0634 , 0635, 0636, 0637, 0638, 0 639, 0640, 06 41, 0642, 064 3, 0644, 0645 , 0646, 0647, 0648, 0649, 0 650, 0651, 06 52, 0653, 065 4, 0655, 0656 , 0657, 0658, 0659, 0660, 0 661, 0662, 06 63, 0664, 066 5, 0666, 0667 , 0668, 0669, 0670, 0671, 0 672, 0673, 06 74, 0675, 067 6, 0677, 0678 , 0679, 0680,	
USA	LX570	URJ	2008-2020	Mirror	✓	✓	✓		0278, 0280, 0 281, 0282, 02 83, 0317, 042 6, 0427, 0428 , 0429, 0433, 0434, 0435, 0 436, 0437	
USA	LX570	URJ	2008-2020	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0 025, 0026	
USA	LX570	URJ	2008-2020	Rain Sensor	✓	✓	✓			
USA	LX570	URJ	2008-2020	AFS	✓	✓	✓	✓	0007, 0008, 0 009, 0474, 04 75, 0476, 047 7, 0478, 0479 , 0480, 0481, 0482, 0483, 0 484, 0485, 04 86, 0487, 048 8, 0489, 0490 , 0491, 0492, 0493	

USA	LX570	URJ	2008-2020	Smart Key	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	LX570	URJ	2008-2020	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
USA	LX570	URJ	2008-2020	Telematics	√	√	√	√		
USA	LX570	URJ	2008-2020	Radar Cruise	√	√	√	√		SP0061, SP0062
USA	LX570	URJ	2008-2020	Pre-Collision	√	√	√	√	0347, 0348, 0349, 0350	
USA	LX570	URJ	2008-2020	Advanced Parking Guidance/ Parking Assist Monitor	√	√	√	√		
USA	LX570	URJ	2008-2020	Navigatio n System	√	√	√	√		

USA	LX570	URJ	2008- 2020	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0083, 008 4, 0085, 0086 , 0087, 0088, 0089, 0096, 0 097, 0098, 00 99, 0100, 010 1, 0102, 0103 , 0104, 0105, 0106, 0107, 0 108, 0109, 01 10, 0111, 011 2, 0113, 0114 , 0115, 0116, 0117, 0118, 0 119, 0120, 01 21, 0122, 012 3, 0124, 0125 , 0126, 0127, 0128, 0129, 0 130, 0131, 01 32, 0133, 013 4, 0135, 0136 , 0137, 0138, 0139, 0140, 0 141, 0142, 01 43, 0144, 014 5, 0146, 0147 , 0148, 0149,	SP0004, SP0 026, SP0030 , SP0032, SP 0042, SP004 3, SP0072, S P0073, SP00 74, SP0075, SP0076, SP0 101
-----	-------	-----	---------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------

USA	LX570	URJ	2008-2020	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0072, SP0101
USA	LX570	URJ	2008-2020	4-Wheel Drive (4WD)	✓	✓	✓			
USA	LX570	URJ	2008-2020	PPS	✓	✓	✓	✓		
USA	LX570	URJ	2008-2020	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
USA	LX570	URJ	2008-2020	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086

USA	LX570	URJ	2008-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
USA	LX570	URJ	2008-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	LX570	URJ	2008-2020	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
USA	LX570	URJ	2008-2020	Central Gateway	√	√	√	√		
USA	LX570	URJ	2008-2020	Head Up Display	√	√	√	√	0047, 0048, 0049, 0050, 0051	
USA	LX570	URJ	2008-2020	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	LX570	URJ	2008-2020	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	LX570	URJ	2008-2020	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	LX570	URJ	2008-2020	Remote Engine Starter	√	√	√	√		SP0046
USA	LX570	URJ	2008-2020	Starting Control	√	√	√	√	0256, 0257	
USA	LX570	URJ	2008-2020	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071
USA	LX570	URJ	2008-2020	Slave Blind Spot Monitor	√	√	√	√		

USA	LX570	URJ	2008-2020	Automatic high beam	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
USA	LX570	URJ	2008-2020	Radar Cruise 1	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	LX570	URJ	2008-2020	Radar Cruise 2	√	√	√	√	0017, 0018	SP0061, SP0069
USA	LX570	URJ	2008-2020	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	



USA	NX200t	***	2015-2017	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	SP0004, SP0 026, SP0032 , SP0042, SP 0073, SP007 5, SP0101, S P0102
-----	--------	-----	-----------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------

USA	NX200t	***	2015-2017	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
USA	NX200t	***	2015-2017	Cruise Control	✓	✓	✓	✓		
USA	NX200t	***	2015-2017	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

USA	NX200t	***	2015-2017	ABS/VSC/T RAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
USA	NX200t	***	2015-2017	4-Wheel Drive (4WD)	√	√	√	√	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
USA	NX200t	***	2015-2017	Tire Pressure Monitor	√	√	√			SP0001, SP0002
USA	NX200t	***	2015-2017	EMPS	√	√	√	√		SP0001, SP0009, SP0010
USA	NX200t	***	2015-2017	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
USA	NX200t	***	2015-2017	Advanced Parking Guidance/ Parking Assist Monitor	√	√	√	√		

USA	NX200t	***	2015-2017	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	SP0086, SP0087
USA	NX200t	***	2015-2017	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	NX200t	***	2015-2017	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0001

USA	NX200t	***	2015-2017	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	NX200t	***	2015-2017	Gateway	√	√	√	√		SP0005
USA	NX200t	***	2015-2017	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	NX200t	***	2015-2017	Driver Door Motor	√	√	√		0528	SP0003
USA	NX200t	***	2015-2017	Passenger Door Motor	√	√	√		0528	SP0003
USA	NX200t	***	2015-2017	Left Rear Door Motor	√	√	√		0528	SP0003
USA	NX200t	***	2015-2017	Right Rear Door Motor	√	√	√		0528	SP0003
USA	NX200t	***	2015-2017	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	NX200t	***	2015-2017	Master Switch	√	√	√			
USA	NX200t	***	2015-2017	Sliding Roof	√	√	√		0529	

USA	NX200t	***	2015-2017	Tilt&Tele scopic	√	√	√	√	0472, 0473	
USA	NX200t	***	2015-2017	Combinati on Meter	√	√	√	√	0398, 0616, 0 617, 0618, 06 19, 0620, 062 1, 0622, 0623 , 0624, 0625, 0626, 0627, 0 628, 0629, 06 30, 0631, 063 2, 0633, 0634 , 0635, 0636, 0637, 0638, 0 639, 0640, 06 41, 0642, 064 3, 0644, 0645 , 0646, 0647, 0648, 0649, 0 650, 0651, 06 52, 0653, 065 4, 0655, 0656 , 0657, 0658, 0659, 0660, 0 661, 0662, 06 63, 0664, 066 5, 0666, 0667 , 0668, 0669, 0670, 0671, 0 672, 0673, 06 74, 0675, 067 6, 0677, 0678 , 0679, 0680,	
USA	NX200t	***	2015-2017	Left Mirror	√	√	√	√	0275, 0276, 0 277, 0278, 02 79, 0280, 028 1, 0282, 0283 , 0284	
USA	NX200t	***	2015-2017	Right Mirror	√	√	√	√	0275, 0276, 0 277, 0278, 02 79, 0280, 028 1, 0282, 0283 , 0284	
USA	NX200t	***	2015-2017	Intuitive Parking Assist	√	√	√	√	0023, 0024, 0 025, 0026	
USA	NX200t	***	2015-2017	Auto Leveling Of Headlamp	√	√	√	√	0001, 0002, 0 003, 0004, 00 05, 0006, 000 7, SP0008	

USA	NX200t	***	2015-2017	Smart Key	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	NX200t	***	2015-2017	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	NX200t	***	2015-2017	Detection Of Occupant	√	√	√	√		SP0034, SP0035, SP0036
USA	NX200t	***	2015-2017	Starting Control	√	√	√	√	0256, 0257	
USA	NX200t	***	2015-2017	Navigation System	√	√	√	√		
USA	NX200t	***	2015-2017	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071
USA	NX200t	***	2015-2017	Slave Blind Spot Monitor	√	√	√	√		
USA	NX200t	***	2015-2017	ASC	√	√	√	√	1182	
USA	NX200t	***	2015-2017	Telematics	√	√	√	√		
USA	NX200t	***	2015-2017	Radar Cruise	√	√	√	√		
USA	NX200t	***	2015-2017	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
USA	NX200t	***	2015-2017	Accessory Gateway	√	√	√	√		SP0005
USA	NX200t	***	2015-2017	Remote Engine Starter	√	√	√	√		SP0046

USA	NX200t	***	2015-2017	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	NX300	***	2018-2021	Engine	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	SP0004, SP0026, SP0032, SP0042, SP0073, SP0075, SP0098, SP0099, SP0100, SP0101, SP0102, SP0114, SP0115, SP0116, SP0162



USA	NX300	***	2018-2021	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	SP0004, SP0029, SP0032, SP0101
USA	NX300	***	2018-2021	Cruise Control	✓	✓	✓	✓		
USA	NX300	***	2018-2021	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

USA	NX300	***	2018-2021	ABS/VSC/T RAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084, SP0149
USA	NX300	***	2018-2021	4-Wheel Drive (4WD)	√	√	√	√	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
USA	NX300	***	2018-2021	Tire Pressure Monitor	√	√	√			SP0001, SP0002, SP0117, SP0118, SP0119
USA	NX300	***	2018-2021	EMPS	√	√	√	√		SP0001, SP0009, SP0010
USA	NX300	***	2018-2021	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
USA	NX300	***	2018-2021	Front Recognition Camera	√	√	√	√	0052	SP0126, SP0134, SP0182, SP0183, SP0184

USA	NX300	***	2018-2021	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
USA	NX300	***	2018-2021	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	NX300	***	2018-2021	Panoramic view monitor	√	√	√	√		
USA	NX300	***	2018-2021	Parking Assist Camera	√	√	√	√		
USA	NX300	***	2018-2021	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0051, SP0169, SP0170, SP0171, SP0172, SP0173

USA	NX300	***	2018-2021	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
USA	NX300	***	2018-2021	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044, SP0127, SP0128, SP0134, SP0143, SP0144
USA	NX300	***	2018-2021	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	NX300	***	2018-2021	Accessory Gateway	✓	✓	✓	✓		SP0005
USA	NX300	***	2018-2021	Central Gateway	✓	✓	✓	✓		SP0005
USA	NX300	***	2018-2021	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	NX300	***	2018-2021	Driver Door Motor	✓	✓	✓		0528	SP0003
USA	NX300	***	2018-2021	Passenger Door Motor	✓	✓	✓		0528	SP0003

USA	NX300	***	2018-2021	Left Rear Door Motor	√	√	√		0528	SP0003
USA	NX300	***	2018-2021	Right Rear Door Motor	√	√	√		0528	SP0003
USA	NX300	***	2018-2021	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	NX300	***	2018-2021	Master Switch	√	√	√			
USA	NX300	***	2018-2021	Sliding Roof	√	√	√		0529	
USA	NX300	***	2018-2021	Tilt&Telescopic	√	√	√	√	0472, 0473	
USA	NX300	***	2018-2021	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	SP0174
USA	NX300	***	2018-2021	Head Up Display	√	√	√	√	0047, 0048, 0049, 0050, 0051	

USA	NX300	***	2018-2021	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	NX300	***	2018-2021	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	NX300	***	2018-2021	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
USA	NX300	***	2018-2021	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	SP0166
USA	NX300	***	2018-2021	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	SP0008, SP0166
USA	NX300	***	2018-2021	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0012, SP0014, SP0015, SP0018, SP0167, SP0168
USA	NX300	***	2018-2021	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	NX300	***	2018-2021	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036, SP0176
USA	NX300	***	2018-2021	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048

USA	NX300	***	2018-2021	Starting Control	√	√	√	√	0256, 0257	
USA	NX300	***	2018-2021	Navigation System	√	√	√	√		SP0049, SP0050, SP0078, SP0079, SP0154, SP0155, SP0163, SP0164, SP0165
USA	NX300	***	2018-2021	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071, SP0177, SP0178
USA	NX300	***	2018-2021	Slave Blind Spot Monitor	√	√	√	√		SP0137, SP0179, SP0180, SP0181
USA	NX300	***	2018-2021	ASC	√	√	√	√	1182	
USA	NX300	***	2018-2021	Telematics	√	√	√	√	1521, 1522	SP0158, SP0159, SP0160
USA	NX300	***	2018-2021	Radar Cruise 1	√	√	√	√		
USA	NX300	***	2018-2021	Radar Cruise 2	√	√	√	√	0017, 0018, 1504, 1505	SP0061, SP0069, SP0134
USA	NX300	***	2018-2021	Brake/EPB	√	√	√		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
USA	NX300	***	2018-2021	Lane Control	√	√	√		0824, 0989	
USA	NX300	***	2018-2021	Pre-Collision System	√	√	√		1524, 1525, 1526	
USA	NX300	***	2018-2021	Road Sign Assist	√	√	√			
USA	NX300	***	2018-2021	Front Recognition Camera (Front Lighting Control)	√	√	√			
USA	NX300	***	2018-2021	Front Radar Sensor	√	√	√			

USA	NX300h	AYZ	2015-2021	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
USA	NX300h	AYZ	2015-2021	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058
USA	NX300h	AYZ	2015-2021	Cruise Control	✓	✓	✓	✓		



USA	NX300h	AYZ	2015-2021	ABS/VSC/T RAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0088
USA	NX300h	AYZ	2015-2021	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	NX300h	AYZ	2015-2021	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	NX300h	AYZ	2015-2021	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
USA	NX300h	AYZ	2015-2021	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		
USA	NX300h	AYZ	2015-2021	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087

USA	NX300h	AYZ	2015-2021	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	NX300h	AYZ	2015-2021	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	NX300h	AYZ	2015-2021	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	NX300h	AYZ	2015-2021	HV Gateway	√	√	√	√		SP0005
USA	NX300h	AYZ	2015-2021	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	NX300h	AYZ	2015-2021	Driver Door Motor	√	√	√		0528	SP0003
USA	NX300h	AYZ	2015-2021	Passenger Door Motor	√	√	√		0528	SP0003
USA	NX300h	AYZ	2015-2021	Left Rear Door Motor	√	√	√		0528	SP0003
USA	NX300h	AYZ	2015-2021	Right Rear Door Motor	√	√	√		0528	SP0003
USA	NX300h	AYZ	2015-2021	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	NX300h	AYZ	2015-2021	Master Switch	√	√	√			
USA	NX300h	AYZ	2015-2021	Sliding Roof	√	√	√		0529	

USA	NX300h	AYZ	2015-2021	Tilt&Telescopic	√	√	√	√	0472, 0473	
USA	NX300h	AYZ	2015-2021	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	NX300h	AYZ	2015-2021	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	NX300h	AYZ	2015-2021	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	NX300h	AYZ	2015-2021	Intuitive Parking Assist	√	√	√	√	0023, 0024, 0025, 0026	
USA	NX300h	AYZ	2015-2021	Auto Leveling Of Headlamp	√	√	√	√	0001, 0002, 0003, 0004, 0005, 0006, 0007, SP0008	

USA	NX300h	AYZ	2015-2021	Smart Key	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	NX300h	AYZ	2015-2021	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	NX300h	AYZ	2015-2021	Detection Of Occupant	√	√	√	√		SP0034, SP0035, SP0036
USA	NX300h	AYZ	2015-2021	Navigation System	√	√	√	√		
USA	NX300h	AYZ	2015-2021	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071
USA	NX300h	AYZ	2015-2021	Slave Blind Spot Monitor	√	√	√	√		
USA	NX300h	AYZ	2015-2021	Notification System Of Vehicle Proximity	√	√	√		0044, 0045, 0046	
USA	NX300h	AYZ	2015-2021	ASC	√	√	√	√	1182	
USA	NX300h	AYZ	2015-2021	Telematics	√	√	√	√	1521, 1522	
USA	NX300h	AYZ	2015-2021	Radar Cruise	√	√	√	√		
USA	NX300h	AYZ	2015-2021	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
USA	NX300h	AYZ	2015-2021	Accessory Gateway	√	√	√	√		SP0005
USA	NX300h	AYZ	2015-2021	Remote Engine Starter	√	√	√	√		SP0046

USA	NX300h	AYZ	2015-2021	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	NX300h	AYZ	2015-2021	Front Recognition Camera	✓	✓	✓	✓	0052	
USA	NX300h	AYZ	2015-2021	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
USA	NX300h	AYZ	2015-2021	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	✓	✓	✓	✓		
USA	NX300h	AYZ	2015-2021	Panoramic view monitor	✓	✓	✓	✓		
USA	NX300h	AYZ	2015-2021	Parking Assist Camera	✓	✓	✓	✓		
USA	NX300h	AYZ	2015-2021	Central Gateway	✓	✓	✓	✓		
USA	NX300h	AYZ	2015-2021	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
USA	NX300h	AYZ	2015-2021	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	

USA	NX300h	AYZ	2015-2021	Radar Cruise 1	√	√	√	√			
USA	NX300h	AYZ	2015-2021	Radar Cruise 2	√	√	√	√	1504, 1505		
USA	NX300h	AYZ	2015-2021	Lane Control	√	√	√		0824, 0989		
USA	NX300h	AYZ	2015-2021	Pre-Collision System	√	√	√		1524, 1525, 1526		
USA	NX300h	AYZ	2015-2021	Road Sign Assist	√	√	√				
USA	NX300h	AYZ	2015-2021	Front Recognition Camera (Front Lighting Control)	√	√	√				
USA	NX300h	AYZ	2015-2021	Front Radar Sensor	√	√	√				
USA	RC-F	USC	2015-2020	Engine	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0029, SP0030, SP0032, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0098, SP0099, SP0100, SP0101, SP0116, SP0161, SP0162	

USA	RC-F	USC	2015-2020	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0072, SP0101
USA	RC-F	USC	2015-2020	Cruise Control	✓	✓	✓	✓		
USA	RC-F	USC	2015-2020	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0117, SP0118, SP0119
USA	RC-F	USC	2015-2020	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	RC-F	USC	2015-2020	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		
USA	RC-F	USC	2015-2020	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087



USA	RC-F	USC	2015-2020	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051, SP0169, SP0170, SP0171, SP0172, SP0173
USA	RC-F	USC	2015-2020	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	RC-F	USC	2015-2020	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	RC-F	USC	2015-2020	Gateway	✓	✓	✓	✓		SP0005
USA	RC-F	USC	2015-2020	Driver Door Motor	✓	✓	✓		0528	SP0003
USA	RC-F	USC	2015-2020	Passenger Door Motor	✓	✓	✓		0528	SP0003
USA	RC-F	USC	2015-2020	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	RC-F	USC	2015-2020	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	RC-F	USC	2015-2020	Master Switch	✓	✓	✓			
USA	RC-F	USC	2015-2020	Sliding Roof	✓	✓	✓		0529	
USA	RC-F	USC	2015-2020	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	

USA	RC-F	USC	2015-2020	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	SP0174
USA	RC-F	USC	2015-2020	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	RC-F	USC	2015-2020	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	RC-F	USC	2015-2020	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
USA	RC-F	USC	2015-2020	Auto Leveling Of Headlamp	✓	✓	✓	✓	0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	SP0008, SP0166

USA	RC-F	USC	2015-2020	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	RC-F	USC	2015-2020	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	RC-F	USC	2015-2020	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036, SP0176
USA	RC-F	USC	2015-2020	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	RC-F	USC	2015-2020	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0078, SP0079, SP0154, SP0155, SP0163, SP0164, SP0165
USA	RC-F	USC	2015-2020	Active Rear Wing	✓	✓	✓	✓	1189, 1190, 1191, 1192, 1193	SP0136
USA	RC-F	USC	2015-2020	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071, SP0177, SP0178
USA	RC-F	USC	2015-2020	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071, SP0137, SP0179, SP0180, SP0181
USA	RC-F	USC	2015-2020	ASC	✓	✓	✓	✓	1182	
USA	RC-F	USC	2015-2020	Telematics	✓	✓	✓	✓		SP0158, SP0159, SP0160
USA	RC-F	USC	2015-2020	Radar Cruise	✓	✓	✓	✓		
USA	RC-F	USC	2015-2020	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044, SP0127, SP0128, SP0134, SP0143, SP0144

USA	RC-F	USC	2015-2020	ABS/VSC/T RAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
USA	RC-F	USC	2015-2020	TVD	✓	✓	✓	✓	0042, 0043	SP0004, SP0194
USA	RC-F	USC	2015-2020	Accessory Gateway	✓	✓	✓	✓		SP0005
USA	RC-F	USC	2015-2020	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	RC-F	USC	2015-2020	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

USA	RC-F	USC	2015-2020	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0012, SP0014, SP0015, SP0018, SP0167, SP0168
USA	RC-F	USC	2015-2020	Front Recognition Camera	✓	✓	✓	✓	0052	SP0126, SP0134, SP0182, SP0183, SP0184
USA	RC-F	USC	2015-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
USA	RC-F	USC	2015-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	✓	✓	✓	✓		
USA	RC-F	USC	2015-2020	Central Gateway	✓	✓	✓	✓		SP0005
USA	RC-F	USC	2015-2020	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	SP0001, SP0003, SP0023, SP0024, SP0157
USA	RC-F	USC	2015-2020	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	SP0008, SP0166

USA	RC200t	***	2016- 2017	Engine	√	√	√	√	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 , SP0004, SP0 37, 0249, 025 0042, SP007 0, 0254, 0258 3, SP0075, S , 0262, 1194, P0098, SP00 1195, 1196, 1 99, SP0100, 197, 1198, 11 SP0101, SP0 99, 1200, 120 102, SP0114 1, 1202, 1203 , SP0115, SP , 1204, 1205, 0116, SP016 1206, 1207, 1 2 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,
-----	--------	-----	---------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

USA	RC200t	***	2016-2017	Transmission	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	SP0004, SP0029, SP0032, SP0101
USA	RC200t	***	2016-2017	Cruise Control	√	√	√	√		
USA	RC200t	***	2016-2017	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007



USA	RC200t	***	2016-2017	ABS/VSC/T RAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084, SP0149
USA	RC200t	***	2016-2017	Tire Pressure Monitor	√	√	√		SP0001, SP0002, SP0117, SP0118, SP0119	
USA	RC200t	***	2016-2017	EMPS	√	√	√	√	SP0001, SP0009, SP0010	
USA	RC200t	***	2016-2017	Advanced Parking Guidance/Parking Assist Monitor	√	√	√	√		
USA	RC200t	***	2016-2017	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	SP0086, SP0087

USA	RC200t	***	2016-2017	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051, SP0169, SP0170, SP0171, SP0172, SP0173
USA	RC200t	***	2016-2017	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	RC200t	***	2016-2017	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	RC200t	***	2016-2017	Gateway	√	√	√	√		SP0005
USA	RC200t	***	2016-2017	Accessory Gateway	√	√	√	√		SP0005
USA	RC200t	***	2016-2017	Driver Door Motor	√	√	√		0528	SP0003
USA	RC200t	***	2016-2017	Passenger Door Motor	√	√	√		0528	SP0003
USA	RC200t	***	2016-2017	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	RC200t	***	2016-2017	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	RC200t	***	2016-2017	Master Switch	√	√	√			
USA	RC200t	***	2016-2017	Sliding Roof	√	√	√		0529	
USA	RC200t	***	2016-2017	Tilt&Telescopic	√	√	√	√	0472, 0473	

USA	RC200t	***	2016-2017	Combinati on Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	SP0174
USA	RC200t	***	2016-2017	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	RC200t	***	2016-2017	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	RC200t	***	2016-2017	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
USA	RC200t	***	2016-2017	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, SP008	

USA	RC200t	***	2016-2017	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0012, SP0013, SP0014, SP0015, SP0018, SP0167, SP0168
USA	RC200t	***	2016-2017	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	RC200t	***	2016-2017	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036, SP0176
USA	RC200t	***	2016-2017	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
USA	RC200t	***	2016-2017	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	RC200t	***	2016-2017	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0078, SP0079, SP0154, SP0155, SP0163, SP0164, SP0165
USA	RC200t	***	2016-2017	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071, SP0177, SP0178
USA	RC200t	***	2016-2017	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0137, SP0179, SP0180, SP0181
USA	RC200t	***	2016-2017	ASC	✓	✓	✓	✓	1182	
USA	RC200t	***	2016-2017	Telematics	✓	✓	✓	✓		SP0158, SP0159, SP0160
USA	RC200t	***	2016-2017	Radar Cruise	✓	✓	✓	✓		
USA	RC200t	***	2016-2017	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044, SP0127, SP0128, SP0134, SP0143, SP0144

USA	RC200t	***	2016-2017	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553
USA	RC300	***	2018-2020	Engine	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,

USA	RC300	***	2018-2020	Transmission	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
USA	RC300	***	2018-2020	Radar Cruise	√	√	√	√	
USA	RC300	***	2018-2020	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471

USA	RC300	***	2018-2020	ABS/VSC/T RAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	
USA	RC300	***	2018-2020	Tire Pressure Monitor	√	√	√			
USA	RC300	***	2018-2020	EMPS	√	√	√	√		
USA	RC300	***	2018-2020	Advanced Parking Guidance/ Parking Assist Monitor	√	√	√	√		
USA	RC300	***	2018-2020	Front Recognition Camera	√	√	√	√	0052	
USA	RC300	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	



USA	RC300	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	RC300	***	2018-2020	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
USA	RC300	***	2018-2020	Supplement Restraint System (SRS) Airbag	√	√	√	√		
USA	RC300	***	2018-2020	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	

USA	RC300	***	2018-2020	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
USA	RC300	***	2018-2020	Accessory Gateway	√	√	√	√		
USA	RC300	***	2018-2020	Central Gateway	√	√	√	√		
USA	RC300	***	2018-2020	Driver Door Motor	√	√	√		0528	
USA	RC300	***	2018-2020	Passenger Door Motor	√	√	√		0528	
USA	RC300	***	2018-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	RC300	***	2018-2020	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	RC300	***	2018-2020	Master Switch	√	√	√			
USA	RC300	***	2018-2020	Sliding Roof	√	√	√		0529	
USA	RC300	***	2018-2020	Tilt&Telescopic	√	√	√	√	0472, 0473	

USA	RC300	***	2018-2020	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
USA	RC300	***	2018-2020	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	RC300	***	2018-2020	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	RC300	***	2018-2020	Intuitive Parking Assist	√	√	√	√	0023, 0024, 0025, 0026
USA	RC300	***	2018-2020	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015

USA	RC300	***	2018-2020	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	RC300	***	2018-2020	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	
USA	RC300	***	2018-2020	Detection Of Occupant	√	√	√	√		
USA	RC300	***	2018-2020	Remote Engine Starter	√	√	√	√		
USA	RC300	***	2018-2020	Starting Control	√	√	√	√	0256, 0257	
USA	RC300	***	2018-2020	Navigation System	√	√	√	√		
USA	RC300	***	2018-2020	Master Blind Spot Monitor	√	√	√	√		
USA	RC300	***	2018-2020	Slave Blind Spot Monitor	√	√	√	√		
USA	RC300	***	2018-2020	ASC	√	√	√	√	1182	
USA	RC300	***	2018-2020	Telematics	√	√	√	√	1521, 1522	
USA	RC300	***	2018-2020	Radar Cruise 1	√	√	√	√		
USA	RC300	***	2018-2020	4-Wheel Drive (4WD)	√	√	√	√	0819, 0820, 0821, 0822	
USA	RC300	***	2018-2020	VGRS	√	√	√	√		
USA	RC300	***	2018-2020	DRS	√	√	√	√		

USA	RC300	***	2018-2020	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	RC300	GSC	2016-2017	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
USA	RC300	GSC	2016-2017	Cruise Control	√	√	√	√		

USA	RC300	GSC	2016-2017	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
USA	RC300	GSC	2016-2017	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
USA	RC300	GSC	2016-2017	4-Wheel Drive (4WD)	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
USA	RC300	GSC	2016-2017	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	RC300	GSC	2016-2017	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010

USA	RC300	GSC	2016-2017	VGRS	✓	✓	✓	✓		SP0004, SP0037
USA	RC300	GSC	2016-2017	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		
USA	RC300	GSC	2016-2017	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
USA	RC300	GSC	2016-2017	DRS	✓	✓	✓	✓		SP0004, SP0081, SP0082, SP0083
USA	RC300	GSC	2016-2017	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	RC300	GSC	2016-2017	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	RC300	GSC	2016-2017	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	RC300	GSC	2016-2017	Gateway	✓	✓	✓	✓		SP0005
USA	RC300	GSC	2016-2017	Accessory Gateway	✓	✓	✓	✓		SP0005
USA	RC300	GSC	2016-2017	Driver Door Motor	✓	✓	✓		0528	SP0003
USA	RC300	GSC	2016-2017	Passenger Door Motor	✓	✓	✓		0528	SP0003
USA	RC300	GSC	2016-2017	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	RC300	GSC	2016-2017	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	RC300	GSC	2016-2017	Master Switch	✓	✓	✓			
USA	RC300	GSC	2016-2017	Sliding Roof	✓	✓	✓		0529	
USA	RC300	GSC	2016-2017	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	



USA	RC300	GSC	2016-2017	Combinati on Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
USA	RC300	GSC	2016-2017	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	RC300	GSC	2016-2017	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	RC300	GSC	2016-2017	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026
USA	RC300	GSC	2016-2017	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, SP0008

USA	RC300	GSC	2016-2017	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	RC300	GSC	2016-2017	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	RC300	GSC	2016-2017	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036
USA	RC300	GSC	2016-2017	Remote Engine Starter	✓	✓	✓	✓		SP0046
USA	RC300	GSC	2016-2017	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	RC300	GSC	2016-2017	Navigation System	✓	✓	✓	✓		
USA	RC300	GSC	2016-2017	Multi Bus Gateway	✓	✓	✓	✓		
USA	RC300	GSC	2016-2017	No. 1 Multi Bus Monitor	✓	✓	✓	✓		
USA	RC300	GSC	2016-2017	No. 2 Multi Bus Monitor	✓	✓	✓	✓		
USA	RC300	GSC	2016-2017	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	RC300	GSC	2016-2017	Slave Blind Spot Monitor	✓	✓	✓	✓		
USA	RC300	GSC	2016-2017	ASC	✓	✓	✓	✓	1182	
USA	RC300	GSC	2016-2017	Telematics	✓	✓	✓	✓		
USA	RC300	GSC	2016-2017	Radar Cruise	✓	✓	✓	✓		
USA	RC300	GSC	2016-2017	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

USA	RC300	GSC	2016-2017	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553
USA	RC350	***	2018-2020	Engine	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,

USA	RC350	***	2018-2020	Transmission	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
USA	RC350	***	2018-2020	Radar Cruise	√	√	√	√	
USA	RC350	***	2018-2020	Air suspension	√	√	√	√	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471

USA	RC350	***	2018-2020	ABS/VSC/T RAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	
USA	RC350	***	2018-2020	4-Wheel Drive (4WD)	√	√	√	√	0819, 0820, 0821, 0822	
USA	RC350	***	2018-2020	Tire Pressure Monitor	√	√	√			
USA	RC350	***	2018-2020	EMPS	√	√	√	√		
USA	RC350	***	2018-2020	VGRS	√	√	√	√		
USA	RC350	***	2018-2020	Advanced Parking Guidance/ Parking Assist Monitor	√	√	√	√		
USA	RC350	***	2018-2020	Front Recognition Camera	√	√	√	√	0052	

USA	RC350	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
USA	RC350	***	2018-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	RC350	***	2018-2020	DRS	√	√	√	√		
USA	RC350	***	2018-2020	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
USA	RC350	***	2018-2020	Supplement Restraint System (SRS) Airbag	√	√	√	√		

USA	RC350	***	2018-2020	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
USA	RC350	***	2018-2020	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
USA	RC350	***	2018-2020	Accessory Gateway	√	√	√	√		
USA	RC350	***	2018-2020	Central Gateway	√	√	√	√		
USA	RC350	***	2018-2020	Driver Door Motor	√	√	√		0528	
USA	RC350	***	2018-2020	Passenger Door Motor	√	√	√		0528	
USA	RC350	***	2018-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	RC350	***	2018-2020	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	RC350	***	2018-2020	Master Switch	√	√	√			

USA	RC350	***	2018-2020	Sliding Roof	✓	✓	✓		0529	
USA	RC350	***	2018-2020	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
USA	RC350	***	2018-2020	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	
USA	RC350	***	2018-2020	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	RC350	***	2018-2020	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	RC350	***	2018-2020	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
USA	RC350	***	2018-2020	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	



USA	RC350	***	2018-2020	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	RC350	***	2018-2020	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
USA	RC350	***	2018-2020	Detection Of Occupant	✓	✓	✓	✓		
USA	RC350	***	2018-2020	Remote Engine Starter	✓	✓	✓	✓		
USA	RC350	***	2018-2020	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	RC350	***	2018-2020	Navigation System	✓	✓	✓	✓		
USA	RC350	***	2018-2020	Master Blind Spot Monitor	✓	✓	✓	✓		
USA	RC350	***	2018-2020	Slave Blind Spot Monitor	✓	✓	✓	✓		
USA	RC350	***	2018-2020	ASC	✓	✓	✓	✓	1182	
USA	RC350	***	2018-2020	Telematics	✓	✓	✓	✓	1521, 1522	
USA	RC350	***	2018-2020	Cruise Control	✓	✓	✓	✓		
USA	RC350	***	2018-2020	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	

USA	RC350	GSC	2015-2017	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0030, SP0032, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
-----	-------	-----	-----------	--------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------

USA	RC350	GSC	2015-2017	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0072, SP0101
USA	RC350	GSC	2015-2017	Cruise Control	✓	✓	✓	✓		
USA	RC350	GSC	2015-2017	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

USA	RC350	GSC	2015-2017	ABS/VSC/T RAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084
USA	RC350	GSC	2015-2017	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	RC350	GSC	2015-2017	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	RC350	GSC	2015-2017	VGRS	✓	✓	✓	✓		SP0004, SP0037
USA	RC350	GSC	2015-2017	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		
USA	RC350	GSC	2015-2017	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
USA	RC350	GSC	2015-2017	DRS	✓	✓	✓	✓		SP0004, SP0081, SP0082, SP0083

USA	RC350	GSC	2015-2017	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017
USA	RC350	GSC	2015-2017	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	RC350	GSC	2015-2017	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	RC350	GSC	2015-2017	Gateway	√	√	√	√		SP0005
USA	RC350	GSC	2015-2017	Driver Door Motor	√	√	√		0528	SP0003
USA	RC350	GSC	2015-2017	Passenger Door Motor	√	√	√		0528	SP0003
USA	RC350	GSC	2015-2017	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	RC350	GSC	2015-2017	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	RC350	GSC	2015-2017	Master Switch	√	√	√			
USA	RC350	GSC	2015-2017	Sliding Roof	√	√	√		0529	
USA	RC350	GSC	2015-2017	Tilt&Telescopic	√	√	√	√	0472, 0473	

USA	RC350	GSC	2015-2017	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,
USA	RC350	GSC	2015-2017	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	RC350	GSC	2015-2017	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	RC350	GSC	2015-2017	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026
USA	RC350	GSC	2015-2017	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, SP0008

USA	RC350	GSC	2015-2017	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	RC350	GSC	2015-2017	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	RC350	GSC	2015-2017	Detection Of Occupant	✓	✓	✓	✓		SP0034, SP0035, SP0036
USA	RC350	GSC	2015-2017	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	RC350	GSC	2015-2017	Navigation System	✓	✓	✓	✓		
USA	RC350	GSC	2015-2017	Multi Bus Gateway	✓	✓	✓	✓		
USA	RC350	GSC	2015-2017	No. 1 Multi Bus Monitor	✓	✓	✓	✓		
USA	RC350	GSC	2015-2017	No. 2 Multi Bus Monitor	✓	✓	✓	✓		
USA	RC350	GSC	2015-2017	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
USA	RC350	GSC	2015-2017	Slave Blind Spot Monitor	✓	✓	✓	✓		
USA	RC350	GSC	2015-2017	ASC	✓	✓	✓	✓	1182	
USA	RC350	GSC	2015-2017	Telematics	✓	✓	✓	✓		



USA	RC350	GSC	2015-2017	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0101
USA	RC350	GSC	2015-2017	4-Wheel Drive (4WD)	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
USA	RC350	GSC	2015-2017	Radar Cruise	✓	✓	✓	✓		
USA	RC350	GSC	2015-2017	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
USA	RC350	GSC	2015-2017	Accessory Gateway	✓	✓	✓	✓		SP0005
USA	RC350	GSC	2015-2017	Remote Engine Starter	✓	✓	✓	✓		SP0046

USA	RC350	GSC	2015-2017	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	RX300	MCU	1999-2003	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004, SP0026
USA	RX300	MCU	1999-2003	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	

USA	RX300	MCU	1999-2003	Immobiliser	✓	✓	✓			SP0065, SP0066, SP0148
USA	RX300	MCU	1999-2003	Supplement Restraint System (SRS) Airbag	✓	✓				SP0004
USA	RX300	MCU	1999-2003	Body	✓	✓	✓		0031, 0032, 0319, 0333, 0337, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0807, 0816, 0913, 0914, 0915, 0922, 0923, 0931, 0932, 0934, 0935, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013	SP0005, SP0019, SP0020
USA	RX300	MCU	1999-2003	Driver Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	RX300	MCU	1999-2003	Passenger Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	RX300	MCU	1999-2003	Left Rear Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	RX300	MCU	1999-2003	Right Rear Door	✓	✓	✓		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	

USA	RX300	MCU	1999-2003	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
USA	RX300	MCU	1999-2003	Sliding Roof			√		0529	
USA	RX300	MCU	1999-2003	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	

USA	RX300	MCU	1999– 2003	ABS/VSC/T RAC	✓	✓	✓	✓	0821, 0822, 0 826, 0827, 08 28, 0829, 083 1, 0840, 0848 , 0849, 0854, 0855, 0856, 0 857, 0876, 08 89, 0890, 089 9, 0900, 0901 , 0902, 0903, 0904, 0905, 0 906, 0907, 09 09, 0910, 091 1, 1077, 1078 , 1079, 1080, 1081, 1083, 1 096, 1098, 10 99, 1101, 110 2, 1104, 1105 , 1106, 1117, 1118, 1121, 1 122, 1123, 11 24, 1125, 153 8, 1547, 1548 , 1549, 1550, 1551, 1552, 1 553, 1554, 15 55, 1556, 155 7, 1558, 1559 , 1560, 1561,	SP0001, SPO 003, SP0021 , SP0023
-----	-------	-----	---------------	------------------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------

USA	RX330	MCU	2004-2006	Engine and ECT	√	√	√	√	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004, SP0026
USA	RX330	MCU	2004-2006	Laser Cruise	√	√	√	√		
USA	RX330	MCU	2004-2006	Air suspension	√	√	√		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001, SP0007

USA	RX330	MCU	2004-2006	ABS/VSC/TRAC	√	√	√	√	0821, 0822, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1083, 1096, 1098, 1099, 1101, 1102, 1104, 1105, 1106, 1117, 1118, 1121, 1122, 1123, 1124, 1125, 1538, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561,	SP0001, SP0003, SP0021, SP0023
USA	RX330	MCU	2004-2006	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
USA	RX330	MCU	2004-2006	Immobiliser	√	√	√		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066
USA	RX330	MCU	2004-2006	Supplement Restraint System (SRS) Airbag	√	√				SP0004

USA	RX330	MCU	2004-2006	Body	√	√	√	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005, SP0019, SP0020
USA	RX330	MCU	2004-2006	Back Door	√	√	√	0316, 0429, 0521, 0522, 0523, 0524, 0526, 0528, 0967, 0992	
USA	RX330	MCU	2004-2006	Driver Seat			√	0422, 0423, 0424, 0515, 0516, 0517	
USA	RX330	MCU	2004-2006	Master Switch			√	0939, 0940, 0941, 0942	
USA	RX330	MCU	2004-2006	Sliding Roof			√	0529	
USA	RX330	MCU	2004-2006	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005



USA	RX330	MCU	2004-2006	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
USA	RX330	MCU	2004-2006	Left Mirror			√		0279, 0280, 0281, 0282, 0283	
USA	RX330	MCU	2004-2006	Right Mirror			√		0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
USA	RX330	MCU	2004-2006	Rain Sensor			√			
USA	RX330	MCU	2004-2006	Wiper			√		0031, 0032, 0332	
USA	RX330	MCU	2004-2006	AFS	√	√	√		0008, 0475, 0476, 0477, 0968	SP0064
USA	RX330	MCU	2004-2006	Detection Of Occupant	√	√	√			SP0034, SP0035, SP0036
USA	RX330	MCU	2004-2006	Cruise Control	√	√	√	√		

USA	RX350	***	2016-2020	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	SP0004, SP0026, SP0029, SP0032, SP0042, SP0073, SP0075, SP0098, SP0099, SP0100, SP0101, SP0102, SP0114, SP0115, SP0116, SP0162
-----	-------	-----	-----------	--------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------

USA	RX350	***	2016-2020	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	SP0004, SP0029, SP0032, SP0101
USA	RX350	***	2016-2020	Cruise Control	✓	✓	✓	✓		
USA	RX350	***	2016-2020	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

USA	RX350	***	2016-2020	ABS/VSC/TRAC/EPB	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	
USA	RX350	***	2016-2020	4-Wheel Drive (4WD)	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
USA	RX350	***	2016-2020	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0117, SP0118, SP0119
USA	RX350	***	2016-2020	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	RX350	***	2016-2020	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0087, SP0126, SP0182, SP0183
USA	RX350	***	2016-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	

USA	RX350	***	2016-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	✓	✓	✓	✓		
USA	RX350	***	2016-2020	Panoramic view monitor	✓	✓	✓	✓		
USA	RX350	***	2016-2020	Parking Assist Camera	✓	✓	✓	✓		
USA	RX350	***	2016-2020	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051, SP0169, SP0170, SP0171, SP0172, SP0173
USA	RX350	***	2016-2020	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001
USA	RX350	***	2016-2020	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

USA	RX350	***	2016-2020	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	RX350	***	2016-2020	Accessory Gateway	√	√	√	√		SP0005
USA	RX350	***	2016-2020	Central Gateway	√	√	√	√		SP0005
USA	RX350	***	2016-2020	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	RX350	***	2016-2020	Driver Door Motor	√	√	√		0528	SP0003
USA	RX350	***	2016-2020	Passenger Door Motor	√	√	√		0528	SP0003
USA	RX350	***	2016-2020	Left Rear Door Motor	√	√	√		0528	SP0003
USA	RX350	***	2016-2020	Right Rear Door Motor	√	√	√		0528	SP0003
USA	RX350	***	2016-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	RX350	***	2016-2020	Master Switch	√	√	√			

USA	RX350	***	2016-2020	Sliding Roof	√	√	√		0529	
USA	RX350	***	2016-2020	Sliding Sunshade	√	√	√		1181	
USA	RX350	***	2016-2020	Tilt&Telescopic	√	√	√	√	0472, 0473	
USA	RX350	***	2016-2020	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683, 0684	SP0174
USA	RX350	***	2016-2020	Head Up Display	√	√	√	√	0047, 0048, 0049, 0050, 0051	
USA	RX350	***	2016-2020	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	RX350	***	2016-2020	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	

USA	RX350	***	2016-2020	Advanced Parking Guidance/ Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A)	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006, SP0091, SP0185
USA	RX350	***	2016-2020	Rain Sensor	✓	✓	✓			
USA	RX350	***	2016-2020	Wiper	✓	✓	✓	✓	0031, 0032	
USA	RX350	***	2016-2020	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	SP0166
USA	RX350	***	2016-2020	Auto Leveling Of Headlamp	✓	✓	✓	✓	0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	SP0008, SP0166
USA	RX350	***	2016-2020	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	RX350	***	2016-2020	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	RX350	***	2016-2020	Detection Of Occupant	✓	✓	✓	✓	0034	



USA	RX350	***	2016-2020	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
USA	RX350	***	2016-2020	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	RX350	***	2016-2020	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0078, SP0079, SP0154, SP0155, SP0163, SP0164, SP0165
USA	RX350	***	2016-2020	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071, SP0177, SP0178
USA	RX350	***	2016-2020	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0137, SP0179, SP0180, SP0181
USA	RX350	***	2016-2020	Telematics	✓	✓	✓	✓	1521, 1522	SP0159, SP0188, SP0189, SP0190
USA	RX350	***	2016-2020	Radar Cruise 1	✓	✓	✓	✓		
USA	RX350	***	2016-2020	Radar Cruise 2	✓	✓	✓	✓	0017, 0018, 1504, 1505	SP0061, SP0069
USA	RX350	***	2016-2020	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0012, SP0014, SP0015, SP0018, SP0167, SP0168
USA	RX350	***	2016-2020	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	RX350	***	2016-2020	Brake/EPB	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	SP0001, SP0003, SP0023, SP0024, SP0157, SP0186, SP0187
USA	RX350	***	2016-2020	Lane Control	✓	✓	✓		0824, 0989	

USA	RX350	***	2016-2020	Pre-Collision System	√	√	√		1524, 1525, 1526	
USA	RX350	***	2016-2020	Road Sign Assist	√	√	√			
USA	RX350	***	2016-2020	Automatic high beam	√	√	√			
USA	RX350	***	2016-2020	Front Radar Sensor	√	√	√			SP0127, SP0128, SP0129
USA	RX350	GGL	2010-2015	Engine	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0029, SP0030, SP0032, SP0042, SP0043, SP0072, SP0073, SP0074, SP0075, SP0076, SP0098, SP0099, SP0100, SP0101, SP0116, SP0161, SP0162

USA	RX350	GGL	2010-2015	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0072, SP0101
USA	RX350	GGL	2010-2015	Cruise Control	✓	✓	✓	✓		
USA	RX350	GGL	2010-2015	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007

USA	RX350	GGL	2010-2015	ABS/VSC/T RAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0024, SP0084, SP0149, SP0175
USA	RX350	GGL	2010-2015	4-Wheel Drive (4WD)	✓	✓	✓	✓	0819, 0820, 0821, 0822	SP0003, SP0052, SP0084, SP0085
USA	RX350	GGL	2010-2015	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	RX350	GGL	2010-2015	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	RX350	GGL	2010-2015	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		

USA	RX350	GGL	2010-2015	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051, SP0169, SP0170, SP0171, SP0172, SP0173
USA	RX350	GGL	2010-2015	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	RX350	GGL	2010-2015	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	RX350	GGL	2010-2015	PM1 Gateway	✓	✓	✓	✓		SP0005
USA	RX350	GGL	2010-2015	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	RX350	GGL	2010-2015	Driver Door Motor	✓	✓	✓		0528	SP0003
USA	RX350	GGL	2010-2015	Passenger Door Motor	✓	✓	✓		0528	SP0003
USA	RX350	GGL	2010-2015	Left Rear Door Motor	✓	✓	✓		0528	SP0003
USA	RX350	GGL	2010-2015	Right Rear Door Motor	✓	✓	✓		0528	SP0003
USA	RX350	GGL	2010-2015	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	RX350	GGL	2010-2015	Master Switch	✓	✓	✓			
USA	RX350	GGL	2010-2015	Sliding Roof	✓	✓	✓		0529	

USA	RX350	GGL	2010-2015	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
USA	RX350	GGL	2010-2015	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	SP0174
USA	RX350	GGL	2010-2015	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	RX350	GGL	2010-2015	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	RX350	GGL	2010-2015	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	

USA	RX350	GGL	2010-2015	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	SP0166
USA	RX350	GGL	2010-2015	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0012, SP0013, SP0014, SP0015, SP0167, SP0168
USA	RX350	GGL	2010-2015	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	RX350	GGL	2010-2015	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036, SP0176
USA	RX350	GGL	2010-2015	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
USA	RX350	GGL	2010-2015	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	RX350	GGL	2010-2015	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0078, SP0079, SP0154, SP0155, SP0163, SP0164, SP0165
USA	RX350	GGL	2010-2015	PM2 Gateway	✓	✓	✓	✓		SP0005
USA	RX350	GGL	2010-2015	Telematics	✓	✓	✓	✓		SP0158
USA	RX350	GGL	2010-2015	Radar Cruise	✓	✓	✓	✓		
USA	RX350	GGL	2010-2015	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
USA	RX350	GGL	2010-2015	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044



USA	RX350	GGL	2010-2015	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071, SP0177, SP0178
USA	RX350	GGL	2010-2015	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071, SP0137, SP0179, SP0180, SP0181
USA	RX350	GSU	2007-2009	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0032, SP0076, SP0101
USA	RX350	GSU	2007-2009	Laser Cruise	✓	✓	✓	✓		SP0061, SP0062
USA	RX350	GSU	2007-2009	Air suspension	✓	✓	✓		0439, 0440, 0446, 0447, 0450, 0451, 0454, 0455, 0456, 0457, 0464, 0465, 0466, 0467, 0469, 0470, 0471, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076	SP0001, SP0007

USA	RX350	GSU	2007-2009	ABS/VSC/TRAC	√	√	√	√	0821, 0822, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1083, 1096, 1098, 1099, 1101, 1102, 1104, 1105, 1106, 1117, 1118, 1121, 1122, 1123, 1124, 1125, 1538, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561,	SP0001, SP0003, SP0021, SP0023
USA	RX350	GSU	2007-2009	Tire Pressure Monitor	√	√	√			SP0001, SP0002
USA	RX350	GSU	2007-2009	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
USA	RX350	GSU	2007-2009	Immobiliser	√	√	√		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066

USA	RX350	GSU	2007-2009	Supplement Restraint System (SRS) Airbag	✓	✓				SP0004
USA	RX350	GSU	2007-2009	Body	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005, SP0019, SP0020
USA	RX350	GSU	2007-2009	Back Door	✓	✓	✓		0316, 0429, 0521, 0522, 0523, 0524, 0526, 0528, 0967, 0992	
USA	RX350	GSU	2007-2009	Driver Seat			✓		0422, 0423, 0424, 0515, 0516, 0517	
USA	RX350	GSU	2007-2009	Master Switch			✓		0939, 0940, 0941, 0942	
USA	RX350	GSU	2007-2009	Sliding Roof			✓		0529	
USA	RX350	GSU	2007-2009	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473, 1005	

USA	RX350	GSU	2007-2009	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
USA	RX350	GSU	2007-2009	Left Mirror			√	0279, 0280, 0281, 0282, 0283	
USA	RX350	GSU	2007-2009	Right Mirror			√	0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
USA	RX350	GSU	2007-2009	Rain Sensor			√		
USA	RX350	GSU	2007-2009	Wiper			√	0031, 0032, 0332	
USA	RX350	GSU	2007-2009	AFS	√	√	√	0008, 0475, 0476, 0477, 0968	SP0064
USA	RX350	GSU	2007-2009	Detection Of Occupant	√	√	√		SP0034, SP0035, SP0036
USA	RX350	GSU	2007-2009	Cruise Control	√	√	√	√	

USA	RX400h	MHU	2006-2008	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0032, SP0073, SP0074, SP0075, SP0076, SP0098, SP0099, SP0100, SP0101, SP0116, SP0161, SP0162
USA	RX400h	MHU	2006-2008	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117	SP0003, SP0004, SP0005, SP0024, SP0026
USA	RX400h	MHU	2006-2008	Laser Cruise	✓	✓	✓	✓		

USA	RX400h	MHU	2006-2008	ABS/VSC/TRAC	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0175
USA	RX400h	MHU	2006-2008	EMPS	√	√	√	√		SP0001, SP0009, SP0010
USA	RX400h	MHU	2006-2008	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
USA	RX400h	MHU	2006-2008	Immobiliser	√	√	√		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066, SP0196

USA	RX400h	MHU	2006-2008	Supplement Restraint System (SRS) Airbag	✓	✓				SP0004
USA	RX400h	MHU	2006-2008	Body	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935, 0969	SP0005, SP0019, SP0020
USA	RX400h	MHU	2006-2008	Gateway	✓	✓	✓		0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	
USA	RX400h	MHU	2006-2008	Back Door	✓	✓	✓		0316, 0429, 0521, 0522, 0523, 0524, 0526, 0528, 0967, 0992	

USA	RX400h	MHU	2006-2008	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517
USA	RX400h	MHU	2006-2008	Master Switch			√		0939, 0940, 0941, 0942
USA	RX400h	MHU	2006-2008	Sliding Roof			√		0529
USA	RX400h	MHU	2006-2008	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005
USA	RX400h	MHU	2006-2008	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,
USA	RX400h	MHU	2006-2008	Left Mirror			√		0279, 0280, 0281, 0282, 0283
USA	RX400h	MHU	2006-2008	Right Mirror			√		0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980
USA	RX400h	MHU	2006-2008	Rain Sensor			√		
USA	RX400h	MHU	2006-2008	Wiper			√		0031, 0032, 0332



USA	RX400h	MHU	2006-2008	AFS	✓	✓	✓		0008, 0475, 0476, 0477, 0968	SP0064
USA	RX400h	MHU	2006-2008	Detection Of Occupant	✓	✓	✓			SP0034, SP0035, SP0036, SP0176
USA	RX400h	MHU	2006-2008	Cruise Control	✓	✓	✓	✓		
USA	RX400h	MHU	2006-2008	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002
USA	RX450h	GYL	2010-2020	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0003, SP0004, SP0026, SP0029, SP0030, SP0032, SP0042, SP0072, SP0073, SP0074, SP0075, SP0076, SP0098, SP0099, SP0100, SP0101, SP0116, SP0161, SP0162
USA	RX450h	GYL	2010-2020	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081	SP0003, SP0004, SP0005, SP0024, SP0025, SP0026, SP0053, SP0054, SP0055, SP0056, SP0057, SP0058, SP0089
USA	RX450h	GYL	2010-2020	Cruise Control	✓	✓	✓	✓		

USA	RX450h	GYL	2010-2020	Air suspension	✓	✓	✓	✓	0438, 0439, 0440, 0441, 0442, 0443, 0444, 0445, 0446, 0447, 0448, 0449, 0450, 0451, 0452, 0453, 0454, 0455, 0456, 0457, 0458, 0459, 0460, 0461, 0462, 0463, 0464, 0465, 0466, 0467, 0468, 0469, 0470, 0471	SP0001, SP0007
USA	RX450h	GYL	2010-2020	Front Stabilizer	✓	✓	✓		0527	
USA	RX450h	GYL	2010-2020	Rear Stabilizer	✓	✓	✓		0527	
USA	RX450h	GYL	2010-2020	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	SP0001, SP0003, SP0021, SP0022, SP0023, SP0175

USA	RX450h	GYL	2010-2020	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0117, SP0118, SP0119
USA	RX450h	GYL	2010-2020	EMPS	✓	✓	✓	✓		SP0001, SP0009, SP0010
USA	RX450h	GYL	2010-2020	Advanced Parking Guidance/ Parking Assist Monitor	✓	✓	✓	✓		
USA	RX450h	GYL	2010-2020	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	SP0016, SP0017, SP0051, SP0169, SP0170, SP0171, SP0172, SP0173
USA	RX450h	GYL	2010-2020	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0001

USA	RX450h	GYL	2010-2020	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	SP0005, SP0018, SP0019, SP0020, SP0189
USA	RX450h	GYL	2010-2020	PM1 Gateway	✓	✓	✓	✓		SP0005
USA	RX450h	GYL	2010-2020	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	RX450h	GYL	2010-2020	Driver Door Motor	✓	✓	✓		0528	SP0003
USA	RX450h	GYL	2010-2020	Passenger Door Motor	✓	✓	✓		0528	SP0003
USA	RX450h	GYL	2010-2020	Left Rear Door Motor	✓	✓	✓		0528	SP0003
USA	RX450h	GYL	2010-2020	Right Rear Door Motor	✓	✓	✓		0528	SP0003
USA	RX450h	GYL	2010-2020	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	RX450h	GYL	2010-2020	Master Switch	✓	✓	✓			
USA	RX450h	GYL	2010-2020	Sliding Roof	✓	✓	✓		0529	

USA	RX450h	GYL	2010-2020	Tilt&Telescopic	√	√	√	√	0472, 0473	
USA	RX450h	GYL	2010-2020	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0623, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0631, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0671, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680,	SP0174
USA	RX450h	GYL	2010-2020	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	RX450h	GYL	2010-2020	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	RX450h	GYL	2010-2020	Intuitive Parking Assist	√	√	√	√	0023, 0024, 0025, 0026	

USA	RX450h	GYL	2010-2020	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	SP0166
USA	RX450h	GYL	2010-2020	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0011, SP0013, SP0014, SP0015, SP0018, SP0168
USA	RX450h	GYL	2010-2020	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	SP0045
USA	RX450h	GYL	2010-2020	Detection Of Occupant	✓	✓	✓	✓	0034, 0035, 0036	
USA	RX450h	GYL	2010-2020	Remote Engine Starter	✓	✓	✓	✓		SP0046, SP0047, SP0048
USA	RX450h	GYL	2010-2020	Navigation System	✓	✓	✓	✓		SP0049, SP0050, SP0078, SP0079, SP0154, SP0155, SP0163, SP0164, SP0165
USA	RX450h	GYL	2010-2020	PM2 Gateway	✓	✓	✓	✓		SP0005
USA	RX450h	GYL	2010-2020	Telematics	✓	✓	✓	✓	1521, 1522	SP0158, SP0159, SP0160
USA	RX450h	GYL	2010-2020	Radar Cruise	✓	✓	✓	✓		
USA	RX450h	GYL	2010-2020	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	

USA	RX450h	GYL	2010-2020	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044, SP0127, SP0128, SP0134, SP0143, SP0144
USA	RX450h	GYL	2010-2020	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071, SP0177, SP0178
USA	RX450h	GYL	2010-2020	Slave Blind Spot Monitor	√	√	√	√		SP0070, SP0071, SP0137, SP0179, SP0180, SP0181
USA	RX450h	GYL	2010-2020	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
USA	RX450h	GYL	2010-2020	Front Recognition Camera	√	√	√	√	0052	SP0086, SP0126, SP0134, SP0182, SP0183, SP0184
USA	RX450h	GYL	2010-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
USA	RX450h	GYL	2010-2020	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)	√	√	√	√		
USA	RX450h	GYL	2010-2020	Panoramic view monitor	√	√	√	√		
USA	RX450h	GYL	2010-2020	Parking Assist Camera	√	√	√	√		
USA	RX450h	GYL	2010-2020	Accessory Gateway	√	√	√	√		SP0005

USA	RX450h	GYL	2010-2020	Central Gateway	✓	✓	✓	✓		SP0005
USA	RX450h	GYL	2010-2020	Sliding Sunshade	✓	✓	✓		1181	
USA	RX450h	GYL	2010-2020	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
USA	RX450h	GYL	2010-2020	Advanced Parking Guidance/ Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A)	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006, SP0091, SP0185
USA	RX450h	GYL	2010-2020	Rain Sensor	✓	✓	✓			
USA	RX450h	GYL	2010-2020	Wiper	✓	✓	✓	✓	0031, 0032	
USA	RX450h	GYL	2010-2020	Auto Leveling Of Headlamp	✓	✓	✓	✓	0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	SP0008, SP0166
USA	RX450h	GYL	2010-2020	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
USA	RX450h	GYL	2010-2020	Radar Cruise 1	✓	✓	✓	✓		
USA	RX450h	GYL	2010-2020	Radar Cruise 2	✓	✓	✓	✓	0017, 0018, 00504, 001505	SP0061, SP0069
USA	RX450h	GYL	2010-2020	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	SP0012, SP0014, SP0015, SP0018, SP0167, SP0168



USA	RX450h	GYL	2010-2020	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
USA	RX450h	GYL	2010-2020	Lane Control	✓	✓	✓		0824, 0989	
USA	RX450h	GYL	2010-2020	Road Sign Assist	✓	✓	✓			
USA	RX450h	GYL	2010-2020	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
USA	RX450h	GYL	2010-2020	Front Radar Sensor	✓	✓	✓			
USA	RX450h	GYL	2010-2020	Vehicle proximity notification system	✓	✓	✓	✓	0044, 0045, 0046	
USA	SC300	JZZ	1996-2000	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004
USA	SC300	JZZ	1996-2000	Cruise Control	✓	✓	✓	✓		
USA	SC300	JZZ	1996-2000	Immobiliser	✓	✓	✓			SP0065, SP0066, SP0148

USA	SC400	UZZ	1996-2000	Engine and ECT	✓	✓	✓	✓	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004
USA	SC400	UZZ	1996-2000	Cruise Control	✓	✓	✓	✓		
USA	SC400	UZZ	1996-2000	Immobiliser	✓	✓	✓			SP0065, SP0066, SP0148

USA	SC430	UZZ	2002-2010	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149,	SP0004, SP0026, SP0030, SP0032, SP0042, SP0101
-----	-------	-----	-----------	--------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------

USA	SC430	UZZ	2002-2010	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0131, 0132, 0133, 0134, 0135, 0136, 0137, 0138, 0139, 0140, 0141, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0169,	SP0003, SP0004, SP0032, SP0101
USA	SC430	UZZ	2002-2010	Cruise Control	✓	✓	✓	✓		

USA	SC430	UZZ	2002-2010	ABS/VSC/TRAC	√	√	√	√	0821, 0822, 0826, 0827, 0828, 0829, 0831, 0840, 0848, 0849, 0854, 0855, 0856, 0857, 0876, 0889, 0890, 0899, 0900, 0901, 0902, 0903, 0904, 0905, 0906, 0907, 0909, 0910, 0911, 1077, 1078, 1079, 1080, 1081, 1083, 1096, 1098, 1099, 1101, 1102, 1104, 1105, 1106, 1117, 1118, 1121, 1122, 1123, 1124, 1125, 1538, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561,	SP0001, SP0003, SP0021, SP0023
USA	SC430	UZZ	2002-2010	Tire Pressure Monitor	√	√	√			SP0001, SP0002
USA	SC430	UZZ	2002-2010	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0569, 0573, 0585, 0586, 0588, 0594, 0598, 0599, 0610, 0611, 0614, 0615, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028	
USA	SC430	UZZ	2002-2010	Immobiliser	√	√	√		0501, 0983, 0984, 0985, 0986, 0987, 0988, 0989	SP0065, SP0066

USA	SC430	UZZ	2002-2010	Theft Deterrent	✓	✓	✓	0321, 0333, 0337, 0494, 0495, 0498, 0500, 0501, 0785, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1000, 1001, 1002, 1003, 1004	SP0018, SP0019, SP0020
USA	SC430	UZZ	2002-2010	Supplement Restraint System (SRS) Airbag	✓	✓	✓		SP0001, SP0004
USA	SC430	UZZ	2002-2010	Gateway	✓	✓	✓		SP0005
USA	SC430	UZZ	2002-2010	Body No. 2	✓	✓	✓	0031, 0032, 0319, 0331, 0333, 0335, 0337, 0339, 0429, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0802, 0805, 0806, 0807, 0809, 0815, 0816, 0912, 0913, 0914, 0915, 0916, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0925, 0926, 0927, 0928, 0929, 0930, 0931, 0932, 0933, 0934, 0935	

USA	SC430	UZZ	2002-2010	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967
USA	SC430	UZZ	2002-2010	Body No. 4	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967

USA	SC430	UZZ	2002-2010	Body No. 5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0331, 0332, 0333, 0337, 0338, 0805, 0912, 0917, 0918, 0929, 0931, 0943, 0947, 0948, 0949, 0950, 0951, 0952, 0953, 0954, 0955, 0956, 0957, 0958, 0959, 0960, 0961, 0962, 0963, 0964, 0965, 0966, 0967	
USA	SC430	UZZ	2002-2010	Driver Door	√	√	√		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	SC430	UZZ	2002-2010	Passenger Door	√	√	√		0279, 0280, 0281, 0282, 0283, 0284, 0317, 0429, 0430, 0437, 0503, 0507, 0508, 0509, 0528, 0990, 0991	
USA	SC430	UZZ	2002-2010	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
USA	SC430	UZZ	2002-2010	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
USA	SC430	UZZ	2002-2010	Hardtop Retractable	√	√	√		0970	
USA	SC430	UZZ	2002-2010	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	



USA	SC430	UZZ	2002-2010	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0662, 0665, 0669, 0670, 0671, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0692, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0773, 0774, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044,	
USA	SC430	UZZ	2002-2010	Combination Switch			√		
USA	SC430	UZZ	2002-2010	Switch Of Steering Pad			√		
USA	SC430	UZZ	2002-2010	AFS	√	√	√	0008, 0475, 0476, 0477, 0968	
USA	SC430	UZZ	2002-2010	Detection Of Occupant	√	√	√		SP0034, SP0035, SP0036

USA	SC430	UZZ	2002-2010	Engine and ECT	√	√	√	√	0169, 0255, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1575, 1576	SP0003, SP0004, SP0026
-----	-------	-----	-----------	----------------	---	---	---	---	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------

USA	UX200	***	2019- 2020	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	
-----	-------	-----	---------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

USA	UX200	***	2019-2020	Transmission	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
USA	UX200	***	2019-2020	Radar Cruise 1	√	√	√	√		
USA	UX200	***	2019-2020	Radar Cruise 2	√	√	√		1504, 1505	
USA	UX200	***	2019-2020	Brake/EPB	√	√	√		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
USA	UX200	***	2019-2020	Tire Pressure Monitor	√	√	√			
USA	UX200	***	2019-2020	EMPS	√	√	√	√		
USA	UX200	***	2019-2020	Front Recognition Camera	√	√	√			
USA	UX200	***	2019-2020	Lane Control	√	√	√		0824, 0989	
USA	UX200	***	2019-2020	Steering Angle Sensor	√	√	√			
USA	UX200	***	2019-2020	Parking Assist Camera	√	√	√	√		

USA	UX200	***	2019-2020	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0559, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0587, 0588, 0589, 0590, 0591, 0592, 0593, 0594, 0595, 0596, 0597, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615	
USA	UX200	***	2019-2020	Supplement Restraint System (SRS) Airbag	√	√	√	√		
USA	UX200	***	2019-2020	Pre-Collision System	√	√	√		1524, 1525, 1526	

USA	UX200	***	2019-2020	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0794, 0795, 0796, 0797, 0798, 0799, 0800, 0801, 0802, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0814, 0815, 0816, 0817, 0818	
USA	UX200	***	2019-2020	Central Gateway	√	√	√	√		
USA	UX200	***	2019-2020	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
USA	UX200	***	2019-2020	Driver Door Motor	√	√	√		0528	
USA	UX200	***	2019-2020	Passenger Door Motor	√	√	√		0528	
USA	UX200	***	2019-2020	Left Rear Door Motor	√	√	√		0528	
USA	UX200	***	2019-2020	Right Rear Door Motor	√	√	√		0528	
USA	UX200	***	2019-2020	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
USA	UX200	***	2019-2020	Master Switch	√	√	√			
USA	UX200	***	2019-2020	Sliding Roof	√	√	√		0529	

USA	UX200	***	2019-2020	Tilt&Telescopic	√	√	√		1513, 1514	
USA	UX200	***	2019-2020	Combination Meter	√	√	√		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
USA	UX200	***	2019-2020	Head Up Display	√	√	√		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
USA	UX200	***	2019-2020	Road Sign Assist	√	√	√			
USA	UX200	***	2019-2020	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	UX200	***	2019-2020	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284	
USA	UX200	***	2019-2020	Clearance Warning	√	√	√		0023, 0024	
USA	UX200	***	2019-2020	Rain and/or Humidity Sensor	√	√	√			

USA	UX200	***	2019-2020	Wiper	√	√	√		0031, 0032, 0033, 0034	
USA	UX200	***	2019-2020	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
USA	UX200	***	2019-2020	Adaptive Front Lighting System (AFS) (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	
USA	UX200	***	2019-2020	Auto Leveling Of Headlamp	√	√	√		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015	
USA	UX200	***	2019-2020	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	
USA	UX200	***	2019-2020	Front Recognition Camera (Front Lighting Control)	√	√	√			
USA	UX200	***	2019-2020	Smart Access	√	√	√	√	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553	
USA	UX200	***	2019-2020	Power Source Control	√	√	√	√	0299, 0300, 0301, 0302, 0303, 0304, 0305	



USA	UX200	***	2019-2020	Detection Of Occupant	✓	✓	✓			
USA	UX200	***	2019-2020	Starting Control	✓	✓	✓	✓	0256, 0257	
USA	UX200	***	2019-2020	Navigation System	✓	✓	✓	✓		
USA	UX200	***	2019-2020	Front Radar Sensor	✓	✓	✓			
USA	UX200	***	2019-2020	Master Blind Spot Monitor	✓	✓	✓	✓		
USA	UX200	***	2019-2020	Slave Blind Spot Monitor	✓	✓	✓	✓		
USA	UX200	***	2019-2020	ASC	✓	✓	✓	✓	1182	
USA	UX200	***	2019-2020	Telematics	✓	✓	✓	✓		
USA	UX250h/UX260h	***	2019-2020	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	

USA	UX250h/UX260h	***	2019-2020	Hybrid Control	✓	✓	✓		0070, 0071, 0079, 0081, 0180, 0194, 0195, 1207, 1208, 1493, 1494, 1495, 1496, 1497	
USA	UX250h/UX260h	***	2019-2020	Motor Generator	✓	✓	✓			
USA	UX250h/UX260h	***	2019-2020	Rear Motor Generator	✓	✓	✓	✓		
USA	UX250h/UX260h	***	2019-2020	Radar Cruise 1	✓	✓	✓	✓		
USA	UX250h/UX260h	***	2019-2020	Radar Cruise 2	✓	✓	✓		1504, 1505	
USA	UX250h/UX260h	***	2019-2020	ABS/VSC/TRAC	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0471, 0821, 0822, 0826, 0827, 0828, 0829, 0830, 0831, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0850, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888,	
USA	UX250h/UX260h	***	2019-2020	Tire Pressure Monitor	✓	✓	✓			
USA	UX250h/UX260h	***	2019-2020	EMPS	✓	✓	✓	✓		

USA	UX250h/U X260h	***	2019- 2020	Electric Parking Brake	√	√	√	√	0376, 0377, 0 378, 0379, 03 80, 0381, 038 2, 0383, 0384 , 0385, 0386, 0387, 0388, 0 389, 0390, 03 91, 0392, 039 3, 0394, 0395 , 0396, 0397	
USA	UX250h/U X260h	***	2019- 2020	Front Recogniti on Camera	√	√	√			
USA	UX250h/U X260h	***	2019- 2020	Lane Control	√	√	√		0824, 0989	
USA	UX250h/U X260h	***	2019- 2020	Steering Angle Sensor	√	√	√			
USA	UX250h/U X260h	***	2019- 2020	Parking Assist Camera	√	√	√	√		
USA	UX250h/U X260h	***	2019- 2020	Air Condition er	√	√	√	√	0556, 0557, 0 558, 0559, 05 60, 0561, 056 2, 0563, 0564 , 0565, 0566, 0567, 0568, 0 569, 0570, 05 71, 0572, 057 3, 0574, 0575 , 0576, 0577, 0578, 0579, 0 580, 0581, 05 82, 0583, 058 4, 0585, 0586 , 0587, 0588, 0589, 0590, 0 591, 0592, 05 93, 0594, 059 5, 0596, 0597 , 0598, 0599, 0600, 0601, 0 602, 0603, 06 04, 0605, 060 6, 0607, 0608 , 0609, 0610, 0611, 0612, 0 613, 0614, 06 15	
USA	UX250h/U X260h	***	2019- 2020	Supplemen t Restraint System (SRS) Airbag	√	√	√	√		

USA	UX250h/U X260h	***	2019- 2020	Pre- Collision System	✓	✓	✓		1524, 1525, 1 526	
USA	UX250h/U X260h	***	2019- 2020	Main Body	✓	✓	✓	✓	0005, 0282, 0 300, 0301, 03 17, 0319, 033 3, 0335, 0337 , 0339, 0426, 0427, 0429, 0 433, 0434, 04 35, 0436, 049 0, 0496, 0497 , 0498, 0499, 0500, 0501, 0 502, 0783, 07 84, 0785, 078 6, 0787, 0788 , 0789, 0790, 0791, 0792, 0 793, 0794, 07 95, 0796, 079 7, 0798, 0799 , 0800, 0801, 0802, 0803, 0 804, 0805, 08 06, 0807, 080 8, 0809, 0810 , 0811, 0812, 0813, 0814, 0 815, 0816, 08 17, 0818	
USA	UX250h/U X260h	***	2019- 2020	Central Gateway	✓	✓	✓	✓		
USA	UX250h/U X260h	***	2019- 2020	Back Door	✓	✓	✓	✓	0520, 0521, 0 522, 0523, 05 24, 0525, 052 6	
USA	UX250h/U X260h	***	2019- 2020	Driver Door Motor	✓	✓	✓		0528	
USA	UX250h/U X260h	***	2019- 2020	Passenger Door Motor	✓	✓	✓		0528	
USA	UX250h/U X260h	***	2019- 2020	Left Rear Door Motor	✓	✓	✓		0528	
USA	UX250h/U X260h	***	2019- 2020	Right Rear Door Motor	✓	✓	✓		0528	
USA	UX250h/U X260h	***	2019- 2020	Driver Seat	✓	✓	✓	✓	0026, 0421, 0 422, 0423, 04 24, 0513, 051 4, 0515, 0516 , 0517, 0518, 0519	

USA	UX250h/UX260h	***	2019-2020	Master Switch	✓	✓	✓		
USA	UX250h/UX260h	***	2019-2020	Sliding Roof	✓	✓	✓		0529
USA	UX250h/UX260h	***	2019-2020	Tilt&Telescopic	✓	✓	✓		1513, 1514
USA	UX250h/UX260h	***	2019-2020	Combination Meter	✓	✓	✓		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,
USA	UX250h/UX260h	***	2019-2020	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512
USA	UX250h/UX260h	***	2019-2020	Road Sign Assist	✓	✓	✓		
USA	UX250h/UX260h	***	2019-2020	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	UX250h/UX260h	***	2019-2020	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284
USA	UX250h/UX260h	***	2019-2020	Clearance Warning	✓	✓	✓		0023, 0024

USA	UX250h/UX260h	***	2019-2020	Rain and/or Humidity Sensor	✓	✓	✓		
USA	UX250h/UX260h	***	2019-2020	Wiper	✓	✓	✓		0031, 0032, 0033, 0034
USA	UX250h/UX260h	***	2019-2020	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
USA	UX250h/UX260h	***	2019-2020	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028
USA	UX250h/UX260h	***	2019-2020	Auto Leveling Of Headlamp	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015
USA	UX250h/UX260h	***	2019-2020	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028
USA	UX250h/UX260h	***	2019-2020	Front Recognition Camera (Front Lighting Control)	✓	✓	✓		
USA	UX250h/UX260h	***	2019-2020	Smart Access	✓	✓	✓	✓	0329, 0333, 0496, 0498, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0541, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553

USA	UX250h/UX260h	***	2019-2020	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 0302, 0303, 0304, 0305	
USA	UX250h/UX260h	***	2019-2020	Detection Of Occupant	✓	✓	✓			
USA	UX250h/UX260h	***	2019-2020	Navigation System	✓	✓	✓	✓		
USA	UX250h/UX260h	***	2019-2020	Front Radar Sensor	✓	✓	✓			
USA	UX250h/UX260h	***	2019-2020	Master Blind Spot Monitor	✓	✓	✓	✓		
USA	UX250h/UX260h	***	2019-2020	Slave Blind Spot Monitor	✓	✓	✓	✓		
USA	UX250h/UX260h	***	2019-2020	Vehicle proximity notification system	✓	✓	✓	✓	0044, 0045, 0046	
USA	UX250h/UX260h	***	2019-2020	ASC	✓	✓	✓	✓	1182	
USA	UX250h/UX260h	***	2019-2020	Telematics	✓	✓	✓	✓		
USA	UX250h/UX260h	***	2019-2020	Cruise Control	✓	✓	✓	✓		

JAP	CT200h	ZWA	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0042, SP0043, SP0101, SP0103, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0118, SP0119, SP0111, SP0113, SP0119
JAP	CT200h	ZWA	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 1577, 1578	
JAP	CT200h	ZWA	All years	Cruise Control	✓	✓	✓	✓		



JAP	CT200h	ZWA	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024, SP0088
JAP	CT200h	ZWA	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	CT200h	ZWA	All years	Transmission Control	✓	✓	✓	✓		

JAP	CT200h	ZWA	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	CT200h	ZWA	All years	Theft Deterrent	✓	✓	✓		0333, 0498, 0499, 0501, 0502, 1647	
JAP	CT200h	ZWA	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0004

JAP	CT200h	ZWA	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018, SP0019, SP0020
JAP	CT200h	ZWA	All years	PM1 Gateway	✓	✓	✓	✓		SP0005
JAP	CT200h	ZWA	All years	PM2 Gateway	✓	✓	✓	✓		SP0005
JAP	CT200h	ZWA	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	CT200h	ZWA	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	CT200h	ZWA	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	CT200h	ZWA	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	CT200h	ZWA	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	CT200h	ZWA	All years	Master Switch	✓	✓	✓			
JAP	CT200h	ZWA	All years	Sliding Roof	✓	✓	✓		0529	

JAP	CT200h	ZWA	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	CT200h	ZWA	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	CT200h	ZWA	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	CT200h	ZWA	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
JAP	CT200h	ZWA	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0007, SP0008	

JAP	CT200h	ZWA	All years	Entry&start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0201
JAP	CT200h	ZWA	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	SP0045
JAP	CT200h	ZWA	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
JAP	CT200h	ZWA	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	CT200h	ZWA	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0069
JAP	CT200h	ZWA	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	CT200h	ZWA	All years	Pre-Crash	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0040, SP0044, SP0199, SP0200
JAP	CT200h	ZWA	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
JAP	CT200h	ZWA	All years	Radar Cruise 1	✓	✓	✓	✓		
JAP	CT200h	ZWA	All years	Radar Cruise 2	✓	✓	✓	✓		

JAP	CT200h	ZWA	All years	ABS/VSC/TRC (TRAC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	CT200h	ZWA	All years	EMPS	✓	✓	✓	✓		
JAP	CT200h	ZWA	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
JAP	CT200h	ZWA	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
JAP	CT200h	ZWA	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			

JAP	CT200h	ZWA	All years	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	CT200h	ZWA	All years	Central Gateway	✓	✓	✓	✓		
JAP	ES300h	AXZH10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	
JAP	ES300h	AXZH10	All years	Hybrid Control	✓	✓	✓	✓		
JAP	ES300h	AXZH10	All years	Motor Generator	✓	✓	✓	✓		
JAP	ES300h	AXZH10	All years	Radar Cruise 1	✓	✓	✓			
JAP	ES300h	AXZH10	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	

JAP	ES300h	AXZH10	All years	Air suspension	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	
JAP	ES300h	AXZH10	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	ES300h	AXZH10	All years	Tire Pressure Monitor	√	√	√			
JAP	ES300h	AXZH10	All years	EMPS	√	√	√	√		



JAP	ES300h	AXZH10	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397
JAP	ES300h	AXZH10	All years	Front Recognition Camera	√	√	√		
JAP	ES300h	AXZH10	All years	Panoramic View Monitor	√	√	√	√	
JAP	ES300h	AXZH10	All years	Lane Control	√	√	√		0824, 0989
JAP	ES300h	AXZH10	All years	Steering Angle Sensor	√	√	√		
JAP	ES300h	AXZH10	All years	Parking Assist Camera	√	√	√	√	
JAP	ES300h	AXZH10	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661

JAP	ES300h	AXZH10	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		
JAP	ES300h	AXZH10	All years	Pre-Collision System	√	√	√		1524, 1525, 1526	
JAP	ES300h	AXZH10	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	ES300h	AXZH10	All years	Accessory Gateway	√	√	√	√		
JAP	ES300h	AXZH10	All years	Central Gateway	√	√	√	√		
JAP	ES300h	AXZH10	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	ES300h	AXZH10	All years	Driver Door Motor	√	√	√		0528	
JAP	ES300h	AXZH10	All years	Passenger Door Motor	√	√	√		0528	
JAP	ES300h	AXZH10	All years	Left Rear Door Motor	√	√	√		0528	

JAP	ES300h	AXZH10	All years	Right Rear Door Motor	√	√	√		0528	
JAP	ES300h	AXZH10	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	ES300h	AXZH10	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	ES300h	AXZH10	All years	Master Switch	√	√	√			
JAP	ES300h	AXZH10	All years	Sliding Roof	√	√	√		0529	
JAP	ES300h	AXZH10	All years	Tilt&Telescopic	√	√	√		1513, 1514	
JAP	ES300h	AXZH10	All years	Combination Meter	√	√	√		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
JAP	ES300h	AXZH10	All years	Head Up Display	√	√	√		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	

JAP	ES300h	AXZH10	All years	Road Sign Assist	√	√	√			
JAP	ES300h	AXZH10	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	ES300h	AXZH10	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	ES300h	AXZH10	All years	Digital Side-View Monitor	√	√	√			SP0203
JAP	ES300h	AXZH10	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
JAP	ES300h	AXZH10	All years	Rain and/or Humidity Sensor	√	√	√			
JAP	ES300h	AXZH10	All years	Wiper	√	√	√		0031, 0032, 0033, 0034	
JAP	ES300h	AXZH10	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	ES300h	AXZH10	All years	Adaptive Front Lighting System (AFS) (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	
JAP	ES300h	AXZH10	All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	

JAP	ES300h	AXZH10	All years	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0006	
JAP	ES300h	AXZH10	All years	Front Recognition Camera (Front Lighting Control)	√	√	√			
JAP	ES300h	AXZH10	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	ES300h	AXZH10	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	ES300h	AXZH10	All years	Remote Engine Starter	√	√	√	√		
JAP	ES300h	AXZH10	All years	Navigation System	√	√	√	√		
JAP	ES300h	AXZH10	All years	Front Radar Sensor	√	√	√			
JAP	ES300h	AXZH10	All years	Master Blind Spot Monitor	√	√	√	√		
JAP	ES300h	AXZH10	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	ES300h	AXZH10	All years	Grill Shutter	√	√	√		0037, 0038, 0039, 0040	
JAP	ES300h	AXZH10	All years	Vehicle proximity notification system	√	√	√	√		
JAP	ES300h	AXZH10	All years	Active Noise Control	√	√	√		1515, 1516, 1517, 1518, 1519	

JAP	ES300h	AXZH10	All years	Connection Of ITS	√	√	√	√			
JAP	ES300h	AXZH10	All years	Pedestrian Protection	√	√	√			SP0004	
JAP	GS F	URL	All years	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,		

JAP	GS F	URL	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,	
JAP	GS F	URL	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	
JAP	GS F	URL	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	

JAP	GS F	URL	All years	ABS/VSC/TRC (TRAC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	GS F	URL	All years	Tire Pressure Monitor	✓	✓	✓			
JAP	GS F	URL	All years	EMPS	✓	✓	✓	✓		
JAP	GS F	URL	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
JAP	GS F	URL	All years	Front Recognition Camera	✓	✓	✓	✓	0052	



JAP	GS F	URL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	GS F	URL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
JAP	GS F	URL	All years	TVD	√	√	√	√	0042, 0043	
JAP	GS F	URL	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	
JAP	GS F	URL	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		

JAP	GS F	URL	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	GS F	URL	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	GS F	URL	All years	Central Gateway	√	√	√	√		
JAP	GS F	URL	All years	Right Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS F	URL	All years	Left Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS F	URL	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	GS F	URL	All years	Driver Door Motor	√	√	√		0528	
JAP	GS F	URL	All years	Passenger Door Motor	√	√	√		0528	

JAP	GS F	URL	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	GS F	URL	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	GS F	URL	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	GS F	URL	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	GS F	URL	All years	Master Switch	✓	✓	✓			
JAP	GS F	URL	All years	Sliding Roof	✓	✓	✓		0529	
JAP	GS F	URL	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
JAP	GS F	URL	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	

JAP	GS F	URL	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051
JAP	GS F	URL	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026
JAP	GS F	URL	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
JAP	GS F	URL	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648
JAP	GS F	URL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617
JAP	GS F	URL	All years	Remote Engine Starter	✓	✓	✓	✓	
JAP	GS F	URL	All years	Starting Control	✓	✓	✓	✓	0256, 0257
JAP	GS F	URL	All years	Navigation System	✓	✓	✓	✓	
JAP	GS F	URL	All years	Master Blind Spot Monitor	✓	✓	✓	✓	
JAP	GS F	URL	All years	Slave Blind Spot Monitor	✓	✓	✓	✓	
JAP	GS F	URL	All years	ASC	✓	✓	✓	✓	1182
JAP	GS F	URL	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015

JAP	GS200t	ARL10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,
-----	--------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	GS200t	ARL10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
JAP	GS200t	ARL10	All years	Stop&Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297
JAP	GS200t	ARL10	All years	Radar Cruise	✓	✓	✓	✓	
JAP	GS200t	ARL10	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646

JAP	GS200t	ARL10	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	GS200t	ARL10	All years	Tire Pressure Monitor	✓	✓	✓			
JAP	GS200t	ARL10	All years	EHPS	✓	✓	✓	✓		
JAP	GS200t	ARL10	All years	VGRS	✓	✓	✓	✓		
JAP	GS200t	ARL10	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
JAP	GS200t	ARL10	All years	Front Recognition Camera	✓	✓	✓	✓	0052	

JAP	GS200t	ARL10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824		
JAP	GS200t	ARL10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√			
JAP	GS200t	ARL10	All years	DRS	√	√	√	√			
JAP	GS200t	ARL10	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661		
JAP	GS200t	ARL10	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√			



JAP	GS200t	ARL10	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	GS200t	ARL10	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	GS200t	ARL10	All years	Central Gateway	√	√	√	√		
JAP	GS200t	ARL10	All years	Right Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS200t	ARL10	All years	Left Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS200t	ARL10	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	GS200t	ARL10	All years	Driver Door Motor	√	√	√		0528	
JAP	GS200t	ARL10	All years	Passenger Door Motor	√	√	√		0528	

JAP	GS200t	ARL10	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	GS200t	ARL10	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	GS200t	ARL10	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	GS200t	ARL10	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	GS200t	ARL10	All years	Master Switch	✓	✓	✓			
JAP	GS200t	ARL10	All years	Sliding Roof	✓	✓	✓		0529	
JAP	GS200t	ARL10	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
JAP	GS200t	ARL10	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	

JAP	GS200t	ARL10	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
JAP	GS200t	ARL10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
JAP	GS200t	ARL10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	GS200t	ARL10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	GS200t	ARL10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	GS200t	ARL10	All years	Remote Engine Starter	✓	✓	✓	✓		
JAP	GS200t	ARL10	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
JAP	GS200t	ARL10	All years	Navigation System	✓	✓	✓	✓		
JAP	GS200t	ARL10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
JAP	GS200t	ARL10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		

JAP	GS250	GRL	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0042, SP0043, SP0101, SP0103, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0118, SP0109, SP0111, SP0113, SP0118, SP0119, SP0113, SP0118, SP0119
JAP	GS250	GRL	All years	Cruise Control	✓	✓	✓	✓		
JAP	GS250	GRL	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	SP0001, SP0004, SP0007

JAP	GS250	GRL	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	GS250	GRL	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0004
JAP	GS250	GRL	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	GS250	GRL	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004

JAP	GS250	GRL	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	GS250	GRL	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0004

JAP	GS250	GRL	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018
JAP	GS250	GRL	All years	Gateway	✓	✓	✓	✓		SP0005
JAP	GS250	GRL	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS250	GRL	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS250	GRL	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	GS250	GRL	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	GS250	GRL	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	GS250	GRL	All years	Left Rear Door Motor	✓	✓	✓		0528	

JAP	GS250	GRL	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	GS250	GRL	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	GS250	GRL	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	GS250	GRL	All years	Master Switch	✓	✓	✓			
JAP	GS250	GRL	All years	Sliding Roof	✓	✓	✓		0529	
JAP	GS250	GRL	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
JAP	GS250	GRL	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	GS250	GRL	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006



JAP	GS250	GRL	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	GS250	GRL	All years	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0018, SP0201
JAP	GS250	GRL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	SP0045
JAP	GS250	GRL	All years	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274, 1607, 1608, 1609, 1610, 1611	SP0067, SP0068
JAP	GS250	GRL	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
JAP	GS250	GRL	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
JAP	GS250	GRL	All years	Charging Control	✓	✓	✓	✓	0258, 1613	
JAP	GS250	GRL	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	GS250	GRL	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
JAP	GS250	GRL	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
JAP	GS250	GRL	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	SP0061, SP0069
JAP	GS250	GRL	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038

JAP	GS250	GRL	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	GS250	GRL	All years	Pre-Crash	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
JAP	GS250	GRL	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
JAP	GS250	GRL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
JAP	GS250	GRL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
JAP	GS250	GRL	All years	Central Gateway	✓	✓	✓	✓		
JAP	GS250	GRL	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	

JAP	GS300	ARL10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,
-----	-------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	GS300	ARL10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
JAP	GS300	ARL10	All years	Stop&Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297
JAP	GS300	ARL10	All years	Radar Cruise	✓	✓	✓	✓	
JAP	GS300	ARL10	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646

JAP	GS300	ARL10	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	GS300	ARL10	All years	Tire Pressure Monitor	√	√	√			
JAP	GS300	ARL10	All years	EMPS	√	√	√	√		
JAP	GS300	ARL10	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
JAP	GS300	ARL10	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	

JAP	GS300	ARL10	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	GS300	ARL10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	GS300	ARL10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			√			
JAP	GS300	ARL10	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	
JAP	GS300	ARL10	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		

JAP	GS300	ARL10	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	GS300	ARL10	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	GS300	ARL10	All years	Central Gateway	√	√	√	√		
JAP	GS300	ARL10	All years	Right Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS300	ARL10	All years	Left Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS300	ARL10	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	GS300	ARL10	All years	Driver Door Motor	√	√	√		0528	
JAP	GS300	ARL10	All years	Passenger Door Motor	√	√	√		0528	

JAP	GS300	ARL10	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	GS300	ARL10	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	GS300	ARL10	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	GS300	ARL10	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	GS300	ARL10	All years	Master Switch	✓	✓	✓			
JAP	GS300	ARL10	All years	Sliding Roof	✓	✓	✓		0529	
JAP	GS300	ARL10	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
JAP	GS300	ARL10	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	



JAP	GS300	ARL10	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	
JAP	GS300	ARL10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
JAP	GS300	ARL10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	GS300	ARL10	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	GS300	ARL10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	GS300	ARL10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	GS300	ARL10	All years	Remote Engine Starter	✓	✓	✓	✓		
JAP	GS300	ARL10	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
JAP	GS300	ARL10	All years	Navigation System	✓	✓	✓	✓		
JAP	GS300	ARL10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
JAP	GS300	ARL10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		

JAP	GS300h	AWL	All years	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0042, SP0043, SP0101, SP0103, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0198
JAP	GS300h	AWL	All years	HV	√	√	√	√	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 1577, 1578	
JAP	GS300h	AWL	All years	Cruise Control	√	√	√	√		

JAP	GS300h	AWL	All years	Air suspension	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	SP0001, SP0004, SP0007
JAP	GS300h	AWL	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	GS300h	AWL	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002, SP0004
JAP	GS300h	AWL	All years	EHPS	√	√	√	√		SP0001, SP0004, SP0009, SP0010

JAP	GS300h	AWL	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
JAP	GS300h	AWL	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	GS300h	AWL	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0004

JAP	GS300h	AWL	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018
JAP	GS300h	AWL	All years	Gateway	√	√	√	√		SP0005
JAP	GS300h	AWL	All years	Right Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS300h	AWL	All years	Left Front Door	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS300h	AWL	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	GS300h	AWL	All years	Driver Door Motor	√	√	√		0528	
JAP	GS300h	AWL	All years	Passenger Door Motor	√	√	√		0528	
JAP	GS300h	AWL	All years	Left Rear Door Motor	√	√	√		0528	

JAP	GS300h	AWL	All years	Right Rear Door Motor	√	√	√		0528	
JAP	GS300h	AWL	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	GS300h	AWL	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	GS300h	AWL	All years	Master Switch	√	√	√			
JAP	GS300h	AWL	All years	Sliding Roof	√	√	√		0529	
JAP	GS300h	AWL	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	
JAP	GS300h	AWL	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	GS300h	AWL	All years	Intuitive Parking Assist	√	√	√	√	0023, 0024, 0025, 0026	SP0006

JAP	GS300h	AWL	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	GS300h	AWL	All years	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0018, SP0201
JAP	GS300h	AWL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	SP0045
JAP	GS300h	AWL	All years	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274, 1607, 1608, 1609, 1610, 1611	SP0067, SP0068
JAP	GS300h	AWL	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
JAP	GS300h	AWL	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	GS300h	AWL	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
JAP	GS300h	AWL	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
JAP	GS300h	AWL	All years	Grill Shutter	✓	✓	✓		0037, 0038, 0039, 0040	SP0080
JAP	GS300h	AWL	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
JAP	GS300h	AWL	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	SP0061, SP0069

JAP	GS300h	AWL	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038
JAP	GS300h	AWL	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	GS300h	AWL	All years	Pre-Crash	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
JAP	GS300h	AWL	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
JAP	GS300h	AWL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
JAP	GS300h	AWL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
JAP	GS300h	AWL	All years	Central Gateway	✓	✓	✓	✓		
JAP	GS300h	AWL	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	



JAP	GS350	GRL	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0042, SP0043, SP0101, SP0103, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0118, SP0109, SP0111, SP0113, SP0118, SP0119
JAP	GS350	GRL	All years	Cruise Control	✓	✓	✓	✓		
JAP	GS350	GRL	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	SP0001, SP0004, SP0007

JAP	GS350	GRL	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	GS350	GRL	All years	4WD (CAN)	✓	✓	✓	✓	0819, 0820, 0821, 0822, 1669	SP0003, SP0052
JAP	GS350	GRL	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0004
JAP	GS350	GRL	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	GS350	GRL	All years	VGRS	✓	✓	✓	✓		SP0004, SP0037
JAP	GS350	GRL	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
JAP	GS350	GRL	All years	DRS	✓	✓	✓	✓		SP0004, SP0081, SP0082, SP0083

JAP	GS350	GRL	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	GS350	GRL	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0004

JAP	GS350	GRL	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018
JAP	GS350	GRL	All years	Gateway	✓	✓	✓	✓		SP0005
JAP	GS350	GRL	All years	Multi Bus Gateway	✓	✓	✓	✓		
JAP	GS350	GRL	All years	No. 1 Multi Bus Monitor	✓	✓	✓	✓		SP0005
JAP	GS350	GRL	All years	No. 2 Multi Bus Monitor	✓	✓	✓	✓		SP0005
JAP	GS350	GRL	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS350	GRL	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS350	GRL	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	

JAP	GS350	GRL	All years	Driver Door Motor	√	√	√		0528	
JAP	GS350	GRL	All years	Passenger Door Motor	√	√	√		0528	
JAP	GS350	GRL	All years	Left Rear Door Motor	√	√	√		0528	
JAP	GS350	GRL	All years	Right Rear Door Motor	√	√	√		0528	
JAP	GS350	GRL	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	GS350	GRL	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	GS350	GRL	All years	Master Switch	√	√	√			
JAP	GS350	GRL	All years	Sliding Roof	√	√	√		0529	
JAP	GS350	GRL	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	

JAP	GS350	GRL	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	GS350	GRL	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
JAP	GS350	GRL	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	

JAP	GS350	GRL	All years	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0018, SP0201
JAP	GS350	GRL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	SP0045
JAP	GS350	GRL	All years	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274, 1607, 1608, 1609, 1610, 1611	SP0067, SP0068
JAP	GS350	GRL	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
JAP	GS350	GRL	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
JAP	GS350	GRL	All years	Charging Control	✓	✓	✓	✓	0258, 1613	
JAP	GS350	GRL	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	GS350	GRL	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
JAP	GS350	GRL	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0137, SP0179
JAP	GS350	GRL	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	SP0061, SP0069
JAP	GS350	GRL	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038
JAP	GS350	GRL	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	GS350	GRL	All years	Pre-Crash	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044, SP0128, SP0143, SP0144

JAP	GS350	GRL	All years	ECT	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0084, 008 5, 0086, 0087 , 0088, 0089, 0096, 0097, 0 100, 0101, 01 02, 0103, 010 4, 0105, 0106 , 0107, 0108, 0110, 0111, 0 112, 0113, 01 18, 0122, 012 4, 0125, 0149 , 0159, 0161, 0162, 0163, 0 164, 0165, 01 66, 0167, 016 8, 0170, 0171 , 0172, 0173, 0174, 0175, 0 179, 0180, 01 81, 0182, 018 3, 0184, 0185 , 0186, 0187, 0188, 0189, 0 190, 0191, 01 92, 0193, 019 4, 0195, 0196 , 0197, 0198,	SP0003, SP0 004, SP0032 , SP0101
-----	-------	-----	--------------	-----	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------



JAP	GS350	GRL	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,
-----	-------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	GS350	GRL	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
JAP	GS350	GRL	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
JAP	GS350	GRL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
JAP	GS350	GRL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
JAP	GS350	GRL	All years	Central Gateway	✓	✓	✓	✓		
JAP	GS350	GRL	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051	

JAP	GS350	GRL	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
JAP	GS350	GRL	All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	GS350	GRL	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	GS350	GRS	All years	Engine	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0101, SP0103, SP0104, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0198

JAP	GS350	GRS	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,	SP0003, SP0004, SP0030, SP0032, SP0101
JAP	GS350	GRS	All years	Cruise Control	✓	✓	✓	✓		
JAP	GS350	GRS	All years	Air Suspension	✓	✓	✓		0469, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646, 1715, 1716, 1717, 1718, 1719, 1720, 1721, 1722, 1723, 1724, 1725, 1726, 1727, 1728	SP0001, SP0004, SP0007

JAP	GS350	GRS	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	GS350	GRS	All years	4WD (CAN)	✓	✓	✓	✓	0819, 0820, 0821, 0822, 1669	SP0003, SP0052
JAP	GS350	GRS	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0004
JAP	GS350	GRS	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	GS350	GRS	All years	VGRS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0037
JAP	GS350	GRS	All years	Lane Keeping Assist (LKA)	✓	✓	✓			

JAP	GS350	GRS	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0573, 0594, 0598, 0599, 0615, 1016, 1017, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1703, 1704, 1705, 1706, 1707, 1708, 1709, 1710, 1711, 1712, 1713, 1714	SP0017
JAP	GS350	GRS	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓			SP0004
JAP	GS350	GRS	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	SP0061
JAP	GS350	GRS	All years	Body	✓	✓	✓		0319, 0331, 0333, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0805, 0806, 0809, 0815, 0816, 0912, 0913, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0926, 0927, 0928, 0929, 0934, 0969, 1648, 1665, 1666, 1682, 1688	SP0005
JAP	GS350	GRS	All years	Gateway	✓	✓	✓	✓		SP0005

JAP	GS350	GRS	All years	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0917, 0918, 0931, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0952, 0953, 0955, 0956, 0957, 0958, 0959, 0961, 0962, 0967, 1678, 1679, 1680, 1681
JAP	GS350	GRS	All years	Body No. 4	✓		✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0929, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681
JAP	GS350	GRS	All years	Body No. 5			✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681, 1689
JAP	GS350	GRS	All years	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0317, 0429, 0437, 0528, 0991

JAP	GS350	GRS	All years	Passenger Door	√	√	√		0279, 0280, 0281, 0282, 0283, 0317, 0429, 0430, 0437, 0528, 0991	
JAP	GS350	GRS	All years	Left Rear Door	√	√	√		0284, 0317, 0429, 0437, 0528, 0990, 0991	
JAP	GS350	GRS	All years	Right Rear Door	√	√	√		0284, 0317, 0429, 0437, 0528, 0990, 0991	
JAP	GS350	GRS	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	GS350	GRS	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	GS350	GRS	All years	Master Switch			√		0939, 0940, 0941, 0942	
JAP	GS350	GRS	All years	Driver Seat Switch			√			
JAP	GS350	GRS	All years	Sliding Roof			√		0529	
JAP	GS350	GRS	All years	Tilt&Teleopic	√	√	√	√	0472, 0473, 1005	



JAP	GS350	GRS	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0669, 0670, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044, 1045, 1046, 1048, 1049, 1050, 1051, 1052,	
JAP	GS350	GRS	All years	Combination Switch			√			
JAP	GS350	GRS	All years	Intuitive Parking Assist	√	√	√		0023, 0024	SP0006
JAP	GS350	GRS	All years	Rain Sensor			√			
JAP	GS350	GRS	All years	AFS	√	√	√		0008, 0009, 0475, 1683, 1684, 1685	
JAP	GS350	GRS	All years	Entry&Start	√	√	√		0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0938	SP0011, SP0013, SP0014, SP0201
JAP	GS350	GRS	All years	Power Source Control	√	√	√		0300, 0301, 0818, 0936	
JAP	GS350	GRS	All years	Radar Cruise	√	√	√	√		SP0061, SP0062

JAP	GS350	GRS	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	✓	✓	✓	✓		
JAP	GS350	GRS	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
JAP	GS350	GRS	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	GS430	UZS	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0101, SP0103, SP0104, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0198

JAP	GS430	UZS	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,	SP0003, SP0004, SP0030, SP0032, SP0101
JAP	GS430	UZS	All years	Cruise Control	✓	✓	✓	✓		
JAP	GS430	UZS	All years	Air Suspension	✓	✓	✓		0469, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646, 1715, 1716, 1717, 1718, 1719, 1720, 1721, 1722, 1723, 1724, 1725, 1726, 1727, 1728	SP0001, SP0004, SP0007
JAP	GS430	UZS	All years	Stabilizer	✓	✓	✓			SP0001

JAP	GS430	UZS	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	GS430	UZS	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0004
JAP	GS430	UZS	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	GS430	UZS	All years	VGRS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0037
JAP	GS430	UZS	All years	Lane Keeping Assist (LKA)	✓	✓	✓			

JAP	GS430	UZS	All years	Air Conditioner	✓	✓	✓	0556, 0557, 0558, 0561, 0562, 0573, 0594, 0598, 0599, 0615, 1016, 1017, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1703, 1704, 1705, 1706, 1707, 1708, 1709, 1710, 1711, 1712, 1713, 1714	SP0017
JAP	GS430	UZS	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓		SP0004
JAP	GS430	UZS	All years	Pre-Collision	✓	✓	✓	0348, 0349	SP0061
JAP	GS430	UZS	All years	Body	✓	✓	✓	0319, 0331, 0333, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0805, 0806, 0809, 0815, 0816, 0912, 0913, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0926, 0927, 0928, 0929, 0934, 0969, 1648, 1665, 1666, 1682, 1688	SP0005
JAP	GS430	UZS	All years	Gateway	✓	✓	✓	✓	SP0005

JAP	GS430	UZS	All years	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0917, 0918, 0931, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0952, 0953, 0955, 0956, 0957, 0958, 0959, 0961, 0962, 0967, 1678, 1679, 1680, 1681
JAP	GS430	UZS	All years	Body No. 4	✓		✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0929, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681
JAP	GS430	UZS	All years	Body No. 5			✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681, 1689
JAP	GS430	UZS	All years	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0317, 0429, 0437, 0528, 0991

JAP	GS430	UZS	All years	Passenger Door	√	√	√		0279, 0280, 0281, 0282, 0283, 0317, 0429, 0430, 0437, 0528, 0991	
JAP	GS430	UZS	All years	Left Rear Door	√	√	√		0284, 0317, 0429, 0437, 0528, 0990, 0991	
JAP	GS430	UZS	All years	Right Rear Door	√	√	√		0284, 0317, 0429, 0437, 0528, 0990, 0991	
JAP	GS430	UZS	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	GS430	UZS	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	GS430	UZS	All years	Master Switch			√		0939, 0940, 0941, 0942	
JAP	GS430	UZS	All years	Driver Seat Switch			√			
JAP	GS430	UZS	All years	Sliding Roof			√		0529	
JAP	GS430	UZS	All years	Tilt&Teleopic	√	√	√	√	0472, 0473, 1005	

JAP	GS430	UZS	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0669, 0670, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044, 1045, 1046, 1048, 1049, 1050, 1051, 1052,	
JAP	GS430	UZS	All years	Combination Switch			√			
JAP	GS430	UZS	All years	Intuitive Parking Assist	√	√	√		0023, 0024	SP0006
JAP	GS430	UZS	All years	Rain Sensor			√			
JAP	GS430	UZS	All years	AFS	√	√	√		0008, 0009, 0475, 1683, 1684, 1685	
JAP	GS430	UZS	All years	Entry&Start	√	√	√		0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0938	SP0011, SP0013, SP0014, SP0201
JAP	GS430	UZS	All years	Power Source Control	√	√	√		0300, 0301, 0818, 0936	
JAP	GS430	UZS	All years	Radar Cruise	√	√	√	√		SP0061, SP0062



JAP	GS450h	GWL	All years	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0042, SP0043, SP0101, SP0103, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP01198
JAP	GS450h	GWL	All years	HV	√	√	√	√	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 1577, 1578	
JAP	GS450h	GWL	All years	Cruise Control	√	√	√	√		

JAP	GS450h	GWL	All years	Air suspension	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	SP0001, SP0004, SP0007
JAP	GS450h	GWL	All years	Antilock Brake System (ABS) - Vehicle Stability Control (VSC) - Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	GS450h	GWL	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002, SP0004
JAP	GS450h	GWL	All years	EHPS	√	√	√	√		SP0001, SP0004, SP0009, SP0010
JAP	GS450h	GWL	All years	VGRS	√	√	√	√		SP0004, SP0037

JAP	GS450h	GWL	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
JAP	GS450h	GWL	All years	DRS	√	√	√	√		SP0004, SP0081, SP0082, SP0083
JAP	GS450h	GWL	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	GS450h	GWL	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0004

JAP	GS450h	GWL	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018
JAP	GS450h	GWL	All years	Gateway	✓	✓	✓	✓		SP0005
JAP	GS450h	GWL	All years	Multi Bus Gateway	✓	✓	✓	✓		
JAP	GS450h	GWL	All years	No. 1 Multi Bus Monitor	✓	✓	✓	✓		SP0005
JAP	GS450h	GWL	All years	No. 2 Multi Bus Monitor	✓	✓	✓	✓		SP0005
JAP	GS450h	GWL	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS450h	GWL	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	GS450h	GWL	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	

JAP	GS450h	GWL	All years	Driver Door Motor	√	√	√		0528	
JAP	GS450h	GWL	All years	Passenger Door Motor	√	√	√		0528	
JAP	GS450h	GWL	All years	Left Rear Door Motor	√	√	√		0528	
JAP	GS450h	GWL	All years	Right Rear Door Motor	√	√	√		0528	
JAP	GS450h	GWL	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	GS450h	GWL	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	GS450h	GWL	All years	Master Switch	√	√	√			
JAP	GS450h	GWL	All years	Sliding Roof	√	√	√		0529	
JAP	GS450h	GWL	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	

JAP	GS450h	GWL	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	GS450h	GWL	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
JAP	GS450h	GWL	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	

JAP	GS450h	GWL	All years	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0018, SP0201
JAP	GS450h	GWL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	SP0045
JAP	GS450h	GWL	All years	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274, 1607, 1608, 1609, 1610, 1611	SP0067, SP0068
JAP	GS450h	GWL	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
JAP	GS450h	GWL	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	GS450h	GWL	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
JAP	GS450h	GWL	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
JAP	GS450h	GWL	All years	Grill Shutter	✓	✓	✓		0037, 0038, 0039, 0040	SP0080, SP0142
JAP	GS450h	GWL	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	SP0061, SP0069
JAP	GS450h	GWL	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038
JAP	GS450h	GWL	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	GS450h	GWL	All years	Pre-Crash	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
JAP	GS450h	GWL	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	

JAP	GS450h	GWL	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	GS450h	GWL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	GS450h	GWL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
JAP	GS450h	GWL	All years	Central Gateway	√	√	√	√		
JAP	GS450h	GWL	All years	Head Up Display	√	√	√	√	0047, 0048, 0049, 0050, 0051	
JAP	GS450h	GWS	All years	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0101, SP0103, SP0104, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0198



JAP	GS450h	GWS	All years	HV	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117, 1577, 1578	SP0003, SP0004, SP0005, SP0024, SP0025
JAP	GS450h	GWS	All years	Cruise Control	✓	✓	✓	✓		
JAP	GS450h	GWS	All years	Air Suspension	✓	✓	✓		0469, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646, 1715, 1716, 1717, 1718, 1719, 1720, 1721, 1722, 1723, 1724, 1725, 1726, 1727, 1728	SP0001, SP0004, SP0007
JAP	GS450h	GWS	All years	Stabilizer	✓	✓	✓			SP0001
JAP	GS450h	GWS	All years	Antilock Brake System (ABS) - Vehicle Stability Control (VSC) - Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024

JAP	GS450h	GWS	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0004
JAP	GS450h	GWS	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	GS450h	GWS	All years	VGRS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0037
JAP	GS450h	GWS	All years	Lane Keeping Assist (LKA)	✓	✓	✓			
JAP	GS450h	GWS	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0573, 0594, 0598, 0599, 0615, 1016, 1017, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1703, 1704, 1705, 1706, 1707, 1708, 1709, 1710, 1711, 1712, 1713, 1714	SP0017
JAP	GS450h	GWS	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓			SP0004
JAP	GS450h	GWS	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	SP0061
JAP	GS450h	GWS	All years	Body	✓	✓	✓		0319, 0331, 0333, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0805, 0806, 0809, 0815, 0816, 0912, 0913, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0926, 0927, 0928, 0929, 0934, 0969, 1648, 1665, 1666, 1682, 1688	SP0005
JAP	GS450h	GWS	All years	Gateway	✓	✓	✓	✓		SP0005

JAP	GS450h	GWS	All years	HV Gateway	√	√	√	√		SP0005
JAP	GS450h	GWS	All years	Body No. 3	√	√	√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0917, 0918, 0931, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0952, 0953, 0955, 0956, 0957, 0958, 0959, 0961, 0962, 0967, 1678, 1679, 1680, 1681	
JAP	GS450h	GWS	All years	Body No. 4	√		√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0929, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681	
JAP	GS450h	GWS	All years	Body No. 5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681, 1689	
JAP	GS450h	GWS	All years	Driver Door	√	√	√		0279, 0280, 0281, 0282, 0283, 0317, 0429, 0437, 0528, 0991	

JAP	GS450h	GWS	All years	Passenger Door	√	√	√		0279, 0280, 0281, 0282, 0283, 0317, 0429, 0430, 0437, 0528, 0991	
JAP	GS450h	GWS	All years	Left Rear Door	√	√	√		0284, 0317, 0429, 0437, 0528, 0990, 0991	
JAP	GS450h	GWS	All years	Right Rear Door	√	√	√		0284, 0317, 0429, 0437, 0528, 0990, 0991	
JAP	GS450h	GWS	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	GS450h	GWS	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	GS450h	GWS	All years	Master Switch			√		0939, 0940, 0941, 0942	
JAP	GS450h	GWS	All years	Driver Seat Switch			√			
JAP	GS450h	GWS	All years	Sliding Roof			√		0529	
JAP	GS450h	GWS	All years	Tilt&Teleopic	√	√	√	√	0472, 0473, 1005	

JAP	GS450h	GWS	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0669, 0670, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044, 1045, 1046, 1048, 1049, 1050, 1051, 1052,	
JAP	GS450h	GWS	All years	Combination Switch			√			
JAP	GS450h	GWS	All years	Intuitive Parking Assist	√	√	√		0023, 0024	SP0006
JAP	GS450h	GWS	All years	Rain Sensor			√			
JAP	GS450h	GWS	All years	AFS	√	√	√		0008, 0009, 0475, 1683, 1684, 1685	
JAP	GS450h	GWS	All years	Entry&Start	√	√	√		0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0938	SP0011, SP0013, SP0014, SP0201
JAP	GS450h	GWS	All years	Power Source Control	√	√	√		0300, 0301, 0818, 0936	
JAP	GS450h	GWS	All years	Radar Cruise	√	√	√	√		SP0061, SP0062

JAP	GS450h	GWS	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	✓	✓	✓	✓		
JAP	GS450h	GWS	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
JAP	GS450h	GWS	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	GS460	URS	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0101, SP0103, SP0104, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0198

JAP	GS460	URS	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,	SP0003, SP0004, SP0030, SP0032, SP0101
JAP	GS460	URS	All years	Cruise Control	✓	✓	✓	✓		
JAP	GS460	URS	All years	Air Suspension	✓	✓	✓		0469, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646, 1715, 1716, 1717, 1718, 1719, 1720, 1721, 1722, 1723, 1724, 1725, 1726, 1727, 1728	SP0001, SP0004, SP0007
JAP	GS460	URS	All years	Stabilizer	✓	✓	✓			SP0001

JAP	GS460	URS	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	GS460	URS	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0004
JAP	GS460	URS	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	GS460	URS	All years	VGRS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0037
JAP	GS460	URS	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	✓	✓	✓	✓		
JAP	GS460	URS	All years	Lane Keeping Assist (LKA)	✓	✓	✓			



JAP	GS460	URS	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0573, 0594, 0598, 0599, 0615, 1016, 1017, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1703, 1704, 1705, 1706, 1707, 1708, 1709, 1710, 1711, 1712, 1713, 1714	SP0017
JAP	GS460	URS	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓			SP0004
JAP	GS460	URS	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	GS460	URS	All years	Body	✓	✓	✓		0319, 0331, 0333, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0805, 0806, 0809, 0815, 0816, 0912, 0913, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0926, 0927, 0928, 0929, 0934, 0969, 1648, 1665, 1666, 1682, 1688	SP0005
JAP	GS460	URS	All years	Gateway	✓	✓	✓	✓		SP0005
JAP	GS460	URS	All years	Accessory Gateway	✓	✓	✓	✓		SP0005

JAP	GS460	URS	All years	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0917, 0918, 0931, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0952, 0953, 0955, 0956, 0957, 0958, 0959, 0961, 0962, 0967, 1678, 1679, 1680, 1681
JAP	GS460	URS	All years	Body No. 4	✓		✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0929, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681
JAP	GS460	URS	All years	Body No. 5			✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681, 1689
JAP	GS460	URS	All years	Driver Door	✓	✓	✓	0279, 0280, 0281, 0282, 0283, 0317, 0429, 0437, 0528, 0991

JAP	GS460	URS	All years	Passenger Door	√	√	√		0279, 0280, 0281, 0282, 0283, 0317, 0429, 0430, 0437, 0528, 0991	
JAP	GS460	URS	All years	Left Rear Door	√	√	√		0284, 0317, 0429, 0437, 0528, 0990, 0991	
JAP	GS460	URS	All years	Right Rear Door	√	√	√		0284, 0317, 0429, 0437, 0528, 0990, 0991	
JAP	GS460	URS	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	GS460	URS	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	GS460	URS	All years	Master Switch			√		0939, 0940, 0941, 0942	
JAP	GS460	URS	All years	Driver Seat Switch			√			
JAP	GS460	URS	All years	Sliding Roof			√		0529	
JAP	GS460	URS	All years	Tilt&Teleopic	√	√	√	√	0472, 0473, 1005	

JAP	GS460	URS	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0669, 0670, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044, 1045, 1046, 1048, 1049, 1050, 1051, 1052,	
JAP	GS460	URS	All years	Combination Switch			√			
JAP	GS460	URS	All years	Intuitive Parking Assist	√	√	√		0023, 0024	SP0006
JAP	GS460	URS	All years	Rain Sensor			√			
JAP	GS460	URS	All years	AFS	√	√	√		0008, 0009, 0475, 1683, 1684, 1685	
JAP	GS460	URS	All years	Entry&Start	√	√	√		0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0938	SP0011, SP0013, SP0014, SP0201
JAP	GS460	URS	All years	Power Source Control	√	√	√		0300, 0301, 0818, 0936	
JAP	GS460	URS	All years	Navigation System	√	√	√	√		SP0050
JAP	GS460	URS	All years	Radar Cruise	√	√	√	√		SP0061, SP0062

JAP	HS250h	ANF	All years	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0101, SP0103, SP0104, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0198
JAP	HS250h	ANF	All years	HV	√	√	√	√	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117, 1577, 1578	SP0003, SP0004, SP0005, SP0024, SP0025
JAP	HS250h	ANF	All years	Cruise Control	√	√	√	√		

JAP	HS250h	ANF	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024, SP0088
JAP	HS250h	ANF	All years	EHPS	√	√	√	√		SP0001, SP0004, SP0009, SP0010
JAP	HS250h	ANF	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	√	√	√	√		
JAP	HS250h	ANF	All years	Transmission Control	√	√	√	√		

JAP	HS250h	ANF	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	HS250h	ANF	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0004

JAP	HS250h	ANF	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018, SP0019, SP0020
JAP	HS250h	ANF	All years	PM1 Gateway	√	√	√	√		SP0005
JAP	HS250h	ANF	All years	PM2 Gateway	√	√	√	√		SP0005
JAP	HS250h	ANF	All years	Driver Door Motor	√	√	√		0528	
JAP	HS250h	ANF	All years	Passenger Door Motor	√	√	√		0528	
JAP	HS250h	ANF	All years	Left Rear Door Motor	√	√	√		0528	
JAP	HS250h	ANF	All years	Right Rear Door Motor	√	√	√		0528	
JAP	HS250h	ANF	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	HS250h	ANF	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	



JAP	HS250h	ANF	All years	Master Switch	✓	✓	✓				
JAP	HS250h	ANF	All years	Sliding Roof	✓	✓	✓		0529		
JAP	HS250h	ANF	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473		
JAP	HS250h	ANF	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,		
JAP	HS250h	ANF	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612		
JAP	HS250h	ANF	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612		
JAP	HS250h	ANF	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006	

JAP	HS250h	ANF	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	HS250h	ANF	All years	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0201
JAP	HS250h	ANF	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	SP0045
JAP	HS250h	ANF	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
JAP	HS250h	ANF	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	HS250h	ANF	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0069
JAP	HS250h	ANF	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038
JAP	HS250h	ANF	All years	Active Headrest Right	✓	✓	✓		0306, 0307, 0308, 0309	
JAP	HS250h	ANF	All years	Active Headrest Left	✓	✓	✓		0306, 0307, 0308, 0309	
JAP	HS250h	ANF	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	HS250h	ANF	All years	Pre-Crash	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0040, SP0044, SP0199, SP0200

JAP	HS250h	AZK	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0101, SP0103, SP0104, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0117, SP0118, SP0119, SP0121, SP0122, SP0123, SP0124, SP0125, SP0126, SP0127, SP0128, SP0129, SP0130, SP0131, SP0132, SP0133, SP0134, SP0135, SP0136, SP0137, SP0138, SP0139, SP0140, SP0141, SP0142, SP0143, SP0144, SP0145, SP0146, SP0147, SP0148, SP0149, SP0150, SP0151, SP0152, SP0153, SP0154, SP0155, SP0156, SP0157, SP0158, SP0159, SP0160, SP0161, SP0162, SP0163, SP0164, SP0165,
JAP	HS250h	AZK	All years	HV	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117, 1577, 1578	SP0003, SP0004, SP0005, SP0024, SP0025
JAP	HS250h	AZK	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0069

JAP	HS250h	AZK	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024, SP0088
JAP	HS250h	AZK	All years	EHPS	√	√	√	√		SP0001, SP0004, SP0009, SP0010
JAP	HS250h	AZK	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	√	√	√	√		
JAP	HS250h	AZK	All years	Lane Keeping Assist (LKA)	√	√	√	√		SP0038
JAP	HS250h	AZK	All years	Transmission Control	√	√	√	√		

JAP	HS250h	AZK	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	HS250h	AZK	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0004
JAP	HS250h	AZK	All years	Active Headrest Right	√	√	√		0306, 0307, 0308, 0309	
JAP	HS250h	AZK	All years	Active Headrest Left	√	√	√		0306, 0307, 0308, 0309	
JAP	HS250h	AZK	All years	Pre-Collision	√	√	√	√	0347, 0348, 0349, 0350	
JAP	HS250h	AZK	All years	Pre-Crash	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0040, SP0044, SP0199, SP0200

JAP	HS250h	AZK	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018
JAP	HS250h	AZK	All years	PM1 Gateway	✓	✓	✓	✓		SP0005
JAP	HS250h	AZK	All years	PM2 Gateway	✓	✓	✓	✓		SP0005
JAP	HS250h	AZK	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	HS250h	AZK	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	HS250h	AZK	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	HS250h	AZK	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	HS250h	AZK	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	HS250h	AZK	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	

JAP	HS250h	AZK	All years	Master Switch	✓	✓	✓				
JAP	HS250h	AZK	All years	Sliding Roof	✓	✓	✓		0529		
JAP	HS250h	AZK	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473		
JAP	HS250h	AZK	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,		
JAP	HS250h	AZK	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612		
JAP	HS250h	AZK	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612		
JAP	HS250h	AZK	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006	

JAP	HS250h	AZK	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	HS250h	AZK	All years	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0201
JAP	HS250h	AZK	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	SP0045
JAP	HS250h	AZK	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
JAP	HS250h	AZK	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	HS250h	AZK	All years	Cruise Control	✓	✓	✓	✓		



JAP	IS F	USE	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0084, 008 5, 0086, 0087 , 0088, 0089, 0090, 0091, 0 092, 0093, 00 94, 0095, 009 6, 0097, 0098 , 0099, 0100, 0101, 0102, 0 103, 0104, 01 05, 0106, 010 7, 0108, 0109 , 0110, 0111, 0112, 0113, 0 114, 0118, 01 22, 0124, 012 5, 0130, 0131 , 0135, 0137, 0138, 0142, 0 143, 0144, 01 45, 0146, 014 7, 0148, 0149 , 0150, 0151, 0152, 0154, 0 155, 0156, 01 59, 0160, 016 1, 0162, 0163 , 0164, 0165,	SP0003, SP0 004, SP0027 , SP0029, SP 0030, SP003 1, SP0032, S P0101, SP01 03, SP0104, SP0106, SP0 107, SP0108 , SP0109, SP 0110, SP011 1, SP0113, S P0198
-----	------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	IS F	USE	All years	ECT	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0084, 008 5, 0086, 0087 , 0088, 0089, 0096, 0097, 0 100, 0101, 01 02, 0103, 010 4, 0105, 0106 , 0107, 0108, 0110, 0111, 0 112, 0113, 01 18, 0122, 012 4, 0125, 0149 , 0159, 0161, 0162, 0163, 0 164, 0165, 01 66, 0167, 016 8, 0170, 0171 , 0172, 0173, 0174, 0175, 0 179, 0180, 01 81, 0182, 018 3, 0184, 0185 , 0186, 0187, 0188, 0189, 0 190, 0191, 01 92, 0193, 019 4, 0195, 0196 , 0197, 0198,	SP0003, SPO 004, SP0030 , SP0032, SP 0101
JAP	IS F	USE	All years	Cruise Control	✓	✓	✓	✓		

JAP	IS F	USE	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	IS F	USE	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	IS F	USE	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0573, 0594, 0598, 0599, 0615, 1016, 1017, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1703, 1704, 1705, 1706, 1707, 1708, 1709, 1710, 1711, 1712, 1713, 1714	SP0017
JAP	IS F	USE	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓			SP0004

JAP	IS F	USE	All years	Body	√	√	√	0319, 0331, 0333, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0805, 0806, 0809, 0815, 0816, 0912, 0913, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0926, 0927, 0928, 0929, 0934, 0969, 1648, 1665, 1666, 1682, 1688	SP0005
JAP	IS F	USE	All years	Gateway	√	√	√		SP0005
JAP	IS F	USE	All years	Body No. 3	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0917, 0918, 0931, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0952, 0953, 0955, 0956, 0957, 0958, 0959, 0961, 0962, 0967, 1678, 1679, 1680, 1681	
JAP	IS F	USE	All years	Body No. 5			√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681, 1689	

JAP	IS F	USE	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	IS F	USE	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	IS F	USE	All years	Master Switch			√		0939, 0940, 0941, 0942	
JAP	IS F	USE	All years	Sliding Roof			√		0529	
JAP	IS F	USE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	
JAP	IS F	USE	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0669, 0670, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044, 1045, 1046, 1048, 1049, 1050, 1051, 1052,	
JAP	IS F	USE	All years	Intuitive Parking Assist	√	√	√		0023, 0024	SP0006
JAP	IS F	USE	All years	Rain Sensor			√			
JAP	IS F	USE	All years	AFS	√	√	√		0008, 0009, 0475, 1683, 1684, 1685	

JAP	IS F	USE	All years	Entry&Start	√	√	√		0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0938	SP0011, SP0013, SP0014, SP0201
JAP	IS F	USE	All years	Power Source Control	√	√	√		0300, 0301, 0818, 0936	
JAP	IS F	USE	All years	Radar Cruise	√	√	√	√		SP0061, SP0062
JAP	IS F	USE	All years	Pre-Collision	√	√	√	√	0347, 0348, 0349, 0350	SP0061
JAP	IS F	USE	All years	Right Mirror			√		0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
JAP	IS F	USE	All years	Left Mirror			√		0279, 0280, 0281, 0282, 0283, 0971, 0973, 0975, 0976, 0977, 0978, 0979, 0980, 1686, 1687	
JAP	IS F	USE	All years	Combination Switch			√			
JAP	IS F	USE	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	√	√	√	√		
JAP	IS F	USE	All years	Accessory Gateway	√	√	√	√		SP0005
JAP	IS F	USE	All years	Navigation System	√	√	√	√		SP0050

JAP	IS200t	ASE30	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,
-----	--------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	IS200t	ASE30	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
JAP	IS200t	ASE30	All years	Stop&Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297
JAP	IS200t	ASE30	All years	Cruise Control	✓	✓	✓	✓	
JAP	IS200t	ASE30	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0446, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646



JAP	IS200t	ASE30	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	IS200t	ASE30	All years	Tire Pressure Monitor	√	√	√			
JAP	IS200t	ASE30	All years	EHPS	√	√	√	√		
JAP	IS200t	ASE30	All years	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	

JAP	IS200t	ASE30	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661
JAP	IS200t	ASE30	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓	

JAP	IS200t	ASE30	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	IS200t	ASE30	All years	Gateway	√	√	√	√		
JAP	IS200t	ASE30	All years	Accessory Gateway	√	√	√	√		
JAP	IS200t	ASE30	All years	Driver Door Motor	√	√	√		0528	
JAP	IS200t	ASE30	All years	Passenger Door Motor	√	√	√		0528	
JAP	IS200t	ASE30	All years	Left Rear Door Motor	√	√	√		0528	
JAP	IS200t	ASE30	All years	Right Rear Door Motor	√	√	√		0528	
JAP	IS200t	ASE30	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	IS200t	ASE30	All years	Master Switch	√	√	√			
JAP	IS200t	ASE30	All years	Sliding Roof	√	√	√		0529	
JAP	IS200t	ASE30	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	

JAP	IS200t	ASE30	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	IS200t	ASE30	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	IS200t	ASE30	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	IS200t	ASE30	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
JAP	IS200t	ASE30	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	

JAP	IS200t	ASE30	All years	Smart Key	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	IS200t	ASE30	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	IS200t	ASE30	All years	Remote Engine Starter	√	√	√	√		
JAP	IS200t	ASE30	All years	Starting Control	√	√	√	√	0256, 0257	
JAP	IS200t	ASE30	All years	Navigation System	√	√	√	√		
JAP	IS200t	ASE30	All years	Master Blind Spot Monitor	√	√	√	√		
JAP	IS200t	ASE30	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	IS200t	ASE30	All years	Radar Cruise	√	√	√	√	0017, 0018	
JAP	IS200t	ASE30	All years	Pre-Crash	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	IS200t	ASE30	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	IS200t	ASE30	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	

JAP	IS200t	ASE30	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
JAP	IS200t	ASE30	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	IS200t	ASE30	All years	Central Gateway	√	√	√	√		
JAP	IS200t	ASE30	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
JAP	IS200t	ASE30	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	

JAP	IS250	GSE	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0084, 008 5, 0086, 0087 , 0088, 0089, 0090, 0091, 0 092, 0093, 00 94, 0095, 009 6, 0097, 0098 , 0099, 0100, 0101, 0102, 0 103, 0104, 01 05, 0106, 010 7, 0108, 0109 , 0110, 0111, 0112, 0113, 0 114, 0118, 01 22, 0124, 012 5, 0130, 0131 , 0135, 0137, 0138, 0142, 0 143, 0144, 01 45, 0146, 014 7, 0148, 0149 , 0150, 0151, 0152, 0154, 0 155, 0156, 01 59, 0160, 016 1, 0162, 0163 , 0164, 0165,	SP0003, SP0 004, SP0027 , SP0029, SP 0030, SP003 1, SP0032, S P0101, SP01 03, SP0104, SP0106, SP0 107, SP0108 , SP0109, SP 0110, SP011 1, SP0113, S P0198
-----	-------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	IS250	GSE	All years	ECT	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0084, 008 5, 0086, 0087 , 0088, 0089, 0096, 0097, 0 100, 0101, 01 02, 0103, 010 4, 0105, 0106 , 0107, 0108, 0110, 0111, 0 112, 0113, 01 18, 0122, 012 4, 0125, 0149 , 0159, 0161, 0162, 0163, 0 164, 0165, 01 66, 0167, 016 8, 0170, 0171 , 0172, 0173, 0174, 0175, 0 179, 0180, 01 81, 0182, 018 3, 0184, 0185 , 0186, 0187, 0188, 0189, 0 190, 0191, 01 92, 0193, 019 4, 0195, 0196 , 0197, 0198,	SP0003, SP0 004, SP0030 , SP0032, SP 0101
JAP	IS250	GSE	All years	Cruise Control	✓	✓	✓	✓		



JAP	IS250	GSE	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	IS250	GSE	All years	4WD (CAN)	✓	✓	✓	✓	0819, 0820, 0821, 0822, 1669	SP0003, SP0052
JAP	IS250	GSE	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010

JAP	IS250	GSE	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1016, 1017, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1649, 1650, 1651, 1652, 1653, 1654, 1655,	SP0016, SP0017, SP0051
JAP	IS250	GSE	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0004
JAP	IS250	GSE	All years	Body	√	√	√		0319, 0331, 0333, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0805, 0806, 0809, 0815, 0816, 0912, 0913, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0926, 0927, 0928, 0929, 0934, 0969, 1648, 1665, 1666, 1682, 1688	SP0005

JAP	IS250	GSE	All years	Gateway	√	√	√	√		SP0005
JAP	IS250	GSE	All years	Body No. 3	√	√	√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0917, 0918, 0931, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0952, 0953, 0955, 0956, 0957, 0958, 0959, 0961, 0962, 0967, 1678, 1679, 1680, 1681	
JAP	IS250	GSE	All years	Body No. 5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681, 1689	
JAP	IS250	GSE	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	IS250	GSE	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	IS250	GSE	All years	Master Switch	√	√	√		0939, 0940, 0941, 0942	
JAP	IS250	GSE	All years	Sliding Roof	√	√	√		0529	
JAP	IS250	GSE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	

JAP	IS250	GSE	All years	Combination Meter	√	√	√	√	0274, 0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682,	
JAP	IS250	GSE	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980, 1612	
JAP	IS250	GSE	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 0971, 0973, 0975, 0976, 0977, 0978, 0979, 0980, 1612, 1686, 1687	
JAP	IS250	GSE	All years	Combination Switch			√			

JAP	IS250	GSE	All years	Intuitive Parking Assist	√	√	√	√	0023, 0024, 0025, 0026	SP0006
JAP	IS250	GSE	All years	Rain Sensor			√			
JAP	IS250	GSE	All years	AFS	√	√	√		0008, 0009, 0475, 1683, 1684, 1685	
JAP	IS250	GSE	All years	Entry&Start	√	√	√		0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0938	SP0011, SP0013, SP0014, SP0201
JAP	IS250	GSE	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 0818, 0936, 1614, 1615, 1616, 1617	SP0045
JAP	IS250	GSE	All years	Radar Cruise	√	√	√	√		SP0061, SP0062, SP0069
JAP	IS250	GSE	All years	Pre-Collision	√	√	√	√	0347, 0348, 0349, 0350	SP0061
JAP	IS250	GSE	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	√	√	√	√		
JAP	IS250	GSE	All years	Accessory Gateway	√	√	√	√		SP0005
JAP	IS250	GSE	All years	Navigation System	√	√	√	√		SP0050

JAP	IS250	GSE	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0042, SP0043, SP0101, SP0103, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0118, SP0109, SP0111, SP0113, SP0198
JAP	IS250	GSE	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	SP0001, SP0004, SP0007
JAP	IS250	GSE	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0004
JAP	IS250	GSE	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087

JAP	IS250	GSE	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018
JAP	IS250	GSE	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	IS250	GSE	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	IS250	GSE	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	IS250	GSE	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	IS250	GSE	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, SP0008	

JAP	IS250	GSE	All years	Smart Key	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0018, SP0201
JAP	IS250	GSE	All years	Remote Engine Starter	√	√	√	√		SP0046
JAP	IS250	GSE	All years	Starting Control	√	√	√	√	0256, 0257	
JAP	IS250	GSE	All years	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071
JAP	IS250	GSE	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	IS250	GSE	All years	Pre-Crash	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044



JAP	IS250C	GSE	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0084, 008 5, 0086, 0087 , 0088, 0089, 0090, 0091, 0 092, 0093, 00 94, 0095, 009 6, 0097, 0098 , 0099, 0100, 0101, 0102, 0 103, 0104, 01 05, 0106, 010 7, 0108, 0109 , 0110, 0111, 0112, 0113, 0 114, 0118, 01 22, 0124, 012 5, 0130, 0131 , 0135, 0137, 0138, 0142, 0 143, 0144, 01 45, 0146, 014 7, 0148, 0149 , 0150, 0151, 0152, 0154, 0 155, 0156, 01 59, 0160, 016 1, 0162, 0163 , 0164, 0165,	SP0003, SP0 004, SP0027 , SP0029, SP 0030, SP003 1, SP0032, S P0101, SP01 03, SP0104, SP0106, SP0 107, SP0108 , SP0109, SP 0110, SP011 1, SP0113, S P0198
-----	--------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	IS250C	GSE	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,	SP0003, SP0004, SP0030, SP0032, SP0101
JAP	IS250C	GSE	All years	Cruise Control	✓	✓	✓	✓		

JAP	IS250C	GSE	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	IS250C	GSE	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002, SP0004
JAP	IS250C	GSE	All years	EHPS	√	√	√	√		SP0001, SP0004, SP0009, SP0010
JAP	IS250C	GSE	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	√	√	√	√		

JAP	IS250C	GSE	All years	Air Conditioner	✓	✓	✓		0556, 0557, 0558, 0561, 0562, 0573, 0594, 0598, 0599, 0615, 1016, 1017, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1703, 1704, 1705, 1706, 1707, 1708, 1709, 1710, 1711, 1712, 1713, 1714	SP0017
JAP	IS250C	GSE	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0004
JAP	IS250C	GSE	All years	Body	✓	✓	✓		0319, 0331, 0333, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0805, 0806, 0809, 0815, 0816, 0912, 0913, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0926, 0927, 0928, 0929, 0934, 0969, 1648, 1665, 1666, 1682, 1688	SP0005
JAP	IS250C	GSE	All years	Gateway	✓	✓	✓			SP0005
JAP	IS250C	GSE	All years	Accessory Gateway	✓	✓	✓	✓		SP0005

JAP	IS250C	GSE	All years	Body No. 3	✓	✓	✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0917, 0918, 0931, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0952, 0953, 0955, 0956, 0957, 0958, 0959, 0961, 0962, 0967, 1678, 1679, 1680, 1681
JAP	IS250C	GSE	All years	Body No. 5			✓	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681, 1689
JAP	IS250C	GSE	All years	Driver Seat			✓	0422, 0423, 0424, 0515, 0516, 0517
JAP	IS250C	GSE	All years	Passenger Seat			✓	0422, 0423, 0424, 0515, 0516, 0517
JAP	IS250C	GSE	All years	Master Switch			✓	0939, 0940, 0941, 0942
JAP	IS250C	GSE	All years	P Master Switch			✓	0941
JAP	IS250C	GSE	All years	Hardtop Retractable	✓	✓	✓	0970
JAP	IS250C	GSE	All years	Tilt&Telescopic	✓	✓	✓	0472, 0473, 1005

JAP	IS250C	GSE	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0669, 0670, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044, 1045, 1046, 1048, 1049, 1050, 1051, 1052,	
JAP	IS250C	GSE	All years	Right Mirror			√		0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
JAP	IS250C	GSE	All years	Left Mirror			√		0279, 0280, 0281, 0282, 0283, 0971, 0973, 0975, 0976, 0977, 0978, 0979, 0980, 1686, 1687	
JAP	IS250C	GSE	All years	Combination Switch			√			
JAP	IS250C	GSE	All years	Intuitive Parking Assist	√	√	√		0023, 0024	SP0006
JAP	IS250C	GSE	All years	Rain Sensor			√			
JAP	IS250C	GSE	All years	AFS	√	√	√		0008, 0009, 0475, 1683, 1684, 1685	

JAP	IS250C	GSE	All years	Entry&Start	✓	✓	✓		0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0938	SP0011, SP0013, SP0014, SP0201
JAP	IS250C	GSE	All years	Power Source Control	✓	✓	✓		0300, 0301, 0818, 0936	
JAP	IS250C	GSE	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	IS250C	GSE	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
JAP	IS250C	GSE	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	IS300	ASE30	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	

JAP	IS300	ASE30	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
JAP	IS300	ASE30	All years	Stop&Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297
JAP	IS300	ASE30	All years	Radar Cruise	✓	✓	✓	✓	
JAP	IS300	ASE30	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646



JAP	IS300	ASE30	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	IS300	ASE30	All years	Tire Pressure Monitor	√	√	√			
JAP	IS300	ASE30	All years	EMPS	√	√	√	√		
JAP	IS300	ASE30	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
JAP	IS300	ASE30	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	IS300	ASE30	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	

JAP	IS300	ASE30	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
JAP	IS300	ASE30	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	
JAP	IS300	ASE30	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		
JAP	IS300	ASE30	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	

JAP	IS300	ASE30	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	IS300	ASE30	All years	Accessory Gateway	✓	✓	✓	✓		
JAP	IS300	ASE30	All years	Central Gateway	✓	✓	✓	✓		
JAP	IS300	ASE30	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	IS300	ASE30	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	IS300	ASE30	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	IS300	ASE30	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	IS300	ASE30	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	IS300	ASE30	All years	Master Switch	✓	✓	✓			
JAP	IS300	ASE30	All years	Sliding Roof	✓	✓	✓		0529	
JAP	IS300	ASE30	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	

JAP	IS300	ASE30	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	IS300	ASE30	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	IS300	ASE30	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	IS300	ASE30	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	

JAP	IS300	ASE30	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	IS300	ASE30	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	IS300	ASE30	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	IS300	ASE30	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	IS300	ASE30	All years	Remote Engine Starter	✓	✓	✓	✓		
JAP	IS300	ASE30	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
JAP	IS300	ASE30	All years	Navigation System	✓	✓	✓	✓		
JAP	IS300	ASE30	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
JAP	IS300	ASE30	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		



JAP	IS300h	AVE	All years	Air suspension	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	SP0001, SP0004, SP0007
JAP	IS300h	AVE	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	IS300h	AVE	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002, SP0004
JAP	IS300h	AVE	All years	EHPS	√	√	√	√		SP0001, SP0004, SP0009, SP0010

JAP	IS300h	AVE	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
JAP	IS300h	AVE	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	IS300h	AVE	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0004



JAP	IS300h	AVE	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018
JAP	IS300h	AVE	All years	Gateway	✓	✓	✓	✓		SP0005
JAP	IS300h	AVE	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
JAP	IS300h	AVE	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	IS300h	AVE	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	IS300h	AVE	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	IS300h	AVE	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	IS300h	AVE	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	IS300h	AVE	All years	Master Switch	✓	✓	✓			
JAP	IS300h	AVE	All years	Sliding Roof	✓	✓	✓		0529	
JAP	IS300h	AVE	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	

JAP	IS300h	AVE	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	IS300h	AVE	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	IS300h	AVE	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	IS300h	AVE	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
JAP	IS300h	AVE	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, SP0008	

JAP	IS300h	AVE	All years	Smart Key	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0018, SP0201
JAP	IS300h	AVE	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	SP0045
JAP	IS300h	AVE	All years	Remote Engine Starter	√	√	√	√		SP0046
JAP	IS300h	AVE	All years	Navigation System	√	√	√	√		SP0050
JAP	IS300h	AVE	All years	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071
JAP	IS300h	AVE	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	IS300h	AVE	All years	Notification System Of Vehicle Proximity	√	√	√		0044, 0045, 0046	
JAP	IS300h	AVE	All years	Radar Cruise	√	√	√	√		SP0061, SP0069
JAP	IS300h	AVE	All years	Pre-Crash	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
JAP	IS300h	AVE	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	IS300h	AVE	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	

JAP	IS300h	AVE	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	IS300h	AVE	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	IS300h	AVE	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	IS300h	AVE	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			√			
JAP	IS300h	AVE	All years	Central Gateway	√	√	√	√		

JAP	IS350	GSE	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0084, 008 5, 0086, 0087 , 0088, 0089, 0090, 0091, 0 092, 0093, 00 94, 0095, 009 6, 0097, 0098 , 0099, 0100, 0101, 0102, 0 103, 0104, 01 05, 0106, 010 7, 0108, 0109 , 0110, 0111, 0112, 0113, 0 114, 0118, 01 22, 0124, 012 5, 0130, 0131 , 0135, 0137, 0138, 0142, 0 143, 0144, 01 45, 0146, 014 7, 0148, 0149 , 0150, 0151, 0152, 0154, 0 155, 0156, 01 58, 0159, 016 0, 0161, 0162 , 0163, 0164,	SP0003, SP0 004, SP0027 , SP0029, SP 0030, SP003 1, SP0032, S P0101, SP01 03, SP0104, SP0106, SP0 107, SP0108 , SP0109, SP 0110, SP011 1, SP0113, S P0198
-----	-------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	IS350	GSE	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,	SP0003, SP0004, SP0030, SP0032, SP0101
JAP	IS350	GSE	All years	Cruise Control	✓	✓	✓	✓		

JAP	IS350	GSE	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	IS350	GSE	All years	4WD (CAN)	✓	✓	✓	✓	0819, 0820, 0821, 0822, 1669	SP0003, SP0052
JAP	IS350	GSE	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010

JAP	IS350	GSE	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0562, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0573, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0598, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1016, 1017, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1649, 1650, 1651, 1652, 1653, 1654, 1655,	SP0016, SP0017, SP0051
JAP	IS350	GSE	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0004
JAP	IS350	GSE	All years	Body	√	√	√		0319, 0331, 0333, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0805, 0806, 0809, 0815, 0816, 0912, 0913, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0926, 0927, 0928, 0929, 0934, 0969, 1648, 1665, 1666, 1682, 1688	SP0005



JAP	IS350	GSE	All years	Gateway	√	√	√	√		SP0005
JAP	IS350	GSE	All years	Body No. 3	√	√	√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0917, 0918, 0931, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0952, 0953, 0955, 0956, 0957, 0958, 0959, 0961, 0962, 0967, 1678, 1679, 1680, 1681	
JAP	IS350	GSE	All years	Body No. 5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681, 1689	
JAP	IS350	GSE	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	IS350	GSE	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	IS350	GSE	All years	Master Switch	√	√	√		0939, 0940, 0941, 0942	
JAP	IS350	GSE	All years	Sliding Roof	√	√	√		0529	
JAP	IS350	GSE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	

JAP	IS350	GSE	All years	Combination Meter	√	√	√	√	0274, 0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682,	
JAP	IS350	GSE	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980, 1612	
JAP	IS350	GSE	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0279, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 0971, 0973, 0975, 0976, 0977, 0978, 0979, 0980, 1612, 1686, 1687	
JAP	IS350	GSE	All years	Combination Switch			√			

JAP	IS350	GSE	All years	Intuitive Parking Assist	√	√	√	√	0023, 0024, 0025, 0026	SP0006
JAP	IS350	GSE	All years	Rain Sensor			√			
JAP	IS350	GSE	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493, 1683, 1684, 1685	
JAP	IS350	GSE	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0938, 1648	SP0011, SP0013, SP0014, SP0201
JAP	IS350	GSE	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 0818, 0936, 1614, 1615, 1616, 1617	SP0045
JAP	IS350	GSE	All years	Radar Cruise	√	√	√	√	0017, 0018	SP0061, SP0062, SP0069
JAP	IS350	GSE	All years	Pre-Collision	√	√	√	√	0347, 0348, 0349, 0350	SP0061
JAP	IS350	GSE	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	√	√	√	√		
JAP	IS350	GSE	All years	Accessory Gateway	√	√	√	√		SP0005
JAP	IS350	GSE	All years	Navigation System	√	√	√	√		SP0050

JAP	IS350	GSE	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0042, SP0043, SP0101, SP0103, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0118, SP0109, SP0111, SP0113, SP0118, SP0198
JAP	IS350	GSE	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	SP0001, SP0004, SP0007
JAP	IS350	GSE	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0004
JAP	IS350	GSE	All years	VGRS	✓	✓	✓	✓		SP0004, SP0037
JAP	IS350	GSE	All years	DRS	✓	✓	✓	✓		SP0004, SP0081, SP0082, SP0083

JAP	IS350	GSE	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087
JAP	IS350	GSE	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018
JAP	IS350	GSE	All years	Multi Bus Gateway	✓	✓	✓	✓		
JAP	IS350	GSE	All years	No. 1 Multi Bus Monitor	✓	✓	✓	✓		SP0005
JAP	IS350	GSE	All years	No. 2 Multi Bus Monitor	✓	✓	✓	✓		SP0005
JAP	IS350	GSE	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	IS350	GSE	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	IS350	GSE	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	IS350	GSE	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	IS350	GSE	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, SP0008	

JAP	IS350	GSE	All years	Smart Key	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0018, SP0201
JAP	IS350	GSE	All years	Remote Engine Starter	√	√	√	√		SP0046
JAP	IS350	GSE	All years	Starting Control	√	√	√	√	0256, 0257	
JAP	IS350	GSE	All years	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071
JAP	IS350	GSE	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	IS350	GSE	All years	Pre-Crash	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044
JAP	IS350	GSE	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	IS350	GSE	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	IS350	GSE	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			√			
JAP	IS350	GSE	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	

JAP	IS350	GSE	All years	Central Gateway	√	√	√	√		
JAP	IS350	GSE	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
JAP	IS350	GSE	All years	Transmission	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
JAP	IS350	GSE	All years	EMPS	√	√	√	√		

JAP	IS350C	GSE	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0084, 008 5, 0086, 0087 , 0088, 0089, 0090, 0091, 0 092, 0093, 00 94, 0095, 009 6, 0097, 0098 , 0099, 0100, 0101, 0102, 0 103, 0104, 01 05, 0106, 010 7, 0108, 0109 , 0110, 0111, 0112, 0113, 0 114, 0118, 01 22, 0124, 012 5, 0130, 0131 , 0135, 0137, 0138, 0142, 0 143, 0144, 01 45, 0146, 014 7, 0148, 0149 , 0150, 0151, 0152, 0154, 0 155, 0156, 01 59, 0160, 016 1, 0162, 0163 , 0164, 0165,	SP0003, SP0 004, SP0027 , SP0029, SP 0030, SP003 1, SP0032, S P0101, SP01 03, SP0104, SP0106, SP0 107, SP0108 , SP0109, SP 0110, SP011 1, SP0113, S P0198
-----	--------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



JAP	IS350C	GSE	All years	ECT	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0084, 008 5, 0086, 0087 , 0088, 0089, 0096, 0097, 0 100, 0101, 01 02, 0103, 010 4, 0105, 0106 , 0107, 0108, 0110, 0111, 0 112, 0113, 01 18, 0122, 012 4, 0125, 0149 , 0159, 0161, 0162, 0163, 0 164, 0165, 01 66, 0167, 016 8, 0170, 0171 , 0172, 0173, 0174, 0175, 0 179, 0180, 01 81, 0182, 018 3, 0184, 0185 , 0186, 0187, 0188, 0189, 0 190, 0191, 01 92, 0193, 019 4, 0195, 0196 , 0197, 0198,	SP0003, SP0 004, SP0030 , SP0032, SP 0101
JAP	IS350C	GSE	All years	Cruise Control	✓	✓	✓	✓		

JAP	IS350C	GSE	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	IS350C	GSE	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002, SP0004
JAP	IS350C	GSE	All years	EHPS	√	√	√	√		SP0001, SP0004, SP0009, SP0010
JAP	IS350C	GSE	All years	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0573, 0594, 0598, 0599, 0615, 1016, 1017, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1703, 1704, 1705, 1706, 1707, 1708, 1709, 1710, 1711, 1712, 1713, 1714	SP0017

JAP	IS350C	GSE	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0004
JAP	IS350C	GSE	All years	Body	√	√	√		0319, 0331, 0333, 0337, 0339, 0429, 0498, 0499, 0500, 0501, 0783, 0784, 0785, 0801, 0805, 0806, 0809, 0815, 0816, 0912, 0913, 0917, 0918, 0919, 0920, 0921, 0922, 0923, 0924, 0926, 0927, 0928, 0929, 0934, 0969, 1648, 1665, 1666, 1682, 1688	SP0005
JAP	IS350C	GSE	All years	Gateway	√	√	√			SP0005
JAP	IS350C	GSE	All years	Accessory Gateway	√	√	√	√		SP0005
JAP	IS350C	GSE	All years	Body No. 3	√	√	√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0917, 0918, 0931, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0952, 0953, 0955, 0956, 0957, 0958, 0959, 0961, 0962, 0967, 1678, 1679, 1680, 1681	

JAP	IS350C	GSE	All years	Body No.5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681, 1689	
JAP	IS350C	GSE	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	IS350C	GSE	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	IS350C	GSE	All years	Master Switch			√		0939, 0940, 0941, 0942	
JAP	IS350C	GSE	All years	P Master Switch			√		0941	
JAP	IS350C	GSE	All years	Hardtop Retractable	√	√	√		0970	
JAP	IS350C	GSE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	

JAP	IS350C	GSE	All years	Combination Meter			√	0274, 0616, 0617, 0618, 0619, 0629, 0669, 0670, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044, 1045, 1046, 1048, 1049, 1050, 1051, 1052,	
JAP	IS350C	GSE	All years	Right Mirror			√	0279, 0280, 0281, 0282, 0283, 0971, 0972, 0973, 0974, 0975, 0976, 0977, 0978, 0979, 0980	
JAP	IS350C	GSE	All years	Left Mirror			√	0279, 0280, 0281, 0282, 0283, 0971, 0973, 0975, 0976, 0977, 0978, 0979, 0980, 1686, 1687	
JAP	IS350C	GSE	All years	Combination Switch			√		
JAP	IS350C	GSE	All years	Intuitive Parking Assist	√	√	√	0023, 0024	SP0006
JAP	IS350C	GSE	All years	Rain Sensor			√		

JAP	IS350C	GSE	All years	Entry&Start	✓	✓	✓		0536, 0537, 0542, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 0938	SP0011, SP0013, SP0014, SP0201
JAP	IS350C	GSE	All years	Power Source Control	✓	✓	✓		0300, 0301, 0818, 0936	
JAP	IS350C	GSE	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	IS350C	GSE	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0062
JAP	IS350C	GSE	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	LC500	URZ	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	

JAP	LC500	URZ	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
JAP	LC500	URZ	All years	Radar Cruise 1	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
JAP	LC500	URZ	All years	Radar Cruise 2	✓	✓	✓	✓	
JAP	LC500	URZ	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646

JAP	LC500	URZ	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	LC500	URZ	All years	Tire Pressure Monitor	√	√	√			
JAP	LC500	URZ	All years	EHPS	√	√	√	√		
JAP	LC500	URZ	All years	VGRS	√	√	√	√		
JAP	LC500	URZ	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
JAP	LC500	URZ	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		



JAP	LC500	URZ	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
JAP	LC500	URZ	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
JAP	LC500	URZ	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
JAP	LC500	URZ	All years	DRS	✓	✓	✓	✓		
JAP	LC500	URZ	All years	Steering Angle Sensor	✓	✓	✓			
JAP	LC500	URZ	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	
JAP	LC500	URZ	All years	Theft Deterrent	✓	✓	✓		0333, 0498, 0499, 0501, 0502, 1647	

JAP	LC500	URZ	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
JAP	LC500	URZ	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	LC500	URZ	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	LC500	URZ	All years	Accessory Gateway	✓	✓	✓	✓		
JAP	LC500	URZ	All years	Central Gateway	✓	✓	✓	✓		
JAP	LC500	URZ	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	LC500	URZ	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	

JAP	LC500	URZ	All years	Driver Door Motor	√	√	√		0528	
JAP	LC500	URZ	All years	Passenger Door Motor	√	√	√		0528	
JAP	LC500	URZ	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	LC500	URZ	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	LC500	URZ	All years	Master Switch	√	√	√			
JAP	LC500	URZ	All years	Tilt&Telescopic	√	√	√		1513, 1514	
JAP	LC500	URZ	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	

JAP	LC500	URZ	All years	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
JAP	LC500	URZ	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
JAP	LC500	URZ	All years	Rain and/or Humidity Sensor	✓	✓	✓			
JAP	LC500	URZ	All years	Wiper	✓	✓	✓	✓	0031, 0032	
JAP	LC500	URZ	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	LC500	URZ	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	
JAP	LC500	URZ	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	LC500	URZ	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	LC500	URZ	All years	Remote Engine Starter	✓	✓	✓	✓		
JAP	LC500	URZ	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
JAP	LC500	URZ	All years	Navigation System	✓	✓	✓	✓		
JAP	LC500	URZ	All years	Active Rear Wing	✓	✓	✓		1189, 1190, 1191, 1192, 1193	
JAP	LC500	URZ	All years	Master Blind Spot Monitor	✓	✓	✓	✓		

JAP	LC500	URZ	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
JAP	LC500	URZ	All years	Active Noise Control	✓	✓	✓		1515, 1516, 1517, 1518, 1519	
JAP	LC500	URZ	All years	Pedestrian Protection	✓	✓	✓			
JAP	LC500	URZ	All years	Sub Battery Module	✓	✓	✓			
JAP	LC500	URZ	All years	Power Integration No. 1	✓	✓	✓			
JAP	LC500	URZ	All years	Power Integration No. 3	✓	✓	✓			
JAP	LC500	URZ	All years	Telematics	✓	✓	✓		1521, 1522	
JAP	LC500c	URZ100	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	

JAP	LC500c	URZ100	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
JAP	LC500c	URZ100	All years	Radar Cruise 1	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	LC500c	URZ100	All years	Radar Cruise 2	✓	✓	✓	✓		
JAP	LC500c	URZ100	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	

JAP	LC500c	URZ100	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	LC500c	URZ100	All years	Tire Pressure Monitor	✓	✓	✓			
JAP	LC500c	URZ100	All years	EHPS	✓	✓	✓	✓		
JAP	LC500c	URZ100	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
JAP	LC500c	URZ100	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		

JAP	LC500c	URZ100	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	LC500c	URZ100	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	LC500c	URZ100	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			√			
JAP	LC500c	URZ100	All years	Steering Angle Sensor	√	√	√			
JAP	LC500c	URZ100	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	



JAP	LC500c	URZ100	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
JAP	LC500c	URZ100	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	LC500c	URZ100	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	LC500c	URZ100	All years	Accessory Gateway	✓	✓	✓	✓		
JAP	LC500c	URZ100	All years	Central Gateway	✓	✓	✓	✓		
JAP	LC500c	URZ100	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	LC500c	URZ100	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	

JAP	LC500c	URZ10 0	All years	Driver Door Motor	√	√	√		0528	
JAP	LC500c	URZ10 0	All years	Passenger Door Motor	√	√	√		0528	
JAP	LC500c	URZ10 0	All years	Left Rear Door Motor	√	√	√		0528	
JAP	LC500c	URZ10 0	All years	Right Rear Door Motor	√	√	√		0528	
JAP	LC500c	URZ10 0	All years	Driver Seat	√	√	√	√	0026, 0421, 0 422, 0423, 04 24, 0513, 051 4, 0515, 0516 , 0517, 0518, 0519	
JAP	LC500c	URZ10 0	All years	Passenger Seat	√	√	√	√	0026, 0421, 0 422, 0423, 04 24, 0425, 051 3, 0514, 0515 , 0516, 0517, 0519	
JAP	LC500c	URZ10 0	All years	Master Switch	√	√	√			
JAP	LC500c	URZ10 0	All years	Sliding Roof	√	√	√			
JAP	LC500c	URZ10 0	All years	Tilt&Tele scopic	√	√	√		1513, 1514	

JAP	LC500c	URZ100	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	LC500c	URZ100	All years	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
JAP	LC500c	URZ100	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
JAP	LC500c	URZ100	All years	Rain and/or Humidity Sensor	✓	✓	✓			
JAP	LC500c	URZ100	All years	Wiper	✓	✓	✓	✓	0031, 0032	
JAP	LC500c	URZ100	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	LC500c	URZ100	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	

JAP	LC500c	URZ100	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	LC500c	URZ100	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	LC500c	URZ100	All years	Remote Engine Starter	√	√	√	√		
JAP	LC500c	URZ100	All years	Starting Control	√	√	√	√	0256, 0257	
JAP	LC500c	URZ100	All years	Navigation System	√	√	√	√		
JAP	LC500c	URZ100	All years	Master Blind Spot Monitor	√	√	√	√		
JAP	LC500c	URZ100	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	LC500c	URZ100	All years	Active Noise Control	√	√	√		1515, 1516, 1517, 1518, 1519	
JAP	LC500c	URZ100	All years	Pedestrian Protection	√	√	√			
JAP	LC500c	URZ100	All years	Sub Battery Module	√	√	√			
JAP	LC500c	URZ100	All years	Power Integration No.1	√	√	√			
JAP	LC500c	URZ100	All years	Power Integration No.3	√	√	√			
JAP	LC500c	URZ100	All years	Telematics	√	√	√		1521, 1522	

JAP	LC500h	GWZ100	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	
JAP	LC500h	GWZ100	All years	Hybrid Control	✓	✓	✓	✓		
JAP	LC500h	GWZ100	All years	Motor Generator	✓	✓	✓	✓		
JAP	LC500h	GWZ100	All years	HV battery	✓	✓	✓		1494, 1520	
JAP	LC500h	GWZ100	All years	Radar Cruise 1	✓	✓	✓			
JAP	LC500h	GWZ100	All years	Radar Cruise 2	✓	✓	✓	✓		

JAP	LC500h	GWZ100	All years	Air suspension	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	
JAP	LC500h	GWZ100	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	LC500h	GWZ100	All years	Tire Pressure Monitor	√	√	√			
JAP	LC500h	GWZ100	All years	EMPS	√	√	√	√		
JAP	LC500h	GWZ100	All years	VGRS	√	√	√	√		

JAP	LC500h	GWZ100	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
JAP	LC500h	GWZ100	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
JAP	LC500h	GWZ100	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	LC500h	GWZ100	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	LC500h	GWZ100	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
JAP	LC500h	GWZ100	All years	DRS	√	√	√	√		
JAP	LC500h	GWZ100	All years	Steering Angle Sensor	√	√	√			

JAP	LC500h	GWZ100	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661
JAP	LC500h	GWZ100	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓	
JAP	LC500h	GWZ100	All years	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298



JAP	LC500h	GWZ100	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668
JAP	LC500h	GWZ100	All years	Accessory Gateway	✓	✓	✓	✓	
JAP	LC500h	GWZ100	All years	Central Gateway	✓	✓	✓	✓	
JAP	LC500h	GWZ100	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	LC500h	GWZ100	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	LC500h	GWZ100	All years	Driver Door Motor	✓	✓	✓		0528
JAP	LC500h	GWZ100	All years	Passenger Door Motor	✓	✓	✓		0528
JAP	LC500h	GWZ100	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519

JAP	LC500h	GWZ100	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	LC500h	GWZ100	All years	Master Switch	✓	✓	✓			
JAP	LC500h	GWZ100	All years	Tilt&Telescopic	✓	✓	✓		1513, 1514	
JAP	LC500h	GWZ100	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	LC500h	GWZ100	All years	Head Up Display	✓	✓	✓		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
JAP	LC500h	GWZ100	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
JAP	LC500h	GWZ100	All years	Rain and/or Humidity Sensor	✓	✓	✓			
JAP	LC500h	GWZ100	All years	Wiper	✓	✓	✓	✓	0031, 0032	

JAP	LC500h	GWZ100	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
JAP	LC500h	GWZ100	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028
JAP	LC500h	GWZ100	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015
JAP	LC500h	GWZ100	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006
JAP	LC500h	GWZ100	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648
JAP	LC500h	GWZ100	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617
JAP	LC500h	GWZ100	All years	Remote Engine Starter	✓	✓	✓	✓	
JAP	LC500h	GWZ100	All years	Navigation System	✓	✓	✓	✓	
JAP	LC500h	GWZ100	All years	Active Rear Wing	✓	✓	✓		1189, 1190, 1191, 1192, 1193

JAP	LC500h	GWZ100	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
JAP	LC500h	GWZ100	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
JAP	LC500h	GWZ100	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
JAP	LC500h	GWZ100	All years	Active Noise Control	✓	✓	✓		1515, 1516, 1517, 1518, 1519	
JAP	LC500h	GWZ100	All years	Pedestrian Protection	✓	✓	✓			
JAP	LC500h	GWZ100	All years	Sub Battery Module	✓	✓	✓			
JAP	LC500h	GWZ100	All years	Power Integration No. 1	✓	✓	✓			SP0191
JAP	LC500h	GWZ100	All years	Power Integration No. 2	✓	✓	✓			SP0191
JAP	LC500h	GWZ100	All years	Power Integration No. 3	✓	✓	✓			SP0191
JAP	LC500h	GWZ100	All years	Vehicle proximity notification system	✓	✓	✓		0044, 0045, 1766, 1767, 1768, 1769, 1770, 1771	
JAP	LC500h	GWZ100	All years	Telematics	✓	✓	✓		1521, 1522	

JAP	LFA	LFA	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0042, SP0043, SP0101, SP0103, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0106, SP0107, SP0108, SP0109, SP0111, SP0113, SP0198
-----	-----	-----	-----------	----------------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	LFA	LFA	All years	Engine2	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181,	SP0004, SP0141
JAP	LFA	LFA	All years	ASG	✓	✓	✓	✓	1184, 1185, 1186, 1187, 1188	SP0135

JAP	LFA	LFA	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	LFA	LFA	All years	EHPS	√	√	√	√		SP0001, SP0004, SP0009, SP0010
JAP	LFA	LFA	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004

JAP	LFA	LFA	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	LFA	LFA	All years	Immobiliser	✓	✓	✓		0501	SP0066
JAP	LFA	LFA	All years	Security	✓	✓	✓		0333, 0498, 0499, 0501, 0502, 1647	
JAP	LFA	LFA	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0004



JAP	LFA	LFA	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018, SP0019, SP0020
JAP	LFA	LFA	All years	Gateway	✓	✓	✓	✓		SP0005
JAP	LFA	LFA	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	LFA	LFA	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	LFA	LFA	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	LFA	LFA	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	

JAP	LFA	LFA	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	LFA	LFA	All years	Electric Power Control	✓	✓	✓	✓	0342, 0343, 0344, 0345, 0346	
JAP	LFA	LFA	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	LFA	LFA	All years	Active Rear Wing	✓	✓	✓		1189, 1190, 1191, 1192, 1193	SP0136

JAP	LS460	USF	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0084, 008 5, 0086, 0087 , 0088, 0089, 0090, 0091, 0 092, 0093, 00 94, 0095, 009 6, 0097, 0098 , 0099, 0100, 0101, 0102, 0 103, 0104, 01 05, 0106, 010 7, 0108, 0109 , 0110, 0111, 0112, 0113, 0 114, 0118, 01 22, 0124, 012 5, 0130, 0131 , 0135, 0137, 0138, 0142, 0 143, 0144, 01 45, 0146, 014 7, 0148, 0149 , 0150, 0151, 0152, 0154, 0 155, 0156, 01 59, 0160, 016 1, 0162, 0163 , 0164, 0165,	SP0003, SP0 004, SP0027 , SP0029, SP 0030, SP003 1, SP0032, S P0101, SP01 03, SP0104, SP0106, SP0 107, SP0108 , SP0109, SP 0110, SP011 1, SP0113, S P0198
-----	-------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	LS460	USF	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,	SP0003, SP0004, SP0030, SP0032, SP0101
JAP	LS460	USF	All years	Cruise Control	✓	✓	✓	✓		
JAP	LS460	USF	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	SP0001, SP0004, SP0007

JAP	LS460	USF	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	LS460	USF	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	LS460	USF	All years	VGRS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0037
JAP	LS460	USF	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
JAP	LS460	USF	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	✓	✓	✓	✓		

JAP	LS460	USF	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	LS460	USF	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0004
JAP	LS460	USF	All years	Active Headrest Right	√	√	√		0306, 0307, 0308, 0309	
JAP	LS460	USF	All years	Active Headrest Left	√	√	√		0306, 0307, 0308, 0309	

JAP	LS460	USF	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018, SP0019, SP0020
JAP	LS460	USF	All years	Engine Control Module (ECM) Gateway	✓	✓	✓	✓		SP0005
JAP	LS460	USF	All years	Electronic Controlled Braking (ECB) Gateway	✓	✓	✓	✓		SP0005
JAP	LS460	USF	All years	Whiplash Injury Lessening (WIL) Gateway	✓	✓	✓	✓		SP0005
JAP	LS460	USF	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
JAP	LS460	USF	All years	Body No. 4	✓	✓	✓		0310, 0311, 0312, 0313, 0314, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0327, 0328, 0329, 1618, 1619	

JAP	LS460	USF	All years	Body No. 5	✓	✓	✓		0031, 0032, 0330, 0331, 0332, 0333, 0334, 0335, 0336, 0337, 0338, 0339, 0340, 0341	
JAP	LS460	USF	All years	Driver Door	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0433, 0434, 0435, 0436, 0437	
JAP	LS460	USF	All years	Passenger Door	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0430, 0431	
JAP	LS460	USF	All years	Left Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
JAP	LS460	USF	All years	Right Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
JAP	LS460	USF	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	LS460	USF	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	LS460	USF	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	LS460	USF	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	LS460	USF	All years	Right Rear Door Motor	✓	✓	✓		0528	



JAP	LS460	USF	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	LS460	USF	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	LS460	USF	All years	Left Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
JAP	LS460	USF	All years	Right Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
JAP	LS460	USF	All years	Master Switch	✓	✓	✓			
JAP	LS460	USF	All years	Driver Seat Switch			✓			
JAP	LS460	USF	All years	Switch Of Center Console			✓		0355, 0356, 0357	
JAP	LS460	USF	All years	Rear Console Switch	✓	✓	✓		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
JAP	LS460	USF	All years	Left Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354	
JAP	LS460	USF	All years	Right Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354	
JAP	LS460	USF	All years	Left Rear Seat Air Conditioner (A/C)	✓	✓	✓		0351, 0352, 0353, 0354	
JAP	LS460	USF	All years	Right Rear Seat Air Conditioner (A/C)	✓	✓	✓		0351, 0352, 0353, 0354	
JAP	LS460	USF	All years	Sliding Roof	✓	✓	✓		0529	
JAP	LS460	USF	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	

JAP	LS460	USF	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	LS460	USF	All years	Combination Switch			✓			
JAP	LS460	USF	All years	Switch Of Steering Pad			✓			
JAP	LS460	USF	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
JAP	LS460	USF	All years	Rain Sensor	✓	✓	✓			
JAP	LS460	USF	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	SP0008, SP0166

JAP	LS460	USF	All years	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0201
JAP	LS460	USF	All years	Remote Security	✓	✓	✓		1772	
JAP	LS460	USF	All years	Electric Power Control	✓	✓	✓	✓	0342, 0343, 0344, 0345, 0346	
JAP	LS460	USF	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	LS460	USF	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	SP0061, SP0069
JAP	LS460	USF	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038
JAP	LS460	USF	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	LS460	USF	All years	Pre-Crash	✓	✓	✓	✓	0022	SP0005, SP0038, SP0039, SP0040, SP0041
JAP	LS460	USF	All years	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274, 1607, 1608, 1609, 1610, 1611	SP0067, SP0068
JAP	LS460	USF	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0004
JAP	LS460	USF	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071, SP0177, SP0178
JAP	LS460	USF	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		SP0180, SP0181
JAP	LS460	USF	All years	Mirror	✓	✓	✓		0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0433, 0434, 0435, 0436, 0437	

JAP	LS500	VXFA5 #	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,
-----	-------	------------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	LS500	VXFA5 #	All years	Transmiss ion	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0168 , 0180, 0182, 0185, 0187, 0 188, 0190, 01 91, 0192, 019 3, 0194, 0195 , 0204, 0206, 0211, 0236, 0 237, 0249, 02 50, 0254, 025 8, 0262, 1194 , 1195, 1196, 1197, 1198, 1 199, 1200, 12 01, 1202, 120 3, 1204, 1205 , 1206, 1207, 1208, 1209, 1 210, 1211, 12 12, 1213, 121 4, 1215, 1216 , 1217, 1218, 1219, 1220, 1 221, 1222, 12 23, 1224, 122 5, 1226, 1227 , 1228, 1229,	
JAP	LS500	VXFA5 #	All years	Stop and Start	✓	✓	✓		1480, 1481, 1 482, 1483, 14 84, 1485, 148 6, 1487, 1488 , 1489, 1490, 1491, 1492	SP0035
JAP	LS500	VXFA5 #	All years	Radar Cruise 1	✓	✓	✓	✓		
JAP	LS500	VXFA5 #	All years	Radar Cruise 2	✓	✓	✓	✓	1504, 1505	

JAP	LS500	VXFA5#	All years	Adaptive Variable Suspension (AVS) System	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	
JAP	LS500	VXFA5#	All years	Air suspension	√	√	√		SP0130, SP0131, SP0132, SP0133	
JAP	LS500	VXFA5#	All years	Front Stabilizer	√	√	√	0527		
JAP	LS500	VXFA5#	All years	Rear Stabilizer	√	√	√	0527		
JAP	LS500	VXFA5#	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	

JAP	LS500	VXFA5 #	All years	Tire Pressure Monitor	✓	✓	✓		
JAP	LS500	VXFA5 #	All years	EMPS	✓	✓	✓	✓	
JAP	LS500	VXFA5 #	All years	VGRS	✓	✓	✓	✓	
JAP	LS500	VXFA5 #	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397
JAP	LS500	VXFA5 #	All years	Front Recogniti on Camera	✓	✓	✓	✓	0052 SP0086, SP0087, SP0126, SP0182, SP0183, SP0204
JAP	LS500	VXFA5 #	All years	Panoramic View Monitor	✓	✓	✓	✓	
JAP	LS500	VXFA5 #	All years	DRS	✓	✓	✓	✓	
JAP	LS500	VXFA5 #	All years	Lane Control	✓	✓	✓		0824, 0989
JAP	LS500	VXFA5 #	All years	Steering Angle Sensor	✓	✓	✓		
JAP	LS500	VXFA5 #	All years	Parking Assist Camera	✓	✓	✓	✓	

JAP	LS500	VXFA5 #	All years	Air Condition er	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	
JAP	LS500	VXFA5 #	All years	Supplemen t Restraint System (SRS) Airbag	√	√	√	√		
JAP	LS500	VXFA5 #	All years	Driving Support System	√	√	√			
JAP	LS500	VXFA5 #	All years	Seat Belt Control	√	√	√			
JAP	LS500	VXFA5 #	All years	Pre- Collision System	√	√	√		1524, 1525, 1526	



JAP	LS500	VXFA5 #	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0 300, 0301, 03 17, 0319, 033 3, 0335, 0337 , 0339, 0426, 0427, 0429, 0 433, 0434, 04 35, 0436, 049 0, 0496, 0497 , 0498, 0499, 0500, 0501, 0 502, 0783, 07 84, 0785, 078 6, 0787, 0788 , 0789, 0790, 0791, 0792, 0 793, 0796, 07 97, 0798, 079 9, 0800, 0801 , 0803, 0804, 0805, 0806, 0 807, 0808, 08 09, 0810, 081 1, 0812, 0813 , 0815, 0816, 0817, 0818, 1 665, 1666, 16 67, 1668	
JAP	LS500	VXFA5 #	All years	Accessory Gateway	✓	✓	✓	✓		
JAP	LS500	VXFA5 #	All years	Central Gateway	✓	✓	✓	✓		
JAP	LS500	VXFA5 #	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0 277, 0278, 02 80, 0281, 028 2, 0283, 0284 , 0426, 0427, 1612	
JAP	LS500	VXFA5 #	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0 277, 0278, 02 80, 0281, 028 2, 0283, 0284 , 0426, 0427, 1612	
JAP	LS500	VXFA5 #	All years	Left Rear Door	✓	✓	✓	✓	0278, 0284, 0 317, 0428, 04 29, 0437, 050 3, 0504, 0505 , 0506, 0507, 0508, 0509, 0 510, 0511, 05 12	

JAP	LS500	VXFA5 #	All years	Right Rear Door	✓	✓	✓	✓	0278, 0284, 0 317, 0428, 04 29, 0437, 050 3, 0504, 0505 , 0506, 0507, 0508, 0509, 0 510, 0511, 05 12	
JAP	LS500	VXFA5 #	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0 522, 0523, 05 24, 0525, 052 6	
JAP	LS500	VXFA5 #	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	LS500	VXFA5 #	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	LS500	VXFA5 #	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	LS500	VXFA5 #	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	LS500	VXFA5 #	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0 422, 0423, 04 24, 0513, 051 4, 0515, 0516 , 0517, 0518, 0519	
JAP	LS500	VXFA5 #	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0 422, 0423, 04 24, 0425, 051 3, 0514, 0515 , 0516, 0517, 0519	
JAP	LS500	VXFA5 #	All years	Left Rear Seat	✓	✓	✓		0026, 0421, 0 422, 0423, 04 24, 0425	
JAP	LS500	VXFA5 #	All years	Right Rear Seat	✓	✓	✓		0026, 0421, 0 422, 0423, 04 24, 0425	
JAP	LS500	VXFA5 #	All years	Master Switch	✓	✓	✓			
JAP	LS500	VXFA5 #	All years	Rear Console Switch	✓	✓	✓		0355, 0358, 0 359, 0360, 03 61, 0362, 036 3, 0364, 0365 , 0366, 0367, 0368, 0369, 0 370, 0371, 03 72, 0373, 037 4, 0375	
JAP	LS500	VXFA5 #	All years	Sliding Roof	✓	✓	✓		0529	

JAP	LS500	VXFA5 #	All years	Tilt&Tele scopic	√	√	√		1513, 1514	
JAP	LS500	VXFA5 #	All years	Combinati on Meter	√	√	√		0274, 0398, 0 475, 0488, 06 20, 0624, 062 6, 0627, 0638 , 0648, 0650, 0651, 0652, 0 656, 0657, 06 59, 0660, 067 0, 0671, 0675 , 0676, 0684, 0686, 0690, 0 693, 0701, 07 02, 0704, 071 0, 0723, 0724 , 0728, 0729, 0730, 0731, 0 732, 0734, 07 35, 0736, 073 7, 0752, 0753 , 1233, 1234, 1235, 1236, 1 237, 1238, 12 39, 1240, 124 1, 1242, 1243 , 1244, 1245, 1246, 1247, 1 248, 1249, 12 50, 1251, 125 2, 1253, 1254 , 1255, 1256,	
JAP	LS500	VXFA5 #	All years	Head Up Display	√	√	√		0049, 0050, 1 506, 1507, 15 08, 1509, 151 0, 1511, 1512	
JAP	LS500	VXFA5 #	All years	Road Sign Assist	√	√	√			
JAP	LS500	VXFA5 #	All years	Intellige nt Parking Assist (IPA)/Int elligent Clearance Sonar (ICS)/Cle arance Sonar	√	√	√	√	0023, 0024, 0 025, 0026	
JAP	LS500	VXFA5 #	All years	Rain and/or Humidity Sensor	√	√	√			
JAP	LS500	VXFA5 #	All years	Wiper	√	√	√	√	0031, 0032	

JAP	LS500	VXFA5 #	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	LS500	VXFA5 #	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028	
JAP	LS500	VXFA5 #	All years	Front Recogniti on Camera (Front Lighting Control)	✓	✓	✓			
JAP	LS500	VXFA5 #	All years	Entry&Sta rt	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	LS500	VXFA5 #	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	LS500	VXFA5 #	All years	Remote Engine Starter	✓	✓	✓	✓		
JAP	LS500	VXFA5 #	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
JAP	LS500	VXFA5 #	All years	Navigatio n System	✓	✓	✓	✓		
JAP	LS500	VXFA5 #	All years	Front Radar Sensor	✓	✓	✓			SP0127, SP0128, SP0129
JAP	LS500	VXFA5 #	All years	Front Side Radar Master	✓	✓	✓			SP0120, SP0121, SP0122

JAP	LS500	VXFA5 #	All years	Front Side Radar Slave	√	√	√			SP0123, SP0 124, SP0125
JAP	LS500	VXFA5 #	All years	Master Blind Spot Monitor	√	√	√	√		
JAP	LS500	VXFA5 #	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	LS500	VXFA5 #	All years	Active Noise Control	√	√	√		1515, 1516, 1 517, 1518, 15 19	
JAP	LS500	VXFA5 #	All years	Connectio n Of ITS	√	√	√	√		
JAP	LS500	VXFA5 #	All years	Pedestria n Protectio n	√	√	√			
JAP	LS500	VXFA5 #	All years	Sub Battery Module	√	√	√			
JAP	LS500	VXFA5 #	All years	Power Integrati on No. 1	√	√	√			
JAP	LS500	VXFA5 #	All years	Power Integrati on No. 2	√	√	√			
JAP	LS500	VXFA5 #	All years	Power Integrati on No. 3	√	√	√			
JAP	LS500	VXFA5 #	All years	Lane- Keeping Assist (LKA)/Lan e Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	LS500	VXFA5 #	All years	Lane- Keeping Assist (LKA)/Lan e Departure Alert (LDA) (Sub)			√			
JAP	LS500	VXFA5 #	All years	Pre- Collision 2	√	√	√	√	0016, 0017, 0 018, 0020, 00 21, 0022, 029 8	

JAP	LS500	VXFA5#	All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	LS500	VXFA5#	All years	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0006	
JAP	LS500	VXFA5#	All years	Brake/EPB	√	√	√		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
JAP	LS500h	GVF5#	All years	Engine	√	√	√	√	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	
JAP	LS500h	GVF5#	All years	Hybrid Control	√	√	√	√		
JAP	LS500h	GVF5#	All years	Motor Generator	√	√	√	√		
JAP	LS500h	GVF5#	All years	HV battery	√	√	√		1494, 1520	SP0004
JAP	LS500h	GVF5#	All years	Radar Cruise 1	√	√	√			
JAP	LS500h	GVF5#	All years	Radar Cruise 2	√	√	√	√	1504, 1505	

JAP	LS500h	GVF5#	All years	Adaptive Variable Suspension (AVS) System	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	
JAP	LS500h	GVF5#	All years	Air suspension	√	√	√			SP0007
JAP	LS500h	GVF5#	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	LS500h	GVF5#	All years	Tire Pressure Monitor	√	√	√			
JAP	LS500h	GVF5#	All years	EMPS	√	√	√	√		

JAP	LS500h	GVF5#	All years	VGRS	✓	✓	✓	✓		
JAP	LS500h	GVF5#	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
JAP	LS500h	GVF5#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
JAP	LS500h	GVF5#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
JAP	LS500h	GVF5#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
JAP	LS500h	GVF5#	All years	Panoramic View Monitor	✓	✓	✓	✓		
JAP	LS500h	GVF5#	All years	DRS	✓	✓	✓	✓		
JAP	LS500h	GVF5#	All years	Steering Angle Sensor	✓	✓	✓			
JAP	LS500h	GVF5#	All years	Parking Assist Camera	✓	✓	✓	✓		



JAP	LS500h	GVF5#	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661
JAP	LS500h	GVF5#	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√	
JAP	LS500h	GVF5#	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298

JAP	LS500h	GVF5#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668
JAP	LS500h	GVF5#	All years	Accessory Gateway	✓	✓	✓	✓	
JAP	LS500h	GVF5#	All years	Central Gateway	✓	✓	✓	✓	
JAP	LS500h	GVF5#	All years	Right Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	LS500h	GVF5#	All years	Left Front Door	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	LS500h	GVF5#	All years	Left Rear Door	✓	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512

JAP	LS500h	GVF5#	All years	Right Rear Door	√	√	√	√	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512	
JAP	LS500h	GVF5#	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	LS500h	GVF5#	All years	Driver Door Motor	√	√	√		0528	
JAP	LS500h	GVF5#	All years	Passenger Door Motor	√	√	√		0528	
JAP	LS500h	GVF5#	All years	Left Rear Door Motor	√	√	√		0528	
JAP	LS500h	GVF5#	All years	Right Rear Door Motor	√	√	√		0528	
JAP	LS500h	GVF5#	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	LS500h	GVF5#	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	LS500h	GVF5#	All years	Left Rear Seat	√	√	√		0026, 0421, 0422, 0423, 0424, 0425	
JAP	LS500h	GVF5#	All years	Right Rear Seat	√	√	√		0026, 0421, 0422, 0423, 0424, 0425	
JAP	LS500h	GVF5#	All years	Master Switch	√	√	√			
JAP	LS500h	GVF5#	All years	Rear Console Switch	√	√	√		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
JAP	LS500h	GVF5#	All years	Sliding Roof	√	√	√		0529	

JAP	LS500h	GVF5#	All years	Tilt&Tele scopic	√	√	√		1513, 1514	
JAP	LS500h	GVF5#	All years	Combinati on Meter	√	√	√		0274, 0398, 0 475, 0488, 06 20, 0624, 062 6, 0627, 0638 , 0648, 0650, 0651, 0652, 0 656, 0657, 06 59, 0660, 067 0, 0671, 0675 , 0676, 0684, 0686, 0690, 0 693, 0701, 07 02, 0704, 071 0, 0723, 0724 , 0728, 0729, 0730, 0731, 0 732, 0734, 07 35, 0736, 073 7, 0752, 0753 , 1233, 1234, 1235, 1236, 1 237, 1238, 12 39, 1240, 124 1, 1242, 1243 , 1244, 1245, 1246, 1247, 1 248, 1249, 12 50, 1251, 125 2, 1253, 1254 , 1255, 1256,	
JAP	LS500h	GVF5#	All years	Head Up Display	√	√	√		0049, 0050, 1 506, 1507, 15 08, 1509, 151 0, 1511, 1512	
JAP	LS500h	GVF5#	All years	Intellige nt Parking Assist (IPA)/Int elligent Clearance Sonar (ICS)/Cle arance Sonar	√	√	√	√	0023, 0024, 0 025, 0026	
JAP	LS500h	GVF5#	All years	Rain and/or Humidity Sensor	√	√	√			
JAP	LS500h	GVF5#	All years	Wiper	√	√	√	√	0031, 0032	

JAP	LS500h	GVF5#	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
JAP	LS500h	GVF5#	All years	Adaptive Front Lighting System (AFS) (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0028
JAP	LS500h	GVF5#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648
JAP	LS500h	GVF5#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617
JAP	LS500h	GVF5#	All years	Remote Engine Starter	✓	✓	✓	✓	
JAP	LS500h	GVF5#	All years	Navigation System	✓	✓	✓	✓	
JAP	LS500h	GVF5#	All years	Master Blind Spot Monitor	✓	✓	✓	✓	
JAP	LS500h	GVF5#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓	
JAP	LS500h	GVF5#	All years	Grill Shutter	✓	✓	✓		0037, 0038, 0039, 0040
JAP	LS500h	GVF5#	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046

JAP	LS500h	GVF5#	All years	Active Noise Control	√	√	√		1515, 1516, 1517, 1518, 1519	
JAP	LS500h	GVF5#	All years	Connection Of ITS	√	√	√	√		
JAP	LS500h	GVF5#	All years	Pedestrian Protection	√	√	√			
JAP	LS500h	GVF5#	All years	Sub Battery Module	√	√	√			
JAP	LS500h	GVF5#	All years	Power Integration No. 1	√	√	√			
JAP	LS500h	GVF5#	All years	Power Integration No. 2	√	√	√			
JAP	LS500h	GVF5#	All years	Power Integration No. 3	√	√	√			
JAP	LS500h	GVF5#	All years	Lane Control	√	√	√		0824, 0989	
JAP	LS500h	GVF5#	All years	Driving Support System	√	√	√			
JAP	LS500h	GVF5#	All years	Seat Belt Control	√	√	√			
JAP	LS500h	GVF5#	All years	Pre-Collision System	√	√	√		1524, 1525, 1526	
JAP	LS500h	GVF5#	All years	Road Sign Assist	√	√	√			
JAP	LS500h	GVF5#	All years	Front Recognition Camera (Front Lighting Control)	√	√	√			
JAP	LS500h	GVF5#	All years	Front Radar Sensor	√	√	√			
JAP	LS500h	GVF5#	All years	Front Side Radar Master	√	√	√			
JAP	LS500h	GVF5#	All years	Front Side Radar Slave	√	√	√			
JAP	LS500h	GVF5#	All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	

JAP	LS500h	GVF5#	All years	Auto Leveling Of Headlamp (Sub)	✓	✓	✓		0001, 0002, 0003, 0004, 0005, 0006	
JAP	LS600h	UVF	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0101, SP0103, SP0104, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0198
JAP	LS600h	UVF	All years	HV	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117, 1577, 1578	SP0003, SP0004, SP0005, SP0024, SP0025
JAP	LS600h	UVF	All years	Cruise Control	✓	✓	✓	✓		

JAP	LS600h	UVF	All years	Air suspension	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	SP0001, SP0004, SP0007
JAP	LS600h	UVF	All years	Front Stabilizer	√	√	√		0527	SP0151, SP0152
JAP	LS600h	UVF	All years	Rear Stabilizer	√	√	√		0527	SP0151, SP0152
JAP	LS600h	UVF	All years	Antilock Brake System (ABS) - Vehicle Stability Control (VSC) - Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	LS600h	UVF	All years	EHPS	√	√	√	√		SP0001, SP0004, SP0009, SP0010



JAP	LS600h	UVF	All years	VGRS	√	√	√	√		SP0001, SP0004, SP0009, SP0037
JAP	LS600h	UVF	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	SP0003, SP0004
JAP	LS600h	UVF	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	√	√	√	√		
JAP	LS600h	UVF	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	LS600h	UVF	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		SP0004

JAP	LS600h	UVF	All years	Active Headrest Right	√	√	√		0306, 0307, 0308, 0309	
JAP	LS600h	UVF	All years	Active Headrest Left	√	√	√		0306, 0307, 0308, 0309	
JAP	LS600h	UVF	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018, SP0019, SP0020
JAP	LS600h	UVF	All years	Engine Control Module (ECM) Gateway	√	√	√	√		SP0005
JAP	LS600h	UVF	All years	Electronic Controlled Braking (ECB) Gateway	√	√	√	√		SP0005
JAP	LS600h	UVF	All years	Whiplash Injury Lessening (WIL) Gateway	√	√	√	√		SP0005
JAP	LS600h	UVF	All years	Accessory Gateway	√	√	√	√		SP0005

JAP	LS600h	UVF	All years	Body No. 4	✓	✓	✓	0310, 0311, 0312, 0313, 0314, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0327, 0328, 0329, 1618, 1619
JAP	LS600h	UVF	All years	Body No. 5	✓	✓	✓	0031, 0032, 0330, 0331, 0332, 0333, 0334, 0335, 0336, 0337, 0338, 0339, 0340, 0341
JAP	LS600h	UVF	All years	Driver Door	✓	✓	✓	0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0433, 0434, 0435, 0436, 0437
JAP	LS600h	UVF	All years	Passenger Door	✓	✓	✓	0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0430, 0431
JAP	LS600h	UVF	All years	Left Rear Door	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512
JAP	LS600h	UVF	All years	Right Rear Door	✓	✓	✓	0278, 0284, 0317, 0428, 0429, 0437, 0503, 0504, 0505, 0506, 0507, 0508, 0509, 0510, 0511, 0512
JAP	LS600h	UVF	All years	Back Door	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526
JAP	LS600h	UVF	All years	Driver Door Motor	✓	✓	✓	0528
JAP	LS600h	UVF	All years	Passenger Door Motor	✓	✓	✓	0528

JAP	LS600h	UVF	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	LS600h	UVF	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	LS600h	UVF	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	LS600h	UVF	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	LS600h	UVF	All years	Left Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
JAP	LS600h	UVF	All years	Right Rear Seat	✓	✓	✓		0026, 0421, 0422, 0423, 0424, 0425	
JAP	LS600h	UVF	All years	Master Switch	✓	✓	✓			
JAP	LS600h	UVF	All years	Driver Seat Switch			✓			
JAP	LS600h	UVF	All years	Switch Of Center Console			✓		0355, 0356, 0357	
JAP	LS600h	UVF	All years	Rear Console Switch	✓	✓	✓		0355, 0358, 0359, 0360, 0361, 0362, 0363, 0364, 0365, 0366, 0367, 0368, 0369, 0370, 0371, 0372, 0373, 0374, 0375	
JAP	LS600h	UVF	All years	Left Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354	
JAP	LS600h	UVF	All years	Right Front Seat A/C	✓	✓	✓		0351, 0352, 0353, 0354	
JAP	LS600h	UVF	All years	Left Rear Seat Air Conditioner (A/C)	✓	✓	✓		0351, 0352, 0353, 0354	
JAP	LS600h	UVF	All years	Right Rear Seat Air Conditioner (A/C)	✓	✓	✓		0351, 0352, 0353, 0354	

JAP	LS600h	UVF	All years	Sliding Roof	✓	✓	✓		0529	
JAP	LS600h	UVF	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	
JAP	LS600h	UVF	All years	Combinati on Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	LS600h	UVF	All years	Combinati on Switch			✓			
JAP	LS600h	UVF	All years	Switch Of Steering Pad			✓			
JAP	LS600h	UVF	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
JAP	LS600h	UVF	All years	Rain Sensor	✓	✓	✓			
JAP	LS600h	UVF	All years	AFS	✓	✓	✓	✓	0007, SP0008	

JAP	LS600h	UVF	All years	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0201
JAP	LS600h	UVF	All years	Remote Security	✓	✓	✓		1772	
JAP	LS600h	UVF	All years	Night View	✓	✓	✓	✓	0271, 0272, 0273, 0274, 1607, 1608, 1609, 1610, 1611	SP0067, SP0068
JAP	LS600h	UVF	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	LS600h	UVF	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	SP0061, SP0069
JAP	LS600h	UVF	All years	Lane Keeping Assist (LKA)	✓	✓	✓	✓		SP0038
JAP	LS600h	UVF	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	LS600h	UVF	All years	Pre-Crash	✓	✓	✓	✓	0022	SP0005, SP0038, SP0039, SP0040, SP0041
JAP	LS600h	UVF	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0004
JAP	LS600h	UVF	All years	Master Blind Spot Monitor	✓	✓	✓	✓		SP0070, SP0071
JAP	LS600h	UVF	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
JAP	LS600h	UVF	All years	Cruise Control (Internal Controller Area Network HV)	✓	✓	✓	✓		

JAP	LS600h	UVF	All years	Mirror	√	√	√	0278, 0280, 0281, 0282, 0283, 0317, 0426, 0427, 0428, 0429, 0433, 0434, 0435, 0436, 0437
JAP	LX570	URJ	All years	Engine	√	√	√	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,

JAP	LX570	URJ	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,	
JAP	LX570	URJ	All years	Radar Cruise 1	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	LX570	URJ	All years	Radar Cruise 2	✓	✓	✓	✓		
JAP	LX570	URJ	All years	4-Wheel Drive (4WD)	✓	✓	✓			



JAP	LX570	URJ	All years	Air suspension	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	
JAP	LX570	URJ	All years	ABS-VSC-TRC (TRAC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	LX570	URJ	All years	Tire Pressure Monitor	√	√	√			
JAP	LX570	URJ	All years	PPS	√	√	√	√		
JAP	LX570	URJ	All years	VGRS	√	√	√	√		

JAP	LX570	URJ	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
JAP	LX570	URJ	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
JAP	LX570	URJ	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	LX570	URJ	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	LX570	URJ	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		

JAP	LX570	URJ	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661
JAP	LX570	URJ	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓	
JAP	LX570	URJ	All years	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298

JAP	LX570	URJ	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	LX570	URJ	All years	Accessory Gateway	✓	✓	✓	✓		
JAP	LX570	URJ	All years	Central Gateway	✓	✓	✓	✓		
JAP	LX570	URJ	All years	Body No. 4	✓	✓	✓		0310, 0311, 0312, 0313, 0314, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0327, 0328, 0329, 1618, 1619	
JAP	LX570	URJ	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	LX570	URJ	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	LX570	URJ	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	LX570	URJ	All years	Left Rear Door Motor	✓	✓	✓		0528	

JAP	LX570	URJ	All years	Right Rear Door Motor	√	√	√		0528	
JAP	LX570	URJ	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	LX570	URJ	All years	Master Switch	√	√	√			
JAP	LX570	URJ	All years	Sliding Roof	√	√	√		0529	
JAP	LX570	URJ	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	
JAP	LX570	URJ	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	LX570	URJ	All years	Head Up Display	√	√	√	√	0047, 0048, 0049, 0050, 0051	
JAP	LX570	URJ	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	

JAP	LX570	URJ	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	LX570	URJ	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
JAP	LX570	URJ	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	LX570	URJ	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	LX570	URJ	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	LX570	URJ	All years	Remote Engine Starter	✓	✓	✓	✓		
JAP	LX570	URJ	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
JAP	LX570	URJ	All years	Navigation System	✓	✓	✓	✓		
JAP	LX570	URJ	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
JAP	LX570	URJ	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
JAP	LX570	URJ	All years	Automatic High Beam	✓	✓	✓		0035	
JAP	LX570	URJ	All years	Cruise Control	✓	✓	✓	✓		

JAP	LX570	URJ	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	NX200t	AGZ1#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,	SP0102, SP0114, SP0115, SP0162

JAP	NX200t	AGZ1#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
JAP	NX200t	AGZ1#	All years	Stop&Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297
JAP	NX200t	AGZ1#	All years	Cruise Control	✓	✓	✓	✓	
JAP	NX200t	AGZ1#	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646



JAP	NX200t	AGZ1#	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	NX200t	AGZ1#	All years	4WD (CAN)	✓	✓	✓	✓	0819, 0820, 0821, 0822, 1669	
JAP	NX200t	AGZ1#	All years	Tire Pressure Monitor	✓	✓	✓			
JAP	NX200t	AGZ1#	All years	EHPS	✓	✓	✓	✓		
JAP	NX200t	AGZ1#	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	

JAP	NX200t	AGZ1#	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√			
JAP	NX200t	AGZ1#	All years	Panoramic View Monitor	√	√	√	√			
JAP	NX200t	AGZ1#	All years	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824		
JAP	NX200t	AGZ1#	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661		
JAP	NX200t	AGZ1#	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√			

JAP	NX200t	AGZ1#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	NX200t	AGZ1#	All years	Gateway	✓	✓	✓	✓		
JAP	NX200t	AGZ1#	All years	Accessory Gateway	✓	✓	✓	✓		
JAP	NX200t	AGZ1#	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	NX200t	AGZ1#	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	NX200t	AGZ1#	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	NX200t	AGZ1#	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	NX200t	AGZ1#	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	NX200t	AGZ1#	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	NX200t	AGZ1#	All years	Master Switch	✓	✓	✓			

JAP	NX200t	AGZ1#	All years	Sliding Roof	✓	✓	✓		0529	
JAP	NX200t	AGZ1#	All years	Tilt&Teleopic	✓	✓	✓	✓	0472, 0473	
JAP	NX200t	AGZ1#	All years	Combinati on Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	NX200t	AGZ1#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	NX200t	AGZ1#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	NX200t	AGZ1#	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026	
JAP	NX200t	AGZ1#	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	

JAP	NX200t	AGZ1#	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	NX200t	AGZ1#	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	NX200t	AGZ1#	All years	Starting Control	√	√	√	√	0256, 0257	
JAP	NX200t	AGZ1#	All years	Navigation System	√	√	√	√		
JAP	NX200t	AGZ1#	All years	Master Blind Spot Monitor	√	√	√	√		
JAP	NX200t	AGZ1#	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	NX200t	AGZ1#	All years	ASC	√	√	√	√	1182	
JAP	NX200t	AGZ1#	All years	Radar Cruise	√	√	√	√	0017, 0018	
JAP	NX200t	AGZ1#	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	NX200t	AGZ1#	All years	Remote Engine Starter	√	√	√	√		

JAP	NX300	AGZ1#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,
-----	-------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	NX300	AGZ1#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
JAP	NX300	AGZ1#	All years	Stop and Start	✓	✓	✓		1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
JAP	NX300	AGZ1#	All years	Radar Cruise 1	✓	✓	✓	✓		
JAP	NX300	AGZ1#	All years	Radar Cruise 2	✓	✓	✓	✓	1504, 1505	

JAP	NX300	AGZ1#	All years	Air suspension	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	
JAP	NX300	AGZ1#	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	NX300	AGZ1#	All years	4-Wheel Drive (4WD)	√	√	√	√	0819, 0820, 0821, 0822, 1669	
JAP	NX300	AGZ1#	All years	Tire Pressure Monitor	√	√	√			
JAP	NX300	AGZ1#	All years	EMPS	√	√	√	√		



JAP	NX300	AGZ1#	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
JAP	NX300	AGZ1#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
JAP	NX300	AGZ1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
JAP	NX300	AGZ1#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
JAP	NX300	AGZ1#	All years	Panoramic View Monitor	✓	✓	✓	✓		
JAP	NX300	AGZ1#	All years	Parking Assist Camera	✓	✓	✓	✓		

JAP	NX300	AGZ1#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661
JAP	NX300	AGZ1#	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓	
JAP	NX300	AGZ1#	All years	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298

JAP	NX300	AGZ1#	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	NX300	AGZ1#	All years	Accessory Gateway	√	√	√	√		
JAP	NX300	AGZ1#	All years	Central Gateway	√	√	√	√		
JAP	NX300	AGZ1#	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	NX300	AGZ1#	All years	Driver Door Motor	√	√	√		0528	
JAP	NX300	AGZ1#	All years	Passenger Door Motor	√	√	√		0528	
JAP	NX300	AGZ1#	All years	Left Rear Door Motor	√	√	√		0528	
JAP	NX300	AGZ1#	All years	Right Rear Door Motor	√	√	√		0528	
JAP	NX300	AGZ1#	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	NX300	AGZ1#	All years	Master Switch	√	√	√			

JAP	NX300	AGZ1#	All years	Sliding Roof	√	√	√		0529	
JAP	NX300	AGZ1#	All years	Tilt&Teleopic	√	√	√	√	0472, 0473	
JAP	NX300	AGZ1#	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	NX300	AGZ1#	All years	Head Up Display	√	√	√	√	0047, 0048, 0049, 0050, 0051	
JAP	NX300	AGZ1#	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	NX300	AGZ1#	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	

JAP	NX300	AGZ1#	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
JAP	NX300	AGZ1#	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	NX300	AGZ1#	All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	NX300	AGZ1#	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	NX300	AGZ1#	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	NX300	AGZ1#	All years	Remote Engine Starter	√	√	√	√		
JAP	NX300	AGZ1#	All years	Starting Control	√	√	√	√	0256, 0257	
JAP	NX300	AGZ1#	All years	Navigation System	√	√	√	√		
JAP	NX300	AGZ1#	All years	Master Blind Spot Monitor	√	√	√	√		

JAP	NX300	AGZ1#	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	NX300	AGZ1#	All years	ASC	√	√	√	√	1182	
JAP	NX300	AGZ1#	All years	Connection Of ITS	√	√	√	√		
JAP	NX300	AGZ1#	All years	Brake/EPB	√	√	√		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
JAP	NX300	AGZ1#	All years	Lane Control	√	√	√		0824, 0989	
JAP	NX300	AGZ1#	All years	Pre-Collision System	√	√	√		1524, 1525, 1526	
JAP	NX300	AGZ1#	All years	Road Sign Assist	√	√	√			
JAP	NX300	AGZ1#	All years	Front Recognition Camera (Front Lighting Control)	√	√	√			
JAP	NX300	AGZ1#	All years	Front Radar Sensor	√	√	√			

JAP	NX300h	AYZ	All years	Engine	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	
JAP	NX300h	AYZ	All years	Hybrid Control	√	√	√	√	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 1577, 1578	
JAP	NX300h	AYZ	All years	Cruise Control	√	√	√	√		

JAP	NX300h	AYZ	All years	Air suspension	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	
JAP	NX300h	AYZ	All years	ABS-VSC-TRC (TRAC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	NX300h	AYZ	All years	Tire Pressure Monitor	√	√	√			
JAP	NX300h	AYZ	All years	EMPS	√	√	√	√		



JAP	NX300h	AYZ	All years	Electric Parking Brake	√	√	√	√	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397
JAP	NX300h	AYZ	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√	
JAP	NX300h	AYZ	All years	Panoramic View Monitor	√	√	√	√	
JAP	NX300h	AYZ	All years	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824
JAP	NX300h	AYZ	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661

JAP	NX300h	AYZ	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
JAP	NX300h	AYZ	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	NX300h	AYZ	All years	HV Gateway	✓	✓	✓	✓		
JAP	NX300h	AYZ	All years	Accessory Gateway	✓	✓	✓	✓		
JAP	NX300h	AYZ	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	NX300h	AYZ	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	NX300h	AYZ	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	NX300h	AYZ	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	NX300h	AYZ	All years	Right Rear Door Motor	✓	✓	✓		0528	

JAP	NX300h	AYZ	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
JAP	NX300h	AYZ	All years	Master Switch	✓	✓	✓		
JAP	NX300h	AYZ	All years	Sliding Roof	✓	✓	✓		0529
JAP	NX300h	AYZ	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
JAP	NX300h	AYZ	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,
JAP	NX300h	AYZ	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	NX300h	AYZ	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612

JAP	NX300h	AYZ	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	
JAP	NX300h	AYZ	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	NX300h	AYZ	All years	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	NX300h	AYZ	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	NX300h	AYZ	All years	Remote Engine Starter	✓	✓	✓	✓		
JAP	NX300h	AYZ	All years	Navigation System	✓	✓	✓	✓		
JAP	NX300h	AYZ	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
JAP	NX300h	AYZ	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
JAP	NX300h	AYZ	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
JAP	NX300h	AYZ	All years	ASC	✓	✓	✓	✓	1182	
JAP	NX300h	AYZ	All years	Radar Cruise	✓	✓	✓	✓	0017, 0018	
JAP	NX300h	AYZ	All years	Pre-Crash	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	NX300h	AYZ	All years	Radar Cruise 1	✓	✓	✓	✓		
JAP	NX300h	AYZ	All years	Radar Cruise 2	✓	✓	✓	✓	1504, 1505	

JAP	NX300h	AYZ	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	NX300h	AYZ	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	NX300h	AYZ	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
JAP	NX300h	AYZ	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	NX300h	AYZ	All years	Central Gateway	√	√	√	√		
JAP	NX300h	AYZ	All years	Head Up Display	√	√	√	√	0047, 0048, 0049, 0050, 0051	
JAP	NX300h	AYZ	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
JAP	NX300h	AYZ	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	

JAP	NX300h	AYZ	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	NX300h	AYZ	All years	Connection Of ITS	√	√	√	√		
JAP	NX300h	AYZ	All years	Lane Control	√	√	√		0824, 0989	
JAP	NX300h	AYZ	All years	Pre-Collision System	√	√	√		1524, 1525, 1526	
JAP	NX300h	AYZ	All years	Road Sign Assist	√	√	√			
JAP	NX300h	AYZ	All years	Front Recognition Camera (Front Lighting Control)	√	√	√			
JAP	NX300h	AYZ	All years	Front Radar Sensor	√	√	√			
JAP	NX300h	AYZ	All years	Vehicle proximity notification system	√	√	√	√		

JAP	RC-F	USC	All years	Engine	✓	✓	✓	✓	0071, 0079, 0 080, 0081, 00 82, 0084, 008 5, 0086, 0087 , 0088, 0089, 0090, 0091, 0 092, 0093, 00 94, 0095, 009 6, 0097, 0098 , 0099, 0100, 0101, 0102, 0 103, 0104, 01 05, 0106, 010 7, 0108, 0109 , 0110, 0111, 0112, 0113, 0 114, 0118, 01 22, 0124, 012 5, 0130, 0131 , 0135, 0137, 0138, 0142, 0 143, 0144, 01 45, 0146, 014 7, 0148, 0149 , 0150, 0151, 0152, 0154, 0 155, 0156, 01 59, 0160, 016 1, 0162, 0163 , 0164, 0165,	SP0003, SP0 004, SP0027 , SP0029, SP 0030, SP003 1, SP0032, S P0042, SP00 43, SP0101, SP0103, SP0 106, SP0107 , SP0108, SP 0109, SP011 0, SP0111, S P0113, SP01 98
-----	------	-----	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	RC-F	USC	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,	SP0003, SP0004, SP0032, SP0101
JAP	RC-F	USC	All years	Cruise Control	✓	✓	✓	✓		
JAP	RC-F	USC	All years	Tire Pressure Monitor	✓	✓	✓			SP0001, SP0002, SP0004
JAP	RC-F	USC	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	RC-F	USC	All years	Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	SP0086, SP0087



JAP	RC-F	USC	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	RC-F	USC	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0004

JAP	RC-F	USC	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018
JAP	RC-F	USC	All years	Gateway	✓	✓	✓	✓		SP0005
JAP	RC-F	USC	All years	Accessory Gateway	✓	✓	✓	✓		SP0005
JAP	RC-F	USC	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	RC-F	USC	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	RC-F	USC	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	RC-F	USC	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	RC-F	USC	All years	Master Switch	✓	✓	✓			
JAP	RC-F	USC	All years	Sliding Roof	✓	✓	✓		0529	
JAP	RC-F	USC	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	

JAP	RC-F	USC	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	RC-F	USC	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	RC-F	USC	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	RC-F	USC	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
JAP	RC-F	USC	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, SP0008	

JAP	RC-F	USC	All years	Smart Key	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0018, SP0201
JAP	RC-F	USC	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	SP0045
JAP	RC-F	USC	All years	Remote Engine Starter	√	√	√	√		SP0046
JAP	RC-F	USC	All years	Starting Control	√	√	√	√	0256, 0257	
JAP	RC-F	USC	All years	Navigation System	√	√	√	√		SP0050
JAP	RC-F	USC	All years	Active Rear Wing	√	√	√		1189, 1190, 1191, 1192, 1193	SP0136
JAP	RC-F	USC	All years	Master Blind Spot Monitor	√	√	√	√		SP0070, SP0071
JAP	RC-F	USC	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	RC-F	USC	All years	ASC	√	√	√	√	1182	
JAP	RC-F	USC	All years	Radar Cruise	√	√	√	√		SP0061, SP0069
JAP	RC-F	USC	All years	TVD	√	√	√	√	0042, 0043	SP0004, SP00194, SP0202
JAP	RC-F	USC	All years	Pre-Crash	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0044

JAP	RC-F	USC	All years	Air suspension	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646
JAP	RC-F	USC	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,
JAP	RC-F	USC	All years	Theft Deterrent	√	√	√		0333, 0498, 0499, 0501, 0502, 1647
JAP	RC-F	USC	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298
JAP	RC-F	USC	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026

JAP	RC-F	USC	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	RC-F	USC	All years	ABS/VSC/TRC (TRAC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	RC-F	USC	All years	EMPS	✓	✓	✓	✓		
JAP	RC-F	USC	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		

JAP	RC-F	USC	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
JAP	RC-F	USC	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
JAP	RC-F	USC	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				✓		
JAP	RC-F	USC	All years	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	RC-F	USC	All years	Central Gateway	✓	✓	✓	✓		
JAP	RC-F	USC	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	RC-F	USC	All years	Brake	✓	✓	✓		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	

JAP	RC200t	ASC10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,
-----	--------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



JAP	RC200t	ASC10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
JAP	RC200t	ASC10	All years	Stop&Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	
JAP	RC200t	ASC10	All years	Cruise Control	✓	✓	✓	✓		
JAP	RC200t	ASC10	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	

JAP	RC200t	ASC10	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	RC200t	ASC10	All years	Tire Pressure Monitor	√	√	√			
JAP	RC200t	ASC10	All years	EHPS	√	√	√	√		
JAP	RC200t	ASC10	All years	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	

JAP	RC200t	ASC10	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661
JAP	RC200t	ASC10	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓	

JAP	RC200t	ASC10	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	RC200t	ASC10	All years	Gateway	√	√	√	√		
JAP	RC200t	ASC10	All years	Accessory Gateway	√	√	√	√		
JAP	RC200t	ASC10	All years	Driver Door Motor	√	√	√		0528	
JAP	RC200t	ASC10	All years	Passenger Door Motor	√	√	√		0528	
JAP	RC200t	ASC10	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	RC200t	ASC10	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	RC200t	ASC10	All years	Master Switch	√	√	√			
JAP	RC200t	ASC10	All years	Sliding Roof	√	√	√		0529	
JAP	RC200t	ASC10	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	

JAP	RC200t	ASC10	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,
JAP	RC200t	ASC10	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RC200t	ASC10	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RC200t	ASC10	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026
JAP	RC200t	ASC10	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015

JAP	RC200t	ASC10	All years	Smart Key	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	RC200t	ASC10	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	RC200t	ASC10	All years	Remote Engine Starter	√	√	√	√		
JAP	RC200t	ASC10	All years	Starting Control	√	√	√	√	0256, 0257	
JAP	RC200t	ASC10	All years	Navigation System	√	√	√	√		
JAP	RC200t	ASC10	All years	Master Blind Spot Monitor	√	√	√	√		
JAP	RC200t	ASC10	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	RC200t	ASC10	All years	Radar Cruise	√	√	√	√	0017, 0018	
JAP	RC200t	ASC10	All years	Pre-Crash	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	

JAP	RC300	ASC10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,
-----	-------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	RC300	ASC10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
JAP	RC300	ASC10	All years	Stop&Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	
JAP	RC300	ASC10	All years	Radar Cruise	✓	✓	✓	✓		
JAP	RC300	ASC10	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	



JAP	RC300	ASC10	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	RC300	ASC10	All years	Tire Pressure Monitor	√	√	√			
JAP	RC300	ASC10	All years	EMPS	√	√	√	√		
JAP	RC300	ASC10	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		
JAP	RC300	ASC10	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	RC300	ASC10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	

JAP	RC300	ASC10	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
JAP	RC300	ASC10	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	
JAP	RC300	ASC10	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		
JAP	RC300	ASC10	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	

JAP	RC300	ASC10	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	RC300	ASC10	All years	Accessory Gateway	✓	✓	✓	✓		
JAP	RC300	ASC10	All years	Central Gateway	✓	✓	✓	✓		
JAP	RC300	ASC10	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	RC300	ASC10	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	RC300	ASC10	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	RC300	ASC10	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	RC300	ASC10	All years	Master Switch	✓	✓	✓			
JAP	RC300	ASC10	All years	Sliding Roof	✓	✓	✓		0529	
JAP	RC300	ASC10	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473	

JAP	RC300	ASC10	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,
JAP	RC300	ASC10	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RC300	ASC10	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RC300	ASC10	All years	Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026
JAP	RC300	ASC10	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493

JAP	RC300	ASC10	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	RC300	ASC10	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	RC300	ASC10	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	RC300	ASC10	All years	Remote Engine Starter	✓	✓	✓	✓		
JAP	RC300	ASC10	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
JAP	RC300	ASC10	All years	Navigation System	✓	✓	✓	✓		
JAP	RC300	ASC10	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
JAP	RC300	ASC10	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
JAP	RC300	ASC10	All years	Telematics	✓	✓	✓		1521, 1522	

JAP	RC300h	AVC	All years	Engine	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	
JAP	RC300h	AVC	All years	Hybrid Control	√	√	√	√	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 1577, 1578	
JAP	RC300h	AVC	All years	Cruise Control	√	√	√	√		

JAP	RC300h	AVC	All years	Air suspension	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	
JAP	RC300h	AVC	All years	ABS-VSC-TRC (TRAC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	RC300h	AVC	All years	Tire Pressure Monitor	√	√	√			
JAP	RC300h	AVC	All years	EHPS	√	√	√	√		
JAP	RC300h	AVC	All years	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	

JAP	RC300h	AVC	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661
JAP	RC300h	AVC	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√	



JAP	RC300h	AVC	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	RC300h	AVC	All years	Gateway	√	√	√	√		
JAP	RC300h	AVC	All years	Accessory Gateway	√	√	√	√		
JAP	RC300h	AVC	All years	Driver Door Motor	√	√	√		0528	
JAP	RC300h	AVC	All years	Passenger Door Motor	√	√	√		0528	
JAP	RC300h	AVC	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	RC300h	AVC	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	RC300h	AVC	All years	Master Switch	√	√	√			
JAP	RC300h	AVC	All years	Sliding Roof	√	√	√		0529	
JAP	RC300h	AVC	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	

JAP	RC300h	AVC	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,
JAP	RC300h	AVC	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RC300h	AVC	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RC300h	AVC	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026
JAP	RC300h	AVC	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015

JAP	RC300h	AVC	All years	Smart Key	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	RC300h	AVC	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	RC300h	AVC	All years	Remote Engine Starter	√	√	√	√		
JAP	RC300h	AVC	All years	Navigation System	√	√	√	√		
JAP	RC300h	AVC	All years	Master Blind Spot Monitor	√	√	√	√		
JAP	RC300h	AVC	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	RC300h	AVC	All years	Notification System Of Vehicle Proximity	√	√	√		0044, 0045, 0046	
JAP	RC300h	AVC	All years	Radar Cruise	√	√	√	√	0017, 0018	
JAP	RC300h	AVC	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	RC300h	AVC	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
JAP	RC300h	AVC	All years	EMPS	√	√	√	√		
JAP	RC300h	AVC	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		

JAP	RC300h	AVC	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	RC300h	AVC	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	RC300h	AVC	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
JAP	RC300h	AVC	All years	Central Gateway	√	√	√	√		
JAP	RC300h	AVC	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	RC300h	AVC	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	RC300h	AVC	All years	Telematics	√	√	√		1521, 1522	

JAP	RC300h	AVE	All years	Engine	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	
JAP	RC300h	AVE	All years	Hybrid Control	√	√	√	√	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 1577, 1578	
JAP	RC300h	AVE	All years	Cruise Control	√	√	√	√		

JAP	RC300h	AVE	All years	Air suspension	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	
JAP	RC300h	AVE	All years	ABS-VSC-TRC (TRAC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	RC300h	AVE	All years	Tire Pressure Monitor	√	√	√			
JAP	RC300h	AVE	All years	EHPS	√	√	√	√		
JAP	RC300h	AVE	All years	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	

JAP	RC300h	AVE	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661
JAP	RC300h	AVE	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓	

JAP	RC300h	AVE	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	RC300h	AVE	All years	Gateway	√	√	√	√		
JAP	RC300h	AVE	All years	Accessory Gateway	√	√	√	√		
JAP	RC300h	AVE	All years	Driver Door Motor	√	√	√		0528	
JAP	RC300h	AVE	All years	Passenger Door Motor	√	√	√		0528	
JAP	RC300h	AVE	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	RC300h	AVE	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	RC300h	AVE	All years	Master Switch	√	√	√			
JAP	RC300h	AVE	All years	Sliding Roof	√	√	√		0529	
JAP	RC300h	AVE	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	



JAP	RC300h	AVE	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,
JAP	RC300h	AVE	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RC300h	AVE	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RC300h	AVE	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026
JAP	RC300h	AVE	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015

JAP	RC300h	AVE	All years	Smart Key	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	RC300h	AVE	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	RC300h	AVE	All years	Remote Engine Starter	√	√	√	√		
JAP	RC300h	AVE	All years	Navigation System	√	√	√	√		
JAP	RC300h	AVE	All years	Master Blind Spot Monitor	√	√	√	√		
JAP	RC300h	AVE	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	RC300h	AVE	All years	Notification System Of Vehicle Proximity	√	√	√		0044, 0045, 0046	
JAP	RC300h	AVE	All years	Radar Cruise	√	√	√	√	0017, 0018	
JAP	RC300h	AVE	All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	RC300h	AVE	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
JAP	RC300h	AVE	All years	EMPS	√	√	√	√		
JAP	RC300h	AVE	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	√	√	√	√		

JAP	RC300h	AVE	All years	Front Recognition Camera	√	√	√	√	0052	
JAP	RC300h	AVE	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	RC300h	AVE	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			√			
JAP	RC300h	AVE	All years	Central Gateway	√	√	√	√		
JAP	RC300h	AVE	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	RC300h	AVE	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	RC300h	AVE	All years	Telematics	√	√	√		1521, 1522	

JAP	RC350	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,
-----	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	RC350		All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,
JAP	RC350		All years	Radar Cruise	✓	✓	✓	✓	
JAP	RC350		All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646

JAP	RC350	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	RC350	All years	Tire Pressure Monitor	✓	✓	✓			
JAP	RC350	All years	EMPS	✓	✓	✓	✓		
JAP	RC350	All years	VGRS	✓	✓	✓	✓		
JAP	RC350	All years	Intelligent Parking Assist (IPA)/Parking Assist Monitor	✓	✓	✓	✓		
JAP	RC350	All years	Front Recognition Camera	✓	✓	✓	✓	0052	

JAP	RC350		All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	RC350		All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
JAP	RC350		All years	DRS	√	√	√	√		
JAP	RC350		All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	
JAP	RC350		All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		

JAP	RC350		All years	Pre-Collision 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	RC350		All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	RC350		All years	Accessory Gateway	√	√	√	√		
JAP	RC350		All years	Central Gateway	√	√	√	√		
JAP	RC350		All years	Driver Door Motor	√	√	√		0528	
JAP	RC350		All years	Passenger Door Motor	√	√	√		0528	
JAP	RC350		All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	RC350		All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	RC350		All years	Master Switch	√	√	√			



JAP	RC350		All years	Sliding Roof	✓	✓	✓		0529	
JAP	RC350		All years	Tilt&Teleopic	✓	✓	✓	✓	0472, 0473	
JAP	RC350		All years	Combinati on Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	
JAP	RC350		All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	RC350		All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	

JAP	RC350		All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
JAP	RC350		All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	RC350		All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	RC350		All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	RC350		All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	RC350		All years	Remote Engine Starter	√	√	√	√		
JAP	RC350		All years	Starting Control	√	√	√	√	0256, 0257	
JAP	RC350		All years	Navigation System	√	√	√	√		
JAP	RC350		All years	Master Blind Spot Monitor	√	√	√	√		

JAP	RC350		All years	Slave Blind Spot Monitor	√	√	√	√			
JAP	RC350		All years	Telematics	√	√	√		1521, 1522		
JAP	RC350	GSC	All years	Engine and ECT	√	√	√	√	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,		

JAP	RC350	GSC	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,
JAP	RC350	GSC	All years	Cruise Control	✓	✓	✓	✓	
JAP	RC350	GSC	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646

JAP	RC350	GSC	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	RC350	GSC	All years	Tire Pressure Monitor	√	√	√			
JAP	RC350	GSC	All years	EHPS	√	√	√	√		
JAP	RC350	GSC	All years	VGRS	√	√	√	√		
JAP	RC350	GSC	All years	DRS	√	√	√	√		
JAP	RC350	GSC	All years	Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	

JAP	RC350	GSC	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661
JAP	RC350	GSC	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓	

JAP	RC350	GSC	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	RC350	GSC	All years	Gateway	✓	✓	✓	✓		
JAP	RC350	GSC	All years	Multi Bus Gateway	✓	✓	✓	✓		
JAP	RC350	GSC	All years	No. 1 Multi Bus Monitor	✓	✓	✓	✓		
JAP	RC350	GSC	All years	No. 2 Multi Bus Monitor	✓	✓	✓	✓		
JAP	RC350	GSC	All years	Accessory Gateway	✓	✓	✓	✓		
JAP	RC350	GSC	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	RC350	GSC	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	RC350	GSC	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

JAP	RC350	GSC	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
JAP	RC350	GSC	All years	Master Switch	✓	✓	✓		
JAP	RC350	GSC	All years	Sliding Roof	✓	✓	✓		0529
JAP	RC350	GSC	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
JAP	RC350	GSC	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,
JAP	RC350	GSC	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RC350	GSC	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612



JAP	RC350	GSC	All years	Intuitive Parking Assist	√	√	√	√	0023, 0024, 0025, 0026	
JAP	RC350	GSC	All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	RC350	GSC	All years	Smart Key	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	RC350	GSC	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	RC350	GSC	All years	Remote Engine Starter	√	√	√	√		
JAP	RC350	GSC	All years	Starting Control	√	√	√	√	0256, 0257	
JAP	RC350	GSC	All years	Navigation System	√	√	√	√		
JAP	RC350	GSC	All years	Master Blind Spot Monitor	√	√	√	√		
JAP	RC350	GSC	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	RC350	GSC	All years	Radar Cruise	√	√	√	√	0017, 0018	
JAP	RC350	GSC	All years	Pre-Crash	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	

JAP	RX200t	AGL2#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,
-----	--------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	RX200t	AGL2#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
JAP	RX200t	AGL2#	All years	Stop&Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	
JAP	RX200t	AGL2#	All years	Cruise Control	✓	✓	✓	✓		
JAP	RX200t	AGL2#	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	

JAP	RX200t	AGL2#	All years	ABS/VSC/TRC (TRAC)/EPB	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	RX200t	AGL2#	All years	4WD (CAN)	✓	✓	✓	✓	0819, 0820, 0821, 0822, 1669	
JAP	RX200t	AGL2#	All years	Tire Pressure Monitor	✓	✓	✓			
JAP	RX200t	AGL2#	All years	EHPS	✓	✓	✓	✓		
JAP	RX200t	AGL2#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	SP0086, SP0126, SP0134, SP0182, SP0183
JAP	RX200t	AGL2#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	

JAP	RX200t	AGL2#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				✓			
JAP	RX200t	AGL2#	All years	Panoramic View Monitor	✓	✓	✓	✓			
JAP	RX200t	AGL2#	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	✓	✓	✓	✓			
JAP	RX200t	AGL2#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661		
JAP	RX200t	AGL2#	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓			

JAP	RX200t	AGL2#	All years	Pre-Crash	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	RX200t	AGL2#	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	RX200t	AGL2#	All years	Accessory Gateway	√	√	√	√		
JAP	RX200t	AGL2#	All years	Central Gateway	√	√	√	√		
JAP	RX200t	AGL2#	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	RX200t	AGL2#	All years	Driver Door Motor	√	√	√		0528	
JAP	RX200t	AGL2#	All years	Passenger Door Motor	√	√	√		0528	
JAP	RX200t	AGL2#	All years	Left Rear Door Motor	√	√	√		0528	
JAP	RX200t	AGL2#	All years	Right Rear Door Motor	√	√	√		0528	

JAP	RX200t	AGL2#	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519
JAP	RX200t	AGL2#	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
JAP	RX200t	AGL2#	All years	Master Switch	√	√	√		
JAP	RX200t	AGL2#	All years	Sliding Roof	√	√	√		0529
JAP	RX200t	AGL2#	All years	Sliding Sunshade	√	√	√		1181
JAP	RX200t	AGL2#	All years	Tilt&Telescopic	√	√	√	√	0472, 0473
JAP	RX200t	AGL2#	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,
JAP	RX200t	AGL2#	All years	Head Up Display	√	√	√	√	0047, 0048, 0049, 0050, 0051

JAP	RX200t	AGL2#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RX200t	AGL2#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RX200t	AGL2#	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	✓	✓	✓	✓	
JAP	RX200t	AGL2#	All years	Rain Sensor	✓	✓	✓		
JAP	RX200t	AGL2#	All years	Wiper	✓	✓	✓	✓	0031, 0032
JAP	RX200t	AGL2#	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
JAP	RX200t	AGL2#	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015



JAP	RX200t	AGL2#	All years	Smart Key	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	RX200t	AGL2#	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	RX200t	AGL2#	All years	Remote Engine Starter	√	√	√	√		
JAP	RX200t	AGL2#	All years	Starting Control	√	√	√	√	0256, 0257	
JAP	RX200t	AGL2#	All years	Navigation System	√	√	√	√		
JAP	RX200t	AGL2#	All years	Master Blind Spot Monitor	√	√	√	√		
JAP	RX200t	AGL2#	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	RX200t	AGL2#	All years	Connection Of ITS	√	√	√	√	0206	
JAP	RX200t	AGL2#	All years	Radar Cruise 1	√	√	√	√		
JAP	RX200t	AGL2#	All years	Radar Cruise	√	√	√	√		
JAP	RX200t	AGL2#	All years	Radar Cruise 2	√	√	√	√		
JAP	RX200t	AGL2#	All years	Parking Assist Camera	√	√	√	√		
JAP	RX200t	AGL2#	All years	Pre-Crash 2	√	√	√	√	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	RX200t	AGL2#	All years	Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
JAP	RX200t	AGL2#	All years	Rain and/or Humidity Sensor	√	√	√			

JAP	RX200t	AGL2#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648
JAP	RX270	AGL	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165, SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0042, SP0043, SP0101, SP0103, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0118, SP0198

JAP	RX270	AGL	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,	SP0003, SP0004, SP0032, SP0101
JAP	RX270	AGL	All years	Cruise Control	✓	✓	✓	✓		

JAP	RX270	AGL	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	RX270	AGL	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	RX270	AGL	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	✓	✓	✓	✓		

JAP	RX270	AGL	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	RX270	AGL	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0004

JAP	RX270	AGL	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018
JAP	RX270	AGL	All years	PM1 Gateway	√	√	√	√		SP0005
JAP	RX270	AGL	All years	PM2 Gateway	√	√	√	√		SP0005
JAP	RX270	AGL	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	RX270	AGL	All years	Driver Door Motor	√	√	√		0528	
JAP	RX270	AGL	All years	Passenger Door Motor	√	√	√		0528	
JAP	RX270	AGL	All years	Left Rear Door Motor	√	√	√		0528	
JAP	RX270	AGL	All years	Right Rear Door Motor	√	√	√		0528	
JAP	RX270	AGL	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

JAP	RX270	AGL	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
JAP	RX270	AGL	All years	Master Switch	✓	✓	✓		
JAP	RX270	AGL	All years	Sliding Roof	✓	✓	✓		0529
JAP	RX270	AGL	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
JAP	RX270	AGL	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,
JAP	RX270	AGL	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RX270	AGL	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612

JAP	RX270	AGL	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
JAP	RX270	AGL	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	RX270	AGL	All years	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0201
JAP	RX270	AGL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	SP0045
JAP	RX270	AGL	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
JAP	RX270	AGL	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
JAP	RX270	AGL	All years	Charging Control	✓	✓	✓	✓	0258, 1613	
JAP	RX270	AGL	All years	Navigation System	✓	✓	✓	✓		SP0050



JAP	RX300	AGL2#	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,
-----	-------	-------	--------------	--------	---	---	---	---	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	RX300	AGL2#	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
JAP	RX300	AGL2#	All years	Stop&Start	✓	✓	✓	✓	0026, 0285, 0286, 0287, 0288, 0289, 0290, 0291, 0292, 0293, 0294, 0295, 0296, 0297	
JAP	RX300	AGL2#	All years	Radar Cruise 1	✓	✓	✓	✓		
JAP	RX300	AGL2#	All years	Radar Cruise 2	✓	✓	✓	✓	1504, 1505	

JAP	RX300	AGL2#	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	
JAP	RX300	AGL2#	All years	ABS/VSC/TRC (TRAC)/EPB	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	
JAP	RX300	AGL2#	All years	4WD (CAN)	✓	✓	✓	✓	0819, 0820, 0821, 0822, 1669	
JAP	RX300	AGL2#	All years	Tire Pressure Monitor	✓	✓	✓			
JAP	RX300	AGL2#	All years	EMPS	✓	✓	✓	✓		

JAP	RX300	AGL2#	All years	Front Recognition Camera	✓	✓	✓	✓	0052	
JAP	RX300	AGL2#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	✓	✓	✓	✓	0823, 0824	
JAP	RX300	AGL2#	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)			✓			
JAP	RX300	AGL2#	All years	Panoramic View Monitor	✓	✓	✓	✓		
JAP	RX300	AGL2#	All years	Parking Assist Camera	✓	✓	✓	✓		
JAP	RX300	AGL2#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	

JAP	RX300	AGL2#	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		
JAP	RX300	AGL2#	All years	Pre-Collision 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	RX300	AGL2#	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	RX300	AGL2#	All years	Accessory Gateway	✓	✓	✓	✓		
JAP	RX300	AGL2#	All years	Central Gateway	✓	✓	✓	✓		
JAP	RX300	AGL2#	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	RX300	AGL2#	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	RX300	AGL2#	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	RX300	AGL2#	All years	Left Rear Door Motor	✓	✓	✓		0528	

JAP	RX300	AGL2#	All years	Right Rear Door Motor	√	√	√		0528	
JAP	RX300	AGL2#	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	RX300	AGL2#	All years	Passenger Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519	
JAP	RX300	AGL2#	All years	Master Switch	√	√	√			
JAP	RX300	AGL2#	All years	Sliding Roof	√	√	√		0529	
JAP	RX300	AGL2#	All years	Sliding Sunshade	√	√	√		1181	
JAP	RX300	AGL2#	All years	Tilt&Telescopic	√	√	√	√	0472, 0473	
JAP	RX300	AGL2#	All years	Combination Meter	√	√	√	√	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,	

JAP	RX300	AGL2#	All years	Head Up Display	✓	✓	✓	✓	0047, 0048, 0049, 0050, 0051
JAP	RX300	AGL2#	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RX300	AGL2#	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RX300	AGL2#	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	✓	✓	✓	✓	0023, 0024, 0025, 0026
JAP	RX300	AGL2#	All years	Rain and/or Humidity Sensor	✓	✓	✓		
JAP	RX300	AGL2#	All years	Wiper	✓	✓	✓	✓	0031, 0032
JAP	RX300	AGL2#	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
JAP	RX300	AGL2#	All years	Auto Leveling Of Headlamp	✓	✓	✓	✓	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015

JAP	RX300	AGL2#	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	RX300	AGL2#	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	RX300	AGL2#	All years	Remote Engine Starter	√	√	√	√		
JAP	RX300	AGL2#	All years	Starting Control	√	√	√	√	0256, 0257	
JAP	RX300	AGL2#	All years	Navigation System	√	√	√	√		
JAP	RX300	AGL2#	All years	Master Blind Spot Monitor	√	√	√	√		
JAP	RX300	AGL2#	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	RX300	AGL2#	All years	Connection Of ITS	√	√	√	√		
JAP	RX300	AGL2#	All years	Stop and Start	√	√	√		1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
JAP	RX300	AGL2#	All years	Brake/EPB	√	√	√		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
JAP	RX300	AGL2#	All years	Lane Control	√	√	√		0824, 0989	
JAP	RX300	AGL2#	All years	Pre-Collision System	√	√	√		1524, 1525, 1526	
JAP	RX300	AGL2#	All years	Road Sign Assist	√	√	√			



JAP	RX300	AGL2#	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
JAP	RX300	AGL2#	All years	Front Radar Sensor	✓	✓	✓			
JAP	RX300	AGL2#	All years	Telematics	✓	✓	✓		1521, 1522	
JAP	RX350	GGL	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0101, SP0103, SP0104, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0198

JAP	RX350	GGL	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,	SP0003, SP004, SP0030, SP0032, SP0101
JAP	RX350	GGL	All years	Cruise Control	✓	✓	✓	✓		
JAP	RX350	GGL	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	SP0001, SP004, SP0007

JAP	RX350	GGL	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	RX350	GGL	All years	4WD (CAN)	✓	✓	✓	✓	0819, 0820, 0821, 0822, 1669	SP0003, SP0052
JAP	RX350	GGL	All years	EHPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	RX350	GGL	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	✓	✓	✓	✓		

JAP	RX350	GGL	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	RX350	GGL	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0004

JAP	RX350	GGL	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018, SP0019, SP0020
JAP	RX350	GGL	All years	PM1 Gateway	✓	✓	✓	✓		SP0005
JAP	RX350	GGL	All years	PM2 Gateway	✓	✓	✓	✓		SP0005
JAP	RX350	GGL	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	RX350	GGL	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	RX350	GGL	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	RX350	GGL	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	RX350	GGL	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	RX350	GGL	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

JAP	RX350	GGL	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
JAP	RX350	GGL	All years	Master Switch	✓	✓	✓		
JAP	RX350	GGL	All years	Sliding Roof	✓	✓	✓		0529
JAP	RX350	GGL	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
JAP	RX350	GGL	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,
JAP	RX350	GGL	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RX350	GGL	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612

JAP	RX350	GGL	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
JAP	RX350	GGL	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	RX350	GGL	All years	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0201
JAP	RX350	GGL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	SP0045
JAP	RX350	GGL	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
JAP	RX350	GGL	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
JAP	RX350	GGL	All years	Charging Control	✓	✓	✓	✓	0258, 1613	
JAP	RX350	GGL	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	RX350	GGL	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0069
JAP	RX350	GGL	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	RX350	GGL	All years	Pre-Crash	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0040, SP0044, SP0199, SP0200

JAP	RX450h	GYL	All years	Engine and ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0101, SP0103, SP0104, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0198
JAP	RX450h	GYL	All years	HV	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 0117, 1577, 1578	SP0003, SP0004, SP0005, SP0024, SP0025
JAP	RX450h	GYL	All years	Cruise Control	✓	✓	✓	✓		
JAP	RX450h	GYL	All years	Air suspension	✓	✓	✓	✓	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	SP0001, SP0004, SP0007



JAP	RX450h	GYL	All years	Front Stabilizer	✓	✓	✓		0527	
JAP	RX450h	GYL	All years	Rear Stabilizer	✓	✓	✓		0527	
JAP	RX450h	GYL	All years	ABS-VSC-TRC (TRAC)	✓	✓	✓	✓	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	RX450h	GYL	All years	EMPS	✓	✓	✓	✓		SP0001, SP0004, SP0009, SP0010
JAP	RX450h	GYL	All years	Intelligent Parking Assist (IPA) Back Guide Monitor	✓	✓	✓	✓		

JAP	RX450h	GYL	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	SP0016, SP0017, SP0051
JAP	RX450h	GYL	All years	Supplement Restraint System (SRS) Airbag	✓	✓	✓	✓		SP0004

JAP	RX450h	GYL	All years	Main Body	✓	✓	✓	✓	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	SP0005, SP0018, SP0019, SP0020
JAP	RX450h	GYL	All years	PM1 Gateway	✓	✓	✓	✓		SP0005
JAP	RX450h	GYL	All years	PM2 Gateway	✓	✓	✓	✓		SP0005
JAP	RX450h	GYL	All years	Back Door	✓	✓	✓	✓	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	RX450h	GYL	All years	Driver Door Motor	✓	✓	✓		0528	
JAP	RX450h	GYL	All years	Passenger Door Motor	✓	✓	✓		0528	
JAP	RX450h	GYL	All years	Left Rear Door Motor	✓	✓	✓		0528	
JAP	RX450h	GYL	All years	Right Rear Door Motor	✓	✓	✓		0528	
JAP	RX450h	GYL	All years	Driver Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	

JAP	RX450h	GYL	All years	Passenger Seat	✓	✓	✓	✓	0026, 0421, 0422, 0423, 0424, 0425, 0513, 0514, 0515, 0516, 0517, 0519
JAP	RX450h	GYL	All years	Master Switch	✓	✓	✓		
JAP	RX450h	GYL	All years	Sliding Roof	✓	✓	✓		0529
JAP	RX450h	GYL	All years	Tilt&Telescopic	✓	✓	✓	✓	0472, 0473
JAP	RX450h	GYL	All years	Combination Meter	✓	✓	✓	✓	0398, 0616, 0617, 0618, 0619, 0620, 0621, 0622, 0624, 0625, 0626, 0627, 0628, 0629, 0630, 0632, 0633, 0634, 0635, 0636, 0637, 0638, 0639, 0640, 0641, 0642, 0643, 0644, 0645, 0646, 0647, 0648, 0649, 0650, 0651, 0652, 0653, 0654, 0655, 0656, 0657, 0658, 0659, 0660, 0661, 0662, 0663, 0664, 0665, 0666, 0667, 0668, 0669, 0670, 0672, 0673, 0674, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0682, 0683,
JAP	RX450h	GYL	All years	Right Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	RX450h	GYL	All years	Left Mirror	✓	✓	✓	✓	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612

JAP	RX450h	GYL	All years	Intuitive Parking Assist	✓	✓	✓	✓	0023, 0024, 0025, 0026	SP0006
JAP	RX450h	GYL	All years	AFS	✓	✓	✓	✓	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	RX450h	GYL	All years	Smart Key	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	SP0011, SP0012, SP0013, SP0014, SP0201
JAP	RX450h	GYL	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	SP0045
JAP	RX450h	GYL	All years	Remote Engine Starter	✓	✓	✓	✓		SP0046
JAP	RX450h	GYL	All years	Navigation System	✓	✓	✓	✓		SP0050
JAP	RX450h	GYL	All years	Radar Cruise	✓	✓	✓	✓		SP0061, SP0069
JAP	RX450h	GYL	All years	Pre-Collision	✓	✓	✓	✓	0347, 0348, 0349, 0350	
JAP	RX450h	GYL	All years	Pre-Crash	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	SP0005, SP0038, SP0039, SP0040, SP0044, SP0199, SP0200

JAP	RX450h	GYL	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	
JAP	RX450h	GYL	All years	Hybrid Control	✓	✓	✓	✓	0068, 0069, 0070, 0071, 0072, 0073, 0074, 0075, 0076, 0077, 0078, 0079, 0080, 0081, 1577, 1578	
JAP	RX450h	GYL	All years	Tire Pressure Monitor	✓	✓	✓			
JAP	RX450h	GYL	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397	
JAP	RX450h	GYL	All years	Front Recognition Camera	✓	✓	✓	✓	0052	

JAP	RX450h	GYL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA)	√	√	√	√	0823, 0824	
JAP	RX450h	GYL	All years	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA) (Sub)				√		
JAP	RX450h	GYL	All years	Panoramic View Monitor	√	√	√	√		
JAP	RX450h	GYL	All years	Accessory Gateway	√	√	√	√		
JAP	RX450h	GYL	All years	Central Gateway	√	√	√	√		
JAP	RX450h	GYL	All years	Sliding Sunshade	√	√	√		1181	
JAP	RX450h	GYL	All years	Head Up Display	√	√	√	√	0047, 0048, 0049, 0050, 0051	
JAP	RX450h	GYL	All years	Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar	√	√	√	√	0023, 0024, 0025, 0026	
JAP	RX450h	GYL	All years	Rain Sensor	√	√	√			
JAP	RX450h	GYL	All years	Wiper	√	√	√	√	0031, 0032	
JAP	RX450h	GYL	All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	RX450h	GYL	All years	Master Blind Spot Monitor	√	√	√	√		

JAP	RX450h	GYL	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
JAP	RX450h	GYL	All years	Notification System Of Vehicle Proximity	✓	✓	✓		0044, 0045, 0046	
JAP	RX450h	GYL	All years	Connection Of ITS	✓	✓	✓	✓		
JAP	RX450h	GYL	All years	Radar Cruise 1	✓	✓	✓	✓		
JAP	RX450h	GYL	All years	Radar Cruise 2	✓	✓	✓	✓	1504, 1505	
JAP	RX450h	GYL	All years	Parking Assist Camera	✓	✓	✓	✓		
JAP	RX450h	GYL	All years	Pre-Crash 2	✓	✓	✓	✓	0016, 0017, 0018, 0020, 0021, 0022, 0298	
JAP	RX450h	GYL	All years	Rain and/or Humidity Sensor	✓	✓	✓			
JAP	RX450h	GYL	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	RX450h	GYL	All years	Lane Control	✓	✓	✓		0824, 0989	
JAP	RX450h	GYL	All years	Pre-Collision System	✓	✓	✓		1524, 1525, 1526	
JAP	RX450h	GYL	All years	Road Sign Assist	✓	✓	✓			
JAP	RX450h	GYL	All years	Front Recognition Camera (Front Lighting Control)	✓	✓	✓			
JAP	RX450h	GYL	All years	Front Radar Sensor	✓	✓	✓			



JAP	RX450h	GYL	All years	Vehicle proximity notification system	✓	✓	✓	✓			
JAP	RX450h	GYL	All years	Telematics	✓	✓	✓		1521, 1522		
JAP	SC430	UZZ	All years	Engine	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0118, 0122, 0124, 0125, 0130, 0131, 0135, 0137, 0138, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0151, 0152, 0154, 0155, 0156, 0159, 0160, 0161, 0162, 0163, 0164, 0165,	SP0003, SP0004, SP0027, SP0029, SP0030, SP0031, SP0032, SP0101, SP0103, SP0104, SP0106, SP0107, SP0108, SP0109, SP0110, SP0111, SP0113, SP0198	

JAP	SC430	UZZ	All years	ECT	✓	✓	✓	✓	0071, 0079, 0080, 0081, 0082, 0084, 0085, 0086, 0087, 0088, 0089, 0096, 0097, 0100, 0101, 0102, 0103, 0104, 0105, 0106, 0107, 0108, 0110, 0111, 0112, 0113, 0118, 0122, 0124, 0125, 0149, 0159, 0161, 0162, 0163, 0164, 0165, 0166, 0167, 0168, 0170, 0171, 0172, 0173, 0174, 0175, 0179, 0180, 0181, 0182, 0183, 0184, 0185, 0186, 0187, 0188, 0189, 0190, 0191, 0192, 0193, 0194, 0195, 0196, 0197, 0198,	SP0003, SP0004, SP0030, SP0032, SP0101
JAP	SC430	UZZ	All years	Cruise Control	✓	✓	✓	✓		

JAP	SC430	UZZ	All years	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)	√	√	√	√	0839, 0843, 0844, 0854, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0867, 0876, 0889, 0896, 0897, 0898, 0907, 0911, 1104, 1106, 1670, 1671, 1672, 1673, 1674, 1675, 1729, 1730, 1731, 1732, 1733, 1734, 1735, 1736, 1737, 1738, 1739, 1740, 1741, 1742, 1743, 1744, 1745, 1746, 1747, 1748, 1749, 1750, 1751, 1752, 1753, 1754, 1755, 1756, 1757, 1758, 1759, 1760, 1761, 1762, 1763, 1764, 1765	SP0001, SP0003, SP0004, SP0021, SP0022, SP0023, SP0024
JAP	SC430	UZZ	All years	Tire Pressure Monitor	√	√	√			SP0001, SP0002, SP0004
JAP	SC430	UZZ	All years	Air Conditioner	√	√	√		0556, 0557, 0558, 0561, 0562, 0573, 0594, 0598, 0599, 0615, 1016, 1017, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1703, 1704, 1705, 1706, 1707, 1708, 1709, 1710, 1711, 1712, 1713, 1714	SP0017
JAP	SC430	UZZ	All years	Immobiliser	√	√	√		0501, 1690, 1691, 1692, 1693, 1694, 1695, 1696, 1697, 1698, 1699	SP0014, SP0066, SP0145

JAP	SC430	UZZ	All years	Security	√	√	√	0333, 0498, 0501, 0993, 0994, 0995, 0996, 0997, 0998, 0999, 1002, 1700, 1701, 1702	SP0066, SP0196, SP0205
JAP	SC430	UZZ	All years	Supplement Restraint System (SRS) Airbag	√	√	√		SP0004
JAP	SC430	UZZ	All years	Gateway	√	√	√		SP0005
JAP	SC430	UZZ	All years	Body No. 2	√	√	√	0319, 0500, 0783, 0784, 0785, 0815, 0816, 0913, 0917, 0918, 0919, 0926, 0933, 1682	
JAP	SC430	UZZ	All years	Body No. 3	√	√	√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0805, 0917, 0918, 0931, 0944, 0945, 0946, 0947, 0948, 0949, 0950, 0952, 0953, 0955, 0956, 0957, 0958, 0959, 0961, 0962, 0967, 1678, 1679, 1680, 1681	
JAP	SC430	UZZ	All years	Body No. 4	√		√	0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0325, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0929, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681	

JAP	SC430	UZZ	All years	Body No. 5			√		0031, 0032, 0312, 0313, 0314, 0315, 0316, 0320, 0321, 0329, 0330, 0332, 0337, 0338, 0917, 0918, 0931, 0953, 0955, 0956, 0957, 0958, 0961, 0962, 0967, 1678, 1679, 1680, 1681, 1689	
JAP	SC430	UZZ	All years	Driver Door	√	√	√		0279, 0280, 0281, 0282, 0283, 0317, 0429, 0437, 0528, 0991	
JAP	SC430	UZZ	All years	Passenger Door	√	√	√		0279, 0280, 0281, 0282, 0283, 0317, 0429, 0430, 0437, 0528, 0991	
JAP	SC430	UZZ	All years	Driver Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	SC430	UZZ	All years	Passenger Seat			√		0422, 0423, 0424, 0515, 0516, 0517	
JAP	SC430	UZZ	All years	Hardtop Retractable	√	√	√		0970	
JAP	SC430	UZZ	All years	Tilt&Telescopic	√	√	√	√	0472, 0473, 1005	

JAP	SC430	UZZ	All years	Combination Meter			√		0274, 0616, 0617, 0618, 0619, 0629, 0669, 0670, 0672, 0673, 0675, 0676, 0677, 0678, 0679, 0680, 0681, 0719, 0745, 0746, 0749, 0756, 0760, 0761, 0762, 0763, 0764, 0765, 0766, 0767, 0768, 0769, 0770, 0771, 0772, 0775, 0776, 0777, 0778, 0779, 0780, 0781, 0782, 1000, 1029, 1030, 1031, 1032, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044, 1045, 1046, 1048, 1049, 1050, 1051, 1052,	
JAP	SC430	UZZ	All years	Combination Switch			√			
JAP	SC430	UZZ	All years	Switch Of Steering Pad			√			
JAP	SC430	UZZ	All years	AFS	√	√	√		0008, 0009, 0475, 1683, 1684, 1685	
JAP	SC430	UZZ	All years	Accessory Gateway	√	√	√	√		SP0005

JAP	UX200	MZAA10	All years	Engine	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0155, 0158, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227,
-----	-------	--------	-----------	--------	---	---	---	---	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

JAP	UX200	MZAA10	All years	Transmission	✓	✓	✓	✓	0071, 0080, 0081, 0110, 0111, 0114, 0137, 0149, 0168, 0180, 0182, 0185, 0187, 0188, 0190, 0191, 0192, 0193, 0194, 0195, 0204, 0206, 0211, 0236, 0237, 0249, 0250, 0254, 0258, 0262, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229,	
JAP	UX200	MZAA10	All years	Stop and Start	✓	✓	✓		1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492	
JAP	UX200	MZAA10	All years	Radar Cruise 1	✓	✓	✓	✓		
JAP	UX200	MZAA10	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	



JAP	UX200	MZAA10	All years	Adaptive Variable Suspension (AVS) System	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646	
JAP	UX200	MZAA10	All years	Brake/EPB	√	√	√		0471, 0830, 0839, 0887, 0911, 1498, 1499, 1500, 1501, 1502, 1503	
JAP	UX200	MZAA10	All years	Tire Pressure Monitor	√	√	√			
JAP	UX200	MZAA10	All years	EMPS	√	√	√	√		
JAP	UX200	MZAA10	All years	Front Recognition Camera	√	√	√			
JAP	UX200	MZAA10	All years	Panoramic View Monitor	√	√	√	√		
JAP	UX200	MZAA10	All years	Lane Control	√	√	√		0824, 0989	
JAP	UX200	MZAA10	All years	Steering Angle Sensor	√	√	√			
JAP	UX200	MZAA10	All years	Parking Assist Camera	√	√	√	√		

JAP	UX200	MZAA10	All years	Air Conditioner	√	√	√	√	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661	
JAP	UX200	MZAA10	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		
JAP	UX200	MZAA10	All years	Pre-Collision System	√	√	√		1524, 1525, 1526	

JAP	UX200	MZAA10	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	UX200	MZAA10	All years	Accessory Gateway	√	√	√	√		
JAP	UX200	MZAA10	All years	Central Gateway	√	√	√	√		
JAP	UX200	MZAA10	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	UX200	MZAA10	All years	Driver Door Motor	√	√	√		0528	
JAP	UX200	MZAA10	All years	Passenger Door Motor	√	√	√		0528	
JAP	UX200	MZAA10	All years	Left Rear Door Motor	√	√	√		0528	
JAP	UX200	MZAA10	All years	Right Rear Door Motor	√	√	√		0528	
JAP	UX200	MZAA10	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	UX200	MZAA10	All years	Master Switch	√	√	√			

JAP	UX200	MZAA10	All years	Sliding Roof	√	√	√		0529	
JAP	UX200	MZAA10	All years	Tilt&Telescopic	√	√	√		1513, 1514	
JAP	UX200	MZAA10	All years	Combination Meter	√	√	√		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
JAP	UX200	MZAA10	All years	Head Up Display	√	√	√		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
JAP	UX200	MZAA10	All years	Road Sign Assist	√	√	√			
JAP	UX200	MZAA10	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	UX200	MZAA10	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612	
JAP	UX200	MZAA10	All years	Clearance Warning	√	√	√		0023, 0024	

JAP	UX200	MZAA10	All years	Rain and/or Humidity Sensor	√	√	√			
JAP	UX200	MZAA10	All years	Wiper	√	√	√	√	0031, 0032	
JAP	UX200	MZAA10	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493	
JAP	UX200	MZAA10	All years	Adaptive Front Lighting System (AFS) (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028	
JAP	UX200	MZAA10	All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015	
JAP	UX200	MZAA10	All years	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0006	
JAP	UX200	MZAA10	All years	Front Recognition Camera (Front Lighting Control)	√	√	√			
JAP	UX200	MZAA10	All years	Entry&Start	√	√	√	√	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	

JAP	UX200	MZAA10	All years	Power Source Control	√	√	√	√	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	UX200	MZAA10	All years	Remote Engine Starter	√	√	√	√		
JAP	UX200	MZAA10	All years	Starting Control	√	√	√	√	0256, 0257	
JAP	UX200	MZAA10	All years	Navigation System	√	√	√	√		
JAP	UX200	MZAA10	All years	Front Radar Sensor	√	√	√			
JAP	UX200	MZAA10	All years	Master Blind Spot Monitor	√	√	√	√		
JAP	UX200	MZAA10	All years	Slave Blind Spot Monitor	√	√	√	√		
JAP	UX200	MZAA10	All years	ASC	√	√	√	√	1182	
JAP	UX200	MZAA10	All years	Connection Of ITS	√	√	√	√		

JAP	UX250h/U X260h	MZAH1 #	All years	Engine	✓	✓	✓	✓	0071, 0080, 0 081, 0110, 01 11, 0114, 013 7, 0149, 0155 , 0158, 0168, 0180, 0182, 0 185, 0187, 01 88, 0190, 019 1, 0192, 0193 , 0194, 0195, 0204, 0206, 0 211, 0236, 02 37, 0249, 025 0, 0254, 0258 , 0262, 1194, 1195, 1196, 1 197, 1198, 11 99, 1200, 120 1, 1202, 1203 , 1204, 1205, 1206, 1207, 1 208, 1209, 12 10, 1211, 121 2, 1213, 1214 , 1215, 1216, 1217, 1218, 1 219, 1220, 12 21, 1222, 122 3, 1224, 1225 , 1226, 1227,	
JAP	UX250h/U X260h	MZAH1 #	All years	Hybrid Control	✓	✓	✓	✓		
JAP	UX250h/U X260h	MZAH1 #	All years	Motor Generator	✓	✓	✓	✓		
JAP	UX250h/U X260h	MZAH1 #	All years	Rear Motor Generator	✓	✓	✓	✓		
JAP	UX250h/U X260h	MZAH1 #	All years	Radar Cruise 1	✓	✓	✓			
JAP	UX250h/U X260h	MZAH1 #	All years	Radar Cruise 2	✓	✓	✓		1504, 1505	

JAP	UX250h/UX260h	MZAH1#	All years	Adaptive Variable Suspension (AVS) System	√	√	√	√	0441, 0442, 0464, 0465, 0466, 0469, 0470, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646
JAP	UX250h/UX260h	MZAH1#	All years	ABS/VSC/TRC (TRAC)	√	√	√	√	0026, 0376, 0377, 0379, 0380, 0382, 0383, 0821, 0822, 0826, 0827, 0828, 0829, 0832, 0833, 0834, 0835, 0836, 0837, 0838, 0839, 0840, 0841, 0842, 0843, 0844, 0845, 0846, 0847, 0848, 0849, 0851, 0852, 0853, 0854, 0855, 0856, 0857, 0858, 0859, 0860, 0861, 0862, 0863, 0864, 0865, 0866, 0867, 0868, 0869, 0870, 0871, 0872, 0873, 0874, 0876, 0877, 0884, 0885, 0886, 0887, 0888, 0889, 0890, 0891, 0892,
JAP	UX250h/UX260h	MZAH1#	All years	Tire Pressure Monitor	√	√	√		
JAP	UX250h/UX260h	MZAH1#	All years	EMPS	√	√	√	√	



JAP	UX250h/UX260h	MZAH1#	All years	Electric Parking Brake	✓	✓	✓	✓	0376, 0377, 0378, 0379, 0380, 0381, 0382, 0383, 0384, 0385, 0386, 0387, 0388, 0389, 0390, 0391, 0392, 0393, 0394, 0395, 0396, 0397
JAP	UX250h/UX260h	MZAH1#	All years	Front Recognition Camera	✓	✓	✓		
JAP	UX250h/UX260h	MZAH1#	All years	Panoramic View Monitor	✓	✓	✓	✓	
JAP	UX250h/UX260h	MZAH1#	All years	Lane Control	✓	✓	✓		0824, 0989
JAP	UX250h/UX260h	MZAH1#	All years	Steering Angle Sensor	✓	✓	✓		
JAP	UX250h/UX260h	MZAH1#	All years	Parking Assist Camera	✓	✓	✓	✓	
JAP	UX250h/UX260h	MZAH1#	All years	Air Conditioner	✓	✓	✓	✓	0556, 0557, 0558, 0560, 0561, 0563, 0564, 0565, 0566, 0567, 0568, 0569, 0570, 0571, 0572, 0574, 0575, 0576, 0577, 0578, 0579, 0580, 0581, 0582, 0583, 0584, 0585, 0586, 0588, 0594, 0599, 0600, 0601, 0602, 0603, 0604, 0605, 0606, 0607, 0608, 0609, 0610, 0611, 0612, 0613, 0614, 0615, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661

JAP	UX250h/UX260h	MZAH1#	All years	Supplement Restraint System (SRS) Airbag	√	√	√	√		
JAP	UX250h/UX260h	MZAH1#	All years	Pre-Collision System	√	√	√		1524, 1525, 1526	
JAP	UX250h/UX260h	MZAH1#	All years	Main Body	√	√	√	√	0005, 0282, 0300, 0301, 0317, 0319, 0333, 0335, 0337, 0339, 0426, 0427, 0429, 0433, 0434, 0435, 0436, 0490, 0496, 0497, 0498, 0499, 0500, 0501, 0502, 0783, 0784, 0785, 0786, 0787, 0788, 0789, 0790, 0791, 0792, 0793, 0796, 0797, 0798, 0799, 0800, 0801, 0803, 0804, 0805, 0806, 0807, 0808, 0809, 0810, 0811, 0812, 0813, 0815, 0816, 0817, 0818, 1665, 1666, 1667, 1668	
JAP	UX250h/UX260h	MZAH1#	All years	Accessory Gateway	√	√	√	√		
JAP	UX250h/UX260h	MZAH1#	All years	Central Gateway	√	√	√	√		
JAP	UX250h/UX260h	MZAH1#	All years	Back Door	√	√	√	√	0520, 0521, 0522, 0523, 0524, 0525, 0526	
JAP	UX250h/UX260h	MZAH1#	All years	Driver Door Motor	√	√	√		0528	
JAP	UX250h/UX260h	MZAH1#	All years	Passenger Door Motor	√	√	√		0528	
JAP	UX250h/UX260h	MZAH1#	All years	Left Rear Door Motor	√	√	√		0528	

JAP	UX250h/UX260h	MZAH1#	All years	Right Rear Door Motor	√	√	√		0528	
JAP	UX250h/UX260h	MZAH1#	All years	Driver Seat	√	√	√	√	0026, 0421, 0422, 0423, 0424, 0513, 0514, 0515, 0516, 0517, 0518, 0519	
JAP	UX250h/UX260h	MZAH1#	All years	Master Switch	√	√	√			
JAP	UX250h/UX260h	MZAH1#	All years	Sliding Roof	√	√	√		0529	
JAP	UX250h/UX260h	MZAH1#	All years	Tilt&Telescopic	√	√	√		1513, 1514	
JAP	UX250h/UX260h	MZAH1#	All years	Combination Meter	√	√	√		0274, 0398, 0475, 0488, 0620, 0624, 0626, 0627, 0638, 0648, 0650, 0651, 0652, 0656, 0657, 0659, 0660, 0670, 0671, 0675, 0676, 0684, 0686, 0690, 0693, 0701, 0702, 0704, 0710, 0723, 0724, 0728, 0729, 0730, 0731, 0732, 0734, 0735, 0736, 0737, 0752, 0753, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256,	
JAP	UX250h/UX260h	MZAH1#	All years	Head Up Display	√	√	√		0049, 0050, 1506, 1507, 1508, 1509, 1510, 1511, 1512	
JAP	UX250h/UX260h	MZAH1#	All years	Road Sign Assist	√	√	√			

JAP	UX250h/UX260h	MZAH1#	All years	Right Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	UX250h/UX260h	MZAH1#	All years	Left Mirror	√	√	√	√	0275, 0276, 0277, 0278, 0280, 0281, 0282, 0283, 0284, 0426, 0427, 1612
JAP	UX250h/UX260h	MZAH1#	All years	Clearance Warning	√	√	√		0023, 0024
JAP	UX250h/UX260h	MZAH1#	All years	Rain and/or Humidity Sensor	√	√	√		
JAP	UX250h/UX260h	MZAH1#	All years	Wiper	√	√	√	√	0031, 0032
JAP	UX250h/UX260h	MZAH1#	All years	AFS	√	√	√	√	0007, 0008, 0009, 0474, 0475, 0476, 0477, 0478, 0479, 0480, 0481, 0482, 0483, 0484, 0485, 0486, 0487, 0488, 0489, 0490, 0491, 0492, 0493
JAP	UX250h/UX260h	MZAH1#	All years	Adaptive Front Lighting System (AFS) (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0028
JAP	UX250h/UX260h	MZAH1#	All years	Auto Leveling Of Headlamp	√	√	√	√	0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0013, 0014, 0015
JAP	UX250h/UX260h	MZAH1#	All years	Auto Leveling Of Headlamp (Sub)	√	√	√		0001, 0002, 0003, 0004, 0005, 0006
JAP	UX250h/UX260h	MZAH1#	All years	Front Recognition Camera (Front Lighting Control)	√	√	√		

JAP	UX250h/UX260h	MZAH1#	All years	Entry&Start	✓	✓	✓	✓	0329, 0333, 0496, 0501, 0502, 0530, 0531, 0532, 0533, 0534, 0535, 0536, 0537, 0538, 0539, 0540, 0542, 0543, 0544, 0545, 0546, 0547, 0548, 0549, 0550, 0551, 0552, 0553, 1648	
JAP	UX250h/UX260h	MZAH1#	All years	Power Source Control	✓	✓	✓	✓	0299, 0300, 0301, 1614, 1615, 1616, 1617	
JAP	UX250h/UX260h	MZAH1#	All years	Remote Engine Starter	✓	✓	✓	✓		
JAP	UX250h/UX260h	MZAH1#	All years	Starting Control	✓	✓	✓	✓	0256, 0257	
JAP	UX250h/UX260h	MZAH1#	All years	Navigation System	✓	✓	✓	✓		
JAP	UX250h/UX260h	MZAH1#	All years	Front Radar Sensor	✓	✓	✓			
JAP	UX250h/UX260h	MZAH1#	All years	Master Blind Spot Monitor	✓	✓	✓	✓		
JAP	UX250h/UX260h	MZAH1#	All years	Slave Blind Spot Monitor	✓	✓	✓	✓		
JAP	UX250h/UX260h	MZAH1#	All years	Vehicle proximity notification system	✓	✓	✓	✓		
JAP	UX250h/UX260h	MZAH1#	All years	ASC	✓	✓	✓	✓	1182	
JAP	UX250h/UX260h	MZAH1#	All years	Connection Of ITS	✓	✓	✓	✓		

# Actuation Test List

No.	Actuation Test Name	System Name
0001	Cleaner Of Headlight	Adaptive Front Lighting System (AFS) (Sub), Auto Leveling Of Headlamp, Auto Leveling Of Headlamp (Sub)
0002	Clearance Light	Adaptive Front Lighting System (AFS) (Sub), Auto Leveling Of Headlamp, Auto Leveling Of Headlamp (Sub)
0003	Low Beam Of Headlight	Adaptive Front Lighting System (AFS) (Sub), Auto Leveling Of Headlamp, Auto Leveling Of Headlamp (Sub)
0004	High Beam Of Headlight	Adaptive Front Lighting System (AFS) (Sub), Auto Leveling Of Headlamp, Auto Leveling Of Headlamp (Sub)
0005	Daytime Running Light (DRL)	Main Body, Adaptive Front Lighting System (AFS) (Sub), Auto Leveling Of Headlamp, Auto Leveling Of Headlamp (Sub)
0006	Cornering Light	Auto Leveling Of Headlamp, Auto Leveling Of Headlamp (Sub)
0007	Drive The Leveling Motor UP	Auto Leveling Of Headlamp, AFS
0008	Drive The Leveling Motor	Auto Leveling Of Headlamp, AFS
0009	Drive The Leveling Motor Down	Auto Leveling Of Headlamp, AFS
0010	Headlight Indicator	Auto Leveling Of Headlamp
0011	Leveling Indicator Of Headlight	Auto Leveling Of Headlamp
0012	Electronic Control Unit (ECU) State Indicator	Auto Leveling Of Headlamp
0013	Front Fog Light	Auto Leveling Of Headlamp
0014	Right Turn Signal Light	Auto Leveling Of Headlamp
0015	Left Turn Signal Light	Auto Leveling Of Headlamp
0016	Face Direction Check	Pre-Crash 2, Pre-Collision 2, Automatic high beam, Pre-Crash
0017	Radar Cruise Stop Buzzer	Radar Cruise 2, Pre-Crash 2, Radar Cruise, Pre-Collision 2, Cruise Control, Automatic high beam, Pre-Crash
0018	Radar Cruise Approach Alarm Buzzer	Radar Cruise 2, Pre-Crash 2, Radar Cruise, Pre-Collision 2, Cruise Control, Automatic high beam, Pre-Crash
0019	Pre-Collision System (PCS) Collision Alarm Buzzer	Pre-Collision 2
0020	Pre-Collision System (PCS) Approach Alarm Buzzer	Pre-Crash 2, Pre-Collision 2, Automatic high beam, Pre-Crash
0021	Lane-Keeping Assist (LKA) Lane Out Alarm Buzzer	Pre-Crash 2, Pre-Collision 2, Automatic high beam, Pre-Crash
0022	State Of Infrared Signal	Pre-Crash 2, Pre-Collision 2, Automatic high beam, Pre-Crash

0023	Front Buzzer	Clearance Sonar, Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar, Clearance Warning, Intuitive Parking Assist, Advanced Parking Guidance/Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A)
0024	Rear Buzzer	Clearance Sonar, Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar, Clearance Warning, Intuitive Parking Assist, Advanced Parking Guidance/Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A)
0025	Front/Rear Buzzer	Clearance Sonar, Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar, Intuitive Parking Assist, Advanced Parking Guidance/Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A)
0026	Buzzer	ABS/VSC/TRC, Driver Seat, Clearance Sonar, Stop and Start, Passenger Seat, Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar, ABS/VSC/TRC/EPB, Left Rear Seat, Right Rear Seat, ABS/VSC/TRAC, Intuitive Parking Assist, Advanced Parking Guidance/Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A), Radar Cruise 1, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), Stop&Start, ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC)/EPB
0027	Sliding Sunshade - Rear	Sliding Sunshade - Rear
0028	Cornering Light/Front Side Illuminate Light	Adaptive Front Lighting System (AFS) (Sub), Auto Leveling Of Headlamp (Sub)
0029	Protection Relay	Sub Battery Module
0030	Backup Relay	Sub Battery Module
0031	Wiper Moter - Low	Wiper, Body, Gateway, Body No. 3, Body No. 4, Body No. 5, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0032	Wiper Moter - High	Wiper, Body, Gateway, Body No. 3, Body No. 4, Body No. 5, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0033	Front Washer	Wiper
0034	Rear Washer	Wiper
0035	Automatic High Beam	Automatic high beam, Automatic High Beam
0036	Beep	Telematics
0037	Lock Detection Of Shutter Opening Operation	Grill Shutter, Grill shutter
0038	Fixed Length Of Shutter Closing Operation	Grill Shutter, Grill shutter
0039	Fixed Length Of Shutter Opening Operation	Grill Shutter, Grill shutter

0040	Lock Detection Of Shutter Closing Operation	Grill Shutter, Grill shutter
0041	Shutter Half-Open Operation	Grill shutter
0042	Right-Hand Motor	TVD
0043	Left-Hand Motor	TVD
0044	Proximity Sound Indicator	Notification System Of Vehicle Proximity, Vehicle proximity notification system
0045	Proximity Sound (Vehicle Stationary)	Notification System Of Vehicle Proximity, Vehicle proximity notification system
0046	Proximity Sound - Low Speed	Notification System Of Vehicle Proximity, Vehicle proximity notification system
0047	Indicator - Main	Head Up Display
0048	Navigation Indicator	Head Up Display
0049	Display Brightness	Head Up Display
0050	Display Position	Head Up Display
0051	Color Test Screen	Head Up Display
0052	Pre-Collision System (PCS) Buzzer	Front Recognition Camera
0053	Left Rear Personal Light 2 Modulated Light	ILLUMINATION
0054	Lounge Mode	ILLUMINATION
0055	Left Rear Personal Light 2	ILLUMINATION
0056	Right Rear Personal Light 1 Modulated Light	ILLUMINATION
0057	Right Rear Personal Light 2 Modulated Light.	ILLUMINATION
0058	Left Rear Personal Light 1 Modulated Light	ILLUMINATION
0059	Color Light-Emitting Diode (LED) (Blue) Modulated Light.	ILLUMINATION
0060	Right Rear Personal Light 1	ILLUMINATION
0061	Right Rear Personal Light 2	ILLUMINATION
0062	Left Rear Personal Light 1	ILLUMINATION
0063	Color Light-Emitting Diode (LED) (Green)	ILLUMINATION
0064	Color Light-Emitting Diode (LED) (Blue)	ILLUMINATION
0065	Color Light-Emitting Diode (LED) (Yellow) Modulated Light.	ILLUMINATION
0066	Color Light-Emitting Diode (LED) (Green) Modulated Light.	ILLUMINATION
0067	Color Light-Emitting Diode (LED) (Yellow)	ILLUMINATION
0068	Battery Charge	Hybrid Control, HV



0069	Forcible Stop of Inverter Drive	Hybrid Control, HV
0070	Compression Test	Hybrid Control, EV, HV
0071	Activate the Solenoid (SL1)	Engine and ECT, Hybrid Control, Engine, Transmission, ECT, Engine2, EV, HV
0072	Activate the solenoid (Line Pressure)	Hybrid Control, HV
0073	Oil Pump Of T/M Cooler	Hybrid Control, HV
0074	Activate the (Inverter) Water Pump	Hybrid Control, HV
0075	Driving the Battery Cooling Fan	Hybrid Control, HV
0076	Activate the Oil Pump(500rpm)	Hybrid Control, HV
0077	Discharging Battery to Check Weak Cells	Hybrid Control, HV
0078	Activate the Oil Pump(1000rpm)	Hybrid Control, HV
0079	Connect the TC and TE1	Engine and ECT, Hybrid Control, Engine, ECT, Engine2, EV, HV
0080	Control the Shift Position	Engine and ECT, Hybrid Control, Engine, Transmission, ECT, Engine2, HV
0081	Activate the Solenoid (SL2)	Engine and ECT, Hybrid Control, Engine, Transmission, ECT, Engine2, EV, HV
0082	Check HICM System	Engine and ECT, Engine, ECT, Engine2
0083	Control the Injection Volume for A/F Sensor (CNG)	Engine and ECT, Engine, ECT, Engine2
0084	Control the Injection Volume (CNG)	Engine and ECT, Engine, ECT, Engine2
0085	Control the Regulator Shut Valve	Engine and ECT, Engine, ECT, Engine2
0086	Control the Select Cylinder Fuel Cut (CNG)	Engine and ECT, Engine, ECT, Engine2
0087	Inspection Of Brake Ejector Vacuum Switching Valve (VSV)	Engine and ECT, Engine, ECT, Engine2
0088	Control the All Cylinders Fuel Cut (CNG)	Engine and ECT, Engine, ECT, Engine2
0089	Control the ISC Step Position	Engine and ECT, Engine, ECT, Engine2
0090	Injection Timing Select Cylinder	Engine and ECT, Engine
0091	Value Of Pilot Injection Volume	Engine and ECT, Engine
0092	Select Cylinder Pilot Injection Volume	Engine and ECT, Engine
0093	Injection Timing	Engine and ECT, Engine
0094	Value Of Injection Timing	Engine and ECT, Engine
0095	Pilot Injection Volume	Engine and ECT, Engine
0096	Activate the Solenoid(SC)	Engine and ECT, Engine, ECT, Engine2
0097	Activate the Solenoid(SLP)	Engine and ECT, Engine, ECT, Engine2

0098	Target Angle Of Diesel Throttle - #2	Engine and ECT, Engine, Engine2
0099	Test the Turbo Charger Step Motor #2	Engine and ECT, Engine, Engine2
0100	Activate the Fuel Route Switching Valve Relay	Engine and ECT, Engine, ECT, Engine2
0101	Activate the Intank Fuel Pump Relay	Engine and ECT, Engine, ECT, Engine2
0102	Activate the Fuel Return Pipe Valve	Engine and ECT, Engine, ECT, Engine2
0103	Activate the VN Turbo Open	Engine and ECT, Engine, ECT, Engine2
0104	Activate the Solenoid (SLN)	Engine and ECT, Engine, ECT, Engine2
0105	Activate the Air Pump Heater	Engine and ECT, Engine, ECT, Engine2
0106	Activate the Brake Ejector VSV	Engine and ECT, Engine, ECT, Engine2
0107	Activate the Solenoid (DSU)	Engine and ECT, Engine, ECT, Engine2
0108	Activate the Solenoid (SLC)	Engine and ECT, Engine, ECT, Engine2
0109	Activate the VSV for Swirl Control Valve	Engine and ECT, Engine, ECT, Engine2
0110	Control the All Cylinders Fuel Cut	Engine and ECT, Engine, Transmission, ECT, Engine2
0111	Check the Cylinder Compression	Engine and ECT, Engine, Transmission, ECT, Engine2
0112	Test the Turbo Charger Step Motor	Engine and ECT, Engine, ECT, Engine2
0113	Target Angle Of Diesel Throttle	Engine and ECT, Engine, ECT, Engine2
0114	Control the Select Cylinder Fuel Cut	Engine and ECT, Engine, Transmission, Engine2
0115	Activate the Water Flow Valve 2	Engine and ECT, Engine, ECT, Engine2
0116	Activate the Water Flow Valve 1	Engine and ECT, Engine, ECT, Engine2
0117	Activate the Water Pump	Engine and ECT, Engine, ECT, Hybrid Control, Engine2, HV
0118	Control the VVT-iE Linear (Bank2)	Engine and ECT, Engine, ECT, Engine2
0119	Activate the Water Flow Valve 5	Engine and ECT, Engine, ECT, Engine2
0120	Activate the Water Flow Valve 4	Engine and ECT, Engine, ECT, Engine2
0121	Activate the Water Flow Valve 3	Engine and ECT, Engine, ECT, Engine2
0122	Control the VVT-iE Linear (Bank1)	Engine and ECT, Engine, ECT, Engine2
0123	Activate the VSV for Canister Control	Engine and ECT, Engine, ECT, Engine2
0124	Activate the VSV for Exhaust Switching Valve	Engine and ECT, Engine, ECT, Engine2

0125	Control the Fuel Pump / Speed	Engine and ECT, Engine, ECT, Engine2
0126	Control the VVTL System (Bank2)	Engine and ECT, Engine, ECT, Engine2
0127	Control the VVTL System (Bank1)	Engine and ECT, Engine, ECT, Engine2
0128	Activate the VSV for Tank Bypass	Engine and ECT, Engine, ECT, Engine2
0129	Activate the VSV for Evap (Purge)	Engine and ECT, Engine, ECT, Engine2
0130	Activate the VSV for Evap Control	Engine and ECT, Engine, ECT, Engine2
0131	Control the A/C Magnet Clutch	Engine and ECT, Engine, ECT, Engine2
0132	Activate the VSV for Purge Cut	Engine and ECT, Engine, ECT, Engine2
0133	Control the A/C Cut Signal	Engine and ECT, Engine, ECT, Engine2
0134	Activate the VSV2 for Intake Control	Engine and ECT, Engine, ECT, Engine2
0135	Control the VVT System (Bank2)	Engine and ECT, Engine, ECT, Engine2
0136	Activate the VSV for Vapor Pressure	Engine and ECT, Engine, ECT, Engine2
0137	Activate the VSV for Intake Control	Engine and ECT, Engine, Transmission, ECT, Engine2
0138	Control the EGR System	Engine and ECT, Engine, ECT, Engine2
0139	Activate the VSV for Fuel Pressure Up Control	Engine and ECT, Engine, ECT, Engine2
0140	Activate the VSV for Variable Intake Control	Engine and ECT, Engine, ECT, Engine2
0141	Activate the VSV for Turbo Pressure	Engine and ECT, Engine, ECT, Engine2
0142	Manual item 8 and Check Type Support I	Engine and ECT, Engine, Engine2
0143	Manual item 7 and Check Type Support J	Engine and ECT, Engine, Engine2
0144	Manual item 10 and Check Type Support Y	Engine and ECT, Engine, Engine2
0145	Manual item 9 and Check Type Support X	Engine and ECT, Engine, Engine2
0146	Manual item 2 and Check Type Support G	Engine and ECT, Engine, Engine2
0147	Manual item 1 and Check Type Support H	Engine and ECT, Engine, Engine2
0148	Manual item 4 and Check Type Support E	Engine and ECT, Engine, Engine2
0149	Activate the Fuel Vapor-Containment Valve	Engine and ECT, Engine, Transmission, ECT, Engine2
0150	Manual item 3 and Check Type Support F	Engine and ECT, Engine, Engine2
0151	Manual item 6 and Check Type Support C	Engine and ECT, Engine, Engine2
0152	Manual item 5 and Check Type Support D	Engine and ECT, Engine, Engine2

0153	Activate the VSV for Vent Value and Vacuum Pump	Engine and ECT, Engine
0154	Control the Cylinder Fuel Cut	Engine and ECT, Engine
0155	D-4S (Injection Volume)	Engine and ECT, Engine
0156	Injection Volume	Engine and ECT, Engine
0157	Auto item 1	Engine and ECT, Engine, Engine2
0158	D-4S (A/F Control)	Engine and ECT, Engine
0159	Control the Injection Way	Engine and ECT, Engine, ECT, Engine2
0160	D-4S (Fuel Cut)	Engine and ECT, Engine
0161	Activate the VSV for Exhaust Brake	Engine and ECT, Engine, ECT, Engine2
0162	Activate the VSV for EGR Cooler Bypass	Engine and ECT, Engine, ECT, Engine2
0163	Control the Purge Dilution Valve Duty Bank1	Engine and ECT, Engine, ECT, Engine2
0164	Control the Purge Dilution Valve Duty Bank2	Engine and ECT, Engine, ECT, Engine2
0165	Control the Fuel Pump Duty	Engine and ECT, Engine, ECT, Engine2
0166	Activate the VALVEMATIC after Warm Up	Engine and ECT, Engine, ECT, Engine2
0167	Activate the VALVEMATIC before Warm Up	Engine and ECT, Engine, ECT, Engine2
0168	Activate the Electric Water Pump	Engine and ECT, Engine, Transmission, ECT, Engine2
0169	Sub Fuel Tank Vacuum Switching Valve (VSV)	Engine and ECT, Engine, ECT, Engine2
0170	Activate the VALVEMATIC (ENG OFF)	Engine and ECT, Engine, ECT, Engine2
0171	Activate the VALVEMATIC (ENG ON)	Engine and ECT, Engine, ECT, Engine2
0172	Activate the Fuel Pump2 Speed Control	Engine and ECT, Engine, ECT, Engine2
0173	Activate the Return Solenoid Valve	Engine and ECT, Engine, ECT, Engine2
0174	Activate the LPG Solenoid Valve	Engine and ECT, Engine, ECT, Engine2
0175	Activate the Emergency Solenoid Valve	Engine and ECT, Engine, ECT, Engine2
0176	Activate the Fuel Pressure Switching Valve	Engine and ECT, Engine, ECT, Engine2
0177	Activate the VSV for A/C Idle Up Control	Engine and ECT, Engine, ECT, Engine2
0178	Activate the VSV for Exhaust Bypass Control	Engine and ECT, Engine, ECT, Engine2
0179	Activate the Solenoid (SLS)	Engine and ECT, Engine, ECT, Engine2
0180	Activate the Solenoid (SLT)	Engine and ECT, Engine, Transmission, Hybrid Control, ECT, Engine2, EV
0181	Activate the Solenoid (SB)	Engine and ECT, Engine, ECT, Engine2
0182	Activate the Solenoid (SR)	Engine and ECT, Engine, Transmission, ECT, Engine2
0183	Activate the Solenoid (ST)	Engine and ECT, Engine, ECT, Engine2
0184	Control the SLS Pressure	Engine and ECT, Engine, ECT, Engine2

0185	Activate the Solenoid (S1)	Engine and ECT, Engine, Transmission, ECT, Engine2
0186	Activate the Solenoid (DSL)	Engine and ECT, Engine, ECT, Engine2
0187	Activate the Solenoid (SLU)	Engine and ECT, Engine, Transmission, ECT, Engine2
0188	Activate the Solenoid (SL)	Engine and ECT, Engine, Transmission, ECT, Engine2
0189	Activate the Solenoid (DS1)	Engine and ECT, Engine, ECT, Engine2
0190	Activate the Solenoid (S4)	Engine and ECT, Engine, Transmission, ECT, Engine2
0191	Activate the Solenoid (S3)	Engine and ECT, Engine, Transmission, ECT, Engine2
0192	Activate the Solenoid (S2)	Engine and ECT, Engine, Transmission, ECT, Engine2
0193	Activate the Solenoid (SL5)	Engine and ECT, Engine, Transmission, ECT, Engine2
0194	Activate the Solenoid (SL4)	Engine and ECT, Engine, Transmission, Hybrid Control, ECT, Engine2, EV
0195	Activate the Solenoid (SL3)	Engine and ECT, Engine, Transmission, Hybrid Control, ECT, Engine2, EV
0196	Activate the Solenoid (DS2)	Engine and ECT, Engine, ECT, Engine2
0197	Activate the DPF Rejuvenate (S)	Engine and ECT, Engine, ECT, Engine2
0198	Activate the DPF Rejuvenate (PM)	Engine and ECT, Engine, ECT, Engine2
0199	Activate the Lock Up	Engine and ECT, Engine, ECT, Engine2
0200	Check HCAC Vacuum Switching Valve (VSV)	Engine and ECT, Engine, ECT, Engine2
0201	Activate HCAC Vacuum Switching Valve (VSV)	Engine and ECT, Engine, ECT, Engine2
0202	Fuel Pressure Relief Valve Close	Engine and ECT, Engine, ECT, Engine2
0203	Fuel Pressure Relief Valve Open	Engine and ECT, Engine, ECT, Engine2
0204	Activate the Fuel Filler Opener	Engine and ECT, Engine, Transmission, ECT, Engine2
0205	Activate the VSV for EGR Cut	Engine and ECT, Engine, ECT, Engine2
0206	Control the EGR Step Position	Engine and ECT, Engine, Transmission, ECT, Engine2
0207	Activate the EGR Valve Close	Engine and ECT, Engine, ECT, Engine2
0208	Control the EGR Step Position #2	Engine and ECT, Engine, ECT, Engine2
0209	Activate the VSV for Exhaust Shutter	Engine and ECT, Engine, ECT, Engine2
0210	Control the Delivery Shut Valve	Engine and ECT, Engine, ECT, Engine2
0211	Control the ACM Inhibit	Engine and ECT, Engine, Transmission, ECT, Engine2
0212	Control the Lock Up	Engine and ECT, Engine, ECT, Engine2

0213	Activate the VSV for HCAC System	Engine and ECT, Engine, ECT, Engine2
0214	Control the Stratified Charge Combustion	Engine and ECT, Engine, ECT, Engine2
0215	Control the Stoichiometric Ratio Combustion	Engine and ECT, Engine, ECT, Engine2
0216	Control the Line Pressure Up	Engine and ECT, Engine, ECT, Engine2
0217	Control the C/D	Engine and ECT, Engine, ECT, Engine2
0218	Control the O/D Cut	Engine and ECT, Engine, ECT, Engine2
0219	Control the Auto Oil Supply System	Engine and ECT, Engine, ECT, Engine2
0220	Activate the VVT System (Bank1)	Engine and ECT, Engine, ECT, Engine2
0221	Control the Supercharger	Engine and ECT, Engine, ECT, Engine2
0222	Activate the Slip Control System	Engine and ECT, Engine, ECT, Engine2
0223	Activate the VSV for Air Bleed Control	Engine and ECT, Engine, ECT, Engine2
0224	Activate the VSV for Intake Air Control	Engine and ECT, Engine, ECT, Engine2
0225	Activate the VSV for Exhaust Gas Control	Engine and ECT, Engine, ECT, Engine2
0226	Activate the Air Pump	Engine and ECT, Engine, ECT, Engine2
0227	Activate the Air Switching Valve	Engine and ECT, Engine, ECT, Engine2
0228	Control the SCV Duty Ratio	Engine and ECT, Engine, ECT, Engine2
0229	Control the IAC Duty Ratio	Engine and ECT, Engine, ECT, Engine2
0230	Test the Fuel Leak	Engine and ECT, Engine, ECT, Engine2
0231	Control the VVT Exhaust Linear (Bank1)	Engine and ECT, Engine, ECT, Engine2
0232	Control the VVT Exhaust Linear (Bank2)	Engine and ECT, Engine, ECT, Engine2
0233	Control the VVT Linear (Bank1)	Engine and ECT, Engine, ECT, Engine2
0234	Control the VVT System (Bank1)	Engine and ECT, Engine, ECT, Engine2
0235	Control the VVT Linear (Bank2)	Engine and ECT, Engine, ECT, Engine2
0236	Control the ETCS Open/Close Slow Speed	Engine and ECT, Engine, Transmission, ECT, Engine2
0237	Control the ETCS Open/Close Fast Speed	Engine and ECT, Engine, Transmission, ECT, Engine2
0238	Control the Injection Timing #1	Engine and ECT, Engine, ECT, Engine2
0239	Control the Injection Timing #2	Engine and ECT, Engine, ECT, Engine2
0240	Control the Injection Timing #6	Engine and ECT, Engine, ECT, Engine2
0241	Control the Injection Timing #5	Engine and ECT, Engine, ECT, Engine2
0242	Control the Injection Timing #4	Engine and ECT, Engine, ECT, Engine2

0243	Control the Injection Timing #3	Engine and ECT, Engine, ECT, Engine2
0244	Control the Injection Timing #8	Engine and ECT, Engine, ECT, Engine2
0245	Control the Injection Timing #7	Engine and ECT, Engine, ECT, Engine2
0246	Control the Target Fuel Pressure	Engine and ECT, Engine, ECT, Engine2
0247	Control the Electric Cooling Fan	Engine and ECT, Engine, ECT, Engine2
0248	Activate the VSV for AICS	Engine and ECT, Engine, ECT, Engine2
0249	Activate the Vacuum Pump	Engine and ECT, Engine, Transmission, ECT, Engine2
0250	Activate the VSV for Vent Valve	Engine and ECT, Engine, Transmission, ECT, Engine2
0251	Control the Idle Fuel Cut Prohibit	Engine and ECT, Engine, ECT, Engine2
0252	Prohibit the Catalyst OT Misfire prevent F/C	Engine and ECT, Engine, ECT, Engine2
0253	Fuel Cut Bank 2 for Idle	Engine and ECT, Engine, ECT, Engine2
0254	Control the Injection Volume for A/F Sensor	Engine and ECT, Engine, Transmission, ECT, Engine2
0255	Air Fuel Ratio (A/F) Control	Engine and ECT, Engine
0256	Activate the ACC Cut Relay	Engine and ECT, Starting Control, Engine, ECT, Engine2
0257	Activate the Starter Relay	Engine and ECT, Starting Control, Engine, ECT, Engine2
0258	Control the Voltage of Alternator	Engine and ECT, Engine, Transmission, ECT, Engine2, Charging Control
0259	Activate the VSV for Turbo Boost Control	Engine and ECT, Engine, ECT, Engine2
0260	Activate the VSV for Secondary Air Control	Engine and ECT, Engine, ECT, Engine2
0261	Activate the Fuel Pump Speed Control	Engine and ECT, Engine, ECT, Engine2
0262	Control the Injection Volume	Engine and ECT, Engine, Transmission, ECT, Engine2
0263	Control the Cylinder#1 Fuel Cut	ECT
0264	Control the Cylinder#8 Fuel Cut	ECT
0265	Control the Cylinder#4 Fuel Cut	ECT
0266	Control the Cylinder#3 Fuel Cut	ECT
0267	Control the Cylinder#2 Fuel Cut	ECT
0268	Control the Cylinder#7 Fuel Cut	ECT
0269	Control the Cylinder#6 Fuel Cut	ECT

0270	Control the Cylinder#5 Fuel Cut	ECT
0271	Infrared Ray (IR) Floodlight	Night View
0272	Display Warning	Night View
0273	Operation Of Night View System	Night View
0274	Night View Indicator	Combination Meter, Night View
0275	Interior Illumination Light	Left Mirror, Right Mirror, Right Front Door, Left Front Door
0276	Power Window Switch LED	Left Mirror, Right Mirror, Right Front Door, Left Front Door
0277	Inside Handle Light	Left Mirror, Right Mirror, Right Front Door, Left Front Door
0278	Courtesy Light	Left Mirror, Right Mirror, Mirror, Right Front Door, Left Front Door, Left Rear Door, Right Rear Door, Driver Door, Passenger Door
0279	Mirror Fold/Return	Left Mirror, Right Mirror, Driver Door, Passenger Door, Right Front Door, Left Front Door, Left Rear Door, Right Rear Door, Mirror
0280	Right/Left Mirror	Left Mirror, Right Mirror, Mirror, Driver Door, Passenger Door, Right Front Door, Left Front Door, Left Rear Door, Right Rear Door
0281	Mirror Up/Down	Left Mirror, Right Mirror, Mirror, Driver Door, Passenger Door, Right Front Door, Left Front Door, Left Rear Door, Right Rear Door
0282	Heater Of Mirror	Main Body, Left Mirror, Right Mirror, Mirror, Driver Door, Passenger Door, Right Front Door, Left Front Door, Left Rear Door, Right Rear Door
0283	Foot Light	Left Mirror, Right Mirror, Mirror, Driver Door, Passenger Door, Right Front Door, Left Front Door, Left Rear Door, Right Rear Door
0284	Ashtray Light	Left Mirror, Right Mirror, Driver Door, Passenger Door, Right Front Door, Left Front Door, Left Rear Door, Right Rear Door
0285	Drive Magnet Switch Of Starter Motor	Stop and Start, Stop&Start
0286	Pinion Gear Plunger	Stop and Start, Stop&Start
0287	Starter	Stop and Start, Stop&Start
0288	Permission Condition (Battery)	Stop and Start, Stop&Start
0289	Permission Condition (Engine)	Stop and Start, Stop&Start
0290	Automatic Transmission (AT) Oil Pump - High	Stop and Start, Stop&Start
0291	Automatic Transmission (AT) Oil Pump - Low	Stop and Start, Stop&Start
0292	Permit Cond (A/C)	Stop and Start, Stop&Start
0293	Permission Condition (Anti-Lock Brake System)	Stop and Start, Stop&Start
0294	Precondition (Control)	Stop and Start, Stop&Start



0295	Permission Condition (Ambient Temperature)	Stop and Start, Stop&Start
0296	Precondition 2 (Control)	Stop and Start, Stop&Start
0297	Start Condition - Hood Crtsy	Stop and Start, Stop&Start
0298	Pre-Collision System (PCS) Crash Alarm Buzzer	Pre-Crash 2, Pre-Collision 2, Automatic high beam, Pre-Crash
0299	IGP Signal	Power Source Control
0300	Condition Of Indicator	Main Body, Power Source Control
0301	P Supply for Steering Lock	Main Body, Power Source Control
0302	ACC	Power Source Control
0303	Start Switch	Power Source Control
0304	Ignition2	Power Source Control
0305	Ignition1	Power Source Control
0306	Headrest Sensor	Active Headrest Right, Active Headrest Left
0307	Headrest Auto	Active Headrest Right, Active Headrest Left
0308	Headrest Manual Forward	Active Headrest Right, Active Headrest Left
0309	Headrest Manual Backward	Active Headrest Right, Active Headrest Left
0310	Nozzle Heater Of Front Washer	Body No. 4
0311	Rear Step Light	Body No. 4
0312	Control Of Luggage Light	Body No. 3, Body No. 4, Body No. 5
0313	Stop Light	Body No. 3, Body No. 4, Body No. 5
0314	Rear Fog Light	Body No. 3, Body No. 4, Body No. 5
0315	High Mount Stop Light	Body No. 3, Body No. 4, Body No. 5
0316	Backup Light	Body No. 3, Body No. 4, Body No. 5, Back Door
0317	Inside Handle Illumination	Main Body, Mirror, Driver Door, Passenger Door, Left Rear Door, Right Rear Door, Body No. 4
0318	Buckle Light - Front Passenger Side	Body No. 4
0319	Illuminated Entry System	Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2, Body No. 4
0320	Fuel Lid Open	Body No. 3, Body No. 4, Body No. 5
0321	Open Trunk Lid	Theft Deterrent, Body No. 3, Body No. 4, Body No. 5, Smart Key
0322	Open Tail Gate Panel	Body No. 4
0323	Buckle Light - Driver Side	Body No. 4
0324	Shoulder Anchor - Front Passenger Side	Body No. 4
0325	Operation Of Rear Sunshade	Body No. 3, Body No. 4
0326	Low Rear Wiper	Body No. 4
0327	Rear Air Conditioner (A/C) Magnetic Valve	Body No. 4
0328	Shoulder Anchor - Driver Side	Body No. 4
0329	Tail Light	Theft Deterrent, Entry&Start, Body No. 3, Body No. 4, Body No. 5, Smart Key, Smart Access, Entry&start
0330	Operation Of Horn Relay	Body No. 3, Body No. 4, Body No. 5
0331	Wireless Buzzer - Continuous Sound	Body, Gateway, Body No. 5, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0332	Operation Of Washer Motor	Body No. 3, Body No. 4, Body No. 5, Wiper

0333	Security Horn	Theft Deterrent, Main Body, Entry&Start, Body, Gateway, Body No. 5, Body Electronic Area Network (BEAN) Gateway, Body No. 2, Smart Key, Smart Access, Entry&start, Security
0334	Wiper Deicer	Body No. 5
0335	Cleaner Of Head Light	Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2, Body No. 5
0336	Operation Of Rear Defogger	Body No. 5
0337	Relay Of Front Fog Light	Main Body, Theft Deterrent, Body, Gateway, Body No. 3, Body No. 4, Body No. 5, Body Electronic Area Network (BEAN) Gateway, Body No. 2, Smart Key
0338	Operation Of Clearance Light	Body No. 3, Body No. 4, Body No. 5
0339	Head Light High	Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2, Body No. 5
0340	Head Light High Daytime Running Lamp (DRL) Operation	Body No. 5
0341	Head Light Low	Body No. 5
0342	Clear Integrated Current for Factory Mode	Electric Power Control
0343	Request to Limit Air Suspension	Electric Power Control
0344	Activate Power Cut Relay	Electric Power Control
0345	Load Level Limit	Electric Power Control
0346	Request to Limit EPS	Electric Power Control
0347	Backwards Operation Of Seat Belt Motor	Pre-Crash, Pre-Collision
0348	Motor Of Driver Seat Belt	Pre-Crash, Pre-Collision
0349	Motor Of Passenger Seat Belt	Pre-Crash, Pre-Collision
0350	Driver and Passenger Seat Belt Motor	Pre-Crash, Pre-Collision
0351	Target Temperature Of Seat Heater	Left Front Seat A/C, Right Front Seat A/C, Left Rear Seat Air Conditioner (A/C), Right Rear Seat Air Conditioner (A/C)
0352	Airflow	Left Front Seat A/C, Right Front Seat A/C, Left Rear Seat Air Conditioner (A/C), Right Rear Seat Air Conditioner (A/C)
0353	Warm air	Left Front Seat A/C, Right Front Seat A/C, Left Rear Seat Air Conditioner (A/C), Right Rear Seat Air Conditioner (A/C)
0354	Cool air	Left Front Seat A/C, Right Front Seat A/C, Left Rear Seat Air Conditioner (A/C), Right Rear Seat Air Conditioner (A/C)
0355	Night Lighting	Driver Seat Switch, Rear Console Switch, Switch Of Center Console
0356	Full Rear Seat A/C Indicator	Switch Of Center Console
0357	Reduced Rear Seat A/C Indicator	Switch Of Center Console

0358	Air Conditioner (A/C) Auto Indicator Of Right Rear Seat - Red	Rear Console Switch
0359	Air Conditioner (A/C) Auto Indicator Of Left Rear Seat - Red	Rear Console Switch
0360	Air Conditioner (A/C) Level Indicator Of Right Rear Seat - Full	Rear Console Switch
0361	Air Conditioner (A/C) Level Indicator Of Left Rear Seat - Red	Rear Console Switch
0362	Air Conditioner (A/C) Level Indicator Of Right Rear Seat - Red	Rear Console Switch
0363	Air Conditioner (A/C) Level Indicator Of Left Rear Seat - Full	Rear Console Switch
0364	Air Conditioner (A/C) Auto Indicator Of Right Rear Seat - Full	Rear Console Switch
0365	Air Conditioner (A/C) Auto Indicator Of Left Rear Seat - Full	Rear Console Switch
0366	Audio / Heater Power Supply	Rear Console Switch
0367	Audio / Heater IG	Rear Console Switch
0368	Right/Left Selection Switch Right Indicator Red	Rear Console Switch
0369	Right/Left Selection Switch Left Indicator Red	Rear Console Switch
0370	Air Conditioner (A/C) Indicator Of Rear Right Seat - Red	Rear Console Switch
0371	Air Conditioner (A/C) Indicator Of Left Rear Seat - Red	Rear Console Switch
0372	Right/Left Selection Switch Right Indicator Full	Rear Console Switch
0373	Right/Left Selection Switch Left Indicator Full	Rear Console Switch
0374	Rear Right Seat A/C Indicator Full	Rear Console Switch
0375	Air Conditioner (A/C) Indicator Of Left Rear Seat - Full	Rear Console Switch
0376	Auto Mode	ABS/VSC/TRC, Electric Parking Brake, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB

0377	Park Brake (PKB) Lock Control	ABS/VSC/TRC, Electric Parking Brake, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0378	Lock Display	Electric Parking Brake
0379	Electrical Park Brake (EPB) Warning Light	ABS/VSC/TRC, Electric Parking Brake, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0380	Release Control Of Park Brake (PKB)	ABS/VSC/TRC, Electric Parking Brake, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0381	Release Display	Electric Parking Brake
0382	Light Of Park Brake (PKB)	ABS/VSC/TRC, Electric Parking Brake, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0383	PKB Full Release Control	ABS/VSC/TRC, Electric Parking Brake, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0384	Park Range Display	Electric Parking Brake
0385	Auto Light	Electric Parking Brake
0386	Overheat Display	Electric Parking Brake
0387	Check Display	Electric Parking Brake
0388	Not Available Display	Electric Parking Brake
0389	Park Brake (PKB) Release 1	Electric Parking Brake
0390	Deactivation Of Full Release Mode	Electric Parking Brake
0391	Test Mode	Electric Parking Brake
0392	Park Brake (PKB) Lock 1	Electric Parking Brake
0393	Activation Of Full Release Mode	Electric Parking Brake
0394	Lock Display Fault	Electric Parking Brake
0395	Interlocking Shift OFF Display	Electric Parking Brake
0396	Interlocking Shift ON Display	Electric Parking Brake
0397	Park Brake (PKB) Haul Display	Electric Parking Brake
0398	Crawl Indicator	Combination Meter, Driver Seat Switch
0399	Off-road Guidance Indicator	Driver Seat Switch

0400	Indicator Of BSM Switch (Night/Moving)	Driver Seat Switch
0401	Indicator Of BSM Switch (Night/Stopped)	Driver Seat Switch
0402	Indicator Of BSM Switch (Daytime)	Driver Seat Switch
0403	Activation Of 2nd Gear Start Switch	Driver Seat Switch
0404	Activation Of Clearance Sonar Switch	Driver Seat Switch
0405	Off-road 3 Indicator (Nighttime)	Driver Seat Switch
0406	Off-road 4 Indicator (Nighttime)	Driver Seat Switch
0407	Off-road Switch Light	Driver Seat Switch
0408	Off-road 3 Indicator (Daytime)	Driver Seat Switch
0409	Off-road 1 Indicator (Daytime)	Driver Seat Switch
0410	Off-road 2 Indicator (Daytime)	Driver Seat Switch
0411	Active Request Of Steering Heater - Direct Line	Driver Seat Switch
0412	Off-road 4 Indicator (Daytime)	Driver Seat Switch
0413	Off-road 2 Indicator (Nighttime)	Driver Seat Switch
0414	Off-road 1 Indicator (Nighttime)	Driver Seat Switch
0415	Clearance Sonar Indicator (Night Running)	Driver Seat Switch
0416	Auto Indicator Of Mirror - Night Stopping	Driver Seat Switch
0417	Clearance Sonar Indicator (Night Stopping)	Driver Seat Switch
0418	Auto Indicator Of Mirror - Night Running	Driver Seat Switch
0419	Auto Indicator Of Mirror - Daytime	Driver Seat Switch
0420	Clearance Sonar Indicator (Daytime)	Driver Seat Switch
0421	Lumbar Adjustment Of Rear Seat	Driver Seat, Passenger Seat, Left Rear Seat, Right Rear Seat, Radar Cruise 1
0422	Operation Of Headrest	Driver Seat, Passenger Seat, Left Rear Seat, Right Rear Seat, Radar Cruise 1
0423	Seat Reclining	Driver Seat, Passenger Seat, Left Rear Seat, Right Rear Seat, Radar Cruise 1
0424	Seat Slide Operation	Driver Seat, Passenger Seat, Left Rear Seat, Right Rear Seat, Radar Cruise 1
0425	Ottoman	Passenger Seat, Left Rear Seat, Right Rear Seat, Radar Cruise 1
0426	Mirror Fold	Main Body, Mirror, Driver Door, Passenger Door, Right Mirror, Left Mirror, Right Front Door, Left Front Door

0427	Mirror Return	Main Body, Mirror, Driver Door, Passenger Door, Right Mirror, Left Mirror, Right Front Door, Left Front Door
0428	Seat Memory Light	Mirror, Left Rear Door, Right Rear Door, Driver Door, Passenger Door
0429	Door Lock	Main Body, Mirror, Body, Driver Door, Passenger Door, Gateway, Left Rear Door, Right Rear Door, Body Electronic Area Network (BEAN) Gateway, Body No. 2, Back Door
0430	P Manual Switch LED	Driver Door, Passenger Door, Left Rear Door, Right Rear Door
0431	Double lock unset	Passenger Door
0432	Check the E-ACM	E-ACM
0433	Right-Hand Mirror Right/Left	Main Body, Mirror, Driver Door
0434	Left-Hand Mirror Up/Down	Main Body, Mirror, Driver Door
0435	Left-Hand Mirror Right/Left	Main Body, Mirror, Driver Door
0436	Right-Hand Mirror Up/Down	Main Body, Mirror, Driver Door
0437	Double Lock Unset	Mirror, Driver Door, Passenger Door, Left Rear Door, Right Rear Door
0438	Front Wheel Up/Down	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0439	Exhaust Solenoid	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0440	Rear Gate Solenoid	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0441	4-Wheel Damping Force Full Soft	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0442	4-Wheel Damping Force Full Hard	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0443	Left Rear Height Solenoid	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0444	Valve Of Front Gate	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0445	Rear Gate Valve	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0446	Left Front Solenoid	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0447	Right Front Solenoid	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0448	Relay Of Compressor Motor	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0449	Valve Of Accumulator	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0450	Left Rear Solenoid	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0451	Right Rear Solenoid	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0452	Front Wheel Up by Accumulator	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0453	Rear Wheel Up by Accumulator	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC

0454	Right Front Wheel Up/Down	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0455	Left Front Wheel Up/Down	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0456	Right Rear Wheel Up/Down	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0457	Left Rear Wheel Up/Down	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0458	Right Front Height Solenoid	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0459	Relay Of Pump Motor	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0460	Left Front Gas Spring Switch Valve	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0461	Right Front Gas Spring Switch Valve	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0462	Right Rear Height Solenoid	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0463	Left Front Height Solenoid	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0464	Right Front Damper Step	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0465	Left Front Damper Step	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0466	Right Rear Damper Step	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0467	Rear Leveling Solenoid	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0468	Rear Wheel Up/Down	Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0469	Low Pressure Tank Solenoid	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC, Air Suspension
0470	Left Rear Damper Step	EMS, Air suspension, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC
0471	Relay Of Motor	ABS/VSC/TRC, Brake/EPB, EMS, Air suspension, ABS/VSC/TRC/EPB, Adaptive Variable Suspension (AVS) System, Air suspension 2, AHC, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Brake
0472	Tilt Operation	Tilt&Telescopic
0473	Telescopic Operation	Tilt&Telescopic
0474	Right Drive Swivel Motor - Right	Auto Leveling Of Headlamp, AFS
0475	Adaptive Front Lighting System (AFS) Off Indicator	Auto Leveling Of Headlamp, AFS, Combination Meter
0476	Right Drive Swivel Motor	Auto Leveling Of Headlamp, AFS
0477	Drive Swivel Motor Left	Auto Leveling Of Headlamp, AFS
0478	Left/Right Variable Shade Beam	Auto Leveling Of Headlamp, AFS
0479	Left Variable Shade Beam	Auto Leveling Of Headlamp, AFS
0480	Right Variable Shade Beam	Auto Leveling Of Headlamp, AFS
0481	Extra High Beam	Auto Leveling Of Headlamp, AFS
0482	AHS	Auto Leveling Of Headlamp, AFS
0483	Right High Beam	Auto Leveling Of Headlamp, AFS

0484	Auto High Beam Control Indicator	Auto Leveling Of Headlamp, AFS
0485	Warning Indicator Of Auto High Beam	Auto Leveling Of Headlamp, AFS
0486	Adaptive Front Lighting System (AFS) Alarm Display	Auto Leveling Of Headlamp, AFS
0487	Left High Beam	Auto Leveling Of Headlamp, AFS
0488	High Beam Indicator	Auto Leveling Of Headlamp, AFS, Combination Meter
0489	Advice Display	Auto Leveling Of Headlamp, AFS
0490	Automatic High Beam Operation	Main Body, Auto Leveling Of Headlamp, AFS
0491	Right Drive Swivel Motor - Left	Auto Leveling Of Headlamp, AFS
0492	Left Drive Swivel Motor Left	Auto Leveling Of Headlamp, AFS
0493	Left Drive Swivel Motor Right	Auto Leveling Of Headlamp, AFS
0494	Accessory Output Pager	Theft Deterrent, Smart Key
0495	Accessory Output Buzzer	Theft Deterrent, Smart Key
0496	Intrusion Sensor Power	Theft Deterrent, Main Body, Entry&Start, Smart Key, Smart Access, Entry&start
0497	Intrusion Sensor 2 Power	Theft Deterrent, Main Body
0498	Security Horn 2	Theft Deterrent, Main Body, Entry&Start, Body, Smart Key, Smart Access, Security
0499	Vehicle Horn	Theft Deterrent, Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2, Security
0500	Relay Of Headlight	Theft Deterrent, Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2, Smart Key
0501	Security Indicator	Theft Deterrent, Main Body, Entry&Start, Body, Immobiliser, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2, Steering Lock, Smart Key, Smart Access, Entry&start, Security
0502	Tilt Sensor Power	Theft Deterrent, Main Body, Entry&Start, Smart Key, Smart Access, Entry&start, Security
0503	Release Of Actuator	Driver Door, Passenger Door, Left Rear Door, Right Rear Door
0504	Power Sliding Door (PSD) Close	Left Rear Door, Right Rear Door
0505	Power Sliding Door (PSD) Open	Left Rear Door, Right Rear Door
0506	Power Sliding Door (PSD) Open Signal	Left Rear Door, Right Rear Door
0507	Power Sliding Door (PSD) Buzzer	Driver Door, Passenger Door, Left Rear Door, Right Rear Door
0508	Power Sliding Door (PSD) Motor	Driver Door, Passenger Door, Left Rear Door, Right Rear Door
0509	Power Sliding Door (PSD) Clutch	Driver Door, Passenger Door, Left Rear Door, Right Rear Door
0510	Rear Door Sunshade - Up	Left Rear Door, Right Rear Door



0511	Rear Door Sunshade - Down	Left Rear Door, Right Rear Door
0512	Memory Cancel Light	Left Rear Door, Right Rear Door
0513	Side Support Operation	Driver Seat, Passenger Seat, Radar Cruise 1
0514	Pelvis Support Operation	Driver Seat, Passenger Seat, Radar Cruise 1
0515	Length Of Cushion	Driver Seat, Passenger Seat, Radar Cruise 1
0516	Front Vertical Operation	Driver Seat, Passenger Seat, Radar Cruise 1
0517	Operation Of Lifter	Driver Seat, Passenger Seat, Radar Cruise 1
0518	Lumbar Lift	Driver Seat
0519	Lumbar Slide	Driver Seat, Passenger Seat, Radar Cruise 1
0520	Power Back Door (PBD) Open/Close	Back Door
0521	Signal Of Courtesy Switch	Back Door
0522	Motor Of Power Back Door (PBD)	Back Door
0523	Clutch Of Power Back Door (PBD)	Back Door
0524	Power Back Door (PBD) Buzzer	Back Door
0525	Power Back Door (PBD) Close Switch Light	Back Door
0526	Release Latch	Back Door
0527	Check Stabilizer	Front Stabilizer, Rear Stabilizer
0528	Power Window	Driver Door Motor, Passenger Door Motor, Left Rear Door Motor, Right Rear Door Motor, Driver Door, Passenger Door, Left Rear Door, Right Rear Door, Back Door
0529	Slide Roof	Sliding Roof
0530	Power Switch Light	Entry&Start, Smart Key, Smart Access, Entry&start
0531	Multi Channel Switch	Entry&Start, Smart Key, Smart Access, Entry&start
0532	Back Door Select	Entry&Start, Smart Key, Smart Access, Entry&start
0533	Operation Of Wireless Buzzer	Entry&Start, Smart Key, Smart Access, Entry&start
0534	Power for P-Seat Sens	Entry&Start, Smart Key, Smart Access, Entry&start
0535	Power for DR-Seat Sens	Entry&Start, Smart Key, Smart Access, Entry&start
0536	Driver Rear Seat Select	Entry&Start, Smart Key, Smart Access, Entry&start
0537	Passenger Rear Seat Select	Entry&Start, Smart Key, Smart Access, Entry&start
0538	Light Of Power/Engine Switch	Entry&Start, Smart Key, Smart Access, Entry&start
0539	Indicator Of Immobiliser	Entry&Start, Smart Key, Smart Access, Entry&start
0540	Power for PR-Seat Sens	Entry&Start, Smart Key, Smart Access, Entry&start
0541	Power for BDoor Sens	Entry&Start, Smart Key, Smart Access
0542	Rear Driver Seat Outside Transmitter	Entry&Start, Smart Key, Smart Access, Entry&start
0543	Rear Passenger-Seat Outside Transmitter	Entry&Start, Smart Key, Smart Access, Entry&start

0544	Select Passenger Seat	Entry&Start, Smart Key, Smart Access, Entry&start
0545	Power Supply Of Inside Luggage Tuner Is On.	Entry&Start, Smart Key, Smart Access, Entry&start
0546	Overhead Tuner Power Supply ON	Entry&Start, Smart Key, Smart Access, Entry&start
0547	Inside Transmitter - Rr-Seat	Entry&Start, Smart Key, Smart Access, Entry&start
0548	Inside Trunk/Backdoor Transmitter	Entry&Start, Smart Key, Smart Access, Entry&start
0549	Transmitter Of Outside Trunk/Backdoor	Entry&Start, Smart Key, Smart Access, Entry&start
0550	Driver Seat Select	Entry&Start, Smart Key, Smart Access, Entry&start
0551	Passenger Seat Outside Transmitter	Entry&Start, Smart Key, Smart Access, Entry&start
0552	Inside Transmitter Of Fr-Seat	Entry&Start, Smart Key, Smart Access, Entry&start
0553	Driver Seat Outside Transmitter	Entry&Start, Smart Key, Smart Access, Entry&start
0554	Valve Of Accumulator (Downside)	KDSS
0555	Valve Of Accumulator (Upside)	KDSS
0556	Front Deicer Relay	Air Conditioner
0557	Relay Of Mirror Heater	Air Conditioner
0558	Rear Defogger Relay	Air Conditioner
0559	Air Purifier Mode	Air Conditioner
0560	Assist Fan	Air Conditioner
0561	Electrical Fan	Air Conditioner
0562	Water Pump	Air Conditioner
0563	Active Level Of Heater	Air Conditioner
0564	HWD Relay	Air Conditioner
0565	Electric Water Heater	Air Conditioner
0566	Magnetic Valve Of Battery	Air Conditioner
0567	Evaporator Magnetic Valve	Air Conditioner
0568	Operation Of Magnetic Valve	Air Conditioner
0569	Passenger Air Outlet Servo Pulse	Air Conditioner
0570	Ion Generator	Air Conditioner
0571	Air Purifier (Ion)	Air Conditioner
0572	Air Purifier (Clean)	Air Conditioner
0573	Compressor Target Speed	Air Conditioner
0574	Passenger Rear Air Outlet (A/O) Servo Pulse	Air Conditioner
0575	Passenger Cool Air Bypass Pulse	Air Conditioner
0576	Emission Pulse (Rear)	Air Conditioner
0577	Diffuse Pulse (R)	Air Conditioner
0578	Drive Rear Air Outlet (A/O) Servo Pulse	Air Conditioner

0579	Passenger Front And Rear Air Outlet (A/O) Servo Pulse	Air Conditioner
0580	Driver Front And Rear Air Outlet (A/O) Servo Pulse	Air Conditioner
0581	Rear Air Mix Servo Target Pulse	Air Conditioner
0582	Target Pulse Of Battery Cool Down Servo	Air Conditioner
0583	DEF Air Outlet (A/O) Servo Pulse (Driver)	Air Conditioner
0584	Passenger Rear Air Mix Servo Pulse	Air Conditioner
0585	Rear Blower Motor	Air Conditioner
0586	Passenger Air Mix Servo Target Pulse	Air Conditioner
0587	Heat Exchange Shut Valve	Air Conditioner
0588	Driver Air Mix Servo Target Pulse	Air Conditioner
0589	Heating Three-way Valve	Air Conditioner
0590	High Pressure Magnetic Valve	Air Conditioner
0591	Low Pressure Magnetic Valve	Air Conditioner
0592	Dehumidification Magnetic Valve	Air Conditioner
0593	Viscous Heater	Air Conditioner
0594	Electric Heater 2	Air Conditioner
0595	Electric Heater 3	Air Conditioner
0596	Rear Air Conditioner (A/C) Magnet Valve	Air Conditioner
0597	Oxygen Drive	Air Conditioner
0598	Relay Of Magnetic Clutch	Air Conditioner
0599	Electric Heater 1	Air Conditioner
0600	A/M Servo Pulse(F&R P)	Air Conditioner
0601	Driver Front And Rear Air Mix (A/M) Servo Pulse	Air Conditioner
0602	M/H Bypass Cool Servo Pulse	Air Conditioner
0603	Passenger Foot Air Outlet (A/O) Servo Pulse	Air Conditioner
0604	M/H Bypass Hot Servo Pulse	Air Conditioner
0605	Passenger Face Air Outlet (A/O) Servo Pulse	Air Conditioner
0606	Driver Face Air Outlet (A/O) Servo Pulse	Air Conditioner
0607	Driver Foot Air Outlet (A/O) Servo Pulse	Air Conditioner
0608	Passenger Cool A/M Servo Pulse	Air Conditioner
0609	Passenger Hot Air/Mix (A/M) Servo Pulse	Air Conditioner
0610	Target Pulse Of Air Inlet Damper	Air Conditioner

0611	Cool Air Bypass Pulse	Air Conditioner
0612	Driver Hot Air Mix (A/M) Servo Pulse	Air Conditioner
0613	Driver Cool A/M Servo Pulse	Air Conditioner
0614	Driver Air Outlet Servo Pulse	Air Conditioner
0615	Blower Motor	Air Conditioner
0616	Automatic Transmission (A/T) Indicator Operation 2	Combination Meter
0617	Operation Of Fuel Consumption Meter	Combination Meter
0618	Operation Of Power Meter	Combination Meter
0619	Automatic Transmission (A/T) Indicator Operation 1	Combination Meter
0620	Electrical Park Brake (EPB) Auto Off Indicator	Combination Meter
0621	Fuel Indicator (Compressed Natural Gas)	Combination Meter
0622	Operation Of Fuel Meter (CNG)	Combination Meter
0623	Go to Dealer Indicator	Combination Meter
0624	Over Drive (O/D) Off Indicator	Combination Meter
0625	Brake Override Indicator	Combination Meter
0626	Indicator Of Compressed Natural Gas (CNG) Mode	Combination Meter
0627	Indicator Of Tow Haul	Combination Meter
0628	Vehicle Stop Indicator	Combination Meter
0629	Main Battery (HV) Indicator	Combination Meter
0630	Intelligent Clearance Sonar (ICS) Off Indicator	Combination Meter
0631	Ready (EV) Indicator	Combination Meter
0632	Indicator Of EV System	Combination Meter
0633	Charge Warning Indicator	Combination Meter
0634	SOC Gauge	Combination Meter
0635	ASL Warning Indicator	Combination Meter
0636	SOC Warning Indicator	Combination Meter
0637	Charging Indicator	Combination Meter
0638	Limited Power Indicator	Combination Meter
0639	Right Lane Departure Alert (LDA) Control Indicator	Combination Meter
0640	Right Lane Departure Alert (LDA) Warning Indicator	Combination Meter
0641	Blind Spot Monitor (BSM) Control Indicator	Combination Meter
0642	Left Lane Departure Alert (LDA) Control Indicator	Combination Meter
0643	Left Lane Departure Alert (LDA) Warning Indicator	Combination Meter
0644	Check Engine Indicator	Combination Meter

0645	Lane Departure Alert (LDA) Control Indicator	Combination Meter
0646	Lane Departure Alert (LDA) Warning Indicator	Combination Meter
0647	Maintenance Indicator	Combination Meter
0648	Warning Of Hybrid System	Combination Meter
0649	Radar Cruise Indicator	Combination Meter
0650	Off Indicator Of Vehicle Approach Warning	Combination Meter
0651	Rear Inner Wheel Control Indicator	Combination Meter
0652	Rear Inner Wheel Control Warning	Combination Meter
0653	Crawl Warning Indicator	Combination Meter
0654	ACTIVE TRC Warning Indicator	Combination Meter
0655	Indicator Of Seatbelt Information	Combination Meter
0656	Stop and Start ON Indicator	Combination Meter
0657	Stop and Start OFF Indicator	Combination Meter
0658	Indicator Of Blind Spot Monitor	Combination Meter
0659	Indicator Of Smart System	Combination Meter
0660	Warning Of Smart System	Combination Meter
0661	Indicator Of Automatic High Beam	Combination Meter
0662	Intuitive Parking Assist (P/A) LCD Indicator	Combination Meter
0663	Indicate ECO	Combination Meter
0664	Lithium Charge Indicator	Combination Meter
0665	Tail Cancel Indicator	Combination Meter
0666	Indicate KEY	Combination Meter
0667	Timing Belt Indicator	Combination Meter
0668	Indicate EV Mode	Combination Meter
0669	Ready (HV) Indicator	Combination Meter
0670	Master Warning	Combination Meter
0671	Over Speed Indicator	Combination Meter
0672	Electric Power Steering (EPS) Indicator	Combination Meter
0673	Drift From The Lane	Combination Meter
0674	Ready Indicator Of Radar Cruise	Combination Meter
0675	Clearance Sonar LCD Indicator	Combination Meter
0676	Height High Indicator	Combination Meter
0677	Automatic Transmission (A/T) Oil Temperature Operation	Combination Meter
0678	Indicat. Lamp ABS	Combination Meter
0679	Precrash Indicator	Combination Meter
0680	Tire Pressure Warning System Indicator	Combination Meter

0681	Front Fog Indicator Lamp	Combination Meter
0682	Indicator Of Fuel Filter	Combination Meter
0683	KDSS Indicator	Combination Meter
0684	Indicator Of OFF Road Guidance	Combination Meter
0685	Air Suspension (HI) Indicator	Combination Meter
0686	Normal Indicator Of Air Suspension	Combination Meter
0687	Air Suspension (LO) Indicator	Combination Meter
0688	Air Conditioner Auto Indicator	Combination Meter
0689	Rear Seat Belt	Combination Meter
0690	Indicator Of Luggage Mode	Combination Meter
0691	Tail OFF Indicator	Combination Meter
0692	Set Indicator	Combination Meter
0693	ASL Indicator	Combination Meter
0694	Sport (CVT Sport) Indicator	Combination Meter
0695	Indicate Economy Mode	Combination Meter
0696	Indicat. A/T P	Combination Meter
0697	SIL Indicator (Up)	Combination Meter
0698	SIL Indicator (Down)	Combination Meter
0699	Rear Differential Lock Indicator	Combination Meter
0700	4 Low Indicator	Combination Meter
0701	Ride Mode Indicator	Combination Meter
0702	Vehicle Stability Control (VSC) Off Indicator	Combination Meter
0703	SIL Indicator	Combination Meter
0704	2nd Start Indicator	Combination Meter
0705	Control Differential Lock Indicator	Combination Meter
0706	Toyota Electronically Modulated Suspension (TEMS) Comfort Indicator	Combination Meter
0707	Park Indicator	Combination Meter
0708	NAVI Continuously Variable Transmission (CVT) Indicator	Combination Meter
0709	Four Wheel Drive (4WD) AUTO Indicator	Combination Meter
0710	Auto Limited Slip Differential (LSD) Indicator	Combination Meter
0711	Indicate Downhill Assist Control	Combination Meter
0712	Indicate Brake Hold	Combination Meter
0713	Indicate Hold	Combination Meter
0714	Multi-Mode Manual Transmission (MMT) M Mode Indicator	Combination Meter

0715	Multi-Mode Manual Transmission (MMT) E Mode Indicator	Combination Meter
0716	Four Wheel Drive (4WD) Lock Indicator	Combination Meter
0717	Door Is Open - Front Passenger Side	Combination Meter
0718	Right-Hand Rear Door Open Indicator	Combination Meter
0719	Seat Belt - Front Passenger Side	Combination Meter
0720	Doors All Open Indicator Lamp	Combination Meter
0721	Door Open - Driver Side	Combination Meter
0722	Meter Display 2	Combination Meter
0723	Indicator Of Head Up Display	Combination Meter
0724	Warning Of Diesel Particulate Filter	Combination Meter
0725	Indicator Of HV System	Combination Meter
0726	Indicator Of HV System Certification Mode	Combination Meter
0727	Warning Of LED Head Lamp	Combination Meter
0728	Left Turn Signal Indicator	Combination Meter
0729	Right Turn Signal Indicator	Combination Meter
0730	Park Range Indicator	Combination Meter
0731	Indicator Of Lithium Battery Hot	Combination Meter
0732	EV Mode Indicator	Combination Meter
0733	Hot Warning Indicator Of HV Unit	Combination Meter
0734	Indicator Of Lithium Battery Check	Combination Meter
0735	Cruise Indicator	Combination Meter
0736	Indicator Of Radar Cruise	Combination Meter
0737	Shift-by-wire Warning	Combination Meter
0738	Automatic Transmission (A/T) Indicator Operation 3	Combination Meter
0739	Meter Display 1	Combination Meter
0740	PPS Indicator	Combination Meter
0741	Auxiliary Battery Charge Warning	Combination Meter
0742	Left-Hand Rear Door Open Indicator	Combination Meter
0743	Water Level Indicator Lamp	Combination Meter
0744	Indicate Economy	Combination Meter
0745	Four Wheel Drive (4WD) Indicator	Combination Meter
0746	Toyota Electronically Modulated Suspension (TEMS) Sports Indicator	Combination Meter

0747	Coolant Cool Indicator Lamp	Combination Meter
0748	Coolant Hot Indicator Lamp	Combination Meter
0749	GLOW Indicator	Combination Meter
0750	Oil Pressure Indicator	Combination Meter
0751	Electronic Controlled Braking (ECB) Indicator Lamp	Combination Meter
0752	Active Traction Control System (TRC) Indicator	Combination Meter
0753	VSC TRC Indicator	Combination Meter
0754	4-Wheel Drive (4WD) Warning Indicator	Combination Meter
0755	Indicate Headlamp Auto Leveling	Combination Meter
0756	Adaptive Front Lighting System (AFS) Indicator	Combination Meter
0757	Luggage Door Open Indicator Lamp	Combination Meter
0758	Back Door Open Indicator Lamp	Combination Meter
0759	Hood Door Open Indicator Lamp	Combination Meter
0760	Tail Indicator Lamp	Combination Meter
0761	Head Indicator Lamp	Combination Meter
0762	Rear Fog Indicator Lamp	Combination Meter
0763	Electrical Controlled Transmission (ECT) Power Indicator Lamp	Combination Meter
0764	Electrical Controlled Transmission (ECT) Snow Indicator Lamp	Combination Meter
0765	Cruise Indicator Lamp	Combination Meter
0766	Fuel Indicator Lamp	Combination Meter
0767	Rear Light Indicator Lamp	Combination Meter
0768	Oil Level Indicator Lamp	Combination Meter
0769	Seat Belt - Driver Side	Combination Meter
0770	Brake Indicator Lamp	Combination Meter
0771	Charge Indicator Lamp	Combination Meter
0772	Operation Of Tachometer	Combination Meter
0773	Operation Of Fuel Meter	Combination Meter
0774	Operation Of Water Temperature Meter	Combination Meter
0775	Operation Of Speed Meter	Combination Meter
0776	Vehicle Stability Control (VSC) Indicator Lamp	Combination Meter
0777	Slip Indicator Lamp	Combination Meter
0778	Beam Indicator Lamp	Combination Meter
0779	Airbag Indicator Lamp	Combination Meter
0780	Washer Indicator Lamp	Combination Meter
0781	Operation Of Volt Meter	Combination Meter
0782	Operation Of Oil Pressure Meter	Combination Meter



0783	Operation Of Left Turn Light Relay	Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0784	Operation Of Right Turn Light Relay	Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0785	Tail Light Relay	Main Body, Theft Deterrent, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2, Smart Key
0786	Advanced Illumination System	Main Body
0787	Interior Illumination Light 1	Main Body
0788	Interior Illumination Light 2	Main Body
0789	Forced Retracting Of Power Running Board	Main Body
0790	Relay for Interior Light Auto Cut Function	Main Body
0791	Fuel Lid Lock	Main Body
0792	Opener Of Fuel Lid	Main Body
0793	Signal Of Reverse Gear	Main Body
0794	Day/Night Time Signal	Main Body
0795	Relay Of Rear Wiper Washer Motor	Main Body
0796	Power Supply Of Rear Wiper	Main Body
0797	Cargo Light	Main Body
0798	Side Mirror Foot Light	Main Body
0799	Step Light	Main Body
0800	Signal Of Parking Brake	Main Body
0801	Relay Of Rear Fog Light	Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0802	Unlock Shock Detection	Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0803	Right-Hand Courtesy Light	Main Body
0804	Left-Hand Courtesy Light	Main Body
0805	Interior Panel Relay	Main Body, Body, Gateway, Body No. 3, Body No. 4, Body No. 5, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0806	Dimmer Signal	Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0807	Wireless Buzzer	Main Body, Body, Gateway, Entry&Start, Body Electronic Area Network (BEAN) Gateway, Body No. 2, Smart Access
0808	Rear personal light	Main Body
0809	IG OFF P/W Control Permission Output	Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0810	Door Lock/Unlock State Lamp	Main Body
0811	Center Console Spot Light	Main Body
0812	Fr Foot Light	Main Body
0813	Ceiling Light	Main Body
0814	Glass Hatch Open	Main Body
0815	Trunk and Back-Door Open	Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2

0816	Hazard	Main Body, Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0817	Driver Door Unlock	Main Body
0818	Indicator for Lighting	Main Body, Power Source Control
0819	4-Wheel Drive (4WD) Lock Light	4WD, 4-Wheel Drive (4WD), 4WD (CAN)
0820	4-Wheel Drive (4WD) Auto Mode Light	4WD, 4-Wheel Drive (4WD), 4WD (CAN)
0821	Slip Indicator Light	ABS/VSC/TRC, 4WD, ABS/VSC/TRC/EPB, 4-Wheel Drive (4WD), ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), 4WD (CAN), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0822	4-Wheel Drive (4WD) Warning Light	ABS/VSC/TRC, 4WD, ABS/VSC/TRC/EPB, 4-Wheel Drive (4WD), ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), 4WD (CAN), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0823	Lane Departure Alert (LDA) Buzzer	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA), Lane Departure Alert (LDA)
0824	Vibration Of Steering Wheel	Lane-Keeping Assist (LKA)/Lane Departure Alert (LDA), Lane Control, Lane Departure Alert (LDA)
0825	Vehicle Stability Control (VSC)/Traction Control System (TRC) Off Indicator Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB
0826	Brake Warning Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0827	Warning Light Of Anti-Slip Regulation System (ARS)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0828	Antilock Brake System (ABS) Warning Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0829	Warning Light Of Vehicle Stability Control (VSC)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0830	Electronic Braking System (EBS) Relay	ABS/VSC/TRC, Brake/EPB, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Brake

0831	Accumulator Zero Down	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0832	Warning Light Of Tire Pressure Monitoring System (TPMS)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0833	Vehicle Stability Control (VSC)/Traction Control System (TRC) Solenoid	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0834	A-Traction Control System (TRC) Indicator Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0835	Vehicle Stability Control (VSC) Off Indicator Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0836	Traction Control System (TRC) Off Indicator Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0837	Electronic Controlled Braking (ECB) Solenoid (SCC)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0838	Electronic Controlled Braking (ECB) Solenoid (SSC)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0839	Electronic Controlled Braking (ECB) Main Relay	ABS/VSC/TRC, Brake/EPB, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), Brake, ABS/VSC/TRC (TRAC) /EPB
0840	Cut Valve Pattern Of Stroke Simulator	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0841	ECB Solenoid (SRC)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB

0842	Electronic Controlled Braking (ECB) Solenoid (SMC)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0843	Electronic Controlled Braking (ECB) Solenoid (SC2)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0844	Electronic Controlled Braking (ECB) Solenoid (SC1)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0845	Electronic Controlled Braking (ECB) Solenoid (SMC/SRC/SCC)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0846	Downhill Assist Control Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0847	Auto Limited Slip Differential (LSD) Indicator Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0848	Right Rear Wheel Air Bleeding Pattern	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0849	Left Rear Wheel Air Bleeding Pattern	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0850	Electronic Controlled Braking (ECB) Control Not Valid	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0851	Tire Pressure Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0852	Electronic Controlled Braking (ECB) Warning Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB

0853	DAB Indicator Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0854	Electronic Controlled Braking (ECB) Main Relay 2	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0855	Air Bleeding Pattern 1 Of Power Supply	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0856	Air Bleeding Pattern 2 Of Power Supply	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0857	Actuator Air Bleeding Pattern	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0858	Electronic Controlled Braking (ECB) Solenoid (SLRRL) Valve Open	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0859	Electronic Controlled Braking (ECB) Solenoid (SLRRR) Valve Open	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0860	Electronic Controlled Braking (ECB) Solenoid (SLARL) Valve Open	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0861	Electronic Controlled Braking (ECB) Solenoid (SLRFR) Valve Open	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0862	Electronic Controlled Braking (ECB) Solenoid (SLAFL) Valve Open	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB

0863	Electronic Controlled Braking (ECB) Solenoid (SLRFL) Valve Open	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0864	Electronic Controlled Braking (ECB) Solenoid (SLARR) Valve Open	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0865	Electronic Controlled Braking (ECB) Solenoid (SLR) Valve Close	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0866	Electronic Controlled Braking (ECB) Solenoid (SLA) Valve Close	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0867	Electronic Controlled Braking (ECB) Solenoid (SLAFR) Valve Open	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0868	Electronic Controlled Braking (ECB) Solenoid (SLRRR) Valve Close	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0869	Electronic Controlled Braking (ECB) Solenoid (SLARL) Valve Close	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0870	Electronic Controlled Braking (ECB) Solenoid (SLRRL) Valve Close	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0871	Electronic Controlled Braking (ECB) Solenoid (SLRFR) Valve Close	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0872	Electronic Controlled Braking (ECB) Solenoid (SLAFL) Valve Close	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB

0873	Electronic Controlled Braking (ECB) Solenoid (SLRFL) Valve Close	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0874	Electronic Controlled Braking (ECB) Solenoid (SLARR) Valve Close	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0875	Vehicle Stability Control (VSC)/Traction Control System (TRC) Solenoid - SPFL	ABS/VSC/TRC, ABS/VSC/TRC/EPB
0876	PPS Solenoid	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0877	Electronic Controlled Braking (ECB) Solenoid (SLAFR) Valve Close	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0878	Vehicle Stability Control (VSC)/Traction Control System (TRC) Solenoid - SMR	ABS/VSC/TRC, ABS/VSC/TRC/EPB
0879	Vehicle Stability Control (VSC)/Traction Control System (TRC) Solenoid - SPFR	ABS/VSC/TRC, ABS/VSC/TRC/EPB
0880	Vehicle Stability Control (VSC)/Traction Control System (TRC) Solenoid - SMF	ABS/VSC/TRC, ABS/VSC/TRC/EPB
0881	Vehicle Stability Control (VSC)/Traction Control System (TRC) Solenoid - SRMF	ABS/VSC/TRC, ABS/VSC/TRC/EPB
0882	Vehicle Stability Control (VSC)/Traction Control System (TRC) Solenoid - SRMR	ABS/VSC/TRC, ABS/VSC/TRC/EPB
0883	Vehicle Stability Control (VSC)/Traction Control System (TRC) Solenoid - SRCR	ABS/VSC/TRC, ABS/VSC/TRC/EPB
0884	Signal Buzzer Of Driving Support System (DSS)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB

0885	Relay Of Electronic Controlled Braking (ECB) Motor	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0886	Relay 2 Of Electronic Controlled Braking (ECB) Motor	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0887	Antilock Brake System (ABS) Solenoid	ABS/VSC/TRC, Brake/EPB, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), Brake, ABS/VSC/TRC (TRAC) /EPB
0888	Stop light System Indicator Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0889	Air Bleeding Pattern Of Drain System	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0890	Check Pattern Of Pump	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0891	Pre Crash Brake Off Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0892	BH Standby Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0893	BH Operated Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0894	Crawl Control Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB



0895	Vehicle Stability Control (VSC)/Traction Control System (TRC) Solenoid - SRCF	ABS/VSC/TRC, ABS/VSC/TRC/EPB
0896	Electronic Controlled Braking (ECB) Solenoid (SCSS)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0897	Electronic Controlled Braking (ECB) Solenoid (SMC1)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0898	Electronic Controlled Braking (ECB) Solenoid (SMC2)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0899	Antilock Brake System (ABS) Solenoid (SRRR)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0900	Antilock Brake System (ABS) Solenoid (SRRH)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0901	Antilock Brake System (ABS) Solenoid (SRLR)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0902	Antilock Brake System (ABS) Solenoid (SFLR)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0903	Antilock Brake System (ABS) Solenoid (SFRR)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0904	Antilock Brake System (ABS) Solenoid (SFRH)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0905	Antilock Brake System (ABS) Solenoid (SFLH)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0906	Antilock Brake System (ABS) Solenoid (SRLH)	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0907	Relay Of H/B Motor	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
0908	Relay Of Traction Control System (TRC/TRAC) Motor	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0909	Pre-Charge Pump	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0910	Relay Of Stop Light	ABS/VSC/TRC, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
0911	Solenoid Relay	ABS/VSC/TRC, Brake/EPB, ABS/VSC/TRC/EPB, ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), Brake, ABS/VSC/TRC (TRAC) /EPB

0912	Rear Room Light	Body, Gateway, Body No. 3, Body No. 4, Body No. 5, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0913	Output Of Driver Buckle Light	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0914	Output Of Passenger Buckle Light	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0915	Output Of Rear Buckle Light	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0916	Relay of DRL	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0917	Operation Of Step Light	Body, Gateway, Body No. 3, Body No. 4, Body No. 5, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0918	Light Operation Of Center Console	Body, Gateway, Body No. 3, Body No. 4, Body No. 5, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0919	Scuff Plate Light	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0920	Power Of Intrusion Sensor	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0921	Shift Reverse Signal	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0922	Right Rear Power Window Up/Down	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0923	Left Rear Power Window Up/Down	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0924	Passenger Power Window Up/Down	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0925	Other Electronic Control Unit (ECU) Power Cut	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0926	Up/Down Of Shoulder Belt	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0927	Dome Relay Cut	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0928	Door Open Warning Light	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0929	Rear Defogger	Body, Gateway, Body No. 3, Body No. 4, Body No. 5, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0930	Cancel Operation Of Rheostat	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0931	Control Of Wiper Angle	Body, Gateway, Body No. 3, Body No. 4, Body No. 5, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0932	Operation Of Rear Washer Relay	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0933	Motor Of Rear Wiper	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0934	Key Reminder Buzzer	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0935	Wiper Motor	Body, Gateway, Body Electronic Area Network (BEAN) Gateway, Body No. 2
0936	Key Lock	Power Source Control

0937	Security indicator	Entry&Start, Smart Access
0938	Rear Passenger Seat Outside Transmitter	Entry&Start, Smart Access
0939	Left Rear Power Window	Master Switch
0940	Power Window - Driver Side	Master Switch
0941	Power Window - Passenger Side	Master Switch, P Master Switch
0942	Right Rear Window	Master Switch
0943	Deck Light	Body No. 3, Body No. 4, Body No. 5
0944	Operation Of Interior Light	Body No. 3
0945	Dim Operation Of Interior Light	Body No. 3
0946	Operation Of Exterior Foot Light	Body No. 3
0947	Operation Of Seat Light	Body No. 3, Body No. 4, Body No. 5
0948	Operation Of Steering Light	Body No. 3, Body No. 4, Body No. 5
0949	Operation Of Shift Light	Body No. 3, Body No. 4, Body No. 5
0950	Left Turn Light	Body No. 3, Body No. 4, Body No. 5
0951	Operation Of Oil Film Washer Motor	Body No. 3, Body No. 4, Body No. 5
0952	Right Turn Light	Body No. 3, Body No. 4, Body No. 5
0953	Buckle Light 1	Body No. 3, Body No. 4, Body No. 5
0954	Relay Of Heater	Body No. 3, Body No. 4, Body No. 5
0955	Control Of Reverse Signal	Body No. 3, Body No. 4, Body No. 5
0956	Left Rear Room Light	Body No. 3, Body No. 4, Body No. 5
0957	Right Rear Room Light	Body No. 3, Body No. 4, Body No. 5
0958	Front Room Light	Body No. 3, Body No. 4, Body No. 5
0959	Alter L signal output	Body No. 3, Body No. 4, Body No. 5
0960	Buckle Light 2	Body No. 3, Body No. 4, Body No. 5
0961	Operation Of Shoulder Anchor	Body No. 3, Body No. 4, Body No. 5
0962	Head Light (High)	Body No. 3, Body No. 4, Body No. 5
0963	Head Light (Low)	Body No. 3, Body No. 4, Body No. 5
0964	Operation Of Left Cornering Light	Body No. 3, Body No. 4, Body No. 5
0965	Operation Of Right Cornering Light	Body No. 3, Body No. 4, Body No. 5
0966	Light Head High Daytime Running Light (DRL) Operation	Body No. 3, Body No. 4, Body No. 5
0967	License Light	Body No. 3, Body No. 4, Body No. 5, Back Door
0968	Check Headlight Indicator	AFS
0969	Map and Courtesy Light	Body
0970	Luggage Closer Close/Return Initial Position	Hardtop Retractable
0971	Passenger Mirror Fold/Return	Mirror, Right Mirror, Left Mirror
0972	Passenger Foot Light	Mirror, Right Mirror
0973	Heater Of Passenger Mirror	Mirror, Right Mirror, Left Mirror
0974	Driver Foot Light	Mirror, Right Mirror
0975	Driver Mirror Heater	Mirror, Right Mirror, Left Mirror

0976	Passenger Mirror Up/Down	Mirror, Right Mirror, Left Mirror
0977	Passenger Mirror Right/Left	Mirror, Right Mirror, Left Mirror
0978	Driver Mirror Up/Down	Mirror, Right Mirror, Left Mirror
0979	Driver Mirror Right/Left	Mirror, Right Mirror, Left Mirror
0980	Driver Mirror Fold/Return	Mirror, Right Mirror, Left Mirror
0981	Refreshing ECU	Left Rear Seat, Right Rear Seat
0982	Neckrest Operation	Left Rear Seat, Right Rear Seat
0983	Continuously Chime Of Meter	Immobiliser, Steering Lock
0984	Not P-position Warning	Immobiliser, Steering Lock
0985	Break Cable Warning	Immobiliser, Steering Lock
0986	Key Warning Not Match	Immobiliser, Steering Lock
0987	Warning Of Stuck Steering	Immobiliser, Steering Lock
0988	Meter Chime	Immobiliser, Steering Lock
0989	Meter Buzzer	Lane Control, Immobiliser, Steering Lock
0990	Memory Cancel Lamp	Driver Door, Passenger Door, Left Rear Door, Right Rear Door
0991	Courtesy Lamp	Driver Door, Passenger Door, Left Rear Door, Right Rear Door
0992	Rear Wiper	Back Door
0993	Driver Transmitter	Theft Deterrent, Smart Key, Security
0994	Passenger Transmitter	Theft Deterrent, Smart Key, Security
0995	Fr Transmitter	Theft Deterrent, Smart Key, Security
0996	Smart Indicator	Theft Deterrent, Smart Key, Security
0997	Rr Transmitter	Theft Deterrent, Smart Key, Security
0998	In Luggage Transmitter	Theft Deterrent, Smart Key, Security
0999	Luggage Transmitter	Theft Deterrent, Smart Key, Security
1000	Key Remained Buzzer	Theft Deterrent, Combination Meter, Smart Key
1001	Hazard Lamp	Theft Deterrent, Smart Key
1002	Response Sound Of Buzzer	Theft Deterrent, Smart Key, Security
1003	Over Head Tuner	Theft Deterrent, Smart Key
1004	Inside Luggage Tuner	Theft Deterrent, Smart Key
1005	Operation Of Seat Belt Anchor	Tilt&Telescopic
1006	All Courtesy Output	Body, Body No. 2
1007	Operation Of Rheostat	Body, Body No. 2
1008	Bus Cut Relay No. 1	Body, Body No. 2
1009	Bus Cut Relay No. 2	Body, Body No. 2
1010	Super Sonic Windshield Mirror	Body, Body No. 2
1011	Output Of Alter L Signal	Body, Body No. 2
1012	Trunk and back-door open	Body, Body No. 2
1013	Wireless Buzzer (continuous sound)	Body, Body No. 2
1014	Passenger Side Air Outlet Servomotor Step	Air Conditioner
1015	Exhaust Damper Position (Rear)	Air Conditioner
1016	Rear Air Mix Damper	Air Conditioner
1017	Position Of Rear Air Outlet Damper	Air Conditioner
1018	Driver Side Air Outlet Servomotor Step	Air Conditioner

1019	Driver Side Air Mix Servomotor Step	Air Conditioner
1020	Passenger Side Air Mix Servomotor Step	Air Conditioner
1021	Position Of Air Inlet Damper (Linear)	Air Conditioner
1022	Driver Side Cool Air Bypass Damper	Air Conditioner
1023	Passenger Side Cool Air Bypass Damper	Air Conditioner
1024	Driver Side Air Mix Damper	Air Conditioner
1025	Passenger Side Air Mix Damper	Air Conditioner
1026	Position Of Driver Side Air Outlet Damper	Air Conditioner
1027	Position Of Passenger Side Air Outlet Damper	Air Conditioner
1028	Actuator Check	Air Conditioner
1029	Operation Of Automatic Transmission (A/T) Indicator	Combination Meter
1030	Coolant Temperature LCD	Combination Meter
1031	Smart Key Indicator	Combination Meter
1032	Required Maintenance	Combination Meter
1033	Variable Gear Ratio Steering (VGRS) Indicator	Combination Meter
1034	Multi-Display	Combination Meter
1035	Electronic Controlled Braking (ECB) Indicator	Combination Meter
1036	Indicat. A/T Shift LCD	Combination Meter
1037	Odometer/Trip Display Indicator	Combination Meter
1038	Overdrive Off Indicator Lamp	Combination Meter
1039	L-Cruise Ready Indicator Lamp	Combination Meter
1040	L-Cruise Check Indicator Lamp	Combination Meter
1041	Laser Cruise Display Indicator	Combination Meter
1042	Traction Control System (TRAC/TRC) Off Indicator Lamp	Combination Meter
1043	Off Indicator Of Daytime Running Light (DRL)	Combination Meter
1044	Circuit Mode Indicator	Combination Meter
1045	Speedometer Liquid Crystal Display (LCD)	Combination Meter
1046	indicat ECD ON	Combination Meter
1047	Engine (HV E/G Nonstop Mode)	Combination Meter
1048	Indicate DABS	Combination Meter
1049	Headlamp Auto Level Indicator Lamp	Combination Meter

1050	Vehicle Stability Control (VSC) Off Indicator Lamp	Combination Meter
1051	Compass Display Indicator	Combination Meter
1052	Speed Buzzer	Combination Meter
1053	Warning Buzzer	Combination Meter
1054	Ready Buzzer	Combination Meter
1055	Torque Converter Oil Temperature Indicator Lamp	Combination Meter
1056	Reject Buzzer Of Sports Shift	Combination Meter
1057	Reverse Buzzer	Combination Meter
1058	Seat Belt Buzzer	Combination Meter
1059	Light Remained Buzzer	Combination Meter
1060	Laser Cruise at Constant-Speed	Combination Meter
1061	Economy Indicator Lamp	Combination Meter
1062	Door Indicator Lamp	Combination Meter
1063	Exhaust Temperature Indicator Lamp	Combination Meter
1064	Oil Indicator Lamp	Combination Meter
1065	Engine Indicator Lamp	Combination Meter
1066	Anti-Slip Regulation System (ARS) Indicator Lamp	Combination Meter
1067	Turn Left Indicator Lamp	Combination Meter
1068	Turn Right Indicator Lamp	Combination Meter
1069	Solenoid Of Accumulator	EMS, Air suspension, AHC
1070	Front Leveling Solenoid	EMS, Air suspension, AHC
1071	Solenoid Of Front Gate	EMS, Air suspension, AHC
1072	Right Rear Damper Test	EMS, Air suspension, AHC
1073	Main Relay	EMS, Air suspension, AHC
1074	Right Front Damper Test	EMS, Air suspension, AHC
1075	Right Rear Height	EMS, Air suspension, AHC
1076	Right Front Height	EMS, Air suspension, AHC
1077	Electronic Controlled Braking (ECB) Not Valid	ABS/VSC/TRC, ABS/VSC/TRAC
1078	Warning Light Of Tire Pressure	ABS/VSC/TRC, ABS/VSC/TRAC
1079	Indicator Light Of Electronic Controlled Braking (ECB)	ABS/VSC/TRC, ABS/VSC/TRAC
1080	Master Cut Valve 2	ABS/VSC/TRC, ABS/VSC/TRAC
1081	Electronic Controlled Braking (ECB) Main Relay 1	ABS/VSC/TRC, ABS/VSC/TRAC
1082	Traction Control System (TRC) Solenoid - SPFL	ABS/VSC/TRC
1083	Master Cut Valve 1	ABS/VSC/TRC, ABS/VSC/TRAC
1084	Traction Control System (TRC) Solenoid - SMR	ABS/VSC/TRC
1085	Traction Control System (TRC) Solenoid - SPFR	ABS/VSC/TRC
1086	Traction Control System (TRC) Solenoid - SRMF & SRMR	ABS/VSC/TRC

1087	Traction Control System (TRC) Solenoid - SMF	ABS/VSC/TRC
1088	Traction Control System (TRC) Solenoid - SRMF	ABS/VSC/TRC
1089	Traction Control System (TRC) Solenoid - SRMR	ABS/VSC/TRC
1090	Traction Control System (TRC) Solenoid - SRCR	ABS/VSC/TRC
1091	Traction Control System (TRC) Solenoid - SRCF & SRCR	ABS/VSC/TRC
1092	Traction Control System (TRC) Solenoid - SA1	ABS/VSC/TRC
1093	Traction Control System (TRC) Solenoid - SA2	ABS/VSC/TRC
1094	Traction Control System (TRC) Solenoid - SRLR & SRLH	ABS/VSC/TRC
1095	Traction Control System (TRC) Solenoid - SMFL	ABS/VSC/TRC
1096	Antilock Brake System (ABS) Solenoid (SFLR & SFLH)	ABS/VSC/TRC, ABS/VSC/TRAC
1097	Traction Control System (TRC) Solenoid - SMFR	ABS/VSC/TRC
1098	Cut Relay Of Exhaust Brake	ABS/VSC/TRC, ABS/VSC/TRAC
1099	Sub-Throttle	ABS/VSC/TRC, ABS/VSC/TRAC
1100	Relay Of Traction Control System (TRC) Motor	ABS/VSC/TRC
1101	Antilock Brake System (ABS) Motor Relay	ABS/VSC/TRC, ABS/VSC/TRAC
1102	ES Start Light	ABS/VSC/TRC, ABS/VSC/TRAC
1103	Acceleration Slip Regulation (ASR)/Traction Control System (TRC) Warning Light	ABS/VSC/TRC
1104	Relay 2 Of Motor	ABS/VSC/TRC, ABS/VSC/TRAC, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1105	ES Start Buzzer	ABS/VSC/TRC, ABS/VSC/TRAC
1106	Relay 1 Of Motor	ABS/VSC/TRC, ABS/VSC/TRAC, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1107	Traction Control System (TRC) Solenoid - SMR & SPFR	ABS/VSC/TRC
1108	Traction Control System (TRC) Solenoid - SRCF	ABS/VSC/TRC
1109	Traction Control System (TRC) Solenoid - SMFR & SMFL	ABS/VSC/TRC
1110	Traction Control System (TRC) Solenoid - SRRR & SRRH	ABS/VSC/TRC

1111	Traction Control System (TRC) Solenoid - SRH	ABS/VSC/TRC
1112	Traction Control System (TRC) Solenoid - SFRH & SFLH	ABS/VSC/TRC
1113	Traction Control System (TRC) Solenoid - SA1 & SA2	ABS/VSC/TRC
1114	Traction Control System (TRC) Solenoid - SFLR & SFLH	ABS/VSC/TRC
1115	Traction Control System (TRC) Solenoid - SFRR & SFRH	ABS/VSC/TRC
1116	Traction Control System (TRC) Solenoid - SS	ABS/VSC/TRC
1117	Solenoid - SLA	ABS/VSC/TRC, ABS/VSC/TRAC
1118	Solenoid - SLR	ABS/VSC/TRC, ABS/VSC/TRAC
1119	Traction Control System (TRC) Solenoid - SMC1	ABS/VSC/TRC
1120	Traction Control System (TRC) Solenoid - SMC2	ABS/VSC/TRC
1121	Warning Buzzer Of Vehicle Stability Control (VSC) H/B	ABS/VSC/TRC, ABS/VSC/TRAC
1122	Antilock Brake System (ABS) Solenoid (SRRR & SRRH)	ABS/VSC/TRC, ABS/VSC/TRAC
1123	Antilock Brake System (ABS) Solenoid (SFRH & SFLH)	ABS/VSC/TRC, ABS/VSC/TRAC
1124	Antilock Brake System (ABS) Solenoid (SFRR & SFRH)	ABS/VSC/TRC, ABS/VSC/TRAC
1125	Antilock Brake System (ABS) Solenoid (SRLR & SRLH)	ABS/VSC/TRC, ABS/VSC/TRAC
1126	Fuel Pump	Engine and ECT
1127	Purge Cut Vacuum Switching Valve (VSV)	Engine and ECT
1128	Relay Of A/C Magnetic Clutch	Engine and ECT
1129	Idle Up Vacuum Switching Valve (VSV)	Engine and ECT
1130	Variable Valve Timing Lift (VVTL) Control - Bank 1	Engine and ECT
1131	Vapor Pressure Vacuum Switching Valve (VSV)	Engine and ECT
1132	Canister Pressure Control Vacuum Switching Valve (VSV)	Engine and ECT
1133	Tank Pressure Bypass Vacuum Switching Valve (VSV)	Engine and ECT
1134	Exhaust Gas Control VSV	Engine and ECT



1135	Exhaust Bypass Valve	Engine and ECT
1136	E-ABV Step	Engine and ECT
1137	Boost Pressure Control Vacuum Switching Valve (VSV)	Engine and ECT
1138	Automatic Oil Supply	Engine and ECT
1139	Air Bleed	Engine and ECT
1140	Intake Air Control Vacuum Switching Valve (VSV)	Engine and ECT
1141	Variable Valve Timing (VVT) Control - Bank 1	Engine and ECT
1142	Intake Control Vacuum Switching Valve (VSV) 2	Engine and ECT, Engine, Engine2
1143	Supercharger Control Relay	Engine and ECT
1144	Variable Valve Timing (VVT) Control - Bank 2	Engine and ECT
1145	Purge Vacuum Switching Valve (VSV)	Engine and ECT
1146	SLS Pressure	Engine and ECT
1147	Idle Air Control Valve (IACV) Motor	Engine and ECT
1148	Fuel Pressure	Engine and ECT
1149	Motor Of Fan	Engine and ECT
1150	AICV VSV	Engine and ECT
1151	Vent Valve	Engine and ECT
1152	Vacuum Pump	Engine and ECT
1153	HC Adsorber and Catalyst VSV	Engine and ECT
1154	Timing Solenoid	Engine and ECT
1155	SB Solenoid	Engine and ECT
1156	Active Control Mount	Engine and ECT, Engine, Engine2
1157	Fuel Shutoff Valve for Delivery Pipe	Engine and ECT
1158	Fuel Shutoff Valve for Press Regulator	Engine and ECT
1159	Line Pressure Up Solenoid	Engine and ECT
1160	Slip Control Solenoid	Engine and ECT
1161	Fuel Cut Idle Prohibit	Engine and ECT
1162	TE1(TC)	Engine and ECT
1163	Overdrive Cut Solenoid	Engine and ECT
1164	C/D Control Solenoid	Engine and ECT
1165	Variable Valve Timing Lift (VVTL) Control - Bank 2	Engine and ECT
1166	SLS Solenoid	Engine and ECT
1167	Lock Up Solenoid	Engine and ECT
1168	Fuel Pressure Up VSV	Engine and ECT
1169	Exhaust Gas Recirculation (EGR) System	Engine and ECT
1170	Intake Control Vacuum Switching Valve (VSV) 1	Engine and ECT
1171	Idle Air Control (IAC) Step	Engine and ECT
1172	Exhaust Gas Recirculation (EGR) Step	Engine and ECT

1173	Air Conditioning (A/C) Cut Signal	Engine and ECT, Engine, Engine2
1174	Variable Intake VSV	Engine and ECT
1175	Injector volume	Engine and ECT
1176	Idle Air Control (IAC) Duty	Engine and ECT
1177	Secondary Air Vacuum Switching Valve (VSV)	Engine and ECT
1178	SCV Vacuum Switching Valve (VSV)	Engine and ECT
1179	Relay Of Fuel Pump	Engine and ECT
1180	Shift	Engine and ECT
1181	Sliding Sunshade	Sliding Sunshade
1182	Sound	ASC
1183	Rear Suspension Arm (RSA) Simple Display Request	Road Sign Assist
1184	Activate the Clutch Stroke	ASG
1185	Release the Gear Stuck	ASG
1186	Activate the Oil Cooler Motor	ASG
1187	Activate the HPU Motor	ASG
1188	Activate the Gear Position	ASG
1189	Manual Switch Indicator	Active Rear Wing
1190	Wing Extend	Active Rear Wing
1191	Wing Fold	Active Rear Wing
1192	Wing and Deflector Extend/Fold	Active Rear Wing
1193	Wing Angle	Active Rear Wing
1194	Activate the EVAP Purge VSV	Engine, Transmission
1195	Control the Intake VVT OCV Duty Ratio Bank 1	Engine, Transmission
1196	Control the Exhaust VVT OCV Duty Ratio Bank 1	Engine, Transmission
1197	Control the Target Fuel Pressure Offset	Engine, Transmission
1198	Control the Intercooler Water Pump	Engine, Transmission
1199	Control the Fuel Pump Duty Ratio	Engine, Transmission
1200	Control the Engine Cooling Fan Duty Ratio	Engine, Transmission
1201	Activate the Air Bypass Valve	Engine, Transmission
1202	Control the Wastegate Valve Duty Ratio	Engine, Transmission
1203	Activate the TC Terminal	Engine, Transmission
1204	Activate the Fuel Pressure Discharge	Engine, Transmission
1205	Activate the Circuit Relay	Engine, Transmission
1206	Control the Engine Cooling Fan	Engine, Transmission
1207	Activate the Solenoid (SC2)	Engine, Transmission, Hybrid Control, EV

1208	Activate the Solenoid (SC1)	Engine, Transmission, Hybrid Control, EV
1209	Activate the Solenoid (SLP)	Engine, Transmission
1210	Activate the Solenoid (SLS) MAX/MIN	Engine, Transmission
1211	Activate the Solenoid (SLS) High/Low	Engine, Transmission
1212	Activate the Solenoid (SC)	Engine, Transmission
1213	Activate the ACM Inhibit	Engine, Transmission
1214	Activate the Coolant Water Route Switching Valve	Engine, Transmission
1215	Control the Intake VVT OCV Duty Ratio Bank 2	Engine, Transmission
1216	Control the Exhaust VVT OCV Duty Ratio Bank 2	Engine, Transmission
1217	Control the ACIS VSV Motor Duty Ratio	Engine, Transmission
1218	Single Phase Energization Of Fuel Pump	Engine, Transmission
1219	Activate the Solenoid (SL6)	Engine, Transmission
1220	Activate the Solenoid (SC3)	Engine, Transmission
1221	Control the Electric Thermostat Duty Ratio	Engine, Transmission
1222	Control the VVT-iE Opening Angle Bank 1	Engine, Transmission
1223	Activate the Coolant Water Route Switching Valve 2	Engine, Transmission
1224	Activate the Engine Oil Pressure Control Valve	Engine, Transmission
1225	Control the VVT-iE Opening Angle Bank 2	Engine, Transmission
1226	Prohibit the Idle Fuel Cut	Engine, Transmission
1227	Prohibit the Catalyst OT Misfire Prevent Fuel Cut	Engine, Transmission
1228	Control the Injection Mode	Engine, Transmission
1229	Activate the Lock Up Solenoid	Engine, Transmission
1230	D-4S (4 Cylinder Fuel Cut)	Engine
1231	Control the Shift Area (CVT)	Engine, Transmission
1232	D-4S (6 Cylinder Fuel Cut)	Engine
1233	Operation Of Buzzer (800Hz, Vol L, With Damping)	Combination Meter
1234	Operation Of Buzzer (800Hz, Vol L, Without Damping)	Combination Meter
1235	Operation Of Buzzer (800Hz, Vol S, With Damping)	Combination Meter

1236	Operation Of Buzzer (800Hz, Vol S, Without Damping)	Combination Meter
1237	Operation Of Buzzer (1.6kHz, Vol S, Without Damping)	Combination Meter
1238	Operation Of Buzzer (2.0kHz, Vol S, Without Damping)	Combination Meter
1239	Operation Of Buzzer (2.4kHz, Vol L, Without Damping)	Combination Meter
1240	Multi Display All (White)	Combination Meter
1241	Multi Display Default Screen	Combination Meter
1242	Indicator Of Fuel Gauge	Combination Meter
1243	Vehicle Stop Warning	Combination Meter
1244	Go to Service Warning	Combination Meter
1245	Indicator Of Headlamp	Combination Meter
1246	Tail Lamp Indicator	Combination Meter
1247	Indicator Of Front Fog Lamp	Combination Meter
1248	Indicator Of Rear Fog Lamp	Combination Meter
1249	Indicator Of Auto Leveling Headlamp	Combination Meter
1250	Indicator Of Automatic High Beam (Green)	Combination Meter
1251	Indicator Of Automatic High Beam (Yellow)	Combination Meter
1252	Warning Of LED Headlamp	Combination Meter
1253	Rear Light Indicator	Combination Meter
1254	Seat Belt Warning - Driver Side	Combination Meter
1255	Warning Of Passenger Side Seat Belt	Combination Meter
1256	Warning Of Rear Seat Belt	Combination Meter
1257	Washer Warning	Combination Meter
1258	Open Warning Of Door	Combination Meter
1259	Warning Of Airbag	Combination Meter
1260	Pedestrian Protection Warning	Combination Meter
1261	Indicator Of Auto Air Conditioner	Combination Meter
1262	Emergency Exit Warning	Combination Meter
1263	Warning Of Oil Pressure	Combination Meter
1264	Warning Of Oil Level	Combination Meter
1265	GLOW Warning	Combination Meter
1266	Hot Warning Lamp Of Coolant	Combination Meter
1267	Coolant Cool Warning Lamp	Combination Meter
1268	Water Level Warning	Combination Meter
1269	ECONO Indicator	Combination Meter
1270	Maintenance Warning	Combination Meter
1271	Warning Of Timing Belt	Combination Meter

1272	Warning Of Fuel Filter	Combination Meter
1273	Check Engine Warning	Combination Meter
1274	Fuel Warning (Compressed Natural Gas)	Combination Meter
1275	Indicator Of LPG	Combination Meter
1276	Reductant Warning	Combination Meter
1277	Electrical Controlled Transmission (ECT) Power Indicator	Combination Meter
1278	Electrical Controlled Transmission (ECT) Snow Indicator	Combination Meter
1279	Sport Indicator - CVT Sport	Combination Meter
1280	ECO Mode Indicator	Combination Meter
1281	Warning Of MMT E Mode	Combination Meter
1282	SIL Indicator - Up	Combination Meter
1283	SIL Indicator - Down	Combination Meter
1284	Automatic Transmission (A/T) Oil Temperature Warning	Combination Meter
1285	Automatic Transmission (A/T) Pressure Warning	Combination Meter
1286	4-Wheel Drive (4WD) Warning	Combination Meter
1287	4-Wheel Drive (4WD) Auto Indicator	Combination Meter
1288	4-Wheel Drive (4WD) Indicator (Green)	Combination Meter
1289	4-Wheel Drive (4WD) Indicator (Yellow)	Combination Meter
1290	Indicator Of Center Differential Lock	Combination Meter
1291	Indicator Of Rear Differential Lock	Combination Meter
1292	4-Wheel Drive (4WD) Lock Indicator	Combination Meter
1293	4 Low (4LO) Indicator	Combination Meter
1294	iMT Indicator (Green)	Combination Meter
1295	iMT Indicator (Yellow)	Combination Meter
1296	NAVI Continuously Variable Transmission (CVT) Indicator	Combination Meter
1297	Brake Warning	Combination Meter
1298	Warning Of Park	Combination Meter
1299	Antilock Brake System (ABS) Warning	Combination Meter
1300	Electronic Controlled Braking (ECB) Warning	Combination Meter
1301	Slip Warning	Combination Meter
1302	ACTIVE TRC Warning	Combination Meter
1303	Brake Hold Indicator	Combination Meter
1304	Hold Indicator	Combination Meter

1305	Downhill Assist Control Indicator	Combination Meter
1306	Warning Of Downhill Assist Control	Combination Meter
1307	Crawl Warning	Combination Meter
1308	Warning Of OFF Road Guidance	Combination Meter
1309	Indicator Of Tire Pressure Warning System	Combination Meter
1310	Electric Power Steering (EPS) Warning	Combination Meter
1311	PPS Warning	Combination Meter
1312	Variable Gear Ratio Steering (VGRS) Warning	Combination Meter
1313	Adaptive Variable Suspension (AVS) Sports Indicator	Combination Meter
1314	Adaptive Variable Suspension (AVS) Comfort Indicator	Combination Meter
1315	KDSS Warning	Combination Meter
1316	Height High Warning	Combination Meter
1317	Indicator Of Air Suspension (High)	Combination Meter
1318	Indicator Of Air Suspension (Low)	Combination Meter
1319	Indicator Of Luggage Mode - Yellow	Combination Meter
1320	Pre-Collision System (PCS) Off Warning	Combination Meter
1321	Pre-Collision System (PCS) Warning	Combination Meter
1322	Indicator Of Radar Cruise - Yellow	Combination Meter
1323	Cruise Indicator (Yellow)	Combination Meter
1324	SET Indicator	Combination Meter
1325	Lane Departure Alert (LDA) Steering Control Indicator	Combination Meter
1326	Indicator Of Drift From The Lane	Combination Meter
1327	Warning Of Drift From The Lane	Combination Meter
1328	Lane Departure Alert (LDA) Indicator	Combination Meter
1329	Lane Departure Alert (LDA) Warning	Combination Meter
1330	Left Lane-Departure Alert (LDA) Indicator	Combination Meter
1331	Left Lane-Departure Alert (LDA) Warning	Combination Meter
1332	Right Lane Departure Alert (LDA) Indicator	Combination Meter
1333	Right Lane Departure Alert (LDA) Warning	Combination Meter

1334	ASL Warning	Combination Meter
1335	Blind Spot Monitor (BSM) Indicator	Combination Meter
1336	Blind Spot Monitor (BSM) Warning	Combination Meter
1337	Indicator Of RCTA	Combination Meter
1338	Intelligent Clearance Sonar (ICS) Off Warning	Combination Meter
1339	Intelligent Parking Assist Indicator	Combination Meter
1340	Brake Override Warning	Combination Meter
1341	Ready Indicator	Combination Meter
1342	EV Drive Indicator	Combination Meter
1343	Hot Warning Of HV Unit	Combination Meter
1344	SOC Warning	Combination Meter
1345	Charge Indicator	Combination Meter
1346	Charge Warning	Combination Meter
1347	Warning Of Hydrogen Leak	Combination Meter
1348	All Indicators	Combination Meter
1349	Warning Of Auxiliary Battery	Combination Meter
1350	Odometer (ODO)/Trip Change Switch	Combination Meter
1351	Trip Reset Switch	Combination Meter
1352	Multi Display Select Switch	Combination Meter
1353	Meter Day Mode Switch	Combination Meter
1354	Light Control Switch - Single	Combination Meter
1355	Timer Switch - Single	Combination Meter
1356	Speedometer Operation (0km/h, 0MPH)	Combination Meter
1357	Speedometer Operation (40km/h, 40MPH)	Combination Meter
1358	Speedometer Operation (80km/h, 80MPH)	Combination Meter
1359	Speedometer Operation (120km/h, 120MPH)	Combination Meter
1360	Speedometer Operation (160km/h, 160MPH)	Combination Meter
1361	Speedometer Operation (200km/h, 200MPH)	Combination Meter
1362	Speedometer Operation (240km/h, 240MPH)	Combination Meter
1363	Speedometer Operation (280km/h, 280MPH)	Combination Meter
1364	Speedometer Operation (320km/h, 320MPH)	Combination Meter
1365	Speedometer Operation (360km/h, 360MPH)	Combination Meter
1366	Speedometer Operation (400km/h, 400MPH)	Combination Meter
1367	Operation Of Tachometer - 0 RPM	Combination Meter

1368	TachoMeter Operation (1000rpm)	Combination Meter
1369	TachoMeter Operation (2000rpm)	Combination Meter
1370	TachoMeter Operation (3000rpm)	Combination Meter
1371	TachoMeter Operation (4000rpm)	Combination Meter
1372	TachoMeter Operation (5000rpm)	Combination Meter
1373	TachoMeter Operation (6000rpm)	Combination Meter
1374	TachoMeter Operation (7000rpm)	Combination Meter
1375	TachoMeter Operation (8000rpm)	Combination Meter
1376	TachoMeter Operation (9000rpm)	Combination Meter
1377	TachoMeter Operation (10000rpm)	Combination Meter
1378	Operation Of Fuel Gauge (Sender E)	Combination Meter
1379	Operation Of Fuel Gauge (Empty)	Combination Meter
1380	Operation Of Fuel Gauge (Warning)	Combination Meter
1381	Operation Of Fuel Gauge (1/4)	Combination Meter
1382	Operation Of Fuel Gauge (1/2)	Combination Meter
1383	Operation Of Fuel Gauge (3/4)	Combination Meter
1384	Operation Of Fuel Gauge (Full)	Combination Meter
1385	Operation Of Fuel Gauge (Sender F)	Combination Meter
1386	Operation Of Sub Fuel Gauge - Sender E	Combination Meter
1387	Operation Of Sub Fuel Gauge - Empty	Combination Meter
1388	Operation Of Sub Fuel Gauge - 1/4	Combination Meter
1389	Operation Of Sub Fuel Gauge - 1/2	Combination Meter
1390	Operation Of Sub Fuel Gauge - 3/4	Combination Meter
1391	Operation Of Sub Fuel Gauge - Full	Combination Meter
1392	Operation Of Sub Fuel Gauge - Sender F	Combination Meter
1393	Operation Of Water Temperature Meter - 50C, 122F	Combination Meter



1394	Operation Of Water Temperature Meter - 60C, 140F	Combination Meter
1395	Operation Of Water Temperature Meter - 70C, 158F	Combination Meter
1396	Operation Of Water Temperature Meter - 80C, 176F	Combination Meter
1397	Operation Of Water Temperature Meter - Middle	Combination Meter
1398	Operation Of Water Temperature Meter - 110C, 230F	Combination Meter
1399	Operation Of Water Temperature Meter - 120C, 248F	Combination Meter
1400	Operation Of Water Temperature Meter - 127C, 260F	Combination Meter
1401	Operation Of Volt Meter - 0V	Combination Meter
1402	Operation Of Volt Meter - 3V	Combination Meter
1403	Operation Of Volt Meter - 6V	Combination Meter
1404	Operation Of Volt Meter - 9V	Combination Meter
1405	Operation Of Volt Meter - 12V	Combination Meter
1406	Operation Of Volt Meter - 15V	Combination Meter
1407	Operation Of Volt Meter - 18V	Combination Meter
1408	Operation Of Oil Pressure Meter (Low)	Combination Meter
1409	Operation Of Oil Pressure Meter (1/4)	Combination Meter
1410	Operation Of Oil Pressure Meter (1/2)	Combination Meter
1411	Operation Of Oil Pressure Meter (3/4)	Combination Meter
1412	Operation Of Oil Pressure Meter (High)	Combination Meter
1413	Indicator Of HV System (Minimum)	Combination Meter
1414	Indicator Of HV System (-50%)	Combination Meter
1415	Indicator Of HV System (0%)	Combination Meter
1416	Indicator Of HV System (100%)	Combination Meter
1417	Indicator Of HV System (200%)	Combination Meter

1418	Indicator Of HV System (300%)	Combination Meter
1419	Indicator Of HV System (400%)	Combination Meter
1420	Indicator Of HV System (Maximum)	Combination Meter
1421	SOC Gauge (MIN)	Combination Meter
1422	SOC Gauge (1/4)	Combination Meter
1423	SOC Gauge (1/2)	Combination Meter
1424	SOC Gauge (3/4)	Combination Meter
1425	SOC Gauge (MAX)	Combination Meter
1426	Fuel Gauge Operation for CNG (Sender E)	Combination Meter
1427	Fuel Gauge Operation for CNG (Empty)	Combination Meter
1428	Fuel Gauge Operation for CNG (Warning)	Combination Meter
1429	Fuel Gauge Operation for CNG (1/4)	Combination Meter
1430	Fuel Gauge Operation for CNG (1/2)	Combination Meter
1431	Fuel Gauge Operation for CNG (3/4)	Combination Meter
1432	Fuel Gauge Operation for CNG (Full)	Combination Meter
1433	Fuel Gauge Operation for CNG (Sender F)	Combination Meter
1434	Meter Display (All)	Combination Meter
1435	Meter Display (0)	Combination Meter
1436	Meter Display (1)	Combination Meter
1437	Meter Display (2)	Combination Meter
1438	Meter Display (3)	Combination Meter
1439	Meter Display (4)	Combination Meter
1440	Meter Display (5)	Combination Meter
1441	Meter Display (6)	Combination Meter
1442	Meter Display (7)	Combination Meter
1443	Meter Display (8)	Combination Meter
1444	Meter Display (9)	Combination Meter
1445	Automatic Transmission (A/T) Indicator Operation (Park)	Combination Meter
1446	Automatic Transmission (A/T) Indicator Operation (Reverse)	Combination Meter
1447	Automatic Transmission (A/T) Indicator Operation (Neutral)	Combination Meter
1448	Automatic Transmission (A/T) Indicator Operation (Drive)	Combination Meter
1449	Automatic Transmission (A/T) Indicator Operation (4)	Combination Meter

1450	Automatic Transmission (A/T) Indicator Operation (3)	Combination Meter
1451	Automatic Transmission (A/T) Indicator Operation (2)	Combination Meter
1452	Automatic Transmission (A/T) Indicator Operation (Low)	Combination Meter
1453	Automatic Transmission (A/T) Indicator Operation (Brake)	Combination Meter
1454	Automatic Transmission (A/T) Indicator Operation (Sport)	Combination Meter
1455	Automatic Transmission (A/T) Indicator Operation (Sport M)	Combination Meter
1456	Automatic Transmission (A/T) Indicator Operation (Sport S)	Combination Meter
1457	Speed Signal Input 0	Combination Meter
1458	Speed Signal Input 40	Combination Meter
1459	Speed Signal Input 80	Combination Meter
1460	Speed Signal Input 120	Combination Meter
1461	Speed Signal Input 160	Combination Meter
1462	Speed Signal Input 200	Combination Meter
1463	Speed Signal Input 240	Combination Meter
1464	Speed Signal Input 280	Combination Meter
1465	Speed Signal Input 320	Combination Meter
1466	Speed Signal Input 360	Combination Meter
1467	Speed Signal Input 400	Combination Meter
1468	Light Control Switch - UP	Combination Meter
1469	Light Control Switch - Down	Combination Meter
1470	Timer Switch - H	Combination Meter
1471	Timer Switch - M	Combination Meter
1472	Timer Switch - 00	Combination Meter
1473	Multi Switch (Up)	Combination Meter
1474	Multi Switch (Down)	Combination Meter
1475	Multi Switch (Left)	Combination Meter
1476	Multi Switch (Right)	Combination Meter
1477	Multi Switch (Enter)	Combination Meter
1478	Multi Switch (Back)	Combination Meter
1479	Multi Switch (Top)	Combination Meter
1480	Stop&Start Buzzer	Stop and Start
1481	Heater Water Pump	Stop and Start
1482	Stop&Start Permit Condition (Engine)	Stop and Start
1483	Stop&Start Permit Condition (Battery)	Stop and Start
1484	Stop&Start Permit Condition (Anti-Lock Brake System)	Stop and Start

1485	Stop&Start Permit Condition (Air Conditioner)	Stop and Start
1486	Stop&Start Precondition 2 (Control)	Stop and Start
1487	Electromagnetic Oil Pump	Stop and Start
1488	Accumulator Drive	Stop and Start
1489	Starter - Hood Close	Stop and Start
1490	Pinion Gear Plunger - Hood Close	Stop and Start
1491	Drive Magnet Switch Of Starter Motor - Hood Close	Stop and Start
1492	Oil Pump	Stop and Start
1493	Activate the Inverter Water Pump	Hybrid Control, EV
1494	Control the Hybrid Battery Cooling Fan	Hybrid Control, EV, EV Battery, High Voltage (HV) Battery, HV battery
1495	Hybrid Battery Charge	Hybrid Control, EV
1496	Control the Motor/Generator Cooling Oil Pump	Hybrid Control, EV
1497	Control the Transmission Oil Pump	Hybrid Control, EV
1498	Relay Of Stop Lamp	Brake/EPB, Brake
1499	EX0	Brake/EPB, Brake
1500	Electronic Controlled Braking (ECB) Solenoid (SLR)	Brake/EPB, Brake
1501	Electronic Controlled Braking (ECB) Solenoid (SLA)	Brake/EPB, Brake
1502	Vehicle Stability Control (VSC) Solenoid	Brake/EPB, Brake
1503	Electronic Controlled Braking (ECB) Solenoid	Brake/EPB, Brake
1504	Radar Cruise Proximity Warning Buzzer	Radar Cruise 2
1505	Radar Cruise Stop Keeping Announce Buzzer	Radar Cruise 2
1506	Color Test Screen (Black)	Head Up Display
1507	Color Test Screen (White)	Head Up Display
1508	Color Test Screen (Red)	Head Up Display
1509	Color Test Screen (Green)	Head Up Display
1510	Color Test Screen (Blue)	Head Up Display
1511	Color Test Screen (Color Bars)	Head Up Display
1512	Color Test Screen (Adjustment)	Head Up Display
1513	Tilt Motor	Tilt&Telescopic
1514	Telescopic Motor	Tilt&Telescopic
1515	Sound (All CH)	Active Noise Control
1516	Sound 'CH1'	Active Noise Control
1517	Sound 'CH2'	Active Noise Control
1518	Sound 'CH3'	Active Noise Control

1519	Sound 'CH4'	Active Noise Control
1520	Relay Of Hybrid Battery Heater	EV Battery, High Voltage (HV) Battery, HV battery
1521	Green Indicator	Telematics
1522	Red Indicator	Telematics
1523	Activate the Charger Cooling Fan	Plug-in Control
1524	PCS Warning Buzzer	Pre-Collision System
1525	PCS Reminder Buzzer	Pre-Collision System
1526	PCS Collision Avoidance Assist	Pre-Collision System
1527	Check Type Support B	Engine and ECT, Engine, Engine2
1528	Activate VSV for Tank Bypass and Canister Control	Engine and ECT, Engine
1529	#6	Engine and ECT, Engine, ECT, Engine2
1530	#7	Engine and ECT, Engine, ECT, Engine2
1531	#8	Engine and ECT, Engine, ECT, Engine2
1532	#2	Engine and ECT, Engine, ECT, Engine2
1533	#3	Engine and ECT, Engine, ECT, Engine2
1534	#4	Engine and ECT, Engine, ECT, Engine2
1535	#5	Engine and ECT, Engine, ECT, Engine2
1536	Check the Imbalance Cylinder	Engine and ECT, Engine, ECT, Engine2
1537	#1	Engine and ECT, Engine, ECT, Engine2
1538	Vehicle Stability Control (VSC)/Traction Control System (TRAC) Off Indicator Light	ABS/VSC/TRAC, ABS/VSC/TRAC/EPB, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC)/EPB
1539	Vehicle Stability Control (VSC)/Traction Control System (TRAC) Solenoid - SPFL	ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
1540	Vehicle Stability Control (VSC)/Traction Control System (TRAC) Solenoid - SPFR	ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
1541	Vehicle Stability Control (VSC)/Traction Control System (TRAC) Solenoid - SMF	ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
1542	Vehicle Stability Control (VSC)/Traction Control System (TRAC) Solenoid - SMR	ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
1543	Vehicle Stability Control (VSC)/Traction Control System (TRAC) Solenoid - SRMF	ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
1544	Vehicle Stability Control (VSC)/Traction Control System (TRAC) Solenoid - SRMR	ABS/VSC/TRAC, ABS/VSC/TRAC/EPB

1545	Vehicle Stability Control (VSC)/Traction Control System (TRAC) Solenoid - SRCR	ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
1546	Vehicle Stability Control (VSC)/Traction Control System (TRAC) Solenoid - SRCF	ABS/VSC/TRAC, ABS/VSC/TRAC/EPB
1547	Traction Control System (TRAC) Solenoid - SPFL	ABS/VSC/TRAC
1548	Traction Control System (TRAC) Solenoid - SMR	ABS/VSC/TRAC
1549	Traction Control System (TRAC) Solenoid - SPFR	ABS/VSC/TRAC
1550	Traction Control System (TRAC) Solenoid - SRMF & SRMR	ABS/VSC/TRAC
1551	Traction Control System (TRAC) Solenoid - SMF	ABS/VSC/TRAC
1552	Traction Control System (TRAC) Solenoid - SRMF	ABS/VSC/TRAC
1553	Traction Control System (TRAC) Solenoid - SRMR	ABS/VSC/TRAC
1554	Traction Control System (TRAC) Solenoid - SRCR	ABS/VSC/TRAC
1555	Traction Control System (TRAC) Solenoid - SRCF & SRCR	ABS/VSC/TRAC
1556	Traction Control System (TRAC) Solenoid - SA2	ABS/VSC/TRAC
1557	Traction Control System (TRAC) Solenoid - SA1	ABS/VSC/TRAC
1558	Traction Control System (TRAC) Solenoid - SMFL	ABS/VSC/TRAC
1559	Traction Control System (TRAC) Solenoid - SMFR & SMFL	ABS/VSC/TRAC
1560	Traction Control System (TRAC) Solenoid - SMFR	ABS/VSC/TRAC
1561	Relay Of Traction Control System (TRAC) Motor	ABS/VSC/TRAC
1562	Acceleration Slip Regulation (ASR)/Traction Control System (TRAC) Warning Light	ABS/VSC/TRAC
1563	Traction Control System (TRAC) Solenoid - SMR & SPFR	ABS/VSC/TRAC
1564	Traction Control System (TRAC) Solenoid - SRCF	ABS/VSC/TRAC
1565	Traction Control System (TRAC) Solenoid - SRLR & SRLH	ABS/VSC/TRAC

1566	Traction Control System (TRAC) Solenoid - SRRR & SRRH	ABS/VSC/TRAC
1567	Traction Control System (TRAC) Solenoid - SRH	ABS/VSC/TRAC
1568	Traction Control System (TRAC) Solenoid - SFRH & SFLH	ABS/VSC/TRAC
1569	Traction Control System (TRAC) Solenoid - SA1 & SA2	ABS/VSC/TRAC
1570	Traction Control System (TRAC) Solenoid - SFRR & SFRH	ABS/VSC/TRAC
1571	Traction Control System (TRAC) Solenoid - SFLR & SFLH	ABS/VSC/TRAC
1572	Traction Control System (TRAC) Solenoid - SMC2	ABS/VSC/TRAC
1573	Traction Control System (TRAC) Solenoid - SS	ABS/VSC/TRAC
1574	Traction Control System (TRAC) Solenoid - SMC1	ABS/VSC/TRAC
1575	Tank Pressure Bypass VSV and Canister Pressure Control VSV	Engine and ECT
1576	Vent Value and Vacuum Pump	Engine and ECT
1577	Equalizing charge relay	Hybrid Control, HV
1578	cooling fan air volume	Hybrid Control, HV
1579	VSV variable intake	Engine, Engine and ECT, Engine2
1580	fuel pressure up VSV	Engine, Engine and ECT, Engine2
1581	Canister close valve	Engine, Engine and ECT, Engine2
1582	Fuel ho Nfu air vent	Engine, Engine and ECT, Engine2
1583	VSV intake passage control	Engine, Engine and ECT, Engine2
1584	Variable Valve Timing Lift (VVTL)-I NO.2 OCV	Engine, Engine and ECT, Engine2
1585	Variable Valve Timing Lift (VVTL)-I NO.1 OCV	Engine, Engine and ECT, Engine2
1586	tank bypass	Engine, Engine and ECT, Engine2
1587	SOL forward-reverse switching	Engine, Engine and ECT, Engine2
1588	lock-up control SOL	Engine, Engine and ECT, Engine2
1589	Shut-off valve delivery	Engine, Engine and ECT, Engine2
1590	Stratified combustion control force	Engine, Engine and ECT, Engine2
1591	Force stoichiometric control	Engine, Engine and ECT, Engine2
1592	Shut-off valve regulator	Engine, Engine and ECT, Engine2
1593	SOL engagement pressure control	Engine, Engine and ECT, Engine2
1594	0 / D cut SOL	Engine, Engine and ECT, Engine2
1595	Automatic lubrication oil	Engine, Engine and ECT, Engine2
1596	VSV boost pressure control	Engine, Engine and ECT, Engine2
1597	Sucha charger control	Engine, Engine and ECT, Engine2

1598	slip control SOL	Engine, Engine and ECT, Engine2
1599	exhaust bypass valve control	Engine, Engine and ECT, Engine2
1600	Exhaust valve control switch	Engine, Engine and ECT, Engine2
1601	Intake valve control switch	Engine, Engine and ECT, Engine2
1602	Bleed air	Engine, Engine and ECT, Engine2
1603	purge cut VSV	Engine, Engine and ECT, Engine2
1604	idle-up	Engine, Engine and ECT, Engine2
1605	VSV three-way	Engine, Engine and ECT, Engine2
1606	CVT shift position	ECT, Engine2
1607	Camera reference image	Night View
1608	Pedestrian Detection Frame	Night View
1609	Pedestrian Detectable Indicator	Night View
1610	Reminder Frame	Night View
1611	Pedestrian Undetectable Indicator	Night View
1612	Feet light	Right Mirror, Left Mirror, Right Front Door, Left Front Door
1613	Charging Control	Charging Control
1614	IG1	Power Source Control
1615	ACC Switch (MPX)	Power Source Control
1616	Ignition 2 Signal	Power Source Control
1617	Signal Of Engine Switch	Power Source Control
1618	RL seat buckle lighting	Body No. 4
1619	RR seat buckle lighting	Body No. 4
1620	FR wheel spring switching valve	Air suspension, Adaptive Variable Suspension (AVS) System
1621	rear wheel accumulator rise	Air suspension, Adaptive Variable Suspension (AVS) System
1622	front wheel accumulator rise	Air suspension, Adaptive Variable Suspension (AVS) System
1623	Height control front wheel	Air suspension, Adaptive Variable Suspension (AVS) System
1624	High-wheeled vehicles solenoid FL	Air suspension, Adaptive Variable Suspension (AVS) System
1625	Solenoid wheel vehicle height FR	Air suspension, Adaptive Variable Suspension (AVS) System
1626	pump motor relay	Air suspension, Adaptive Variable Suspension (AVS) System
1627	FL wheel spring switching valve	Air suspension, Adaptive Variable Suspension (AVS) System
1628	Rear gate valve	Air suspension, Adaptive Variable Suspension (AVS) System
1629	Front gate valve	Air suspension, Adaptive Variable Suspension (AVS) System
1630	Solenoid wheel vehicle height RL	Air suspension, Adaptive Variable Suspension (AVS) System
1631	High-wheeled vehicles solenoid RR	Air suspension, Adaptive Variable Suspension (AVS) System
1632	SLRG	Air suspension, Adaptive Variable Suspension (AVS) System



1633	SLRL	Air suspension, Adaptive Variable Suspension (AVS) System
1634	compressor motor relay	Air suspension, Adaptive Variable Suspension (AVS) System
1635	Accumulator valve	Air suspension, Adaptive Variable Suspension (AVS) System
1636	Height control rear wheel	Air suspension, Adaptive Variable Suspension (AVS) System
1637	Solenoid exhaust	Air suspension, Air Suspension, Adaptive Variable Suspension (AVS) System
1638	FR solenoid	Air suspension, Air Suspension, Adaptive Variable Suspension (AVS) System
1639	FL solenoid	Air suspension, Air Suspension, Adaptive Variable Suspension (AVS) System
1640	RR solenoid	Air suspension, Air Suspension, Adaptive Variable Suspension (AVS) System
1641	RL solenoid	Air suspension, Air Suspension, Adaptive Variable Suspension (AVS) System
1642	RL wheel height control	Air suspension, Air Suspension, Adaptive Variable Suspension (AVS) System
1643	RR wheel height control	Air suspension, Air Suspension, Adaptive Variable Suspension (AVS) System
1644	Height control wheel FL	Air suspension, Air Suspension, Adaptive Variable Suspension (AVS) System
1645	FR wheel height control	Air suspension, Air Suspension, Adaptive Variable Suspension (AVS) System
1646	motor relay	Air suspension, Air Suspension, Adaptive Variable Suspension (AVS) System
1647	dome lamp	Theft Deterrent, Security
1648	Self-powered siren	Entry&start, Entry&Start, Smart Key, Body
1649	heat exchange shut valve drive	Air Conditioner
1650	electric compressor rotation	Air Conditioner
1651	plasma cluster drive	Air Conditioner
1652	electric water pump	Air Conditioner
1653	High pressure solenoid valves	Air Conditioner
1654	Low pressure solenoid valves	Air Conditioner
1655	Dehumidification solenoid valves	Air Conditioner
1656	Rear A / C Magnet	Air Conditioner
1657	oxygen-rich drive	Air Conditioner
1658	viscous heater drive	Air Conditioner
1659	Three-way valve drive heating	Air Conditioner
1660	compressor drive valve	Air Conditioner
1661	electric heater 3	Air Conditioner
1662	ETC indicator	Combination Meter
1663	Water temperature gauge	Combination Meter
1664	Fuel gauge	Combination Meter
1665	Operation permission P / W	Main Body, Body
1666	shock sensing unlock	Main Body, Body

1667	All seats courtesy SW signal	Main Body
1668	down the high beam bulb light lighting output	Main Body
1669	LOCK light	4WD(CAN), 4-Wheel Drive (4WD)
1670	Motor relay	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
1671	pre-charge pump	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
1672	stop lamp relay	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
1673	brake control prohibition	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
1674	actuator operation confirmation	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
1675	TRC motor relay	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
1676	EBS relay	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
1677	Auto LSD light	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS/VSC/TRC (TRAC), ABS-VSC-TRC (TRAC), ABS/VSC/TRC (TRAC) /EPB
1678	buckle lighting	Body No. 3, Body No. 4, Body No. 5
1679	Lh cornering lamps	Body No. 3, Body No. 4, Body No. 5
1680	Rh cornering lamps	Body No. 3, Body No. 4, Body No. 5
1681	oil slick up washer motor	Body No. 3, Body No. 4, Body No. 5
1682	tuner power	Body, Body No. 2
1683	left swivel motor	AFS
1684	right swivel motor	AFS
1685	Leveling motor up off	AFS
1686	D seat foot lamp	Left Mirror
1687	P seat foot lamp	Left Mirror
1688	wireless buzzer (lock)	Body
1689	Rear washer motor	Body No. 5
1690	Suteroku confirmation warning	Immobiliser
1691	Suteroku not release warning	Immobiliser
1692	cable breakage warning	Immobiliser

1693	non-shift P warning	Immobiliser
1694	meter buzzer	Immobiliser
1695	meter chime	Immobiliser
1696	meter chime (continuous)	Immobiliser
1697	caught warning	Immobiliser
1698	key difference warning	Immobiliser
1699	Security Indicators	Immobiliser
1700	front fog relay	Security
1701	Tail relay	Security
1702	head lamp relay	Security
1703	bypass (pulse)	Air Conditioner
1704	P A / M (pulse)	Air Conditioner
1705	D blowout (pulse)	Air Conditioner
1706	suction port (pulse)	Air Conditioner
1707	D A / M (pulse)	Air Conditioner
1708	Rear A / C indicator	Air Conditioner
1709	rear air purifier	Air Conditioner
1710	rear exhaust damper position	Air Conditioner
1711	water valve	Air Conditioner
1712	suction port (servo motor)	Air Conditioner
1713	rear blower air volume	Air Conditioner
1714	active test	Air Conditioner
1715	Right Front Maximum Damper Step	Air Suspension
1716	Left Front Maximum Damper Step	Air Suspension
1717	Right Rear Maximum Damper Step	Air Suspension
1718	Left Rear Maximum Damper Step	Air Suspension
1719	Expectation Of Main Relay	Air Suspension
1720	Front damping force control	Air Suspension
1721	Rear damping force control	Air Suspension
1722	rear gate	Air Suspension
1723	front leveling	Air Suspension
1724	front gate	Air Suspension
1725	accumulator	Air Suspension
1726	front vehicle height control	Air Suspension
1727	rear vehicle height control	Air Suspension
1728	rear leveling	Air Suspension
1729	SS	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1730	Solenoid - SMC2	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1731	Solenoid - SS	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)

1732	SLA current solenoid	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1733	SLR current solenoid	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1734	brake warning lamp	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1735	ARS warning lamp	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1736	4WD warning lamp	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1737	Solenoid - SMC1	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1738	ABS lamp	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1739	VSC lamp	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1740	TRC OFF lamp	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1741	SLIP lamp	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1742	Station blur cut relay	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1743	sub-throttle	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1744	VSC- HB buzzer	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1745	ABS motor relay	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1746	ABS solenoid	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1747	VSC, TRC solenoid	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1748	HB motor relay	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1749	HB buzzer	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)

1750	Power supply pattern drive 2	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1751	brake warning lamp (yellow)	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1752	Power supply pattern drive 1	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1753	SCSS valve pattern	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1754	ESS buzzer	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1755	ESS lamp	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1756	actuator patterns drive	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1757	SLRRL (communication valve closed)	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1758	SLRFL (communication valve closed)	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1759	SLARR (communication valve closed)	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1760	SLRRR (communication valve closed)	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1761	SLARL (communication valve closed)	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1762	ARS actuator	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1763	SLAFR (communication valve closed)	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1764	SLRFR (communication valve closed)	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1765	SLAFL (communication valve closed)	Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
1766	Proximity Sound (10km/h, 6MPH)	Vehicle proximity notification system
1767	Proximity Sound (5km/h, 3MPH)	Vehicle proximity notification system
1768	Proximity Sound (15km/h, 9MPH)	Vehicle proximity notification system

1769	Proximity Sound (20km/h, 12MPH)	Vehicle proximity notification system
1770	Proximity Sound (Reverse 6km/h, 3.6MPH)	Vehicle proximity notification system
1771	Proximity Sound (30km/h, 18MPH)	Vehicle proximity notification system
1772	Security Camera Power Supply	Remote Security

XTOOL

# Special Functions List

No.	Functions Name	System Name
SP0001	Signal Check	ABS/VSC/TRC, Tire Pressure Monitor, EMPS, Supplement Restraint System (SRS) Airbag, EMS, Air suspension, VGRS, KDSS, AHC, Brake/EPB, ABS/VSC/TRAC, Adaptive Variable Suspension (AVS) System, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), EHPS, Air Suspension, Stabilizer, ABS-VSC-TRC (TRAC)
SP0002	ID Registration	Tire Pressure Monitor
SP0003	Reset Memory	Engine and ECT, Hybrid Control, ABS/VSC/TRC, Driver Door Motor, Passenger Door Motor, Left Rear Door Motor, Right Rear Door Motor, ECT, Electric Parking Brake, 4WD, Brake/EPB, Engine, ABS/VSC/TRAC, 4-Wheel Drive (4WD), Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), 4WD (CAN), HV, ABS-VSC-TRC (TRAC)
SP0004	Check Mode	Engine and ECT, Hybrid Control, Engine, Stop and Start, Supplement Restraint System (SRS) Airbag, ECT, EMPS, Electric Parking Brake, TVD, VGRS, DRS, Pedestrian Protection, Engine2, ABS/VSC/TRC/EPB, High Voltage (HV) Battery, Transmission, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), EHPS, Air suspension, Tire Pressure Monitor, Air Suspension, HV, HV battery, ABS-VSC-TRC (TRAC)
SP0005	Initialization	Hybrid Control, Main Body, PM1 Gateway, PM2 Gateway, Entry&Start, Pre-Crash 2, Gateway, Body, Accessory Gateway, No. 1 Multi Bus Monitor, No. 2 Multi Bus Monitor, HV Gateway, Engine Control Module (ECM) Gateway, Electronic Controlled Braking (ECB) Gateway, Whiplash Injury Lessening (WIL) Gateway, Pre-Collision 2, Gateway Controller Area Network (CAN), Central Gateway, Pre-Crash, HV
SP0006	Steering Initialization	Clearance Sonar, Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar, Intuitive Parking Assist, Advanced Parking Guidance/Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A)
SP0007	Height Offset	Air suspension, AHC, Adaptive Variable Suspension (AVS) System, Air Suspension

SP0008	Height Sensor Initialization	Auto Leveling Of Headlamp, AFS
SP0009	Abnormal Operation History	EMPS, VGRS, EHPS
SP0010	Torque Sensor Adjustment	EMPS, EHPS
SP0011	Key Code Registration	Entry&Start, Immobiliser, Theft Deterrent, Smart Key, Smart Access, Entry&start
SP0012	Driver Information Registration	Entry&Start, Smart Access, Smart Key, Entry&start
SP0013	Key Code Erasure	Entry&Start, Immobiliser, Theft Deterrent, Smart Key, Smart Access, Entry&start
SP0014	ECU Communication ID Registration	Entry&Start, Steering Lock, Smart Key, Smart Access, Entry&start, Immobiliser
SP0015	Communication Check(Key Diag Mode)	Entry&Start, Smart Key, Smart Access
SP0016	Refrigerant Gas Volume Check	Air Conditioner
SP0017	Servo motor initialization	Air Conditioner
SP0018	Wireless Door Lock Diagnosis Mode	Main Body, Entry&Start, Theft Deterrent, Smart Key, Smart Access
SP0019	Wireless Code Erasure	Main Body, Body, Theft Deterrent
SP0020	Wireless Code Registration	Main Body, Body, Theft Deterrent
SP0021	Test Mode	ABS/VSC/TRC, ABS/VSC/TRAC, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS-VSC-TRC (TRAC)
SP0022	Electronic Controlled Braking (ECB) Utility	ABS/VSC/TRC, ABS/VSC/TRAC, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS-VSC-TRC (TRAC)
SP0023	Air Bleeding	ABS/VSC/TRC, Brake/EPB, ABS/VSC/TRAC, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), ABS-VSC-TRC (TRAC)
SP0024	Inspection Mode	Hybrid Control, ABS/VSC/TRC, Brake/EPB, ABS/VSC/TRAC, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC), HV, ABS-VSC-TRC (TRAC)
SP0025	Air Bleeding - Bank 1	Hybrid Control, HV
SP0026	VIN	Engine and ECT, Hybrid Control, Engine
SP0027	Chassis Dynamometer Mode	Engine and ECT, Engine
SP0028	HICM Resistance Learning Value Reset	Engine and ECT, Engine
SP0029	CVT Oil Pressure Calibration	Engine and ECT, Engine, Transmission
SP0030	Deceleration Sensor Zero Point Calibration	Engine and ECT, Stop and Start, Engine, ECT
SP0031	Automatic Transmission (A/T) Unit Correction (Initialization)	Engine and ECT, Engine, ECT
SP0032	A/T Code Registration	Engine and ECT, Engine, ECT, Transmission
SP0033	Electric Throttle Learning	Engine and ECT, Engine
SP0034	Zero Point Calibration	Detection Of Occupant
SP0035	ECU Exchange	Detection Of Occupant, Stop and Start



SP0036	Sensitivity Check	Detection Of Occupant
SP0037	Steering Angle Adjust	VGRS
SP0038	Camera/Target Position Memory	Pre-Crash 2, Lane Keeping Assist (LKA), Pre-Collision 2, Lane Departure Alert (LDA), Pre-Crash
SP0039	Camera Axis Adjust	Pre-Crash 2, Lane Keeping Assist (LKA), Pre-Collision 2, Lane Departure Alert (LDA), Pre-Crash
SP0040	Rear Radar Optical Axis Adjustment	Pre-Crash 2, Pre-Crash
SP0041	Rear Radar Sensor Check	Pre-Crash 2, Pre-Crash
SP0042	Learning Value Reset	Engine and ECT, Engine
SP0043	Shift Control Synchronization	Engine, Engine and ECT
SP0044	Reset Of Recognition ECU High Temperature History	Pre-Crash 2, Pre-Collision 2, Pre-Crash
SP0045	Auto Power Off Cancel	Power Source Control
SP0046	Clear Trouble Factor Code	Remote Engine Starter
SP0047	Remote Engine Starter ID Registration	Remote Engine Starter
SP0048	Remote Engine Starter Initial Registration	Remote Engine Starter
SP0049	Map Information	Navigation System
SP0050	Video Device Connection Check	Navigation System
SP0051	Blower Motor Brush Wear Amount Initialization	Air Conditioner
SP0052	Control Mode Change	4WD, 4-Wheel Drive (4WD), 4WD (CAN)
SP0053	Normal Battery Stack Average Voltage Calculation	Hybrid Control
SP0054	High Voltage (HV) Battery Cell Low Voltage READY ON Prevention Cancel	Hybrid Control
SP0055	Battery Status Info Update	Hybrid Control, High Voltage (HV) Battery
SP0056	Battery Diagnosis	Hybrid Control, High Voltage (HV) Battery
SP0057	Temporary Vehicle Start Up	Hybrid Control
SP0058	Prediagnostic Battery Charge	Hybrid Control, High Voltage (HV) Battery
SP0059	Auxiliary Battery Exchange	Telematics
SP0060	Setting Of Data Communication Module (DCM) Mode	Telematics
SP0061	Beam Axis Adjustment	Radar Cruise 2, Cruise Control, Radar Cruise, Laser Cruise, Pre-Collision
SP0062	Laser/Radar Cruise Initialization	Radar Cruise, Laser Cruise
SP0063	Stabilizer System Check	Stabilizer
SP0064	Steering Sensor Initialization	AFS
SP0065	Transponder Code Registration	Immobiliser, Steering Lock
SP0066	Transponder Code Erasure	Immobiliser, Steering Lock, Security
SP0067	Camera Auto Adjustment	Night View

SP0068	Camera Manual Adjustment	Night View
SP0069	Beam Axis Misalignment Reading	Radar Cruise 2, Cruise Control, Radar Cruise
SP0070	BSM Master Abnormal History	Master Blind Spot Monitor, Slave Blind Spot Monitor
SP0071	BSM Master Beam Axis Inspection	Master Blind Spot Monitor, Slave Blind Spot Monitor
SP0072	Automatic Transmission Fluid (ATF) Thermal Degradation Estimate Reset	Engine and ECT, Engine, ECT
SP0073	Switch Oil Maintenance Display	Engine, Engine and ECT
SP0074	iMT Installation Information Reset	Engine and ECT, Engine
SP0075	Switch Battery Type	Engine, Engine and ECT
SP0076	Fuel Density Learning Value Reset	Engine and ECT, Engine
SP0077	Diagnosis mode	Navigation System
SP0078	Software Error History	Navigation System
SP0079	Optical Disc Error History	Navigation System
SP0080	Grill Shutter Control Mode Switching	Grill Shutter
SP0081	Activate Rear Steering Motor	DRS
SP0082	DRS Off-center Correction	DRS
SP0083	Dynamic Rear Steering (DRS) Neutral Memorization	DRS
SP0084	Vehicle Stability Control (VSC)/Traction Control System (TRC)/4WD Control Prevention Mode	ABS/VSC/TRC, 4WD, ABS/VSC/TRAC, 4-Wheel Drive (4WD)
SP0085	4-Wheel Drive (4WD) Control Prevention Mode	4WD, 4-Wheel Drive (4WD)
SP0086	Recognition Camera/Target Position Memory	Front Recognition Camera, Lane Departure Alert (LDA)
SP0087	Recognition Camera Axis Adjust	Front Recognition Camera, Lane Departure Alert (LDA)
SP0088	Electronic Controlled Braking (ECB)-R Utility	ABS/VSC/TRC, ABS/VSC/TRAC, Antilock Brake System (ABS)- Vehicle Stability Control (VSC)- Traction Control System (TRC)
SP0089	High Voltage Fuse Accumulated Load History Reset	Hybrid Control
SP0090	Clearance Sonar Detection/Steering Adjustment	Clearance Sonar
SP0091	Tire Circumference Setting	Clearance Sonar, Intelligent Parking Assist (IPA)/Intelligent Clearance Sonar (ICS)/Clearance Sonar, Advanced Parking Guidance/Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A)
SP0092	Reset A/C Information	Stop and Start
SP0093	Integrated Current Value Initialization	Stop and Start

SP0094	Deceleration Sensor Zero Point Clear	Stop and Start
SP0095	Oil Pump Air Bleeding	Stop and Start
SP0096	Starter Exchange	Stop and Start
SP0097	Total Number of Engine Starts Reset	Stop and Start
SP0098	GPF Deposition Values Save	Engine,Engine and ECT
SP0099	GPF Deposition Values Write	Engine,Engine and ECT
SP0100	GPF Deposition Values Clear	Engine,Engine and ECT
SP0101	A/T Code Reset	Engine and ECT, Engine, ECT, Transmission
SP0102	Engine Oil Jet Control Check	Engine
SP0103	i-ART Learning Value Reset	Engine and ECT, Engine
SP0104	Engine Oil Pressure Control Check	Engine and ECT, Engine
SP0105	DPF Deterioration Record Clear	Engine and ECT
SP0106	Learning Values Confirmation	Engine and ECT, Engine
SP0107	Pilot Quantity Learning (Detail)	Engine and ECT, Engine
SP0108	Wide Inter-cylinder Correction Learning Value Initialization	Engine and ECT, Engine
SP0109	A/F Sensor Learning Value Initialization	Engine and ECT, Engine
SP0110	Injector Compensation	Engine and ECT, Engine
SP0111	Pilot Quantity Learning	Engine and ECT, Engine
SP0112	Catalyst Record Clear	Engine and ECT
SP0113	Supply Pump Learning Value Initialization	Engine and ECT, Engine
SP0114	Switch Specification Information	Engine
SP0115	Heavy Knock History	Engine
SP0116	PM Rejuvenate Mode	Engine,Engine and ECT
SP0117	ID Registration/Tire Number Registration	Tire Pressure Monitor
SP0118	ID Registration/Tire Position Write	Tire Pressure Monitor
SP0119	Tire Position Write	Tire Pressure Monitor
SP0120	Front Side Radar Master Abnormal History	Front Side Radar Master
SP0121	Front Side Radar Master Beam Axis Display	Front Side Radar Master
SP0122	Front Side Radar Master Beam Axis Adjustment	Front Side Radar Master
SP0123	Front Side Radar Slave Abnormal History	Front Side Radar Slave
SP0124	Front Side Radar Slave Beam Axis Display	Front Side Radar Slave
SP0125	Front Side Radar Slave Beam Axis Adjustment	Front Side Radar Slave

SP0126	Initial Axis Adjust Value Display	Front Recognition Camera
SP0127	Front Beam Axis Adjustment	Front Radar Sensor, Pre-Collision 2
SP0128	Front Beam Axis Misalignment Reading	Pre-Crash 2, Front Radar Sensor, Pre-Collision 2, Pre-Crash
SP0129	Front Radar Acceleration Sensor Calibration	Front Radar Sensor
SP0130	Air Transfer Pattern C	Air suspension
SP0131	Height Control Prohibition Switch	Air suspension
SP0132	Air Transfer Pattern A	Air suspension
SP0133	Air Transfer Pattern B	Air suspension
SP0134	History Clear	Pre-Crash 2, Radar Cruise 2, Front Recognition Camera, Pre-Collision 2
SP0135	ASG System Initial Learning	ASG
SP0136	Rear Wing Zero Point Calibration	Active Rear Wing
SP0137	BSM Slave Beam Axis Inspection	Slave Blind Spot Monitor
SP0138	Sensor Adjustment	KDSS
SP0139	Pilot Quantity Learning Values Reset	Engine and ECT
SP0140	Vehicle Mileage Write	Engine and ECT
SP0141	Drive History Reset	Engine2
SP0142	Grill Shutter Initialization	Grill Shutter
SP0143	Control Mode	Pre-Crash 2, Pre-Collision 2, Pre-Crash
SP0144	Front Beam Axis Offset Reading	Pre-Crash 2, Pre-Collision 2, Pre-Crash
SP0145	Key Number Registration	Steering Lock, Theft Deterrent, Immobiliser
SP0146	Key Number Change	Steering Lock, Theft Deterrent, Immobiliser
SP0147	Communication Check (Key Diag Mode)	Theft Deterrent, Smart Key
SP0148	Auto Registration Closure	Immobiliser
SP0149	VSC Line Air Bleeding	ABS/VSC/TRC, ABS/VSC/TRAC
SP0150	ECB2.0/2.5 Utility	ABS/VSC/TRC
SP0151	Stabilizer Check	Front Stabilizer, Rear Stabilizer
SP0152	Motor Rotation Angle Sensor Calibration	Front Stabilizer, Rear Stabilizer
SP0153	Rear Beam Axis Adjustment	Pre-Crash 2
SP0154	Valet Mode Cancel	Navigation System
SP0155	Camera Synchronous Error History	Navigation System
SP0156	Clearance Sonar Detection Adjustment (Simple)	Clearance Sonar
SP0157	Calibration	Brake/EPB
SP0158	DCM Service	Telematics
SP0159	Backup Battery Replacement Reset	Telematics
SP0160	NAD Firmware Update	Telematics
SP0161	PM Regenerate Mode	Engine and ECT, Engine
SP0162	Secondary Air Injection Check	Engine and ECT, Engine

SP0163	Wi-Fi Connection History	Navigation System
SP0164	Bluetooth Connection History	Navigation System
SP0165	Diagnostic Mode	Navigation System
SP0166	ECU Information Sync	AFS, Auto Leveling Of Headlamp
SP0167	Smart Code Erasure	Smart Access, Smart Key
SP0168	Smart Code Reset	Smart Key, Smart Access
SP0169	Refrigerant Filling Mode	Air Conditioner
SP0170	Refrigerant High Pressure History Clear	Air Conditioner
SP0171	Refrigerant Recovery Preparation Mode	Air Conditioner
SP0172	A/C Operation Limitation History Count Clear	Air Conditioner
SP0173	Middle Differential Pressure Valve State Check	Air Conditioner
SP0174	Cruising Range Reset	Combination Meter
SP0175	Electronic Controlled Braking (ECB) 2.0/2.5 Utility	ABS/VSC/TRAC
SP0176	Zero Point Calibration & Sensitivity Check	Detection Of Occupant
SP0177	BSM Master Beam Axis Adjustment	Master Blind Spot Monitor
SP0178	BSM Master Beam Axis Display	Master Blind Spot Monitor
SP0179	BSM Slave Abnormal History	Slave Blind Spot Monitor
SP0180	BSM Slave Beam Axis Adjustment	Slave Blind Spot Monitor
SP0181	BSM Slave Beam Axis Display	Slave Blind Spot Monitor
SP0182	PCS Image Information Clear	Front Recognition Camera
SP0183	PCS Image Record Setting	Front Recognition Camera
SP0184	Headlight Type Setting	Front Recognition Camera
SP0185	Intuitive P/A Detection/Steering Adjustment	Advanced Parking Guidance/Intelligent Clearance Sonar (ICS)/Intuitive Parking Assist (P/A)
SP0186	EPB Control Switch	Brake/EPB
SP0187	EPB Full release	Brake/EPB
SP0188	Cancel Communication Function Pausing	Telematics
SP0189	Remote door lock setting	Main Body, Telematics
SP0190	DCM Firmware Update	Telematics
SP0191	Fuse Shut Off History	Power Integration No.1, Power Integration No.2, Power Integration No.3
SP0192	Wiper Specification Switch	Steering Angle Sensor
SP0193	Wiper Arm Installation	Main Body
SP0194	Parts Exchange Learning	TVD
SP0195	Undesignated Key Permanent Erasure	Smart Access
SP0196	Key Registration	Steering Lock, Immobiliser, Security
SP0197	Rear Cooling Unit Check	Air Conditioner

SP0198	Engine Control Values Initialization	Engine, Engine and ECT
SP0199	Left Front Side Radar Optical Axis Adjustment	Pre-Crash
SP0200	Right Front Side Radar Optical Axis Adjustment	Pre-Crash
SP0201	Smart Communication Check	Entry&start, Smart Key, Entry&Start
SP0202	Learning Value Initialization	TVD
SP0203	Camera Angle Adjustment Mode	Digital Side-View Monitor
SP0204	Front Recognition Camera Axis Misalignment Reading	Front Recognition Camera
SP0205	Wireless Diagnosis Mode	Security
SP0206	Navigation System Type Learning	Connection Of ITS