## LUXGEN V1. 42 Function List (for your information)

	LUMUI				1011	птос	(lor your ii	HOT Mat 10H/
Remark: ●Su	pports this	feature OWitho	out this f		01	- ·		
Vehicle	System	System Name	Informat ion	Read DTCs	Clear DTCs	Read Datas	Active test	Special function
MPV Series	MPV	engine control module	•	•	•	•	•	Crankshaft position to adapt to the sampling count, production start up counter, the vehicle identification number, code or repair shop tes equipment serial number, calibration reset the date, the date of the correction reflashing
MPV Series	MPV	transmission system	•	•	•	•	•	
MPV Series	MPV	anti-lock brake system	0	•	•	•	•	ABS exhaust, ABS vacuum oiling
MPV Series	MPV	meter	•	•	•	0	•	
MPV Series	MPV	Body Control Module	•	•	•	•	•	Overspeed warning function settings
MPV Series	MPV	FECU	•	•	•	0		J. Company
MPV Series	MPV	CSW	•	•	•	•	0	
MPV Series	MPV	GW	•	•	•	0	0	· ·
MPV Series	MPV	air- conditioning system	•	•	•		•	
MPV Series	MPV	THINK+	•	•	•	0		
MPV Series	MPV	HMI	•	•	•		0	
MPV Series	MPV	DVD	•	•	•	0	0	
MPV Series	MPV	LDWS+	•	•	•	•	•	
MPV Series	MPV	TPMS+	•	<b>A</b> •	•	0	0	
MPV Series	MPV	KCU	•	•			•	
MPV Series	MPV	srs- supplementary restraint system	•	•	•	•	•	Ignition lock, ignition unlocking
MPV Series	MPV	PSD left	•	•		•	0	
MPV Series	MPV	PSD Right	•	•	•	•	0	
MPV Series	MPV	bend auxiliary lighting system	•	•	•	•	•	
MPV Series	MPV	anti-theft	•		•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning

MPV Series	CEO	engine control module	•	•	•	•	•	Crankshaft position to adapt to the sampling count, production start-up counter, the vehicle identification number, code or repair shop test equipment serial number, calibration reset the date, the date of the correction reflashing
MPV Series	CE0	transmission system	•	•	•	•	•	
MPV Series	CEO	anti-lock brake system	0	•	•	•	•	ABS exhaust, ABS vacuum oiling
MPV Series	CEO	meter	•	•	•	0	•	
MPV Series	CEO	Body Control Module	•	•	•	•	•	Overspeed warning function settings
MPV Series	CE0	FECU	•	•	•	0	•	
MPV Series	CE0	CSW	•	•	•	•	0	
MPV Series	CEO	GW	•	•	•	0	0	A
MPV Series	CEO	air- conditioning system	•	•	•	•	•	
MPV Series	CEO	THINK+	•	•	•	0		
MPV Series	CEO	HMI	•	•	•	•	0	
MPV Series	CEO	DVD	•	•	•	0	0	
MPV Series MPV Series	CEO CEO	DVBT LDWS+	•	•	•	0	0	
MPV Series	CEO	KCU		•			•	
MPV Series	CEO	srs- supplementary restraint system	•	•	•		•	Ignition lock, ignition unlocking
MPV Series	CEO CEO	PSD left PSD Right	-				0	
MPV Series	CEO	bend auxiliary lighting system	•	• (	•		•	
MPV Series	CEO	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
MPV Series	MPV RA (2012)	engine control module	•	•	•	•	•	Crankshaft position to adapt to the sampling count, production start-up counter, the vehicle identification number, code or repair shop test equipment serial number, calibration reset the date, the date of the correction reflashing
MPV Series	MPV RA (2012)	transmission system	•	•	•	•	•	

		<b>I</b>		ı	ı	, ,		1
MPV Series	MPV RA(2012)\a nti-lock brake system	anti-lock brake	0	•	•	•	•	ABS exhaust, ABS vacuum oiling
MPV Series	MPV RA(2012)\a nti-lock brake system	electronic stability control	•	•	•	•	0	ABS vacuum oiling
MPV Series	MPV RA (2012)	meter	•	•	•	0	•	
MPV Series	MPV RA (2012)	Body Control Module	•	•	•	•	•	Overspeed warning function settings
MPV Series	MPV RA (2012)	FECU	•	•	•	0	•	
MPV Series	MPV RA (2012)	CSW	•	•	•	•	0	
MPV Series	MPV RA (2012)	GW	•	•	•	0	0	
MPV Series	MPV RA (2012)	air- conditioning system	•	•	•	•	•	
MPV Series	MPV RA (2012)	switchbox	•	•	•	•	0	
MPV Series	MPV RA (2012)	THINK+	•	•	•	0	•	
MPV Series	MPV RA (2012)	HMI	•	•	•	• /	0	
MPV Series	MPV RA(2012)	DVD	•	•	•	0	0	
MPV Series	MPV RA(2012)	lane departure warning system	•	•	•		•	
MPV Series	MPV RA (2012)	KCU	•	•	•	•	•	
MPV Series	MPV RA (2012)	srs- supplementary restraint system	•	•	•	•	•	Ignition lock, ignition unlocking
MPV Series	MPV RA (2012)	PSD left	•	•	•	•	0	
MPV Series	MPV RA (2012)	PSD Right	•	•	•	•	0	
MPV Series	MPV RA (2012)	bend auxiliary lighting system	•	•	•	•	•	
MPV Series	MPV RA (2012)	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning

MPV Series	MPV ML	engine control module	•	•	•	•	•	Crankshaft position to adapt to the sampling count, production start-up counter, the vehicle identification number, code or repair shop test equipment serial number, calibration reset the date, the date of the correction reflashing
MPV Series	MPV ML	transmission system	•	•	•	•	•	
MPV Series	MPV ML	anti-lock brake system	0	•	•	•	•	ABS exhaust, ABS vacuum oiling
MPV Series	MPV ML	meter	•	•	•	0	•	
MPV Series	MPV ML	Body Control Module	•	•	•	•	•	Overspeed warning function settings
MPV Series	MPV ML	FECU	•	•	•	0	•,	
MPV Series	MPV ML	CSW	•	•	•	•	0	
MPV Series	MPV ML	GW	•	•	•	0	0	
MPV Series	MPV ML	air- conditioning system	•	•	•	•		
MPV Series	MPV ML	car computer	•	•	•	0		
MPV Series	MPV ML	HMI	•	•	•	•	0	
MPV Series	MPV ML	DVD	•	•	•	0	0	
MPV Series	MPV ML	lane departure warning system	•	•	•		•	
MPV Series	MPV ML	KCU	•	•	•		•	
MPV Series	MPV ML	srs- supplementary restraint system	•	1	•	•	•	Ignition lock, ignition unlocking
MPV Series	MPV ML	PSD left	•	•			0	
MPV Series	MPV ML	PSD right	•	•		•	0	
MPV Series	MPV ML	AFS (KEBODA)	•	•		•	•	
MPV Series	MPV ML	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
MPV Series	MPV ML	switchbox	•	•	•	•	0	
MPV Series	MPV MC	engine control module	•	•	•	•	•	Crankshaft position to adapt to the sampling count, production start-up counter, the vehicle identification number, code or repair shop test equipment serial number, calibration reset the date, the date of the correction reflashing
MPV Series	MPV MC	transmission system	•	•	•	•	•	
MPV Series	MPV MC	anti-lock brake system	0	•	•	•	•	ABS exhaust, ABS vacuum oiling
MPV Series	MPV MC	meter	•	•	•	0	•	

	1	<u> </u>						Io
MPV Series	MPV MC	Body Control Module	•	•	•	•	•	Overspeed warning function settings
MPV Series	MPV MC	FECU	•	•	•	0	•	
MPV Series	MPV MC	CSW	•	•	•	•	0	
MPV Series	MPV MC	GW	•	•	•	0	0	
MPV Series	MPV MC	air- conditioning system	•	•	•	•	•	
MPV Series	MPV MC\OBU	switch box	•	•	•	0	0	
MPV Series	MPV MC\OBU	CarPC	•	•	•	•	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, on / off NaviBox, EQ function unsealed
MPV Series	MPV MC	HMI	•	•	•	•	0	
MPV Series	MPV MC\DVD	Porton	•	•	•	0	0	
MPV Series	MPV MC\DVD	Panasonic	•	•	•	0	0	
MPV Series	MPV MC	FRD	•	•	•	0	0	
MPV Series	MPV MC	AMP	•		•	0	0	
MPV Series	MPV MC	EVS	•		•	0	0	
MPV Series	MPV MC	FRD	•	•	•	0	0	
MPV Series	MPV MC	TK	•		•	0	0	
MPV Series	MPV MC	NAVIBOX	÷			0	0	
MI / Delles	MI V MC	NAVIDOA		_				
MPV Series	MPV MC	lane departure warning system	•	•	•	•	•	
MPV Series	MPV MC	KCU	•	<b>A</b> •	• \		•	
MPV Series	MPV MC	srs- supplementary restraint system	•	•		•	•	Ignition lock, ignition unlocking
MPV Series	MPV MC	PSD left	•			•	0	
MPV Series		PSD Right	•	• 7	•		0	
MPV Series	MPV MC	Auto Body level system	•	•	•	•	•	ALS initialization correction
MPV Series	MPV MC	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
MPV Series	СЕО МС	engine control module	•	•	•	•	•	Crankshaft position to adapt to the sampling count, production start-up counter, the vehicle identification number, code or repair shop test equipment serial number, calibration reset the date, the date of the correction reflashing
MPV Series	CEO MC	transmission system	•	•	•	•	•	

							ī	
MPV Series	CEO MC	electronic stability control system	•	•	•	•	0	ABS vacuum oiling
MPV Series	CEO MC	Meter	•	•	•	0	•	
MPV Series	CEO MC	BCM	•	•	•	•	•	Overspeed warning function settings
MPV Series	CEO MC	FECU	•	•	•	0	•	
MPV Series	CEO MC	CSW	•	•	•	•	0	
MPV Series	CEO MC	GW	•	•	•	0	0	
MPV Series	CEO MC	air- conditioning system	•	•	•	•	•	
MPV Series	СЕО МС	switch box	•	•	•	•	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, on / off NaviBox, EQ function unsealed
MPV Series	CEO MC	HMI	•	•	•	•	0	
MPV Series	CEO MC	DVD	•	•	•	0	0	
MPV Series	CEO MC	FRD	•	•	•	0	0	
MPV Series	CEO MC	KCU	•	•	•	•		
MPV Series	CEO MC	SRS	•	•	•	•	•	Ignition lock, ignition unlocking
MPV Series	CEO MC	PSD left	•	•	•	•	0	
MPV Series	CEO MC	PSD Right	•	•	•	•	0	
MPV Series	CEO MC	Auto Body level system	•	•	•	•	•	ALS initialization correction
MPV Series	СЕО МС	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
MPV Series	MPV RA (2015)	engine control module	•		•	•	•	Crankshaft position to adapt to the sampling count, production start-up counter, the vehicle identification number, code or repair shop test equipment serial number, calibration reset the date, the date of the correction reflashing
MPV Series	MPV RA(2015)	transmission system (AISIN)	•	•	•	•	•	N range learning
MPV Series	MPV RA (2015)	electronic stability control system	•	•	•	•	0	ABS vacuum oiling
MPV Series	MPV RA (2015)	Meter	•	•	•	0	•	
MPV Series	MPV RA (2015)	BCM	•	•	•	•	•	Overspeed warning function settings
MPV Series	MPV RA (2015)	GW	•	•	•	0	0	

MPV Series	MPV RA (2015)	FECU	•	•	•	0	•	
MPV Series	MPV RA (2015)	CSW	•	•	•	•	0	
MPV Series	MPV RA (2015)	air- conditioning system	•	•	•	•	•	
MPV Series	MPV RA (2015)	electro- hydraulic power steering	•	•	•	0	0	Car manufacturer's specifications (EHPS matrix selection), EHPS matrix selection
MPV Series	MPV RA (2015)	SAS	•	•	•	0	0	
MPV Series	MPV RA (2015)	ESMCU	•	•	•	•	•	
MPV Series	MPV RA (2015)	Auto Body level system	•	•	•	•	•	ALS initialization correction
MPV Series	MPV RA (2015) \0 BU		•	•	•	0	0	
MPV Series	MPV RA (2015) \0 BU	switch box	•	•	•	•	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, on / off NaviBox, EQ function unsealed
MPV Series	MPV RA (2015)	TK	•	•	•	0	0	
MPV Series	MPV RA (2015) \D VD	Panasonic	•	•	•	0	0	
MPV Series	MPV RA (2015) \D VD	Porton	•	•	•	0	0	
MPV Series	MPV RA (2015)	AMP	•	• /	•	0	0	
MPV Series	MPV RA (2015)	EVS	•	•	•	0	0	
MPV Series	MPV RA (2015)	lane departure warning system	•	•	•	•	•	
MPV Series	MPV RA (2015)	FRD	•	•	•	0	0	
MPV Series	MPV RA (2015)	NAVIBOX	•	•	•	0	0	
MPV Series	MPV RA (2015)	KCU	•	•	•	•	•	
MPV Series	MPV RA (2015)	SRS	•	•	•	•	•	Ignition lock, ignition unlocking
MPV Series	MPV RA (2015)	PSD left	•	•	•	•	0	Ĭ
MPV Series	MPV RA (2015)	PSD Right	•	•	•	•	0	
MPV Series	MPV RA (2015)	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning

MPV Series	MPV MC ML	engine control module	•	•	•	•	•	Crankshaft position to adapt to the sampling count, production start-up counter, the vehicle identification number, code or repair shop test equipment serial number, calibration reset the date, the date of the correction reflashing
MPV Series	MPV MC ML	transmission system (AISIN)	•	•	•	•	•	N range learning
MPV Series	MPV MC ML	electronic stability control system	•	•	•	•	0	ABS vacuum oiling
MPV Series	MPV MC ML	Meter	•	•	•	0	• ,	
MPV Series	MPV MC ML	BCM	•	•	•	•	•	Overspeed warning function settings
MPV Series	MPV MC ML	GW	•	•	•	0	0	- 5110 01011 00 0011180
MPV Series	MPV MC ML	FECU	•	•	•	0		
MPV Series	MPV MC ML	CSW	•	•	•	•	0	
MPV Series	MPV MC ML	air- conditioning system	•	•	•	•		
MPV Series	MPV MC ML	electro- hydraulic power steering	•	•	•	0	0	Car manufacturer's specifications (EHPS matrix selection), EHPS matrix selection
MPV Series	MPV MC ML	SAS	•	•	•	0	0	
MPV Series	MPV MC ML	ESMCU	•	<b>A</b> •	•	•	•	
MPV Series	MPV MC ML	Auto Body level system	•	•	•	•	•	ALS initialization correction
MPV Series	MPV MC ML\OBU	CarPc	•	•	•	0	0	
MPV Series	MPV MC ML\OBU	switch box	•	•	•	•	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed film DVBT function, on / off NaviBox, EQ function unsealed
MPV Series	MPV MC ML	TK	•	•	•	0	0	
MPV Series	MPV MC ML\DVD	Panasonic	•	•	•	0	0	
MPV Series	MPV MC ML\DVD	Porton	•	•	•	0	0	
MPV Series	MPV MC ML	AMP	•	•	•	0	0	
MPV Series	MPV MC ML	EVS	•	•	•	0	0	
MPV Series	MPV MC ML	lane departure warning system	•	•	•	•	•	
MPV Series	MPV MC ML	FRD	•	•	•	0	0	
MPV Series	MPV MC ML	NAVIBOX	•	•	•	0	0	
MPV Series	MPV MC ML	KCU	•	•	•	•	•	
MPV Series	MPV MC ML	SRS	•	•	•	•	•	Ignition lock, ignition unlocking

MPV	Series	MPV MC ML	PSD left	•	•	•	•	0	
	Series		PSD Right	•	•	•	•	0	
MPV	Series	MPV MC ML	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
SUV 7)	Series(Big	SUV	engine control module	•	•	•	•	•	Crankshaft position to adapt to the sampling count, production startup counter, the vehicle identification number, code or repair shop test equipment serial number, calibration reset the date, the date of the correction reflashing
	Series(Big	SUV	transmission	•	•	•	•	•	A
7) SUV 7)	Series(Big	SUV	system anti-lock brake system	0	•	•	•	•	ABS exhaust, ABS vacuum oiling
	Series(Big	SUV	Meter	•	•	•	0	•	J
	Series(Big	SUV	all wheel drive	•	•	•	•	•	
SUV 7)	Series(Big	SUV	BCM+GW	•	•	•	•	•	
SUV 7)	Series(Big	SUV	FECU	•	•	•	0	•	
	Series(Big	SUV	CSW	•	•	•	•	0	
SUV 7)	Series(Big	SUV	air- conditioning system	•	•	•	•	•	
7)	Series(Big	SUV	THINK+	•	• /	•	0	•	
SUV 7)	Series(Big	SUV	HMI	•	•	•	•	0	
SUV 7)	Series(Big	SUV	DVD	•	•	•	0	0	
SUV 7)	Series(Big	SUV	LDWS+	•	•	•	•	•	
SUV 7)	Series(Big	SUV	TPMS+	•	•	•	0	0	
SUV 7)	Series(Big	SUV	KCU	•	•	•	•	•	
SUV 7)	Series(Big	SUV	SRS	•	•	•	•	•	SRS offline unlock / lock
SUV 7)	Series(Big	SUV	PTG	•	•	•	•	•	
	Series(Big	SUV	bend auxiliary lighting system	•	•	•	•	•	
SUV 7)	Series(Big	SUV	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning

SUV Series(Big 7)	SUV	Switch box	•	•	•	•	0	
SUV Series(Big 7)	SUV ML	engine control module	•	•	•	•	•	Crankshaft position to adapt to the sampling count, production start-up counter, the vehicle identification number, code or repair shop test equipment serial number, calibration reset the date, the date of the correction reflashing
SUV Series(Big 7)	SUV ML	transmission system	•	•	•	•	•	
SUV Series(Big 7)	SUV ML	anti-lock brake system	0	•	•	•	•	ABS exhaust, ABS vacuum oiling
SUV Series(Big 7)	SUV ML	Meter	•	•	•	0	•	
SUV Series(Big 7)	SUV ML	all wheel drive	•	•	•	•	•	A .
SUV Series(Big 7)	SUV ML	BCM+GW	•	•	•	•	•	
SUV Series(Big 7)	SUV ML	FECU	•	•	•	0	•	
SUV Series(Big 7)	SUV ML	CSW	•	•	•	•	0	
SUV Series(Big 7)	SUV ML	air- conditioning system	•	•	•	K	•	
SUV Series(Big 7)	SUV ML	THINK+	•	•	•	0	•	
SUV Series(Big 7)	SUV ML	НМІ	•		•	•	0	
SUV Series(Big 7)	SUV ML	DVD	• /	•	•	0	0	
SUV Series(Big 7)	SUV ML	LDWS+	•	•	•	•	•	
SUV Series(Big 7)	SUV ML	TPMS+	•	•	•	0	0	
SUV Series(Big 7)	SUV ML	KCU	•	•	•	•	•	
SUV Series(Big 7)	SUV ML	SRS	•	•	•	•	•	SRS offline unlock / lock
SUV Series(Big 7)	SUV ML	PTG	•	•	•	•	•	
SUV Series(Big 7)	SUV ML	AFS (KEBODA)	•	•	•	•	•	
SUV Series(Big 7)	SUV ML	ЕРВ	•	•	•	•	•	Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
SUV Series(Big 7)	SUV ML	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
SUV Series(Big 7)	SUV ML	Switch box	•	•	•	•	0	

SUV Series(Big 7)	SUV D	engine control module	•	•	•	•	•	Crankshaft position to adapt to the sampling count, production start-up counter, the vehicle identification number, code or repair shop test equipment serial number, calibration reset the date, the date of the correction reflashing
SUV Series(Big 7)	SUV D	transmission system	•	•	•	•	•	
SUV Series(Big 7)	SUV D	anti-lock brake system	0	•	•	•	•	ABS exhaust, ABS vacuum oiling
SUV Series(Big 7)	SUV D	Meter	•	•	•	0	•	
SUV Series(Big 7)	SUV D	all wheel drive	•	•	•	•	•	
SUV Series(Big 7)	SUV D	BCM+GW	•	•	•	•	•	Α
SUV Series(Big 7)	SUV D	FECU	•	•	•	0	<b>-•</b> (	
SUV Series(Big 7)	SUV D	CSW	•	•	•	•	0	
SUV Series(Big 7)	SUV D	air- conditioning system	•	•	•	•	•	
SUV Series(Big 7)	SUV D	THINK+	•	•	•	0	•	
SUV Series(Big 7)	SUV D	НМІ	•	•	•	•	0	
SUV Series(Big 7)	SUV D	DVD	•	•	•	0	0	
SUV Series(Big 7)	SUV D	lane departure warning system	•	•			•	
SUV Series(Big 7)	SUV D	TPMS	•	• (	•	•	0	
SUV Series(Big 7)	SUV D	KCU	•	•	•	•	•	
SUV Series(Big 7)	SUV D	SRS	•	•	•	•	•	SRS offline unlock /
SUV Series(Big 7)	SUV D	PTG	•	•	•	•	•	
SUV Series(Big	SUV D	bend auxiliary lighting system	•	•	•	•	•	
SUV Series(Big 7)	SUV D	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
SUV Series(Big 7)	SUV D	Switch box	•	•	•	•	0	

SUV Series(Big 7)	SUV RA (2012)	engine control module	•	•	•	•	•	Crankshaft position to adapt to the sampling count, production start-up counter, the vehicle identification number, code or repair shop test equipment serial number, calibration reset the date, the date of the correction reflashing
SUV Series(Big		transmission	•	•	•	•	•	
7) SUV Series(Big	RA (2012) SUV	system anti-lock			_			ABS exhaust, ABS
7)	RA (2012)	brake system	0	•	•	•		vacuum oiling
SUV Series(Big 7)	SUV RA (2012)	Meter	•	•	•	0	•	
SUV Series(Big		all wheel	•	•	•	•	•	
7) SUV Series(Big	RA (2012) SUV	drive BCM+GW	•					
7) SUV Series(Big	RA (2012)	DUM+GW		_	_			
50V Series (Big 7)	RA (2012)	FECU	•	•	•	0	•	
SUV Series(Big 7)	SUV RA (2012)	CSW	•	•	•	•	0	
SUV Series(Big		air-						
7)	RA (2012)	conditioning system	•	•	•	• //	•	
SUV Series (Big		THINK+	•	•	•	0	•	/
7) SUV Series(Big	RA (2012) SUV	INIT	_	_				
7) SUV Series(Big	RA (2012)	HMI		•	•		0	
7) Series (big	RA (2012)	DVD	•	_ •	•	0	0	
SUV Series(Big 7)	SUV RA (2012)	lane departure warning system	•	•		•	•	
SUV Series(Big 7)	SUV RA (2012)	TPMS	•	• (	•	•	0	
SUV Series(Big 7)		KCU	•	•	•	•	•	
SUV Series(Big	SUV	SRS	•	•	•	•	•	SRS offline unlock /
7) SUV Series (Big		PTG	•	•	•	•	•	IOCK
7)	RA (2012)							
SUV Series(Big 7)	SUV RA (2012)	bend auxiliary lighting system	•	•	•	•	•	
SUV Series(Big 7)	SUV RA (2012)	ЕРВ	•	•	•	•	•	Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
SUV Series(Big 7)	SUV RA (2012)	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning

SUV Series(Big		LDWS+	•	•	•	•	•	
7) SUV Series(Big	RA (2012) SUV					+		
7) SUV Series(Big	RA (2012)	TPMS+		•	•	0	0	
7)	RA (2012)	Switch box	•	•	•	•	0	
SUV Series(Big 7)	SUV MC	engine control module	•	•	•	•	•	Write VIN, refresh date programming, programming reflashing date
SUV Series(Big 7)	SUV MC	transmission system	•	•	•	•	•	
SUV Series(Big 7)	SUV MC\anti- lock brake system	anti-lock brake	0	•	•	•	•	ABS exhaust, ABS vacuum oiling
SUV Series(Big 7)	SUV MC\anti- lock brake system	electronic stability control	•	•	•	•	0	ABS vacuum oiling
SUV Series(Big 7)	SUV MC	all wheel drive	•	•	•	•		
SUV Series(Big 7)	SUV MC	BCM+GW	•	•	•	•	•	
SUV Series(Big 7)	SUV MC	FECU	•	•	•	0	•	
SUV Series(Big 7)	SUV MC	CSW	•	•	•	•	0	
SUV Series(Big 7)	SUV MC	air- conditioning system	•	•	•		•	
SUV Series(Big 7)	SUV MC\OBU	switch box	•	·			0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, on / off NaviBox, EQ function unsealed
SUV Series(Big 7)	SUV MC\OBU	CarPC	•	•	•	0	0	
SUV Series(Big 7)	SUV MC	touch keys	•	•	•	•	•	
SUV Series(Big 7)	SUV MC	DVD	•	•	•	0	0	
SUV Series(Big 7)	SUV MC	DAS+	•	•	•	0	0	
SUV Series(Big 7)	SUV MC	TPMS	•	•	•	•	0	
SUV Series(Big 7)	SUV MC	KCU	•	•	•	•	•	
SUV Series(Big 7)	SUV MC	SRS	•	•	•	•	•	SRS offline unlock / lock
SUV Series(Big 7)	SUV MC	PTG	•	•	•	•	•	
SUV Series(Big 7)	SUV MC	bend auxiliary lighting system	•	•	•	•	•	
SUV Series(Big 7)	SUV MC	Auto Body level system	•	•	•	•	•	ALS initialization correction

	1							
SUV Series(Big 7)	SUV MC	ЕРВ	•	•	•	•	•	Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
SUV Series(Big 7)	SUV MC	emergency call	•	•	•	•	•	
SUV Series(Big 7)	SUV MC	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
SUV Series(Big 7)	SUV RA (2015)	engine control module	•	•	•	•	•	Write VIN, refresh date programming, programming reflashing date
SUV Series(Big 7)	SUV RA (2015)	transmission system (AISIN)	•	•	•	•	•	N range learning
SUV Series(Big 7)	SUV RA (2015)	electronic stability control system	•	•	•	•	0	ABS vacuum oiling
SUV Series(Big 7)	SUV RA (2015)	Meter	•	•	•	0	•	
SUV Series(Big 7)	SUV RA (2015)	ВСМ	•	•	•			Automatic locking state, the overspeed warning state, the mirror control state, panorama image light control, reversing buzzer control
SUV Series(Big 7)	SUV RA (2015)	FECU	•	•	•	0	•	
SUV Series(Big 7)	_	CSW	•	•	•	•	0	
SUV Series(Big 7)		air- conditioning system	•	•	•	•	•	
SUV Series(Big 7)	RA (2015)	electro- hydraulic power steering	•	•	•	0	0	Car manufacturer's specifications (EHPS matrix selection), EHPS matrix selection
SUV Series(Big 7)	RA (2015)	SAS	•	•	•	0	0	
SUV Series(Big 7)	SUV RA (2015)	ESMCU	•	•	•	•	•	
SUV Series(Big 7)	SUV RA (2015)	Auto Body level system	•	•	•	•	•	ALS initialization correction
SUV Series(Big 7)	SUV RA (2015)	ЕРВ	•	•	•	•	•	Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
SUV Series(Big 7)	SUV RA (2015)	all wheel drive	•	•	•	•	•	

SUV Series(Big 7)	SUV RA (2015) \0 BU	switch box	•	•	•	•	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, on / off NaviBox, EQ function unsealed
SUV Series(Big 7)	SUV RA (2015) \0 BU	CarPC	•	•	•	0	0	
SUV Series(Big 7)	SUV RA (2015)	touch keys	•	•	•	•	•	
SUV Series(Big 7)	SUV RA (2015)	DVD	•	•	•	0	0	
SUV Series(Big 7)	SUV RA (2015)	FRD	•	•	•	•	0	
SUV Series(Big 7)	SUV RA (2015)	NAVIBOX	•	•	•	0	0	
SUV Series(Big 7)	SUV RA (2015)	DAS+	•	•	•	0	0	
SUV Series(Big 7)	SUV RA (2015)	KCU	•	•	•	•	•	
SUV Series(Big 7)	SUV RA (2015)	SRS	•	•	•	•	•	SRS offline unlock / lock
SUV Series(Big 7)		PTG	•	•	•	•	•	
SUV Series(Big 7)	SUV RA (2015)	anti-theft	•	•	•	X	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
SUV Series(Big 7)	SUV MC ML	engine control module	•	•	•	•	•	Write VIN, refresh date programming, programming reflashing date
SUV Series(Big 7)	SUV MC ML	transmission system	•	•	•	•	•	
SUV Series(Big 7)	SUV MC ML\anti- lock brake system	anti-lock brake	0	•	•	•	•	ABS exhaust, ABS vacuum oiling
SUV Series(Big 7)	SUV MC ML\anti- lock brake system	electronic stability control	•	•	•	•	0	ABS vacuum oiling
SUV Series(Big 7)	SUV MC ML	Meter	•	•	•	0	•	
SUV Series(Big 7)	SUV MC ML	all wheel drive	•	•	•	•	•	
SUV Series(Big 7)	SUV MC ML	ВСМ	•	•	•	•	•	Automatic locking state, the overspeed warning state, the mirror control state, panorama image light control, reversing buzzer control

	1	1						
SUV Series(Big 7)	SUV MC ML	FECU	•	•	•	0	•	
SUV Series(Big 7)	SUV MC ML	CSW	•	•	•	•	0	
SUV Series(Big 7)	SUV MC ML	air- conditioning system	•	•	•	•	•	
SUV Series(Big 7)	SUV MC ML	bend auxiliary lighting system	•	•	•	•	•	
SUV Series(Big 7)	SUV MC ML	ЕРВ	•	•	•	•	•	Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
SUV Series(Big 7)	SUV MC ML\OBU	switch box	•	•	•	•	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, on / off NaviBox, EQ function unsealed
SUV Series(Big 7)	SUV MC ML\OBU	CarPC	•	•	•	0	0	
SUV Series(Big 7)	SUV MC ML	touch keys	•	•	•	•	•	
SUV Series(Big 7)	SUV MC ML	DVD	•	•	•	0	0	
SUV Series(Big 7)	SUV MC ML	IDWS	•	•	•	0	0	
SUV Series(Big 7)	SUV MC ML	TPMS	•	<b>A</b> •	•	•	0	
SUV Series(Big 7)	SUV MC ML	KCU	•	•	•	•	•	
SUV Series(Big 7)	SUV MC ML	SRS	•	•	•	•	•	SRS offline unlock /
SUV Series(Big 7)	SUV MC ML	PTG	•	•	•	•	•	, con
SUV Series(Big 7)	SUV MC ML	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
N5 series	GPS (N5)	engine control module	•	•	•	•	•	Write VIN, refresh date programming, programming reflashing date
N5 series	GPS (N5)	transmission system (AISIN)	•	•	•	•	•	N range learning
N5 series	GPS(N5)\an ti-lock brake system	anti-lock brake	•	•	•	•	0	
N5 series	GPS(N5)\an ti-lock brake system	stability control	•	•	•	•	0	ABS vacuum oiling
N5 series	GPS (N5)	Meter	•	•	•	0	•	

N5 series	GPS (N5)	ВСМ	•	•	•	•	•	Automatic locking state, the overspeed warning state, the mirror control state, panorama image light control, reversing buzzer control
N5 series	GPS (N5)	FECU	•	•	•	0	•	
N5 series	GPS (N5)	CSW	•	•	•	•	0	
N5 series	GPS (N5)	air- conditioning system	•	•	•	•	•	
N5 series	GPS (N5)	SAS	•	•	•	0	•	
N5 series	GPS (N5) \OB U	Switch box	•	•	•	0	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, when HUD rise, still displays the speed function is enabled, the on / off NaviBox, TPMS function hoist
N5 series	GPS (N5) \OB U	CarPC	•	•	•	0	0	
N5 series	GPS (N5)	miniHMI	•	•	•	0		
N5 series	GPS (N5)	DVD	•	•	•	0	0	
N5 series	GPS (N5)	lane departure warning system	•	•	•	•	•	
N5 series	GPS (N5)	KCU	•	•	•	•	•	
N5 series N5 series	GPS (N5) GPS (N5)	SRS Auto Body level system	•		•	•	•	ALS initialization correction
N5 series	GPS (N5)	ЕРВ	•		•	•	•	Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
N5 series	GPS (N5)	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
N5 series		engine control module	•	•	•	•	•	Write VIN, refresh date programming, programming reflashing date
N5 series	GPS(N5 2015 year)\tran smission system	Power Technology	•	•	•	•	•	

	ana (NE	1						1
N5 series	GPS(N5 2015 year)\tran smission system	AISIN	•	•	•	•	•	N range learning
N5 series	GPS(N5 2015 year)\anti -lock brake system	anti-lock brake	•	•	•	•	0	
N5 series	GPS(N5 2015 year)\anti -lock brake system	electronic stability control	•	•	•	•	0	ABS vacuum oiling
N5 series	GPS (N5 2015 year)	Meter	•	•	•	0	•	
N5 series	GPS(N5 2015 year)	ВСМ	•	•	•	•	X	Automatic locking state, the overspeed warning state, the mirror control state, panorama image light control, reversing buzzer control
N5 series	GPS (N5 2015 year)	FECU	•	•	•	0	•	
N5 series	GPS (N5 2015 year)	CSW	•	•	•	•	0	
N5 series	GPS (N5 2015 year)	air- conditioning system	•	<b>1</b> •	• (	•	•	
N5 series	GPS (N5 2015 year)	EPS	•			0	0	Cars variant adjust selector left RES initial position, the initial position of the right RES rack length, PDC initial torque value, EPS correction, EPS correction (16-inch tires), EPS correction (17-inch tires)
N5 series	GPS (N5 2015 year) \OBU	Switch box	•	•	•	0	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, when HUD rise, still displays the speed function is enabled, the on / off NaviBox, TPMS function hoist

N5 series	GPS (N5 2015 year) \OBU	CarPC	•	•	•	0	0	
N5 series	GPS (N5 2015 year)	miniHMI	•	•	•	0	•	
N5 series	GPS(N5 2015 year)	DVD	•	•	•	0	0	
N5 series	GPS (N5 2015 year)	FRD	•	•	•	•	0	
N5 series	GPS (N5 2015 year)	lane departure warning system	•	•	•	•	•	
N5 series	GPS(N5 2015 year)	KCU	•	•	•	•	•	
N5 series	GPS(N5 2015 year)	SRS	•	•	•	•	0	
N5 series	GPS(N5 2015 year)	Auto Body level system	•	•	•	•	X	ALS initialization correction
N5 series	GPS(N5 2015 year)	ЕРВ	•	•	•	X	•	Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
N5 series	GPS(N5 2015 year)	anti-theft	•	·	Ż.		0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
N5 series	GPS MC (N5)	engine control module	•	•	•	•	•	Write VIN, refresh date programming, programming reflashing date
N5 series	GPS MC(N5)	transmission system (AISIN)	•	•	•	•	•	N range learning
N5 series	GPS MC(N5)	electronic stability control system	•	•	•	•	0	ABS vacuum oiling

N5 series	GPS MC(N5)	EPS	•	•	•	0	0	Cars variant adjust selector left RES initial position, the initial position of the right RES rack length, PDC initial torque value, EPS correction, EPS correction (16-inch tires), EPS correction (17-inch tires)
N5 series	GPS MC(N5)	ЕРВ	•	•	•	•	•	Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
N5 series	GPS MC(N5)	Auto Body level system	•	•	•	•	•	ALS initialization correction
N5 series	GPS MC(N5)		•	•	•	0	•	
N5 series	GPS MC(N5)	ВСМ	•	•	•	X	•	Automatic locking state, the overspeed warning state, the mirror control state, panorama image light control, reversing buzzer control
N5 series	GPS MC(N5)	FECU	•	•	•	0	•	
N5 series	GPS MC(N5)	CSW	•	<b>( •</b>	• (	•	0	
N5 series	GPS MC(N5)	air- conditioning system	•	•	•	•	•	
N5 series	GPS MC(N5)	ESMCU	•	•		•	•	
N5 series	GPS MC(N5)	ACP	•	•	•	0	0	
N5 series	GPS MC (N5) \OBU	Switch box	•	•	•	0	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, when HUD rise, still displays the speed function is enabled, the on / off NaviBox, TPMS function hoist
N5 series	GPS MC (N5) \OBU	CarPC	•	•	•	0	0	
N5 series	GPS MC(N5)	miniHMI	•	•	•	0	•	
N5 series	GPS MC (N5)	CDMP3	•	•	•	0	0	

N5 series	GPS MC(N5)	NAVIBOX	•	•	•	0	0	
N5 series	GPS MC(N5)	DVD	•	•	•	0	0	
N5 series	GPS MC(N5)	FRD	•	•	•	•	0	
N5 series	GPS MC(N5)	DAS+/LDWS	•	•	•	•	•	
N5 series	GPS MC(N5)	TPMS	•	•	•	•	0	
N5 series	GPS MC(N5)	KCU	•	•	•	•	•	
N5 series	GPS MC(N5)	SRS	•	•	•	•	0	
N5 series	GPS MC(N5)	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
N5 series	GPS ML(N5 1.8T)	engine control module	•	•	•	•	X	Write VIN, refresh date programming, programming reflashing date
N5 series	GPS ML(N5 1.8T)	transmission system(Power Technology)	•	•	•	•		
N5 series	GPS ML(N5 1.8T)\anti -lock brake system	anti-lock brake	•	•	•		0	
N5 series	GPS ML(N5 1.8T)\anti -lock brake system	electronic stability control	•	•	•		0	ABS vacuum oiling
N5 series	GPS ML(N5 1.8T)	Meter	•	•	•	0	•	
N5 series	GPS ML(N5	ВСМ	•			•	•	Automatic locking state, the overspeed warning state, the mirror control state, panorama image light control, reversing buzzer control
N5 series	GPS ML(N5 1.8T)	FECU	•	•	•	0	•	
N5 series	GPS ML(N5 1.8T)	CSW	•	•	•	•	0	
N5 series	GPS ML(N5 1.8T)	air- conditioning system	•	•	•	•	•	
N5 series	GPS ML(N5 1.8T)	SAS	•	•	•	0	•	

N5 series	GPS ML(N5 1.8T)\OBU	Switch box	•	•	•	0	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, when HUD rise, still displays the speed function is enabled, the on / off NaviBox, TPMS function hoist
N5 series	GPS ML(N5	CarPC	•	•	•	0	0	Tuneeron norse
	1.8T)\OBU GPS ML(N5							
N5 series	1.8T) GPS ML(N5	miniHMI	•	•	•	0	•	
N5 series	1.8T)	CDMP3	•	•	•	0	0	
N5 series	GPS ML(N5 1.8T)	DVD	•	•	•	0	0	
N5 series	GPS ML(N5 1.8T)	FRD	•	•	•	•	0	
N5 series	GPS ML (N5 1.8T)	NAVIBOX	•	•	•	0	0	
N5 series	GPS ML (N5 1.8T)	KCU	•	•	•	•	•	
N5 series	GPS ML(N5 1.8T)	ЕРВ	•	•	•	X		Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
N5 series	GPS ML(N5 1.8T)	SRS	•	<b>A</b> •	• (	•	0	
N5 series	GPS ML(N5	anti-theft	•	•	<b>\</b>	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
N5 series	GPS ML (N5 2. 0T)	engine control module	•	•	•	•	•	Write VIN, refresh date programming, programming reflashing date
N5 series	GPS ML(N5 2.0T)	transmission system (AISIN)	•	•	•	•	•	N range learning
N5 series	GPS ML (N5 2. 0T)	electronic stability control system	•	•	•	•	0	ABS vacuum oiling
N5 series	GPS ML(N5 2.0T)	Meter	•	•	•	0	•	
N5 series	GPS ML (N5 2. OT)	ВСМ	•	•	•	•	•	Automatic locking state, the overspeed warning state, the mirror control state, panorama image light control, reversing buzzer control

N5 series	GPS ML(N5 2.0T)	FECU	•	•	•	0	•	
N5 series	GPS ML(N5 2. OT)	CSW	•	•	•	•	0	
N5 series	GPS ML (N5 2. OT)	air- conditioning system	•	•	•	•	•	
N5 series	GPS ML(N5 2. OT)	SAS	•	•	•	0	•	
N5 series	GPS ML(N5 2. OT)	OBU(CarPC)	•	•	•	0	0	
N5 series	GPS ML(N5 2.0T)	miniHMI	•	•	•	0	•	
N5 series	GPS ML(N5 2.0T)	DVD	•	•	•	0	0	
N5 series	GPS ML (N5 2. OT)	lane departure warning system	•	•	•	•	•	
N5 series	GPS ML(N5 2.0T)	NAVIBOX	•	•	•	0	0	
N5 series	GPS ML(N5 2. 0T)	KCU	•	•	•	•	•/	
N5 series	GPS ML(N5 2.0T)	Auto Body level system	•	•	•	•		ALS initialization correction
N5 series	GPS ML(N5 2.0T)	EPB	•	•	•	×	•	Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
N5 series	GPS ML(N5 2.0T)	SRS	•	•	•	•	0	
N5 series	GPS ML(N5 2. 0T)	anti-theft	•	•			0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
N5 series	GPS RA(N5 1.8T)	engine control module	•	•	•	•	•	Write VIN, refresh date programming, programming reflashing date
N5 series	GPS RA (N5 1.8T)	transmission system(Power Technology)	•	•	•	•	•	
N5 series	GPS RA(N5 1.8T)	anti-lock brake system	•	•	•	•	0	
N5 series	GPS RA(N5 1.8T)	Meter	•	•	•	0	•	
N5 series	GPS RA(N5 1.8T)	ВСМ	•	•	•	•	•	Automatic locking state, the overspeed warning state, the mirror control state, panorama image light control, reversing buzzer control
N5 series	GPS RA (N5 1.8T)	FECU	•	•	•	0	•	

		1						
N5 series	GPS RA(N5 1.8T)	air- conditioning system	•	•	•	•	•	
N5 series	GPS RA(N5 1.8T)	SAS	•	•	•	0	•	
N5 series	GPS RA(N5 1.8T)\0BU	Switch box	•	•	•	0	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, when HUD rise, still displays the speed function is enabled, the on / off NaviBox, TPMS function hoist
N5 series	GPS RA(N5 1.8T)\OBU	CarPC	•	•	•	0	0	
N5 series	GPS RA(N5 1.8T)	miniHMI	•	•	•	0	•	
N5 series	GPS RA(N5 1.8T)	CDMP3	•	•	•	0	0	
N5 series	GPS RA(N5 1.8T)	FRD	•	•	•	•	0	
N5 series	GPS RA(N5 1.8T)	NAVIBOX	•	•	•	0	0	
N5 series	GPS RA(N5 1.8T)	SRS	•	•	•	• /	0	
N5 series	GPS RA(N5 1.8T)	ЕРВ	•	•	•			Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
N5 series	GPS RA (N5 2. OT)	engine control module	•	•	•	•	•	Write VIN, refresh date programming, programming reflashing date
N5 series	GPS RA (N5 2. 0T)	transmission system (AISIN)	•	• 7	•	•	•	N range learning
N5 series	GPS RA(N5 2.0T)\anti -lock brake system	anti-lock brake	•	•	•	•	0	
N5 series	GPS RA(N5 2.0T)\anti -lock brake system	electronic stability control	•		•	•	0	ABS vacuum oiling
N5 series	GPS RA(N5 2.0T)	Meter	•	•	•	0	•	
N5 series	GPS RA(N5 2. 0T)	ВСМ	•	•	•	•	•	Automatic locking state, the overspeed warning state, the mirror control state, panorama image light control, reversing buzzer control
N5 series	GPS RA (N5 2. 0T)	FECU	•	•	•	0	•	

	GPS RA (N5	aaw.						
N5 series	2. 0T)	CSW .	•	•	•	•	0	
N5 series	GPS RA (N5 2. 0T)	air- conditioning system	•	•	•	•	•	
N5 series	GPS RA (N5 2. OT)	SAS	•	•	•	0	•	
N5 series	GPS RA(N5 2. OT)\OBU	Switch box	•	•	•	0	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, when HUD rise, still displays the speed function is enabled, the on / off NaviBox, TPMS function hoist
N5 series	GPS RA (N5 2. OT) \OBU	CarPC	•	•	•	0	0	
N5 series	GPS RA(N5 2. OT)	miniHMI	•	•	•	0	•/	
N5 series	GPS RA (N5 2. OT)	DVD	•	•	•	0	0	
N5 series	GPS RA (N5 2. 0T)	FRD	•	•	•	•	0	
N5 series	GPS RA (N5 2. 0T)	NAVIBOX	•	•	•	0	0	
N5 series	GPS RA (N5 2. OT)	KCU	•	•	•	•	•	
N5 series	GPS RA (N5 2. OT)	SRS	•	•	•	•	0	
N5 series	GPS RA (N5 2. 0T)	Auto Body level system	•		•	•	•	ALS initialization correction
N5 series	GPS RA (N5 2. 0T)	ЕРВ	•		A.		•	Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
N5 series	GPS RA (N5 2. OT)	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
U6 Series	GPK (U6)	engine control module	•	•	•	•	•	Write VIN, refresh date programming, programming reflashing date
U6 Series	GPK(U6)\tr ansmission system	AISIN	•	•	•	•	•	N range learning
U6 Series	GPK(U6)\tr ansmission system	Power Technology	•	•	•	•	•	
U6 Series	GPK(U6)\an ti-lock brake system	anti-lock brake	•	•	•	•	0	

	1	1		1	1	1	1	
	GPK(U6)∖an	electronic						
U6 Series	ti-lock	stability	•				0	ABS vacuum oiling
CO BCITCS	brake	control						ADD Vacadim Offing
	system	COILLIOI						
U6 Series	GPK (U6)	Meter	•	•	•	0	•	
U6 Series	GPK (U6)	ВСМ	•	•	•	•	•	Automatic locking state, the overspeed warning state, the mirror control state, panorama image light control, reversing buzzer control
U6 Series	GPK (U6)	FECU	•	•	•	0	•	
U6 Series	GPK (U6)	CSW	•	•	•	•	0	
00 SCITCS	01 K (00)	air-						+
U6 Series	GPK (U6)	conditioning system	•	•	•	•	•	
U6 Series	GPK (U6)	SAS	•	•	•	0	•	
		Auto Body		<del>t                                     </del>	Ť			ALS initialization
U6 Series	GPK (U6)	level system	•	•	•	•	•	correction
U6 Series	GPK (U6)	ЕРВ	•	•	•	•	X	Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
U6 Series	GPK (U6) \OB U	Switch box	•	•		0	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, when HUD rise, still displays the speed function is enabled, the on / off NaviBox, TPMS function hoist
U6 Series	GPK (U6) \OB U	CarPC	•	• \	•	0	0	
U6 Series	GPK (U6)	miniHMI	•	•	•	0	•	
U6 Series	GPK (U6)	CDMP3	•	•	•	0	0	
U6 Series	GPK (U6)	DVD	•	•	•	0	0	1
U6 Series	GPK (U6)	NAVIBOX	•	•	•	0	0	
U6 Series	GPK (U6)	DAS+	•	•	•	0	0	†
U6 Series	GPK (U6)	KCU			•	•	•	+
U6 Series		HUD	-	•		0	•	+
	GPK (U6)			_		-		+
U6 Series	GPK (U6)	SRS	•	•	•	•	0	
U6 Series	GPK (U6)	PTG	•	•	•	0	0	
U6 Series	GPK (U6)	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
U6 Series	GPK (U6)	FRD	•	•	•	•	0	
U6 Series	GPK RA(U6)	engine control	•	•	•	•	•	Write VIN, refresh date programming, programming reflashing date

U6 Series	GPK RA(U6)	transmission system (AISIN)	•	•	•	•	•	N range learning
U6 Series	GPK RA(U6)	electronic	•	•	•	•	0	ABS vacuum oiling
U6 Series	GPK RA(U6)		•	•	•	0	0	Cars variant adjust selector left RES initial position, the initial position of the right RES rack length, PDC initial torque value, EPS correction, EPS correction (16-inch tires), EPS correction (17-inch tires)
U6 Series	GPK RA(U6)	ЕРВ	•	•	•	•		Since the row car / hand function switching row of cars, parking stall on / off, start dissociation on / off
U6 Series	GPK RA(U6)	Auto Body level system	•	•	•	•	•	ALS initialization correction
U6 Series	GPK RA(U6)	Meter	•	•	•	0	•	
U6 Series	GPK RA(U6)	ВСМ	•		·	6	•	Automatic locking state, the overspeed warning state, the mirror control state, panorama image light control, reversing buzzer control
U6 Series	GPK RA(U6)	FECU	•	• /	•	0	•	
U6 Series	GPK RA(U6)	CSW	•	•	•	•	0	
U6 Series	GPK RA(U6)	air- conditioning system	•	•	•	•	•	
U6 Series	GPK RA(U6)	ESMCU	•	•	•	•	•	
U6 Series	GPK RA (U6) \OBU	Switch box	•	•	•	0	0	Function unsealed side and rear CCD function unsealed, DVD function unsealed unsealed film DVBT function, when HUD rise, still displays the speed function is enabled, the on / off NaviBox, TPMS function hoist
U6 Series	GPK RA (U6) \OBU	CarPC	•	•	•	0	0	

U6 Series	GPK RA(U6)	miniHMI	•	•	•	0	•	
U6 Series	GPK RA(U6)	NAVIBOX	•	•	•	0	0	
U6 Series	GPK RA(U6)	CDMP3	•	•	•	0	0	
U6 Series	GPK RA(U6)	DVD	•	•	•	0	0	
U6 Series	GPK RA(U6)	FRD	•	•	•	•	0	
U6 Series	GPK RA(U6)	DAS+	•	•	•	0	0	
U6 Series	GPK RA(U6)		•	•	•	•	0	
U6 Series	GPK RA(U6)			•				
U6 Series	GPK RA(U6)	282	•	_	_		0	
U6 Series	GPK RA(U6)	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
EVSeries(Elect ric cars)	MV EV\P line	VMS	•	•	•	•	•	Write VIN
EVSeries(Elect ric cars)	MV EV\P line	EVPCU	•	•	•	0	0	,
EVSeries(Elect	MV EV\P	anti-lock	0	•	•		•	ABS exhaust, ABS
ric cars) EVSeries(Elect	line MV EV\P	brake system						vacuum oiling
ric cars)	line	Meter	•	•	•	0	•	
EVSeries(Elect ric cars)	MV EV\P line	BCM	•	•	•	•	•	
	MV EV\P line	FECU	•		•	0		
EVSeries (Elect		CSW	•	•	•	•	0	
EVSeries(Elect	MV EV\P	GW	•	• 4	•	0	0	
ric cars)	line	air-						
EVSeries(Elect ric cars)	MV EV\P line	conditioning system	•	•	•	•	•	
EVSeries(Elect ric cars)	MV EV\P line	CHCU	•	•	•	0	0	
EVSeries (Elect		THINK+	•	•	•	0	•	
EVSeries(Elect	MV EV\P	VSP	•	•	•	0	0	
ric cars) EVSeries(Elect		HMI	•		•	•	0	
ric cars) EVSeries(Elect	line MV EV\P	DVD	•		•	0	0	
ric cars) EVSeries(Elect	line MV EV\P	עעע	•	•	_	U		
ric cars)	line	LDWS+	•	•	•	•	•	
EVSeries(Elect ric cars)	MV EV\P line	TPMS+	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV\P line	KCU	•	•	•	•	•	
EVSeries(Electric cars)		SRS	•	•	•	•	•	Ignition lock, ignition unlocking
EVSeries(Elect	MV EV\P	PSD left	•	•	•	•	0	15mitton unitotking
ric cars)	line	15D TOTA						ļ

EVSeries(Elect	MA EA/D	1 1	ı					1
ric cars)	MV EV\P line	PSD Right	•	•	•	•	0	
EVSeries(Elect ric cars)	MV EV\P line	bend auxiliary lighting system	•	•	•	•	•	
EVSeries(Elect ric cars)	MV EV\P line	anti-theft	•	•	•	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
EVSeries(Elect ric cars)	MV EV MC\All lines	VMS	•	•	•	•	•	Write VIN
EVSeries(Elect ric cars)	MV EV MC\All lines	EVPCU	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	VSP	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	CHCU	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	electronic stability control system	•	•	•	•	0	ABS vacuum oiling
EVSeries(Elect ric cars)	MV EV MC\All lines	electro- hydraulic power steering	•	•	•	0	0	Car manufacturer's specifications (EHPS matrix selection), EHPS matrix selection
EVSeries(Elect ric cars)	MV EV MC\All lines	SAS	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	GW	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	Meter	•	•	•	0	•	
EVSeries(Elect ric cars)	MV EV MC\All lines	BCM	•	•	•	•	•	
EVSeries(Elect ric cars)	MV EV MC\All lines	air- conditioning system	•	•	•	•	•	
EVSeries(Elect ric cars)	MV EV MC\All lines	FECU	•	•	•	0	•	
EVSeries(Elect ric cars)	MV EV MC\All lines	CSW	•	•	•	•	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	Auto Body level system	•	•	•	•	•	ALS initialization correction
EVSeries(Elect ric cars)	MV EV MC\All lines	OBU(CarPC)	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	NaviBox	•	•	•	0	0	

	MV EV	<del>                                     </del>						ı
EVSeries(Elect ric cars)	MV EV MC\All lines	WM	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	touch keys	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	DVD(Panasonic)	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	AMP	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	FRD	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	EVS	•	•	•	0	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	lane departure warning system	•	•	•	•	•	
EVSeries(Elect ric cars)	MV EV MC\All lines	KCU	•	•	•	•	X	
EVSeries(Elect ric cars)	MV EV MC\All lines	SRS	•	•	•	•	•	Ignition lock, ignition unlocking
EVSeries(Elect ric cars)	MV EV MC\All lines	PSD left	•	•	•	X	0	
EVSeries(Elect ric cars)	MV EV MC\All lines	PSD Right	•	•	•		0	
EVSeries(Elect ric cars)	MV EV MC\All lines	anti-theft	•	•	·	•	0	PIN initialization, smart card matching, ECU reset settings, ECM reset settings, KCU resetting, check the status of learning
LCSeries	LCS	engine system (Bosch)	•	•	•	•	•	Write VIN, refresh date programming, programming reflashing date
LCSeries	LCS	transmission system(CVT)	•	•	•	0	0	
LCSeries	LCS	anti-lock brake system	•	•	•	•	0	
LCSeries	LCS	Meter(Dial)	•	•	•	•	0	
LCSeries	LCS	Meter	•	•	•	•	0	
LCSeries	LCS	CSW	•	•	•	•	•	
LCSeries	LCS	air- conditioning system	•	•	•	0	•	
LCSeries	LCS	EPS	•	•	•	•	0	EPS fine-tune settings, EPS Clear trimming

LCSeries	LCS	BCM+GW	•	•	•	•	•	automatic locking state, left Threshold, turn right at the threshold, type turn signals, with overspeed warning, turn signal automatic calibration, mirror control, buzzer control
LCSeries	LCS	OBU(CarPC)	•	•	•	0	0	
LCSeries	LCS	TKU	•	•	•	0	0	
LCSeries	LCS	CDMP3	•	•	•	0	0	
LCSeries	LCS	EVS	•	•	•	0	0	
LCSeries	LCS	Airbag(ABM)	•	•	•	•	0	
LCSeries	LCS	anti-theft	•	•	•	•	•	
LCSeries	LCS	TPMS	•	•	•	•	0	
LCSeries	LCS	NAVIBOX	•	•	•	•	0	

