



Shenzhen Xtooltech Co., Ltd

Mazda Function List V11.62

Tips and Instructions:

- * This feature is new.
- ✓ This feature is supported.
- ✗ This feature is not supported.
- ※ This feature is partially supported.

Vehicle Name	Capacity	EngineType	Year	System Name	Read Trouble Code	Clear Trouble Code	Live Data	Actuation Test	Special Functions
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE/I4	2005 MY	4X4(4X4 Control Module)	✓	✓	✓	✓	
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE/I4	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	✓	✓	✓	✓	SP0002
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE/I4	2005 MY	GEM(Generic Electronic Module)	✓	✓	✓	✓	
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE/I4	2005 MY	IC(Instrument Cluster)	✓	✓	✓	✓	
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE/I4	2005 MY	PAM(Parking Aid Module)	✓	✓	✓	✓	
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE/I4	2005 MY	PCM(Powertrain Control Module)	✓	✓	✓	✓	SP0001
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE/I4	2005 MY	RCM(Restraint Control Module)	✓	✓	✓	✓	SP0014
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	4X4(4X4 Control Module)	✓	✓	✓	✓	
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	✓	✓	✓	✓	SP0002
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	GEM(Generic Electronic Module)	✓	✓	✓	✓	
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	IC(Instrument Cluster)	✓	✓	✓	✓	
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	PAM(Parking Aid Module)	✓	✓	✓	✓	
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	PCM(Powertrain Control Module)	✓	✓	✓	✓	SP0001
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005 MY	RCM(Restraint Control Module)	✓	✓	✓	✓	SP0014
626/626 WAGON/TELSTAR	2.0L	FS	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	✓	✓	✓	✓	
626/626 WAGON/TELSTAR	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	✓	✓	✓	✓	SP0001
626/626 WAGON/TELSTAR	2.0L	FS	1999 MY	A/C(Air Conditioning)	✓	✓			
626/626 WAGON/TELSTAR	2.0L	FS	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	✓	✓	✓	✓	
626/626 WAGON/TELSTAR	2.0L	FS	1999 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	✓	✓	✓	✓	
626/626 WAGON/TELSTAR	2.0L	FS	1999 MY	CCM(Cruise Control)	✓	✓			
626/626 WAGON/TELSTAR	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	✓	✓	✓	✓	SP0001
626/626 WAGON/TELSTAR	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	✓	✓	✓	✓	
626/626 WAGON/TELSTAR	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	✓	✓	✓	✓	
626/626 WAGON/TELSTAR	2.5L	KL	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	✓	✓	✓	✓	
626/626 WAGON/TELSTAR	2.5L	KL	2001 MY	PCM(Powertrain Control Module)	✓	✓	✓	✓	SP0001
626/626 WAGON/TELSTAR	2.0L	FS	1997 MY	A/C(Air Conditioning)	✓	✓			
626/626 WAGON/TELSTAR	2.0L	FS	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	✓	✓			
626/626 WAGON/TELSTAR	2.0L	FS	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	✓	✓	✓	✓	
626/626 WAGON/TELSTAR	2.0L	FS	1997 MY	CCM(Cruise Control)	✓	✓			

626/626 WAGON/TELSTAR	2.0L	FS	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	2.0L	FS	1998 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	2.0L	FS	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
626/626 WAGON/TELSTAR	2.5L	KL	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	2.5L	KL	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
626/626 WAGON/TELSTAR	2.0L	RF T	1999 MY	A/C(Air Conditioning)	√	√			
626/626 WAGON/TELSTAR	2.0L	RF T	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	2.0L	RF T	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	1.8L	FP	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
626/626 WAGON/TELSTAR	1.8L	FP	1997 MY	CCM(Cruise Control)	√	√			
626/626 WAGON/TELSTAR	1.8L	FP	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
626/626 WAGON/TELSTAR	1.8L	FP	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	2.0L	FS	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
626/626 WAGON/TELSTAR	2.5L	KL	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
626/626 WAGON/TELSTAR	2.5L	KL	1997 MY	CCM(Cruise Control)	√	√			
626/626 WAGON/TELSTAR	2.5L	KL	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	1.8L	FP	1999 MY	A/C(Air Conditioning)	√	√			
626/626 WAGON/TELSTAR	1.8L	FP	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	1.8L	FP	1999 MY	CCM(Cruise Control)	√	√			
626/626 WAGON/TELSTAR	1.8L	FP	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	2.0L	RF T	1997 MY	A/C(Air Conditioning)	√	√			
626/626 WAGON/TELSTAR	2.0L	RF T	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
626/626 WAGON/TELSTAR	2.0L	RF T	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	1.8L	FP	2000 MY	A/C(Air Conditioning)	√	√			
626/626 WAGON/TELSTAR	1.8L	FP	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	1.8L	FP	2000 MY	CCM(Cruise Control)	√	√			
626/626 WAGON/TELSTAR	1.8L	FP	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	2.0L	RF T	2000 MY	A/C(Air Conditioning)	√	√			
626/626 WAGON/TELSTAR	2.0L	RF T	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	2.0L	RF T	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	2.5L	KL	1998 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
626/626 WAGON/TELSTAR	2.5L	KL	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Astina	1.8L	Other	Other	PCM(Powertrain Control Module (PCM))	√	√			
Astina	2.0L	Other	Other	PCM(Powertrain Control Module (PCM))	√	√			
ATENZA	2.0L	PE	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
ATENZA	2.0L	PE	Other	AM(Amplifier Module)	√	√			
ATENZA	2.0L	PE	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	√	√			

ATENZA	2.0L	PE	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
ATENZA	2.0L	PE	Other	DSM(Driver Seat Module)	√	√	√		
ATENZA	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	√	√	√		
ATENZA	2.0L	PE	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	√	√	√		
ATENZA	2.0L	PE	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
ATENZA	2.0L	PE	Other	HUD(Head Up Display)	√	√			
ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	√	√	√	√	
ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	√	√			SP0084,SP0086,SP0086,SP0084
ATENZA	2.0L	PE	Other	PSM#1(Parking Sensor Module)	√	√	√		
ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)	√	√	√		
ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
ATENZA	2.0L	PE	Other	SCBS(Smart City Brake Support)	√	√	√		
ATENZA	2.0L	PE	Other	SSU(Smart Start Unit)	√	√	√	√	
ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	√	√	√	√	
ATENZA	2.5L	PY	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
ATENZA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
ATENZA	2.5L	PY	Other	AM(Amplifier Module)	√	√			
ATENZA	2.5L	PY	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
ATENZA	2.5L	PY	Other	CMU(Connectivity Master Unit)	√	√			
ATENZA	2.5L	PY	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
ATENZA	2.5L	PY	Other	DSM(Driver Seat Module)	√	√	√		
ATENZA	2.5L	PY	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
ATENZA	2.5L	PY	Other	EPB(Electric Parking Brake)	√	√	√		
ATENZA	2.5L	PY	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	√	√	√		
ATENZA	2.5L	PY	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
ATENZA	2.5L	PY	Other	HUD(Head Up Display)	√	√			
ATENZA	2.5L	PY	Other	IC(Instrument Cluster)	√	√	√	√	
ATENZA	2.5L	PY	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
ATENZA	2.5L	PY	Other	PSM#1(Parking Sensor Module)	√	√	√		
ATENZA	2.5L	PY	Other	RCM(Restraint Control Module)	√	√	√		
ATENZA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
ATENZA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
ATENZA	2.5L	PY	Other	SCBS(Smart City Brake Support)	√	√	√		
ATENZA	2.5L	PY	Other	SSU(Smart Start Unit)	√	√	√	√	
ATENZA	2.5L	PY	Other	TCM(Transmission Control Module)	√	√	√	√	
ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	√	√	√	√	

ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	ICCM(Intelligent Cruise Control Module)	√	√	√		
ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	LCM(Lighting Control Module)	√	√			
ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	MPM(Motor Pretensioner Module)	√	√	√	√	
ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	RCM(Restraint Control Module)	√	√	√		
ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	RVM(Rear Vehicle Monitoring)	√	√	√	√	
ATENZA (JPN)/MAZDA6 (General)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
ATENZA (JPN)/MAZDA6 (General)	2.5L	L5	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
ATENZA (JPN)/MAZDA6 (General)	2.5L	L5	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
ATENZA (JPN)/MAZDA6 (General)	2.5L	L5	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
ATENZA (JPN)/MAZDA6 (General)	2.5L	L5	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
ATENZA (JPN)/MAZDA6 (General)	2.5L	L5	2007 MY	IC(Instrument Cluster)	√	√	√	√	
ATENZA (JPN)/MAZDA6 (General)	2.5L	L5	2007 MY	ICCM(Intelligent Cruise Control Module)	√	√	√		
ATENZA (JPN)/MAZDA6 (General)	2.5L	L5	2007 MY	LCM(Lighting Control Module)	√	√			
ATENZA (JPN)/MAZDA6 (General)	2.5L	L5	2007 MY	MPM(Motor Pretensioner Module)	√	√	√	√	
ATENZA (JPN)/MAZDA6 (General)	2.5L	L5	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
ATENZA (JPN)/MAZDA6 (General)	2.5L	L5	2007 MY	RCM(Restraint Control Module)	√	√	√		
ATENZA (JPN)/MAZDA6 (General)	2.5L	L5	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
ATENZA (JPN)/MAZDA6 (General)	2.5L	L5	2007 MY	RVM(Rear Vehicle Monitoring)	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	LCM(Lighting Control Module)	√	√			
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	4X4(4X4 Control Module)	√	√			
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	LCM(Lighting Control Module)	√	√			
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	4X4(4X4 Control Module)	√	√			
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012

ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	IC(Instrument Cluster)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	RCM(Restraint Control Module)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	TCM(Transmission Control Module)	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	4X4(4X4 Control Module)	√	√			
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	GEM(Generic Electronic Module)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	IC(Instrument Cluster)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	LCM(Lighting Control Module)	√	√			
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	SP0007
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	RCM(Restraint Control Module)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2002 MY	IC(Instrument Cluster)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2002 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	SP0007
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2002 MY	RCM(Restraint Control Module)	√	√	√		
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2002 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
AXELA (Hybrid)	1.3L	P3	Other	ACN#1(Electronic Control Unit Of Air Conditioning)	√	√	√	√	
AXELA (Hybrid)	1.3L	P3	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
AXELA (Hybrid)	1.3L	P3	Other	AM(Amplifier Module)	√	√			
AXELA (Hybrid)	1.3L	P3	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
AXELA (Hybrid)	1.3L	P3	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
AXELA (Hybrid)	1.3L	P3	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
AXELA (Hybrid)	1.3L	P3	Other	CMU(Connectivity Master Unit)	√	√			
AXELA (Hybrid)	1.3L	P3	Other	EATC#1(Temperature Controller Of Electronic Air)	√	√	√	√	
AXELA (Hybrid)	1.3L	P3	Other	ECRB(Controlled Electronically Regenerative Cooperative Brake)	√	√	√	√	
AXELA (Hybrid)	1.3L	P3	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA (Hybrid)	1.3L	P3	Other	FSC(Forward Sensing Camera)	√	√	√		
AXELA (Hybrid)	1.3L	P3	Other	F BCM(Body Control Module - Front)	√	√	√	√	
AXELA (Hybrid)	1.3L	P3	Other	HV-ECU(Electronic Control Unit (ECU) Of Hybrid Vehicle)	√	√	√	√	
AXELA (Hybrid)	1.3L	P3	Other	IC(Instrument Cluster)	√	√	√	√	
AXELA (Hybrid)	1.3L	P3	Other	PCM(Powertrain Control Module)	√	√	√	√	
AXELA (Hybrid)	1.3L	P3	Other	PLK#1(Parking Lock Electronic Control Unit)	√	√	√		
AXELA (Hybrid)	1.3L	P3	Other	RCM(Restraint Control Module)	√	√	√		

AXELA (Hybrid)	1.3L	P3	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
AXELA (Hybrid)	1.3L	P3	Other	R BCM(Rear Body Control Module)	√	√	√	√	
AXELA (Hybrid)	1.3L	P3	Other	SCBS(Smart City Brake Support)	√	√	√		
AXELA (Hybrid)	1.3L	P3	Other	SSU(Smart Start Unit)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	ACN#1(Electronic Control Unit Of Air Conditioning)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
AXELA (Hybrid)	2.5L	PY	Other	AM(Amplifier Module)	√	√			
AXELA (Hybrid)	2.5L	PY	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	CMU(Connectivity Master Unit)	√	√			
AXELA (Hybrid)	2.5L	PY	Other	EATC#1(Temperature Controller Of Electronic Air)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	ECRB(Controlled Electronically Regenerative Cooperative Brake)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA (Hybrid)	2.5L	PY	Other	FSC(Forward Sensing Camera)	√	√	√		
AXELA (Hybrid)	2.5L	PY	Other	F BCM(Body Control Module - Front)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	HV-ECU(Electronic Control Unit (ECU) Of Hybrid Vehicle)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	IC(Instrument Cluster)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	PCM(Powertrain Control Module)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	PLK#1(Parking Lock Electronic Control Unit)	√	√	√		
AXELA (Hybrid)	2.5L	PY	Other	RCM(Restraint Control Module)	√	√	√		
AXELA (Hybrid)	2.5L	PY	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	R BCM(Rear Body Control Module)	√	√	√	√	
AXELA (Hybrid)	2.5L	PY	Other	SCBS(Smart City Brake Support)	√	√	√		
AXELA (Hybrid)	2.5L	PY	Other	SSU(Smart Start Unit)	√	√	√	√	
AXELA (Hybrid)	2.0L	PE	Other	ACN#1(Electronic Control Unit Of Air Conditioning)	√	√	√	√	
AXELA (Hybrid)	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
AXELA (Hybrid)	2.0L	PE	Other	AM(Amplifier Module)	√	√			
AXELA (Hybrid)	2.0L	PE	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
AXELA (Hybrid)	2.0L	PE	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
AXELA (Hybrid)	2.0L	PE	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
AXELA (Hybrid)	2.0L	PE	Other	CMU(Connectivity Master Unit)	√	√			
AXELA (Hybrid)	2.0L	PE	Other	EATC#1(Temperature Controller Of Electronic Air)	√	√	√	√	
AXELA (Hybrid)	2.0L	PE	Other	ECRB(Controlled Electronically Regenerative Cooperative Brake)	√	√	√	√	
AXELA (Hybrid)	2.0L	PE	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA (Hybrid)	2.0L	PE	Other	FSC(Forward Sensing Camera)	√	√	√		
AXELA (Hybrid)	2.0L	PE	Other	F BCM(Body Control Module - Front)	√	√	√	√	
AXELA (Hybrid)	2.0L	PE	Other	HV-ECU(Electronic Control Unit (ECU) Of Hybrid Vehicle)	√	√	√	√	
AXELA (Hybrid)	2.0L	PE	Other	IC(Instrument Cluster)	√	√	√	√	
AXELA (Hybrid)	2.0L	PE	Other	PCM(Powertrain Control Module)	√	√	√	√	
AXELA (Hybrid)	2.0L	PE	Other	PLK#1(Parking Lock Electronic Control Unit)	√	√	√		
AXELA (Hybrid)	2.0L	PE	Other	RCM(Restraint Control Module)	√	√	√		
AXELA (Hybrid)	2.0L	PE	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	

AXELA (Hybrid)	2.0L	PE	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
AXELA (Hybrid)	2.0L	PE	Other	SCBS(Smart City Brake Support)	√	√	√		
AXELA (Hybrid)	2.0L	PE	Other	SSU(Smart Start Unit)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	ACN#1(Electronic Control Unit Of Air Conditioning)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
AXELA (Hybrid)	2.2L	SH	Other	AM(Amplifier Module)	√	√			
AXELA (Hybrid)	2.2L	SH	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	CMU(Connectivity Master Unit)	√	√			
AXELA (Hybrid)	2.2L	SH	Other	EATC#1(Temperature Controller Of Electronic Air)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	ECRB(Controlled Electronically Regenerative Cooperative Brake)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA (Hybrid)	2.2L	SH	Other	FSC(Forward Sensing Camera)	√	√	√		
AXELA (Hybrid)	2.2L	SH	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	HV-ECU(Electronic Control Unit (ECU) Of Hybrid Vehicle)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	IC(Instrument Cluster)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	PCM(Powertrain Control Module)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	PLK#1(Parking Lock Electronic Control Unit)	√	√	√		
AXELA (Hybrid)	2.2L	SH	Other	RCM(Restraint Control Module)	√	√	√		
AXELA (Hybrid)	2.2L	SH	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
AXELA (Hybrid)	2.2L	SH	Other	SCBS(Smart City Brake Support)	√	√	√		
AXELA (Hybrid)	2.2L	SH	Other	SSU(Smart Start Unit)	√	√	√	√	
AXELA/MAZDA3	2.0L	PE	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3	2.0L	PE	Other	ACU(Audio Control Unit)	√	√			SP0046
AXELA/MAZDA3	2.0L	PE	Other	AFS(Adaptive Front Lighting System)	√	√	√		
AXELA/MAZDA3	2.0L	PE	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	2.0L	PE	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	2.0L	PE	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
AXELA/MAZDA3	2.0L	PE	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
AXELA/MAZDA3	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
AXELA/MAZDA3	2.0L	PE	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3	2.0L	PE	Other	IC(Instrument Cluster)	√	√	√	√	
AXELA/MAZDA3	2.0L	PE	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	2.0L	PE	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	2.0L	PE	Other	MID#1(Multi-Information Display)	√	√	√		
AXELA/MAZDA3	2.0L	PE	Other	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3	2.0L	PE	Other	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3	2.0L	PE	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
AXELA/MAZDA3	2.0L	PE	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
AXELA/MAZDA3	1.6L	Y6	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3	1.6L	Y6	Other	ACU(Audio Control Unit)	√	√			SP0024,SP0046

AXELA/MAZDA3	1.6L	Y6	Other	AFS(Adaptive Front Lighting System)	√	√	√		
AXELA/MAZDA3	1.6L	Y6	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	1.6L	Y6	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	1.6L	Y6	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
AXELA/MAZDA3	1.6L	Y6	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
AXELA/MAZDA3	1.6L	Y6	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
AXELA/MAZDA3	1.6L	Y6	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3	1.6L	Y6	Other	FACM(Fuel Additive Control Module)	√	√	√	√	SP0051
AXELA/MAZDA3	1.6L	Y6	Other	IC(Instrument Cluster)	√	√	√	√	
AXELA/MAZDA3	1.6L	Y6	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	1.6L	Y6	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	1.6L	Y6	Other	MID#1(Multi-Information Display)	√	√	√		
AXELA/MAZDA3	1.6L	Y6	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0013,SP0052,SP0053,SP0054
AXELA/MAZDA3	1.6L	Y6	Other	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3	1.6L	Y6	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
AXELA/MAZDA3	1.6L	Y6	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
AXELA/MAZDA3	1.6L	Z6	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3	1.6L	Z6	Other	ACU(Audio Control Unit)	√	√			SP0046
AXELA/MAZDA3	1.6L	Z6	Other	AFS(Adaptive Front Lighting System)	√	√	√		
AXELA/MAZDA3	1.6L	Z6	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	1.6L	Z6	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	1.6L	Z6	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
AXELA/MAZDA3	1.6L	Z6	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
AXELA/MAZDA3	1.6L	Z6	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
AXELA/MAZDA3	1.6L	Z6	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3	1.6L	Z6	Other	IC(Instrument Cluster)	√	√	√	√	
AXELA/MAZDA3	1.6L	Z6	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	1.6L	Z6	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	1.6L	Z6	Other	MID#1(Multi-Information Display)	√	√	√		
AXELA/MAZDA3	1.6L	Z6	Other	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3	1.6L	Z6	Other	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3	1.6L	Z6	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
AXELA/MAZDA3	1.6L	Z6	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
AXELA/MAZDA3	2.3L	L3 T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3	2.3L	L3 T	Other	ACU(Audio Control Unit)	√	√			SP0024,SP0046
AXELA/MAZDA3	2.3L	L3 T	Other	AFS(Adaptive Front Lighting System)	√	√	√		
AXELA/MAZDA3	2.3L	L3 T	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	2.3L	L3 T	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	2.3L	L3 T	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
AXELA/MAZDA3	2.3L	L3 T	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
AXELA/MAZDA3	2.3L	L3 T	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
AXELA/MAZDA3	2.3L	L3 T	Other	EPS(Electronic Controlled Power Steering)	√	√	√		

AXELA/MAZDA3	2.3L	L3 T	Other	IC(Instrument Cluster)	√	√	√	√	
AXELA/MAZDA3	2.3L	L3 T	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	2.3L	L3 T	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	2.3L	L3 T	Other	MID#1(Multi-Information Display)	√	√	√		
AXELA/MAZDA3	2.3L	L3 T	Other	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3	2.3L	L3 T	Other	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3	2.3L	L3 T	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
AXELA/MAZDA3	2.3L	L3 T	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
AXELA/MAZDA3	1.5L	ZY	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3	1.5L	ZY	Other	ACU(Audio Control Unit)	√	√			SP0046
AXELA/MAZDA3	1.5L	ZY	Other	AFS(Adaptive Front Lighting System)	√	√	√		
AXELA/MAZDA3	1.5L	ZY	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	1.5L	ZY	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	1.5L	ZY	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
AXELA/MAZDA3	1.5L	ZY	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
AXELA/MAZDA3	1.5L	ZY	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
AXELA/MAZDA3	1.5L	ZY	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3	1.5L	ZY	Other	IC(Instrument Cluster)	√	√	√	√	
AXELA/MAZDA3	1.5L	ZY	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	1.5L	ZY	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	1.5L	ZY	Other	MID#1(Multi-Information Display)	√	√	√		
AXELA/MAZDA3	1.5L	ZY	Other	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3	1.5L	ZY	Other	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3	1.5L	ZY	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
AXELA/MAZDA3	1.5L	ZY	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
AXELA/MAZDA3	1.5L	ZY	Other	TCM(Transmission Control Module)	√	√	√	√	
AXELA/MAZDA3	2.0L	LF	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3	2.0L	LF	Other	ACU(Audio Control Unit)	√	√			SP0024,SP0046
AXELA/MAZDA3	2.0L	LF	Other	AFS(Adaptive Front Lighting System)	√	√	√		
AXELA/MAZDA3	2.0L	LF	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	2.0L	LF	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	2.0L	LF	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
AXELA/MAZDA3	2.0L	LF	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
AXELA/MAZDA3	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
AXELA/MAZDA3	2.0L	LF	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3	2.0L	LF	Other	IC(Instrument Cluster)	√	√	√	√	
AXELA/MAZDA3	2.0L	LF	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	2.0L	LF	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	2.0L	LF	Other	MID#1(Multi-Information Display)	√	√	√		
AXELA/MAZDA3	2.0L	LF	Other	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3	2.0L	LF	Other	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3	2.0L	LF	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
AXELA/MAZDA3	2.0L	LF	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
AXELA/MAZDA3	2.0L	LF	Other	TCM(Transmission Control Module)	√	√	√	√	

AXELA/MAZDA3	2.2L	R2 T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3	2.2L	R2 T	Other	ACU(Audio Control Unit)	√	√			SP0046
AXELA/MAZDA3	2.2L	R2 T	Other	AFS(Adaptive Front Lighting System)	√	√	√		
AXELA/MAZDA3	2.2L	R2 T	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	2.2L	R2 T	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	2.2L	R2 T	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
AXELA/MAZDA3	2.2L	R2 T	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
AXELA/MAZDA3	2.2L	R2 T	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
AXELA/MAZDA3	2.2L	R2 T	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3	2.2L	R2 T	Other	FFH(Fuel Fired Coolant Heating Module)	√	√	√	√	
AXELA/MAZDA3	2.2L	R2 T	Other	IC(Instrument Cluster)	√	√	√	√	
AXELA/MAZDA3	2.2L	R2 T	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	2.2L	R2 T	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	2.2L	R2 T	Other	MID#1(Multi-Information Display)	√	√	√		
AXELA/MAZDA3	2.2L	R2 T	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0020
AXELA/MAZDA3	2.2L	R2 T	Other	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3	2.2L	R2 T	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
AXELA/MAZDA3	2.2L	R2 T	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
AXELA/MAZDA3	2.5L	L5	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3	2.5L	L5	Other	ACU(Audio Control Unit)	√	√			SP0024,SP0046
AXELA/MAZDA3	2.5L	L5	Other	AFS(Adaptive Front Lighting System)	√	√	√		
AXELA/MAZDA3	2.5L	L5	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	2.5L	L5	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
AXELA/MAZDA3	2.5L	L5	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
AXELA/MAZDA3	2.5L	L5	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
AXELA/MAZDA3	2.5L	L5	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
AXELA/MAZDA3	2.5L	L5	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3	2.5L	L5	Other	IC(Instrument Cluster)	√	√	√	√	
AXELA/MAZDA3	2.5L	L5	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	2.5L	L5	Other	LCM(Lighting Control Module)	√	√			
AXELA/MAZDA3	2.5L	L5	Other	MID#1(Multi-Information Display)	√	√	√		
AXELA/MAZDA3	2.5L	L5	Other	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3	2.5L	L5	Other	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3	2.5L	L5	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
AXELA/MAZDA3	2.5L	L5	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
AXELA/MAZDA3	2.5L	L5	Other	TCM(Transmission Control Module)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2003 MY	EATC(Electronic Automatic Temperature Control)	√	√			
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2003 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2003 MY	GEM(Generic Electronic Module)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2003 MY	IC(Instrument Cluster)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2003 MY	RCM(Restraint Control Module)	√	√	√		

AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√			
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2006 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2006 MY	IC(Instrument Cluster)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2006 MY	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√			
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2006 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2006 MY	IC(Instrument Cluster)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2006 MY	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3 T	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3 T	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√			
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3 T	2006 MY	GEM(Generic Electronic Module)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3 T	2006 MY	IC(Instrument Cluster)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3 T	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3 T	2006 MY	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3 T	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√			
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2006 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2006 MY	GEM(Generic Electronic Module)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2006 MY	IC(Instrument Cluster)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2006 MY	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	1.5L	ZY	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2003 MY	EATC(Electronic Automatic Temperature Control)	√	√			
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2003 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2003 MY	GEM(Generic Electronic Module)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2003 MY	IC(Instrument Cluster)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	2.3L	L3	2003 MY	RCM(Restraint Control Module)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012

AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2003 MY	EATC(Electronic Automatic Temperature Control)	√	√			
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2003 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2003 MY	GEM(Generic Electronic Module)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2003 MY	IC(Instrument Cluster)	√	√	√		
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
AXELA/MAZDA3 (Japan/General Specifications)	2.0L	LF	2003 MY	RCM(Restraint Control Module)	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A-T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A-T	Other	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A-T	Other	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A-T	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A-T	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A-T	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A-T	2001 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	F6A-T	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	F6A-T	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	F6A-T	1998 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A	2002 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A	2002 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A	1998 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A	2000 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A-T	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A-T	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A-T	1999 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	K6A	1999 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	F6A-T	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	F6A-T	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ)/SPIANO (HF)	660cc	F6A-T	2000 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		

AZ WAGON (MD/MJ/SPIANO (HF))	660cc	F6A-T	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	F6A-T	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	F6A-T	1999 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A-T	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A-T	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A-T	2000 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	F6A-T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	F6A-T	Other	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	F6A-T	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A-T	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A-T	1998 MY	PCM(Powertrain Control Module)	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A-T	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A-T	1998 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A-T	1998 MY	TCM(Transmission Control Module)	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A	2001 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ WAGON (MD/MJ/SPIANO (HF))	660cc	K6A	2005 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-OFFROAD	660cc	K6A-T	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-OFFROAD	660cc	K6A-T	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ-OFFROAD	660cc	K6A-T	2008 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-OFFROAD	660cc	K6A-T	2008 MY	TCM(Transmission Control Module)	√	√	√		
AZ-OFFROAD	660cc	K6A-T	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-OFFROAD	660cc	K6A-T	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ-OFFROAD	660cc	K6A-T	2003 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-OFFROAD	660cc	K6A-T	2003 MY	TCM(Transmission Control Module)	√	√	√		
AZ-OFFROAD	660cc	K6A-T	2002 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-OFFROAD	660cc	K6A-T	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ-OFFROAD	660cc	K6A-T	2002 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-OFFROAD	660cc	K6A-T	2002 MY	TCM(Transmission Control Module)	√	√	√		
AZ-OFFROAD	660cc	K6A-T	2004 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-OFFROAD	660cc	K6A-T	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	

AZ-OFFROAD	660cc	K6A-T	2004 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-OFFROAD	660cc	K6A-T	2004 MY	TCM(Transmission Control Module)	√	√	√		
AZ-OFFROAD	660cc	K6A-T	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-OFFROAD	660cc	K6A-T	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ-OFFROAD	660cc	K6A-T	1999 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-OFFROAD	660cc	K6A-T	1999 MY	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON (MJ)	660cc	K6A	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-WAGON (MJ)	660cc	K6A	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ-WAGON (MJ)	660cc	K6A	2006 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-WAGON (MJ)	660cc	K6A	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-WAGON (MJ)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ-WAGON (MJ)	660cc	K6A	2005 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-WAGON (MJ)	660cc	K6A	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-WAGON (MJ)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ-WAGON (MJ)	660cc	K6A	2003 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-WAGON (MJ)	660cc	K6A-T	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-WAGON (MJ)	660cc	K6A-T	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ-WAGON (MJ)	660cc	K6A-T	2005 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-WAGON (MJ)	660cc	K6A-T	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-WAGON (MJ)	660cc	K6A-T	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
AZ-WAGON (MJ)	660cc	K6A-T	2003 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	ABS(Antilock Braking System (ABS))	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	BCM#1(Body Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	IC(Instrument Cluster)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	LCM(Lighting Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	PCM(Powertrain Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		

AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A-T	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	ABS(Antilock Braking System (ABS))	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	BCM#1(Body Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	IC(Instrument Cluster)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	LCM(Lighting Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	PCM(Powertrain Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	ABS(Antilock Braking System (ABS))	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	BCM#1(Body Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	IC(Instrument Cluster)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	LCM(Lighting Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	PCM(Powertrain Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	TCM(Transmission Control Module)	√	√	√		

AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	A-STOP(A-STOP System - No Idling System)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	ABS(Antilock Braking System (ABS))	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	BCM#1(Body Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	IC(Instrument Cluster)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	LCM(Lighting Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	PCM(Powertrain Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A T (A Stop)	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	A-STOP(A-STOP System - No Idling System)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	ABS(Antilock Braking System (ABS))	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	BCM#1(Body Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	IC(Instrument Cluster)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	LCM(Lighting Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	PCM(Powertrain Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		

AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	K6A (A-STOP)	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	A-STOP(A-STOP System - No Idling System)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	ABS(Antilock Braking System (ABS))	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	BCM#1(Body Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	IC(Instrument Cluster)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	LCM(Lighting Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	PCM(Powertrain Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	TCM(Transmission Control Module)	√	√	√		
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/FLAIR WAGON/FLAIR	660cc	R06A (A Stop)	Other	TCM(Transmission Control Module)	√	√	√		
Biante(Japan)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Biante(Japan)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Biante(Japan)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
Biante(Japan)	2.3L	L3	2008 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
Biante(Japan)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	√	√	√		
Biante(Japan)	2.3L	L3	2008 MY	IC(Instrument Cluster)	√	√	√		
Biante(Japan)	2.3L	L3	2008 MY	LPSDM(Power Sliding Door Module - Left)	√	√	√		
Biante(Japan)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
Biante(Japan)	2.3L	L3	2008 MY	RCM(Restraint Control Module)	√	√	√		
Biante(Japan)	2.3L	L3	2008 MY	RKE(Remote Keyless Entry)	√	√	√	√	
Biante(Japan)	2.3L	L3	2008 MY	RPSDM(Right Power Sliding Door Module)	√	√	√		
Biante(Japan)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
Biante(Japan)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Biante(Japan)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012

Biante(Japan)	2.0L	LF	2008 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
Biante(Japan)	2.0L	LF	2008 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
Biante(Japan)	2.0L	LF	2008 MY	GEM(Generic Electronic Module)	√	√	√		
Biante(Japan)	2.0L	LF	2008 MY	IC(Instrument Cluster)	√	√	√		
Biante(Japan)	2.0L	LF	2008 MY	LPSDM(Power Sliding Door Module - Left)	√	√	√		
Biante(Japan)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
Biante(Japan)	2.0L	LF	2008 MY	RCM(Restraint Control Module)	√	√	√		
Biante(Japan)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	√	√	√	√	
Biante(Japan)	2.0L	LF	2008 MY	RPSDM(Right Power Sliding Door Module)	√	√	√		
Biante(Japan)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
Biante(Japan)	2.0L	PE	2012 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
Biante(Japan)	2.0L	PE	2012 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
Biante(Japan)	2.0L	PE	2012 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
Biante(Japan)	2.0L	PE	2012 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
Biante(Japan)	2.0L	PE	2012 MY	GEM(Generic Electronic Module)	√	√	√		
Biante(Japan)	2.0L	PE	2012 MY	IC(Instrument Cluster)	√	√	√	√	
Biante(Japan)	2.0L	PE	2012 MY	LPSDM(Power Sliding Door Module - Left)	√	√	√		
Biante(Japan)	2.0L	PE	2012 MY	PCM(Powertrain Control Module)	√	√	√	√	
Biante(Japan)	2.0L	PE	2012 MY	RCM(Restraint Control Module)	√	√	√		
Biante(Japan)	2.0L	PE	2012 MY	RKE(Remote Keyless Entry)	√	√	√	√	
Biante(Japan)	2.0L	PE	2012 MY	RPSDM(Right Power Sliding Door Module)	√	√	√		
Biante(Japan)	2.0L	PE	2012 MY	TCM(Transmission Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.0L	FE	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.0L	FE	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.0L	FE	2002 MY	TCM(Transmission Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.0L	FE	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.0L	FE	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.5L	WL	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.5L	WL	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.5L	WL	1999 MY	TCM(Transmission Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.0L	FE	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.0L	FE	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.0L	FE	1999 MY	TCM(Transmission Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.2L	R2	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	2.2L	R2	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO BRAWNY/ECONOVAN/MAZDA E-SERIES	1.8L	F8	1999 MY	A/C(Air Conditioning)	√	√			

BONGO BRAUNY/ECONOVAN/MAZDA E-SERIES	1.8L	F8	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO BRAUNY/ECONOVAN/MAZDA E-SERIES	1.8L	F8	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO BRAUNY/ECONOVAN/MAZDA E-SERIES	2.0L	FE	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO BRAUNY/ECONOVAN/MAZDA E-SERIES	2.0L	FE	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	2.2L	R2	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	2.2L	R2	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	F8	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	F8	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	F8	1999 MY	TCM(Transmission Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	2.0L	RF T	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	2.0L	RF T	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	2.0L	RF T	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	2.0L	RF T	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	L8	2016 (MY)	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	L8	2016 (MY)	IC(Instrument Cluster)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	L8	2016 (MY)	PCM(Powertrain Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	L8	2016 (MY)	TCM(Transmission Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	2.0L	RF T	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	2.0L	RF T	2003 MY	PCM(Powertrain Control Module (PCM))	√	√			
BONGO/BONGO BRAUNY/SPECTRON	2.0L	RF T	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	2.0L	RF T	2003 MY	TCM(Transmission Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	2.0L	RF T	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	2.0L	RF T	2004 MY	PCM(Powertrain Control Module (PCM))	√	√			
BONGO/BONGO BRAUNY/SPECTRON	2.0L	RF T	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	2.0L	RF T	2004 MY	TCM(Transmission Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	F8	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	F8	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	F8	2002 MY	TCM(Transmission Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	L8	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	L8	2010 MY	IC(Instrument Cluster)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	L8	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
BONGO/BONGO BRAUNY/SPECTRON	1.8L	L8	2010 MY	TCM(Transmission Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endavour	2.5L	WL T	1999 MY	TCM(Transmission Control Module)	√	√			
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endavour	2.5L	WL	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endavour	2.5L	WL	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	

B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.6L	G6	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.9L	W9	1999 MY	PCM(Powertrain Control Module (PCM))	√	√			
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.2L	F2	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.5L	WL	1999 MY	PCM(Powertrain Control Module (PCM))	√	√			
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.5L	WL	1999 MY	TCM(Transmission Control Module)	√	√			
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.5L	WL T	2002 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.5L	WL T	2002 MY	PCM(Powertrain Control Module (PCM))	√	√			
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.5L	WL T	2002 MY	TCM(Transmission Control Module)	√	√			
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.2L	F2	2002 MY	PCM(Powertrain Control Module)	√	√	√		
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.2L	F2	2002 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.5L	WL T	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.5L	WL T	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.5L	WL T	2001 MY	TCM(Transmission Control Module)	√	√			
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.2L	F2	Other	PCM(Powertrain Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.9L	W9	2002 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.9L	W9	2002 MY	PCM(Powertrain Control Module (PCM))	√	√			
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.5L	WL	2002 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endeavour	2.5L	WL	2002 MY	PCM(Powertrain Control Module (PCM))	√	√			

B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endavour	2.2L	F2	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endavour	2.5L	WL T	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endavour	2.5L	WL T	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endavour	2.5L	WL T	2005 MY	TCM(Transmission Control Module)	√	√			
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endavour	2.6L	G6	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
B-Series/Bravo/Fighter/Courier/Ranger/Everest/Endavour	2.6L	G6	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
BT-50/Ranger	2.5L	WL	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BT-50/Ranger	2.5L	WL	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
BT-50/Ranger	2.5L	WL	2007 MY	RCM(Restraint Control Module)	√	√	√		
BT-50/Ranger	2.5L	L5	2012 MY	IC(Instrument Cluster)	√	√			
BT-50/Ranger	2.5L	L5	2012 MY	PCM(Powertrain Control Module)	√	√	√		
BT-50/Ranger	2.2L	F2	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BT-50/Ranger	2.2L	F2	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
BT-50/Ranger	2.2L	F2	2007 MY	RCM(Restraint Control Module)	√	√	√		
BT-50/Ranger	2.6L	G6	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BT-50/Ranger	2.6L	G6	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
BT-50/Ranger	2.6L	G6	2007 MY	RCM(Restraint Control Module)	√	√	√		
BT-50/Ranger	3.0L	WE-CD	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BT-50/Ranger	3.0L	WE-CD	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
BT-50/Ranger	3.0L	WE-CD	2007 MY	RCM(Restraint Control Module)	√	√	√		
BT-50/Ranger	3.0L	WE-CD	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
BT-50/Ranger	4.0L	V6 SOHC	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
BT-50/Ranger	4.0L	V6 SOHC	2007 MY	ESOF(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BT-50/Ranger	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
BT-50/Ranger	4.0L	V6 SOHC	2007 MY	RCM(Restraint Control Module)	√	√	√		
BT-50/Ranger	2.5L	WL-CD	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
BT-50/Ranger	2.5L	WL-CD	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
BT-50/Ranger	2.5L	WL-CD	2007 MY	RCM(Restraint Control Module)	√	√	√		
BT-50/Ranger	2.5L	WL-CD	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	2.0L	FS	1999 MY	A/C(Air Conditioning)	√	√			
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	2.0L	FS	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	1.8L	FP	1999 MY	A/C(Air Conditioning)	√	√			

CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	1.8L	FP	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	1.8L	FP	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	1.8L	FP	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	1.8L	FP	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	2.5L	KL	1999 MY	A/C(Air Conditioning)	√	√			
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	2.5L	KL	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	2.5L	KL	1999 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	2.0L	RF	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	2.0L	RF	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	2.0L	FS	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	2.0L	FS	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAROL	660cc	K6A	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL	660cc	K6A	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAROL	660cc	K6A	1998 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL	660cc	K6A	1998 MY	TCM(Transmission Control Module)	√	√	√		
CAROL	660cc	K6A	2002 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL	660cc	K6A	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAROL	660cc	K6A	2002 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL	660cc	F6A	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL	660cc	F6A	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAROL	660cc	F6A	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAROL	660cc	F6A	1998 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL	660cc	K6A	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL	660cc	K6A	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAROL	660cc	K6A	2001 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL	660cc	K6A	2001 MY	TCM(Transmission Control Module)	√	√	√		
CAROL	660cc	K6A	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL	660cc	K6A	Other	PCM(Powertrain Control Module)	√	√	√		
CAROL	660cc	K6A	Other	PCM(Powertrain Control Module)	√	√	√	√	
CAROL	660cc	K6A	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL	660cc	K6A	Other	TCM(Transmission Control Module)	√	√	√		
CAROL	660cc	K6A	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL	660cc	K6A	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAROL	660cc	K6A	1999 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL	660cc	K6A	1999 MY	TCM(Transmission Control Module)	√	√	√		
CAROL	660cc	K6A	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		

CAROL	660cc	K6A	2000 MY	PCM(Powertrain Control Module)	√	√	√		
CAROL	660cc	K6A	2000 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL	660cc	F6A	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL	660cc	F6A	Other	PCM(Powertrain Control Module)	√	√	√	√	
CAROL	660cc	F6A	Other	PCM(Powertrain Control Module)	√	√	√	√	
CAROL	660cc	F6A	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL (2003/9 -)	660cc	K6A	2004 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL (2003/9 -)	660cc	K6A	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAROL (2003/9 -)	660cc	K6A	2004 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL (2003/9 -)	660cc	K6A	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
CAROL (2003/9 -)	660cc	K6A	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√			
CAROL (2003/9 -)	660cc	K6A	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL (2003/9 -)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAROL (2003/9 -)	660cc	K6A	2003 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL (HB24S)	660cc	K6A	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL (HB24S)	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAROL (HB24S)	660cc	K6A	2005 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL (HB24S)	660cc	K6A	2004 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL (HB24S)	660cc	K6A	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
CAROL (HB24S)	660cc	K6A	2004 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	A-STOP(A-STOP System - No Idling System)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	ABS(Antilock Braking System (ABS))	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	AVAS(Acoustic Vehicle Alerting System)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	BCM#1(Body Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	BMU(Management Unit Of Battery)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	CGW(Central Gateway)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	DSBS(Support System Of Dual Sensor Brake)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	HUD(Head Up Display)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	IC(Instrument Cluster)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	ISG(Generator Of Integrated Starter)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	L/T_SW(Switch Of Lighting And Turn Signal)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	LCM(Lighting Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	PCM(Powertrain Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	RBS(Radar Brake Support)	√	√	√		

CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	RCM(Restraint Control Module)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	REBS(Rear Sonar Brake Support)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	SCAM(Stereo Camera)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	SCAM(Stereo Camera)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A T (A Stop)	Other	TCM(Transmission Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	ABS(Antilock Braking System (ABS))	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	BCM#1(Body Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	BMU(Management Unit Of Battery)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	IC(Instrument Cluster)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	ISG(Generator Of Integrated Starter)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	LCM(Lighting Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	PCM(Powertrain Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	RBS(Radar Brake Support)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	SCAM(Stereo Camera)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A (A Stop)	Other	TCM(Transmission Control Module)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	A-STOP(A-STOP System - No Idling System)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	ABS(Antilock Braking System (ABS))	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	AVAS(Acoustic Vehicle Alerting System)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	BCM#1(Body Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	BMU(Management Unit Of Battery)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	CGW(Central Gateway)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	DSBS(Support System Of Dual Sensor Brake)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	HUD(Head Up Display)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	IC(Instrument Cluster)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	ISG(Generator Of Integrated Starter)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	L/T_SW(Switch Of Lighting And Turn Signal)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	LCM(Lighting Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	PCM(Powertrain Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	RBS(Radar Brake Support)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	RCM(Restraint Control Module)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	REBS(Rear Sonar Brake Support)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	SCAM(Stereo Camera)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	SCAM(Stereo Camera)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A	Other	TCM(Transmission Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T	Other	ABS(Antilock Braking System (ABS))	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T	Other	BCM#1(Body Control Module)	√	√	√	√	

CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T	Other	IC(Instrument Cluster)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T	Other	LCM(Lighting Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T	Other	PCM(Powertrain Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T	Other	RBS(Radar Brake Support)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T	Other	RCM(Restraint Control Module)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	R06A-T	Other	TCM(Transmission Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	A-STOP(A-STOP System - No Idling System)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	ABS(Antilock Braking System (ABS))	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	AVAS(Acoustic Vehicle Alerting System)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	BCM#1(Body Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	BMU(Management Unit Of Battery)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	CGW(Central Gateway)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	DSBS(Support System Of Dual Sensor Brake)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	HUD(Head Up Display)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	IC(Instrument Cluster)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	ISG(Generator Of Integrated Starter)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	L/T SW(Switch Of Lighting And Turn Signal)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	LCM(Lighting Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	PCM(Powertrain Control Module)	√	√	√	√	
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	RBS(Radar Brake Support)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	RCM(Restraint Control Module)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	REBS(Rear Sonar Brake Support)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	SCAM(Stereo Camera)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	SCAM(Stereo Camera)	√	√	√		
CAROL/FLAIR WAGON/SCRUM/FLAIR	660cc	K6A	Other	TCM(Transmission Control Module)	√	√	√	√	
Cougar	2.5L	Duratec-VE	2001 MY	ABS(Anti-Lock Brake System)	√	√			
Cougar	2.5L	Duratec-VE	2001 MY	IC(Instrument Cluster)	√	√			
Cougar	2.5L	Duratec-VE	2001 MY	MC(Message Center)	√	√			
Cougar	2.5L	Duratec-VE	2001 MY	PCM(Powertrain Control Module (PCM))	√	√			
Cougar	2.5L	Duratec-VE	2001 MY	PCM(Powertrain Control Module)	√	√	√		
Cougar	2.5L	Duratec-VE	2001 MY	REM(Rear Electronic Module)	√	√	√		
CX-3	2.0L	PE	Other	4X4(4X4 Control Module)	√	√	√	√	
CX-3	2.0L	PE	Other	ABS(Antilock Braking System)	√	√	√	√	
CX-3	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
CX-3	2.0L	PE	Other	BCM#1(Body Control Module)	√	√	√	√	
CX-3	2.0L	PE	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
CX-3	2.0L	PE	Other	CMU(Connectivity Master Unit)	√	√			
CX-3	2.0L	PE	Other	DCDC(DC To DC Converter Control Module)	√	√	√	√	
CX-3	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		

CX-3	2.0L	PE	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-3	2.0L	PE	Other	ESU(Electric Supply Unit)	√	√			
CX-3	2.0L	PE	Other	FSC(Forward Sensing Camera)	√	√	√		
CX-3	2.0L	PE	Other	IC(Instrument Cluster)	√	√	√	√	
CX-3	2.0L	PE	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
CX-3	2.0L	PE	Other	RCM(Restraint Control Module)	√	√	√		
CX-3	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
CX-3	2.0L	PE	Other	SCBS(Smart City Brake Support)	√	√	√		
CX-3	2.0L	PE	Other	SSU(Smart Start Unit)	√	√	√	√	
CX-3	2.0L	PE	Other	TCM(Transmission Control Module)	√	√	√	√	
CX-3	1.5L	S5	Other	ABS(Antilock Braking System)	√	√	√	√	
CX-3	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
CX-3	1.5L	S5	Other	BCM#1(Body Control Module)	√	√	√	√	
CX-3	1.5L	S5	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
CX-3	1.5L	S5	Other	CMU(Connectivity Master Unit)	√	√			
CX-3	1.5L	S5	Other	DCDC(DC To DC Converter Control Module)	√	√	√	√	
CX-3	1.5L	S5	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CX-3	1.5L	S5	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-3	1.5L	S5	Other	ESU(Electric Supply Unit)	√	√			
CX-3	1.5L	S5	Other	FSC(Forward Sensing Camera)	√	√	√		
CX-3	1.5L	S5	Other	IC(Instrument Cluster)	√	√	√	√	
CX-3	1.5L	S5	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
CX-3	1.5L	S5	Other	RCM(Restraint Control Module)	√	√	√		
CX-3	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
CX-3	1.5L	S5	Other	SCBS(Smart City Brake Support)	√	√	√		
CX-3	1.5L	S5	Other	SSU(Smart Start Unit)	√	√	√	√	
CX-3	1.5L	S5	Other	TCM(Transmission Control Module)	√	√	√	√	
CX-3	1.8L	S8	Other	4X4(4X4 Control Module)	√	√	√	√	
CX-3	1.8L	S8	Other	ABS(Antilock Braking System)	√	√	√	√	
CX-3	1.8L	S8	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
CX-3	1.8L	S8	Other	BCM#1(Body Control Module)	√	√	√	√	
CX-3	1.8L	S8	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
CX-3	1.8L	S8	Other	CMU(Connectivity Master Unit)	√	√			
CX-3	1.8L	S8	Other	DCDC(DC To DC Converter Control Module)	√	√	√	√	
CX-3	1.8L	S8	Other	DSM(Driver Seat Module)	√	√	√		
CX-3	1.8L	S8	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CX-3	1.8L	S8	Other	EPB(Electric Parking Brake)	√	√	√		
CX-3	1.8L	S8	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-3	1.8L	S8	Other	ESU(Electric Supply Unit)	√	√			
CX-3	1.8L	S8	Other	FSC(Forward Sensing Camera)	√	√	√		
CX-3	1.8L	S8	Other	HUD(Head Up Display)	√	√	√	√	
CX-3	1.8L	S8	Other	IC(Instrument Cluster)	√	√	√	√	
CX-3	1.8L	S8	Other	PCM(Powertrain Control Module)	√	√			SP0084,SP0086
CX-3	1.8L	S8	Other	PSM#1(Parking Sensor Module)	√	√	√		
CX-3	1.8L	S8	Other	RCM(Restraint Control Module)	√	√	√		

CX-3	1.8L	S8	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
CX-3	1.8L	S8	Other	SSU(Smart Start Unit)	√	√	√	√	
CX-3	1.8L	S8	Other	TCM(Transmission Control Module)	√	√	√	√	
CX-3	1.8L	S8	Other	VMC(View Monitor Camera)	√	√			
CX-4	2.5L	PY	Other	4X4(4X4 Control Module)	√	√	√	√	
CX-4	2.5L	PY	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-4	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
CX-4	2.5L	PY	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
CX-4	2.5L	PY	Other	CMU(Connectivity Master Unit)	√	√			
CX-4	2.5L	PY	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
CX-4	2.5L	PY	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CX-4	2.5L	PY	Other	EPB(Electric Parking Brake)	√	√	√		
CX-4	2.5L	PY	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-4	2.5L	PY	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
CX-4	2.5L	PY	Other	IC(Instrument Cluster)	√	√	√	√	
CX-4	2.5L	PY	Other	PCM(Powertrain Control Module)	√	√	√	√	
CX-4	2.5L	PY	Other	RCM(Restraint Control Module)	√	√	√		
CX-4	2.5L	PY	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
CX-4	2.5L	PY	Other	SCBS(Smart City Brake Support)	√	√	√		
CX-4	2.5L	PY	Other	SSU(Smart Start Unit)	√	√	√	√	
CX-4	2.5L	PY	Other	TCM(Transmission Control Module)	√	√	√	√	
CX-4	2.0L	PE	Other	4X4(4X4 Control Module)	√	√	√	√	
CX-4	2.0L	PE	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-4	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
CX-4	2.0L	PE	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
CX-4	2.0L	PE	Other	CMU(Connectivity Master Unit)	√	√			
CX-4	2.0L	PE	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
CX-4	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CX-4	2.0L	PE	Other	EPB(Electric Parking Brake)	√	√	√		
CX-4	2.0L	PE	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-4	2.0L	PE	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
CX-4	2.0L	PE	Other	IC(Instrument Cluster)	√	√	√	√	
CX-4	2.0L	PE	Other	PCM(Powertrain Control Module)	√	√	√	√	
CX-4	2.0L	PE	Other	RCM(Restraint Control Module)	√	√	√		
CX-4	2.0L	PE	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
CX-4	2.0L	PE	Other	SCBS(Smart City Brake Support)	√	√	√		
CX-4	2.0L	PE	Other	SSU(Smart Start Unit)	√	√	√	√	
CX-4	2.0L	PE	Other	TCM(Transmission Control Module)	√	√	√	√	
CX-5	2.0L	PE	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-5	2.0L	PE	Other	ACU(Audio Control Unit)	√	√			
CX-5	2.0L	PE	Other	AFS(Adaptive Front Lighting System)	√	√	√		SP0070
CX-5	2.0L	PE	Other	AM(Amplifier Module)	√	√			
CX-5	2.0L	PE	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
CX-5	2.0L	PE	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	

CX-5	2.0L	PE	Other	DSM(Driver Seat Module)	√	√	√		
CX-5	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CX-5	2.0L	PE	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-5	2.0L	PE	Other	FSC(Forward Sensing Camera)	√	√	√		
CX-5	2.0L	PE	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
CX-5	2.0L	PE	Other	IC(Instrument Cluster)	√	√	√	√	
CX-5	2.0L	PE	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0085,SP0086
CX-5	2.0L	PE	Other	RCM(Restraint Control Module)	√	√	√		SP0072
CX-5	2.0L	PE	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
CX-5	2.0L	PE	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
CX-5	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		SP0073,SP0074
CX-5	2.0L	PE	Other	SCBS(Smart City Brake Support)	√	√	√		
CX-5	2.0L	PE	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
CX-5	2.0L	PE	Other	EPB(Electric Parking Brake)	√	√	√		
CX-5	2.5L	PY T	Other	4X4(4X4 Control Module)	√	√	√	√	
CX-5	2.5L	PY T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-5	2.5L	PY T	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
CX-5	2.5L	PY T	Other	AM(Amplifier Module)	√	√	√	√	
CX-5	2.5L	PY T	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
CX-5	2.5L	PY T	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-5	2.5L	PY T	Other	CMU(Connectivity Master Unit)	√	√			
CX-5	2.5L	PY T	Other	DCDC(DC To DC Converter Control Module)	√	√			
CX-5	2.5L	PY T	Other	DCM(Data Communication Module)	√	√	√		
CX-5	2.5L	PY T	Other	DSM(Driver Seat Module)	√	√	√		
CX-5	2.5L	PY T	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CX-5	2.5L	PY T	Other	EPB(Electric Parking Brake)	√	√	√		
CX-5	2.5L	PY T	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-5	2.5L	PY T	Other	FSC(Forward Sensing Camera)	√	√	√		
CX-5	2.5L	PY T	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
CX-5	2.5L	PY T	Other	HUD(Head Up Display)	√	√	√	√	
CX-5	2.5L	PY T	Other	IC(Instrument Cluster)	√	√	√	√	
CX-5	2.5L	PY T	Other	PCM(Powertrain Control Module)	√	√	√	√	
CX-5	2.5L	PY T	Other	PLG(Power Liftgate)	√	√	√		
CX-5	2.5L	PY T	Other	PSM#1(Parking Sensor Module)	√	√	√		
CX-5	2.5L	PY T	Other	RCM(Restraint Control Module)	√	√	√		
CX-5	2.5L	PY T	Other	RCM(Restraint Control Module)	√	√	√		
CX-5	2.5L	PY T	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
CX-5	2.5L	PY T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
CX-5	2.5L	PY T	Other	SSU(Smart Start Unit)	√	√	√	√	
CX-5	2.5L	PY T	Other	TCM(Transmission Control Module)	√	√	√	√	
CX-5	2.5L	PY T	Other	VMC(View Monitor Camera)	√	√	√		
CX-5	2.2L	SH	Other	4X4(4X4 Control Module)	√	√	√	√	
CX-5	2.2L	SH	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-5	2.2L	SH	Other	ACU(Audio Control Unit)	√	√			
CX-5	2.2L	SH	Other	AFS(Adaptive Front Lighting System)	√	√	√		

CX-5	2.2L	SH	Other	AM(Amplifier Module)	√	√			
CX-5	2.2L	SH	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
CX-5	2.2L	SH	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
CX-5	2.2L	SH	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-5	2.2L	SH	Other	CMU(Connectivity Master Unit)	√	√			
CX-5	2.2L	SH	Other	DCM(Data Communication Module)	√	√	√		
CX-5	2.2L	SH	Other	DSM(Driver Seat Module)	√	√	√		
CX-5	2.2L	SH	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CX-5	2.2L	SH	Other	EPB(Electric Parking Brake)	√	√	√		
CX-5	2.2L	SH	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-5	2.2L	SH	Other	FSC(Forward Sensing Camera)	√	√	√		
CX-5	2.2L	SH	Other	F BCM(Body Control Module - Front)	√	√	√	√	
CX-5	2.2L	SH	Other	IC(Instrument Cluster)	√	√	√	√	
CX-5	2.2L	SH	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0038,SP0084,SP0085,SP0086
CX-5	2.2L	SH	Other	PSM#1(Parking Sensor Module)	√	√	√		
CX-5	2.2L	SH	Other	RCM(Restraint Control Module)	√	√	√		
CX-5	2.2L	SH	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
CX-5	2.2L	SH	Other	R BCM(Rear Body Control Module)	√	√	√	√	
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
CX-5	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
CX-5	2.2L	SH	Other	SCBS(Smart City Brake Support)	√	√	√		
CX-5	2.2L	SH	Other	SSU(Smart Start Unit)	√	√	√	√	
CX-5	2.2L	SH	Other	TCM(Transmission Control Module)	√	√	√	√	
CX-5	2.5L	PY	Other	4X4(4X4 Control Module)	√	√	√	√	
CX-5	2.5L	PY	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-5	2.5L	PY	Other	ACU(Audio Control Unit)	√	√			
CX-5	2.5L	PY	Other	AFS(Adaptive Front Lighting System)	√	√	√		
CX-5	2.5L	PY	Other	AM(Amplifier Module)	√	√			
CX-5	2.5L	PY	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
CX-5	2.5L	PY	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
CX-5	2.5L	PY	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-5	2.5L	PY	Other	CMU(Connectivity Master Unit)	√	√			
CX-5	2.5L	PY	Other	DCM(Data Communication Module)	√	√	√		
CX-5	2.5L	PY	Other	DSM(Driver Seat Module)	√	√	√		
CX-5	2.5L	PY	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CX-5	2.5L	PY	Other	EPB(Electric Parking Brake)	√	√	√		
CX-5	2.5L	PY	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-5	2.5L	PY	Other	FSC(Forward Sensing Camera)	√	√	√		
CX-5	2.5L	PY	Other	F BCM(Body Control Module - Front)	√	√	√	√	
CX-5	2.5L	PY	Other	IC(Instrument Cluster)	√	√	√	√	
CX-5	2.5L	PY	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0085,SP0086
CX-5	2.5L	PY	Other	PSM#1(Parking Sensor Module)	√	√	√		
CX-5	2.5L	PY	Other	RCM(Restraint Control Module)	√	√	√		
CX-5	2.5L	PY	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
CX-5	2.5L	PY	Other	R BCM(Rear Body Control Module)	√	√	√	√	
CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		

CX-5	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
CX-5	2.5L	PY	Other	SCBS(Smart City Brake Support)	√	√	√		
CX-5	2.5L	PY	Other	SSU(Smart Start Unit)	√	√	√	√	
CX-5	2.5L	PY	Other	TCM(Transmission Control Module)	√	√	√	√	
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	4X4(4X4 Control Module)	√	√			
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	ACU(Audio Control Unit)	√	√			SP0024,SP0046
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	AM(Amplifier Module)	√	√			
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	GEM(Generic Electronic Module)	√	√	√		
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	IC(Instrument Cluster)	√	√	√	√	
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	LCM(Lighting Control Module)	√	√			
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	MID#1(Multi-Information Display)	√	√	√		
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	RCM(Restraint Control Module)	√	√	√		
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	RVM(Rear Vehicle Monitoring)	√	√	√	√	
CX-7 (Europe/General Specifications)	2.3L	L3 T	2009 MY	TCM(Transmission Control Module)	√	√	√	√	SP0037
CX-7 (Europe/General Specifications)	2.3L	L3 T	2006 MY	4X4(4X4 Control Module)	√	√			
CX-7 (Europe/General Specifications)	2.3L	L3 T	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
CX-7 (Europe/General Specifications)	2.3L	L3 T	2006 MY	AM(Amplifier Module)	√	√			
CX-7 (Europe/General Specifications)	2.3L	L3 T	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
CX-7 (Europe/General Specifications)	2.3L	L3 T	2006 MY	GEM(Generic Electronic Module)	√	√	√		
CX-7 (Europe/General Specifications)	2.3L	L3 T	2006 MY	IC(Instrument Cluster)	√	√	√		
CX-7 (Europe/General Specifications)	2.3L	L3 T	2006 MY	LCM(Lighting Control Module)	√	√			
CX-7 (Europe/General Specifications)	2.3L	L3 T	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
CX-7 (Europe/General Specifications)	2.3L	L3 T	2006 MY	RCM(Restraint Control Module)	√	√	√		
CX-7 (Europe/General Specifications)	2.3L	L3 T	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	4X4(4X4 Control Module)	√	√			
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	ACU(Audio Control Unit)	√	√			SP0024,SP0046
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	AM(Amplifier Module)	√	√			
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√		SP0047
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	GEM(Generic Electronic Module)	√	√	√		
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	IC(Instrument Cluster)	√	√	√	√	
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	LCM(Lighting Control Module)	√	√			
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	MID#1(Multi-Information Display)	√	√	√		
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0020
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	RCM(Restraint Control Module)	√	√	√		
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	RVM(Rear Vehicle Monitoring)	√	√	√	√	
CX-7 (Europe/General Specifications)	2.2L	R2 T	2009 MY	SCR CU(Selective Catalytic Reduction)	√	√	√	√	SP0048,SP0049

CX-7 (Japan/General Specifications)	2.3L	L3 T	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
CX-7 (Japan/General Specifications)	2.3L	L3 T	2006 MY	AM(Amplifier Module)	√	√			
CX-7 (Japan/General Specifications)	2.3L	L3 T	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
CX-7 (Japan/General Specifications)	2.3L	L3 T	2006 MY	GEM(Generic Electronic Module)	√	√	√		
CX-7 (Japan/General Specifications)	2.3L	L3 T	2006 MY	IC(Instrument Cluster)	√	√	√		
CX-7 (Japan/General Specifications)	2.3L	L3 T	2006 MY	ICCM(Intelligent Cruise Control Module)	√	√	√		
CX-7 (Japan/General Specifications)	2.3L	L3 T	2006 MY	LCM(Lighting Control Module)	√	√			
CX-7 (Japan/General Specifications)	2.3L	L3 T	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0015
CX-7 (Japan/General Specifications)	2.3L	L3 T	2006 MY	RCM(Restraint Control Module)	√	√	√		
CX-7 (Japan/General Specifications)	2.3L	L3 T	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-7 (Japan/General Specifications)	2.3L	L3 T	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	4X4(4X4 Control Module)	√	√			
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	ACU(Audio Control Unit)	√	√			SP0024,SP0046
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	AM(Amplifier Module)	√	√			
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	GEM(Generic Electronic Module)	√	√	√		
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	IC(Instrument Cluster)	√	√	√	√	
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	ICCM(Intelligent Cruise Control Module)	√	√	√		
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	LCM(Lighting Control Module)	√	√			
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	MID#1(Multi-Information Display)	√	√	√		
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	RCM(Restraint Control Module)	√	√	√		
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	RVM(Rear Vehicle Monitoring)	√	√	√	√	
CX-7 (Japan/General Specifications)	2.3L	L3 T	2009 MY	TCM(Transmission Control Module)	√	√	√	√	SP0037
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	ACU(Audio Control Unit)	√	√			SP0024,SP0046
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	AM(Amplifier Module)	√	√			
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	GEM(Generic Electronic Module)	√	√	√		
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	IC(Instrument Cluster)	√	√	√	√	
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	ICCM(Intelligent Cruise Control Module)	√	√	√		
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	LCM(Lighting Control Module)	√	√			
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	MID#1(Multi-Information Display)	√	√	√		
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	RCM(Restraint Control Module)	√	√	√		
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	RVM(Rear Vehicle Monitoring)	√	√	√	√	
CX-7 (Japan/General Specifications)	2.5L	L5	2009 MY	TCM(Transmission Control Module)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
CX-7 (North America/General Specifications)	2.3L	L3 T	2009 MY	AM(Amplifier Module)	√	√			
CX-7 (North America/General Specifications)	2.3L	L3 T	2009 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
CX-7 (North America/General Specifications)	2.3L	L3 T	2009 MY	GEM(Generic Electronic Module)	√	√	√		

CX-7 (North America/General Specifications)	2.3L	L3 T	2009 MY	IC(Instrument Cluster)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0015
CX-7 (North America/General Specifications)	2.3L	L3 T	2009 MY	RCM(Restraint Control Module)	√	√	√		
CX-7 (North America/General Specifications)	2.3L	L3 T	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2009 MY	TCM(Transmission Control Module)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	ACU(Audio Control Unit)	√	√			SP0024,SP0046
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	AM(Amplifier Module)	√	√			
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	GEM(Generic Electronic Module)	√	√	√		
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	IC(Instrument Cluster)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	LCM(Lighting Control Module)	√	√			
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	MID#1(Multi-Information Display)	√	√	√		
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	RCM(Restraint Control Module)	√	√	√		
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2010 MY	TCM(Transmission Control Module)	√	√	√	√	SP0037
CX-7 (North America/General Specifications)	2.3L	L3 T	2007 MY	4X4(4X4 Control Module)	√	√			
CX-7 (North America/General Specifications)	2.3L	L3 T	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2007 MY	AM(Amplifier Module)	√	√			
CX-7 (North America/General Specifications)	2.3L	L3 T	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2007 MY	GEM(Generic Electronic Module)	√	√	√		
CX-7 (North America/General Specifications)	2.3L	L3 T	2007 MY	IC(Instrument Cluster)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2007 MY	RCM(Restraint Control Module)	√	√	√		
CX-7 (North America/General Specifications)	2.3L	L3 T	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	ACU(Audio Control Unit)	√	√			SP0024,SP0046
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	AM(Amplifier Module)	√	√			
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	GEM(Generic Electronic Module)	√	√	√		
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	IC(Instrument Cluster)	√	√	√	√	
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	LCM(Lighting Control Module)	√	√			
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	MID#1(Multi-Information Display)	√	√	√		
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	RCM(Restraint Control Module)	√	√	√		
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-7 (North America/General Specifications)	2.5L	L5	2010 MY	TCM(Transmission Control Module)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2008 MY	4X4(4X4 Control Module)	√	√			
CX-7 (North America/General Specifications)	2.3L	L3 T	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	

CX-7 (North America/General Specifications)	2.3L	L3 T	2008 MY	AM(Amplifier Module)	√	√			
CX-7 (North America/General Specifications)	2.3L	L3 T	2008 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2008 MY	GEM(Generic Electronic Module)	√	√	√		
CX-7 (North America/General Specifications)	2.3L	L3 T	2008 MY	IC(Instrument Cluster)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2008 MY	RCM(Restraint Control Module)	√	√	√		
CX-7 (North America/General Specifications)	2.3L	L3 T	2008 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-7 (North America/General Specifications)	2.3L	L3 T	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
CX-8	2.5L	PY T	Other	4X4(4X4 Control Module)	√	√	√	√	
CX-8	2.5L	PY T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-8	2.5L	PY T	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
CX-8	2.5L	PY T	Other	AM(Amplifier Module)	√	√	√	√	
CX-8	2.5L	PY T	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
CX-8	2.5L	PY T	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-8	2.5L	PY T	Other	CMU(Connectivity Master Unit)	√	√			
CX-8	2.5L	PY T	Other	DSM(Driver Seat Module)	√	√	√		
CX-8	2.5L	PY T	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CX-8	2.5L	PY T	Other	EPB(Electric Parking Brake)	√	√	√		
CX-8	2.5L	PY T	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-8	2.5L	PY T	Other	FSC(Forward Sensing Camera)	√	√	√		
CX-8	2.5L	PY T	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
CX-8	2.5L	PY T	Other	HUD(Head Up Display)	√	√	√	√	
CX-8	2.5L	PY T	Other	IC(Instrument Cluster)	√	√	√	√	
CX-8	2.5L	PY T	Other	PCM(Powertrain Control Module)	√	√	√	√	
CX-8	2.5L	PY T	Other	PLG(Power Liftgate)	√	√	√		
CX-8	2.5L	PY T	Other	PSM#1(Parking Sensor Module)	√	√	√		
CX-8	2.5L	PY T	Other	RCM(Restraint Control Module)	√	√	√		
CX-8	2.5L	PY T	Other	RSML/RWM(Rear Power Seat Control Module Left / Rear One-touch Walk-in Control Module)	√	√	√		
CX-8	2.5L	PY T	Other	RSWR(Rear Power Seat Control Module Right)	√	√	√		
CX-8	2.5L	PY T	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
CX-8	2.5L	PY T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
CX-8	2.5L	PY T	Other	SSU(Smart Start Unit)	√	√	√	√	
CX-8	2.5L	PY T	Other	TCM(Transmission Control Module)	√	√	√	√	
CX-8	2.5L	PY T	Other	VMC(View Monitor Camera)	√	√	√		
CX-8	2.2L	SH	Other	4X4(4X4 Control Module)	√	√	√	√	
CX-8	2.2L	SH	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-8	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
CX-8	2.2L	SH	Other	AM(Amplifier Module)	√	√	√	√	
CX-8	2.2L	SH	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
CX-8	2.2L	SH	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-8	2.2L	SH	Other	CMU(Connectivity Master Unit)	√	√			
CX-8	2.2L	SH	Other	DSM(Driver Seat Module)	√	√	√		
CX-8	2.2L	SH	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		

CX-8	2.2L	SH	Other	EPB(Electric Parking Brake)	√	√	√		
CX-8	2.2L	SH	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-8	2.2L	SH	Other	FSC(Forward Sensing Camera)	√	√	√		
CX-8	2.2L	SH	Other	F BCM(Body Control Module - Front)	√	√	√	√	
CX-8	2.2L	SH	Other	HUD(Head Up Display)	√	√	√	√	
CX-8	2.2L	SH	Other	IC(Instrument Cluster)	√	√	√	√	
CX-8	2.2L	SH	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
CX-8	2.2L	SH	Other	PLG(Power Liftgate)	√	√	√		
CX-8	2.2L	SH	Other	PSM#1(Parking Sensor Module)	√	√	√		
CX-8	2.2L	SH	Other	RCM(Restraint Control Module)	√	√	√		
CX-8	2.2L	SH	Other	R BCM(Rear Body Control Module)	√	√	√	√	
CX-8	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√			
CX-8	2.2L	SH	Other	SSU(Smart Start Unit)	√	√	√	√	
CX-8	2.2L	SH	Other	TCM(Transmission Control Module)	√	√	√	√	
CX-8	2.2L	SH	Other	VMC(View Monitor Camera)	√	√	√		
CX-8	2.5L	PY	Other	4X4(4X4 Control Module)	√	√	√	√	
CX-8	2.5L	PY	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-8	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
CX-8	2.5L	PY	Other	AM(Amplifier Module)	√	√	√	√	
CX-8	2.5L	PY	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
CX-8	2.5L	PY	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-8	2.5L	PY	Other	CMU(Connectivity Master Unit)	√	√			
CX-8	2.5L	PY	Other	DSM(Driver Seat Module)	√	√	√		
CX-8	2.5L	PY	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CX-8	2.5L	PY	Other	EPB(Electric Parking Brake)	√	√	√		
CX-8	2.5L	PY	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-8	2.5L	PY	Other	FSC(Forward Sensing Camera)	√	√	√		
CX-8	2.5L	PY	Other	F BCM(Body Control Module - Front)	√	√	√	√	
CX-8	2.5L	PY	Other	HUD(Head Up Display)	√	√	√	√	
CX-8	2.5L	PY	Other	IC(Instrument Cluster)	√	√	√	√	
CX-8	2.5L	PY	Other	PCM(Powertrain Control Module)	√	√	√	√	
CX-8	2.5L	PY	Other	PLG(Power Liftgate)	√	√	√		
CX-8	2.5L	PY	Other	PSM#1(Parking Sensor Module)	√	√	√		
CX-8	2.5L	PY	Other	RCM(Restraint Control Module)	√	√	√		
CX-8	2.5L	PY	Other	RSML/RWM(Rear Power Seat Control Module Left / Rear One-touch Walk-in Control Module)	√	√	√		
CX-8	2.5L	PY	Other	RSWR(Rear Power Seat Control Module Right)	√	√	√		
CX-8	2.5L	PY	Other	R BCM(Rear Body Control Module)	√	√	√	√	
CX-8	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
CX-8	2.5L	PY	Other	SSU(Smart Start Unit)	√	√	√	√	
CX-8	2.5L	PY	Other	TCM(Transmission Control Module)	√	√	√	√	
CX-8	2.5L	PY	Other	VMC(View Monitor Camera)	√	√	√		
CX-9	2.5L	PY T	Other	4X4(4X4 Control Module)	√	√	√	√	
CX-9	2.5L	PY T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	

CX-9	2.5L	PY T	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
CX-9	2.5L	PY T	Other	AM(Amplifier Module)	√	√			
CX-9	2.5L	PY T	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
CX-9	2.5L	PY T	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-9	2.5L	PY T	Other	CMU(Connectivity Master Unit)	√	√			
CX-9	2.5L	PY T	Other	DCDC(DC To DC Converter Control Module)	√	√	√	√	
CX-9	2.5L	PY T	Other	DCM(Data Communication Module)	√	√	√		
CX-9	2.5L	PY T	Other	DSM(Driver Seat Module)	√	√	√		
CX-9	2.5L	PY T	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
CX-9	2.5L	PY T	Other	EPB(Electric Parking Brake)	√	√	√		
CX-9	2.5L	PY T	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
CX-9	2.5L	PY T	Other	FSC(Forward Sensing Camera)	√	√	√		
CX-9	2.5L	PY T	Other	F BCM(Body Control Module - Front)	√	√	√	√	
CX-9	2.5L	PY T	Other	HUD(Head Up Display)	√	√	√	√	
CX-9	2.5L	PY T	Other	IC(Instrument Cluster)	√	√	√	√	
CX-9	2.5L	PY T	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0086
CX-9	2.5L	PY T	Other	PLG(Power Liftgate)	√	√	√		
CX-9	2.5L	PY T	Other	PSM#1(Parking Sensor Module)	√	√	√		
CX-9	2.5L	PY T	Other	RCM(Restraint Control Module)	√	√	√		
CX-9	2.5L	PY T	Other	R BCM(Rear Body Control Module)	√	√	√	√	
CX-9	2.5L	PY T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
CX-9	2.5L	PY T	Other	SCBS(Smart City Brake Support)	√	√	√		
CX-9	2.5L	PY T	Other	SSU(Smart Start Unit)	√	√	√	√	
CX-9	2.5L	PY T	Other	TCM(Transmission Control Module)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	4X4(4X4 Control Module)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0012
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	ACU(Audio Control Unit)	√	√			
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	AM(Amplifier Module)	√	√			
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	DSM(Driver Seat Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	GEM(Generic Electronic Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	IC(Instrument Cluster)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	LCM(Lighting Control Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	LTM(Liftgate/Trunk Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0015
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	RCM(Restraint Control Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2010 MY	TCM(Transmission Control Module)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	4X4(4X4 Control Module)	√	√			
CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0012
CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	AM(Amplifier Module)	√	√			
CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	GEM(Generic Electronic Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	IC(Instrument Cluster)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	LCM(Lighting Control Module)	√	√	√		

CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	LTM(Lifgate/Trunk Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0015
CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	RCM(Restraint Control Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2009 MY	TCM(Transmission Control Module)	√	√	√	√	
CX-9 (North America/General Specifications)	3.5L	CY	2007 MY	4X4(4X4 Control Module)	√	√			
CX-9 (North America/General Specifications)	3.5L	CY	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-9 (North America/General Specifications)	3.5L	CY	2007 MY	AM(Amplifier Module)	√	√			
CX-9 (North America/General Specifications)	3.5L	CY	2007 MY	GEM(Generic Electronic Module)	√	√	√		
CX-9 (North America/General Specifications)	3.5L	CY	2007 MY	IC(Instrument Cluster)	√	√	√	√	
CX-9 (North America/General Specifications)	3.5L	CY	2007 MY	LCM(Lighting Control Module)	√	√			
CX-9 (North America/General Specifications)	3.5L	CY	2007 MY	LTM(Lifgate/Trunk Module)	√	√	√		
CX-9 (North America/General Specifications)	3.5L	CY	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
CX-9 (North America/General Specifications)	3.5L	CY	2007 MY	RCM(Restraint Control Module)	√	√	√		
CX-9 (North America/General Specifications)	3.5L	CY	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-9 (North America/General Specifications)	3.5L	CY	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
CX-9 (North America/General Specifications)	3.5L	CY	Other	4X4(4X4 Control Module)	√	√			
CX-9 (North America/General Specifications)	3.5L	CY	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-9 (North America/General Specifications)	3.5L	CY	Other	AM(Amplifier Module)	√	√			
CX-9 (North America/General Specifications)	3.5L	CY	Other	GEM(Generic Electronic Module)	√	√	√		
CX-9 (North America/General Specifications)	3.5L	CY	Other	IC(Instrument Cluster)	√	√	√	√	
CX-9 (North America/General Specifications)	3.5L	CY	Other	LCM(Lighting Control Module)	√	√			
CX-9 (North America/General Specifications)	3.5L	CY	Other	LTM(Lifgate/Trunk Module)	√	√	√		
CX-9 (North America/General Specifications)	3.5L	CY	Other	PCM(Powertrain Control Module)	√	√	√		
CX-9 (North America/General Specifications)	3.5L	CY	Other	RCM(Restraint Control Module)	√	√	√		
CX-9 (North America/General Specifications)	3.5L	CY	Other	RKE(Remote Keyless Entry)	√	√	√	√	
CX-9 (North America/General Specifications)	3.5L	CY	Other	TCM(Transmission Control Module)	√	√			
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	4X4(4X4 Control Module)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0012
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	ACU(Audio Control Unit)	√	√			
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	AM(Amplifier Module)	√	√			
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	DSM(Driver Seat Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	FSC(Forward Sensing Camera)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	GEM(Generic Electronic Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	IC(Instrument Cluster)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	LCM(Lighting Control Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	LTM(Lifgate/Trunk Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	RCM(Restraint Control Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	TCM(Transmission Control Module)	√	√	√	√	SP0037
CX-9 (North America/General Specifications)	3.7L	CA	2011 MY	VSM(Vehicle Security Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	4X4(4X4 Control Module)	√	√			

CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	AM(Amplifier Module)	√	√			
CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	GEM(Generic Electronic Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	IC(Instrument Cluster)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	LCM(Lighting Control Module)	√	√			
CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	LTM(Liftgate/Trunk Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	RCM(Restraint Control Module)	√	√	√		
CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	RKE(Remote Keyless Entry)	√	√	√	√	
CX-9 (North America/General Specifications)	3.7L	CA	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (General)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (General)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (General)	1.3L	ZJ	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
DEMIO (JPN)/MAZDA2 (General)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (General)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (General)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)	√	√	√		
DEMIO (JPN)/MAZDA2 (General)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	√	√	√		
DEMIO (JPN)/MAZDA2 (General)	1.5L	ZY	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (General)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (General)	1.5L	ZY	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
DEMIO (JPN)/MAZDA2 (General)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (General)	1.5L	ZY	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (General)	1.5L	ZY	2007 MY	RCM(Restraint Control Module)	√	√	√		
DEMIO (JPN)/MAZDA2 (General)	1.5L	ZY	2007 MY	RKE(Remote Keyless Entry)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.5L	ZY	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.5L	ZY	Other	ALM#1(Auto Leveling Module)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.5L	ZY	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.5L	ZY	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.5L	ZY	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.5L	ZY	Other	IC(Instrument Cluster)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.5L	ZY	Other	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.5L	ZY	Other	RCM(Restraint Control Module)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.5L	ZY	Other	RKE(Remote Keyless Entry)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.5L	ZY	Other	VSM(Vehicle Security Module)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.6L	Y6	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.6L	Y6	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.6L	Y6	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.6L	Y6	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.6L	Y6	Other	IC(Instrument Cluster)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.6L	Y6	Other	PCM(Powertrain Control Module)	√	√	√	√	

DEMIO (JPN)/MAZDA2 (Other)	1.6L	Y6	Other	RCM(Restraint Control Module)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.6L	Y6	Other	RKE(Remote Keyless Entry)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.6L	Y6	Other	VSM(Vehicle Security Module)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.3L	ZJ	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	ZJ	Other	ALM#1(Auto Leveling Module)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.3L	ZJ	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	ZJ	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	ZJ	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.3L	ZJ	Other	IC(Instrument Cluster)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	ZJ	Other	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	ZJ	Other	RCM(Restraint Control Module)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.3L	ZJ	Other	RKE(Remote Keyless Entry)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	ZJ	Other	VSM(Vehicle Security Module)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	ALM#1(Auto Leveling Module)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	IC(Instrument Cluster)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	RCM(Restraint Control Module)	√	√	√		
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	RKE(Remote Keyless Entry)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	TCM(Transmission Control Module)	√	√	√	√	
DEMIO (JPN)/MAZDA2 (Other)	1.3L	P3	Other	VSM(Vehicle Security Module)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2004 MY	IC(Instrument Cluster)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2004 MY	RCM(Restraint Control Module)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2004 MY	RKE(Remote Keyless Entry)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2002 MY	4X4(4X4 Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2002 MY	IC(Instrument Cluster)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2002 MY	RCM(Restraint Control Module)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2002 MY	RKE(Remote Keyless Entry)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2004 MY	4X4(4X4 Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2004 MY	IC(Instrument Cluster)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2004 MY	RCM(Restraint Control Module)	√	√	√		

DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2004 MY	RKE(Remote Keyless Entry)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	Other	4X4(4X4 Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	Other	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	Other	IC(Instrument Cluster)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	Other	RCM(Restraint Control Module)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	Other	RKE(Remote Keyless Entry)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2005 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2005 MY	IC(Instrument Cluster)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2005 MY	LCM(Lighting Control Module)	√	√			
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2005 MY	RCM(Restraint Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	Other	4X4(4X4 Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	Other	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	Other	IC(Instrument Cluster)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	Other	RCM(Restraint Control Module)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	Other	RKE(Remote Keyless Entry)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2005 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2005 MY	IC(Instrument Cluster)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2005 MY	LCM(Lighting Control Module)	√	√			
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2005 MY	RCM(Restraint Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.5L	ZY	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2002 MY	4X4(4X4 Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2002 MY	IC(Instrument Cluster)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2002 MY	RCM(Restraint Control Module)	√	√	√		
DEMIO (JPN)/VERISA (JPN)/MAZDA2 (General)	1.3L	ZJ	2002 MY	RKE(Remote Keyless Entry)	√	√	√	√	
DEMIO/121 DEMIO/121	1.5L	B5	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO/121 DEMIO/121	1.5L	B5	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
DEMIO/121 DEMIO/121	1.5L	B5	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
DEMIO/121 DEMIO/121	1.3L	B3	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO/121 DEMIO/121	1.3L	B3	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO/121 DEMIO/121	1.3L	B3	2000 MY	EPS(Electronic Controlled Power Steering)	√	√	√	√	
DEMIO/121 DEMIO/121	1.3L	B3	2000 MY	EPS(Electronic Controlled Power Steering)	√	√	√	√	
DEMIO/121 DEMIO/121	1.3L	B3	2000 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
DEMIO/121 DEMIO/121	1.3L	B3	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO/121 DEMIO/121	1.3L	B3	2000 MY	PCM(Powertrain Control Module)	√	√	√		
DEMIO/121 DEMIO/121	1.3L	B3	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	

DEMIO/121 DEMIO/121	1.3L	B3	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
DEMIO/121 DEMIO/121	1.3L	B3	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
DEMIO/121 DEMIO/121	1.3L	B3	1996 MY	PCM(Powertrain Control Module)	√	√	√		
DEMIO/121 DEMIO/121	1.3L	B3	1998 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
DEMIO/121 DEMIO/121	1.3L	B3	1998 MY	PCM(Powertrain Control Module)	√	√	√		
DEMIO/121 DEMIO/121	1.5L	B5	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO/121 DEMIO/121	1.5L	B5	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO/121 DEMIO/121	1.5L	B5	2000 MY	EPS(Electronic Controlled Power Steering)	√	√	√	√	
DEMIO/121 DEMIO/121	1.5L	B5	2000 MY	EPS(Electronic Controlled Power Steering)	√	√	√	√	
DEMIO/121 DEMIO/121	1.5L	B5	2000 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
DEMIO/121 DEMIO/121	1.5L	B5	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO/FESTIVA MINI WAGON	1.3L	B3	Other	PCM(Powertrain Control Module)	√	√	√	√	
DEMIO/FESTIVA MINI WAGON	1.5L	B5	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO/FESTIVA MINI WAGON	1.5L	B5	1999 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
DEMIO/FESTIVA MINI WAGON	1.3L	B3	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO/FESTIVA MINI WAGON	1.3L	B3	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
DEMIO/FESTIVA MINI WAGON	1.3L	B3	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
DEMIO/FESTIVA MINI WAGON	1.3L	B3	1996 MY	PCM(Powertrain Control Module)	√	√	√		
DEMIO/FESTIVA MINI WAGON	1.3L	B3	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO/FESTIVA MINI WAGON	1.3L	B3	1999 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
DEMIO/FESTIVA MINI WAGON	1.3L	B3	1999 MY	PCM(Powertrain Control Module)	√	√	√		
DEMIO/FESTIVA MINI WAGON	1.5L	B5	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO/FESTIVA MINI WAGON	1.5L	B5	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
DEMIO/FESTIVA MINI WAGON	1.5L	B5	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
DEMIO/FESTIVA MINI WAGON	1.3L	B3	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
DEMIO/FESTIVA MINI WAGON	1.3L	B3	2000 MY	PCM(Powertrain Control Module)	√	√	√		
DEMIO/FESTIVA MINI WAGON	1.3L	B3	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2013 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0022
Escape/Kuga	2.5L	IVCT	2013 MY	ACM(Audio Control Module)	√	√	√	√	SP0024
Escape/Kuga	2.5L	IVCT	2013 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026
Escape/Kuga	2.5L	IVCT	2013 MY	BCM#1(Body Control Module)	√	√	√	√	SP0064,SP0077
Escape/Kuga	2.5L	IVCT	2013 MY	BCM#1(Body Control Module)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2013 MY	DDM(Driver Front Door Module)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2013 MY	DSM(Driver Front Seat Module)	√	√	√	√	SP0076
Escape/Kuga	2.5L	IVCT	2013 MY	DSP(Audio) Digital Signal Processing Module)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2013 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2013 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2013 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	

Escape/Kuga	2.5L	IVCT	2013 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2013 MY	FCIM(Controls Interface Module - Front)	√	√	√		
Escape/Kuga	2.5L	IVCT	2013 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Kuga	2.5L	IVCT	2013 MY	HCM(Headlamp Control Module)	√	√	√		
Escape/Kuga	2.5L	IVCT	2013 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2013 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2013 MY	IPM-B(Image Processing Module B)	√	√			
Escape/Kuga	2.5L	IVCT	2013 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Kuga	2.5L	IVCT	2013 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Kuga	2.5L	IVCT	2013 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0004,SP0005,SP0006
Escape/Kuga	2.5L	IVCT	2013 MY	PDM(Passenger Front Door Module)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2013 MY	PSCM(Power Steering Control Module)	√	√	√		SP0075,SP0050
Escape/Kuga	2.5L	IVCT	2013 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Kuga	2.5L	IVCT	2013 MY	RFA(Actuator Of Remote Function)	√	√	√		
Escape/Kuga	2.5L	IVCT	2013 MY	RGTM(Rear Gate/Trunk Module)	√	√	√		SP0079
Escape/Kuga	2.5L	IVCT	2013 MY	SASM(Steering Angle Sensor Module)	√	√	√		
Escape/Kuga	2.5L	IVCT	2013 MY	SOD-L(Side Obstacle Detection Control Module - Left)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2013 MY	SOD-R(Side Obstacle Detection Control Module - Right)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2013 MY	TRM(Trailer Module)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2014 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0022
Escape/Kuga	2.5L	IVCT	2014 MY	ACM(Audio Control Module)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2014 MY	APIM(Accessory Protocol Interface Module)	√	√	√		
Escape/Kuga	2.5L	IVCT	2014 MY	BCM#1(Body Control Module)	√	√	√	√	SP0064,SP0077
Escape/Kuga	2.5L	IVCT	2014 MY	DDM(Driver Front Door Module)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2014 MY	DSM(Driver Front Seat Module)	√	√	√	√	SP0076
Escape/Kuga	2.5L	IVCT	2014 MY	DSP((Audio) Digital Signal Processing Module)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2014 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2014 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2014 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2014 MY	FCIM(Controls Interface Module - Front)	√	√	√		
Escape/Kuga	2.5L	IVCT	2014 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Kuga	2.5L	IVCT	2014 MY	HCM(Headlamp Control Module)	√	√	√		
Escape/Kuga	2.5L	IVCT	2014 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2014 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2014 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Kuga	2.5L	IVCT	2014 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Kuga	2.5L	IVCT	2014 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Kuga	2.5L	IVCT	2014 MY	PDM(Passenger Front Door Module)	√	√	√	√	
Escape/Kuga	2.5L	IVCT	2014 MY	PSCM(Power Steering Control Module)	√	√	√		SP0075,SP0050
Escape/Kuga	2.5L	IVCT	2014 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Kuga	2.5L	IVCT	2014 MY	RFA(Actuator Of Remote Function)	√	√	√		

Escape/Kuga	2.5L	IVCT	2014 MY	RGTM(Rear Gate/Trunk Module)	√	√	√		SP0079
Escape/Kuga	2.5L	IVCT	2014 MY	SASM(Steering Angle Sensor Module)	√	√	√		
Escape/Kuga	2.5L	IVCT	2014 MY	SOD-L(Side Obstacle Detection Control Module - Left)	√	√	√		
Escape/Kuga	2.5L	IVCT	2014 MY	SOD-R(Side Obstacle Detection Control Module - Right)	√	√	√		
Escape/Kuga	2.5L	IVCT	2014 MY	TRM(Trailer Module)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0022
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	ACM(Audio Control Module)	√	√	√	√	SP0024
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	BCM#1(Body Control Module)	√	√	√	√	SP0064,SP0077
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	BCM#1(Body Control Module)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	DDM(Driver Front Door Module)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	DSM(Driver Front Seat Module)	√	√	√	√	SP0076
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	DSP((Audio) Digital Signal Processing Module)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	FCIM(Controls Interface Module - Front)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	HCM(Headlamp Control Module)	√	√	√		

Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	IPM-B(Image Processing Module B)	√	√			
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0004,SP0005,SP0006,SP0078
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	PDM(Passenger Front Door Module)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	PSCM(Power Steering Control Module)	√	√	√		SP0075,SP0050
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	RFA(Actuator Of Remote Function)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	RGTM(Rear Gate/Trunk Module)	√	√	√		SP0079
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	SASM(Steering Angle Sensor Module)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	SOD-L(Side Obstacle Detection Control Module - Left)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	SOD-R(Side Obstacle Detection Control Module - Right)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	TRM(Trailer Module)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0022
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	ACM(Audio Control Module)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	APIM(Accessory Protocol Interface Module)	√	√	√		

Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	BCM#1(Body Control Module)	√	√	√	√	SP0064,SP0077
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	DDM(Driver Front Door Module)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	DSM(Driver Front Seat Module)	√	√	√	√	SP0076
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	DSP((Audio) Digital Signal Processing Module)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	FCIM(Controls Interface Module - Front)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	HCM(Headlamp Control Module)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006,SP0078
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	PDM(Passenger Front Door Module)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	PSCM(Power Steering Control Module)	√	√	√		SP0075,SP0050
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	RCM(Restraint Control Module)	√	√	√		

Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	RFA(Actuator Of Remote Function)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	RGTM(Rear Gate/Trunk Module)	√	√	√		SP0079
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	SASM(Steering Angle Sensor Module)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	SOD-L(Side Obstacle Detection Control Module - Left)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	SOD-R(Side Obstacle Detection Control Module - Right)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	TRM(Trailer Module)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0022
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	ACM(Audio Control Module)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	APIM(Accessory Protocol Interface Module)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	BCM#1(Body Control Module)	√	√	√	√	SP0064,SP0077
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	DDM(Driver Front Door Module)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	DSM(Driver Front Seat Module)	√	√	√	√	SP0076
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	DSP(Audio) Digital Signal Processing Module)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	FCIM(Controls Interface Module - Front)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	GPSM(Global Positioning System Module)	√	√	√		

Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	HCM(Headlamp Control Module)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006,SP0078
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	PDM(Passenger Front Door Module)	√	√	√	√	
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	PSCM(Power Steering Control Module)	√	√	√		SP0075,SP0050
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	RFA(Actuator Of Remote Function)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	RGTM(Rear Gate/Trunk Module)	√	√	√		SP0079
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	SASM(Steering Angle Sensor Module)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	SOD-L(Side Obstacle Detection Control Module - Left)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	SOD-R(Side Obstacle Detection Control Module - Right)	√	√	√		
Escape/Kuga	2.0L	Ecoboost - Gas Turbocharged Direct Injection	2014 MY	TRM(Trailer Module)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0022
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	ACM(Audio Control Module)	√	√	√	√	SP0024
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026

Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	BCM#1(Body Control Module)	√	√	√	√	SP0064,SP0077
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	BCM#1(Body Control Module)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	DDM(Driver Front Door Module)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	DSM(Driver Front Seat Module)	√	√	√	√	SP0076
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	DSP((Audio) Digital Signal Processing Module)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	FCIM(Controls Interface Module - Front)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	HCM(Headlamp Control Module)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	IPM-B(Image Processing Module B)	√	√			
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0004,SP0005,SP0006,SP0078

Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	PDM(Passenger Front Door Module)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	PSCM(Power Steering Control Module)	√	√	√		SP0075,SP0050
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	RFA(Actuator Of Remote Function)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	RGTM(Rear Gate/Trunk Module)	√	√	√		SP0079
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	SASM(Steering Angle Sensor Module)	√	√	√		
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	SOD-L(Side Obstacle Detection Control Module - Left)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	SOD-R(Side Obstacle Detection Control Module - Right)	√	√	√	√	
Escape/Kuga	1.6L	Ecoboost - Gas Turbocharged Direct Injection	2013 MY	TRM(Trailer Module)	√	√	√	√	
Escape/Tribute (2006/4 -)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Escape/Tribute (2006/4 -)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute (2006/4 -)	2.3L	L3	2006 MY	IC(Instrument Cluster)	√	√	√		
Escape/Tribute (2006/4 -)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute (2006/4 -)	2.3L	L3	2006 MY	RCM(Restraint Control Module)	√	√	√	√	
Escape/Tribute (2006/3)	2.3L	L3	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Escape/Tribute (2006/3)	2.3L	L3	2003 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute (2006/3)	2.3L	L3	2003 MY	IC(Instrument Cluster)	√	√	√		
Escape/Tribute (2006/3)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute (2006/3)	2.3L	L3	2003 MY	RCM(Restraint Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	ACCM#2(Air Conditioning (A/C) Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026

Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	BCM(Battery Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	FDIM(Display Interface Module - Front)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014,SP0029
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0004,SP0005,SP0006
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	PSCM(Power Steering Control Module)	√	√			SP0050
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2012 MY	TCM(Transmission Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	FDIM(Display Interface Module - Front)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	PSCM(Power Steering Control Module)	√	√			SP0050
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2012 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	4X4(4X4 Control Module)	√	√	√	√	

Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022,SP0028
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	ACM(Audio Control Module)	√	√	√	√	SP0023,SP0024,SP0025
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	ACM(Audio Control Module)	√	√	√	√	SP0023,SP0024,SP0025
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	FDIM(Display Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014,SP0029
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	PSCM(Power Steering Control Module)	√	√			SP0028
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	PSCM(Power Steering Control Module)	√	√			SP0028
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	RCM(Restraint Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.3L	DURATEC-HE/I4	2008 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	SP0026
Escape/Tribute/Mariner	3.0L	4V	2009 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022,SP0028
Escape/Tribute/Mariner	3.0L	4V	2009 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	3.0L	4V	2009 MY	ACM(Audio Control Module)	√	√	√	√	SP0024,SP0025
Escape/Tribute/Mariner	3.0L	4V	2009 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0036
Escape/Tribute/Mariner	3.0L	4V	2009 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0036
Escape/Tribute/Mariner	3.0L	4V	2009 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2009 MY	FDIM(Display Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2009 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	3.0L	4V	2009 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2009 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2009 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2009 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Tribute/Mariner	3.0L	4V	2009 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Mariner	3.0L	4V	2009 MY	PSCM(Power Steering Control Module)	√	√			SP0028
Escape/Tribute/Mariner	3.0L	4V	2009 MY	PSCM(Power Steering Control Module)	√	√			SP0028
Escape/Tribute/Mariner	3.0L	4V	2009 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Mariner	3.0L	4V	2009 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	SP0026
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	ACCM#2(Air Conditioning (A/C) Control Module)	√	√	√		

Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	BCM(Battery Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	FDIM(Display Interface Module - Front)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014,SP0029
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0004,SP0005,SP0006
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	PSCM(Power Steering Control Module)	√	√			SP0050
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2011 MY	TCM(Transmission Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026,SP0036
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	FDIM(Display Interface Module - Front)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	IC(Instrument Cluster)	√	√	√	√	

Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	PSCM(Power Steering Control Module)	√	√			SP0050
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2010 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Mariner	3.0L	4V	2011 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022
Escape/Tribute/Mariner	3.0L	4V	2011 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	3.0L	4V	2011 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	3.0L	4V	2011 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	3.0L	4V	2011 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026
Escape/Tribute/Mariner	3.0L	4V	2011 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2011 MY	FDIM(Display Interface Module - Front)	√	√	√		
Escape/Tribute/Mariner	3.0L	4V	2011 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	3.0L	4V	2011 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Tribute/Mariner	3.0L	4V	2011 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2011 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2011 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2011 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014,SP0029
Escape/Tribute/Mariner	3.0L	4V	2011 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Tribute/Mariner	3.0L	4V	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2011 MY	PSCM(Power Steering Control Module)	√	√			SP0050
Escape/Tribute/Mariner	3.0L	4V	2011 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0022,SP0028
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	ACM(Audio Control Module)	√	√	√	√	SP0023,SP0024,SP0025
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	ACM(Audio Control Module)	√	√	√	√	SP0023,SP0024,SP0025
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	BCM(Battery Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	FDIM(Display Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014

Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	PSCM(Power Steering Control Module)	√	√			SP0028
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	PSCM(Power Steering Control Module)	√	√			SP0028
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	RCM(Restraint Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	SP0026
Escape/Tribute/Mariner	2.3L	Hybrid Electric Vehicle	2008 MY	TCM(Transmission Control Module)	√	√	√		
Escape/Tribute/Mariner	3.0L	4V	2012 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2012 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022
Escape/Tribute/Mariner	3.0L	4V	2012 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	3.0L	4V	2012 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	3.0L	4V	2012 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	3.0L	4V	2012 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026
Escape/Tribute/Mariner	3.0L	4V	2012 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2012 MY	FDIM(Display Interface Module - Front)	√	√	√		
Escape/Tribute/Mariner	3.0L	4V	2012 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	3.0L	4V	2012 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Tribute/Mariner	3.0L	4V	2012 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2012 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2012 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2012 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014,SP0029
Escape/Tribute/Mariner	3.0L	4V	2012 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Tribute/Mariner	3.0L	4V	2012 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2012 MY	PSCM(Power Steering Control Module)	√	√			SP0050
Escape/Tribute/Mariner	3.0L	4V	2012 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	FDIM(Display Interface Module - Front)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	

Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	PSCM(Power Steering Control Module)	√	√			SP0050
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2011 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	ACCM#2(Air Conditioning (A/C) Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026,SP0036
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	BCM(Battery Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	FDIM(Display Interface Module - Front)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	PSCM(Power Steering Control Module)	√	√			SP0050
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2010 MY	TCM(Transmission Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0028

Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	ACM(Audio Control Module)	√	√	√	√	SP0024,SP0025
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026,SP0036
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026,SP0036
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	BCM(Battery Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	FDIM(Display Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	PSCM(Power Steering Control Module)	√	√			SP0028
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	PSCM(Power Steering Control Module)	√	√			SP0028
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	Hybrid Electric Vehicle	2009 MY	TCM(Transmission Control Module)	√	√	√		
Escape/Tribute/Mariner	Other	Other	2012 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	Other	Other	2012 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Escape/Tribute/Mariner	Other	Other	2012 MY	ACM(Audio Control Module)	√	√	√		
Escape/Tribute/Mariner	Other	Other	2012 MY	ACM(Audio Control Module)	√	√	√		
Escape/Tribute/Mariner	Other	Other	2012 MY	APIM(Accessory Protocol Interface Module)	√	√	√		
Escape/Tribute/Mariner	Other	Other	2012 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	Other	Other	2012 MY	FDIM(Display Interface Module - Front)	√	√	√		
Escape/Tribute/Mariner	Other	Other	2012 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	Other	Other	2012 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Tribute/Mariner	Other	Other	2012 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	

Escape/Tribute/Mariner	Other	Other	2012 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	Other	Other	2012 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	Other	Other	2012 MY	OCSM(Occupant Classification System Module)	√	√	√		
Escape/Tribute/Mariner	Other	Other	2012 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Tribute/Mariner	Other	Other	2012 MY	PSCM(Power Steering Control Module)	√	√			
Escape/Tribute/Mariner	Other	Other	2012 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022,SP0028
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	ACM(Audio Control Module)	√	√	√	√	SP0024,SP0025
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026,SP0036
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026,SP0036
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	FDIM(Display Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014,SP0029
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	PSCM(Power Steering Control Module)	√	√			SP0028
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	PSCM(Power Steering Control Module)	√	√			SP0028
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Mariner	2.5L	DURATEC-HE/I4	2009 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2008 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022,SP0028
Escape/Tribute/Mariner	3.0L	4V	2008 MY	ACM(Audio Control Module)	√	√	√	√	SP0023,SP0024,SP0025
Escape/Tribute/Mariner	3.0L	4V	2008 MY	ACM(Audio Control Module)	√	√	√	√	SP0023,SP0024,SP0025
Escape/Tribute/Mariner	3.0L	4V	2008 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2008 MY	FDIM(Display Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2008 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	3.0L	4V	2008 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2008 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2008 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2008 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014,SP0029
Escape/Tribute/Mariner	3.0L	4V	2008 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Mariner	3.0L	4V	2008 MY	PSCM(Power Steering Control Module)	√	√			SP0028
Escape/Tribute/Mariner	3.0L	4V	2008 MY	PSCM(Power Steering Control Module)	√	√			SP0028

Escape/Tribute/Mariner	3.0L	4V	2008 MY	RCM(Restraint Control Module)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2008 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	SP0026
Escape/Tribute/Mariner	3.0L	4V	2010 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022
Escape/Tribute/Mariner	3.0L	4V	2010 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	3.0L	4V	2010 MY	ACM(Audio Control Module)	√	√	√		SP0024,SP0025
Escape/Tribute/Mariner	3.0L	4V	2010 MY	APIM(Accessory Protocol Interface Module)	√	√	√		SP0026,SP0036
Escape/Tribute/Mariner	3.0L	4V	2010 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2010 MY	FDIM(Display Interface Module - Front)	√	√	√		
Escape/Tribute/Mariner	3.0L	4V	2010 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Escape/Tribute/Mariner	3.0L	4V	2010 MY	GPSM(Global Positioning System Module)	√	√	√		
Escape/Tribute/Mariner	3.0L	4V	2010 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2010 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2010 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2010 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Escape/Tribute/Mariner	3.0L	4V	2010 MY	PAM(Parking Aid Module)	√	√	√		
Escape/Tribute/Mariner	3.0L	4V	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
Escape/Tribute/Mariner	3.0L	4V	2010 MY	PSCM(Power Steering Control Module)	√	√			SP0050
Escape/Tribute/Mariner	3.0L	4V	2010 MY	RCM(Restraint Control Module)	√	√	√		
Escape/Tribute/Maverick	2.0L	Zetec	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Escape/Tribute/Maverick	2.0L	Zetec	2002 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	2.0L	Zetec	2002 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Maverick	2.0L	Zetec	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Maverick	2.0L	Zetec	2002 MY	RCM(Restraint Control Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Escape/Tribute/Maverick	3.0L	4V	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2001 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Maverick	3.0L	4V	2001 MY	RCM(Restraint Control Module)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2007 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2007 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2007 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2007 MY	RCM(Restraint Control Module)	√	√	√	√	SP0014
Escape/Tribute/Maverick	3.0L	4V	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Escape/Tribute/Maverick	3.0L	4V	2003 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2003 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2003 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006

Escape/Tribute/Maverick	3.0L	4V	2003 MY	RCM(Restraint Control Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2007 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Escape/Tribute/Maverick	3.0L	4V	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2007 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2007 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Maverick	3.0L	4V	2007 MY	RCM(Restraint Control Module)	√	√	√	√	SP0014
Escape/Tribute/Maverick	3.0L	4V	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Escape/Tribute/Maverick	3.0L	4V	2002 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2002 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Maverick	3.0L	4V	2002 MY	RCM(Restraint Control Module)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2006 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2006 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2006 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2006 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2006 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2006 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Maverick	2.3L	DURATEC-HE/I4	2006 MY	RCM(Restraint Control Module)	√	√	√	√	SP0014
Escape/Tribute/Maverick	2.0L	Zetec	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Escape/Tribute/Maverick	2.0L	Zetec	2004 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	2.0L	Zetec	2004 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Maverick	2.0L	Zetec	2004 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Maverick	2.0L	Zetec	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Maverick	2.0L	Zetec	2004 MY	RCM(Restraint Control Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Escape/Tribute/Maverick	3.0L	4V	2004 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2004 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2004 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Maverick	3.0L	4V	2004 MY	RCM(Restraint Control Module)	√	√	√	√	
Escape/Tribute/Maverick	2.0L	Zetec	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Escape/Tribute/Maverick	2.0L	Zetec	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	2.0L	Zetec	2001 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Maverick	2.0L	Zetec	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Maverick	2.0L	Zetec	2001 MY	RCM(Restraint Control Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2006 MY	4X4(4X4 Control Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Escape/Tribute/Maverick	3.0L	4V	2006 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2006 MY	GEM(Generic Electronic Module)	√	√	√	√	

Escape/Tribute/Maverick	3.0L	4V	2006 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2006 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2006 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Maverick	3.0L	4V	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Maverick	3.0L	4V	2006 MY	RCM(Restraint Control Module)	√	√	√	√	SP0014
Escape/Tribute/Maverick	2.0L	Zetec	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Escape/Tribute/Maverick	2.0L	Zetec	2003 MY	GEM(Generic Electronic Module)	√	√	√	√	
Escape/Tribute/Maverick	2.0L	Zetec	2003 MY	IC(Instrument Cluster)	√	√	√	√	
Escape/Tribute/Maverick	2.0L	Zetec	2003 MY	PAM(Parking Aid Module)	√	√	√	√	
Escape/Tribute/Maverick	2.0L	Zetec	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Escape/Tribute/Maverick	2.0L	Zetec	2003 MY	RCM(Restraint Control Module)	√	√	√	√	
Etude	2.0L	Other	Other	PCM(Powertrain Control Module (PCM))	√	√			
Etude	1.8L	Other	Other	PCM(Powertrain Control Module (PCM))	√	√			
EUNOS Cosmo (JCESE/JC3SE)	654x3cc	20B	1990 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
EUNOS Cosmo (JCESE/JC3SE)	654x3cc	20B	1990 MY	CCM(Cruise Control)	√	√			
EUNOS Cosmo (JCESE/JC3SE)	654x3cc	20B	1990 MY	PCM(Powertrain Control Module)	√	√	√	√	
EUNOS Cosmo (JCESE/JC3SE)	654x3cc	20B	1990 MY	PCM(Powertrain Control Module (PCM))	√	√			
EUNOS Cosmo (JCESE/JC3SE)	654x3cc	20B	1990 MY	TCM(Transmission Control Module)	√	√			
EUNOS Cosmo (JCESE/JC3SE)	654x2cc	13B	1990 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
EUNOS Cosmo (JCESE/JC3SE)	654x2cc	13B	1990 MY	CCM(Cruise Control)	√	√			
EUNOS Cosmo (JCESE/JC3SE)	654x2cc	13B	1990 MY	PCM(Powertrain Control Module)	√	√	√	√	
EUNOS Cosmo (JCESE/JC3SE)	654x2cc	13B	1990 MY	PCM(Powertrain Control Module (PCM))	√	√			
EUNOS Cosmo (JCESE/JC3SE)	654x2cc	13B	1990 MY	TCM(Transmission Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	ABS(Antilock Braking System)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	ABS(Antilock Braking System)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	ADAS(Advanced Driver Assistance System)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	EPS(Electronic Controlled Power Steering)	√	√	√		
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	GEM(Generic Electronic Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	IPDM(Intelligent Power Distribution Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	LDW(Lane Departure Warning)	√	√	√		
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	PCM(Powertrain Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	RCM(Restraint Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.6L	HR16	2017 (MY)	RCM(Restraint Control Module)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	EPS(Electronic Controlled Power Steering)	√	√			
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	IPDM(Intelligent Power Distribution Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	RCM(Restraint Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	TCM(Transmission Control Module)	√	√	√		

FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	EPS(Electronic Controlled Power Steering)	√	√			
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	IPDM(Intelligent Power Distribution Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	RCM(Restraint Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	TCM(Transmission Control Module)	√	√	√		
FAMILIA VAN (BV*Y12)	1.6L	HR16	2013 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
FAMILIA VAN (BV*Y12)	1.6L	HR16	2013 MY	ABS(Antilock Braking System)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2013 MY	ABS(Antilock Braking System)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2013 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
FAMILIA VAN (BV*Y12)	1.6L	HR16	2013 MY	GEM(Generic Electronic Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2013 MY	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.6L	HR16	2013 MY	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.6L	HR16	2013 MY	IPDM(Intelligent Power Distribution Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2013 MY	PCM(Powertrain Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.6L	HR16	2013 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2013 MY	RCM(Restraint Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.5L	HR15	2013 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2013 MY	ABS(Antilock Braking System)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2013 MY	ABS(Antilock Braking System)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2013 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2013 MY	GEM(Generic Electronic Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2013 MY	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2013 MY	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2013 MY	IPDM(Intelligent Power Distribution Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2013 MY	PCM(Powertrain Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.5L	HR15	2013 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2013 MY	RCM(Restraint Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.5L	HR15	2013 MY	TCM(Transmission Control Module)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	ABS(Antilock Braking System)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	ABS(Antilock Braking System)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	ADAS(Advanced Driver Assistance System)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	EPS(Electronic Controlled Power Steering)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	GEM(Generic Electronic Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	IPDM(Intelligent Power Distribution Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	LDW(Lane Departure Warning)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	PCM(Powertrain Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	RCM(Restraint Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	RCM(Restraint Control Module)	√	√	√		
FAMILIA VAN (BV*Y12)	1.5L	HR15	2017 (MY)	TCM(Transmission Control Module)	√	√	√		

FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	EPS(Electronic Controlled Power Steering)	√	√			
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	IPDM(Intelligent Power Distribution Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	RCM(Restraint Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	TCM(Transmission Control Module)	√	√	√		
FAMILIA VAN (BV*Y12)	1.8L	MR18	2013 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
FAMILIA VAN (BV*Y12)	1.8L	MR18	2013 MY	ABS(Antilock Braking System)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.8L	MR18	2013 MY	ABS(Antilock Braking System)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.8L	MR18	2013 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
FAMILIA VAN (BV*Y12)	1.8L	MR18	2013 MY	GEM(Generic Electronic Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.8L	MR18	2013 MY	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.8L	MR18	2013 MY	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.8L	MR18	2013 MY	IPDM(Intelligent Power Distribution Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.8L	MR18	2013 MY	PCM(Powertrain Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.8L	MR18	2013 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.8L	MR18	2013 MY	RCM(Restraint Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	EPS(Electronic Controlled Power Steering)	√	√			
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	IC(Instrument Cluster)	√	√	√		
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	IPDM(Intelligent Power Distribution Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	RCM(Restraint Control Module)	√	√			
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	TCM(Transmission Control Module)	√	√	√		
FAMILIA WAGON/VAN (B*Y11-500000-)	1.3L	QG13	2002 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA WAGON/VAN (B*Y11-500000-)	1.3L	QG13	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA WAGON/VAN (B*Y11-500000-)	1.3L	QG13	2002 MY	TCM(Transmission Control Module)	√	√	√		
FAMILIA WAGON/VAN (B*Y11-500000-)	1.5L	QG15	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA WAGON/VAN (B*Y11-500000-)	1.8L	QG18	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA WAGON/VAN (B*Y11-500000-)	1.8L	QG18	2002 MY	TCM(Transmission Control Module)	√	√	√		
FAMILIA WAGON/VAN (B*Y11-500000-)	1.5L	QG15	2002 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA WAGON/VAN (B*Y11-500000-)	1.5L	QG15	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA WAGON/VAN (B*Y11-500000-)	1.5L	QG15	2002 MY	TCM(Transmission Control Module)	√	√	√		
FAMILIA WAGON/VAN (B*Y11-500000-)	1.3L	QG13	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA WAGON/VAN (B*Y11-500000-)	1.8L	QG18	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA/LASER	1.5L	ZL	1998 MY	A/C(Air Conditioning)	√	√			
FAMILIA/LASER	1.5L	ZL	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA/LASER	1.5L	ZL	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FAMILIA/LASER	1.5L	ZL	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA/LASER	2.0L	FS	2000 MY	A/C(Air Conditioning)	√	√			

FAMILIA/LASER	2.0L	FS	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA/LASER	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA/LASER	1.5L	Z5	1996 MY	A/C(Air Conditioning)	√	√			
FAMILIA/LASER	1.5L	Z5	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FAMILIA/LASER	1.5L	Z5	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
FAMILIA/LASER	1.3L	B3	1998 MY	A/C(Air Conditioning)	√	√			
FAMILIA/LASER	1.3L	B3	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA/LASER	1.3L	B3	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FAMILIA/LASER	1.3L	B3	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA/LASER	2.0L	FS	2002 MY	A/C(Air Conditioning)	√	√			
FAMILIA/LASER	2.0L	FS	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA/LASER	2.0L	FS	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA/LASER	1.5L	ZL	2002 MY	A/C(Air Conditioning)	√	√			
FAMILIA/LASER	1.5L	ZL	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA/LASER	1.5L	ZL	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA/LASER	1.3L	B3	1996 MY	A/C(Air Conditioning)	√	√			
FAMILIA/LASER	1.3L	B3	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FAMILIA/LASER	1.3L	B3	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
FAMILIA/LASER	1.5L	ZL	2000 MY	A/C(Air Conditioning)	√	√			
FAMILIA/LASER	1.5L	ZL	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA/LASER	1.5L	ZL	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA/LASER	1.5L	ZL	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA/LASER	1.5L	ZL	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA/LASER	1.8L	FP	1998 MY	A/C(Air Conditioning)	√	√			
FAMILIA/LASER	1.8L	FP	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA/LASER	1.8L	FP	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FAMILIA/LASER	1.8L	FP	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA/LASER	2.0L	FS	1999 MY	A/C(Air Conditioning)	√	√			
FAMILIA/LASER	2.0L	FS	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
FAMILIA/LASER	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
FAMILIA/LASER	1.8L	BP	1996 MY	A/C(Air Conditioning)	√	√			
FAMILIA/LASER	1.8L	BP	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FAMILIA/LASER	1.8L	BP	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
FAMILIA/LASER	1.6L	B6	1996 MY	A/C(Air Conditioning)	√	√			
FAMILIA/LASER	1.6L	B6	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FAMILIA/LASER	1.6L	B6	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
FAMILIA/LASER	2.0L	RF	1998 MY	A/C(Air Conditioning)	√	√			
FAMILIA/LASER	2.0L	RF	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	

FAMILIA/LASER	2.0L	RF	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FAMILIA/LASER	2.0L	RF	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1996.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1996.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1996.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1996.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1996.5 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.0L	HCS	1996.75 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	HCS	1996.75 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	HCS	1996.75 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.0L	HCS	1996.75 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.0L	HCS	1996.75 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1994 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1994 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1994 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1994 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1994 MY	PCM(Powertrain Control Module (PCM))	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1999.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1999.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1999.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1999.5 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1999.5 MY	GEM(Generic Electronic Module)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1999.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1999.5 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.8L	Endura DI	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Endura DI	2000 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Endura DI	2000 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.8L	Endura DI	2000 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Endura DI	2000 MY	FIP(Fuel Injection Pump)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Endura DI	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.8L	Endura DI	2000 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.8L	Endura DI	2000 MY	PATS(Passive Anti Theft System (PATS))	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.8L	Endura DI	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	PCM(Powertrain Control Module (PCM))	√	√	√		

Fiesta/Mazda 121/Bantam	1.0L	HCS	1997.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	HCS	1997.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	HCS	1997.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.0L	HCS	1997.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.0L	HCS	1997.5 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999.75 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999.75 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999.75 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999.75 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999.75 MY	GEM(Generic Electronic Module)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999.75 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.6L	Zetec Rocam	1999.75 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1997.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1997.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1997.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1997.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1997.5 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1996 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1996 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1996 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1996 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	1.4 PT-E SFI	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999.5 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999.5 MY	GEM(Generic Electronic Module)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999.5 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.6L	Zetec-SE	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.6L	Zetec-SE	2000 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.6L	Zetec-SE	2000 MY	CSM(Security Module)	√	√			

Fiesta/Mazda 121/Bantam	1.6L	Zetec-SE	2000 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.6L	Zetec-SE	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.6L	Zetec-SE	2000 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.6L	Zetec-SE	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.4L	PT-E	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	PT-E	2000 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.4L	PT-E	2000 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.4L	PT-E	2000 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	PT-E	2000 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	PT-E	2000 MY	PCM(Powertrain Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1996.75 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1996.75 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1996.75 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1996.75 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1996.75 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1998.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1998.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1998.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1998.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1998.5 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	2000 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	2000 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	2000 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	2000 MY	PATS(Passive Anti Theft System (PATS))	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999.5 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999.5 MY	GEM(Generic Electronic Module)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1999.5 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1996.75 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1996.75 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1996.75 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1996.75 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1996.75 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1998.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1998.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1998.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1998.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1998.5 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001

Fiesta/Mazda 121/Bantam	1.0L	HCS	1999 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	HCS	1999 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	HCS	1999 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.0L	HCS	1999 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	HCS	1999 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.0L	HCS	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.8L	Zetec	1994.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Zetec	1994.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Zetec	1994.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.8L	Zetec	1994.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.8L	Zetec	1994.5 MY	PCM(Powertrain Control Module (PCM))	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1997.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1997.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1997.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1997.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1997.5 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.8L	Zetec	1992 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Zetec	1992 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Zetec	1992 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.8L	Zetec	1992 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.8L	Zetec	1992 MY	PCM(Powertrain Control Module (PCM))	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999.75 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999.75 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999.75 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999.75 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999.75 MY	GEM(Generic Electronic Module)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999.75 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.0L	Zetec Rocam	1999.75 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1996 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1996 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1996 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1996 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.3L	Endura-E	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.6L	Other	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.6L	Other	2001 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.6L	Other	2001 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.6L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.6L	Other	2001 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	

Fiesta/Mazda 121/Bantam	1.6L	Other	2001 MY	PATS(Passive Anti Theft System (PATS))	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.6L	Other	2001 MY	PATS(Passive Anti Theft System)	√	√			
Fiesta/Mazda 121/Bantam	1.6L	Other	2001 MY	PCM(Powertrain Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1997 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1997 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1997 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1997 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1997.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1997.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1997.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1997.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1997.5 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	1996.25 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	1996.25 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	1996.25 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	1996.25 MY	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	1996.25 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	1996.25 MY	PATS(Passive Anti Theft System (PATS))	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	1996.25 MY	PCM(Powertrain Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	Other	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	Other	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	Other	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	Other	ECS(Electronic Crash Sensor)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	Other	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	Other	PATS(Passive Anti Theft System (PATS))	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	Other	PATS(Passive Anti Theft System)	√	√	√		
Fiesta/Mazda 121/Bantam	1.8L	Endura-DE	Other	PCM(Powertrain Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1998.5 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1998.5 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1998.5 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1998.5 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.4L	Zetec-SE	1998.5 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1996 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1996 MY	CSM(Security Module)	√	√	√		
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1996 MY	CSM(Security Module)	√	√			
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1996 MY	HEC(Hybrid Electronic Cluster)	√	√	√	√	
Fiesta/Mazda 121/Bantam	1.25L	Zetec-SE	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
FRIENDEE/FREDA/BONGO FRIENDEE	2.0L	FE	1997 MY	A/C(Air Conditioning)	√	√			
FRIENDEE/FREDA/BONGO FRIENDEE	2.0L	FE	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FRIENDEE/FREDA/BONGO FRIENDEE	2.0L	FE	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
FRIENDEE/FREDA/BONGO FRIENDEE	2.0L	FE	1997 MY	TCM(Transmission Control Module)	√	√			
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	J5	1997 MY	A/C(Air Conditioning)	√	√			
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	J5	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			

FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	J5	1997 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	J5	1997 MY	TCM(Transmission Control Module)	√	√			
FRIENDEE/FREDA/BONGO FRIENDEE	2.0L	FE	2002 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FRIENDEE/FREDA/BONGO FRIENDEE	2.0L	FE	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
FRIENDEE/FREDA/BONGO FRIENDEE	2.0L	FE	2002 MY	TCM(Transmission Control Module)	√	√	√	√	
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	WL T	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	WL T	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	WL T	1999 MY	TCM(Transmission Control Module)	√	√	√	√	
FRIENDEE/FREDA/BONGO FRIENDEE	2.0L	FE	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FRIENDEE/FREDA/BONGO FRIENDEE	2.0L	FE	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
FRIENDEE/FREDA/BONGO FRIENDEE	2.0L	FE	1999 MY	TCM(Transmission Control Module)	√	√	√	√	
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	J5	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	J5	1999 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	J5	1999 MY	TCM(Transmission Control Module)	√	√	√	√	
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	WL T	1997 MY	A/C(Air Conditioning)	√	√			
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	WL T	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	WL T	1997 MY	PCM(Powertrain Control Module (PCM))	√	√			
FRIENDEE/FREDA/BONGO FRIENDEE	2.5L	WL T	1997 MY	TCM(Transmission Control Module)	√	√			
LANTIS	2.0L	KF	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LANTIS	2.0L	KF	1996 MY	PCM(Powertrain Control Module (PCM))	√	√			
LANTIS	2.0L	KF	1996 MY	TCM(Transmission Control Module)	√	√			
LANTIS	1.8L	BP	1996 MY	A/C(Air Conditioning)	√	√			
LANTIS	1.8L	BP	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LANTIS	1.8L	BP	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
LAPUTA	660cc	K6A	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LAPUTA	660cc	K6A	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	K6A	2001 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LAPUTA	660cc	K6A	2002 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LAPUTA	660cc	K6A	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	K6A	2002 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LAPUTA	660cc	K6A	2001. 5 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LAPUTA	660cc	K6A	2001. 5 MY	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	K6A	2001. 5 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LAPUTA	660cc	K6A-T	2001. 5 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LAPUTA	660cc	K6A-T	2001. 5 MY	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	K6A-T	2001. 5 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LAPUTA	660cc	K6A-T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		

LAPUTA	660cc	K6A-T	Other	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	K6A-T	Other	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	K6A-T	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LAPUTA	660cc	K6A	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LAPUTA	660cc	K6A	Other	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	K6A	Other	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	K6A	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LAPUTA	660cc	F6A-T	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LAPUTA	660cc	F6A-T	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	F6A-T	2001 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LAPUTA	660cc	K6A	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LAPUTA	660cc	K6A	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	K6A	2000 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LAPUTA	660cc	K6A-T	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LAPUTA	660cc	K6A-T	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	K6A-T	1999 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LAPUTA	660cc	F6A-T	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LAPUTA	660cc	F6A-T	1998 MY	PCM(Powertrain Control Module)	√	√			
LAPUTA	660cc	F6A-T	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	F6A-T	1998 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LAPUTA	660cc	F6A-T	1998 MY	TCM(Transmission Control Module)	√	√	√		
LAPUTA	660cc	F6A-T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LAPUTA	660cc	F6A-T	Other	PCM(Powertrain Control Module)	√	√			
LAPUTA	660cc	F6A-T	Other	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	F6A-T	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LAPUTA	660cc	F6A-T	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LAPUTA	660cc	F6A-T	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	F6A-T	1999 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LAPUTA	660cc	K6A-T	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LAPUTA	660cc	K6A-T	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
LAPUTA	660cc	K6A-T	2001 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
LASER/323/TIERRA	1.8L	Other	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.8L	Other	Other	PCM(Powertrain Control Module (PCM))	√	√			
LASER/323/TIERRA	1.8L	Other	Other	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.8L	FP	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			

LASER/323/TIERRA	1.8L	FP	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.8L	FP	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.5L	ZL	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.5L	ZL	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.5L	ZL	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.3L	B3	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.3L	B3	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.3L	B3	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.3L	B3	2000 MY	PCM(Powertrain Control Module)	√	√	√		
LASER/323/TIERRA	1.3L	B3	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.5L	ZL	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.5L	ZL	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.5L	ZL	Other	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	KF	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	2.0L	KF	Other	PCM(Powertrain Control Module (PCM))	√	√			
LASER/323/TIERRA	2.0L	KF	Other	TCM(Transmission Control Module)	√	√			
LASER/323/TIERRA	2.0L	RF	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	2.0L	RF	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	RF	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	RF	1998 MY	TCM(Transmission Control Module)	√	√			
LASER/323/TIERRA	1.3L	B3	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.3L	B3	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.3L	B3	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.6L	Other	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.6L	Other	Other	PCM(Powertrain Control Module (PCM))	√	√			
LASER/323/TIERRA	1.6L	Other	Other	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.6L	ZM	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.6L	ZM	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.6L	ZM	Other	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.3L	B3	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.3L	B3	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.3L	B3	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.5L	Z5	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.5L	Z5	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			

LASER/323/TIERRA	1.5L	Z5	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.3L	B3	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.3L	B3	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.3L	B3	Other	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	RF T	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	2.0L	RF T	1998 MY	PCM(Powertrain Control Module (PCM))	√	√			
LASER/323/TIERRA	2.0L	RF T	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	FS	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	2.0L	FS	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	FS	2001 MY	TCM(Transmission Control Module)	√	√			
LASER/323/TIERRA	1.6L	B6	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.6L	B6	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.6L	B6	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.5L	Other	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.5L	Other	Other	PCM(Powertrain Control Module (PCM))	√	√			
LASER/323/TIERRA	1.5L	Other	Other	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.6L	B6	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.6L	B6	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LASER/323/TIERRA	1.6L	B6	Other	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.6L	ZM	2000 MY	A/C(Air Conditioning)	√	√			
LASER/323/TIERRA	1.6L	ZM	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.6L	ZM	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.6L	ZM	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.6L	ZM	2000 MY	PCM(Powertrain Control Module)	√	√	√		
LASER/323/TIERRA	1.6L	ZM	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.6L	ZM	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.6L	ZM	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.6L	ZM	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.8L	BP	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.8L	BP	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LASER/323/TIERRA	1.8L	BP	Other	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.3L	B3	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.3L	B3	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.3L	B3	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	

LASER/323/TIERRA	1.8L	FP	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.8L	FP	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.8L	FP	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	RF	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	2.0L	RF	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	RF	Other	PCM(Powertrain Control Module (PCM))	√	√			
LASER/323/TIERRA	2.0L	RF	Other	TCM(Transmission Control Module)	√	√			
LASER/323/TIERRA	1.5L	Z5	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.5L	Z5	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
LASER/323/TIERRA	1.5L	Z5	Other	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	RF T	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	2.0L	RF T	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	RF T	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.8L	FP	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.8L	FP	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	1.8L	FP	Other	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.3L	Other	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.3L	Other	Other	PCM(Powertrain Control Module (PCM))	√	√			
LASER/323/TIERRA	1.3L	Other	Other	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	1.8L	BP	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.8L	BP	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	1.8L	BP	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	FS	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	FS	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
LASER/323/TIERRA	2.0L	FS	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	√	√	√		
LASER/323/TIERRA	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
LASER/323/TIERRA	2.0L	FS	2000 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
MARVIE	2.5L	G5	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA 929	3.0L	JE	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA RX-7	654x2cc	13B	1998 MY	PCM(Powertrain Control Module (PCM))	√	√			
MAZDA RX-7	654x2cc	13B	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA2 (China)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA2 (China)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (China)	1.3L	ZJ	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA2 (China)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	√	√	√	√	

MAZDA2 (China)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA2 (China)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (China)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	√	√	√		
MAZDA2 (China)	1.5L	ZY	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA2 (China)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (China)	1.5L	ZY	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA2 (China)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (China)	1.5L	ZY	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA2 (China)	1.5L	ZY	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (China)	1.5L	ZY	2007 MY	RKE(Remote Keyless Entry)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	IC(Instrument Cluster)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	IC(Instrument Cluster)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	PCM(Powertrain Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	TCM(Transmission Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	IC(Instrument Cluster)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	TCM(Transmission Control Module)	√	√	√		SP0011
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	TCM(Transmission Control Module)	√	√	√		SP0011
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	PCM(Powertrain Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	TCM(Transmission Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	

MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	TCM(Transmission Control Module)	√	√	√		SP0011
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	TCM(Transmission Control Module)	√	√	√		SP0011
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	IC(Instrument Cluster)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	TCM(Transmission Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	TCM(Transmission Control Module)	√	√	√		
MAZDA2 (Europe)	1.4L	Y4	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA2 (Europe)	1.4L	Y4	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (Europe)	1.4L	Y4	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (Europe)	1.4L	Y4	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (Europe)	1.4L	Y4	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA2 (Europe)	1.4L	Y4	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (Europe)	1.4L	Y4	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (Europe)	1.4L	Y4	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (Europe)	1.4L	Y4	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0033
MAZDA2 (Europe)	1.4L	Y4	2007 MY	RCM(Restraint Control Module)	√	√	√		SP0031
MAZDA2 (Europe)	1.4L	Y4	2007 MY	RKE(Remote Keyless Entry)	√	√	√		
MAZDA2 (Europe)	1.4L	Y4	2007 MY	VSM(Vehicle Security Module)	√	√	√		
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	RCM(Restraint Control Module)	√	√	√		SP0031
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	RKE(Remote Keyless Entry)	√	√	√		
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	VSM(Vehicle Security Module)	√	√	√		
MAZDA2 (Europe)	1.6L	Y6	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	

MAZDA2 (Europe)	1.6L	Y6	2008 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (Europe)	1.6L	Y6	2008 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (Europe)	1.6L	Y6	2008 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (Europe)	1.6L	Y6	2008 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA2 (Europe)	1.6L	Y6	2008 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (Europe)	1.6L	Y6	2008 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (Europe)	1.6L	Y6	2008 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (Europe)	1.6L	Y6	2008 MY	PCM(Powertrain Control Module)	√	√	√		SP0038,SP0039,SP0040,SP0041,SP0042,SP0043,SP0044,SP0045
MAZDA2 (Europe)	1.6L	Y6	2008 MY	RCM(Restraint Control Module)	√	√	√		SP0031
MAZDA2 (Europe)	1.6L	Y6	2008 MY	RKE(Remote Keyless Entry)	√	√	√		
MAZDA2 (Europe)	1.6L	Y6	2008 MY	VSM(Vehicle Security Module)	√	√	√		
MAZDA2 (Europe)	1.5L	ZY	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA2 (Europe)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (Europe)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (Europe)	1.5L	ZY	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA2 (Europe)	1.5L	ZY	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA2 (Europe)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (Europe)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (Europe)	1.5L	ZY	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA2 (Europe)	1.5L	ZY	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA2 (Europe)	1.5L	ZY	2007 MY	RCM(Restraint Control Module)	√	√	√		SP0031
MAZDA2 (Europe)	1.5L	ZY	2007 MY	RKE(Remote Keyless Entry)	√	√	√		
MAZDA2 (Europe)	1.5L	ZY	2007 MY	VSM(Vehicle Security Module)	√	√	√		
MAZDA2/DEMIO	1.5L	S5	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA2/DEMIO	1.5L	S5	Other	ALM#1(Auto Leveling Module)	√	√	√		
MAZDA2/DEMIO	1.5L	S5	Other	BCM#1(Body Control Module)	√	√	√	√	
MAZDA2/DEMIO	1.5L	S5	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA2/DEMIO	1.5L	S5	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA2/DEMIO	1.5L	S5	Other	DCDC(DC To DC Converter Control Module)	√	√	√	√	
MAZDA2/DEMIO	1.5L	S5	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
MAZDA2/DEMIO	1.5L	S5	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA2/DEMIO	1.5L	S5	Other	ESU(Electric Supply Unit)	√	√			
MAZDA2/DEMIO	1.5L	S5	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA2/DEMIO	1.5L	S5	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA2/DEMIO	1.5L	S5	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0085,SP0086
MAZDA2/DEMIO	1.5L	S5	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA2/DEMIO	1.5L	S5	Other	SCBS(Smart City Brake Support)	√	√	√		
MAZDA2/DEMIO	1.5L	S5	Other	SSU(Smart Start Unit)	√	√	√	√	
MAZDA2/DEMIO	1.5L	S5	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA2/DEMIO	1.3L	P3	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA2/DEMIO	1.3L	P3	Other	ALM#1(Auto Leveling Module)	√	√	√		
MAZDA2/DEMIO	1.3L	P3	Other	BCM#1(Body Control Module)	√	√	√	√	

MAZDA2/DEMIO	1.3L	P3	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA2/DEMIO	1.3L	P3	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA2/DEMIO	1.3L	P3	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
MAZDA2/DEMIO	1.3L	P3	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA2/DEMIO	1.3L	P3	Other	ESU(Electric Supply Unit)	√	√			
MAZDA2/DEMIO	1.3L	P3	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA2/DEMIO	1.3L	P3	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA2/DEMIO	1.3L	P3	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0085,SP0086
MAZDA2/DEMIO	1.3L	P3	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA2/DEMIO	1.3L	P3	Other	SCBS(Smart City Brake Support)	√	√	√		
MAZDA2/DEMIO	1.3L	P3	Other	SSU(Smart Start Unit)	√	√	√	√	
MAZDA2/DEMIO	1.5L	P5	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA2/DEMIO	1.5L	P5	Other	ALM#1(Auto Leveling Module)	√	√	√		
MAZDA2/DEMIO	1.5L	P5	Other	BCM#1(Body Control Module)	√	√	√	√	
MAZDA2/DEMIO	1.5L	P5	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA2/DEMIO	1.5L	P5	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA2/DEMIO	1.5L	P5	Other	DCDC(DC To DC Converter Control Module)	√	√	√	√	
MAZDA2/DEMIO	1.5L	P5	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
MAZDA2/DEMIO	1.5L	P5	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA2/DEMIO	1.5L	P5	Other	ESU(Electric Supply Unit)	√	√			
MAZDA2/DEMIO	1.5L	P5	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA2/DEMIO	1.5L	P5	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA2/DEMIO	1.5L	P5	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0085,SP0086
MAZDA2/DEMIO	1.5L	P5	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA2/DEMIO	1.5L	P5	Other	SCBS(Smart City Brake Support)	√	√	√		
MAZDA2/DEMIO	1.5L	P5	Other	SSU(Smart Start Unit)	√	√	√	√	
MAZDA2/DEMIO	1.5L	P5	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA3 (China/General)	1.6L	Z6	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA3 (China/General)	1.6L	Z6	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (China/General)	1.6L	Z6	2007 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (China/General)	1.6L	Z6	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (China/General)	1.6L	Z6	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (China/General)	1.6L	Z6	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (China/General)	1.6L	Z6	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA3 (China/General)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA3 (China/General)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (China/General)	2.0L	LF	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (China/General)	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (China/General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (China/General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (China/General)	2.0L	LF	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (China/General)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√			

MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2006 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3 T	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3 T	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3 T	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3 T	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3 T	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3 T	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3 T	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2003 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2003 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2003 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2003 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2006 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2006 MY	FACM(Fuel Additive Control Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0013
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2003 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2003 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2003 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Z6	2003 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012

MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2006 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.3L	ZJ	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2003 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2003 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2003 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2003 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	LF	2003 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	RF T	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	RF T	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	RF T	2006 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	RF T	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	RF T	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	RF T	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	RF T	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	RF T	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.0L	RF T	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2003 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2003 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2003 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2003 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	2.3L	L3	2003 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2003 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2003 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2003 MY	FACM(Fuel Additive Control Module)	√	√	√	√	
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2003 MY	GEM(Generic Electronic Module)	√	√	√		

MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2003 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0013
MAZDA3 (EURO STG3/4/5 And General Specs.)	1.6L	Y6	2003 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2004 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.3L	L3	2004 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (North America/General)	2.3L	L3	2004 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2004 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2004 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2004 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2004 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.3L	L3	2009 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (North America/General)	2.3L	L3	2009 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2009 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2009 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2009 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2009 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2009 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA3 (North America/General)	1.6L	Z6	2012 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA3 (North America/General)	1.6L	Z6	2012 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	1.6L	Z6	2012 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	1.6L	Z6	2012 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	1.6L	Z6	2012 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.3L	L3 T	2008 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (North America/General)	2.3L	L3 T	2008 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2008 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2008 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3 T	2008 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2008 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (North America/General)	2.3L	L3	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2007 MY	RCM(Restraint Control Module)	√	√	√		

MAZDA3 (North America/General)	2.3L	L3	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2007 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.0L	LF	2006 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2006 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.0L	LF	2009 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2009 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2009 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2009 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2009 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2009 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2004 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.0L	LF	2004 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2004 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2004 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2004 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2004 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (North America/General)	2.3L	L3	2008 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2008 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.0L	LF	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2007 MY	RCM(Restraint Control Module)	√	√	√		

MAZDA3 (North America/General)	2.0L	LF	2007 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.3L	L3	2005 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (North America/General)	2.3L	L3	2005 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2005 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.3L	L3 T	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (North America/General)	2.3L	L3 T	2007 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3 T	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2007 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (North America/General)	2.3L	L3	2006 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.3L	L3 T	2009 MY	EATC(Electronic Automatic Temperature Control)	√	√			
MAZDA3 (North America/General)	2.3L	L3 T	2009 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2009 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2009 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.3L	L3 T	2009 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.3L	L3 T	2009 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA3 (North America/General)	1.6L	Z6	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	1.6L	Z6	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	1.6L	Z6	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	1.6L	Z6	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	1.6L	Z6	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	1.6L	Z6	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012

MAZDA3 (North America/General)	2.0L	LF	2005 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2005 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA3 (North America/General)	2.0L	LF	2008 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2008 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2008 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2008 MY	IC(Instrument Cluster)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3 (North America/General)	2.0L	LF	2008 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA3 (North America/General)	2.0L	LF	2008 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
MAZDA3/ AXELA	2.5L	PY	Other	4X4(4X4 Control Module)	√	√	√	√	
MAZDA3/ AXELA	2.5L	PY	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012,SP0098
MAZDA3/ AXELA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MAZDA3/ AXELA	2.5L	PY	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA3/ AXELA	2.5L	PY	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA3/ AXELA	2.5L	PY	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA3/ AXELA	2.5L	PY	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA3/ AXELA	2.5L	PY	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA3/ AXELA	2.5L	PY	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
MAZDA3/ AXELA	2.5L	PY	Other	DCM(Data Communication Module)	√	√	√		
MAZDA3/ AXELA	2.5L	PY	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA3/ AXELA	2.5L	PY	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA3/ AXELA	2.5L	PY	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA3/ AXELA	2.5L	PY	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3/ AXELA	2.5L	PY	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA3/ AXELA	2.5L	PY	Other	F BCM(Body Control Module - Front)	√	√	√	√	
MAZDA3/ AXELA	2.5L	PY	Other	HUD(Head Up Display)	√	√	√		
MAZDA3/ AXELA	2.5L	PY	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA3/ AXELA	2.5L	PY	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA3/ AXELA	2.5L	PY	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA3/ AXELA	2.5L	PY	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA3/ AXELA	2.5L	PY	Other	R BCM(Rear Body Control Module)	√	√	√	√	
MAZDA3/ AXELA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA3/ AXELA	2.5L	PY	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA3/ AXELA	2.5L	PY	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA3/ AXELA	2.5L	PY	Other	VMC(View Monitor Camera)	√	√	√		
MAZDA3/ AXELA	1.5L	S5	Other	4X4(4X4 Control Module)	√	√	√	√	
MAZDA3/ AXELA	1.5L	S5	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012,SP0098
MAZDA3/ AXELA	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		

MAZDA3/ AXELA	1.5L	S5	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA3/ AXELA	1.5L	S5	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA3/ AXELA	1.5L	S5	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA3/ AXELA	1.5L	S5	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA3/ AXELA	1.5L	S5	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA3/ AXELA	1.5L	S5	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
MAZDA3/ AXELA	1.5L	S5	Other	DCM(Data Communication Module)	√	√	√		
MAZDA3/ AXELA	1.5L	S5	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA3/ AXELA	1.5L	S5	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA3/ AXELA	1.5L	S5	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA3/ AXELA	1.5L	S5	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3/ AXELA	1.5L	S5	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA3/ AXELA	1.5L	S5	Other	F BCM(Body Control Module - Front)	√	√	√	√	
MAZDA3/ AXELA	1.5L	S5	Other	HUD(Head Up Display)	√	√	√		
MAZDA3/ AXELA	1.5L	S5	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA3/ AXELA	1.5L	S5	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA3/ AXELA	1.5L	S5	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA3/ AXELA	1.5L	S5	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA3/ AXELA	1.5L	S5	Other	R BCM(Rear Body Control Module)	√	√	√	√	
MAZDA3/ AXELA	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA3/ AXELA	1.5L	S5	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA3/ AXELA	1.5L	S5	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA3/ AXELA	1.5L	S5	Other	VMC(View Monitor Camera)	√	√	√		
MAZDA3/ AXELA	2.2L	SH	Other	4X4(4X4 Control Module)	√	√	√	√	
MAZDA3/ AXELA	2.2L	SH	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012,SP0098
MAZDA3/ AXELA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MAZDA3/ AXELA	2.2L	SH	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA3/ AXELA	2.2L	SH	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA3/ AXELA	2.2L	SH	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA3/ AXELA	2.2L	SH	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA3/ AXELA	2.2L	SH	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA3/ AXELA	2.2L	SH	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
MAZDA3/ AXELA	2.2L	SH	Other	DCM(Data Communication Module)	√	√	√		
MAZDA3/ AXELA	2.2L	SH	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA3/ AXELA	2.2L	SH	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA3/ AXELA	2.2L	SH	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA3/ AXELA	2.2L	SH	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3/ AXELA	2.2L	SH	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA3/ AXELA	2.2L	SH	Other	F BCM(Body Control Module - Front)	√	√	√	√	
MAZDA3/ AXELA	2.2L	SH	Other	HUD(Head Up Display)	√	√	√		
MAZDA3/ AXELA	2.2L	SH	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA3/ AXELA	2.2L	SH	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA3/ AXELA	2.2L	SH	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA3/ AXELA	2.2L	SH	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA3/ AXELA	2.2L	SH	Other	R BCM(Rear Body Control Module)	√	√	√	√	
MAZDA3/ AXELA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		

MAZDA3/ AXELA	2.2L	SH	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA3/ AXELA	2.2L	SH	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA3/ AXELA	2.2L	SH	Other	VMC(View Monitor Camera)	√	√	√		
MAZDA3/ AXELA	1.5L	P5	Other	4X4(4X4 Control Module)	√	√	√	√	
MAZDA3/ AXELA	1.5L	P5	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012,SP0098
MAZDA3/ AXELA	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		SP0070
MAZDA3/ AXELA	1.5L	P5	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA3/ AXELA	1.5L	P5	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA3/ AXELA	1.5L	P5	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA3/ AXELA	1.5L	P5	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA3/ AXELA	1.5L	P5	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA3/ AXELA	1.5L	P5	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
MAZDA3/ AXELA	1.5L	P5	Other	DCM(Data Communication Module)	√	√	√		
MAZDA3/ AXELA	1.5L	P5	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA3/ AXELA	1.5L	P5	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA3/ AXELA	1.5L	P5	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA3/ AXELA	1.5L	P5	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3/ AXELA	1.5L	P5	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA3/ AXELA	1.5L	P5	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
MAZDA3/ AXELA	1.5L	P5	Other	HUD(Head Up Display)	√	√	√		
MAZDA3/ AXELA	1.5L	P5	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA3/ AXELA	1.5L	P5	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA3/ AXELA	1.5L	P5	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA3/ AXELA	1.5L	P5	Other	RCM(Restraint Control Module)	√	√	√		SP0072
MAZDA3/ AXELA	1.5L	P5	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
MAZDA3/ AXELA	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		SP0074
MAZDA3/ AXELA	1.5L	P5	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA3/ AXELA	1.5L	P5	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA3/ AXELA	1.5L	P5	Other	VMC(View Monitor Camera)	√	√	√		
MAZDA3/ AXELA	2.0L	PE	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012,SP0098
MAZDA3/ AXELA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MAZDA3/ AXELA	2.0L	PE	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA3/ AXELA	2.0L	PE	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA3/ AXELA	2.0L	PE	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA3/ AXELA	2.0L	PE	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA3/ AXELA	2.0L	PE	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA3/ AXELA	2.0L	PE	Other	DCM(Data Communication Module)	√	√	√		
MAZDA3/ AXELA	2.0L	PE	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA3/ AXELA	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA3/ AXELA	2.0L	PE	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA3/ AXELA	2.0L	PE	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3/ AXELA	2.0L	PE	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA3/ AXELA	2.0L	PE	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
MAZDA3/ AXELA	2.0L	PE	Other	HUD(Head Up Display)	√	√	√	√	
MAZDA3/ AXELA	2.0L	PE	Other	IC(Instrument Cluster)	√	√	√	√	

MAZDA3/ AXELA	2.0L	PE	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA3/ AXELA	2.0L	PE	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA3/ AXELA	2.0L	PE	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA3/ AXELA	2.0L	PE	Other	R BCM(Rear Body Control Module)	√	√	√	√	
MAZDA3/ AXELA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA3/ AXELA	2.0L	PE	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA3/ AXELA	2.0L	PE	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA3/ AXELA	2.0L	PE	Other	VMC(View Monitor Camera)	√	√	√		
MAZDA3/AXELA	1.5L	S5	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012,SP0098
MAZDA3/AXELA	1.5L	S5	Other	ACU(Audio Control Unit)	√	√			
MAZDA3/AXELA	1.5L	S5	Other	ACU(Audio Control Unit)	√	√			
MAZDA3/AXELA	1.5L	S5	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MAZDA3/AXELA	1.5L	S5	Other	AFS(Adaptive Front Lighting System)	√	√			
MAZDA3/AXELA	1.5L	S5	Other	AFS(Adaptive Front Lighting System)	√	√			
MAZDA3/AXELA	1.5L	S5	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA3/AXELA	1.5L	S5	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA3/AXELA	1.5L	S5	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA3/AXELA	1.5L	S5	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA3/AXELA	1.5L	S5	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA3/AXELA	1.5L	S5	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA3/AXELA	1.5L	S5	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA3/AXELA	1.5L	S5	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA3/AXELA	1.5L	S5	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3/AXELA	1.5L	S5	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA3/AXELA	1.5L	S5	Other	F BCM(Body Control Module - Front)	√	√	√	√	
MAZDA3/AXELA	1.5L	S5	Other	IC(Instrument Cluster)	√	√	√		
MAZDA3/AXELA	1.5L	S5	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA3/AXELA	1.5L	S5	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA3/AXELA	1.5L	S5	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA3/AXELA	1.5L	S5	Other	RCM(Restraint Control Module)	√	√	√		SP0072
MAZDA3/AXELA	1.5L	S5	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA3/AXELA	1.5L	S5	Other	R BCM(Rear Body Control Module)	√	√	√	√	
MAZDA3/AXELA	1.5L	S5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA3/AXELA	1.5L	S5	Other	SCBS(Smart City Brake Support)	√	√	√		
MAZDA3/AXELA	1.5L	S5	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA3/AXELA	1.5L	P5	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012,SP0098
MAZDA3/AXELA	1.5L	P5	Other	ACU(Audio Control Unit)	√	√			
MAZDA3/AXELA	1.5L	P5	Other	ACU(Audio Control Unit)	√	√			
MAZDA3/AXELA	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		SP0070
MAZDA3/AXELA	1.5L	P5	Other	AFS(Adaptive Front Lighting System)	√	√			
MAZDA3/AXELA	1.5L	P5	Other	AFS(Adaptive Front Lighting System)	√	√			
MAZDA3/AXELA	1.5L	P5	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA3/AXELA	1.5L	P5	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA3/AXELA	1.5L	P5	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA3/AXELA	1.5L	P5	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	

MAZDA3/AXELA	1.5L	P5	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA3/AXELA	1.5L	P5	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA3/AXELA	1.5L	P5	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA3/AXELA	1.5L	P5	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA3/AXELA	1.5L	P5	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3/AXELA	1.5L	P5	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA3/AXELA	1.5L	P5	Other	F BCM(Body Control Module - Front)	√	√	√	√	
MAZDA3/AXELA	1.5L	P5	Other	IC(Instrument Cluster)	√	√	√		
MAZDA3/AXELA	1.5L	P5	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA3/AXELA	1.5L	P5	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA3/AXELA	1.5L	P5	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA3/AXELA	1.5L	P5	Other	RCM(Restraint Control Module)	√	√	√		SP0072
MAZDA3/AXELA	1.5L	P5	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA3/AXELA	1.5L	P5	Other	R BCM(Rear Body Control Module)	√	√	√	√	
MAZDA3/AXELA	1.5L	P5	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		SP0074
MAZDA3/AXELA	1.5L	P5	Other	SCBS(Smart City Brake Support)	√	√	√		
MAZDA3/AXELA	1.5L	P5	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA3/AXELA	2.2L	SH	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012,SP0098
MAZDA3/AXELA	2.2L	SH	Other	ACU(Audio Control Unit)	√	√			
MAZDA3/AXELA	2.2L	SH	Other	ACU(Audio Control Unit)	√	√			
MAZDA3/AXELA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MAZDA3/AXELA	2.2L	SH	Other	AFS(Adaptive Front Lighting System)	√	√			
MAZDA3/AXELA	2.2L	SH	Other	AFS(Adaptive Front Lighting System)	√	√			
MAZDA3/AXELA	2.2L	SH	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA3/AXELA	2.2L	SH	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA3/AXELA	2.2L	SH	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA3/AXELA	2.2L	SH	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA3/AXELA	2.2L	SH	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA3/AXELA	2.2L	SH	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
MAZDA3/AXELA	2.2L	SH	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA3/AXELA	2.2L	SH	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA3/AXELA	2.2L	SH	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA3/AXELA	2.2L	SH	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3/AXELA	2.2L	SH	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA3/AXELA	2.2L	SH	Other	F BCM(Body Control Module - Front)	√	√	√	√	
MAZDA3/AXELA	2.2L	SH	Other	IC(Instrument Cluster)	√	√	√		
MAZDA3/AXELA	2.2L	SH	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA3/AXELA	2.2L	SH	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA3/AXELA	2.2L	SH	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA3/AXELA	2.2L	SH	Other	RCM(Restraint Control Module)	√	√	√		SP0072
MAZDA3/AXELA	2.2L	SH	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA3/AXELA	2.2L	SH	Other	R BCM(Rear Body Control Module)	√	√	√	√	
MAZDA3/AXELA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA3/AXELA	2.2L	SH	Other	SCBS(Smart City Brake Support)	√	√	√		
MAZDA3/AXELA	2.2L	SH	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034

MAZDA3/AXELA	1.6L	Z6	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012,SP0098
MAZDA3/AXELA	1.6L	Z6	Other	ACU(Audio Control Unit)	√	√			
MAZDA3/AXELA	1.6L	Z6	Other	ACU(Audio Control Unit)	√	√			
MAZDA3/AXELA	1.6L	Z6	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MAZDA3/AXELA	1.6L	Z6	Other	AFS(Adaptive Front Lighting System)	√	√			
MAZDA3/AXELA	1.6L	Z6	Other	AFS(Adaptive Front Lighting System)	√	√			
MAZDA3/AXELA	1.6L	Z6	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA3/AXELA	1.6L	Z6	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA3/AXELA	1.6L	Z6	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA3/AXELA	1.6L	Z6	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA3/AXELA	1.6L	Z6	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA3/AXELA	1.6L	Z6	Other	DCM(Data Communication Module)	√	√	√		
MAZDA3/AXELA	1.6L	Z6	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA3/AXELA	1.6L	Z6	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA3/AXELA	1.6L	Z6	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA3/AXELA	1.6L	Z6	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3/AXELA	1.6L	Z6	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA3/AXELA	1.6L	Z6	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
MAZDA3/AXELA	1.6L	Z6	Other	HUD(Head Up Display)	√	√	√	√	
MAZDA3/AXELA	1.6L	Z6	Other	IC(Instrument Cluster)	√	√	√		
MAZDA3/AXELA	1.6L	Z6	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA3/AXELA	1.6L	Z6	Other	PCM(Powertrain Control Module)	√	√	√		
MAZDA3/AXELA	1.6L	Z6	Other	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA3/AXELA	1.6L	Z6	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA3/AXELA	1.6L	Z6	Other	RCM(Restraint Control Module)	√	√	√		SP0072
MAZDA3/AXELA	1.6L	Z6	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA3/AXELA	1.6L	Z6	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
MAZDA3/AXELA	1.6L	Z6	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA3/AXELA	1.6L	Z6	Other	SCBS(Smart City Brake Support)	√	√	√		
MAZDA3/AXELA	1.6L	Z6	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA3/AXELA	2.5L	PY	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012,SP0098
MAZDA3/AXELA	2.5L	PY	Other	ACU(Audio Control Unit)	√	√			
MAZDA3/AXELA	2.5L	PY	Other	ACU(Audio Control Unit)	√	√			
MAZDA3/AXELA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MAZDA3/AXELA	2.5L	PY	Other	AFS(Adaptive Front Lighting System)	√	√			
MAZDA3/AXELA	2.5L	PY	Other	AFS(Adaptive Front Lighting System)	√	√			
MAZDA3/AXELA	2.5L	PY	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA3/AXELA	2.5L	PY	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA3/AXELA	2.5L	PY	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA3/AXELA	2.5L	PY	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA3/AXELA	2.5L	PY	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA3/AXELA	2.5L	PY	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA3/AXELA	2.5L	PY	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA3/AXELA	2.5L	PY	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA3/AXELA	2.5L	PY	Other	EPS(Electronic Controlled Power Steering)	√	√	√		

MAZDA3/AXELA	2.5L	PY	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA3/AXELA	2.5L	PY	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
MAZDA3/AXELA	2.5L	PY	Other	IC(Instrument Cluster)	√	√	√		
MAZDA3/AXELA	2.5L	PY	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA3/AXELA	2.5L	PY	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA3/AXELA	2.5L	PY	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA3/AXELA	2.5L	PY	Other	RCM(Restraint Control Module)	√	√	√		SP0072
MAZDA3/AXELA	2.5L	PY	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA3/AXELA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
MAZDA3/AXELA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA3/AXELA	2.5L	PY	Other	SCBS(Smart City Brake Support)	√	√	√		
MAZDA3/AXELA	2.5L	PY	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA3/AXELA	2.0L	PE	Other	4X4(4X4 Control Module)	√	√	√	√	
MAZDA3/AXELA	2.0L	PE	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012,SP0098
MAZDA3/AXELA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MAZDA3/AXELA	2.0L	PE	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA3/AXELA	2.0L	PE	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA3/AXELA	2.0L	PE	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA3/AXELA	2.0L	PE	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA3/AXELA	2.0L	PE	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA3/AXELA	2.0L	PE	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
MAZDA3/AXELA	2.0L	PE	Other	DCM(Data Communication Module)	√	√	√		
MAZDA3/AXELA	2.0L	PE	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA3/AXELA	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA3/AXELA	2.0L	PE	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA3/AXELA	2.0L	PE	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA3/AXELA	2.0L	PE	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA3/AXELA	2.0L	PE	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
MAZDA3/AXELA	2.0L	PE	Other	HUD(Head Up Display)	√	√	√		
MAZDA3/AXELA	2.0L	PE	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA3/AXELA	2.0L	PE	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA3/AXELA	2.0L	PE	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA3/AXELA	2.0L	PE	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA3/AXELA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
MAZDA3/AXELA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA3/AXELA	2.0L	PE	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA3/AXELA	2.0L	PE	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA3/AXELA	2.0L	PE	Other	VMC(View Monitor Camera)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2007 MY	IC(Instrument Cluster)	√	√	√		

MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2007 MY	LPSDM(Power Sliding Door Module - Left)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2007 MY	RPSDM(Right Power Sliding Door Module)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2005 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2005 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2005 MY	GEM(Generic Electronic Module)	√	√	√		SP0017
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2005 MY	GEM(Generic Electronic Module)	√	√	√		SP0017
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2005 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2005 MY	LPSDM(Power Sliding Door Module - Left)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2005 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2005 MY	RPSDM(Right Power Sliding Door Module)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2005 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2005 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	√	√	√		SP0017
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2005 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2005 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016

MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2007 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2007 MY	GEM(Generic Electronic Module)	√	√	√		SP0017
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2007 MY	LPSDM(Power Sliding Door Module - Left)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0008,SP0021,SP0020
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2007 MY	RPSDM(Right Power Sliding Door Module)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2007 MY	LPSDM(Power Sliding Door Module - Left)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2007 MY	PCM(Powertrain Control Module)	√	√			
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2007 MY	RPSDM(Right Power Sliding Door Module)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	1.8L	L8	2007 MY	TCM(Transmission Control Module)	√	√			
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2005 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2005 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√	√	
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2005 MY	GEM(Generic Electronic Module)	√	√	√		SP0017
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2005 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0008,SP0021,SP0020
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2005 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	2.0L	RF T	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	

MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	IC(Instrument Cluster)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	

MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
MAZDA6 (China)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (China)	2.0L	LF	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (China)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (China)	2.0L	LF	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
MAZDA6 (China)	2.0L	LF	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA6 (China)	2.0L	LF	2007 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (China)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (China)	2.0L	LF	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (China)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (China)	2.5L	L5	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (China)	2.5L	L5	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (China)	2.5L	L5	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (China)	2.5L	L5	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
MAZDA6 (China)	2.5L	L5	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA6 (China)	2.5L	L5	2007 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (China)	2.5L	L5	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (China)	2.5L	L5	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (China)	2.5L	L5	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (China)	2.5L	L5	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2004 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√	√	SP0009
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2004 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2004 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	SP0007
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0008,SP0089
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2004 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2004 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2005 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2005 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2005 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2005 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2005 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	√	√	√	√	

MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2005 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2005 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2005 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2005 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	SP0007
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2005 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2005 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.3L	L3 T	2005 MY	4X4(4X4 Control Module)	√	√			
MAZDA6 (EURO STG3/4 And General)	2.3L	L3 T	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (EURO STG3/4 And General)	2.3L	L3 T	2005 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3 T	2005 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3 T	2005 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (EURO STG3/4 And General)	2.3L	L3 T	2005 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	SP0007
MAZDA6 (EURO STG3/4 And General)	2.3L	L3 T	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.3L	L3 T	2005 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3 T	2005 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3 T	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2002 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2002 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2002 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0089
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2002 MY	PCM(Powertrain Control Module)	√	√			
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2002 MY	PCM(Powertrain Control Module (PCM))	√	√			
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2002 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2002 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2003 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2003 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2003 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2003 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2003 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2002 MY	4X4(4X4 Control Module)	√	√			
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2002 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2002 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	

MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module (PCM))	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2002 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2002 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2002 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2005 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√	√	SP0009
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2005 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2005 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2005 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2005 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	SP0007
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0008,SP0021,SP0020
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2005 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2005 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2005 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2005 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2005 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2002 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2002 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2002 MY	PCM(Powertrain Control Module (PCM))	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2002 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	LF	2002 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2002 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2002 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2002 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	1.8L	L8	2002 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		

MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2003 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√	√	SP0009
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2003 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2003 MY	LHID(Left High Intensity Discharge Lamp (LHIDL))	√	√	√	√	SP0007
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0008,SP0089
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2003 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (EURO STG3/4 And General)	2.0L	RF T	2003 MY	RHID(Right High Intensity Discharge (HID) Lamp)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	ACU(Audio Control Unit)	√	√			
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	AFS(Adaptive Front Lighting System)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	ICCM(Intelligent Cruise Control Module)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	MPM(Motor Pretensioner Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	2.5L	L5	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	ACU(Audio Control Unit)	√	√			
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	AFS(Adaptive Front Lighting System)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	ICCM(Intelligent Cruise Control Module)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	MPM(Motor Pretensioner Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (GH, After Facelift) / ATENZA	1.8L	L8	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	ACU(Audio Control Unit)	√	√			
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	AFS(Adaptive Front Lighting System)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	FFH(Fuel Fired Coolant Heating Module)	√	√	√		SP0035

MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	ICCM(Intelligent Cruise Control Module)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	MPM(Motor Pretensioner Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0020,SP0089
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (GH, After Facelift) / ATENZA	2.2L	R2 T	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	ACU(Audio Control Unit)	√	√			
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	AFS(Adaptive Front Lighting System)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	ICCM(Intelligent Cruise Control Module)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	MPM(Motor Pretensioner Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	2.0L	LF	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	ACU(Audio Control Unit)	√	√			
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	AFS(Adaptive Front Lighting System)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	LCM(Lighting Control Module)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (GH, After Facelift) / ATENZA	3.7L	CA	Other	TCM(Transmission Control Module)	√	√	√	√	SP0037
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2007 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√		SP0035
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2007 MY	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2007 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0020,SP0089
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034

MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2007 MY	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA6 (GH, Before Facelift)	2.0L	RF T	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (GH, Before Facelift)	2.0L	RF T	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.0L	RF T	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (GH, Before Facelift)	2.0L	RF T	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
MAZDA6 (GH, Before Facelift)	2.0L	RF T	2007 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√		SP0035
MAZDA6 (GH, Before Facelift)	2.0L	RF T	2007 MY	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (GH, Before Facelift)	2.0L	RF T	2007 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (GH, Before Facelift)	2.0L	RF T	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0020,SP0089
MAZDA6 (GH, Before Facelift)	2.0L	RF T	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.0L	RF T	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (GH, Before Facelift)	2.0L	RF T	2007 MY	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA6 (GH, Before Facelift)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (GH, Before Facelift)	2.0L	LF	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (GH, Before Facelift)	2.0L	LF	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
MAZDA6 (GH, Before Facelift)	2.0L	LF	2007 MY	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (GH, Before Facelift)	2.0L	LF	2007 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (GH, Before Facelift)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (GH, Before Facelift)	2.0L	LF	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (GH, Before Facelift)	2.0L	LF	2007 MY	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2008 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2008 MY	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2008 MY	EPS(Electronic Controlled Power Steering)	√	√	√		SP0092
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2008 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2008 MY	IC(Instrument Cluster)	√	√	√		SP0097
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2008 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2008 MY	PCM(Powertrain Control Module)	√	√			SP0021,SP0090,SP0089
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2008 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2008 MY	RKE(Remote Keyless Entry)	√	√	√		SP0034
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2008 MY	RVM(Rear Vehicle Monitoring)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.2L	R2 T	2008 MY	TCM(Transmission Control Module)	√	√			
MAZDA6 (GH, Before Facelift)	2.5L	L5	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (GH, Before Facelift)	2.5L	L5	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.5L	L5	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (GH, Before Facelift)	2.5L	L5	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
MAZDA6 (GH, Before Facelift)	2.5L	L5	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA6 (GH, Before Facelift)	2.5L	L5	2007 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (GH, Before Facelift)	2.5L	L5	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	

MAZDA6 (GH, Before Facelift)	2.5L	L5	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	2.5L	L5	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (GH, Before Facelift)	2.5L	L5	2007 MY	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA6 (GH, Before Facelift)	1.8L	L8	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (GH, Before Facelift)	1.8L	L8	2007 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	1.8L	L8	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (GH, Before Facelift)	1.8L	L8	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		SP0010
MAZDA6 (GH, Before Facelift)	1.8L	L8	2007 MY	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (GH, Before Facelift)	1.8L	L8	2007 MY	LCM(Lighting Control Module)	√	√			
MAZDA6 (GH, Before Facelift)	1.8L	L8	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (GH, Before Facelift)	1.8L	L8	2007 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (GH, Before Facelift)	1.8L	L8	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (GH, Before Facelift)	1.8L	L8	2007 MY	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA6 (Middle East/General)	2.5L	L5	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (Middle East/General)	2.5L	L5	2009 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (Middle East/General)	2.5L	L5	2009 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
MAZDA6 (Middle East/General)	2.5L	L5	2009 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6 (Middle East/General)	2.5L	L5	2009 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (Middle East/General)	2.5L	L5	2009 MY	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (Middle East/General)	2.5L	L5	2009 MY	LCM(Lighting Control Module)	√	√	√		
MAZDA6 (Middle East/General)	2.5L	L5	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (Middle East/General)	2.5L	L5	2009 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6 (Middle East/General)	2.5L	L5	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (Middle East/General)	3.7L	CA	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (Middle East/General)	3.7L	CA	2010 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (Middle East/General)	3.7L	CA	2010 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA6 (Middle East/General)	3.7L	CA	2010 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6 (Middle East/General)	3.7L	CA	2010 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	
MAZDA6 (Middle East/General)	3.7L	CA	2010 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA6 (Middle East/General)	3.7L	CA	2010 MY	LCM(Lighting Control Module)	√	√	√		
MAZDA6 (Middle East/General)	3.7L	CA	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (Middle East/General)	3.7L	CA	2010 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (Middle East/General)	3.7L	CA	2010 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA6 (Middle East/General)	3.7L	CA	2010 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6 (Middle East/General)	3.7L	CA	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (Middle East/General)	3.7L	CA	2009 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (Middle East/General)	3.7L	CA	2009 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
MAZDA6 (Middle East/General)	3.7L	CA	2009 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6 (Middle East/General)	3.7L	CA	2009 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (Middle East/General)	3.7L	CA	2009 MY	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (Middle East/General)	3.7L	CA	2009 MY	LCM(Lighting Control Module)	√	√	√		

MAZDA6 (Middle East/General)	3.7L	CA	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
MAZDA6 (Middle East/General)	3.7L	CA	2009 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6 (Middle East/General)	3.7L	CA	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (Middle East/General)	3.7L	CA	2009 MY	TCM(Transmission Control Module)	√	√	√	√	SP0037
MAZDA6 (Middle East/General)	2.5L	L5	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (Middle East/General)	2.5L	L5	2010 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (Middle East/General)	2.5L	L5	2010 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
MAZDA6 (Middle East/General)	2.5L	L5	2010 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6 (Middle East/General)	2.5L	L5	2010 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (Middle East/General)	2.5L	L5	2010 MY	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (Middle East/General)	2.5L	L5	2010 MY	LCM(Lighting Control Module)	√	√	√		
MAZDA6 (Middle East/General)	2.5L	L5	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (Middle East/General)	2.5L	L5	2010 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6 (Middle East/General)	2.5L	L5	2010 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (Middle East/General)	2.5L	L5	2010 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6 (North America/General)	3.7L	CA	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (North America/General)	3.7L	CA	2009 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (North America/General)	3.7L	CA	2009 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
MAZDA6 (North America/General)	3.7L	CA	2009 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6 (North America/General)	3.7L	CA	2009 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (North America/General)	3.7L	CA	2009 MY	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (North America/General)	3.7L	CA	2009 MY	LCM(Lighting Control Module)	√	√	√		
MAZDA6 (North America/General)	3.7L	CA	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
MAZDA6 (North America/General)	3.7L	CA	2009 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6 (North America/General)	3.7L	CA	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (North America/General)	3.7L	CA	2009 MY	TCM(Transmission Control Module)	√	√	√	√	SP0037
MAZDA6 (North America/General)	3.7L	CA	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (North America/General)	3.7L	CA	2010 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (North America/General)	3.7L	CA	2010 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA6 (North America/General)	3.7L	CA	2010 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6 (North America/General)	3.7L	CA	2010 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	
MAZDA6 (North America/General)	3.7L	CA	2010 MY	IC(Instrument Cluster)	√	√	√	√	
MAZDA6 (North America/General)	3.7L	CA	2010 MY	LCM(Lighting Control Module)	√	√	√		
MAZDA6 (North America/General)	3.7L	CA	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (North America/General)	3.7L	CA	2010 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6 (North America/General)	3.7L	CA	2010 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA6 (North America/General)	3.7L	CA	2010 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6 (North America/General)	2.5L	L5	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (North America/General)	2.5L	L5	2009 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (North America/General)	2.5L	L5	2009 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
MAZDA6 (North America/General)	2.5L	L5	2009 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	

MAZDA6 (North America/General)	2.5L	L5	2009 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (North America/General)	2.5L	L5	2009 MY	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (North America/General)	2.5L	L5	2009 MY	LCM(Lighting Control Module)	√	√	√		
MAZDA6 (North America/General)	2.5L	L5	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (North America/General)	2.5L	L5	2009 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6 (North America/General)	2.5L	L5	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6 (North America/General)	2.5L	L5	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6 (North America/General)	2.5L	L5	2010 MY	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√		
MAZDA6 (North America/General)	2.5L	L5	2010 MY	BSML(Left Blind Spot Monitoring)	√	√	√	√	SP0032
MAZDA6 (North America/General)	2.5L	L5	2010 MY	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6 (North America/General)	2.5L	L5	2010 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
MAZDA6 (North America/General)	2.5L	L5	2010 MY	IC(Instrument Cluster)	√	√	√	√	SP0097
MAZDA6 (North America/General)	2.5L	L5	2010 MY	LCM(Lighting Control Module)	√	√	√		
MAZDA6 (North America/General)	2.5L	L5	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6 (North America/General)	2.5L	L5	2010 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6 (North America/General)	2.5L	L5	2010 MY	RKE(Remote Keyless Entry)	√	√	√	√	SP0034
MAZDA6(North America/General)	2.3L	L3	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0088
MAZDA6(North America/General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6(North America/General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6(North America/General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0088
MAZDA6(North America/General)	2.3L	L3	2004 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	2.3L	L3	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2004 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6(North America/General)	2.3L	L3	2004 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0088
MAZDA6(North America/General)	3.0L	AJ	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6(North America/General)	3.0L	AJ	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6(North America/General)	2.3L	L3	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2007 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6(North America/General)	2.3L	L3	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2008 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2008 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	2008 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2008 MY	RCM(Restraint Control Module)	√	√	√		SP0091

MAZDA6(North America/General)	3.0L	AJ	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2008 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	4X4(4X4 Control Module)	√	√			
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0088
MAZDA6(North America/General)	3.0L	AJ	2004 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2004 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	2004 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0088
MAZDA6(North America/General)	2.3L	L3	2005 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2005 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6(North America/General)	2.3L	L3	2005 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0088
MAZDA6(North America/General)	2.3L	L3	2003 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2003 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6(North America/General)	2.3L	L3	2003 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	Other	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0088
MAZDA6(North America/General)	3.0L	AJ	Other	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0088
MAZDA6(North America/General)	3.0L	AJ	2007 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2007 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6(North America/General)	3.0L	AJ	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	4X4(4X4 Control Module)	√	√			
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0088
MAZDA6(North America/General)	3.0L	AJ	2005 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	

MAZDA6(North America/General)	3.0L	AJ	2005 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6(North America/General)	3.0L	AJ	2005 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2003 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	3.0L	AJ	2003 MY	RCM(Restraint Control Module)	√	√	√		
MAZDA6(North America/General)	3.0L	AJ	2003 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2008 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2008 MY	GEM(Generic Electronic Module)	√	√	√		
MAZDA6(North America/General)	2.3L	L3	2008 MY	IC(Instrument Cluster)	√	√	√		
MAZDA6(North America/General)	2.3L	L3	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2008 MY	RCM(Restraint Control Module)	√	√	√		SP0091
MAZDA6(North America/General)	2.3L	L3	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6(North America/General)	2.3L	L3	2008 MY	TPM(Tire Pressure Monitor)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	4X4(4X4 Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	AM(Amplifier Module)	√	√		√	
MAZDA6/ ATENZA	2.5L	PY	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA6/ ATENZA	2.5L	PY	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	DCM(Data Communication Module)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	F BCM(Body Control Module - Front)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY	Other	HUD(Head Up Display)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA6/ ATENZA	2.5L	PY	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	R BCM(Rear Body Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY	Other	SSU(Smart Start Unit)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.2L	SH	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.2L	SH	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MAZDA6/ ATENZA	2.2L	SH	Other	AM(Amplifier Module)	√	√		√	
MAZDA6/ ATENZA	2.2L	SH	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	

MAZDA6/ ATENZA	2.2L	SH	Other	BVML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ ATENZA	2.2L	SH	Other	BVMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA6/ ATENZA	2.2L	SH	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
MAZDA6/ ATENZA	2.2L	SH	Other	DCM(Data Communication Module)	√	√	√		
MAZDA6/ ATENZA	2.2L	SH	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA6/ ATENZA	2.2L	SH	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
MAZDA6/ ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA6/ ATENZA	2.2L	SH	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA6/ ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA6/ ATENZA	2.2L	SH	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
MAZDA6/ ATENZA	2.2L	SH	Other	HUD(Head Up Display)	√	√	√		
MAZDA6/ ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA6/ ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA6/ ATENZA	2.2L	SH	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA6/ ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA6/ ATENZA	2.2L	SH	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA6/ ATENZA	2.2L	SH	Other	SSU(Smart Start Unit)	√	√	√	√	
MAZDA6/ ATENZA	2.2L	SH	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.0L	PE	Other	4X4(4X4 Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.0L	PE	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MAZDA6/ ATENZA	2.0L	PE	Other	AM(Amplifier Module)	√	√		√	
MAZDA6/ ATENZA	2.0L	PE	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA6/ ATENZA	2.0L	PE	Other	BVML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ ATENZA	2.0L	PE	Other	BVMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA6/ ATENZA	2.0L	PE	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
MAZDA6/ ATENZA	2.0L	PE	Other	DCM(Data Communication Module)	√	√	√		
MAZDA6/ ATENZA	2.0L	PE	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA6/ ATENZA	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
MAZDA6/ ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA6/ ATENZA	2.0L	PE	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA6/ ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA6/ ATENZA	2.0L	PE	Other	F_BCM(Body Control Module - Front)	√	√	√	√	
MAZDA6/ ATENZA	2.0L	PE	Other	HUD(Head Up Display)	√	√	√		
MAZDA6/ ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA6/ ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA6/ ATENZA	2.0L	PE	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA6/ ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)	√	√	√		
MAZDA6/ ATENZA	2.0L	PE	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA6/ ATENZA	2.0L	PE	Other	SSU(Smart Start Unit)	√	√	√	√	
MAZDA6/ ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY T	Other	4X4(4X4 Control Module)	√	√	√	√	

MAZDA6/ ATENZA	2.5L	PY T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MAZDA6/ ATENZA	2.5L	PY T	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY T	Other	AM(Amplifier Module)	√	√			
MAZDA6/ ATENZA	2.5L	PY T	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY T	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY T	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY T	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA6/ ATENZA	2.5L	PY T	Other	DCDC(DC To DC Converter Control Module)	√	√			
MAZDA6/ ATENZA	2.5L	PY T	Other	DCM(Data Communication Module)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY T	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY T	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA6/ ATENZA	2.5L	PY T	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY T	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY T	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY T	Other	F BCM(Body Control Module - Front)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY T	Other	HUD(Head Up Display)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY T	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY T	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA6/ ATENZA	2.5L	PY T	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY T	Other	RCM(Restraint Control Module)	√	√	√		SP0072
MAZDA6/ ATENZA	2.5L	PY T	Other	R BCM(Rear Body Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY T	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA6/ ATENZA	2.5L	PY T	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA6/ ATENZA	2.5L	PY T	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6/ ATENZA	2.5L	PY T	Other	VMC(View Monitor Camera)	√	√	√		
MAZDA6/ATENZA	2.0L	PE	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012,SP0096
MAZDA6/ATENZA	2.0L	PE	Other	ABS(Antilock Braking System)	√	√	√	√	
MAZDA6/ATENZA	2.0L	PE	Other	ACU(Audio Control Unit)	√	√			
MAZDA6/ATENZA	2.0L	PE	Other	AFS(Adaptive Front Lighting System)	√	√	√		
MAZDA6/ATENZA	2.0L	PE	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA6/ATENZA	2.0L	PE	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA6/ATENZA	2.0L	PE	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ATENZA	2.0L	PE	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ATENZA	2.0L	PE	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA6/ATENZA	2.0L	PE	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA6/ATENZA	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA6/ATENZA	2.0L	PE	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA6/ATENZA	2.0L	PE	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA6/ATENZA	2.0L	PE	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA6/ATENZA	2.0L	PE	Other	F BCM(Body Control Module - Front)	√	√	√	√	
MAZDA6/ATENZA	2.0L	PE	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA6/ATENZA	2.0L	PE	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA6/ATENZA	2.0L	PE	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA6/ATENZA	2.0L	PE	Other	RCM(Restraint Control Module)	√	√	√		SP0072
MAZDA6/ATENZA	2.0L	PE	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA6/ATENZA	2.0L	PE	Other	R BCM(Rear Body Control Module)	√	√	√	√	

MAZDA6/ATENZA	2.0L	PE	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA6/ATENZA	2.0L	PE	Other	SCBS(Smart City Brake Support)	√	√	√		
MAZDA6/ATENZA	2.0L	PE	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA6/ATENZA	2.0L	PE	Other	TCM(Transmission Control Module)	√	√	√	√	
MAZDA6/ATENZA	2.2L	SH	Other	4X4(4X4 Control Module)	√	√	√	√	
MAZDA6/ATENZA	2.2L	SH	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		SP0012,SP0096
MAZDA6/ATENZA	2.2L	SH	Other	ABS(Antilock Braking System)	√	√	√	√	
MAZDA6/ATENZA	2.2L	SH	Other	ACU(Audio Control Unit)	√	√			
MAZDA6/ATENZA	2.2L	SH	Other	AFS(Adaptive Front Lighting System)	√	√	√		
MAZDA6/ATENZA	2.2L	SH	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA6/ATENZA	2.2L	SH	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA6/ATENZA	2.2L	SH	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ATENZA	2.2L	SH	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ATENZA	2.2L	SH	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA6/ATENZA	2.2L	SH	Other	DCDC(DC To DC Converter Control Module)	√	√	√		
MAZDA6/ATENZA	2.2L	SH	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA6/ATENZA	2.2L	SH	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA6/ATENZA	2.2L	SH	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA6/ATENZA	2.2L	SH	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA6/ATENZA	2.2L	SH	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA6/ATENZA	2.2L	SH	Other	F BCM(Body Control Module - Front)	√	√	√	√	
MAZDA6/ATENZA	2.2L	SH	Other	IC(Instrument Cluster)	√	√	√	√	
MAZDA6/ATENZA	2.2L	SH	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086,SP0089,SP0094
MAZDA6/ATENZA	2.2L	SH	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA6/ATENZA	2.2L	SH	Other	RCM(Restraint Control Module)	√	√	√		SP0072
MAZDA6/ATENZA	2.2L	SH	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA6/ATENZA	2.2L	SH	Other	R BCM(Rear Body Control Module)	√	√	√	√	
MAZDA6/ATENZA	2.2L	SH	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA6/ATENZA	2.2L	SH	Other	SCBS(Smart City Brake Support)	√	√	√		
MAZDA6/ATENZA	2.2L	SH	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA6/ATENZA	2.5L	PY	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		SP0012,SP0096
MAZDA6/ATENZA	2.5L	PY	Other	ABS(Antilock Braking System)	√	√	√	√	
MAZDA6/ATENZA	2.5L	PY	Other	ACU(Audio Control Unit)	√	√			
MAZDA6/ATENZA	2.5L	PY	Other	AFS(Adaptive Front Lighting System)	√	√	√		
MAZDA6/ATENZA	2.5L	PY	Other	AM(Amplifier Module)	√	√	√	√	
MAZDA6/ATENZA	2.5L	PY	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MAZDA6/ATENZA	2.5L	PY	Other	BSML(Left Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ATENZA	2.5L	PY	Other	BSMR(Right Blind Spot Monitoring)	√	√	√	√	
MAZDA6/ATENZA	2.5L	PY	Other	CMU(Connectivity Master Unit)	√	√			
MAZDA6/ATENZA	2.5L	PY	Other	DSM(Driver Seat Module)	√	√	√		
MAZDA6/ATENZA	2.5L	PY	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		SP0016
MAZDA6/ATENZA	2.5L	PY	Other	EPB(Electric Parking Brake)	√	√	√		
MAZDA6/ATENZA	2.5L	PY	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MAZDA6/ATENZA	2.5L	PY	Other	FSC(Forward Sensing Camera)	√	√	√		
MAZDA6/ATENZA	2.5L	PY	Other	F BCM(Body Control Module - Front)	√	√	√	√	
MAZDA6/ATENZA	2.5L	PY	Other	IC(Instrument Cluster)	√	√	√	√	

MAZDA6/ATENZA	2.5L	PY	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0084,SP0086
MAZDA6/ATENZA	2.5L	PY	Other	PSM#1(Parking Sensor Module)	√	√	√		
MAZDA6/ATENZA	2.5L	PY	Other	RCM(Restraint Control Module)	√	√	√		SP0072
MAZDA6/ATENZA	2.5L	PY	Other	RVM(Rear Vehicle Monitoring)	√	√	√	√	
MAZDA6/ATENZA	2.5L	PY	Other	R_BCM(Rear Body Control Module)	√	√	√	√	
MAZDA6/ATENZA	2.5L	PY	Other	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)	√	√	√		
MAZDA6/ATENZA	2.5L	PY	Other	SCBS(Smart City Brake Support)	√	√	√		
MAZDA6/ATENZA	2.5L	PY	Other	SSU(Smart Start Unit)	√	√	√	√	SP0034
MAZDA6/ATENZA	2.5L	PY	Other	TCM(Transmission Control Module)	√	√	√	√	
Millenia	2.5L	KL	1997 MY	A/C(Air Conditioning)	√	√			
Millenia	2.5L	KL	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
Millenia	2.5L	KL	1997 MY	CCM(Cruise Control)	√	√			
Millenia	2.5L	KL	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
Millenia	2.3L	KJ	1999 MY	A/C(Air Conditioning)	√	√			
Millenia	2.3L	KJ	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
Millenia	2.3L	KJ	1999 MY	CCM(Cruise Control)	√	√			
Millenia	2.3L	KJ	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
Millenia	2.3L	KJ	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Millenia	2.3L	KJ	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
Millenia	2.3L	KJ	2000 MY	CCM(Cruise Control)	√	√			
Millenia	2.3L	KJ	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
Millenia	2.5L	KL	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Millenia	2.5L	KL	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
Millenia	2.5L	KL	2000 MY	CCM(Cruise Control)	√	√			
Millenia	2.5L	KL	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
Millenia	2.5L	KL	1998 MY	A/C(Air Conditioning)	√	√			
Millenia	2.5L	KL	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
Millenia	2.5L	KL	1998 MY	CCM(Cruise Control)	√	√			
Millenia	2.5L	KL	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
Millenia	2.5L	KL	2001 MY	A/C(Air Conditioning)	√	√			
Millenia	2.5L	KL	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Millenia	2.5L	KL	2001 MY	CCM(Cruise Control)	√	√			
Millenia	2.5L	KL	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
Millenia	2.3L	KJ	1998 MY	A/C(Air Conditioning)	√	√			
Millenia	2.3L	KJ	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
Millenia	2.3L	KJ	1998 MY	CCM(Cruise Control)	√	√			
Millenia	2.3L	KJ	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
Millenia	2.3L	KJ	2001 MY	A/C(Air Conditioning)	√	√			
Millenia	2.3L	KJ	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Millenia	2.3L	KJ	2001 MY	CCM(Cruise Control)	√	√			
Millenia	2.3L	KJ	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
Millenia	2.3L	KJ	1997 MY	A/C(Air Conditioning)	√	√			

Millenia	2.3L	KJ	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
Millenia	2.3L	KJ	1997 MY	CCM(Cruise Control)	√	√			
Millenia	2.3L	KJ	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
Millenia	2.5L	KL	1999 MY	A/C(Air Conditioning)	√	√			
Millenia	2.5L	KL	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
Millenia	2.5L	KL	1999 MY	CCM(Cruise Control)	√	√			
Millenia	2.5L	KL	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
MILLENNIA/EUNOS 800	2.3L	KJ	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MILLENNIA/EUNOS 800	2.3L	KJ	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MILLENNIA/EUNOS 800	2.3L	KJ	1998 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
MILLENNIA/EUNOS 800	2.3L	KJ	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MILLENNIA/EUNOS 800	2.3L	KJ	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
MILLENNIA/EUNOS 800	2.5L	KL	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MILLENNIA/EUNOS 800	2.5L	KL	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
MILLENNIA/EUNOS 800	2.0L	KF	1998 MY	A/C(Air Conditioning)	√	√			
MILLENNIA/EUNOS 800	2.0L	KF	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MILLENNIA/EUNOS 800	2.0L	KF	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MILLENNIA/EUNOS 800	2.0L	KF	1998 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
MILLENNIA/EUNOS 800	2.0L	KF	2000 MY	A/C(Air Conditioning)	√	√			
MILLENNIA/EUNOS 800	2.0L	KF	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MILLENNIA/EUNOS 800	2.0L	KF	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MILLENNIA/EUNOS 800	2.0L	KF	2000 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
MILLENNIA/EUNOS 800	2.3L	KJ	2000 MY	4WS(4 Wheel Steering)	√	√			
MILLENNIA/EUNOS 800	2.3L	KJ	2000 MY	A/C(Air Conditioning)	√	√			
MILLENNIA/EUNOS 800	2.3L	KJ	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MILLENNIA/EUNOS 800	2.3L	KJ	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MILLENNIA/EUNOS 800	2.3L	KJ	2000 MY	CCM(Cruise Control)	√	√			
MILLENNIA/EUNOS 800	2.3L	KJ	2000 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
MILLENNIA/EUNOS 800	2.5L	KL	2000 MY	4WS(4 Wheel Steering)	√	√			
MILLENNIA/EUNOS 800	2.5L	KL	2000 MY	A/C(Air Conditioning)	√	√			
MILLENNIA/EUNOS 800	2.5L	KL	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MILLENNIA/EUNOS 800	2.5L	KL	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MILLENNIA/EUNOS 800	2.5L	KL	2000 MY	CCM(Cruise Control)	√	√			
MILLENNIA/EUNOS 800	2.5L	KL	2000 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
MILLENNIA/EUNOS 800	2.5L	KL	2002 MY	A/C(Air Conditioning)	√	√			
MILLENNIA/EUNOS 800	2.5L	KL	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MILLENNIA/EUNOS 800	2.5L	KL	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	

MILLENNIA/EUNOS 800	2.5L	KL	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MILLENNIA/EUNOS 800	2.5L	KL	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MILLENNIA/EUNOS 800	2.5L	KL	1998 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
MPV (Europe/General)	2.0L	RF T	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (Europe/General)	2.0L	RF T	2003 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√	√	
MPV (Europe/General)	2.0L	RF T	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (Europe/General)	3.0L	JE	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MPV (Europe/General)	3.0L	JE	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
MPV (Europe/General)	2.0L	FS	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (Europe/General)	2.0L	FS	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (Europe/General)	2.0L	FS	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (Europe/General)	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (Europe/General)	2.5L	GY	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (Europe/General)	2.5L	GY	1999 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (Europe/General)	2.5L	GY	1999 MY	CCM(Cruise Control)	√	√			
MPV (Europe/General)	2.5L	GY	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (Europe/General)	2.5L	GY	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (Europe/General)	2.3L	L3	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (Europe/General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (Europe/General)	2.0L	RF T	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (Europe/General)	2.0L	RF T	2002 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√	√	
MPV (Europe/General)	2.0L	RF T	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (Europe/General)	3.0L	AJ	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (Europe/General)	3.0L	AJ	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (Europe/General)	3.0L	AJ	2002 MY	TCM(Transmission Control Module)	√	√	√	√	
MPV (Europe/General)	2.0L	RF T	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (Europe/General)	2.0L	RF T	2004 MY	FFH(Fuel Fired Coolant Heating Module)	√	√	√	√	
MPV (Europe/General)	2.0L	RF T	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (Europe/General)	2.5L	GY	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (Europe/General)	2.5L	GY	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (Europe/General)	2.5L	GY	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (Europe/General)	2.5L	GY	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (JPN/General)	3.0L	AJ	2004 MY	A/C(Air Conditioning)	√	√			
MPV (JPN/General)	3.0L	AJ	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (JPN/General)	3.0L	AJ	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (JPN/General)	3.0L	AJ	2004 MY	TCM(Transmission Control Module)	√	√	√	√	
MPV (JPN/General)	2.3L	L3	2002 MY	A/C(Air Conditioning)	√	√			

MPV (JPN/General)	2.3L	L3	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (JPN/General)	2.3L	L3	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (JPN/General)	2.3L	L3	2004 MY	A/C(Air Conditioning)	√	√			
MPV (JPN/General)	2.3L	L3	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (JPN/General)	2.3L	L3	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (JPN/General)	3.0L	AJ	2002 MY	A/C(Air Conditioning)	√	√			
MPV (JPN/General)	3.0L	AJ	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (JPN/General)	3.0L	AJ	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (JPN/General)	3.0L	AJ	2002 MY	TCM(Transmission Control Module)	√	√	√	√	
MPV (JPN/General)	2.0L	FS	1999 MY	A/C(Air Conditioning)	√	√			
MPV (JPN/General)	2.0L	FS	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (JPN/General)	2.0L	FS	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (JPN/General)	2.3L	L3	2003 MY	A/C(Air Conditioning)	√	√			
MPV (JPN/General)	2.3L	L3	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (JPN/General)	2.3L	L3	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (JPN/General)	2.5L	GY	1999 MY	A/C(Air Conditioning)	√	√			
MPV (JPN/General)	2.5L	GY	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (JPN/General)	2.5L	GY	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2002 MY	CCM(Cruise Control)	√	√			
MPV (North America/General)	3.0L	AJ	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2002 MY	TCM(Transmission Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2005 MY	A/C(Air Conditioning)	√	√			
MPV (North America/General)	3.0L	AJ	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2005 MY	CCM(Cruise Control)	√	√			
MPV (North America/General)	3.0L	AJ	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2005 MY	RCM(Restraint Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2005 MY	TCM(Transmission Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	JE	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MPV (North America/General)	3.0L	JE	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	JE	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MPV (North America/General)	3.0L	JE	1997 MY	CCM(Cruise Control)	√	√			
MPV (North America/General)	3.0L	JE	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2003 MY	CCM(Cruise Control)	√	√			
MPV (North America/General)	3.0L	AJ	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2003 MY	TCM(Transmission Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	JE	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MPV (North America/General)	3.0L	JE	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (North America/General)	2.5L	GY	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	

MPV (North America/General)	2.5L	GY	2001 MY	CCM(Cruise Control)	√	√			
MPV (North America/General)	2.5L	GY	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2004 MY	CCM(Cruise Control)	√	√			
MPV (North America/General)	3.0L	AJ	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2004 MY	RCM(Restraint Control Module)	√	√	√		
MPV (North America/General)	3.0L	AJ	2004 MY	TCM(Transmission Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2006 MY	A/C(Air Conditioning)	√	√			
MPV (North America/General)	3.0L	AJ	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2006 MY	CCM(Cruise Control)	√	√			
MPV (North America/General)	3.0L	AJ	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MPV (North America/General)	3.0L	AJ	2006 MY	RCM(Restraint Control Module)	√	√	√		
MPV (North America/General)	3.0L	AJ	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
MPV (North America/General)	2.5L	GY	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MPV (North America/General)	2.5L	GY	2000 MY	CCM(Cruise Control)	√	√			
MPV (North America/General)	2.5L	GY	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	4X4(4X4 Control Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	AM(Amplifier Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	GEM(Generic Electronic Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	HCM(Headlamp Control Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	IC(Instrument Cluster)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	ICCM(Intelligent Cruise Control Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	LCM(Lighting Control Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	LPSDM(Power Sliding Door Module - Left)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	LTM(Liftgate/Trunk Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	RCM(Restraint Control Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	RPSDM(Right Power Sliding Door Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	4X4(4X4 Control Module)	√	√			

Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	AM(Amplifier Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	GEM(Generic Electronic Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	HCM(Headlamp Control Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	IC(Instrument Cluster)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	ICCM(Intelligent Cruise Control Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	LCM(Lighting Control Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	LPSDM(Power Sliding Door Module - Left)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	LTM(Liftgate/Trunk Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	PCM(Powertrain Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	RCM(Restraint Control Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	RKE(Remote Keyless Entry)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	RKE(Remote Keyless Entry)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	RPSDM(Right Power Sliding Door Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3	2013 MY	TCM(Transmission Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	AM(Amplifier Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	GEM(Generic Electronic Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	HCM(Headlamp Control Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	IC(Instrument Cluster)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	ICCM(Intelligent Cruise Control Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	LCM(Lighting Control Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	LPSDM(Power Sliding Door Module - Left)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	LTM(Liftgate/Trunk Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	PCM(Powertrain Control Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	PCM(Powertrain Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	RCM(Restraint Control Module)	√	√	√		

Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	RKE(Remote Keyless Entry)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	RKE(Remote Keyless Entry)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	RPSDM(Right Power Sliding Door Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.5L	L5	2012 MY	TCM(Transmission Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	4X4(4X4 Control Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	AM(Amplifier Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	GEM(Generic Electronic Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	HCM(Headlamp Control Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	IC(Instrument Cluster)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	ICCM(Intelligent Cruise Control Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	LCM(Lighting Control Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	LPSDM(Power Sliding Door Module - Left)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	LTM(Liftgate/Trunk Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	RCM(Restraint Control Module)	√	√	√		
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	RPSDM(Right Power Sliding Door Module)	√	√			
Multi-Purpose Vehicle (MPV)Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
MX-5	1.6L	B6	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5	1.6L	B6	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5	1.8L	BP	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5	1.8L	BP	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5	1.6L	B6	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MX-5	1.6L	B6	1997 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
MX-5	1.8L	BP	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
MX-5	1.8L	BP	1997 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
MX-5 (Europe/General Specifications)	1.8L	L8	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MX-5 (Europe/General Specifications)	1.8L	L8	2005 MY	DHS(Deployable Hood System)	√	√	√		
MX-5 (Europe/General Specifications)	1.8L	L8	2005 MY	IC(Instrument Cluster)	√	√	√	√	

MX-5 (Europe/General Specifications)	1.8L	L8	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 (Europe/General Specifications)	1.8L	L8	2005 MY	RCM(Restraint Control Module)	√	√	√		
MX-5 (Europe/General Specifications)	1.8L	L8	2005 MY	RHT(Retractable Hard Top)	√	√	√		
MX-5 (Europe/General Specifications)	1.8L	L8	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MX-5 (Europe/General Specifications)	1.8L	L8	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MX-5 (Europe/General Specifications)	1.8L	L8	2008 MY	DHS(Deployable Hood System)	√	√	√		
MX-5 (Europe/General Specifications)	1.8L	L8	2008 MY	IC(Instrument Cluster)	√	√	√	√	
MX-5 (Europe/General Specifications)	1.8L	L8	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 (Europe/General Specifications)	1.8L	L8	2008 MY	RCM(Restraint Control Module)	√	√	√		
MX-5 (Europe/General Specifications)	1.8L	L8	2008 MY	RHT(Retractable Hard Top)	√	√	√		
MX-5 (Europe/General Specifications)	1.8L	L8	2008 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MX-5 (Europe/General Specifications)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MX-5 (Europe/General Specifications)	2.0L	LF	2008 MY	DHS(Deployable Hood System)	√	√	√		
MX-5 (Europe/General Specifications)	2.0L	LF	2008 MY	IC(Instrument Cluster)	√	√	√	√	
MX-5 (Europe/General Specifications)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 (Europe/General Specifications)	2.0L	LF	2008 MY	RCM(Restraint Control Module)	√	√	√		
MX-5 (Europe/General Specifications)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	√	√	√		
MX-5 (Europe/General Specifications)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MX-5 (Europe/General Specifications)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
MX-5 (Europe/General Specifications)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5 (Europe/General Specifications)	2.0L	LF	2005 MY	DHS(Deployable Hood System)	√	√	√		
MX-5 (Europe/General Specifications)	2.0L	LF	2005 MY	IC(Instrument Cluster)	√	√	√	√	
MX-5 (Europe/General Specifications)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 (Europe/General Specifications)	2.0L	LF	2005 MY	RCM(Restraint Control Module)	√	√	√		
MX-5 (Europe/General Specifications)	2.0L	LF	2005 MY	RHT(Retractable Hard Top)	√	√	√		
MX-5 (Europe/General Specifications)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MX-5 (Europe/General Specifications)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	Other	IC(Instrument Cluster)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	Other	PCM(Powertrain Control Module)	√	√	√		
MX-5 (North America/General Specifications)	2.0L	LF	Other	RCM(Restraint Control Module)	√	√	√		
MX-5 (North America/General Specifications)	2.0L	LF	Other	RKE(Remote Keyless Entry)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	Other	TCM(Transmission Control Module)	√	√	√		
MX-5 (North America/General Specifications)	2.0L	LF	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MX-5 (North America/General Specifications)	2.0L	LF	2009 MY	IC(Instrument Cluster)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2009 MY	RCM(Restraint Control Module)	√	√	√		
MX-5 (North America/General Specifications)	2.0L	LF	2009 MY	RHT(Retractable Hard Top)	√	√	√		
MX-5 (North America/General Specifications)	2.0L	LF	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2009 MY	TCM(Transmission Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MX-5 (North America/General Specifications)	2.0L	LF	2007 MY	IC(Instrument Cluster)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2007 MY	RCM(Restraint Control Module)	√	√	√		
MX-5 (North America/General Specifications)	2.0L	LF	2007 MY	RHT(Retractable Hard Top)	√	√	√		
MX-5 (North America/General Specifications)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	

MX-5 (North America/General Specifications)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
MX-5 (North America/General Specifications)	2.0L	LF	2010 MY	IC(Instrument Cluster)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2010 MY	RCM(Restraint Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2010 MY	RHT(Retractable Hard Top)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2010 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2010 MY	TCM(Transmission Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2006 MY	IC(Instrument Cluster)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2006 MY	RCM(Restraint Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2008 MY	IC(Instrument Cluster)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2008 MY	RCM(Restraint Control Module)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	√	√	√	√	
MX-5 (North America/General Specifications)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2001 MY	CCM(Cruise Control)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	1999 MY	CCM(Cruise Control)	√	√	√	√	
MX-5 MIATA	1.8L	BP	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	Barometric Pressure (BP) Turbo	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	Barometric Pressure (BP) Turbo	2004 MY	CCM(Cruise Control)	√	√	√	√	
MX-5 MIATA	1.8L	Barometric Pressure (BP) Turbo	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2004 MY	CCM(Cruise Control)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2000 MY	CCM(Cruise Control)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	1997 MY	CCM(Cruise Control)	√	√	√	√	
MX-5 MIATA	1.8L	BP	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2003 MY	CCM(Cruise Control)	√	√	√	√	

MX-5 MIATA	1.8L	BP	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
MX-5 MIATA	1.8L	BP	2005 MY	CCM(Cruise Control)	√	√			
MX-5 MIATA	1.8L	BP	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
MX-5/ROADSTER	2.0L	PE	Other	ABS(Antilock Braking System)	√	√	√	√	
MX-5/ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MX-5/ROADSTER	2.0L	PE	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MX-5/ROADSTER	2.0L	PE	Other	AM(Amplifier Module)	√	√			
MX-5/ROADSTER	2.0L	PE	Other	BCM#1(Body Control Module)	√	√	√	√	
MX-5/ROADSTER	2.0L	PE	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MX-5/ROADSTER	2.0L	PE	Other	CMU(Connectivity Master Unit)	√	√			
MX-5/ROADSTER	2.0L	PE	Other	DCDC(DC To DC Converter Control Module)	√	√	√	√	
MX-5/ROADSTER	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
MX-5/ROADSTER	2.0L	PE	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MX-5/ROADSTER	2.0L	PE	Other	ESU(Electric Supply Unit)	√	√			
MX-5/ROADSTER	2.0L	PE	Other	EVP#1(Electrical Vacuum Pump)	√	√	√	√	
MX-5/ROADSTER	2.0L	PE	Other	FSC(Forward Sensing Camera)	√	√	√		
MX-5/ROADSTER	2.0L	PE	Other	FSC(Forward Sensing Camera)	√	√	√		
MX-5/ROADSTER	2.0L	PE	Other	IC(Instrument Cluster)	√	√	√	√	
MX-5/ROADSTER	2.0L	PE	Other	PCM(Powertrain Control Module)	√	√	√	√	
MX-5/ROADSTER	2.0L	PE	Other	PSM#1(Parking Sensor Module)	√	√	√		
MX-5/ROADSTER	2.0L	PE	Other	RCM(Restraint Control Module)	√	√	√		
MX-5/ROADSTER	2.0L	PE	Other	RHT(Retractable Hard Top)	√	√	√		
MX-5/ROADSTER	2.0L	PE	Other	SSU(Smart Start Unit)	√	√	√	√	
MX-5/ROADSTER	1.5L	P5	Other	ABS(Antilock Braking System)	√	√	√	√	
MX-5/ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MX-5/ROADSTER	1.5L	P5	Other	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)	√	√	√		
MX-5/ROADSTER	1.5L	P5	Other	AM(Amplifier Module)	√	√			
MX-5/ROADSTER	1.5L	P5	Other	BCM#1(Body Control Module)	√	√	√	√	
MX-5/ROADSTER	1.5L	P5	Other	BSM(Monitoring Of Blind Spot)	√	√	√	√	
MX-5/ROADSTER	1.5L	P5	Other	CMU(Connectivity Master Unit)	√	√			
MX-5/ROADSTER	1.5L	P5	Other	EATC(Electronic Automatic Temperature Control)	√	√	√		
MX-5/ROADSTER	1.5L	P5	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
MX-5/ROADSTER	1.5L	P5	Other	ESU(Electric Supply Unit)	√	√			
MX-5/ROADSTER	1.5L	P5	Other	EVP#1(Electrical Vacuum Pump)	√	√	√	√	
MX-5/ROADSTER	1.5L	P5	Other	FSC(Forward Sensing Camera)	√	√	√		
MX-5/ROADSTER	1.5L	P5	Other	FSC(Forward Sensing Camera)	√	√	√		
MX-5/ROADSTER	1.5L	P5	Other	IC(Instrument Cluster)	√	√	√	√	
MX-5/ROADSTER	1.5L	P5	Other	PCM(Powertrain Control Module)	√	√	√	√	
MX-5/ROADSTER	1.5L	P5	Other	PSM#1(Parking Sensor Module)	√	√	√		
MX-5/ROADSTER	1.5L	P5	Other	RCM(Restraint Control Module)	√	√	√		
MX-5/ROADSTER	1.5L	P5	Other	RHT(Retractable Hard Top)	√	√	√		
MX-5/ROADSTER	1.5L	P5	Other	SSU(Smart Start Unit)	√	√	√	√	
NONE	2.5L	L5	2012 MY	IC(Instrument Cluster)	√	√			
NONE	2.5L	L5	2012 MY	PCM(Powertrain Control Module)	√	√	√	√	

Premacy	1.8L	FP	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy	1.8L	FP	1999 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
Premacy	2.0L	RF T	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy	2.0L	RF T	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
Premacy	2.0L	RF T	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy	2.0L	RF T	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
Premacy	2.0L	FS	2001 MY	A/C(Air Conditioning)	√	√			
Premacy	2.0L	FS	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy	2.0L	FS	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
Premacy	2.0L	FS	2001 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
Premacy	1.8L	FP	2000 MY	A/C(Air Conditioning)	√	√			
Premacy	1.8L	FP	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy	1.8L	FP	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
Premacy	2.0L	RF T	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy	2.0L	RF T	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy	2.0L	RF T	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
Premacy	2.0L	RF T	2000 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
Premacy/IXION	1.8L	FP DE	1999 MY	A/C(Air Conditioning)	√	√			
Premacy/IXION	1.8L	FP DE	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/IXION	1.8L	FP DE	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
Premacy/IXION	1.8L	FP	1999 MY	A/C(Air Conditioning)	√	√			
Premacy/IXION	1.8L	FP	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/IXION	1.8L	FP	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
Premacy/IXION	2.0L	RF T	1999 MY	A/C(Air Conditioning)	√	√			
Premacy/IXION	2.0L	RF T	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
Premacy/IXION	2.0L	RF T	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
Premacy/IXION	1.8L	FP	2002 MY	A/C(Air Conditioning)	√	√			
Premacy/IXION	1.8L	FP	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/IXION	1.8L	FP	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
Premacy/IXION	2.0L	FS	2001 MY	A/C(Air Conditioning)	√	√			
Premacy/IXION	2.0L	FS	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/IXION	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
Premacy/MAZDA5	1.8L	L8	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/MAZDA5	1.8L	L8	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/MAZDA5	1.8L	L8	Other	ACU(Audio Control Unit)	√	√			
Premacy/MAZDA5	1.8L	L8	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	

Premacy/MAZDA5	1.8L	L8	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
Premacy/MAZDA5	1.8L	L8	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
Premacy/MAZDA5	1.8L	L8	Other	IC(Instrument Cluster)	√	√	√	√	
Premacy/MAZDA5	1.8L	L8	Other	LPSDM(Power Sliding Door Module - Left)	√	√	√		
Premacy/MAZDA5	1.8L	L8	Other	PCM(Powertrain Control Module)	√	√	√	√	
Premacy/MAZDA5	1.8L	L8	Other	RCM(Restraint Control Module)	√	√	√		
Premacy/MAZDA5	1.8L	L8	Other	RKE(Remote Keyless Entry)	√	√	√	√	
Premacy/MAZDA5	1.8L	L8	Other	RPSDM(Right Power Sliding Door Module)	√	√	√		
Premacy/MAZDA5	2.5L	L5	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/MAZDA5	2.5L	L5	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/MAZDA5	2.5L	L5	Other	ACU(Audio Control Unit)	√	√			
Premacy/MAZDA5	2.5L	L5	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
Premacy/MAZDA5	2.5L	L5	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
Premacy/MAZDA5	2.5L	L5	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
Premacy/MAZDA5	2.5L	L5	Other	IC(Instrument Cluster)	√	√	√	√	
Premacy/MAZDA5	2.5L	L5	Other	LPSDM(Power Sliding Door Module - Left)	√	√	√		
Premacy/MAZDA5	2.5L	L5	Other	PCM(Powertrain Control Module)	√	√	√	√	
Premacy/MAZDA5	2.5L	L5	Other	RCM(Restraint Control Module)	√	√	√		
Premacy/MAZDA5	2.5L	L5	Other	RKE(Remote Keyless Entry)	√	√	√	√	
Premacy/MAZDA5	2.5L	L5	Other	RPSDM(Right Power Sliding Door Module)	√	√	√		
Premacy/MAZDA5	2.5L	L5	Other	TCM(Transmission Control Module)	√	√	√	√	
Premacy/MAZDA5	1.6L	Y6	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/MAZDA5	1.6L	Y6	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/MAZDA5	1.6L	Y6	Other	ACU(Audio Control Unit)	√	√			
Premacy/MAZDA5	1.6L	Y6	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
Premacy/MAZDA5	1.6L	Y6	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
Premacy/MAZDA5	1.6L	Y6	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
Premacy/MAZDA5	1.6L	Y6	Other	IC(Instrument Cluster)	√	√	√	√	
Premacy/MAZDA5	1.6L	Y6	Other	LPSDM(Power Sliding Door Module - Left)	√	√	√		
Premacy/MAZDA5	1.6L	Y6	Other	PCM(Powertrain Control Module)	√	√	√	√	SP0038,SP0044,SP0055
Premacy/MAZDA5	1.6L	Y6	Other	RCM(Restraint Control Module)	√	√	√		
Premacy/MAZDA5	1.6L	Y6	Other	RKE(Remote Keyless Entry)	√	√	√	√	
Premacy/MAZDA5	1.6L	Y6	Other	RPSDM(Right Power Sliding Door Module)	√	√	√		
Premacy/MAZDA5	2.0L	LF	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/MAZDA5	2.0L	LF	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/MAZDA5	2.0L	LF	Other	ACU(Audio Control Unit)	√	√			
Premacy/MAZDA5	2.0L	LF	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
Premacy/MAZDA5	2.0L	LF	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
Premacy/MAZDA5	2.0L	LF	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
Premacy/MAZDA5	2.0L	LF	Other	IC(Instrument Cluster)	√	√	√	√	

Premacy/MAZDA5	2.0L	LF	Other	LPSDM(Power Sliding Door Module - Left)	√	√	√		
Premacy/MAZDA5	2.0L	LF	Other	PCM(Powertrain Control Module)	√	√	√	√	
Premacy/MAZDA5	2.0L	LF	Other	RCM(Restraint Control Module)	√	√	√		
Premacy/MAZDA5	2.0L	LF	Other	RKE(Remote Keyless Entry)	√	√	√	√	
Premacy/MAZDA5	2.0L	LF	Other	RPSDM(Right Power Sliding Door Module)	√	√	√		
Premacy/MAZDA5	2.0L	LF	Other	TCM(Transmission Control Module)	√	√	√	√	
Premacy/MAZDA5	2.0L	PE	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
Premacy/MAZDA5	2.0L	PE	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Premacy/MAZDA5	2.0L	PE	Other	ACU(Audio Control Unit)	√	√			
Premacy/MAZDA5	2.0L	PE	Other	BCM/GEM(Body Control Module/Generic Electronic Module)	√	√	√	√	
Premacy/MAZDA5	2.0L	PE	Other	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
Premacy/MAZDA5	2.0L	PE	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
Premacy/MAZDA5	2.0L	PE	Other	IC(Instrument Cluster)	√	√	√	√	
Premacy/MAZDA5	2.0L	PE	Other	LPSDM(Power Sliding Door Module - Left)	√	√	√		
Premacy/MAZDA5	2.0L	PE	Other	PCM(Powertrain Control Module)	√	√	√	√	
Premacy/MAZDA5	2.0L	PE	Other	RCM(Restraint Control Module)	√	√	√		
Premacy/MAZDA5	2.0L	PE	Other	RKE(Remote Keyless Entry)	√	√	√	√	
Premacy/MAZDA5	2.0L	PE	Other	RPSDM(Right Power Sliding Door Module)	√	√	√		
Premacy/MAZDA5	2.0L	PE	Other	TCM(Transmission Control Module)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2007 MY	4X4(4X4 Control Module)	√	√			
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2007 MY	GEM(Generic Electronic Module)	√	√	√		SP0017
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2007 MY	IC(Instrument Cluster)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2007 MY	LPSDM(Power Sliding Door Module - Left)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2007 MY	RCM(Restraint Control Module)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2007 MY	RPSDM(Right Power Sliding Door Module)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2005 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2005 MY	EPS(Electronic Controlled Power Steering)	√	√	√		

PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2005 MY	GEM(Generic Electronic Module)	√	√	√		SP0017
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2005 MY	IC(Instrument Cluster)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2005 MY	RCM(Restraint Control Module)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2005 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2005 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2005 MY	GEM(Generic Electronic Module)	√	√	√		SP0017
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2005 MY	IC(Instrument Cluster)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2005 MY	RCM(Restraint Control Module)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2007 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2007 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	SP0016
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2007 MY	GEM(Generic Electronic Module)	√	√	√		SP0017
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2007 MY	IC(Instrument Cluster)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2007 MY	LPSDM(Power Sliding Door Module - Left)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2007 MY	RCM(Restraint Control Module)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2007 MY	RPSDM(Right Power Sliding Door Module)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.3L	L3	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2006 MY	4X4(4X4 Control Module)	√	√			
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2006 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2006 MY	EATC(Electronic Automatic Temperature Control)	√	√	√	√	

PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2006 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2006 MY	GEM(Generic Electronic Module)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2006 MY	IC(Instrument Cluster)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2006 MY	LPSDM(Power Sliding Door Module - Left)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2006 MY	RCM(Restraint Control Module)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2006 MY	RPSDM(Right Power Sliding Door Module)	√	√	√		
PREMACY/MAZDA5 (Japan/General Specifications)	2.0L	LF	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
PROBE/MX-6	2.5L	KL	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROBE/MX-6	2.5L	KL	1997 MY	PCM(Powertrain Control Module)	√	√	√		
PROBE/MX-6	2.0L	Other	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
PROBE/MX-6	2.5L	KL	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROBE/MX-6	2.5L	KL	1996 MY	PCM(Powertrain Control Module)	√	√	√		
PROBE/MX-6	2.0L	Other	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
PROCEED	2.5L	G5	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROCEED	2.6L	G6	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROCEED	2.6L	G6	1996 MY	TCM(Transmission Control Module)	√	√			
PROTEGE	1.6L	ZM	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
PROTEGE	1.6L	ZM	2001 MY	CCM(Cruise Control)	√	√			
PROTEGE	1.6L	ZM	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROTEGE	1.8L	FP	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
PROTEGE	1.8L	FP	1999 MY	CCM(Cruise Control)	√	√			
PROTEGE	1.8L	FP	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROTEGE	1.8L	BP	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
PROTEGE	1.8L	BP	1998 MY	CCM(Cruise Control)	√	√			
PROTEGE	1.8L	BP	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROTEGE	1.8L	FP	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
PROTEGE	1.8L	FP	2000 MY	CCM(Cruise Control)	√	√			
PROTEGE	1.8L	FP	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROTEGE	2.0L	FS	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
PROTEGE	2.0L	FS	2002 MY	CCM(Cruise Control)	√	√			
PROTEGE	2.0L	FS	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROTEGE	1.5L	Z5	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
PROTEGE	1.5L	Z5	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROTEGE	1.5L	Z5	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
PROTEGE	1.5L	Z5	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	

PROTEGE	2.0L	FS	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
PROTEGE	2.0L	FS	2001 MY	CCM(Cruise Control)	√	√			
PROTEGE	2.0L	FS	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROTEGE	1.6L	ZM	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
PROTEGE	1.6L	ZM	2000 MY	CCM(Cruise Control)	√	√			
PROTEGE	1.6L	ZM	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROTEGE	2.0L	FS T	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
PROTEGE	2.0L	FS T	2003 MY	CCM(Cruise Control)	√	√			
PROTEGE	2.0L	FS T	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROTEGE	2.0L	FS	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
PROTEGE	2.0L	FS	2003 MY	CCM(Cruise Control)	√	√			
PROTEGE	2.0L	FS	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROTEGE	1.8L	BP	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
PROTEGE	1.8L	BP	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
PROTEGE	1.6L	ZM	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
PROTEGE	1.6L	ZM	1999 MY	CCM(Cruise Control)	√	√			
PROTEGE	1.6L	ZM	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Courier/Mazda B Series /Bravo	4.0L	V6 SOHC	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Courier/Mazda B Series /Bravo	4.0L	V6 SOHC	2003 MY	ESOF(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Courier/Mazda B Series /Bravo	4.0L	V6 SOHC	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2007 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2007 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2007 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2007 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2007 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.5L	Other	2001 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.5L	Other	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.5L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.5L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.5L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.5L	Other	2001 MY	PATS(Passive Anti Theft System (PATS))	√	√		√	
Ranger/Mazda B-Series/Courier	2.5L	Other	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.5L	Other	2001 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.5L	Other	2001 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1993 MY	PCM(Powertrain Control Module (PCM))	√	√			
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2005 MY	4X4(4X4 Control Module)	√	√	√	√	

Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2005 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2005 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2005 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2005 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2005 MY	RCM(Restraint Control Module)	√	√	√	√	SP0014
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2005 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	OHC	1997 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	OHC	1997 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	OHC	1997 MY	IAB(Integrated Air Bag Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	OHC	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	2.3L	OHC	1997 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1996 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1996 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1996 MY	IAB(Integrated Air Bag Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	3.0L	Other	1996 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.5L	Other	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	2.5L	Other	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.5L	Other	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.5L	Other	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.5L	Other	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	2.5L	Other	2000 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.5L	Other	2000 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2004 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2004 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2004 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2004 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	FFV	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	FFV	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	FFV	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	FFV	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	FFV	2000 MY	PATS(Passive Anti Theft System (PATS))	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	FFV	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	3.0L	FFV	2000 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	FFV	2000 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	2002 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	4.0L	Other	2002 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	Other	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	4.0L	Other	2002 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	2002 MY	RCM(Restraint Control Module)	√	√	√	√	

Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2010 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2010 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2010 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2010 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2010 MY	RCM(Restraint Control Module)	√	√	√		
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2010 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	SP0026
Ranger/Mazda B-Series/Courier	2.3L	OHC	1996 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	OHC	1996 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	OHC	1996 MY	IAB(Integrated Air Bag Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	OHC	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	2.3L	OHC	1996 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2001 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	2001 MY	PATS(Passive Anti Theft System (PATS))	√	√		√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	3.0L	Other	2001 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2001 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2007 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	Other	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	2007 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2007 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Ranger/Mazda B-Series/Courier	3.0L	Other	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	3.0L	Other	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2007 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2007 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2011 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2011 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2011 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2011 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2011 MY	RCM(Restraint Control Module)	√	√	√		

Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2011 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	SP0026
Ranger/Mazda B-Series/Courier	2.5L	Other	1999 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	2.5L	Other	1999 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.5L	Other	1999 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.5L	Other	1999 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.5L	Other	1999 MY	PATS(Passive Anti Theft System (PATS))	√	√			
Ranger/Mazda B-Series/Courier	2.5L	Other	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	2.5L	Other	1999 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.5L	Other	1999 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2004 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2004 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2004 MY	IC(Instrument Cluster)	√	√	√		
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2004 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2009 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2009 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2009 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2009 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2009 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2009 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2009 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	SP0026
Ranger/Mazda B-Series/Courier	3.0L	Other	2002 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	Other	2002 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	3.0L	Other	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	3.0L	Other	2002 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2002 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	1997 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	1997 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	4.0L	Other	1998 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	4.0L	Other	1998 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	Other	1998 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	Other	1998 MY	IAB(Integrated Air Bag Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	4.0L	Other	1998 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1996 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1996 MY	GEM(Generic Electronic Module)	√	√	√	√	

Ranger/Mazda B-Series/Courier	4.0L	Other	1996 MY	IAB(Integrated Air Bag Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	4.0L	Other	1996 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2008 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2008 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	Other	2008 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Ranger/Mazda B-Series/Courier	3.0L	Other	2008 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2008 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Ranger/Mazda B-Series/Courier	3.0L	Other	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	3.0L	Other	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2008 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2008 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2003 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	Other	2003 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	3.0L	Other	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	3.0L	Other	2003 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2003 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2004 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	Other	2004 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	2004 MY	IC(Instrument Cluster)	√	√	√		
Ranger/Mazda B-Series/Courier	3.0L	Other	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	3.0L	Other	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	3.0L	Other	2004 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	FFV	1999 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	FFV	1999 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	FFV	1999 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	FFV	1999 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	FFV	1999 MY	PATS(Passive Anti Theft System (PATS))	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	FFV	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	3.0L	FFV	1999 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	FFV	1999 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2008 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2008 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2008 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2008 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2008 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2008 MY	RCM(Restraint Control Module)	√	√	√	√	

Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2008 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	SP0026
Ranger/Mazda B-Series/Courier	2.3L	Other	1996 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	1996 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	1996 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	4.0L	Other	2001 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	4.0L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	Other	2001 MY	PATS(Passive Anti Theft System (PATS))	√	√		√	
Ranger/Mazda B-Series/Courier	4.0L	Other	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	4.0L	Other	2001 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	2001 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1995 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Ranger/Mazda B-Series/Courier	3.0L	Other	1995 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1995 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	3.0L	Other	1995 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2008 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2008 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2008 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2008 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2008 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2008 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2008 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	SP0026
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2006 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2006 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2006 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2006 MY	RCM(Restraint Control Module)	√	√	√	√	SP0014
Ranger/Mazda B-Series/Courier	2.3L	Other	2002 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	2.3L	Other	2002 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.3L	Other	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	2.3L	Other	2002 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	2002 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1995 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Ranger/Mazda B-Series/Courier	4.0L	Other	1995 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1995 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001

Ranger/Mazda B-Series/Courier	4.0L	Other	1995 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2005 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	Other	2005 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	2005 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2005 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2005 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	3.0L	Other	2005 MY	RCM(Restraint Control Module)	√	√	√	√	SP0014
Ranger/Mazda B-Series/Courier	3.0L	Other	2005 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2006 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2006 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2006 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2006 MY	RCM(Restraint Control Module)	√	√	√	√	SP0014
Ranger/Mazda B-Series/Courier	3.0L	Other	1997 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1997 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1997 MY	IAB(Integrated Air Bag Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	3.0L	Other	1997 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	4.0L	Other	1999 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	Other	1999 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	Other	1999 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	Other	1999 MY	PATS(Passive Anti Theft System (PATS))	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	4.0L	Other	1999 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1999 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	Other	Other	2004 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	Other	Other	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	Other	Other	2004 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	Other	Other	2004 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	Other	Other	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	Other	Other	2004 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2011 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2011 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2011 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2011 MY	OCSM(Occupant Classification System Module)	√	√	√	√	SP0014
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2011 MY	RCM(Restraint Control Module)	√	√	√	√	

Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2011 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	SP0026
Ranger/Mazda B-Series/Courier	2.5L	Other	1998 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	2.5L	Other	1998 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.5L	Other	1998 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.5L	Other	1998 MY	IAB(Integrated Air Bag Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.5L	Other	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	2.5L	Other	1998 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	2001 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	2.3L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.3L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.3L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.3L	Other	2001 MY	PATS(Passive Anti Theft System (PATS))	√	√		√	
Ranger/Mazda B-Series/Courier	2.3L	Other	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	2.3L	Other	2001 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	2001 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1999 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	Other	1999 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	1999 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	1999 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	3.0L	Other	1999 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1999 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2010 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0022
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2010 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2010 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2010 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2010 MY	RCM(Restraint Control Module)	√	√	√		
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2010 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	SP0026
Ranger/Mazda B-Series/Courier	3.0L	Other	2006 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	Other	2006 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	2006 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	3.0L	Other	2006 MY	RCM(Restraint Control Module)	√	√	√	√	SP0014
Ranger/Mazda B-Series/Courier	3.0L	Other	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	Other	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003

Ranger/Mazda B-Series/Courier	3.0L	Other	2000 MY	PATS(Passive Anti Theft System (PATS))	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	3.0L	Other	2000 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	2000 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2005 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2005 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2005 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2005 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2005 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2005 MY	RCM(Restraint Control Module)	√	√	√	√	SP0014
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2005 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	2003 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	2.3L	Other	2003 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.3L	Other	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	2.3L	Other	2003 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	Other	2003 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	4.0L	Other	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	Other	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	Other	2000 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	Other	2000 MY	PATS(Passive Anti Theft System (PATS))	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	4.0L	Other	2000 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	2000 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1998 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	3.0L	Other	1998 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	1998 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	3.0L	Other	1998 MY	IAB(Integrated Air Bag Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	3.0L	Other	1998 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	3.0L	Other	1998 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.8L	Other	2001 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.8L	Other	2001 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.8L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.8L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.8L	Other	2001 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.8L	Other	2001 MY	PATS(Passive Anti Theft System (PATS))	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.8L	Other	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.8L	Other	2001 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.8L	Other	2001 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1997 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1997 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1997 MY	IAB(Integrated Air Bag Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	Other	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001

Ranger/Mazda B-Series/Courier	4.0L	Other	1997 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	OHC	1995 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Ranger/Mazda B-Series/Courier	2.3L	OHC	1995 MY	GEM(Generic Electronic Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	OHC	1995 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Courier	2.3L	OHC	1995 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2003 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2003 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2003 MY	RAP(Remote Anti-Theft/Personality Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2003 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2009 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2009 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2009 MY	GEM / SJB(Generic Electronic Module/Smart Junction Box)	√	√	√	√	SP0027
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2009 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2009 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2009 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	4.0L	V6 SOHC	2009 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	SP0026
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2007 MY	4X4(4X4 Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	SP0003
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2007 MY	IC(Instrument Cluster)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2007 MY	OCSM(Occupant Classification System Module)	√	√	√		SP0014
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001,SP0004,SP0005,SP0006
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2007 MY	RCM(Restraint Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Courier	2.3L	DURATEC-HE/I4	2007 MY	SDARS(Satellite Digital Audio Receiver System)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2020 (MY)	TBM(Tracking And Blocking Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	ABS(Antilock Braking System)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	ACM(Audio Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	APIM(Accessory Protocol Interface Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	ATCM(All Terrain Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	BCM#1(Body Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	BCM#1(Body Control Module)	√	√	√		

Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	C-CM(Cruise-Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	DDM(Driver Front Door Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	FCIM(Controls Interface Module - Front)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	GPSM(Global Positioning System Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	GWM(Gateway Module A)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	HCM(Headlamp Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	HUD(Head Up Display)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	IPC(Instrument Panel Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	IPC(Instrument Panel Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	IPC(Instrument Panel Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	IPM-A(Image Processing Module A)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	PAM(Parking Aid Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	PCM(Powertrain Control Module (PCM))	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	PDM(Passenger Front Door Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	PSCM(Power Steering Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	RCM(Restraint Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	RDCM#1(Reductant Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	RGTM(Rear Gate/Trunk Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	RTM(Radio Transceiver Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	SCCM(Steering Column Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	SOD-L(Side Obstacle Detection Control Module - Left)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	SOD-R(Side Obstacle Detection Control Module - Right)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	TBM(Tracking And Blocking Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	TCU#1(Telematic Control Unit Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	TRM(Trailer Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	ABS(Antilock Braking System)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	ACM(Audio Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	APIM(Accessory Protocol Interface Module)	√	√	√	√	

Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	ATCM(All Terrain Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	BCM#1(Body Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	BCM#1(Body Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	C-CM(Cruise-Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	DDM(Driver Front Door Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	FCIM(Controls Interface Module - Front)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	GPSM(Global Positioning System Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	GWM(Gateway Module A)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	HCM(Headlamp Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	HUD(Head Up Display)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	IPM-A(Image Processing Module A)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	PAM(Parking Aid Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	PDM(Passenger Front Door Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	PSCM(Power Steering Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	RCM(Restraint Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	RGTM(Rear Gate/Trunk Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	RTM(Radio Transceiver Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	SCCM(Steering Column Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	SOD-L(Side Obstacle Detection Control Module - Left)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	SOD-R(Side Obstacle Detection Control Module - Right)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	TBM(Tracking And Blocking Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	TCU#1(Telematic Control Unit Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	IVCT	2015 MY	TRM(Trailer Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ACM(Audio Control Module)	√	√			
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	BCMii(Body Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	DDM(Driver Front Door Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	PAM(Parking Aid Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	PDM(Passenger Front Door Module)	√	√	√	√	

Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	RCM(Restraint Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	SRM(Speech Recognition Module)	√	√	√		
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	TBM(Tracking And Blocking Module)	√	√			
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	TCM(Transmission Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	TRM(Trailer Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0012,SP0060
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0012
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0012,SP0060
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	ACM(Audio Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	BCMii(Body Control Module)	√	√	√	√	SP0064
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	DDM(Driver Front Door Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	PAM(Parking Aid Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0001
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	PDM(Passenger Front Door Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	RCM(Restraint Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	SRM(Speech Recognition Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	TBM(Tracking And Blocking Module)	√	√			SP0061,SP0062,SP0063
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	TCM(Transmission Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.5L	DURATEC-HE/I4	2011 MY	TRM(Trailer Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	ABS(Antilock Braking System)	√	√	√		
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	APIM(Accessory Protocol Interface Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	BCM#1(Body Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	DDM(Driver Front Door Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	FCDIM(Control/Display Interface Module - Front)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	FCIM(Controls Interface Module - Front)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	GPSM(Global Positioning System Module)	√	√			

Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	GWM(Gateway Module A)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	HCM(Headlamp Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	HUD(Head Up Display)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	IPC(Instrument Panel Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	IPM-A(Image Processing Module A)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	PAM(Parking Aid Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	PCM(Powertrain Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	PDM(Passenger Front Door Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	PSCM(Power Steering Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	RCM(Restraint Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	RDCM#1(Reductant Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	RGTM(Rear Gate/Trunk Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	RTM(Radio Transceiver Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	SCCM(Steering Column Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	TBM(Tracking And Blocking Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	TCU#1(Telematic Control Unit Module)	√	√			
Ranger/Mazda B-Series/Troller	2.3L	Ecoboost - Gas Turbocharged Direct Injection	2019 (MY)	TRM(Trailer Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	ABS(Antilock Braking System)	√	√	√		
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	APIM(Accessory Protocol Interface Module)	√	√			

Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	BCM#1(Body Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	DDM(Driver Front Door Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	FCDIM(Control/Display Interface Module - Front)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	FCIM(Controls Interface Module - Front)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	GPSM(Global Positioning System Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	GWM(Gateway Module A)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	HCM(Headlamp Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	HUD(Head Up Display)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	IPC(Instrument Panel Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	IPM-A(Image Processing Module A)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	PAM(Parking Aid Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	PCM(Powertrain Control Module (PCM))	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	PDM(Passenger Front Door Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	PSCM(Power Steering Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	RCM(Restraint Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	RCM(Restraint Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	RDCM#1(Reductant Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	RGTM(Rear Gate/Trunk Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	RTM(Radio Transceiver Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	SCCM(Steering Column Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	TBM(Tracking And Blocking Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	TCM(Transmission Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	TCU#1(Telematic Control Unit Module)	√	√			
Ranger/Mazda B-Series/Troller	2.0L	Duratorq Turbo Diesel Common Rail Injection	2018 (MY)	TRM(Trailer Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0060
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0060
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	ACM(Audio Control Module)	√	√			

Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	BCMii(Body Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	DDM(Driver Front Door Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC))	√	√	√	√	
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	PAM(Parking Aid Module)	√	√	√		
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	PDM(Passenger Front Door Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	RCM(Restraint Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	SRM(Speech Recognition Module)	√	√	√		
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	TBM(Tracking And Blocking Module)	√	√			SP0061,SP0062,SP0063
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	TCM(Transmission Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	Other	Other	2011 MY	TRM(Trailer Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	ABS(Antilock Braking System)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	ACM(Audio Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	APIM(Accessory Protocol Interface Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	ATCM(All Terrain Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	BCM#1(Body Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	BCM#1(Body Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	C-CM(Cruise-Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	DDM(Driver Front Door Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	FCIM(Controls Interface Module - Front)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	GPSM(Global Positioning System Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	GWM(Gateway Module A)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	HCM(Headlamp Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	HUD(Head Up Display)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	IPC(Instrument Panel Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	IPC(Instrument Panel Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	IPC(Instrument Panel Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	IPM-A(Image Processing Module A)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	PAM(Parking Aid Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	PCM(Powertrain Control Module (PCM))	√	√	√		

Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	PDM(Passenger Front Door Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	PSCM(Power Steering Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	RCM(Restraint Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	RDCM#1(Reductant Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	RGTM(Rear Gate/Trunk Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	RTM(Radio Transceiver Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	SCCM(Steering Column Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	SOD-L(Side Obstacle Detection Control Module - Left)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	SOD-R(Side Obstacle Detection Control Module - Right)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	TBM(Tracking And Blocking Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	TCU#1(Telematic Control Unit Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2015 MY	TRM(Trailer Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0012,SP0060
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0012
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0002,SP0012,SP0060
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ACM(Audio Control Module)	√	√			
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	BCMii(Body Control Module)	√	√	√	√	SP0064
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	DDM(Driver Front Door Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	FCDIM(Control/Display Interface Module - Front)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	HVAC(Heating Ventilating And Air Conditioning (HVAC)),	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	IPC(Instrument Panel Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	PAM(Parking Aid Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	SP0038,SP0039,SP0040,SP0065,SP0043,SP0 044,SP0066,SP0067,SP0068,SP0069,SP0055
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	PDM(Passenger Front Door Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	RCM(Restraint Control Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	SRM(Speech Recognition Module)	√	√	√		
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	TBM(Tracking And Blocking Module)	√	√			SP0061,SP0062,SP0063

Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	TCM(Transmission Control Module)	√	√	√	√	
Ranger/Mazda B-Series/Troller	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	TRM(Trailer Module)	√	√	√		
ROADSTER/MX-5	1.6L	B6	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
ROADSTER/MX-5	1.6L	B6	2000 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
ROADSTER/MX-5	1.8L	Barometric Pressure (BP) Turbo	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
ROADSTER/MX-5	1.8L	Barometric Pressure (BP) Turbo	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
ROADSTER/MX-5	1.8L	BP	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
ROADSTER/MX-5	1.8L	BP	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
ROADSTER/MX-5	1.6L	B6	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
ROADSTER/MX-5	1.6L	B6	1997 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
ROADSTER/MX-5	1.8L	BP	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
ROADSTER/MX-5	1.8L	BP	1997 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
ROADSTER/MX-5	1.8L	BP	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
ROADSTER/MX-5	1.8L	BP	2000 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
ROADSTER/MX-5	1.6L	B6	2002 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
ROADSTER/MX-5	1.6L	B6	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2008 MY	DHS(Deployable Hood System)	√	√	√		
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2008 MY	IC(Instrument Cluster)	√	√	√		
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2008 MY	RCM(Restraint Control Module)	√	√	√		
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2008 MY	RHT(Retractable Hard Top)	√	√	√		
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2008 MY	RKE(Remote Keyless Entry)	√	√	√	√	
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2005 MY	DHS(Deployable Hood System)	√	√	√		
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2005 MY	IC(Instrument Cluster)	√	√	√		
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2005 MY	RCM(Restraint Control Module)	√	√	√		
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2005 MY	RHT(Retractable Hard Top)	√	√	√		
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2005 MY	RKE(Remote Keyless Entry)	√	√	√	√	
ROADSTER/MX-5 (Japan/General Specifications)	2.0L	LF	2005 MY	TCM(Transmission Control Module)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	High-Power 13B-MSP	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	High-Power 13B-MSP	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	High-Power 13B-MSP	2003 MY	EPS(Electronic Controlled Power Steering)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	High-Power 13B-MSP	2003 MY	IC(Instrument Cluster)	√	√	√		
RX-8 (Europe/General/Japan Specifications)	654x2cc	High-Power 13B-MSP	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	High-Power 13B-MSP	2003 MY	RCM(Restraint Control Module)	√	√	√		
RX-8 (Europe/General/Japan Specifications)	654x2cc	High-Power 13B-MSP	2003 MY	RKE(Remote Keyless Entry)	√	√	√	√	

RX-8 (Europe/General/Japan Specifications)	654x2cc	High-Power 13B-MSP	2003 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	High-Power 13B-MSP	2003 MY	SASM(Steering Angle Sensor Module)	√	√			
RX-8 (Europe/General/Japan Specifications)	654x2cc	High-Power 13B-MSP	2003 MY	TCM(Transmission Control Module)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	Standard Power Of 13B-MSP	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	Standard Power Of 13B-MSP	2003 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	Standard Power Of 13B-MSP	2003 MY	EPS(Electronic Controlled Power Steering)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	Standard Power Of 13B-MSP	2003 MY	IC(Instrument Cluster)	√	√	√		
RX-8 (Europe/General/Japan Specifications)	654x2cc	Standard Power Of 13B-MSP	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	Standard Power Of 13B-MSP	2003 MY	RCM(Restraint Control Module)	√	√	√		
RX-8 (Europe/General/Japan Specifications)	654x2cc	Standard Power Of 13B-MSP	2003 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	Standard Power Of 13B-MSP	2003 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	Standard Power Of 13B-MSP	2003 MY	SASM(Steering Angle Sensor Module)	√	√			
RX-8 (Europe/General/Japan Specifications)	654x2cc	Standard Power Of 13B-MSP	2003 MY	TCM(Transmission Control Module)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	13B	2008 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
RX-8 (Europe/General/Japan Specifications)	654x2cc	13B	2008 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	13B	2008 MY	EPS(Electronic Controlled Power Steering)	√	√	√	√	SP0010
RX-8 (Europe/General/Japan Specifications)	654x2cc	13B	2008 MY	IC(Instrument Cluster)	√	√	√		
RX-8 (Europe/General/Japan Specifications)	654x2cc	13B	2008 MY	LCM(Lighting Control Module)	√	√			
RX-8 (Europe/General/Japan Specifications)	654x2cc	13B	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	13B	2008 MY	RCM(Restraint Control Module)	√	√	√		
RX-8 (Europe/General/Japan Specifications)	654x2cc	13B	2008 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	13B	2008 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (Europe/General/Japan Specifications)	654x2cc	13B	2008 MY	SASM(Steering Angle Sensor Module)	√	√			
RX-8 (Europe/General/Japan Specifications)	654x2cc	13B	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2004 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2004 MY	IC(Instrument Cluster)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2004 MY	PCM(Powertrain Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2004 MY	RCM(Restraint Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2004 MY	RKE(Remote Keyless Entry)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2004 MY	SASM(Steering Angle Sensor Module)	√	√			
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2004 MY	TCM(Transmission Control Module)	√	√	√		

RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2004 MY	TPM(Tire Pressure Monitor)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2005 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2005 MY	IC(Instrument Cluster)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2005 MY	PCM(Powertrain Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2005 MY	RCM(Restraint Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2005 MY	RKE(Remote Keyless Entry)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2005 MY	SASM(Steering Angle Sensor Module)	√	√			
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2005 MY	TPM(Tire Pressure Monitor)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2008 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2008 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2008 MY	EPS(Electronic Controlled Power Steering)	√	√	√	√	SP0010
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2008 MY	IC(Instrument Cluster)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2008 MY	PCM(Powertrain Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2008 MY	RCM(Restraint Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2008 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2008 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2008 MY	SASM(Steering Angle Sensor Module)	√	√			
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2008 MY	TCM(Transmission Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2008 MY	TPM(Tire Pressure Monitor)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2005 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2005 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2005 MY	IC(Instrument Cluster)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2005 MY	PCM(Powertrain Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2005 MY	RCM(Restraint Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2005 MY	RKE(Remote Keyless Entry)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2005 MY	SASM(Steering Angle Sensor Module)	√	√			
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2005 MY	TCM(Transmission Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	Standard Power Of 13B-MSP	2005 MY	TPM(Tire Pressure Monitor)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2007 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2007 MY	EPS(Electronic Controlled Power Steering)	√	√	√	√	SP0010
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2007 MY	IC(Instrument Cluster)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	

RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2007 MY	RCM(Restraint Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2007 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2007 MY	SASM(Steering Angle Sensor Module)	√	√			
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2007 MY	TCM(Transmission Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2007 MY	TPM(Tire Pressure Monitor)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2004 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2004 MY	EPS(Electronic Controlled Power Steering)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2004 MY	IC(Instrument Cluster)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2004 MY	PCM(Powertrain Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2004 MY	RCM(Restraint Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2004 MY	RKE(Remote Keyless Entry)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2004 MY	SASM(Steering Angle Sensor Module)	√	√			
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2004 MY	TPM(Tire Pressure Monitor)	√	√	√		
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	EPS(Electronic Controlled Power Steering)	√	√	√	√	SP0010
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	IC(Instrument Cluster)	√	√	√		
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	LCM(Lighting Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	PCM(Powertrain Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	RCM(Restraint Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	SASM(Steering Angle Sensor Module)	√	√			
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	TCM(Transmission Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2009 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	SP0012
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	EPS(Electronic Controlled Power Steering)	√	√	√	√	SP0010
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	IC(Instrument Cluster)	√	√	√		
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	LCM(Lighting Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	PCM(Powertrain Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	RCM(Restraint Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	SASM(Steering Angle Sensor Module)	√	√			
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	TCM(Transmission Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	13B	2010 MY	TPM(Tire Pressure Monitor)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	

RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2006 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2006 MY	EPS(Electronic Controlled Power Steering)	√	√	√	√	SP0010
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2006 MY	IC(Instrument Cluster)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2006 MY	PCM(Powertrain Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2006 MY	RCM(Restraint Control Module)	√	√	√		
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2006 MY	RKE(Remote Keyless Entry)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2006 MY	SASM(Steering Angle Sensor Module)	√	√			
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2006 MY	TCM(Transmission Control Module)	√	√	√	√	
RX-8 (North America Specifications)	654x2cc	High-Power 13B-MSP	2006 MY	TPM(Tire Pressure Monitor)	√	√	√		
Scrum	660cc	F6A-T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Scrum	660cc	F6A-T	Other	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	F6A-T	Other	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	F6A-T	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
Scrum	660cc	F6A-T	Other	TCM(Transmission Control Module)	√	√	√		
Scrum	660cc	K6A-T	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Scrum	660cc	K6A-T	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	K6A-T	2001 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
Scrum	660cc	K6A-T	2001 MY	TCM(Transmission Control Module)	√	√	√		
Scrum	660cc	K6A	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Scrum	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	K6A	2005 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
Scrum	660cc	K6A	2001 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Scrum	660cc	K6A	2001 MY	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	K6A	2001 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
Scrum	660cc	F6A	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Scrum	660cc	F6A	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	F6A	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	F6A	1999 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
Scrum	660cc	F6A-T	1999 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Scrum	660cc	F6A-T	1999 MY	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	F6A-T	1999 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
Scrum	660cc	F6A-T	1999 MY	TCM(Transmission Control Module)	√	√	√		
Scrum	660cc	K6A-T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Scrum	660cc	K6A-T	Other	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	K6A-T	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
Scrum	660cc	K6A-T	Other	TCM(Transmission Control Module)	√	√	√		

Scrum	660cc	F6A	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Scrum	660cc	F6A	Other	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	F6A	Other	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	F6A	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
Scrum	660cc	K6A	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
Scrum	660cc	K6A	Other	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	K6A	Other	PCM(Powertrain Control Module)	√	√	√	√	
Scrum	660cc	K6A	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
SCRUM (2003/9 -)	660cc	K6A-T	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
SCRUM (2003/9 -)	660cc	K6A-T	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
SCRUM (2003/9 -)	660cc	K6A-T	2003 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
SCRUM (2003/9 -)	660cc	K6A-T	2003 MY	TCM(Transmission Control Module)	√	√	√		
SCRUM (2003/9 -)	660cc	K6A	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
SCRUM (2003/9 -)	660cc	K6A	Other	PCM(Powertrain Control Module)	√	√			
SCRUM (2003/9 -)	660cc	K6A	Other	PCM(Powertrain Control Module)	√	√			
SCRUM (2003/9 -)	660cc	K6A	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√			
SCRUM (2003/9 -)	660cc	K6A	2003 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
SCRUM (2003/9 -)	660cc	K6A	2003 MY	PCM(Powertrain Control Module)	√	√	√	√	
SCRUM (2003/9 -)	660cc	K6A	2003 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
SCRUM (2003/9 -)	660cc	K6A-T	Other	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
SCRUM (2003/9 -)	660cc	K6A-T	Other	PCM(Powertrain Control Module)	√	√			
SCRUM (2003/9 -)	660cc	K6A-T	Other	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√			
SCRUM (2003/9 -)	660cc	K6A-T	Other	TCM(Transmission Control Module)	√	√			
SCRUM (2005/9) DG64V/DG64W	660cc	K6A-T	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
SCRUM (2005/9) DG64V/DG64W	660cc	K6A-T	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
SCRUM (2005/9) DG64V/DG64W	660cc	K6A-T	2005 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
SCRUM (2005/9) DG64V/DG64W	660cc	K6A	2005 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√		
SCRUM (2005/9) DG64V/DG64W	660cc	K6A	2005 MY	PCM(Powertrain Control Module)	√	√	√	√	
SCRUM (2005/9) DG64V/DG64W	660cc	K6A	2005 MY	RCM(Restraint Control Module (For Use With Vehicle System Test Manual))	√	√	√		
Sentia	3.0L	JE HO	1997 MY	4WS(4 Wheel Steering)	√	√			
Sentia	3.0L	JE HO	1997 MY	A/C(Air Conditioning)	√	√			
Sentia	3.0L	JE HO	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
Sentia	3.0L	JE HO	1997 MY	CCM(Cruise Control)	√	√			
Sentia	3.0L	JE HO	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
Sentia	3.0L	JE	1997 MY	4WS(4 Wheel Steering)	√	√			
Sentia	3.0L	JE	1997 MY	A/C(Air Conditioning)	√	√			

Sentia	3.0L	JE	1997 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
Sentia	3.0L	JE	1997 MY	CCM(Cruise Control)	√	√			
Sentia	3.0L	JE	1997 MY	PCM(Powertrain Control Module)	√	√	√	√	
Titan	4.0L	TF	2002 MY	PCM(Powertrain Control Module)	√	√	√		
Titan	4.0L	TF	2000 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
TITAN (Isuzu OEM)	4.3L	4HF1 Compressed Natural Gas (CNG)	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN (Isuzu OEM)	4.8L	4HL1 T	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN (Isuzu OEM)	4.8L	4HL1 T	2004 MY	TCM(Transmission Control Module)	√	√	√		
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2011 MY	ABS(Antilock Braking System)	√	√	√	√	
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2011 MY	GEM(Generic Electronic Module)	√	√	√	√	
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2011 MY	GEM(Generic Electronic Module)	√	√	√	√	
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2011 MY	ISS/HSA(Start And Stop Of Idling/Aid Hill Start)	√	√	√		
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2011 MY	ISS/HSA(Start And Stop Of Idling/Aid Hill Start)	√	√	√		
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2011 MY	RCM(Restraint Control Module)	√	√	√		
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2011 MY	RCM(Restraint Control Module)	√	√	√		
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2011 MY	RCM(Restraint Control Module)	√	√	√		
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2011 MY	TCM(Transmission Control Module)	√	√	√		
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2007 MY	ABS(Antilock Braking System)	√	√	√	√	
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2007 MY	RCM(Restraint Control Module)	√	√	√		
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2007 MY	TCM(Transmission Control Module)	√	√	√		
TITAN (Isuzu OEM)	4.8L	4HL1	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN (Isuzu OEM)	4.8L	4HL1	2004 MY	TCM(Transmission Control Module)	√	√	√		
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN (Isuzu OEM)	4.6L	4HV1 Compressed Natural Gas (CNG)	2004 MY	TCM(Transmission Control Module)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2014 MY	ISS/HSA(Start And Stop Of Idling/Aid Hill Start)	√	√			
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2014 MY	RCM(Restraint Control Module)	√	√			
TITAN (Isuzu OEM)	5.2L	4HK1 T	2007 MY	ABS(Antilock Braking System)	√	√	√	√	
TITAN (Isuzu OEM)	5.2L	4HK1 T	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
TITAN (Isuzu OEM)	5.2L	4HK1 T	2007 MY	PATS(Passive Anti Theft System (PATS))	√	√	√		
TITAN (Isuzu OEM)	5.2L	4HK1 T	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN (Isuzu OEM)	5.2L	4HK1 T	2007 MY	RCM(Restraint Control Module)	√	√	√		

TITAN (Isuzu OEM)	5.2L	4HK1 T	2007 MY	TCM(Transmission Control Module)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JZ1 T	2018 (MY)	ABS(Antilock Braking System)	√	√	√	√	
TITAN (Isuzu OEM)	3.0L	4JZ1 T	2018 (MY)	EDU(Electronic Driver Unit)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JZ1 T	2018 (MY)	GEM(Generic Electronic Module)	√	√	√	√	
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 (MY)	ISS/HSA(Start And Stop Of Idling/Aid Hill Start)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JZ1 T	2018 (MY)	PCM(Powertrain Control Module (PCM))	√	√	√	√	
TITAN (Isuzu OEM)	3.0L	4JZ1 T	2018 (MY)	RCM(Restraint Control Module)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JZ1 T	2018 (MY)	RKE(Remote Keyless Entry)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 (MY)	SCAM(Stereo Camera)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JZ1_T	2018 (MY)	SCRUCU(Selective Catalytic Reduction Control Unit)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JZ1 T	2018 (MY)	TCM(Transmission Control Module)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2011 MY	ABS(Antilock Braking System)	√	√	√	√	
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2011 MY	GEM(Generic Electronic Module)	√	√	√	√	
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2011 MY	GEM(Generic Electronic Module)	√	√	√	√	
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2011 MY	ISS/HSA(Start And Stop Of Idling/Aid Hill Start)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2011 MY	ISS/HSA(Start And Stop Of Idling/Aid Hill Start)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2011 MY	PATS(Passive Anti Theft System (PATS))	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2011 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2011 MY	RCM(Restraint Control Module)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2011 MY	RCM(Restraint Control Module)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2011 MY	RCM(Restraint Control Module)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2011 MY	TCM(Transmission Control Module)	√	√	√		
TITAN (Isuzu OEM)	3.1L	4JG2	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN (Isuzu OEM)	3.1L	4JG2 Liquefied Petroleum Gas (LPG)	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN (Isuzu OEM)	4.6L	4HG1 Liquefied Petroleum Gas (LPG)	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2007 MY	ABS(Antilock Braking System)	√	√	√	√	
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2007 MY	GEM(Generic Electronic Module)	√	√	√	√	
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2007 MY	PATS(Passive Anti Theft System (PATS))	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2007 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2007 MY	RCM(Restraint Control Module)	√	√	√		
TITAN (Isuzu OEM)	3.0L	4JJ1 T	2007 MY	TCM(Transmission Control Module)	√	√	√		
TITAN DASH	2.5L	WL	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
TITAN DASH	2.5L	WL	2000 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
TITAN DASH	2.5L	WL	2000 MY	TCM(Transmission Control Module)	√	√	√	√	
TITAN DASH	2.0L	FE LPG	2002 MY	PCM(Powertrain Control Module)	√	√	√		
TITAN DASH	2.0L	FE LPG	2002 MY	TCM(Transmission Control Module)	√	√	√	√	
TITAN DASH	2.0L	RF T	2004.5 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN DASH	2.0L	RF T	2004.5 MY	PCM(Powertrain Control Module (PCM))	√	√			
TITAN DASH	2.0L	RF T	2004.5 MY	TCM(Transmission Control Module)	√	√	√	√	
TITAN DASH	2.0L	FE	2002 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN DASH	2.0L	FE	2002 MY	TCM(Transmission Control Module)	√	√	√	√	
TITAN DASH	2.0L	RF T	2004 MY	PCM(Powertrain Control Module)	√	√	√	√	
TITAN DASH	2.0L	RF T	2004 MY	PCM(Powertrain Control Module (PCM))	√	√			
TITAN DASH	2.0L	RF T	2004 MY	TCM(Transmission Control Module)	√	√	√	√	
TITAN DASH	2.0L	FE	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	

TITAN DASH	2.0L	FE	2000 MY	TCM(Transmission Control Module)	√	√	√	√	
VX-1	1.4L	K14B	Other	ABS(Antilock Braking System (ABS))	√	√	√		
VX-1	1.4L	K14B	Other	BCM#1(Body Control Module)	√	√	√	√	
VX-1	1.4L	K14B	Other	EPS(Electronic Controlled Power Steering)	√	√	√		
VX-1	1.4L	K14B	Other	IC(Instrument Cluster)	√	√	√	√	
VX-1	1.4L	K14B	Other	PCM(Powertrain Control Module)	√	√	√	√	
VX-1	1.4L	K14B	Other	RCM(Restraint Control Module)	√	√	√		
XEDOS9	2.3L	KJ	1996 MY	4WS(4 Wheel Steering)	√	√			
XEDOS9	2.3L	KJ	1996 MY	A/C(Air Conditioning)	√	√			
XEDOS9	2.3L	KJ	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
XEDOS9	2.3L	KJ	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
XEDOS9	2.3L	KJ	1996 MY	CCM(Cruise Control)	√	√			
XEDOS9	2.3L	KJ	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
XEDOS9	2.3L	KJ	1998 MY	4WS(4 Wheel Steering)	√	√			
XEDOS9	2.3L	KJ	1998 MY	A/C(Air Conditioning)	√	√			
XEDOS9	2.3L	KJ	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
XEDOS9	2.3L	KJ	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
XEDOS9	2.3L	KJ	1998 MY	CCM(Cruise Control)	√	√			
XEDOS9	2.3L	KJ	1998 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
XEDOS9	2.0L	KF	1996 MY	4WS(4 Wheel Steering)	√	√			
XEDOS9	2.0L	KF	1996 MY	A/C(Air Conditioning)	√	√			
XEDOS9	2.0L	KF	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
XEDOS9	2.0L	KF	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
XEDOS9	2.0L	KF	1996 MY	CCM(Cruise Control)	√	√			
XEDOS9	2.0L	KF	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
XEDOS9	2.5L	KL	1996 MY	4WS(4 Wheel Steering)	√	√			
XEDOS9	2.5L	KL	1996 MY	A/C(Air Conditioning)	√	√			
XEDOS9	2.5L	KL	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
XEDOS9	2.5L	KL	1996 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			
XEDOS9	2.5L	KL	1996 MY	CCM(Cruise Control)	√	√			
XEDOS9	2.5L	KL	1996 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
XEDOS9	2.5L	KL	2000 MY	A/C(Air Conditioning)	√	√			
XEDOS9	2.5L	KL	2000 MY	ABS/TCS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
XEDOS9	2.5L	KL	2000 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
XEDOS9	2.5L	KL	2000 MY	CCM(Cruise Control)	√	√			
XEDOS9	2.5L	KL	2000 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	
XEDOS9	2.5L	KL	2000 MY	PCM(Powertrain Control Module)	√	√	√	√	
XEDOS9	2.5L	KL	1998 MY	4WS(4 Wheel Steering)	√	√			
XEDOS9	2.5L	KL	1998 MY	A/C(Air Conditioning)	√	√			
XEDOS9	2.5L	KL	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√	√	√	
XEDOS9	2.5L	KL	1998 MY	ABS(Anti-Lock Brake/Traction Control Module)	√	√			

XEDOS9	2.5L	KL	1998 MY	CCM(Cruise Control)	√	√			
XEDOS9	2.5L	KL	1998 MY	PCM(Powertrain Control Module (PCM))	√	√	√	√	

XTOOL

Special Functions List

No.	Functions Name	System Name
SP0001	Powertrain Control Module (PCM) Keep Alive Memory (KAM) Reset	PCM(Powertrain Control Module)
SP0002	Service Bleed Of Antilock Braking System (ABS)	ABS/TCS(Anti-Lock Brake/Traction Control Module)
SP0003	Test Of Windshield Wiper	GEM(Generic Electronic Module)
SP0004	Clear Adaptive Tables Of Transmission	PCM(Powertrain Control Module)
SP0005	Adaptive Learning Of Halt Transmission	PCM(Powertrain Control Module)
SP0006	Resume Transmission Adaptive Learning	PCM(Powertrain Control Module)
SP0007	Headlight Zero-Set	LHID(Left High Intensity Discharge Lamp (LHIDL))
SP0008	Reset Data	PCM(Powertrain Control Module)
SP0009	Reset Of Lockout Mode	FFH(Fuel Fired Coolant Heating Module)
SP0010	Setting Of Neutral Position	EPS(Electronic Controlled Power Steering)
SP0011	Auto Shift Manual Transmission (ASM) Service Functions	TCM(Transmission Control Module)
SP0012	Initialization Of Sensor	ABS(Anti-Lock Brake/Traction Control Module)
SP0013	Reset Component/Parameter	PCM(Powertrain Control Module)
SP0014	Reset Of Passenger System	RCM(Restraint Control Module)
SP0015	Learning Of Transmission	PCM(Powertrain Control Module)
SP0016	Check Operation Of Electronic Automatic Temperature Control (EATC)	EATC(Electronic Automatic Temperature Control)
SP0017	Reset Of Rain Sensor	GEM(Generic Electronic Module)
SP0018	Self Test And Prefill Utility Of Fuel Fired Coolant Heating Module (FFH)	FFH(Fuel Fired Coolant Heating Module)
SP0019	Unlock Utility Of Fuel Fired Coolant Heating Module (FFH)	FFH(Fuel Fired Coolant Heating Module)
SP0020	Initialization Of Electronic Throttle Body (ETB)/Exhaust Gas Recirculation (EGR)	PCM(Powertrain Control Module)
SP0021	DPF	PCM(Powertrain Control Module)
SP0022	Initialization Sequence Of Interactive Vehicle Dynamics (IVD)	ABS(Anti-Lock Brake/Traction Control Module)
SP0023	Microphone Test	ACM(Audio Control Module)
SP0024	Walkaround Test Of Audio Speaker	ACM(Audio Control Module)
SP0025	Infotainment Display Test	ACM(Audio Control Module)
SP0026	Tones Test	SDARS(Satellite Digital Audio Receiver System)
SP0027	Tire Pressure Monitoring System	GEM / SJB(Generic Electronic Module/Smart Junction Box)
SP0028	Have The Steering Angle Sensor Configured.	ABS(Anti-Lock Brake/Traction Control Module)
SP0029	Rezero Of Passenger Seat Weight Sensor	OCSM(Occupant Classification System Module)
SP0030	Transmission Control Module (TCM) Keep Alive Memory (KAM) Reset	TCM(Transmission Control Module)
SP0031	Calibration Of Restraint Control Module (RCM)	RCM(Restraint Control Module)

SP0032	Blind Spot Monitoring (BSM) Radar Test	BSML(Left Blind Spot Monitoring)
SP0033	Adaptive Values Resetting	PCM(Powertrain Control Module)
SP0034	Special Ignition ON	RKE(Remote Keyless Entry)
SP0035	Fuel Fired Coolant Heating Module (FFH) Operation Check	FFH(Fuel Fired Coolant Heating Module)
SP0036	Rear Tones Test	APIM(Accessory Protocol Interface Module)
SP0037	Learning Of Neutral Position	TCM(Transmission Control Module)
SP0038	Correction Factors Of Fuel Injector	PCM(Powertrain Control Module)
SP0039	Diesel Particulate Filter Learned Values Reset	PCM(Powertrain Control Module)
SP0040	Exhaust Gas Recirculation Valve Learned Values Reset	PCM(Powertrain Control Module)
SP0041	Have The Exhaust Gas Related Component Initialized	PCM(Powertrain Control Module)
SP0042	Air Conditioning Compressor Learned Values Reset	PCM(Powertrain Control Module)
SP0043	Diesel Particulate Filter Differential Pressure Sensor Learned Values Reset	PCM(Powertrain Control Module)
SP0044	Exhaust Gas Temperature Value Reset	PCM(Powertrain Control Module)
SP0045	Oil Change Indicator Reset	PCM(Powertrain Control Module)
SP0046	Reception Sensitivity Test Of Amplitude Modulation (AM) Antenna	ACU(Audio Control Unit)
SP0047	Fuel Priming Of Fuel Fired Coolant Heating Module (FFH)	FFH(Fuel Fired Coolant Heating Module)
SP0048	Test Of Urea Injector	SCR CU(Selective Catalytic Reduction)
SP0049	Test Of Urea Pump	SCR CU(Selective Catalytic Reduction)
SP0050	Calibration Of Steering Wheel Position Sensor	PSCM(Power Steering Control Module)
SP0051	New Fuel Additive Control Module (FACM)	FACM(Fuel Additive Control Module)
SP0052	Refill The FAT (Fuel Additive Tank).	PCM(Powertrain Control Module)
SP0053	System Prime	PCM(Powertrain Control Module)
SP0054	Dynamic Regeneration Of Diesel Particulate Filter (DPF)	PCM(Powertrain Control Module)
SP0055	High Pressure Fuel System Learned Values Reset	PCM(Powertrain Control Module)
SP0056	ABS	ABS(Antilock Braking System (ABS))
SP0057	Learning Value Clearing	TCM(Transmission Control Module)
SP0058	Setting Of Continuously Variable Transmission (CVT) Learning Value	TCM(Transmission Control Module)
SP0059	Calibration Of Continuously Variable Transmission (CVT) Slope Sensor	TCM(Transmission Control Module)
SP0060	Reset And Configuration Of Antilock Braking System (ABS)	ABS(Anti-Lock Brake/Traction Control Module)
SP0061	Tracking And Blocking Module (TBM) SIM RAV_ID	TBM(Tracking And Blocking Module)
SP0062	Tracking And Blocking Module (TBM) Password Reset	TBM(Tracking And Blocking Module)
SP0063	Tracking And Blocking Module (TBM) Transit Mode	TBM(Tracking And Blocking Module)
SP0064	Reset Battery Monitoring System (BMS)	BCMii(Body Control Module)
SP0065	Intake Air Throttle Valve Learned Values Reset	PCM(Powertrain Control Module)
SP0066	Fuel Injector Learned Values Reset	PCM(Powertrain Control Module)

SP0067	Powertrain Control Module Learned Values Reset	PCM(Powertrain Control Module)
SP0068	Turbocharger Learned Values Reset	PCM(Powertrain Control Module)
SP0069	Water In Fuel Warning Indicator Reset	PCM(Powertrain Control Module)
SP0070	Auto Leveling Sensor	AFS(Adaptive Front Lighting System)
SP0071	Configuration Of Ambient Air Temperature Sensor	PCM(Powertrain Control Module)
SP0072	Calibration Of Seat Weight Sensor (SWS)	RCM(Restraint Control Module)
SP0073	Reader Aiming	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)
SP0074	Initialization Of System	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)
SP0075	Pull Drift Compensation (PDC) Reset	PSCM(Power Steering Control Module)
SP0076	Driver Seat Module	DSM(Driver Front Seat Module)
SP0077	Calibration Of Wiper Motor Module (WMM)	BCM#1(Body Control Module)
SP0078	Automatic Temperature Controller (ATC) Barcode Entry	PCM(Powertrain Control Module)
SP0079	Initialization Of Power Liftgate	RGTM(Rear Gate/Trunk Module)
SP0080	Starter Driving Counter	A-STOP(A-STOP System - No Idling System)
SP0081	Hydraulic Control Test	ABS(Antilock Braking System (ABS))
SP0082	Initial Setting Of Height Sensor	LCM(Lighting Control Module)
SP0083	Initialization Of Slope Sensor	A-STOP(A-STOP System - No Idling System)
SP0084	Maintenance Monitoring Of Engine Oil - Elasticity	PCM(Powertrain Control Module)
SP0085	Oilreturn To Zero Manually	PCM(Powertrain Control Module)
SP0086	Setting Of Oil Change	PCM(Powertrain Control Module)
SP0087	DCM	DCM(Data Communication Module)
SP0088	ABS maintenance deflation	ABS/TCS(Anti-Lock Brake/Traction Control Module)
SP0089	Data reset	PCM(Powertrain Control Module)
SP0090	ETB/EGR	PCM(Powertrain Control Module)
SP0091	Passenger side seat reset sensor is reset to zero	RCM(Restraint Control Module)
SP0092	EPS Neutral position setting	EPS(Electronic Controlled Power Steering)
SP0093	Reset KAM PCM	PCM(Powertrain Control Module)
SP0094	Initialize	PCM(Powertrain Control Module)
SP0095	SCR function	SCRUCU(Selective Catalytic Reduction Control Unit)
SP0096	TPMS (tire pressure monitoring system) reset	ABS(Anti-Lock Brake/Traction Control Module)
SP0097	TPMS Features	IC(Instrument Cluster)
SP0098	Tire Pressure Monitoring System (TPMS) Reset	ABS(Anti-Lock Brake/Traction Control Module)